More software and hardware on: www.tools4car.com

JLR SDD Calibration Files (VBF) - Compatibility List

HOW TO USE THIS LIST

Selecting and copying text is disabled. The only way to search is CTRL + F: press CTRL + F and type the file name shown by SDD during programming (e.g. GX73-12K532-FBC). If the name is listed here, the file is included in the set. Vehicle line is indicative: it is taken from the file header or deduced from the file name prefix. Always check VIN, model, year, engine and equipment before programming. Never use files made for a different model or year.
Type: EXE = application software, DATA = calibration / parameters, SBL = secondary bootloader, SIGCFG = signal configuration, CARCFG = car configuration. Total files in the set: 25,535.

File name	Vehicle line (indicative)	Module (ECU)	Type
5H22-14C027-AA.vbf	Discovery 3/4 (L319)	SRS Airbag	SBL
5H22-14C047-BA.vbf	Discovery 3/4 (L319)	ACM - Low line head Unit / Integrated MOST head unit	SBL
5H22-14C084-AA.vbf	Discovery 3/4 (L319)	FLCM - Headlamp Leveling/AFS	EXE
5H22-14C087-AA.vbf	Discovery 3/4 (L319)	FLCM - Headlamp Leveling/AFS	SBL
5H22-14C098-BA.vbf	Discovery 3/4 (L319)	RCM - Restraints Control Module	DATA
5H22-14C273-TB.vbf	Discovery 3/4 (L319)	PCM - Powertrain Control Module	SBL
5H22-14C635-HA.vbf	Discovery 3/4 (L319)	RCM - Restraints Control Module	DATA
5H22-14C635-JA.vbf	Discovery 3/4 (L319)	RCM - Restraints Control Module	DATA
5H22-14D396-AA.vbf	Discovery 3/4 (L319)	RLCM - Air Suspension	SBL
5H22-7J104-AA.vbf	Discovery 3/4 (L319)	TCM - Transmission Control Module	EXE
5H22-7J105-AA.vbf	Discovery 3/4 (L319)	TCM - Transmission Control Module	DATA
5H22-7J105-CA.vbf	Discovery 3/4 (L319)	TCM - Transmission Control Module	DATA
5H32-14C098-AA.vbf	Range Rover Sport I (L320)	SRS Airbag	DATA
5H32-7J105-AA.vbf	Range Rover Sport I (L320)	TCM - Transmission Control Module	DATA
5H42-14C527-AB.vbf	Range Rover III (L322)	AAM - Audio Amplifier Module	DATA
5U72-14C098-AA.vbf	Not specified	RCM - Restraints Control Module	DATA
5U72-14C635-AA.vbf	Discovery 3/4 (L319)	SRS Airbag	DATA
5U72-14C635-BA.vbf	Discovery 3/4 (L319)	SRS Airbag	DATA
5U72-14C635-CA.vbf	Discovery 3/4 (L319)	SRS Airbag	DATA
5U72-14C635-DA.vbf	Discovery 3/4 (L319)	SRS Airbag	DATA
5U72-14C635-EA.vbf	Not specified	SRS Airbag	DATA
5U72-14C635-FA.vbf	Discovery 3/4 (L319)	SRS Airbag	DATA
5W93-14C039-AC.VBF	Jaguar XJ (X351)	ABS - Anit-Lock Brake System (ABS) Control Module	SBL
6G91-14C107-AC.VBF	Not specified	RFA - Remote Function Actuator	SBL
6G92-14C090-AL.vbf	Freelander 2 (L359)	PAM - Parking Assist Control Module	EXE
6G92-14C093-AC.VBF	Not specified	PAM - Parking Assist Control Module	SBL
6G92-14C377-BB.VBF	Freelander 2 (L359)	PAM - Parking Assist Control Module	SIGCFG
6G9N-14C044-AG.VBF	Not specified	ICM/IGM Infotainment Control/Gateway Module	EXE
6G9N-14C047-AF.VBF	Not specified	ICM/IGM Infotainment Control/Gateway Module	SBL
6G9N-14C083-AB.VBF	Not specified	AHCM - Auxiliary Heater Control Module	SBL
6G9N-14C280-AB.VBF	Not specified	TRM - Trailer Module	EXE
6G9N-14C282-AA.VBF	Not specified	DMY Dummy, Not initialised ECU	SBL
6G9N-14C405-BA.VBF	Not specified	TRM - Trailer Module	SIGCFG
6G9N-14C554-AP.VBF	Not specified	ICM/IGM - Infotainment Control/Gateway Module	EXE
6G9N-14C555-BK.VBF	Not specified	ICM/IGM - Infotainment Control/Gateway Module	DATA
6G9N-14C555-CK.VBF	Not specified	ICM/IGM - Infotainment Control/Gateway Module	DATA
6G9N-14C556-AH.VBF	Not specified	ICM/IGM - Infotainment Control/Gateway Module	SBL
6G9N-4C044-AB.VBF	Not specified	DEM Differential Electronic Module	SBL
6G9T-14C094-KN.VBF	Freelander 2 (L359)	BCM - Body Control Module	EXE
6G9T-14C095-KH.VBF	Freelander 2 (L359)	BCM - Body Control Module	DATA
6G9T-14C097-AD.VBF	Freelander 2 (L359)	BCM - Body Control Module	SBL
6G9T-14C403-KF.VBF	Freelander 2 (L359)	CEM - Central Electronic Module	SIGCFG
6H22-14C204-AJF.vbf	Range Rover III (L322)	ECM - Engine Control Module	EXE
6H22-14C204-AKF.vbf	Range Rover III (L322)	ECM - Engine Control Module	EXE
6H22-14C204-ALF.vbf	Range Rover III (L322)	ECM - Engine Control Module	EXE
6H22-14D394-AC.vbf	Discovery 3/4 (L319)	RLCM - Air Suspension	EXE
6H22-14D394-CC.vbf	Discovery 3/4 (L319)	RLCM - Air Suspension	EXE
6H22-7J104-AB.vbf	Discovery 3/4 (L319)	TCM - Transmission Control Module	EXE
6H22-7J104-BB.vbf	Discovery 3/4 (L319)	TCM - Transmission Control Module	EXE
6H22-7J104-CB.vbf	Discovery 3/4 (L319)	TCM - Transmission Control Module	EXE
6H22-7J105-BB.vbf	Discovery 3/4 (L319)	TCM - Transmission Control Module	DATA
6H22-7J105-CD.vbf	Discovery 3/4 (L319)	TCM - Transmission Control Module	DATA
6H22-7J105-FB.vbf	Discovery 3/4 (L319)	TCM - Transmission Control Module	DATA
6H22-7J105-GB.vbf	Discovery 3/4 (L319)	TCM - Transmission Control Module	DATA
6H22-7J105-HA.vbf	Discovery 3/4 (L319)	TCM - Transmission Control Module	DATA
6H22-7J105-JA.vbf	Discovery 3/4 (L319)	TCM - Transmission Control Module	DATA
6H23-14C204-FAA.vbf	Not specified	ECM - Engine Control Module	EXE
6H2Q-14C204-AB.vbf	Not specified	ECM - Engine Control Module	EXE
6H32-14C204-BAA.vbf	Range Rover Sport I (L320)	ECM - Engine Control Module	EXE
6H32-14C635-AA.vbf	Range Rover Sport I (L320)	RCM - Restraints Control Module	DATA
6H32-7J104-AB.vbf	Range Rover Sport I (L320)	TCM - Transmission Control Module	EXE
6H32-7J105-AD.vbf	Range Rover Sport I (L320)	TCM - Transmission Control Module	DATA
6H32-7J105-DA.vbf	Range Rover Sport I (L320)	TCM - Transmission Control Module	DATA
6H32-7J105-EA.vbf	Range Rover Sport I (L320)	TCM - Transmission Control Module	DATA

File name	Vehicle line (indicative)	Module (ECU)	Type
6H32-7J105-FB.vbf	Range Rover Sport I (L320)	TCM - Transmission Control Module	DATA
6H32-7J105-GB.vbf	Range Rover Sport I (L320)	TCM - Transmission Control Module	DATA
6H33-14C204-FAA.vbf	Not specified	ECM - Engine Control Module	EXE
6H42-14C204-BAC.vbf	Range Rover III (L322)	ECM - Engine Control Module	EXE
6H42-14C204-BBD.vbf	Range Rover III (L322)	ECM - Engine Control Module	EXE
6H42-14C204-BCB.vbf	Range Rover III (L322)	ECM - Engine Control Module	EXE
6H42-14C204-BCC.vbf	Range Rover III (L322)	ECM - Engine Control Module	EXE
6H42-14D394-AB.vbf	Range Rover III (L322)	RLCM - Air Suspension	EXE
6H42-14D394-BB.vbf	Range Rover III (L322)	RLCM - Air Suspension	EXE
6H42-14D394-CB.vbf	Range Rover III (L322)	RLCM - Air Suspension	EXE
6H42-14D394-DA.vbf	Range Rover III (L322)	DCM Distanse Control Module	EXE
6H42-14D394-EA.vbf	Range Rover III (L322)	DCM Distanse Control Module	EXE
6H42-7J105-AC.vbf	Range Rover III (L322)	TCM - Transmission Control Module	DATA
6H42-7J105-BA.vbf	Range Rover III (L322)	TCM - Transmission Control Module	DATA
6H42-7J105-CA.vbf	Range Rover III (L322)	TCM - Transmission Control Module	DATA
6H4M-14D394-AA.vbf	Not specified	DCM Distanse Control Module	EXE
6H52-14C025-AA.VBF	Freelander 2 (L359)	DMY Dummy, Not initialised ECU	SBL
6H52-14C044-AB.vbf	Freelander 2 (L359)	ICM Infotainment Control Module (EuCD)	EXE
6H52-14C044-BB.vbf	Freelander 2 (L359)	ICM Infotainment Control Module (EuCD)	EXE
6H52-14C047-AB.vbf	Freelander 2 (L359)	ICM Infotainment Control Module	SBL
6H52-14C060-BB.vbf	Freelander 2 (L359)	HLDF - ICM/IGM - Gateway	EXE
6H52-14C061-AA.vbf	Freelander 2 (L359)	ICM - Infotainment Control Module	DATA
6H52-14C063-AB.vbf	Freelander 2 (L359)	HLDF - ICM/IGM - Gateway	SBL
6H52-14C395-AA.vbf	Freelander 2 (L359)	ICM - Infotainment Control Module	DATA
6H52-14C513-AB.vbf	Freelander 2 (L359)	ICM - Information Center Module	SIGCFG
6H52-14C514-AK.vbf	Freelander 2 (L359)	ICM Infotainment Control Module (EuCD)	EXE
6H52-14C515-AJ.vbf	Freelander 2 (L359)	ICM Infotainment Control Module (EuCD)	DATA
6H52-14C515-BJ.vbf	Freelander 2 (L359)	ICM Infotainment Control Module (EuCD)	DATA
6H52-14C526-CD.VBF	Freelander 2 (L359)	ICM - Infotainment Control Module	EXE
6H52-14C526-DD.VBF	Freelander 2 (L359)	ICM - Infotainment Control Module	EXE
6H52-14C527-CB.VBF	Freelander 2 (L359)	ICM - Infotainment Control Module	DATA
6H52-14C527-DB.VBF	Freelander 2 (L359)	ICM - Infotainment Control Module	DATA
6H52-14C528-CB.VBF	Freelander 2 (L359)	ICM - Infotainment Control Module	SBL
6H52-14C528-DB.VBF	Freelander 2 (L359)	ICM - Infotainment Control Module	SBL
6H52-14C666-AG.vbf	Freelander 2 (L359)	ICM Infotainment Control Module (EuCD)	DATA
6H52-14D402-AE.VBF	Freelander 2 (L359)	ICM - BMS-MOST-Gateway	EXE
6H52-14D402-AH.vbf	Freelander 2 (L359)	Not specified	EXE
6H52-14D405-AC.VBF	Freelander 2 (L359)	ICM - BMS-MOST-Gateway	SBL
6H52-14D405-AD.vbf	Freelander 2 (L359)	Not specified	SBL
6H52-14D408-AE.VBF	Freelander 2 (L359)	ICM - BMS-MOST-Gateway	DATA
6H52-14D408-AF.vbf	Freelander 2 (L359)	Not specified	DATA
6H52-18D618-AA.vbf	Freelander 2 (L359)	HVAC - HVAC Control Module	SBL
6R83-14C572-AA.VBF	Not specified	PCM - Powertrain Control Module	SBL
6U72-14C098-BA.vbf	Not specified	RCM - Restraints Control Module	DATA
6U72-14C635-AA.vbf	Range Rover Sport I (L320)	SRS Airbag	DATA
6U72-14C635-BA.vbf	Range Rover Sport I (L320)	SRS Airbag	DATA
6U72-14C635-CA.vbf	Range Rover Sport I (L320)	SRS Airbag	DATA
6U72-14D182-AB.vbf	Not specified	OCS - Restraints Occupant Classification System Module	EXE
6U72-14D184-AB.vbf	Freelander 2 (L359)	OCS - Restraints Occupant Classification System Module	SBL
6W83-14C025-AA.VBF	Jaguar XK (X150)	DMY Dummy, Not initialised ECU	SBL
6W83-14C027-AA.VBF	Jaguar XK (X150)	Restraints Control Module	SBL
6W83-14C029-AA.VBF	Jaguar XK (X150)	X - 150 DSM Driver Seat Module <CAN-ID 744 / 21 previous>	SBL
6W83-14C030-AE.VBF	Jaguar XK (X150)	SCCM - Steering Column Control Module	EXE
6W83-14C090-AB.VBF	Jaguar XF (X250)	PAM - Parking Assist Control Module	EXE
6W83-14C168-AD.VBF	Jaguar XK (X150)	PBM - Park Brake Control Module	EXE
6W83-14C171-AA.VBF	Jaguar XK (X150)	PBM - Park Brake Control Module	SBL
6W83-14C172-AD.VBF	Jaguar XK (X150)	CCM - Cruise Control Module	EXE
6W83-14C175-AC.VBF	Jaguar XK (X150)	CCM - Cruise Control Module	SBL
6W83-14C377-AB.VBF	Jaguar XK (X150)	PAM - Parking Assist Control Module	SIGCFG
6W83-14C383-AA.VBF	Jaguar XK (X150)	PBM - Park Brake Control Module	SIGCFG
6W83-14C430-AD.VBF	Jaguar XK (X150)	RFA - Remote Function Actuator	DATA
6W83-14C439-AE.VBF	Jaguar XK (X150)	X - 150 DHM Hood Module <CAN-ID 787 / 2F=756 previous>	EXE
6W83-14C441-AB.VBF	Jaguar XK (X150)	X - 150 DHM Hood Module <CAN-ID 787 / 2F=756 previous>	SBL
6W83-14C513-AA.VBF	Jaguar XK (X150)	ICM Infotainment Control Module (EuCD)	SIGCFG
6W83-14C513-AB.VBF	Jaguar XK (X150)	ICM - Information Center Module	SIGCFG
6W83-14C514-AB.VBF	Jaguar XK (X150)	ICM Infotainment Control Module (EuCD)	EXE
6W83-14C515-AB.VBF	Jaguar XK (X150)	ICM Infotainment Control Module (EuCD)	DATA
6W83-14C516-AA.VBF	Jaguar XK (X150)	ICM - Infotainment Control Module	SBL
6W83-14C526-AE.vbf	Jaguar XK (X150)	ICM - Infotainment Control Module	EXE
6W83-14C527-AD.vbf	Jaguar XK (X150)	ICM - Infotainment Control Module	DATA
6W83-14C528-AE.vbf	Jaguar XK (X150)	ICM - Infotainment Control Module	SBL
6W83-14C544-AC.VBF	Jaguar XK (X150)	ARCM - ACE/ARC	SBL
6W83-14C581-AA.VBF	Jaguar XK (X150)	DMY Dummy, Not initialised ECU	SBL
6W83-14D324-AA.vbf	Jaguar XK (X150)	ICM - Infotainment Control Module	GBL
7G9N-14C044-AA.VBF	Not specified	ICM/IGM Infotainment Control/Gateway Module	EXE
7G9N-14C339-AD.vbf	Not specified	CPM Combustion Preheater Module	SBL

File name	Vehicle line (indicative)	Module (ECU)	Type
7G9T-14C067-AB.VBF	Freelander 2 (L359)	DMY Dummy, Not initialised ECU	SBL
7G9T-14C097-AA.vbf	Freelander 2 (L359)	BCM Body Control Module	SBL
7G9T-14C111-AB.VBF	Freelander 2 (L359)	DMY Dummy, Not initialised ECU	SBL
7H22-14C151-AC.vbf	Discovery 3/4 (L319)	TPM - Tire Pressure Monitor Module	EXE
7H2M-14C635-DA.vbf	Discovery 3/4 (L319)	RCM - Restraints Control Module	DATA
7H32-12K532-CD.vbf	Range Rover Sport I (L320)	ECM - Engine Control Module	EXE
7H32-12K532-DD.vbf	Range Rover Sport I (L320)	ECM - Engine Control Module	EXE
7H32-12K532-GD.vbf	Range Rover Sport I (L320)	ECM - Engine Control Module	EXE
7H32-14C598-AA.vbf	Range Rover Sport I (L320)	RECM - Rear Entertainment RSE	SBL
7H32-14D394-AC.vbf	Range Rover Sport I (L320)	RLCM - Air Suspension	EXE
7H42-14C036-BA.vbf	Range Rover III (L322)	ABS - Anit-Lock Brake System (ABS) Control Module	EXE
7H42-14C039-AA.vbf	Range Rover III (L322)	ABS - Anit-Lock Brake System (ABS) Control Module	SBL
7H42-14C044-AF.vbf	Range Rover III (L322)	ACM - Low line head Unit / Integrated MOST head unit	EXE
7H42-14C144-AF.vbf	Range Rover III (L322)	DMY Dummy, Not initialised ECU	EXE
7H42-14C341-BD.vbf	Range Rover III (L322)	ICM - Information Center Module	EXE
7H42-14C366-AC.vbf	Range Rover III (L322)	TCCM - Transfer Case Control Module	EXE
7H42-14D394-AC.vbf	Range Rover III (L322)	RLCM - Air Suspension	EXE
7H42-4C045-AD.vbf	Range Rover III (L322)	DEM Differential Electronic Module	EXE
7H42-7J105-BD.vbf	Range Rover III (L322)	TCM - Transmission Control Module	DATA
7H4M-14D394-AB.vbf	Not specified	RLCM - Air Suspension	EXE
7H52-14C045-AG.VBF	Freelander 2 (L359)	ICM - Information Center Module	DATA
7U72-14D182-AA.vbf	Range Rover III (L322)	OCS - Restraints Occupant Classification System Module	EXE
7U72-14D183-AA.vbf	Range Rover III (L322)	OCS - Restraints Occupant Classification System Module	DATA
7U72-14D184-AA.vbf	Range Rover III (L322)	OCS - Restraints Occupant Classification System Module	SBL
7U7M-14C635-AA.vbf	Discovery 3/4 (L319)	SRS Airbag	DATA
7W83-14C570-AAD.vbf	Jaguar XK (X150)	PCM - Powertrain Control Module	EXE
7W83-14C570-BAD.vbf	Jaguar XK (X150)	PCM - Powertrain Control Module	EXE
7W83-14C570-CBB.vbf	Jaguar XK (X150)	PCM - Powertrain Control Module	EXE
7W83-14C570-CCB.vbf	Jaguar XK (X150)	PCM - Powertrain Control Module	EXE
7W83-14D043-AH.VBF	Jaguar XK (X150)	ICS - Impact Classification System	DATA
7W83-14D044-AA.VBF	Jaguar XK (X150)	Jag Ped Addr second	SBL
7W83-7J104-AA.VBF	Jaguar XK (X150)	TCM - Transmission Control Module	EXE
7W8M-14C527-AA.vbf	Check in SDD (unconfirmed)	ICM - Infotainment Control Module	DATA
7W93-14D533-AB.vbf	Jaguar XJ (X351)	ICM/IGM - Infotainment Control/Gateway Module	EXE
7W93-14D533-AC.vbf	Jaguar XJ (X351)	ICM/IGM - Infotainment Control/Gateway Module	EXE
7W93-14D533-BA.vbf	Jaguar XJ (X351)	ICM/IGM - Infotainment Control/Gateway Module	EXE
7W93-14D534-AD.vbf	Jaguar XJ (X351)	ICM/IGM - Infotainment Control/Gateway Module	DATA
7W93-14D534-AE.vbf	Jaguar XJ (X351)	ICM/IGM - Infotainment Control/Gateway Module	DATA
7W93-14D534-BB.vbf	Jaguar XJ (X351)	ICM/IGM - Infotainment Control/Gateway Module	DATA
7W93-14D535-AA.VBF	Jaguar XJ (X351)	ICM/IGM - Infotainment Control/Gateway Module	SBL
8G9N-14C104-AA.vbf	Not specified	RFA - Remote Function Actuator	EXE
8G9N-14C104-AB.vbf	Not specified	RFA - Remote Function Actuator	EXE
8H22-12K532-AH.vbf	Discovery 3/4 (L319)	ECM - Engine Control Module	EXE
8H22-12K532-BH.vbf	Discovery 3/4 (L319)	ECM - Engine Control Module	EXE
8H22-12K532-CF.vbf	Discovery 3/4 (L319)	ECM - Engine Control Module	EXE
8H22-12K532-EE.vbf	Discovery 3/4 (L319)	ECM - Engine Control Module	EXE
8H22-12K532-MD.vbf	Discovery 3/4 (L319)	ECM - Engine Control Module	EXE
8H22-14C026-AB.vbf	Discovery 3/4 (L319)	AUM Audio Module	EXE
8H22-14C026-GB.vbf	Discovery 3/4 (L319)	AUM Audio Module	EXE
8H22-14C028-AC.vbf	Discovery 3/4 (L319)	SRS Airbag	EXE
8H22-14C028-AD.vbf	Discovery 3/4 (L319)	RCM - Restraints Control Module	DATA
8H22-14C044-BC.vbf	Discovery 3/4 (L319)	ACM - Low line head Unit / Integrated MOST head unit	EXE
8H22-14C047-AA.vbf	Discovery 3/4 (L319)	ACM - Low line head Unit / Integrated MOST head unit	SBL
8H22-14C088-AB.vbf	Discovery 3/4 (L319)	AUM Audio Module	DATA
8H22-14C088-BB.vbf	Discovery 3/4 (L319)	AUM Audio Module	DATA
8H22-14C088-CB.vbf	Discovery 3/4 (L319)	AUM Audio Module	DATA
8H22-14C088-DB.vbf	Discovery 3/4 (L319)	AUM Audio Module	DATA
8H22-14C088-EB.vbf	Discovery 3/4 (L319)	AUM Audio Module	DATA
8H22-14C088-FB.vbf	Discovery 3/4 (L319)	AUM Audio Module	DATA
8H22-14C088-GB.vbf	Discovery 3/4 (L319)	AUM Audio Module	DATA
8H22-14C088-HB.vbf	Discovery 3/4 (L319)	AUM Audio Module	DATA
8H22-14C088-JB.vbf	Discovery 3/4 (L319)	AUM Audio Module	DATA
8H22-14C088-KB.vbf	Discovery 3/4 (L319)	AUM Audio Module	DATA
8H22-14C088-LB.vbf	Discovery 3/4 (L319)	AUM Audio Module	DATA
8H22-14C088-MB.vbf	Discovery 3/4 (L319)	AUM Audio Module	DATA
8H22-14C098-AA.vbf	Discovery 3/4 (L319)	RCM - Restraints Control Module	DATA
8H22-14C527-AA.vbf	Discovery 3/4 (L319)	AAM - Audio Amplifier Module	DATA
8H22-14C554-AA.vbf	Discovery 3/4 (L319)	ACM - Audio Front Control Module	EXE
8H22-14C555-AB.vbf	Discovery 3/4 (L319)	ACM - Audio Front Control Module	DATA
8H22-14C555-BB.vbf	Discovery 3/4 (L319)	ACM - Audio Front Control Module	DATA
8H22-14C556-AA.vbf	Discovery 3/4 (L319)	ACM - Audio Front Control Module	SBL
8H22-14C635-AA.vbf	Discovery 3/4 (L319)	RCM Restraints Control Module	DATA
8H22-14C635-BA.vbf	Discovery 3/4 (L319)	RCM Restraints Control Module	DATA
8H22-14C635-CA.vbf	Discovery 3/4 (L319)	RCM Restraints Control Module	DATA
8H22-14C635-DA.vbf	Discovery 3/4 (L319)	RCM Restraints Control Module	DATA
8H22-14C635-EA.vbf	Discovery 3/4 (L319)	RCM Restraints Control Module	DATA

File name	Vehicle line (indicative)	Module (ECU)	Type
8H22-14C635-FA.vbf	Discovery 3/4 (L319)	RCM Restraints Control Module	DATA
8H22-14C635-GA.vbf	Discovery 3/4 (L319)	RCM Restraints Control Module	DATA
8H22-14C635-HA.vbf	Discovery 3/4 (L319)	RCM Restraints Control Module	DATA
8H22-7J104-AC.vbf	Discovery 3/4 (L319)	TCM - Transmission Control Module	EXE
8H22-7J105-AF.vbf	Discovery 3/4 (L319)	TCM - Transmission Control Module	DATA
8H22-7J105-BC.vbf	Discovery 3/4 (L319)	TCM - Transmission Control Module	DATA
8H22-7J105-CC.vbf	Discovery 3/4 (L319)	TCM - Transmission Control Module	DATA
8H22-7J105-DC.vbf	Discovery 3/4 (L319)	TCM - Transmission Control Module	DATA
8H22-7J105-EC.vbf	Discovery 3/4 (L319)	TCM - Transmission Control Module	DATA
8H22-7J105-GB.vbf	Discovery 3/4 (L319)	TCM - Transmission Control Module	DATA
8H2M-12K532-AB.vbf	Not specified	ECM - Engine Control Module	EXE
8H2M-12K532-BC.vbf	Not specified	DMY Dummy, Not initialised ECU	EXE
8H2M-14C635-AA.vbf	Discovery 3/4 (L319)	SRS Airbag	DATA
8H2M-14C635-BA.vbf	Not specified	SRS Airbag	DATA
8H2M-14D394-AB.vbf	Not specified	RLCM - Air Suspension	EXE
8H2Q-14C204-AB.vbf	Not specified	DMY Dummy, Not initialised ECU	EXE
8H32-12K532-BG.vbf	Range Rover Sport I (L320)	ECM - Engine Control Module	EXE
8H32-12K532-CG.vbf	Range Rover Sport I (L320)	ECM - Engine Control Module	EXE
8H32-12K532-EH.vbf	Range Rover Sport I (L320)	ECM - Engine Control Module	EXE
8H32-12K532-FG.vbf	Range Rover Sport I (L320)	DMY Dummy, Not initialised ECU	EXE
8H32-12K532-HE.vbf	Range Rover Sport I (L320)	ECM - Engine Control Module	EXE
8H32-12K532-JB.vbf	Range Rover Sport I (L320)	ECM - Engine Control Module	EXE
8H32-12K532-KB.vbf	Range Rover Sport I (L320)	ECM - Engine Control Module	EXE
8H32-12K532-LD.vbf	Range Rover Sport I (L320)	ECM - Engine Control Module	EXE
8H32-14C088-NB.vbf	Range Rover Sport I (L320)	AUM Audio Module	DATA
8H32-14C088-PB.vbf	Range Rover Sport I (L320)	AUM Audio Module	DATA
8H32-14C088-RB.vbf	Range Rover Sport I (L320)	AUM Audio Module	DATA
8H32-14C088-SB.vbf	Range Rover Sport I (L320)	AUM Audio Module	DATA
8H32-14C088-TB.vbf	Range Rover Sport I (L320)	AUM Audio Module	DATA
8H32-14C088-UB.vbf	Range Rover Sport I (L320)	AUM Audio Module	DATA
8H32-14C088-VB.vbf	Range Rover Sport I (L320)	AUM Audio Module	DATA
8H32-14C088-XB.vbf	Range Rover Sport I (L320)	AUM Audio Module	DATA
8H32-14C088-YB.vbf	Range Rover Sport I (L320)	AUM Audio Module	DATA
8H32-14C088-ZB.vbf	Range Rover Sport I (L320)	AUM Audio Module	DATA
8H32-14C098-AA.vbf	Range Rover Sport I (L320)	SRS Airbag	DATA
8H32-14C098-BA.vbf	Range Rover Sport I (L320)	SRS Airbag	DATA
8H32-14C204-BAA.vbf	Range Rover Sport I (L320)	ECM - Engine Control Module	EXE
8H32-14C526-AA.vbf	Range Rover Sport I (L320)	AAM - Audio Amplifier Module	EXE
8H32-14C555-AB.vbf	Range Rover Sport I (L320)	ACM - Audio Front Control Module	DATA
8H32-14C555-BB.vbf	Range Rover Sport I (L320)	ACM - Audio Front Control Module	DATA
8H32-14C555-CB.vbf	Range Rover Sport I (L320)	ACM - Audio Front Control Module	DATA
8H32-14C635-AA.vbf	Range Rover Sport I (L320)	RCM Restraints Control Module	DATA
8H32-14C635-BA.vbf	Range Rover Sport I (L320)	RCM Restraints Control Module	DATA
8H32-14C635-CA.vbf	Range Rover Sport I (L320)	RCM Restraints Control Module	DATA
8H32-14C635-DA.vbf	Range Rover Sport I (L320)	RCM Restraints Control Module	DATA
8H32-7J105-AF.vbf	Range Rover Sport I (L320)	TCM - Transmission Control Module	DATA
8H32-7J105-BE.vbf	Range Rover Sport I (L320)	TCM - Transmission Control Module	DATA
8H32-7J105-CC.vbf	Range Rover Sport I (L320)	TCM - Transmission Control Module	DATA
8H32-7J105-DC.vbf	Range Rover Sport I (L320)	TCM - Transmission Control Module	DATA
8H32-7J105-EC.vbf	Range Rover Sport I (L320)	TCM - Transmission Control Module	DATA
8H32-7J105-FC.vbf	Range Rover Sport I (L320)	TCM - Transmission Control Module	DATA
8H32-7J105-JB.vbf	Range Rover Sport I (L320)	TCM - Transmission Control Module	DATA
8H42-12K532-AF.vbf	Range Rover III (L322)	ECM - Engine Control Module	EXE
8H42-12K532-CC.vbf	Range Rover III (L322)	ECM - Engine Control Module	EXE
8H42-12K532-CD.vbf	Range Rover III (L322)	ECM - Engine Control Module	EXE
8H42-14C026-AC.vbf	Range Rover III (L322)	AUM Audio Module	EXE
8H42-14C060-BA.vbf	Range Rover III (L322)	FECM - Multimedia Module	EXE
8H42-14C060-CA.vbf	Range Rover III (L322)	FECM - Multimedia Module	EXE
8H42-14C204-BAB.vbf	Range Rover III (L322)	ECM - Engine Control Module	EXE
8H42-14C526-AA.vbf	Range Rover III (L322)	AAM - Audio Amplifier Module	EXE
8H42-14C526-BB.vbf	Range Rover III (L322)	AAM - Audio Amplifier Module	EXE
8H42-14C555-AA.vbf	Range Rover III (L322)	ACM - Audio Front Control Module	DATA
8H42-14C555-BA.vbf	Range Rover III (L322)	ACM - Audio Front Control Module	DATA
8H42-7J104-AB.vbf	Range Rover III (L322)	TCM - Transmission Control Module	EXE
8H42-7J105-AF.vbf	Range Rover III (L322)	TCM - Transmission Control Module	DATA
8H42-7J105-BC.vbf	Range Rover III (L322)	TCM - Transmission Control Module	DATA
8H42-7J105-CD.vbf	Range Rover III (L322)	TCM - Transmission Control Module	DATA
8H42-7J105-CE.vbf	Range Rover III (L322)	TCM - Transmission Control Module	DATA
8H42-7J105-DC.vbf	Range Rover III (L322)	TCM - Transmission Control Module	DATA
8H42-7J105-EE.vbf	Range Rover III (L322)	TCM - Transmission Control Module	DATA
8H52-14C029-AB.vbf	Freelander 2 (L359)	AFM AM/FM Module	SBL
8H52-14C030-AC.vbf	Freelander 2 (L359)	AFM AM/FM Module	EXE
8W83-14C026-AC.VBF	Jaguar XK (X150)	HUD - Head Up Display	EXE
8W83-14C029-AA.vbf	Jaguar XK (X150)	AFM AM/FM Module	SBL
8W83-14C030-AB.vbf	Jaguar XK (X150)	AFM AM/FM Module	EXE
8W83-14C030-AC.vbf	Jaguar XK (X150)	AFM AM/FM Module	EXE

File name	Vehicle line (indicative)	Module (ECU)	Type
8W83-14C036-CB.vbf	Jaguar XK (X150)	ABS - Anit-Lock Brake System (ABS) Control Module	EXE
8W83-14C036-DB.vbf	Jaguar XK (X150)	ABS - Anit-Lock Brake System (ABS) Control Module	EXE
8W83-14C039-BA.vbf	Jaguar XK (X150)	ABS	SBL
8W83-14C045-AA.VBF	Jaguar XK (X150)	ICM - Information Center Module	DATA
8W83-14C045-AB.vbf	Jaguar XK (X150)	ICM - Information Center Module	DATA
8W83-14C065-BA.vbf	Jaguar XK (X150)	DDM - Driver Front Door Module	DATA
8W83-14C109-BA.vbf	Jaguar XK (X150)	PDM - Passenger Front Door Module	DATA
8W83-14C168-AD.vbf	Jaguar XK (X150)	PBM - Park Brake Control Module	EXE
8W83-14C168-BD.vbf	Jaguar XK (X150)	PBM - Park Brake Control Module	EXE
8W83-14C171-AA.vbf	Jaguar XK (X150)	PBM - Park Brake Control Module	SBL
8W83-14C172-AE.vbf	Check in SDD (unconfirmed)	CCM - Cruise Control Module	EXE
8W83-14C184-AD.vbf	Jaguar XK (X150)	ecu_address = 0x726;	EXE
8W83-14C184-BA.vbf	Jaguar XK (X150)	ecu_address = 0x7B7;	EXE
8W83-14C184-BG.vbf	Jaguar XK (X150)	ecu_address = 0x7B7;	EXE
8W83-14C187-AA.vbf	Jaguar XK (X150)	ecu_address = 0x726;	SBL
8W83-14C187-BA.vbf	Jaguar XK (X150)	ecu_address = 0x7B7;	SBL
8W83-14C273-YB.vbf	Jaguar XK (X150)	PCM - Powertrain Control Module	SBL
8W83-14C320-BB.vbf	Jaguar XK (X150)	PDM - Passenger Front Door Module	SIGCFG
8W83-14C321-BB.vbf	Jaguar XK (X150)	DDM - Driver Front Door Module	SIGCFG
8W83-14C341-AD.vbf	Jaguar XK (X150)	Not specified	EXE
8W83-14C342-AA.vbf	Jaguar XK (X150)	Not specified	DATA
8W83-14C343-AA.vbf	Jaguar XK (X150)	Not specified	SBL
8W83-14C383-AC.vbf	Jaguar XK (X150)	PBM - Park Brake Control Module	SIGCFG
8W83-14C413-AA.vbf	Check in SDD (unconfirmed)	AFM AM/FM Module	SIGCFG
8W83-14C430-AA.vbf	Jaguar XK (X150)	RFA - Remote Function Actuator	SIGCFG
8W83-14C439-AA.vbf	Jaguar XK (X150)	ecu_address = 0x787;	EXE
8W83-14C441-AA.vbf	Jaguar XK (X150)	ecu_address = 0x787;	SBL
8W83-14C514-AB.VBF	Jaguar XK (X150)	ICM Infotainment Control Module (EuCD)	EXE
8W83-14C515-AB.vbf	Jaguar XK (X150)	ICM Infotainment Control Module (EuCD)	DATA
8W83-14C515-BB.VBF	Jaguar XK (X150)	ICM Infotainment Control Module (EuCD)	DATA
8W83-14C542-AN.vbf	Jaguar XK (X150)	ecu_address = 0x786;	EXE
8W83-14C544-AB.vbf	Jaguar XK (X150)	ecu_address = 0x786;	SBL
8W83-14C544-AC.vbf	Jaguar XK (X150)	ecu_address = 0x786;	SBL
8W83-14C547-AA.vbf	Jaguar XK (X150)	ECM Engine Control Module, petrol	SIGCFG
8W83-14C548-AA.vbf	Jaguar XK (X150)	ECM Engine Control Module, petrol	EXE
8W83-14C548-AB.vbf	Jaguar XK (X150)	ECM Engine Control Module, petrol	EXE
8W83-14C550-AA.vbf	Jaguar XK (X150)	ecu_address = 0x7A3;	SBL
8W83-14C560-AA.vbf	Jaguar XK (X150)	GSM - Gear Shift Module	SIGCFG
8W83-14C561-AA.vbf	Jaguar XK (X150)	GSM - Gear Shift Module	EXE
8W83-14C561-AB.vbf	Jaguar XK (X150)	GSM - Gear Shift Module	EXE
8W83-14C561-AD.vbf	Jaguar XK (X150)	GSM - Gear Shift Module	EXE
8W83-14C563-AA.vbf	Jaguar XK (X150)	GSM - Gear Shift Module	SBL
8W83-14C579-BA.vbf	Jaguar XK (X150)	VIM - Vehicle Immobilizer Control Module	EXE
8X23-12K532-KBM.VBF	Jaguar XF (X250)	ECM - Engine Control Module	EXE
8X23-12K532-LBM.VBF	Jaguar XF (X250)	ECM - Engine Control Module	EXE
8X23-14C027-AB.VBF	Jaguar XF (X250)	TMC Traffic Message Channel Module	SBL
8X23-14C028-AJ.VBF	Jaguar XF (X250)	TMC Traffic Message Channel Module	EXE
8X23-14C036-CF.vbf	Jaguar XF (X250)	ABS - Anit-Lock Brake System (ABS) Control Module	EXE
8X23-14C036-DF.vbf	Jaguar XF (X250)	ABS - Anit-Lock Brake System (ABS) Control Module	EXE
8X23-14C039-AA.VBF	Jaguar XF (X250)	Jaguar Download ID	SBL
8X23-14C045-AB.VBF	Jaguar XF (X250)	ICM - Information Center Module	DATA
8X23-14C098-AF.VBF	Jaguar XF (X250)	TMC Traffic Message Channel Module	CARCFG
8X23-14C098-BF.VBF	Jaguar XF (X250)	TMC Traffic Message Channel Module	CARCFG
8X23-14C144-AF.VBF	Jaguar XF (X250)	DMY Dummy, Not initialised ECU	EXE
8X23-14C144-AG.vbf	Jaguar XF (X250)	DCSM - Driver Climate Control Seat Module	EXE
8X23-14C144-AJ.vbf	Jaguar XF (X250)	DCSM - Driver Climate Control Seat Module	EXE
8X23-14C145-AD.VBF	Jaguar XF (X250)	DMY Dummy, Not initialised ECU	EXE
8X23-14C145-AF.vbf	Jaguar XF (X250)	DCSM - Driver Climate Control Seat Module	EXE
8X23-14C147-AA.VBF	Jaguar XF (X250)	DMY Dummy, Not initialised ECU	SBL
8X23-14C151-AB.vbf	Jaguar XF (X250)	TPM - Tire Pressure Monitor Module	EXE
8X23-14C154-AA.VBF	Jaguar XF (X250)	DMY Dummy, Not initialised ECU	SBL
8X23-14C168-AC.VBF	Jaguar XF (X250)	PBM - Park Brake Control Module	EXE
8X23-14C172-AD.VBF	Jaguar XF (X250)	CCM - Cruise Control Module	EXE
8X23-14C172-AE.vbf	Jaguar XF (X250)	CCM - Cruise Control Module	EXE
8X23-14C273-KB.VBF	Jaguar XF (X250)	PCM - Powertrain Control Module	SBL
8X23-14C383-AA.VBF	Jaguar XF (X250)	PBM - Park Brake Control Module	SIGCFG
8X23-14C407-AE.VBF	Jaguar XF (X250)	TMC Traffic Message Channel Module	SIGCFG
8X23-14C413-AA.VBF	Jaguar XF (X250)	DSM - Driver Front Seat Module	EXE
8X23-14C430-AB.VBF	Jaguar XF (X250)	RFA - Remote Function Actuator	DATA
8X23-14C434-AA.VBF	Jaguar XF (X250)	TPM - Tire Pressure Monitor Module	DATA
8X23-14C513-AA.VBF	Jaguar XF (X250)	ICM - Information Center Module	SIGCFG
8X23-14C514-AJ.vbf	Jaguar XK (X150)	ICM Infotainment Control Module (EuCD)	EXE
8X23-14C514-BG.VBF	Check in SDD (unconfirmed)	ICM Infotainment Control Module (EuCD)	EXE
8X23-14C514-BK.vbf	Check in SDD (unconfirmed)	ICM Infotainment Control Module (EuCD)	EXE
8X23-14C515-AG.vbf	Jaguar XK (X150)	ICM Infotainment Control Module (EuCD)	DATA
8X23-14C515-BG.VBF	Check in SDD (unconfirmed)	ICM Infotainment Control Module (EuCD)	DATA

File name	Vehicle line (indicative)	Module (ECU)	Type
8X23-14C515-BK.vbf	Check in SDD (unconfirmed)	ICM Infotainment Control Module (EuCD)	DATA
8X23-14C515-CG.vbf	Jaguar XK (X150)	ICM Infotainment Control Module (EuCD)	DATA
8X23-14C527-CE.VBF	Jaguar XF (X250)	ICM - Infotainment Control Module	DATA
8X23-14C527-DE.VBF	Jaguar XF (X250)	ICM - Infotainment Control Module	DATA
8X23-14C534-AC.VBF	Jaguar XF (X250)	Not specified	SIGCFG
8X23-14C535-AD.VBF	Jaguar XF (X250)	Not specified	EXE
8X23-14C535-AE.vbf	Jaguar XF (X250)	Not specified	EXE
8X23-14C537-AA.VBF	Jaguar XF (X250)	Not specified	SBL
8X23-14C542-AD.VBF	Jaguar XF (X250)	ARCM - ACE/ARC	EXE
8X23-14C560-AA.VBF	Jaguar XF (X250)	GSM - Gear Shift Module	SIGCFG
8X23-14C560-BB.vbf	Jaguar XF (X250)	GSM - Gear Shift Module	SIGCFG
8X23-14C561-AD.VBF	Jaguar XF (X250)	GSM - Gear Shift Module	EXE
8X23-14C561-BC.vbf	Jaguar XF (X250)	GSM - Gear Shift Module	EXE
8X23-14C563-AA.VBF	Jaguar XF (X250)	DMY Dummy, Not initialised ECU	SBL
8X23-14C570-AAJ.vbf	Jaguar XF (X250)	PCM - Powertrain Control Module	EXE
8X23-14C570-ABE.vbf	Jaguar XF (X250)	PCM - Powertrain Control Module	EXE
8X23-14C570-ACE.vbf	Jaguar XF (X250)	PCM - Powertrain Control Module	EXE
8X23-14C570-ADE.vbf	Jaguar XF (X250)	PCM - Powertrain Control Module	EXE
8X23-14C570-AEE.vbf	Jaguar XF (X250)	PCM - Powertrain Control Module	EXE
8X23-14C570-AFE.vbf	Jaguar XF (X250)	PCM - Powertrain Control Module	EXE
8X23-14C570-BAF.vbf	Jaguar XF (X250)	PCM - Powertrain Control Module	EXE
8X23-14C570-BBE.vbf	Jaguar XF (X250)	PCM - Powertrain Control Module	EXE
8X23-14C570-BCE.vbf	Jaguar XF (X250)	PCM - Powertrain Control Module	EXE
8X23-14C570-BDE.vbf	Jaguar XF (X250)	PCM - Powertrain Control Module	EXE
8X23-14C570-BEE.vbf	Jaguar XF (X250)	PCM - Powertrain Control Module	EXE
8X23-14C570-BFE.vbf	Jaguar XF (X250)	PCM - Powertrain Control Module	EXE
8X23-14C570-DBE.vbf	Jaguar XF (X250)	PCM - Powertrain Control Module	EXE
8X23-14C570-DCE.vbf	Jaguar XF (X250)	PCM - Powertrain Control Module	EXE
8X23-14C570-DDE.vbf	Jaguar XF (X250)	PCM - Powertrain Control Module	EXE
8X23-14C570-DEF.vbf	Jaguar XF (X250)	PCM - Powertrain Control Module	EXE
8X23-14C570-DFE.vbf	Jaguar XF (X250)	PCM - Powertrain Control Module	EXE
8X23-14C570-DSB.vbf	Jaguar XF (X250)	PCM - Powertrain Control Module	EXE
8X23-14C572-AA.VBF	Jaguar XF (X250)	PCM - Powertrain Control Module	SBL
8X23-14C579-BA.VBF	Jaguar XF (X250)	VIM - Vehicle Immobilizer Control Module	EXE
8X23-14D042-AB.VBF	Jaguar XF (X250)	ICS - Impact Classification System	EXE
8X23-14D043-AC.VBF	Jaguar XF (X250)	ICS - Impact Classification System	DATA
8X23-14D044-AA.vbf	Jaguar XF (X250)	ICS - Impact Classification System	SBL
8X23-14D205-AA.vbf	Jaguar XF (X250)	ICM - Information Center Module	EXE
8X23-14D206-AA.vbf	Jaguar XF (X250)	ICM - Information Center Module	DATA
8X23-14D207-AA.vbf	Jaguar XF (X250)	ICM - Information Center Module	SBL
8X23-14D367-AC.VBF	Jaguar XF (X250)	SODL - Side Obstacle Detection Control Module - Left	EXE
8X23-14D367-AD.vbf	Jaguar XF (X250)	SODL - Side Obstacle Detection Control Module - Left	SIGCFG
8X23-14D367-BC.VBF	Jaguar XF (X250)	SODR - Side Obstacle Detection Control Module - Right	EXE
8X23-14D367-BD.vbf	Jaguar XF (X250)	SODR - Side Obstacle Detection Control Module - Right	SIGCFG
8X23-14D368-AK.VBF	Jaguar XF (X250)	SODL - Side Obstacle Detection Control Module - Left	EXE
8X23-14D368-BK.VBF	Jaguar XF (X250)	SODR - Side Obstacle Detection Control Module - Right	EXE
8X23-14D370-AC.VBF	Jaguar XF (X250)	SODL - Side Obstacle Detection Control Module - Left	SBL
8X23-14D370-AD.vbf	Jaguar XF (X250)	SODL - Side Obstacle Detection Control Module - Left	SBL
8X23-14D370-AE.vbf	Jaguar XF (X250)	SODL - Side Obstacle Detection Control Module - Left	SBL
8X23-14D370-BC.VBF	Jaguar XF (X250)	SODR - Side Obstacle Detection Control Module - Right	SBL
8X23-14D370-BE.vbf	Jaguar XF (X250)	SODR - Side Obstacle Detection Control Module - Right	SBL
8X23-14D370-CA.vbf	Jaguar XF (X250)	Not specified	SBL
8X23-14D419-AB.VBF	Jaguar XF (X250)	Not specified	EXE
8X23-18D618-AA.VBF	Jaguar XF (X250)	HVAC = HeVAC	SBL
8X23-18D619-AG.VBF	Jaguar XF (X250)	HVAC - HVAC Control Module	EXE
8X23-7J104-AG.vbf	Jaguar XF (X250)	TCM - Transmission Control Module	DATA
8X23-7J104-BG.vbf	Jaguar XF (X250)	TCM - Transmission Control Module	DATA
8X23-7J104-CG.vbf	Jaguar XF (X250)	TCM - Transmission Control Module	DATA
8X23-7J104-DG.vbf	Jaguar XF (X250)	TCM - Transmission Control Module	DATA
8X23-7J105-AM.vbf	Jaguar XF (X250)	TCM - Transmission Control Module	DATA
8X23-7J105-BL.vbf	Jaguar XF (X250)	TCM - Transmission Control Module	DATA
8X23-7J105-CL.vbf	Jaguar XF (X250)	TCM - Transmission Control Module	DATA
8X23-7J105-DL.vbf	Jaguar XF (X250)	TCM - Transmission Control Module	DATA
8X2Q-14C204-GB.vbf	Not specified	ECM - Engine Control Module	EXE
8X2T-14C184-AE.VBF	Not specified	BCM - Body Control Module	EXE
8X2T-14C184-BB.vbf	Not specified	BCMB - Body Conrol Module	EXE
8X2T-14C184-BE.VBF	Not specified	BCMB - Body Control Module B	EXE
8X2T-14C187-AD.VBF	Not specified	BCM - Body Control Module	SBL
8X2T-14C187-BB.vbf	Not specified	BCMB - Body Control Module	SBL
8X2T-14C187-BD.VBF	Not specified	BCMB - Body Conrol Module	SBL
8X2T-14C408-AC.VBF	Not specified	BCM - Body Control Module	SIGCFG
8X2T-14C408-AD.vbf	Not specified	AEM - Accessories Electronic Module	SIGCFG
8X2T-14C408-BB.vbf	Not specified	BCMB - Body Control Module	SIGCFG
8X2T-14C408-BC.VBF	Not specified	BCMB - Body Conrol Module	SIGCFG
8X2T-14C408-BD.vbf	Not specified	BCMB - Body Control Module	SIGCFG
8X4N-14C337-AB.vbf	Not specified	TCM Transmission Control Module	EXE

File name	Vehicle line (indicative)	Module (ECU)	Type
8X4N-14C337-AC.vbf	Not specified	TCM Transmission Control Module	EXE
8X4N-14C337-AD.vbf	Not specified	TCM Transmission Control Module	EXE
8X4N-14C397-AA.vbf	Not specified	TCM - Transmission Control Module	SIGCFG
9G92-14C377-AC.VBF	Not specified	PAM - Parking Assist Control Module	SIGCFG
9G9N-14C387-AB.vbf	Not specified	SASM - Steering Angle Sensor Module	SIGCFG
9G9N-14C397-BA.vbf	Not specified	TCM - Transmission Control Module	SIGCFG
9G9N-14C569-AB.vbf	Not specified	ECM - Engine Control Module	SIGCFG
9G9N-14C572-AA.VBF	Not specified	PCM - Powertrain Control Module	SBL
9H22-14C204-FAE.vbf	Discovery 3/4 (L319)	ECM - Engine Control Module	EXE
9H22-14C204-FBC.vbf	Discovery 3/4 (L319)	ECM - Engine Control Module	EXE
9H22-14C204-FCC.vbf	Discovery 3/4 (L319)	ECM - Engine Control Module	EXE
9H22-14C204-FDC.vbf	Discovery 3/4 (L319)	ECM - Engine Control Module	EXE
9H22-14C204-GAC.vbf	Discovery 3/4 (L319)	ECM - Engine Control Module	EXE
9H22-14C204-GBC.vbf	Discovery 3/4 (L319)	ECM - Engine Control Module	EXE
9H22-14C204-GCC.vbf	Discovery 3/4 (L319)	ECM - Engine Control Module	EXE
9H22-14C204-GDC.vbf	Discovery 3/4 (L319)	ECM - Engine Control Module	EXE
9H22-14D394-AA.vbf	Discovery 3/4 (L319)	DCM Distanse Control Module	EXE
9H22-14D533-AC.vbf	Discovery 3/4 (L319)	Not specified	EXE
9H22-14D534-AC.vbf	Discovery 3/4 (L319)	Not specified	DATA
9H22-14D534-BA.vbf	Discovery 3/4 (L319)	DACMC - Digital Audio Control Module C	DATA
9H22-14D535-AA.vbf	Discovery 3/4 (L319)	SRM - Satellite Radio Module	SBL
9H2M-14D394-AA.vbf	Not specified	DCM Distanse Control Module	EXE
9H32-14C204-BAE.vbf	Range Rover Sport I (L320)	ECM - Engine Control Module	EXE
9H32-14C204-BBE.vbf	Range Rover Sport I (L320)	ECM - Engine Control Module	EXE
9H32-14C204-BCD.vbf	Range Rover Sport I (L320)	ECM - Engine Control Module	EXE
9H32-14C204-BDD.vbf	Range Rover Sport I (L320)	ECM - Engine Control Module	EXE
9H32-14C204-FAD.vbf	Range Rover Sport I (L320)	ECM - Engine Control Module	EXE
9H32-14C204-FBC.vbf	Range Rover Sport I (L320)	ECM - Engine Control Module	EXE
9H32-14C204-FCC.vbf	Range Rover Sport I (L320)	ECM - Engine Control Module	EXE
9H32-14C204-FDC.vbf	Range Rover Sport I (L320)	ECM - Engine Control Module	EXE
9H32-14D394-AA.vbf	Range Rover Sport I (L320)	DCM Distanse Control Module	EXE
9H32-14D394-BA.vbf	Range Rover Sport I (L320)	DCM Distanse Control Module	EXE
9H42-14C060-BA.vbf	Range Rover III (L322)	FECM - Multimedia Module	EXE
9H42-14C060-CA.vbf	Range Rover III (L322)	FECM - Multimedia Module	EXE
9H42-14C204-BAE.vbf	Range Rover III (L322)	ECM - Engine Control Module	EXE
9H42-14C204-BBF.vbf	Range Rover III (L322)	ECM - Engine Control Module	EXE
9H42-14C204-BCE.vbf	Range Rover III (L322)	ECM - Engine Control Module	EXE
9H42-14C204-BDE.vbf	Range Rover III (L322)	ECM - Engine Control Module	EXE
9H42-14C204-FAE.vbf	Range Rover III (L322)	ECM - Engine Control Module	EXE
9H42-14C204-FBD.vbf	Range Rover III (L322)	ECM - Engine Control Module	EXE
9H42-14C204-FCD.vbf	Range Rover III (L322)	ECM - Engine Control Module	EXE
9H42-14C204-FDD.vbf	Range Rover III (L322)	ECM - Engine Control Module	EXE
9H42-14C343-AA.vbf	Range Rover III (L322)	SRM - Satellite Radio Module	SBL
9H42-14D394-AB.vbf	Range Rover III (L322)	DCM Distanse Control Module	EXE
9H4M-14D394-AA.vbf	Not specified	DCM Distanse Control Module	EXE
9H52-14C027-AA.VBF	Freelander 2 (L359)	RCM - Restraints Control Module	SBL
9H52-14C098-AA.VBF	Freelander 2 (L359)	RCM - Restraints Control Module	DATA
9H52-14C319-AA.vbf	Freelander 2 (L359)	HVAC - HVAC Control Module	SIGCFG
9H52-14D023-AA.VBF	Freelander 2 (L359)	ATCM - All Terrain Control Module	SIGCFG
9H52-14D024-AA.VBF	Freelander 2 (L359)	ATCM - All Terrain Control Module	EXE
9H52-14D026-AA.VBF	Freelander 2 (L359)	ATCM - All Terrain Control Module	SBL
9W83-14C025-AA.vbf	Jaguar XK (X150)	IPC - Instrument Panel Cluster	SBL
9W83-14C026-AF.vbf	Jaguar XK (X150)	IPC - Instrument Panel Cluster (IPC) Control Module	EXE
9W83-14C028-AE.vbf	Jaguar XK (X150)	RCM - Restraints Control Module	EXE
9W83-14C060-AB.vbf	Jaguar XK (X150)	ICM - Infotainment Control Module -	EXE
9W83-14C060-BG.vbf	Jaguar XK (X150)	ICM - Infotainment Control Module -	DATA
9W83-14C061-AA.vbf	Jaguar XK (X150)	ICM - Infotainment Control Module -	DATA
9W83-14C063-AA.vbf	Jaguar XK (X150)	ICM - Infotainment Control Module -	SBL
9W83-14C090-AA.vbf	Jaguar XK (X150)	PAM - Parking Assist Control Module	EXE
9W83-14C090-BB.vbf	Jaguar XK (X150)	PAM - Parking Assist Control Module	EXE
9W83-14C098-AC.vbf	Jaguar XK (X150)	RCM - Restraints Control Module	DATA
9W83-14C098-BB.vbf	Jaguar XK (X150)	RCM - Restraints Control Module	DATA
9W83-14C098-CA.vbf	Jaguar XK (X150)	RCM - Restraints Control Module	DATA
9W83-14C098-DC.vbf	Jaguar XK (X150)	RCM - Restraints Control Module	DATA
9W83-14C098-EC.vbf	Jaguar XK (X150)	RCM - Restraints Control Module	DATA
9W83-14C098-FC.vbf	Jaguar XK (X150)	RCM - Restraints Control Module	DATA
9W83-14C098-GC.vbf	Jaguar XK (X150)	RCM - Restraints Control Module	DATA
9W83-14C098-HC.vbf	Jaguar XK (X150)	RCM - Restraints Control Module	DATA
9W83-14C098-JC.vbf	Jaguar XK (X150)	RCM - Restraints Control Module	DATA
9W83-14C098-KA.vbf	Jaguar XK (X150)	RCM - Restraints Control Module	DATA
9W83-14C098-LA.vbf	Jaguar XK (X150)	RCM - Restraints Control Module	DATA
9W83-14C145-AA.vbf	Jaguar XK (X150)	DCSM - Driver Climate Control Seat Module	EXE
9W83-14C151-AC.vbf	Jaguar XK (X150)	TPM - Tire Pressure Monitor Module	EXE
9W83-14C154-AA.vbf	Jaguar XK (X150)	DMY Dummy, Not initialised ECU	SBL
9W83-14C204-RGB.vbf	Jaguar XK (X150)	PCM - Powertrain Control Module	EXE
9W83-14C377-AA.vbf	Jaguar XK (X150)	PAM - Parking Assist Control Module	SIGCFG

File name	Vehicle line (indicative)	Module (ECU)	Type
9W83-14C395-AA.vbf	Jaguar XK (X150)	ICM - Infotainment Control Module -	DATA
9W83-14C434-AA.vbf	Jaguar XK (X150)	TPM - Tire Pressure Monitor Module	SIGCFG
9W83-14C534-AA.vbf	Jaguar XK (X150)	Not specified	SIGCFG
9W83-14C535-AA.vbf	Jaguar XK (X150)	Not specified	EXE
9W83-14C537-AA.vbf	Jaguar XK (X150)	Not specified	SBL
9W83-14C555-AB.VBF	Jaguar XK (X150)	ICM/IGM - Infotainment Control/Gateway Module	DATA
9W83-14C555-AD.vbf	Jaguar XK (X150)	ICM/IGM - Infotainment Control/Gateway Module	DATA
9W83-14C555-BB.VBF	Jaguar XK (X150)	ICM/IGM - Infotainment Control/Gateway Module	DATA
9W83-14C555-BD.vbf	Jaguar XK (X150)	ICM/IGM - Infotainment Control/Gateway Module	DATA
9W83-14C555-CB.VBF	Jaguar XK (X150)	ICM/IGM - Infotainment Control/Gateway Module	DATA
9W83-14C555-CD.vbf	Jaguar XK (X150)	ICM/IGM - Infotainment Control/Gateway Module	DATA
9W83-14C555-DB.VBF	Jaguar XK (X150)	ICM/IGM - Infotainment Control/Gateway Module	DATA
9W83-14C555-DD.vbf	Jaguar XK (X150)	ICM/IGM - Infotainment Control/Gateway Module	DATA
9W83-14D042-AC.vbf	Jaguar XK (X150)	ICS - Impact Classification System	EXE
9W83-14D519-AC.vbf	Jaguar XK (X150)	HVAC - HVAC Control Module	EXE
9W83-14D521-AA.vbf	Jaguar XK (X150)	HVAC - HVAC Control Module	SBL
9W83-4C044-AA.vbf	Jaguar XK (X150)	ecu_address = 0x795;	SBL
9W83-4C045-AD.vbf	Jaguar XK (X150)	ecu_address = 0x795;	EXE
9W83-7J104-AF.vbf	Jaguar XK (X150)	TCM - Transmission Control Module	DATA
9W83-7J104-BF.vbf	Jaguar XK (X150)	TCM - Transmission Control Module	DATA
9W83-7J105-AH.vbf	Jaguar XK (X150)	TCM - Transmission Control Module	DATA
9W83-7J105-BJ.vbf	Jaguar XK (X150)	TCM - Transmission Control Module	DATA
9W83-7J105-FE.vbf	Jaguar XK (X150)	TCM - Transmission Control Module	DATA
9W83-7J105-GE.vbf	Jaguar XK (X150)	TCM - Transmission Control Module	DATA
9W83-7J105-TD.vbf	Jaguar XK (X150)	TCM - Transmission Control Module	DATA
9W8Y-14C570-BNB.vbf	Jaguar XK (X150)	PCM - Powertrain Control Module	EXE
9W8Y-7J105-AA.VBF	Not specified	TCM - Transmission Control Module	DATA
9X23-12K532-PRK.vbf	Jaguar XF (X250)	PCM - Powertrain Control Module	DATA
9X23-12K532-PSF.vbf	Jaguar XF (X250)	PCM - Powertrain Control Module	DATA
9X23-12K532-PTM.vbf	Jaguar XF (X250)	PCM - Powertrain Control Module	DATA
9X23-14C026-AG.vbf	Jaguar XF (X250)	IPC - Instrument Panel Cluster (IPC) Control Module	EXE
9X23-14C026-BD.vbf	Jaguar XF (X250)	HUD - Head Up Display	EXE
9X23-14C028-AD.vbf	Jaguar XF (X250)	TMC Traffic Message Channel Module	EXE
9X23-14C028-BD.vbf	Jaguar XF (X250)	TMC Traffic Message Channel Module	EXE
9X23-14C036-CB.vbf	Jaguar XF (X250)	ABS - Anit-Lock Brake System (ABS) Control Module	EXE
9X23-14C036-DB.vbf	Jaguar XF (X250)	ABS - Anit-Lock Brake System (ABS) Control Module	EXE
9X23-14C060-AB.vbf	Jaguar XF (X250)	ICM - Infotainment Control Module -	EXE
9X23-14C060-BE.vbf	Jaguar XF (X250)	ICM - Infotainment Control Module -	DATA
9X23-14C061-AA.vbf	Jaguar XF (X250)	ICM - Infotainment Control Module -	DATA
9X23-14C063-AA.vbf	Jaguar XF (X250)	ICM - Infotainment Control Module -	SBL
9X23-14C065-AD.vbf	Jaguar XF (X250)	DDM - Driver Front Door Module	DATA
9X23-14C084-AD.vbf	Jaguar XF (X250)	HCM - Headlamp Control Module #1	EXE
9X23-14C084-BA.vbf	Jaguar XF (X250)	HCM - Headlamp Control Module #1	EXE
9X23-14C087-AA.vbf	Jaguar XF (X250)	HCM - Headlamp Control Module #1	SBL
9X23-14C098-AJ.vbf	Jaguar XF (X250)	TMC Traffic Message Channel Module	CARCFG
9X23-14C098-BJ.vbf	Jaguar XF (X250)	TMC Traffic Message Channel Module	CARCFG
9X23-14C098-CJ.vbf	Jaguar XF (X250)	TMC Traffic Message Channel Module	CARCFG
9X23-14C098-DJ.vbf	Jaguar XF (X250)	TMC Traffic Message Channel Module	CARCFG
9X23-14C098-EA.vbf	Jaguar XF (X250)	TMC Traffic Message Channel Module	CARCFG
9X23-14C098-FA.vbf	Jaguar XF (X250)	TMC Traffic Message Channel Module	CARCFG
9X23-14C098-GA.vbf	Jaguar XF (X250)	TMC Traffic Message Channel Module	CARCFG
9X23-14C098-HA.vbf	Jaguar XF (X250)	TMC Traffic Message Channel Module	CARCFG
9X23-14C109-AD.vbf	Jaguar XF (X250)	PDM - Passenger Front Door Module	DATA
9X23-14C184-AB.vbf	Jaguar XF (X250)	BCM - Body Control Module	EXE
9X23-14C184-BA.vbf	Jaguar XF (X250)	BCMB - Body Control Module B	EXE
9X23-14C184-BB.vbf	Jaguar XF (X250)	BCMB - Body Control Module B	EXE
9X23-14C184-CC.vbf	Jaguar XF (X250)	BCM - Body Control Module	EXE
9X23-14C184-DA.vbf	Jaguar XF (X250)	BCMB - Body Control Module B	EXE
9X23-14C273-PF.vbf	Jaguar XF (X250)	PCM - Powertrain Control Module	SBL
9X23-14C320-BA.vbf	Jaguar XF (X250)	PDM - Passenger Front Door Module	SIGCFG
9X23-14C321-BA.vbf	Jaguar XF (X250)	DDM - Driver Front Door Module	SIGCFG
9X23-14C395-AA.vbf	Jaguar XF (X250)	ICM - Infotainment Control Module -	DATA
9X23-14C407-AA.vbf	Jaguar XF (X250)	TMC Traffic Message Channel Module	SIGCFG
9X23-14C408-AB.vbf	Jaguar XF (X250)	BCM - Body Control Module	SIGCFG
9X23-14C408-BA.vbf	Jaguar XF (X250)	BCMB - Body Conrol Module	SIGCFG
9X23-14C408-BB.vbf	Jaguar XF (X250)	BCMB - Body Control Module B	SIGCFG
9X23-14C542-AF.vbf	Jaguar XF (X250)	ecu_address = 0x786;	EXE
9X23-14C570-AAG.vbf	Jaguar XF (X250)	PCM - Powertrain Control Module	EXE
9X23-14C570-DBB.vbf	Jaguar XF (X250)	PCM - Powertrain Control Module	EXE
9X23-14C570-DCA.vbf	Jaguar XF (X250)	PCM - Powertrain Control Module	EXE
9X23-14C570-DDA.vbf	Jaguar XF (X250)	PCM - Powertrain Control Module	EXE
9X23-14C570-DEB.vbf	Jaguar XF (X250)	PCM - Powertrain Control Module	EXE
9X23-14C570-DFA.vbf	Jaguar XF (X250)	PCM - Powertrain Control Module	EXE
9X23-14C570-DSA.vbf	Jaguar XF (X250)	PCM - Powertrain Control Module	EXE
9X23-14C572-AA.vbf	Jaguar XF (X250)	ECM Engine Control Module	SBL
9X23-14D042-AC.vbf	Jaguar XF (X250)	ICS - Impact Classification System	EXE

File name	Vehicle line (indicative)	Module (ECU)	Type
9X23-14D043-AB.vbf	Jaguar XF (X250)	ICS - Impact Classification System	DATA
9X23-14D046-AC.vbf	Jaguar XF (X250)	ICS - Impact Classification System	DATA
9X23-14D046-BC.vbf	Jaguar XF (X250)	ICS - Impact Classification System	DATA
9X23-14D046-CB.vbf	Jaguar XF (X250)	ICS - Impact Classification System	DATA
9X23-14D368-AC.vbf	Jaguar XF (X250)	SODL - Side Obstacle Detection Control Module - Left	EXE
9X23-14D368-BC.vbf	Jaguar XF (X250)	SODR - Side Obstacle Detection Control Module - Right	EXE
9X23-14D368-CA.vbf	Jaguar XF (X250)	SODL - Side Obstacle Detection Control Module - Left	EXE
9X23-14D646-AA.vbf	Jaguar XF (X250)	BCMB - Body Control Module B	SIGCFG
9X23-14D646-BA.vbf	Jaguar XF (X250)	BCMB - Body Control Module B	SIGCFG
9X23-14D647-AB.vbf	Jaguar XF (X250)	BCMB - Body Control Module B	EXE
9X23-14D647-BA.vbf	Jaguar XF (X250)	BCMB - Body Control Module B	EXE
9X23-18D618-AA.vbf	Jaguar XF (X250)	HVAC - HVAC Control Module	SBL
9X23-18D619-AD.vbf	Jaguar XF (X250)	HVAC - HVAC Control Module	EXE
9X23-7J104-AE.vbf	Jaguar XF (X250)	TCM - Transmission Control Module	DATA
9X23-7J104-BE.vbf	Jaguar XF (X250)	TCM - Transmission Control Module	DATA
9X23-7J104-DD.vbf	Jaguar XF (X250)	TCM - Transmission Control Module	DATA
9X23-7J104-EE.vbf	Jaguar XF (X250)	TCM - Transmission Control Module	DATA
9X23-7J104-FD.vbf	Jaguar XF (X250)	TCM - Transmission Control Module	DATA
9X23-7J105-AH.vbf	Jaguar XF (X250)	TCM - Transmission Control Module	DATA
9X23-7J105-BH.vbf	Jaguar XF (X250)	TCM - Transmission Control Module	DATA
9X23-7J105-CF.vbf	Jaguar XF (X250)	TCM - Transmission Control Module	DATA
9X23-7J105-DF.vbf	Jaguar XF (X250)	TCM - Transmission Control Module	DATA
9X23-7J105-EG.vbf	Jaguar XF (X250)	TCM - Transmission Control Module	DATA
9X23-7J105-FF.vbf	Jaguar XF (X250)	TCM - Transmission Control Module	DATA
9X23-7J105-GE.vbf	Jaguar XF (X250)	TCM - Transmission Control Module	DATA
9X23-7J105-HE.vbf	Jaguar XF (X250)	TCM - Transmission Control Module	DATA
9X2Q-14C204-PE.vbf	Not specified	PCM - Powertrain Control Module	EXE
AF6N-14C047-CJ.vbf	Not specified	Not specified	SBL
AG91-14C273-PA.vbf	Not specified	PCM - Powertrain Control Module	SBL
AG91-14C416-FA.vbf	Not specified	AHCM - Auxiliary Heater Control Module	SIGCFG
AG91-14C416-FB.vbf	Not specified	AHCM - Auxiliary Heater Control Module	SIGCFG
AG92-14C090-AC.vbf	Not specified	PAM - Parking Assist Control Module	EXE
AG92-14C090-BC.VBF	Not specified	PAM - Parking Assist Control Module	EXE
AG92-14C119-AC.vbf	Not specified	RDCM - Rear Differential Control Module	DATA
AG92-14C337-AC.VBF	Not specified	TCM Transmission Control Module	EXE
AG92-14C339-AA.vbf	Not specified	TCM - Transmission Control Module	SBL
AG92-14C339-AB.vbf	Not specified	ecu_address = 0x7E1;	SBL
AG92-14C339-BA.vbf	Not specified	CPM Combustion Preheater Module	SBL
AG92-4C045-AC.vbf	Not specified	RDCM - Rear Differential Control Module	EXE
AG9N-14C036-AA.VBF	Not specified	ABS - Anit-Lock Brake System (ABS) Control Module	EXE
AG9N-14C080-AA.vbf	Not specified	AHCM - Auxiliary Heater Control Module	EXE
AG9N-14C080-CD.vbf	Not specified	AHCM - Auxiliary Heater Control Module	EXE
AG9N-14C081-AA.vbf	Not specified	AHCM - Auxiliary Heater Control Module	DATA
AG9N-14C081-AD.vbf	Not specified	AHCM - Auxiliary Heater Control Module	DATA
AH22-12K532-KBC.vbf	Discovery 3/4 (L319)	ECM - Engine Control Module	EXE
AH22-12K532-KDC.vbf	Discovery 3/4 (L319)	ECM - Engine Control Module	EXE
AH22-12K532-KHC.vbf	Discovery 3/4 (L319)	ECM - Engine Control Module	EXE
AH22-12K532-KJC.vbf	Discovery 3/4 (L319)	ECM - Engine Control Module	EXE
AH22-12K532-KKC.vbf	Discovery 3/4 (L319)	ECM - Engine Control Module	EXE
AH22-12K532-KXC.vbf	Discovery 3/4 (L319)	ECM - Engine Control Module	EXE
AH22-12K532-KYB.vbf	Discovery 3/4 (L319)	ECM - Engine Control Module	EXE
AH22-12K532-PCJ.vbf	Discovery 3/4 (L319)	PCM - Powertrain Control Module	DATA
AH22-12K532-PSJ.vbf	Discovery 3/4 (L319)	PCM - Powertrain Control Module	DATA
AH22-12K532-PTL.vbf	Discovery 3/4 (L319)	PCM - Powertrain Control Module	DATA
AH22-14C026-AL.vbf	Discovery 3/4 (L319)	IPC - Instrument Panel Cluster (IPC) Control Module	EXE
AH22-14C026-AN.vbf	Discovery 3/4 (L319)	IPC - Instrument Panel Cluster (IPC) Control Module	EXE
AH22-14C026-AP.vbf	Discovery 3/4 (L319)	IPC - Instrument Panel Cluster (IPC) Control Module	EXE
AH22-14C027-AB.vbf	Discovery 3/4 (L319)	RCM - Restraints Control Module	SBL
AH22-14C028-AG.vbf	Discovery 3/4 (L319)	RCM - Restraints Control Module	EXE
AH22-14C029-AA.vbf	Discovery 3/4 (L319)	DSM - Driver Front Seat Module	SBL
AH22-14C030-AE.vbf	Discovery 3/4 (L319)	DSM - Driver Front Seat Module	EXE
AH22-14C044-BD.vbf	Discovery 3/4 (L319)	ACM - Audio Front Control Module	EXE
AH22-14C044-CC.vbf	Discovery 3/4 (L319)	ACM - Audio Front Control Module	EXE
AH22-14C047-AA.vbf	Discovery 3/4 (L319)	ACM - Audio Front Control Module	SBL
AH22-14C047-CB.vbf	Discovery 3/4 (L319)	ACM - Audio Front Control Module	SBL
AH22-14C064-AD.vbf	Discovery 3/4 (L319)	DDM - Driver Front Door Module	EXE
AH22-14C064-CA.vbf	Discovery 3/4 (L319)	DDM - Driver Front Door Module	EXE
AH22-14C065-DD.vbf	Discovery 3/4 (L319)	DDM - Driver Front Door Module	DATA
AH22-14C067-AA.vbf	Discovery 3/4 (L319)	DMY Dummy, Not initialised ECU	SBL
AH22-14C068-AF.vbf	Discovery 3/4 (L319)	DDM - Driver Front Door Module	EXE
AH22-14C080-AB.vbf	Discovery 3/4 (L319)	AHCM - Auxiliary Heater Control Module	EXE
AH22-14C081-AC.vbf	Discovery 3/4 (L319)	AHCM - Auxiliary Heater Control Module	DATA
AH22-14C081-BD.vbf	Discovery 3/4 (L319)	AHCM - Auxiliary Heater Control Module	EXE
AH22-14C081-CE.vbf	Discovery 3/4 (L319)	AHCM - Auxiliary Heater Control Module	EXE
AH22-14C083-AA.vbf	Discovery 3/4 (L319)	AHCM - Auxiliary Heater Control Module	SBL
AH22-14C088-AL.vbf	Discovery 3/4 (L319)	IPC - Instrument Panel Cluster (IPC) Control Module	DATA

File name	Vehicle line (indicative)	Module (ECU)	Type
AH22-14C088-AN.vbf	Discovery 3/4 (L319)	IPC - Instrument Panel Cluster (IPC) Control Module	DATA
AH22-14C088-AP.vbf	Discovery 3/4 (L319)	IPC - Instrument Panel Cluster (IPC) Control Module	DATA
AH22-14C098-AA.vbf	Discovery 3/4 (L319)	RCM - Restraints Control Module	DATA
AH22-14C098-BA.vbf	Discovery 3/4 (L319)	RCM - Restraints Control Module	DATA
AH22-14C098-DD.vbf	Discovery 3/4 (L319)	RCM - Restraints Control Module	DATA
AH22-14C098-ED.vbf	Discovery 3/4 (L319)	RCM - Restraints Control Module	DATA
AH22-14C098-FC.vbf	Discovery 3/4 (L319)	RCM - Restraints Control Module	DATA
AH22-14C098-GC.vbf	Discovery 3/4 (L319)	RCM - Restraints Control Module	DATA
AH22-14C098-HC.vbf	Discovery 3/4 (L319)	RCM - Restraints Control Module	DATA
AH22-14C098-JC.vbf	Discovery 3/4 (L319)	RCM - Restraints Control Module	DATA
AH22-14C098-KC.vbf	Discovery 3/4 (L319)	RCM - Restraints Control Module	DATA
AH22-14C098-LC.vbf	Discovery 3/4 (L319)	RCM - Restraints Control Module	DATA
AH22-14C098-MC.vbf	Discovery 3/4 (L319)	RCM - Restraints Control Module	DATA
AH22-14C098-NC.vbf	Discovery 3/4 (L319)	RCM - Restraints Control Module	DATA
AH22-14C104-AJ.vbf	Discovery 3/4 (L319)	TMC Traffic Message Channel Module	EXE
AH22-14C105-AG.vbf	Discovery 3/4 (L319)	TMC Traffic Message Channel Module	DATA
AH22-14C105-AH.vbf	Discovery 3/4 (L319)	TMC Traffic Message Channel Module	DATA
AH22-14C105-AL.vbf	Discovery 3/4 (L319)	TMC Traffic Message Channel Module	DATA
AH22-14C105-BG.vbf	Discovery 3/4 (L319)	TMC Traffic Message Channel Module	DATA
AH22-14C105-BH.vbf	Discovery 3/4 (L319)	TMC Traffic Message Channel Module	DATA
AH22-14C108-AD.vbf	Discovery 3/4 (L319)	PDM - Passenger Front Door Module	EXE
AH22-14C108-CA.vbf	Discovery 3/4 (L319)	PDM - Passenger Front Door Module	EXE
AH22-14C109-DD.vbf	Discovery 3/4 (L319)	PDM - Passenger Front Door Module	DATA
AH22-14C111-AA.vbf	Discovery 3/4 (L319)	DMY Dummy, Not initialised ECU	SBL
AH22-14C112-AF.vbf	Discovery 3/4 (L319)	PDM - Driver Front Door Module	EXE
AH22-14C168-AE.vbf	Discovery 3/4 (L319)	PBM - Park Brake Control Module	EXE
AH22-14C168-AF.vbf	Discovery 3/4 (L319)	PBM - Park Brake Control Module	EXE
AH22-14C204-GBB.vbf	Discovery 3/4 (L319)	PCM - Powertrain Control Module	EXE
AH22-14C204-GCB.vbf	Discovery 3/4 (L319)	PCM - Powertrain Control Module	EXE
AH22-14C273-GA.vbf	Discovery 3/4 (L319)	PCM - Powertrain Control Module	SBL
AH22-14C273-KB.vbf	Discovery 3/4 (L319)	PCM - Powertrain Control Module	SBL
AH22-14C320-CC.vbf	Discovery 3/4 (L319)	PDM - Passenger Front Door Module	SIGCFG
AH22-14C321-CC.vbf	Discovery 3/4 (L319)	DDM - Driver Front Door Module	SIGCFG
AH22-14C416-AA.vbf	Discovery 3/4 (L319)	AHCM - Auxiliary Heater Control Module	SIGCFG
AH22-14C527-AB.vbf	Discovery 3/4 (L319)	AAM - Audio Amplifier Module	DATA
AH22-14C527-BA.vbf	Discovery 3/4 (L319)	AAM - Audio Amplifier Module	DATA
AH22-14C534-AB.vbf	Discovery 3/4 (L319)	FCIMB - Front Controls Interface Module 'B'	SIGCFG
AH22-14C535-AF.vbf	Discovery 3/4 (L319)	FCIMB - Front Controls Interface Module 'B'	EXE
AH22-14C536-AF.vbf	Discovery 3/4 (L319)	FCIMB - Front Controls Interface Module 'B'	DATA
AH22-14C537-AB.vbf	Discovery 3/4 (L319)	FCIMB - Front Controls Interface Module 'B'	SBL
AH22-14C555-DA.vbf	Discovery 3/4 (L319)	ACM - Audio Front Control Module	DATA
AH22-14C555-EA.vbf	Discovery 3/4 (L319)	ACM - Audio Front Control Module	DATA
AH22-14D070-AB.vbf	Discovery 3/4 (L319)	FCIM - Front Controls Interface Module	SIGCFG
AH22-14D071-AG.vbf	Discovery 3/4 (L319)	FCIM - Front Controls Interface Module	EXE
AH22-14D072-AG.vbf	Discovery 3/4 (L319)	FCIM - Front Controls Interface Module	DATA
AH22-14D073-AB.vbf	Discovery 3/4 (L319)	FCIM - Front Controls Interface Module	SBL
AH22-14D197-AA.vbf	Discovery 3/4 (L319)	HCM2 - Headlamp Control Module #2	DATA
AH22-14D312-AA.vbf	Discovery 3/4 (L319)	ACM - Audio Front Control Module	GBL
AH22-14D358-AC.vbf	Discovery 3/4 (L319)	FCDIM - Front Control/Display Interface Module	EXE
AH22-14D359-AC.vbf	Discovery 3/4 (L319)	FCDIM - Front Control/Display Interface Module	EXE
AH22-14D360-AB.vbf	Discovery 3/4 (L319)	FCDIM - Front Control/Display Interface Module	SBL
AH22-14D394-AE.vbf	Discovery 3/4 (L319)	ecu_address = 0x7D3;	EXE
AH22-14D519-AE.vbf	Discovery 3/4 (L319)	HVAC - HVAC Control Module	EXE
AH22-14D521-AA.vbf	Discovery 3/4 (L319)	HVAC - HVAC Control Module	SBL
AH22-14F022-AE.vbf	Discovery 3/4 (L319)	IPMB - Image Processing Module B	DATA
AH22-7J104-EE.vbf	Discovery 3/4 (L319)	TCM - Transmission Control Module	EXE
AH22-7J104-FE.vbf	Discovery 3/4 (L319)	TCM - Transmission Control Module	EXE
AH22-7J105-AL.vbf	Discovery 3/4 (L319)	TCM - Transmission Control Module	DATA
AH22-7J105-CK.vbf	Discovery 3/4 (L319)	TCM - Transmission Control Module	DATA
AH22-7J105-EF.vbf	Discovery 3/4 (L319)	TCM - Transmission Control Module	DATA
AH22-7J105-FF.vbf	Discovery 3/4 (L319)	TCM - Transmission Control Module	DATA
AH22-7J105-GA.vbf	Discovery 3/4 (L319)	TCM - Transmission Control Module	DATA
AH22-7J105-HB.vbf	Discovery 3/4 (L319)	TCM - Transmission Control Module	DATA
AH22-7J105-KB.vbf	Discovery 3/4 (L319)	TCM - Transmission Control Module	DATA
AH22-7J105-LB.vbf	Discovery 3/4 (L319)	TCM - Transmission Control Module	DATA
AH22-7J105-SA.vbf	Discovery 3/4 (L319)	TCM - Transmission Control Module	DATA
AH22-7J105-UA.vbf	Discovery 3/4 (L319)	TCM - Transmission Control Module	DATA
AH22-7J105-VA.vbf	Discovery 3/4 (L319)	TCM - Transmission Control Module	DATA
AH2M-14D394-AB.vbf	Not specified	ecu_address = 0x7D3;	EXE
AH2Q-14C204-KHA.vbf	Not specified	PCM - Powertrain Control Module	EXE
AH32-12K532-SBE.vbf	Range Rover Sport I (L320)	PCM - Powertrain Control Module	EXE
AH32-12K532-SXE.vbf	Range Rover Sport I (L320)	PCM - Powertrain Control Module	EXE
AH32-14C098-AA.vbf	Range Rover Sport I (L320)	SRS Airbag	DATA
AH32-14C098-BA.vbf	Range Rover Sport I (L320)	SRS Airbag	DATA
AH32-14C098-CA.vbf	Range Rover Sport I (L320)	SRS Airbag	DATA
AH32-14C098-DD.vbf	Range Rover Sport I (L320)	RCM - Restraints Control Module	DATA

File name	Vehicle line (indicative)	Module (ECU)	Type
AH32-14C098-EC.vbf	Range Rover Sport I (L320)	RCM - Restraints Control Module	DATA
AH32-14C098-FC.vbf	Range Rover Sport I (L320)	RCM - Restraints Control Module	DATA
AH32-14C098-GC.vbf	Range Rover Sport I (L320)	RCM - Restraints Control Module	DATA
AH32-14C105-AG.vbf	Range Rover Sport I (L320)	TMC Traffic Message Channel Module	DATA
AH32-14C105-AH.vbf	Range Rover Sport I (L320)	TMC Traffic Message Channel Module	DATA
AH32-14C105-AL.vbf	Range Rover Sport I (L320)	TMC Traffic Message Channel Module	DATA
AH32-14C105-BG.vbf	Range Rover Sport I (L320)	TMC Traffic Message Channel Module	DATA
AH32-14C105-BH.vbf	Range Rover Sport I (L320)	TMC Traffic Message Channel Module	DATA
AH32-14C204-YEB.vbf	Range Rover Sport I (L320)	PCM - Powertrain Control Module	EXE
AH32-14C526-AB.vbf	Range Rover Sport I (L320)	AAM - Audio Amplifier Module	EXE
AH32-14C527-AA.vbf	Range Rover Sport I (L320)	AAM - Audio Amplifier Module	DATA
AH32-14C527-BA.vbf	Range Rover Sport I (L320)	AAM - Audio Amplifier Module	DATA
AH32-14C542-AE.vbf	Range Rover Sport I (L320)	ecu_address = 0x786;	EXE
AH32-14C555-DA.vbf	Range Rover Sport I (L320)	ACM - Audio Front Control Module	DATA
AH32-14C555-EA.vbf	Range Rover Sport I (L320)	ACM - Audio Front Control Module	DATA
AH32-14C555-FA.vbf	Range Rover Sport I (L320)	ACM - Audio Front Control Module	DATA
AH32-14D197-AA.vbf	Range Rover Sport I (L320)	HCM2 - Headlamp Control Module #2	DATA
AH32-14D386-AE.vbf	Range Rover Sport I (L320)	ARCM - Active Roll Control Module	EXE
AH32-14D388-AB.vbf	Range Rover Sport I (L320)	ARCM - Active Roll Control Module	SBL
AH32-14D394-AE.vbf	Range Rover Sport I (L320)	ecu_address = 0x7D3;	EXE
AH32-14D394-BE.vbf	Range Rover Sport I (L320)	ecu_address = 0x7D3;	EXE
AH32-14F022-AE.vbf	Range Rover Sport I (L320)	IPMB - Image Processing Module B	DATA
AH32-7J104-AB.vbf	Range Rover Sport I (L320)	TCM - Transmission Control Module	DATA
AH32-7J105-AL.vbf	Range Rover Sport I (L320)	TCM - Transmission Control Module	DATA
AH32-7J105-BL.vbf	Range Rover Sport I (L320)	TCM - Transmission Control Module	DATA
AH32-7J105-CK.vbf	Range Rover Sport I (L320)	TCM - Transmission Control Module	DATA
AH32-7J105-DF.vbf	Range Rover Sport I (L320)	TCM - Transmission Control Module	DATA
AH32-7J105-GE.vbf	Range Rover Sport I (L320)	TCM - Transmission Control Module	DATA
AH32-7J105-HB.vbf	Range Rover Sport I (L320)	TCM - Transmission Control Module	DATA
AH32-7J105-JB.vbf	Range Rover Sport I (L320)	TCM - Transmission Control Module	DATA
AH32-7J105-KB.vbf	Range Rover Sport I (L320)	TCM - Transmission Control Module	DATA
AH32-7J105-LB.vbf	Range Rover Sport I (L320)	TCM - Transmission Control Module	DATA
AH32-7J105-SA.vbf	Range Rover Sport I (L320)	TCM - Transmission Control Module	DATA
AH32-7J105-TA.vbf	Range Rover Sport I (L320)	TCM - Transmission Control Module	DATA
AH32-7J105-UA.vbf	Range Rover Sport I (L320)	TCM - Transmission Control Module	DATA
AH32-7J105-VA.vbf	Range Rover Sport I (L320)	TCM - Transmission Control Module	DATA
AH3M-14F022-AB.vbf	Range Rover Sport I (L320)	IPMB - Image Processing Module B	DATA
AH42-12K532-SBG.vbf	Range Rover III (L322)	PCM - Powertrain Control Module	EXE
AH42-12K532-SXH.vbf	Range Rover III (L322)	PCM - Powertrain Control Module	EXE
AH42-14C025-CC.vbf	Range Rover III (L322)	IPC - Instrument Panel Cluster (IPC) Control Module	SBL
AH42-14C026-AN.vbf	Range Rover III (L322)	IPC - Instrument Panel Cluster (IPC) Control Module	EXE
AH42-14C026-BJ.vbf	Range Rover III (L322)	IPC - Instrument Panel Cluster (IPC) Control Module	EXE
AH42-14C026-CB.vbf	Range Rover III (L322)	IPC - Instrument Panel Cluster (IPC) Control Module	EXE
AH42-14C027-AA.vbf	Range Rover III (L322)	RCM - Restraints Control Module	SBL
AH42-14C028-AE.vbf	Range Rover III (L322)	RCM - Restraints Control Module	EXE
AH42-14C030-CE.vbf	Jaguar XK (X150)	DSM - Driver Front Seat Module	EXE
AH42-14C036-AH.vbf	Range Rover III (L322)	ABS - Anit-Lock Brake System (ABS) Control Module	EXE
AH42-14C039-AB.vbf	Range Rover III (L322)	ABS - Anit-Lock Brake System (ABS) Control Module	SBL
AH42-14C044-BC.vbf	Range Rover III (L322)	ACM - Audio Front Control Module	EXE
AH42-14C047-AB.vbf	Range Rover III (L322)	ACM - Audio Front Control Module	SBL
AH42-14C064-AA.vbf	Range Rover III (L322)	DDM - Driver Front Door Module	EXE
AH42-14C088-AN.vbf	Range Rover III (L322)	IPC - Instrument Panel Cluster (IPC) Control Module	DATA
AH42-14C088-BJ.vbf	Range Rover III (L322)	IPC - Instrument Panel Cluster (IPC) Control Module	DATA
AH42-14C090-AF.vbf	Range Rover III (L322)	PAM - Parking Assist Control Module	EXE
AH42-14C098-AB.vbf	Range Rover III (L322)	RCM - Restraints Control Module	DATA
AH42-14C098-BD.vbf	Range Rover III (L322)	RCM - Restraints Control Module	DATA
AH42-14C104-AB.vbf	Range Rover III (L322)	TMC Traffic Message Channel Module	EXE
AH42-14C105-AG.vbf	Range Rover III (L322)	TMC Traffic Message Channel Module	DATA
AH42-14C105-AH.vbf	Range Rover III (L322)	TMC Traffic Message Channel Module	DATA
AH42-14C105-AL.vbf	Range Rover III (L322)	TMC Traffic Message Channel Module	DATA
AH42-14C105-BB.vbf	Range Rover Sport I (L320)	TMC Traffic Message Channel Module	DATA
AH42-14C107-AB.vbf	Range Rover III (L322)	TMC Traffic Message Channel Module	SBL
AH42-14C108-AA.vbf	Range Rover III (L322)	PDM - Passenger Front Door Module	EXE
AH42-14C172-AA.vbf	Check in SDD (unconfirmed)	CCM - Cruise Control Module	EXE
AH42-14C187-AB.vbf	Range Rover III (L322)	BCM - Body Control Module	SBL
AH42-14C273-SB.vbf	Range Rover III (L322)	PCM - Powertrain Control Module	SBL
AH42-14C341-AA.vbf	Range Rover III (L322)	Not specified	EXE
AH42-14C343-AA.vbf	Range Rover III (L322)	Not specified	SBL
AH42-14C366-AE.vbf	Range Rover III (L322)	ecu_address = 0x761;	EXE
AH42-14C366-BA.vbf	Range Rover III (L322)	ecu_address = 0x761;	EXE
AH42-14C368-AB.vbf	Range Rover III (L322)	ecu_address = 0x761;	SBL
AH42-14C377-AC.vbf	Range Rover III (L322)	PAM - Parking Assist Control Module	SIGCFG
AH42-14C389-AE.vbf	Range Rover III (L322)	TCM - Transmission Control Module	SIGCFG
AH42-14C413-AA.vbf	Check in SDD (unconfirmed)	DSM - Driver Front Seat Module	SIGCFG
AH42-14C413-BB.vbf	Check in SDD (unconfirmed)	DSM - Driver Front Seat Module	SIGCFG
AH42-14C430-AB.vbf	Range Rover III (L322)	TMC Traffic Message Channel Module	DATA

File name	Vehicle line (indicative)	Module (ECU)	Type
AH42-14C526-AJ.vbf	Range Rover III (L322)	AAM - Audio Amplifier Module	EXE
AH42-14C526-BC.vbf	Range Rover III (L322)	AAM - Audio Amplifier Module	EXE
AH42-14C526-CB.vbf	Range Rover III (L322)	AAM - Audio Amplifier Module	EXE
AH42-14C527-AF.vbf	Range Rover III (L322)	AAM - Audio Amplifier Module	DATA
AH42-14C527-BA.vbf	Range Rover III (L322)	AAM - Audio Amplifier Module	DATA
AH42-14C527-CA.vbf	Range Rover III (L322)	AAM - Audio Amplifier Module	DATA
AH42-14C542-AH.vbf	Range Rover III (L322)	ecu_address = 0x786;	EXE
AH42-14C547-BA.vbf	Check in SDD (unconfirmed)	PSM - Passenger Front Seat Module	SIGCFG
AH42-14C548-CE.vbf	Jaguar XK (X150)	PSM - Passenger Front Seat Module	EXE
AH42-14C554-AA.vbf	Range Rover III (L322)	ACM - Audio Front Control Module	EXE
AH42-14C555-CA.vbf	Range Rover III (L322)	ACM - Audio Front Control Module	DATA
AH42-14C555-DA.vbf	Range Rover III (L322)	ACM - Audio Front Control Module	DATA
AH42-14C556-AB.vbf	Range Rover III (L322)	ACM - Audio Front Control Module	SBL
AH42-14C579-AA.vbf	Range Rover III (L322)	VIM - Vehicle Immobilizer Control Module	EXE
AH42-14C581-AA.vbf	Range Rover III (L322)	ESCL - Electric Steering Column Lock [CAN HS]	SBL
AH42-14C596-AC.vbf	Range Rover III (L322)	REM - Rear Entertainment Control Module	EXE
AH42-14C598-AA.vbf	Range Rover III (L322)	REM - Rear Entertainment Control Module	SBL
AH42-14D023-AA.vbf	Range Rover III (L322)	ATCM - All Terrain Control Module	SIGCFG
AH42-14D024-AC.vbf	Range Rover III (L322)	ATCM - All Terrain Control Module	EXE
AH42-14D026-AA.vbf	Range Rover III (L322)	ATCM - All Terrain Control Module	SBL
AH42-14D195-AB.vbf	Range Rover III (L322)	HCM2 - Headlamp Control Module #2	SIGCFG
AH42-14D195-AC.vbf	Range Rover III (L322)	HCM2 - Headlamp Control Module #2	SIGCFG
AH42-14D196-AA.vbf	Range Rover III (L322)	HCM2 - Headlamp Control Module #2	EXE
AH42-14D196-AC.vbf	Range Rover III (L322)	HCM2 - Headlamp Control Module #2	EXE
AH42-14D196-AF.vbf	Range Rover III (L322)	HCM2 - Headlamp Control Module #2	EXE
AH42-14D197-AC.vbf	Range Rover III (L322)	HCM2 - Headlamp Control Module #2	DATA
AH42-14D197-AE.vbf	Range Rover III (L322)	HCM2 - Headlamp Control Module #2	DATA
AH42-14D198-AA.vbf	Range Rover III (L322)	HCM2 - Headlamp Control Module #2	SBL
AH42-14D205-AL.vbf	Range Rover III (L322)	APIM - Accessory Protocol Interface Module	EXE
AH42-14D207-AA.vbf	Range Rover III (L322)	APIM - Accessory Protocol Interface Module	SBL
AH42-14D312-AB.vbf	Range Rover III (L322)	ACM - Audio Front Control Module	GBL
AH42-14D367-AB.vbf	Range Rover III (L322)	SODL - Side Obstacle Detection Control Module - Left	SIGCFG
AH42-14D367-BB.vbf	Range Rover III (L322)	SODR - Side Obstacle Detection Control Module - Right	SIGCFG
AH42-14D368-AJ.vbf	Range Rover III (L322)	SODL - Side Obstacle Detection Control Module - Left	EXE
AH42-14D368-BB.vbf	Range Rover III (L322)	SODR - Side Obstacle Detection Control Module - Right	EXE
AH42-14D368-BJ.vbf	Range Rover III (L322)	SODR - Side Obstacle Detection Control Module - Right	EXE
AH42-14D368-CA.vbf	Range Rover III (L322)	Not specified	EXE
AH42-14D394-AH.vbf	Range Rover III (L322)	ecu_address = 0x7D3;	EXE
AH42-14D396-AA.vbf	Range Rover III (L322)	ecu_address = 0x7D3;	SBL
AH42-14D403-AE.vbf	Range Rover III (L322)	DABM - Digital Audio Broadcast Module	EXE
AH42-14D405-AB.vbf	Range Rover III (L322)	DABM - Digital Audio Broadcast Module	SBL
AH42-14D408-AD.vbf	Range Rover III (L322)	DABM - Digital Audio Broadcast Module	DATA
AH42-14D418-AF.vbf	Range Rover III (L322)	Not specified	EXE
AH42-14D419-AF.vbf	Range Rover III (L322)	Not specified	EXE
AH42-14D519-AB.vbf	Range Rover III (L322)	RHVAC - Rear HVAC Control Module	EXE
AH42-14D521-AA.vbf	Range Rover III (L322)	RHVAC - Rear HVAC Control Module	SBL
AH42-14D592-AA.vbf	Range Rover III (L322)	RDUM - Remote Driver Utility Module	SIGCFG
AH42-14D593-AB.vbf	Range Rover III (L322)	RDUM - Remote Driver Utility Module	EXE
AH42-14D595-AA.vbf	Range Rover III (L322)	RDUM - Remote Driver Utility Module	SBL
AH42-14F016-AA.vbf	Range Rover III (L322)	IPMB - Image Processing Module B	SIGCFG
AH42-14F017-AN.vbf	Range Rover III (L322)	IPMB - Image Processing Module B	EXE
AH42-14F019-AB.vbf	Range Rover III (L322)	IPMB - Image Processing Module B	SBL
AH42-14F022-AG.vbf	Range Rover III (L322)	IPMB - Image Processing Module B	DATA
AH42-18D618-AA.vbf	Range Rover III (L322)	HVAC - HVAC Control Module	SBL
AH42-18D619-AL.vbf	Range Rover III (L322)	HVAC - HVAC Control Module	EXE
AH42-18D620-AH.vbf	Range Rover III (L322)	HVAC - HVAC Control Module	DATA
AH42-18D620-BG.vbf	Range Rover III (L322)	HVAC - HVAC Control Module	DATA
AH42-18D620-CG.vbf	Range Rover III (L322)	HVAC - HVAC Control Module	DATA
AH42-18D620-DG.vbf	Range Rover III (L322)	HVAC - HVAC Control Module	DATA
AH42-18D620-EF.vbf	Range Rover III (L322)	HVAC - HVAC Control Module	DATA
AH42-18D620-FF.vbf	Range Rover III (L322)	HVAC - HVAC Control Module	DATA
AH42-7J104-AJ.vbf	Range Rover III (L322)	TCM - Transmission Control Module	EXE
AH42-7J104-DD.vbf	Range Rover III (L322)	TCM - Transmission Control Module	EXE
AH42-7J104-DE.vbf	Range Rover III (L322)	TCM - Transmission Control Module	EXE
AH42-7J104-SA.vbf	Range Rover III (L322)	TCM - Transmission Control Module	EXE
AH42-7J105-AM.vbf	Range Rover III (L322)	TCM - Transmission Control Module	DATA
AH42-7J105-BM.vbf	Range Rover III (L322)	TCM - Transmission Control Module	DATA
AH42-7J105-DG.vbf	Range Rover III (L322)	TCM - Transmission Control Module	DATA
AH42-7J105-HB.vbf	Range Rover III (L322)	TCM - Transmission Control Module	DATA
AH42-7J105-JB.vbf	Range Rover III (L322)	TCM - Transmission Control Module	DATA
AH42-7J244-AC.vbf	Range Rover III (L322)	TCM - Transmission Control Module	SBL
AH4M-14D394-AC.vbf	Not specified	ecu_address = 0x7D3;	EXE
AH4Q-14C204-SBD.vbf	Not specified	PCM - Powertrain Control Module	EXE
AH52-14C044-AC.vbf	Freelander 2 (L359)	ICM Infotainment Control Module	EXE
AH52-14C044-BC.vbf	Freelander 2 (L359)	ICM Infotainment Control Module	EXE
AH52-14C084-AA.VBF	Freelander 2 (L359)	HCM - Headlamp Control Module #1	EXE

File name	Vehicle line (indicative)	Module (ECU)	Type
AH52-14C087-AA.VBF	Freelander 2 (L359)	HCM - Headlamp Control Module #1	SBL
AH52-14C204-JEC.vbf	Freelander 2 (L359)	PCM - Powertrain Control Module	EXE
AH52-14C204-JFA.vbf	Freelander 2 (L359)	PCM - Powertrain Control Module	EXE
AH52-14C204-JGA.vbf	Freelander 2 (L359)	PCM - Powertrain Control Module	EXE
AH52-14C204-JHA.vbf	Freelander 2 (L359)	PCM - Powertrain Control Module	EXE
AH52-14C204-JNA.vbf	Freelander 2 (L359)	PCM - Powertrain Control Module	EXE
AH52-14C555-AA.vbf	Freelander 2 (L359)	ICM/IGM - Infotainment Control/Gateway Module	DATA
AM5T-14C093-AB.vbf	Not specified	PAM - Parking Assist Control Module	SBL
AMAH42-14C185-AD.vbf	Not specified	RBM - Running Board Control Module	EXE
AMAH42-14C360-AB.vbf	Not specified	RBM - Running Board Control Module	SBL
AMCK5M-14C358-AA.vbf	Not specified	RBM - Running Board Control Module	EXE
AW83-7J105-KD.vbf	Jaguar XK (X150)	TCM - Transmission Control Module	DATA
AW93-12K532-PTG.vbf	Jaguar XJ (X351)	PCM - Powertrain Control Module	DATA
AW93-14C027-AB.vbf	Jaguar XJ (X351)	RCM - Restraints Control Module	SBL
AW93-14C028-AD.vbf	Jaguar XJ (X351)	RCM - Restraints Control Module	EXE
AW93-14C028-BD.vbf	Jaguar XJ (X351)	RCM - Restraints Control Module	EXE
AW93-14C028-CA.vbf	Jaguar XJ (X351)	RCM - Restraints Control Module	EXE
AW93-14C028-DA.vbf	Jaguar XJ (X351)	RCM - Restraints Control Module	EXE
AW93-14C036-CC.vbf	Jaguar XJ (X351)	ABS - Anit-Lock Brake System (ABS) Control Module	EXE
AW93-14C036-DC.vbf	Jaguar XJ (X351)	ABS - Anit-Lock Brake System (ABS) Control Module	EXE
AW93-14C045-AH.vbf	Jaguar XJ (X351)	ICM - Infotainment Control Module	DATA
AW93-14C098-AC.vbf	Jaguar XJ (X351)	RCM - Restraints Control Module	DATA
AW93-14C098-BD.vbf	Jaguar XJ (X351)	RCM - Restraints Control Module	DATA
AW93-14C098-CD.vbf	Jaguar XJ (X351)	RCM - Restraints Control Module	DATA
AW93-14C098-FA.vbf	Jaguar XJ (X351)	RCM - Restraints Control Module	DATA
AW93-14C098-GA.vbf	Jaguar XJ (X351)	RCM - Restraints Control Module	DATA
AW93-14C105-AE.vbf	Jaguar XJ (X351)	TMC Traffic Message Channel Module	DATA
AW93-14C105-AF.vbf	Jaguar XJ (X351)	TMC Traffic Message Channel Module	DATA
AW93-14C105-AG.vbf	Jaguar XJ (X351)	TMC Traffic Message Channel Module	DATA
AW93-14C105-AH.vbf	Jaguar XJ (X351)	TMC Traffic Message Channel Module	DATA
AW93-14C105-BF.vbf	Jaguar XJ (X351)	TMC Traffic Message Channel Module	DATA
AW93-14C105-BG.vbf	Jaguar XJ (X351)	TMC Traffic Message Channel Module	DATA
AW93-14C121-AG.vbf	Jaguar XJ (X351)	RGTM - Rear Gate / Trunk Module	EXE
AW93-14C122-AG.vbf	Jaguar XJ (X351)	RGTM - Rear Gate / Trunk Module	DATA
AW93-14C124-AB.vbf	Jaguar XJ (X351)	RGTM - Rear Gate / Trunk Module	SBL
AW93-14C144-AE.vbf	Jaguar XJ (X351)	DCSM - Driver Climate Control Seat Module	EXE
AW93-14C145-CA.vbf	Jaguar XJ (X351)	DCSM - Driver Climate Control Seat Module	EXE
AW93-14C145-DA.vbf	Jaguar XJ (X351)	DCSM - Driver Climate Control Seat Module	EXE
AW93-14C147-AA.vbf	Jaguar XJ (X351)	DMY Dummy, Not initialised ECU	SBL
AW93-14C147-BA.vbf	Jaguar XJ (X351)	DCSM - Driver Climate Control Seat Module	SBL
AW93-14C185-AC.vbf	Jaguar XJ (X351)	BCM - Body Control Module	DATA
AW93-14C342-AA.vbf	Jaguar XJ (X351)	Not specified	DATA
AW93-14C407-AC.vbf	Jaguar XJ (X351)	RCM - Restraints Control Module	SIGCFG
AW93-14C407-AD.vbf	Jaguar XJ (X351)	RCM - Restraints Control Module	SIGCFG
AW93-14C433-AB.vbf	Jaguar XJ (X351)	RGTM - Rear Gate / Trunk Module	SIGCFG
AW93-14C526-BR.vbf	Jaguar XJ (X351)	Not specified	EXE
AW93-14C526-CV.vbf	Jaguar XJ (X351)	Not specified	EXE
AW93-14C527-AU.vbf	Jaguar XJ (X351)	Not specified	DATA
AW93-14C527-BU.vbf	Jaguar XJ (X351)	Not specified	DATA
AW93-14C527-CX.vbf	Jaguar XJ (X351)	Not specified	DATA
AW93-14C527-DU.vbf	Jaguar XJ (X351)	Not specified	DATA
AW93-14C527-EU.vbf	Jaguar XJ (X351)	Not specified	DATA
AW93-14C527-FX.vbf	Jaguar XJ (X351)	Not specified	DATA
AW93-14C534-AB.vbf	Jaguar XJ (X351)	FCIMB - Front Controls Interface Module 'B'	SIGCFG
AW93-14C535-AB.vbf	Jaguar XJ (X351)	FCIMB - Front Controls Interface Module 'B'	EXE
AW93-14C535-AD.vbf	Jaguar XJ (X351)	FCIMB - Front Controls Interface Module 'B'	EXE
AW93-14C536-AB.vbf	Jaguar XJ (X351)	FCIMB - Front Controls Interface Module 'B'	CUSTOM
AW93-14C536-AC.vbf	Jaguar XJ (X351)	FCIMB - Front Controls Interface Module 'B'	CUSTOM
AW93-14C537-AA.vbf	Jaguar XJ (X351)	FCIMB - Front Controls Interface Module 'B'	SBL
AW93-14C542-AK.vbf	Jaguar XJ (X351)	ecu_address = 0x786;	EXE
AW93-14D368-CA.vbf	Jaguar XJ (X351)	SODL - Side Obstacle Detection Control Module - Left	EXE
AW93-14D394-AH.vbf	Jaguar XJ (X351)	ecu_address = 0x7D3;	EXE
AW93-14D408-AA.vbf	Jaguar XJ (X351)	Not specified	DATA
AW93-14D418-AH.vbf	Jaguar XJ (X351)	Not specified	EXE
AW93-14D418-BF.vbf	Jaguar XJ (X351)	Not specified	EXE
AW93-14D419-AH.vbf	Jaguar XJ (X351)	Not specified	EXE
AW93-14D419-BF.vbf	Jaguar XJ (X351)	Not specified	EXE
AW93-14D420-AC.vbf	Jaguar XJ (X351)	Not specified	DATA
AW93-14D420-BD.vbf	Jaguar XJ (X351)	Not specified	DATA
AW93-14D519-AE.vbf	Jaguar XJ (X351)	HVAC - HVAC Control Module	EXE
AW93-14D519-YA.vbf	Jaguar XJ (X351)	HVAC - HVAC Control Module	EXE
AW93-14D521-AA.vbf	Jaguar XJ (X351)	HVAC - HVAC Control Module	SBL
AW93-14F216-AB.vbf	Jaguar XJ (X351)	RHVAC - Rear HVAC Control Module	SIGCFG
AW93-14F217-AD.vbf	Jaguar XJ (X351)	RHVAC - Rear HVAC Control Module	EXE
AW93-14F218-AB.vbf	Jaguar XJ (X351)	RHVAC - Rear HVAC	CUSTOM
AW93-14F219-AA.vbf	Jaguar XJ (X351)	RHVAC - Rear HVAC Control Module	SBL

File name	Vehicle line (indicative)	Module (ECU)	Type
AW93-14F352-ED.vbf	Jaguar XJ (X351)	SPMA - Seatbelt Pretensioner Control Module "A"	EXE
AW93-14F353-EC.vbf	Jaguar XJ (X351)	SPMA - Seatbelt Pretensioner Control Module "A"	DATA
AW93-14F354-EA.vbf	Jaguar XJ (X351)	SPMA - Seatbelt Pretensioner Control Module "A"	SBL
AW93-14F357-EC.vbf	Jaguar XJ (X351)	SPMA - Seatbelt Pretensioner Control Module "A"	DATA
AW93-14F365-ED.vbf	Jaguar XJ (X351)	SPMB - Seatbelt Pretensioner Control Module "B"	EXE
AW93-14F366-EC.vbf	Jaguar XJ (X351)	SPMB - Seatbelt Pretensioner Control Module "B"	DATA
AW93-14F367-EA.vbf	Jaguar XJ (X351)	SPMB - Seatbelt Pretensioner Control Module "B"	SBL
AW93-14F370-EC.vbf	Jaguar XJ (X351)	SPMB - Seatbelt Pretensioner Control Module "B"	DATA
AW93-7J105-AH.vbf	Jaguar XJ (X351)	TCM - Transmission Control Module	DATA
AW93-7J105-BE.vbf	Jaguar XJ (X351)	TCM - Transmission Control Module	DATA
AW93-7J105-CF.vbf	Jaguar XJ (X351)	TCM - Transmission Control Module	DATA
AW93-7J105-EG.vbf	Jaguar XJ (X351)	TCM - Transmission Control Module	DATA
AW93-7J105-JA.vbf	Jaguar XJ (X351)	TCM - Transmission Control Module	DATA
AW93-7J105-KA.vbf	Jaguar XJ (X351)	TCM - Transmission Control Module	DATA
AW93-7J105-LE.vbf	Jaguar XJ (X351)	TCM - Transmission Control Module	DATA
AX23-14C036-AC.vbf	Jaguar XF (X250)	ABS - Anit-Lock Brake System (ABS) Control Module	EXE
AX23-14C036-BC.vbf	Jaguar XF (X250)	ABS - Anit-Lock Brake System (ABS) Control Module	EXE
AX23-14C542-AA.vbf	Jaguar XF (X250)	ecu_address = 0x786;	EXE
AX23-14C554-AA.vbf	Jaguar XF (X250)	ICM/IGM - Infotainment Control/Gateway Module	EXE
AX23-14C555-AA.vbf	Jaguar XF (X250)	ICM/IGM - Infotainment Control/Gateway Module	DATA
AX23-14C556-AA.vbf	Jaguar XF (X250)	ICM/IGM - Infotainment Control/Gateway Module	SBL
AX23-14D419-AA.vbf	Jaguar XF (X250)	Not specified	EXE
BF6N-14C044-AAR.vbf	Not specified	Not specified	EXE
BF6N-14C044-AAT.vbf	Not specified	Not specified	EXE
BF6N-14C044-AAU.vbf	Not specified	Not specified	EXE
BF6N-14C044-AAV.vbf	Not specified	Not specified	EXE
BF6N-14C044-AAX.vbf	Not specified	Not specified	EXE
BF6N-14C044-JAC.vbf	Not specified	Not specified	EXE
BF6N-14C044-JAE.vbf	Not specified	Not specified	EXE
BF6N-14C044-JAF.vbf	Not specified	Not specified	EXE
BF6N-14C044-JAG.vbf	Not specified	Not specified	EXE
BF6N-14C044-JAH.vbf	Not specified	Not specified	EXE
BF6N-14C044-JAJ.vbf	Not specified	Not specified	EXE
BF6N-14C044-JAK.vbf	Not specified	Not specified	EXE
BF6N-14C044-KAJ.vbf	Not specified	Not specified	EXE
BF6N-14C044-KAR.vbf	Not specified	Not specified	EXE
BF6N-14C044-KAT.vbf	Not specified	Not specified	EXE
BF6N-14C044-KAU.vbf	Not specified	Not specified	EXE
BF6N-14C044-KAV.vbf	Not specified	Not specified	EXE
BF6N-14C044-KAX.vbf	Not specified	Not specified	EXE
BF6N-14C044-LAK.vbf	Not specified	Not specified	EXE
BF6N-14C044-LAR.vbf	Not specified	Not specified	EXE
BF6N-14C044-LAS.vbf	Not specified	Not specified	EXE
BF6N-14C044-LAT.vbf	Not specified	Not specified	EXE
BF6N-14C044-LAU.vbf	Not specified	Not specified	EXE
BF6N-14C044-LAV.vbf	Not specified	Not specified	EXE
BF6N-14C044-MAF.vbf	Not specified	Not specified	EXE
BF6N-14C044-MAH.vbf	Not specified	Not specified	EXE
BF6N-14C044-MAJ.vbf	Not specified	Not specified	EXE
BF6N-14C044-MAK.vbf	Not specified	Not specified	EXE
BF6N-14C044-MAL.vbf	Not specified	Not specified	EXE
BF6N-14C044-NAH.vbf	Not specified	Not specified	EXE
BF6N-14C044-NAM.vbf	Not specified	Not specified	EXE
BF6N-14C044-NAR.vbf	Not specified	Not specified	EXE
BF6N-14C044-NAS.vbf	Not specified	Not specified	EXE
BF6N-14C044-NAT.vbf	Not specified	Not specified	EXE
BF6N-14C044-NAU.vbf	Not specified	Not specified	EXE
BF6N-14C044-NBA.vbf	Not specified	Not specified	EXE
BF6N-14C044-RAK.vbf	Not specified	Not specified	EXE
BF6N-14C044-RAS.vbf	Not specified	Not specified	EXE
BF6N-14C044-RAT.vbf	Not specified	Not specified	EXE
BF6N-14C044-RAU.vbf	Not specified	Not specified	EXE
BF6N-14C044-RAV.vbf	Not specified	Not specified	EXE
BF6N-14C044-RAX.vbf	Not specified	Not specified	EXE
BF6N-14C047-BC.vbf	Not specified	Not specified	SBL
BF6N-14C047-CC.vbf	Not specified	Not specified	SBL
BF6N-14C047-CE.vbf	Not specified	Not specified	SBL
BF6N-14C047-CH.vbf	Not specified	Not specified	SBL
BF6N-14C047-CK.vbf	Not specified	Not specified	SBL
BG92-14C337-AD.vbf	Not specified	TCM Transmission Control Module	EXE
BG92-14C337-BA.VBF	Not specified	TCM Transmission Control Module	EXE
BG92-14C337-CB.vbf	Not specified	TCM Transmission Control Module	EXE
BG92-14C337-DB.vbf	Not specified	TCM Transmission Control Module	EXE
BG9T-14C094-KC.vbf	Freelander 2 (L359)	GPS Global Positioning System module	EXE
BG9T-14C094-KD.vbf	Freelander 2 (L359)	GPS Global Positioning System module	EXE
BG9T-14C095-KB.vbf	Freelander 2 (L359)	GPS Global Positioning System module	DATA

File name	Vehicle line (indicative)	Module (ECU)	Type
BG9T-14C403-KA.vbf	Freelander 2 (L359)	BCM - Body Control Module	SIGCFG
BH22-14C044-AE.vbf	Discovery 3/4 (L319)	ACM - Audio Front Control Module	EXE
BH22-14C185-AA.vbf	Discovery 3/4 (L319)	BCM - Body Control Module	DATA
BH22-14D394-AC.vbf	Discovery 3/4 (L319)	ecu_address = 0x7D3;	EXE
BH2M-14D394-AC.vbf	Not specified	ecu_address = 0x7D3;	EXE
BH32-14D048-AA.vbf	Range Rover Sport I (L320)	CCM - Cruise Control Module	SIGCFG
BH32-14D049-AD.vbf	Range Rover Sport I (L320)	CCM - Cruise Control Module	EXE
BH32-14D049-BC.vbf	Range Rover Sport I (L320)	CCM - Cruise Control Module	EXE
BH32-14D394-AC.vbf	Range Rover Sport I (L320)	ecu_address = 0x7D3;	EXE
BH32-14D394-BC.vbf	Range Rover Sport I (L320)	ecu_address = 0x7D3;	EXE
BH42-12K532-NCK.vbf	Range Rover III (L322)	PCM - Powertrain Control Module	DATA
BH42-12K532-NTL.vbf	Range Rover III (L322)	PCM - Powertrain Control Module	DATA
BH42-14C036-AE.vbf	Range Rover III (L322)	ABS - Anit-Lock Brake System (ABS) Control Module	EXE
BH42-14C039-AA.vbf	Range Rover III (L322)	ABS - Anit-Lock Brake System (ABS) Control Module	SBL
BH42-14C044-AD.vbf	Range Rover III (L322)	ACM - Audio Front Control Module	EXE
BH42-14C056-GC.vbf	Range Rover III (L322)	FECM - Multimedia Module	EXE
BH42-14C056-GD.vbf	Range Rover III (L322)	FECM - Multimedia Module	EXE
BH42-14C056-GE.vbf	Range Rover III (L322)	FECM - Multimedia Module	EXE
BH42-14C056-HC.vbf	Range Rover III (L322)	FECM - Multimedia Module	EXE
BH42-14C056-HD.vbf	Range Rover III (L322)	FECM - Multimedia Module	EXE
BH42-14C056-HE.vbf	Range Rover III (L322)	FECM - Multimedia Module	EXE
BH42-14C056-JD.vbf	Range Rover III (L322)	FECM - Multimedia Module	EXE
BH42-14C056-JE.vbf	Range Rover III (L322)	FECM - Multimedia Module	EXE
BH42-14C056-JF.vbf	Range Rover III (L322)	FECM - Multimedia Module	EXE
BH42-14C056-KC.vbf	Range Rover III (L322)	FECM - Multimedia Module	EXE
BH42-14C056-KD.vbf	Range Rover III (L322)	FECM - Multimedia Module	EXE
BH42-14C056-KE.vbf	Range Rover III (L322)	FECM - Multimedia Module	EXE
BH42-14C056-LC.vbf	Range Rover III (L322)	FECM - Multimedia Module	EXE
BH42-14C056-LD.vbf	Range Rover III (L322)	FECM - Multimedia Module	EXE
BH42-14C056-LE.vbf	Range Rover III (L322)	FECM - Multimedia Module	EXE
BH42-14C064-AA.vbf	Range Rover III (L322)	DDM - Driver Front Door Module	EXE
BH42-14C065-AA.vbf	Range Rover III (L322)	DDM - Driver Front Door Module	DATA
BH42-14C065-AC.vbf	Range Rover III (L322)	DDM - Driver Front Door Module	DATA
BH42-14C067-AA.vbf	Range Rover III (L322)	DDM	SBL
BH42-14C068-AA.vbf	Range Rover III (L322)	DDM - Driver Front Door Module	EXE
BH42-14C098-AA.vbf	Range Rover III (L322)	RCM - Restraints Control Module	DATA
BH42-14C108-AA.vbf	Range Rover III (L322)	PDM - Passenger Front Door Module	EXE
BH42-14C109-AA.vbf	Range Rover III (L322)	PDM - Passenger Front Door Module	DATA
BH42-14C109-AC.vbf	Range Rover III (L322)	PDM - Passenger Front Door Module	DATA
BH42-14C111-AA.vbf	Range Rover III (L322)	PDM	SBL
BH42-14C112-AA.vbf	Range Rover III (L322)	PDM - Passenger Front Door Module	EXE
BH42-14C184-AD.vbf	Range Rover III (L322)	BCM - Body Control Module	EXE
BH42-14C185-AA.vbf	Range Rover III (L322)	BCM - Body Control Module	DATA
BH42-14C204-NTD.vbf	Range Rover III (L322)	PCM - Powertrain Control Module	EXE
BH42-14C273-NA.vbf	Range Rover III (L322)	PCM - Powertrain Control Module	SBL
BH42-14C320-AA.vbf	Check in SDD (unconfirmed)	DDM - Driver Front Door Module	SIGCFG
BH42-14C321-AA.vbf	Check in SDD (unconfirmed)	DDM - Driver Front Door Module	SIGCFG
BH42-14C389-HB.vbf	Range Rover III (L322)	TCM - Transmission Control Module	SIGCFG
BH42-14C408-AA.vbf	Range Rover III (L322)	BCM - Body Control Module	SIGCFG
BH42-14C560-AA.vbf	Range Rover III (L322)	GSM - Gear Shift Module	SIGCFG
BH42-14C561-AG.vbf	Range Rover III (L322)	GSM - Gear Shift Module	EXE
BH42-14D024-AB.vbf	Range Rover III (L322)	ATCM - All Terrain Control Module	EXE
BH42-14D394-AC.vbf	Range Rover III (L322)	ecu_address = 0x7D3;	EXE
BH42-14D418-BA.vbf	Range Rover III (L322)	Not specified	EXE
BH42-14D419-BA.vbf	Range Rover III (L322)	Not specified	EXE
BH42-18D618-AA.vbf	Range Rover III (L322)	HVAC - HVAC Control Module	SBL
BH42-18D619-AF.vbf	Range Rover III (L322)	HVAC - HVAC Control Module	EXE
BH42-18D620-AF.vbf	Range Rover III (L322)	HVAC - HVAC Control Module	DATA
BH42-18D620-BF.vbf	Range Rover III (L322)	HVAC - HVAC Control Module	DATA
BH42-18D620-CF.vbf	Range Rover III (L322)	HVAC - HVAC Control Module	DATA
BH42-18D620-DF.vbf	Range Rover III (L322)	HVAC - HVAC Control Module	DATA
BH42-18D620-EF.vbf	Range Rover III (L322)	HVAC - HVAC Control Module	DATA
BH42-18D620-FF.vbf	Range Rover III (L322)	HVAC - HVAC Control Module	DATA
BH42-18D620-GD.vbf	Range Rover III (L322)	HVAC - HVAC Control Module	DATA
BH42-18D620-KA.vbf	Range Rover III (L322)	HVAC - HVAC Control Module	DATA
BH42-18D620-LA.vbf	Range Rover III (L322)	HVAC - HVAC Control Module	DATA
BH42-7J104-HF.vbf	Range Rover III (L322)	TCM - Transmission Control Module	EXE
BH42-7J105-HK.vbf	Range Rover III (L322)	TCM - Transmission Control Module	DATA
BH42-7J244-HB.vbf	Range Rover III (L322)	TCM - Transmission Control Module	SBL
BH4M-14D394-AB.vbf	Not specified	ecu_address = 0x7D3;	EXE
BH52-12K532-VAD.vbf	Freelander 2 (L359)	PCM - Powertrain Control Module	DATA
BH52-12K532-VBG.vbf	Freelander 2 (L359)	PCM - Powertrain Control Module	DATA
BH52-12K532-VCG.vbf	Freelander 2 (L359)	PCM - Powertrain Control Module	DATA
BH52-12K532-VDF.vbf	Freelander 2 (L359)	PCM - Powertrain Control Module	DATA
BH52-12K532-VEF.vbf	Freelander 2 (L359)	PCM - Powertrain Control Module	DATA
BH52-12K532-VFF.vbf	Freelander 2 (L359)	PCM - Powertrain Control Module	DATA

File name	Vehicle line (indicative)	Module (ECU)	Type
BH52-12K532-VHC.vbf	Freelander 2 (L359)	PCM - Powertrain Control Module	DATA
BH52-12K532-VJG.vbf	Freelander 2 (L359)	PCM - Powertrain Control Module	DATA
BH52-12K532-VRA.vbf	Freelander 2 (L359)	PCM - Powertrain Control Module	DATA
BH52-12K532-VSG.vbf	Freelander 2 (L359)	PCM - Powertrain Control Module	DATA
BH52-12K532-VTG.vbf	Freelander 2 (L359)	PCM - Powertrain Control Module	DATA
BH52-14C026-AF.vbf	Freelander 2 (L359)	IPC - Instrument Panel Cluster (IPC) Control Module	EXE
BH52-14C036-AA.vbf	Freelander 2 (L359)	ABS - Anit-Lock Brake System (ABS) Control Module	EXE
BH52-14C036-BC.vbf	Freelander 2 (L359)	ABS - Anit-Lock Brake System (ABS) Control Module	EXE
BH52-14C039-AA.vbf	Freelander 2 (L359)	ABS - Anit-Lock Brake System (ABS) Control Module	SBL
BH52-14C068-BA.vbf	Freelander 2 (L359)	DDM - Driver Front Door Module	EXE
BH52-14C081-AA.vbf	Freelander 2 (L359)	AHCM - Auxiliary Heater Control Module	DATA
BH52-14C088-AF.vbf	Freelander 2 (L359)	IPC - Instrument Panel Cluster (IPC) Control Module	DATA
BH52-14C088-BF.vbf	Freelander 2 (L359)	IPC - Instrument Panel Cluster (IPC) Control Module	DATA
BH52-14C088-CF.vbf	Freelander 2 (L359)	IPC - Instrument Panel Cluster (IPC) Control Module	DATA
BH52-14C088-DF.vbf	Freelander 2 (L359)	IPC - Instrument Panel Cluster (IPC) Control Module	DATA
BH52-14C088-EF.vbf	Freelander 2 (L359)	IPC - Instrument Panel Cluster (IPC) Control Module	DATA
BH52-14C088-FF.vbf	Freelander 2 (L359)	IPC - Instrument Panel Cluster (IPC) Control Module	DATA
BH52-14C112-BA.vbf	Freelander 2 (L359)	PDM - Passenger Front Door Module	EXE
BH52-14C119-AC.vbf	Freelander 2 (L359)	RDCM - Rear Differential Control Module	EXE
BH52-14C204-JEC.vbf	Freelander 2 (L359)	PCM - Powertrain Control Module	EXE
BH52-14C204-JFA.vbf	Freelander 2 (L359)	PCM - Powertrain Control Module	EXE
BH52-14C204-JGA.vbf	Freelander 2 (L359)	PCM - Powertrain Control Module	EXE
BH52-14C204-JHA.vbf	Freelander 2 (L359)	PCM - Powertrain Control Module	EXE
BH52-14C204-JNA.vbf	Freelander 2 (L359)	PCM - Powertrain Control Module	EXE
BH52-14C204-VC.vbf	Freelander 2 (L359)	PCM - Powertrain Control Module	EXE
BH52-14C320-AA.vbf	Freelander 2 (L359)	DDM - Driver Front Door Module	SIGCFG
BH52-14C321-AA.vbf	Freelander 2 (L359)	DDM - Driver Front Door Module	SIGCFG
BH52-14C388-AA.vbf	Freelander 2 (L359)	RDCM - Rear Differential Control Module	SIGCFG
BH52-14C397-BA.vbf	Freelander 2 (L359)	TCM - Transmission Control Module	SIGCFG
BH52-18D619-AA.vbf	Freelander 2 (L359)	HVAC - HVAC Control Module	EXE
BH52-4C045-AC.vbf	Freelander 2 (L359)	RDCM - Rear Differential Control Module	EXE
BJ32-12K532-VAE.vbf	Range Rover Evoque (L538)	PCM - Powertrain Control Module	DATA
BJ32-12K532-VBG.vbf	Range Rover Evoque (L538)	PCM - Powertrain Control Module	DATA
BJ32-12K532-VCG.vbf	Range Rover Evoque (L538)	PCM - Powertrain Control Module	DATA
BJ32-12K532-VFE.vbf	Range Rover Evoque (L538)	PCM - Powertrain Control Module	DATA
BJ32-12K532-VGA.vbf	Range Rover Evoque (L538)	PCM - Powertrain Control Module	DATA
BJ32-12K532-VHE.vbf	Range Rover Evoque (L538)	PCM - Powertrain Control Module	DATA
BJ32-12K532-VJF.vbf	Range Rover Evoque (L538)	PCM - Powertrain Control Module	DATA
BJ32-12K532-VKE.vbf	Range Rover Evoque (L538)	PCM - Powertrain Control Module	DATA
BJ32-12K532-VLD.vbf	Range Rover Evoque (L538)	PCM - Powertrain Control Module	DATA
BJ32-12K532-VNF.vbf	Range Rover Evoque (L538)	PCM - Powertrain Control Module	DATA
BJ32-12K532-VSF.vbf	Range Rover Evoque (L538)	PCM - Powertrain Control Module	DATA
BJ32-12K532-VTF.vbf	Range Rover Evoque (L538)	PCM - Powertrain Control Module	DATA
BJ32-14C025-AA.vbf	Range Rover Evoque (L538)	IPC - Instrument Panel Cluster (IPC) Control Module	SBL
BJ32-14C026-AG.vbf	Range Rover Evoque (L538)	IPC - Instrument Panel Cluster (IPC) Control Module	EXE
BJ32-14C027-AB.vbf	Range Rover Evoque (L538)	RCM - Restraints Control Module	SBL
BJ32-14C028-AC.vbf	Range Rover Evoque (L538)	RCM - Restraints Control Module	EXE
BJ32-14C029-AA.vbf	Range Rover Evoque (L538)	DSM - Driver Front Seat Module	SBL
BJ32-14C030-AE.vbf	Range Rover Evoque (L538)	DSM - Driver Front Seat Module	EXE
BJ32-14C030-AF.vbf	Range Rover Evoque (L538)	DSM - Driver Front Seat Module	EXE
BJ32-14C036-AG.vbf	Range Rover Evoque (L538)	ABS - Anit-Lock Brake System (ABS) Control Module	EXE
BJ32-14C039-AA.vbf	Range Rover Evoque (L538)	ABS - Anit-Lock Brake System (ABS) Control Module	SBL
BJ32-14C044-AF.vbf	Check in SDD (unconfirmed)	ACM - Audio Front Control Module	EXE
BJ32-14C044-BD.vbf	Check in SDD (unconfirmed)	ACM - Audio Front Control Module	EXE
BJ32-14C045-AN.vbf	Range Rover Evoque (L538)	ICM - Infotainment Control Module	DATA
BJ32-14C045-AP.vbf	Range Rover Evoque (L538)	ICM - Infotainment Control Module	DATA
BJ32-14C045-AR.vbf	Range Rover Evoque (L538)	ICM - Infotainment Control Module	DATA
BJ32-14C045-AU.vbf	Range Rover Evoque (L538)	ICM - Infotainment Control Module	DATA
BJ32-14C045-AV.vbf	Range Rover Evoque (L538)	ICM - Infotainment Control Module	DATA
BJ32-14C045-AX.vbf	Range Rover Evoque (L538)	ICM - Infotainment Control Module	DATA
BJ32-14C045-BH.vbf	Range Rover Evoque (L538)	ICM - Infotainment Control Module	DATA
BJ32-14C045-BK.vbf	Range Rover Evoque (L538)	ICM - Infotainment Control Module	DATA
BJ32-14C045-BL.vbf	Range Rover Evoque (L538)	ICM - Infotainment Control Module	DATA
BJ32-14C045-BM.vbf	Range Rover Evoque (L538)	ICM - Infotainment Control Module	DATA
BJ32-14C045-BN.vbf	Range Rover Evoque (L538)	ICM - Infotainment Control Module	DATA
BJ32-14C045-BP.vbf	Range Rover Evoque (L538)	ICM - Infotainment Control Module	DATA
BJ32-14C045-BS.vbf	Range Rover Evoque (L538)	ICM - Infotainment Control Module	DATA
BJ32-14C047-AD.vbf	Range Rover Evoque (L538)	ACM - Audio Front Control Module	SBL
BJ32-14C060-AM.vbf	Range Rover Evoque (L538)	FCDIM - Front Control/Display Interface Module	EXE
BJ32-14C060-AN.vbf	Range Rover Evoque (L538)	FCDIM - Front Control/Display Interface Module	EXE
BJ32-14C060-BM.vbf	Range Rover Evoque (L538)	FCDIM - Front Control/Display Interface Module	EXE
BJ32-14C060-BN.vbf	Range Rover Evoque (L538)	FCDIM - Front Control/Display Interface Module	EXE
BJ32-14C061-AK.vbf	Range Rover Evoque (L538)	FCDIM - Front Control/Display Interface Module	DATA
BJ32-14C061-AL.vbf	Range Rover Evoque (L538)	FCDIM - Front Control/Display Interface Module	DATA
BJ32-14C063-AB.vbf	Range Rover Evoque (L538)	FCDIM - Front Control/Display Interface Module	SBL
BJ32-14C064-AC.vbf	Range Rover Evoque (L538)	DDM - Driver Front Door Module	EXE

File name	Vehicle line (indicative)	Module (ECU)	Type
BJ32-14C064-AD.vbf	Range Rover Evoque (L538)	DDM - Driver Front Door Module	EXE
BJ32-14C065-AC.vbf	Range Rover Evoque (L538)	DDM - Driver Front Door Module	DATA
BJ32-14C068-AC.vbf	Range Rover Evoque (L538)	DDM - Driver Front Door Module	EXE
BJ32-14C068-AD.vbf	Range Rover Evoque (L538)	DDM - Driver Front Door Module	EXE
BJ32-14C080-AA.vbf	Range Rover Evoque (L538)	AHCM - Auxiliary Heater Control Module	EXE
BJ32-14C081-AB.vbf	Range Rover Evoque (L538)	AHCM - Auxiliary Heater Control Module	DATA
BJ32-14C081-BB.vbf	Range Rover Evoque (L538)	AHCM - Auxiliary Heater Control Module	DATA
BJ32-14C081-CC.vbf	Range Rover Evoque (L538)	AHCM - Auxiliary Heater Control Module	DATA
BJ32-14C081-DC.vbf	Range Rover Evoque (L538)	AHCM - Auxiliary Heater Control Module	DATA
BJ32-14C084-AD.vbf	Range Rover Evoque (L538)	HCM - Headlamp Control Module #1	EXE
BJ32-14C087-AB.vbf	Range Rover Evoque (L538)	HCM - Headlamp Control Module #1	SBL
BJ32-14C090-AJ.vbf	Range Rover Evoque (L538)	PAM - Parking Assist Control Module	EXE
BJ32-14C091-AE.vbf	Range Rover Evoque (L538)	PAM - Parking Assist Control Module	DATA
BJ32-14C098-AJ.vbf	Range Rover Evoque (L538)	RCM - Restraints Control Module	DATA
BJ32-14C098-BJ.vbf	Range Rover Evoque (L538)	RCM - Restraints Control Module	DATA
BJ32-14C104-AE.vbf	Range Rover Evoque (L538)	TMC Traffic Message Channel Module	EXE
BJ32-14C105-AG.vbf	Range Rover Evoque (L538)	TMC Traffic Message Channel Module	DATA
BJ32-14C105-AL.vbf	Range Rover Evoque (L538)	TMC Traffic Message Channel Module	DATA
BJ32-14C105-BG.vbf	Range Rover Evoque (L538)	TMC Traffic Message Channel Module	DATA
BJ32-14C105-BM.vbf	Range Rover Evoque (L538)	TMC Traffic Message Channel Module	DATA
BJ32-14C105-CG.vbf	Range Rover Evoque (L538)	TMC Traffic Message Channel Module	DATA
BJ32-14C105-DG.vbf	Range Rover Evoque (L538)	TMC Traffic Message Channel Module	DATA
BJ32-14C108-AC.vbf	Range Rover Evoque (L538)	PDM - Passenger Front Door Module	EXE
BJ32-14C108-AD.vbf	Range Rover Evoque (L538)	PDM - Passenger Front Door Module	EXE
BJ32-14C109-AC.vbf	Range Rover Evoque (L538)	PDM - Passenger Front Door Module	DATA
BJ32-14C112-AC.vbf	Range Rover Evoque (L538)	PDM - Passenger Front Door Module	EXE
BJ32-14C112-AD.vbf	Range Rover Evoque (L538)	PDM - Passenger Front Door Module	EXE
BJ32-14C119-AE.vbf	Range Rover Evoque (L538)	ecu_address = 0x795;	DATA
BJ32-14C119-BB.vbf	Range Rover Evoque (L538)	ecu_address = 0x795;	DATA
BJ32-14C121-AF.vbf	Range Rover Evoque (L538)	RGTM - Rear Gate / Trunk Module	EXE
BJ32-14C122-AH.vbf	Range Rover Evoque (L538)	RGTM - Rear Gate / Trunk Module	DATA
BJ32-14C124-AA.vbf	Range Rover Evoque (L538)	RGTM - Rear Gate / Trunk Module	SBL
BJ32-14C168-AG.vbf	Range Rover Evoque (L538)	PBM - Park Brake Control Module	EXE
BJ32-14C171-AB.vbf	Range Rover Evoque (L538)	PBM - Park Brake Control Module	SBL
BJ32-14C184-AL.vbf	Range Rover Evoque (L538)	BCM - Body Control Module	EXE
BJ32-14C185-AH.vbf	Range Rover Evoque (L538)	BCM - Body Control Module	DATA
BJ32-14C204-MAZ.vbf	Range Rover Evoque (L538)	PCM - Powertrain Control Module	EXE
BJ32-14C204-MBX.vbf	Range Rover Evoque (L538)	PCM - Powertrain Control Module	EXE
BJ32-14C204-MBY.vbf	Range Rover Evoque (L538)	PCM - Powertrain Control Module	EXE
BJ32-14C204-MCU.vbf	Range Rover Evoque (L538)	PCM - Powertrain Control Module	EXE
BJ32-14C204-MCV.vbf	Range Rover Evoque (L538)	PCM - Powertrain Control Module	EXE
BJ32-14C204-MDA.vbf	Range Rover Evoque (L538)	PCM - Powertrain Control Module	EXE
BJ32-14C204-MEU.vbf	Range Rover Evoque (L538)	PCM - Powertrain Control Module	EXE
BJ32-14C204-MEV.vbf	Range Rover Evoque (L538)	PCM - Powertrain Control Module	EXE
BJ32-14C204-VB.vbf	Range Rover Evoque (L538)	PCM - Powertrain Control Module	EXE
BJ32-14C217-AE.vbf	Range Rover Evoque (L538)	PSCM - Power Steering Control Module	EXE
BJ32-14C217-BA.vbf	Range Rover Evoque (L538)	PSCM - Power Steering Control Module	EXE
BJ32-14C218-AB.vbf	Range Rover Evoque (L538)	Not specified	EXE
BJ32-14C218-BB.vbf	Range Rover Evoque (L538)	Not specified	EXE
BJ32-14C218-CA.vbf	Range Rover Evoque (L538)	Not specified	EXE
BJ32-14C218-DA.vbf	Range Rover Evoque (L538)	Not specified	EXE
BJ32-14C218-EA.vbf	Range Rover Evoque (L538)	Not specified	EXE
BJ32-14C218-FA.vbf	Range Rover Evoque (L538)	Not specified	EXE
BJ32-14C220-AA.vbf	Range Rover Evoque (L538)	Not specified	SBL
BJ32-14C273-AA.vbf	Range Rover Evoque (L538)	PCM - Powertrain Control Module	SBL
BJ32-14C273-VA.vbf	Range Rover Evoque (L538)	PCM - Powertrain Control Module	SBL
BJ32-14C309-AB.vbf	Range Rover Evoque (L538)	SASM - Steering Angle Sensor Module	EXE
BJ32-14C319-AB.vbf	Range Rover Evoque (L538)	HVAC - HVAC Control Module	SIGCFG
BJ32-14C337-AH.vbf	Range Rover Evoque (L538)	TCM Transmission Control Module	EXE
BJ32-14C337-BG.vbf	Range Rover Evoque (L538)	TCM Transmission Control Module	EXE
BJ32-14C337-CA.vbf	Range Rover Evoque (L538)	TCM Transmission Control Module	EXE
BJ32-14C337-EC.vbf	Range Rover Evoque (L538)	TCM Transmission Control Module	EXE
BJ32-14C337-FB.vbf	Range Rover Evoque (L538)	TCM Transmission Control Module	EXE
BJ32-14C339-AA.vbf	Range Rover Evoque (L538)	TCM - Transmission Control Module	SBL
BJ32-14C339-BA.vbf	Range Rover Evoque (L538)	CPM Combustion Preheater Module	SBL
BJ32-14C354-AC.vbf	Range Rover Evoque (L538)	Not specified	EXE
BJ32-14C354-AD.vbf	Range Rover Evoque (L538)	Not specified	EXE
BJ32-14C354-BC.vbf	Range Rover Evoque (L538)	Not specified	EXE
BJ32-14C354-CD.vbf	Range Rover Evoque (L538)	Not specified	EXE
BJ32-14C354-EC.vbf	Range Rover Evoque (L538)	Not specified	EXE
BJ32-14C354-ED.vbf	Range Rover Evoque (L538)	Not specified	EXE
BJ32-14C354-FC.vbf	Range Rover Evoque (L538)	Not specified	EXE
BJ32-14C355-AF.vbf	Range Rover Evoque (L538)	Not specified	EXE
BJ32-14C355-BF.vbf	Range Rover Evoque (L538)	Not specified	EXE
BJ32-14C356-AC.vbf	Range Rover Evoque (L538)	Not specified	SBL
BJ32-14C356-BC.vbf	Range Rover Evoque (L538)	Not specified	SBL

File name	Vehicle line (indicative)	Module (ECU)	Type
BJ32-14C377-AC.vbf	Range Rover Evoque (L538)	PAM - Parking Assist Control Module	SIGCFG
BJ32-14C386-AA.vbf	Range Rover Evoque (L538)	Not specified	EXE
BJ32-14C387-AB.vbf	Range Rover Evoque (L538)	SASM - Steering Angle Sensor Module	SIGCFG
BJ32-14C388-AA.vbf	Range Rover Evoque (L538)	RDCM - Rear Differential Control Module	SIGCFG
BJ32-14C395-AB.vbf	Range Rover Evoque (L538)	FCDIM - Front Control/Display Interface Module	EXE
BJ32-14C395-AC.vbf	Range Rover Evoque (L538)	FCDIM - Front Control/Display Interface Module	EXE
BJ32-14C397-AB.vbf	Range Rover Evoque (L538)	TCM - Transmission Control Module	SIGCFG
BJ32-14C397-AC.vbf	Range Rover Evoque (L538)	TCM - Transmission Control Module	SIGCFG
BJ32-14C397-BA.vbf	Range Rover Evoque (L538)	TCM - Transmission Control Module	SIGCFG
BJ32-14C407-AC.vbf	Range Rover Evoque (L538)	RCM - Restraints Control Module	SIGCFG
BJ32-14C408-AE.vbf	Range Rover Evoque (L538)	BCM - Body Control Module	SIGCFG
BJ32-14C413-AC.vbf	Range Rover Evoque (L538)	DSM - Driver Front Seat Module	SIGCFG
BJ32-14C433-AC.vbf	Range Rover Evoque (L538)	RGTM - Rear Gate / Trunk Module	SIGCFG
BJ32-14C526-AG.vbf	Range Rover Evoque (L538)	Not specified	EXE
BJ32-14C526-BG.vbf	Range Rover Evoque (L538)	Not specified	EXE
BJ32-14C527-AG.vbf	Range Rover Evoque (L538)	Not specified	DATA
BJ32-14C527-AH.vbf	Range Rover Evoque (L538)	Not specified	DATA
BJ32-14C527-BH.vbf	Range Rover Evoque (L538)	Not specified	DATA
BJ32-14C527-DE.vbf	Range Rover Evoque (L538)	Not specified	DATA
BJ32-14C534-AA.vbf	Range Rover Evoque (L538)	FCIMB - Front Controls Interface Module 'B'	SIGCFG
BJ32-14C535-AB.vbf	Range Rover Evoque (L538)	FCIMB - Front Controls Interface Module 'B'	EXE
BJ32-14C536-AB.vbf	Range Rover Evoque (L538)	FCIMB - Front Controls Interface Module 'B'	CUSTOM
BJ32-14C537-AA.vbf	Range Rover Evoque (L538)	FCIMB - Front Controls Interface Module 'B'	SBL
BJ32-14C542-BA.vbf	Range Rover Evoque (L538)	SUMB - Suspension Control Module B	EXE
BJ32-14C543-BA.vbf	Range Rover Evoque (L538)	SUMB - Suspension Control Module B	DATA
BJ32-14C544-AB.vbf	Range Rover Evoque (L538)	SUMB - Suspension Control Module B	SBL
BJ32-14C547-AA.vbf	Range Rover Evoque (L538)	PSM - Passenger Front Seat Module	SIGCFG
BJ32-14C548-AF.vbf	Range Rover Evoque (L538)	PSM - Passenger Front Seat Module	EXE
BJ32-14C550-AA.vbf	Range Rover Evoque (L538)	PSM - Passenger Front Seat Module	SBL
BJ32-14C560-AA.vbf	Range Rover Evoque (L538)	GSM - Gear Shift Module	SIGCFG
BJ32-14C561-AG.vbf	Range Rover Evoque (L538)	GSM - Gear Shift Module	EXE
BJ32-14C563-AB.vbf	Range Rover Evoque (L538)	GSM - Gear Shift Module	SBL
BJ32-14C578-AA.vbf	Range Rover Evoque (L538)	VIM - Vehicle Immobilizer Control Module	SIGCFG
BJ32-14C579-AB.vbf	Range Rover Evoque (L538)	VIM - Vehicle Immobilizer Control Module	EXE
BJ32-14C579-AC.vbf	Range Rover Evoque (L538)	VIM - Vehicle Immobilizer Control Module	EXE
BJ32-14C579-AD.vbf	Range Rover Evoque (L538)	VIM - Vehicle Immobilizer Control Module	EXE
BJ32-14C579-AE.vbf	Range Rover Evoque (L538)	VIM - Vehicle Immobilizer Control Module	EXE
BJ32-14C581-AA.vbf	Range Rover Evoque (L538)	VIM - Vehicle Immobilizer Control Module	SBL
BJ32-14C609-AE.vbf	Range Rover Evoque (L538)	Not specified	EXE
BJ32-14C609-BB.vbf	Range Rover Evoque (L538)	Not specified	EXE
BJ32-14C621-AE.vbf	Range Rover Evoque (L538)	FCDIM - Front Control/Display Interface Module	EXE
BJ32-14D023-AB.vbf	Range Rover Evoque (L538)	FCIM - Front Controls Interface Module	SIGCFG
BJ32-14D024-AB.vbf	Range Rover Evoque (L538)	ATCM - All Terrain Control Module	EXE
BJ32-14D026-AA.vbf	Range Rover Evoque (L538)	ATCM - All Terrain Control Module	SBL
BJ32-14D182-AA.vbf	Range Rover Evoque (L538)	OCS - Restraints Occupant Classification System Module	EXE
BJ32-14D184-AA.vbf	Range Rover Evoque (L538)	OCS - Restraints Occupant Classification System Module	SBL
BJ32-14D196-AG.vbf	Range Rover Evoque (L538)	HCM2 - Headlamp Control Module #2	EXE
BJ32-14D197-AF.vbf	Range Rover Evoque (L538)	HCM2 - Headlamp Control Module #2	DATA
BJ32-14D198-AA.vbf	Range Rover Evoque (L538)	HCM2 - Headlamp Control Module #2	SBL
BJ32-14D358-AE.vbf	Range Rover Evoque (L538)	MFD - Multi functional Display	EXE
BJ32-14D358-BB.vbf	Range Rover Evoque (L538)	MFD - Multi functional Display	EXE
BJ32-14D358-BC.vbf	Range Rover Evoque (L538)	MFD - Multi functional Display	EXE
BJ32-14D358-BD.vbf	Range Rover Evoque (L538)	MFD - Multi functional Display	EXE
BJ32-14D359-AE.vbf	Range Rover Evoque (L538)	MFD - Multi functional Display	DATA
BJ32-14D360-AB.vbf	Range Rover Evoque (L538)	FCDIM - Front Control/Display Interface Module	SBL
BJ32-14D367-AA.vbf	Range Rover Evoque (L538)	SODL - Side Obstacle Detection Control Module - Left	SIGCFG
BJ32-14D367-BA.vbf	Range Rover Evoque (L538)	SODR - Side Obstacle Detection Control Module - Right	SIGCFG
BJ32-14D368-AC.vbf	Range Rover Evoque (L538)	SODL - Side Obstacle Detection Control Module - Left	EXE
BJ32-14D479-AD.vbf	Range Rover Evoque (L538)	IPMB - Image Processing Module B	DATA
BJ32-14D480-AL.vbf	Range Rover Evoque (L538)	IPMB - Image Processing Module B	EXE
BJ32-14D485-AF.vbf	Range Rover Evoque (L538)	IPMB - Image Processing Module B	DATA
BJ32-14F016-AE.vbf	Range Rover Evoque (L538)	IPMB - Image Processing Module B	SIGCFG
BJ32-14F016-AF.vbf	Range Rover Evoque (L538)	IPMB - Image Processing Module B	SIGCFG
BJ32-14F017-AK.vbf	Range Rover Evoque (L538)	IPMB - Image Processing Module B	EXE
BJ32-14F019-AA.vbf	Range Rover Evoque (L538)	IPMB - Image Processing Module B	SBL
BJ32-14F022-AK.vbf	Range Rover Evoque (L538)	IPMB - Image Processing Module B	DATA
BJ32-14F574-AF.vbf	Range Rover Evoque (L538)	GSMB - Gear Shift Module B	EXE
BJ32-14F576-AA.vbf	Range Rover Evoque (L538)	GSMB - Gear Shift Module B	SBL
BJ32-18D619-AK.vbf	Range Rover Evoque (L538)	HVAC - HVAC Control Module	EXE
BJ32-4C045-AE.vbf	Range Rover Evoque (L538)	ecu_address = 0x795;	EXE
BJ3M-14F022-AJ.vbf	Range Rover Evoque (L538)	IPMB - Image Processing Module B	DATA
BV6T-14C309-AD.vbf	Not specified	SASM - Steering Angle Sensor Module	EXE
BV6T-14C311-AA.vbf	Not specified	SASM - Steering Angle Sensor Module	SBL
BW83-14C025-AA.vbf	Jaguar XK (X150)	IPC - Instrument Panel Cluster (IPC) Control Module	SBL
BW83-14C026-AE.vbf	Jaguar XK (X150)	IPC - Instrument Panel Cluster (IPC) Control Module	EXE
BW83-14C090-BC.vbf	Jaguar XK (X150)	PAM - Parking Assist Control Module	EXE

File name	Vehicle line (indicative)	Module (ECU)	Type
BW83-14C090-CA.vbf	Jaguar XK (X150)	PAM - Parking Assist Control Module	EXE
BW83-14C184-AH.vbf	Jaguar XK (X150)	BCM - Body Control Module	EXE
BW83-14C184-AJ.vbf	Jaguar XK (X150)	BCM - Body Control Module	EXE
BW83-14C187-AA.vbf	Jaguar XK (X150)	BCM - Body Control Module Front	SBL
BW83-14C320-AA.vbf	Check in SDD (unconfirmed)	DDM - Driver Front Door Module	SIGCFG
BW83-14C321-AA.vbf	Check in SDD (unconfirmed)	DDM - Driver Front Door Module	SIGCFG
BW83-14D049-CA.vbf	Jaguar XK (X150)	CCM - Cruise Control Module	EXE
BW83-14D049-DA.vbf	Jaguar XK (X150)	CCM - Cruise Control Module	EXE
BW83-14D051-AC.vbf	Jaguar XK (X150)	CCM - Cruise Control Module	SBL
BW83-14D051-BA.vbf	Jaguar XK (X150)	CCM - Cruise Control Module	SBL
BW83-14D647-AF.vbf	Jaguar XK (X150)	BCMB - Body Control Module Rear	EXE
BW83-14D649-AA.vbf	Jaguar XK (X150)	BCMB - Body Control Module Rear	SBL
BW8M-7J105-BD.vbf	Check in SDD (unconfirmed)	TCM - Transmission Control Module	DATA
BW8M-7J105-CE.vbf	Check in SDD (unconfirmed)	TCM - Transmission Control Module	DATA
BW93-12K532-PCC.vbf	Jaguar XJ (X351)	PCM - Powertrain Control Module	DATA
BW93-14C036-BA.vbf	Jaguar XJ (X351)	ABS - Anit-Lock Brake System (ABS) Control Module	EXE
BW93-14C045-AH.vbf	Jaguar XJ (X351)	ICM - Infotainment Control Module	DATA
BW93-14C045-AP.vbf	Jaguar XJ (X351)	ICM - Infotainment Control Module	DATA
BW93-14C045-AS.vbf	Jaguar XJ (X351)	ICM - Infotainment Control Module	DATA
BW93-14C045-AV.vbf	Jaguar XJ (X351)	ICM - Infotainment Control Module	DATA
BW93-14C045-AX.vbf	Jaguar XJ (X351)	ICM - Infotainment Control Module	DATA
BW93-14C045-AZ.vbf	Jaguar XJ (X351)	ICM - Infotainment Control Module	DATA
BW93-14C045-BH.vbf	Jaguar XJ (X351)	ICM - Infotainment Control Module	DATA
BW93-14C045-BJ.vbf	Jaguar XJ (X351)	ICM - Infotainment Control Module	DATA
BW93-14C045-BK.vbf	Jaguar XJ (X351)	ICM - Infotainment Control Module	DATA
BW93-14C045-BL.vbf	Jaguar XJ (X351)	ICM - Infotainment Control Module	DATA
BW93-14C045-BM.vbf	Jaguar XJ (X351)	ICM - Infotainment Control Module	DATA
BW93-14C045-BN.vbf	Jaguar XJ (X351)	ICM - Infotainment Control Module	DATA
BW93-14C045-BP.vbf	Jaguar XJ (X351)	ICM - Infotainment Control Module	DATA
BW93-14C045-BS.vbf	Jaguar XJ (X351)	ICM - Infotainment Control Module	DATA
BW93-14C084-AA.vbf	Jaguar XJ (X351)	HCM - Headlamp Control Module #1	EXE
BW93-14C098-AB.vbf	Jaguar XJ (X351)	RCM - Restraints Control Module	DATA
BW93-14C098-AC.vbf	Jaguar XJ (X351)	RCM - Restraints Control Module	DATA
BW93-14C098-BB.vbf	Jaguar XJ (X351)	RCM - Restraints Control Module	DATA
BW93-14C185-AA.vbf	Jaguar XJ (X351)	BCM - Body Control Module	DATA
BW93-14C354-AE.vbf	Jaguar XJ (X351)	Not specified	EXE
BW93-14C354-BB.vbf	Jaguar XJ (X351)	Not specified	EXE
BW93-14C354-CC.vbf	Jaguar XJ (X351)	Not specified	EXE
BW93-14C354-DD.vbf	Jaguar XJ (X351)	Not specified	EXE
BW93-14C354-ED.vbf	Jaguar XJ (X351)	Not specified	EXE
BW93-14C354-FA.vbf	Jaguar XJ (X351)	Not specified	EXE
BW93-14C570-DBD.vbf	Jaguar XJ (X351)	PCM - Powertrain Control Module	EXE
BW93-14C570-DCD.vbf	Jaguar XJ (X351)	PCM - Powertrain Control Module	EXE
BW93-7J104-DB.vbf	Jaguar XJ (X351)	TCM - Transmission Control Module	DATA
BW93-7J105-DE.vbf	Jaguar XJ (X351)	TCM - Transmission Control Module	DATA
BW9M-14C064-AB.vbf	Not specified	DDM - Driver Front Door Module	EXE
BW9M-14C068-AB.vbf	Not specified	DDM - Driver Front Door Module	EXE
BW9M-14C108-AB.vbf	Not specified	PDM - Passenger Front Door Module	EXE
BW9M-14C112-AB.vbf	Not specified	PDM - Passenger Front Door Module	EXE
BW9M-14C527-AA.vbf	Not specified	Not specified	DATA
BW9M-14D394-AA.vbf	Not specified	ecu_address = 0x7D3;	EXE
BX23-12K532-PCF.vbf	Jaguar XF (X250)	PCM - Powertrain Control Module	DATA
BX23-14C184-AA.vbf	Jaguar XF (X250)	BCM - Body Control Module	EXE
BX23-14C184-BA.vbf	Jaguar XF (X250)	BCM - Body Control Module	EXE
CF6N-14C044-AAH.vbf	Not specified	Not specified	EXE
CF6N-14C044-AAJ.vbf	Not specified	Not specified	EXE
CF6N-14C044-AAL.vbf	Not specified	Not specified	EXE
CF6N-14C044-AAM.vbf	Not specified	Not specified	EXE
CF6N-14C044-AAN.vbf	Not specified	Not specified	EXE
CF6N-14C044-FAH.vbf	Not specified	Not specified	EXE
CF6N-14C044-FAJ.vbf	Not specified	Not specified	EXE
CF6N-14C044-FAL.vbf	Not specified	Not specified	EXE
CF6N-14C044-FAM.vbf	Not specified	Not specified	EXE
CF6N-14C044-FAN.vbf	Not specified	Not specified	EXE
CF6N-14C044-KAH.vbf	Not specified	Not specified	EXE
CF6N-14C044-KAJ.vbf	Not specified	Not specified	EXE
CF6N-14C044-KAK.vbf	Not specified	Not specified	EXE
CF6N-14C044-KAL.vbf	Not specified	Not specified	EXE
CF6N-14C044-KAM.vbf	Not specified	Not specified	EXE
CF6N-14C044-KAN.vbf	Not specified	Not specified	EXE
CF6N-14C044-NAF.vbf	Not specified	Not specified	EXE
CF6N-14C044-NAG.vbf	Not specified	Not specified	EXE
CF6N-14C044-NAH.vbf	Not specified	Not specified	EXE
CF6N-14C044-NAJ.vbf	Not specified	Not specified	EXE
CF6N-14C044-NAK.vbf	Not specified	Not specified	EXE
CF6N-14C044-NAL.vbf	Not specified	Not specified	EXE

File name	Vehicle line (indicative)	Module (ECU)	Type
CF6N-14C044-NCA.vbf	Not specified	Not specified	EXE
CF6N-14C047-BA.vbf	Not specified	Not specified	SBL
CF6N-14C047-CB.vbf	Not specified	Not specified	SBL
CF6N-14C047-CD.vbf	Not specified	Not specified	SBL
CF6N-14C047-CE.vbf	Not specified	Not specified	SBL
CG9T-14C094-KA.vbf	Freelander 2 (L359)	GPS Global Positioning System module	EXE
CG9T-14C095-KB.vbf	Freelander 2 (L359)	GPS Global Positioning System module	DATA
CH22-12K532-PRB.vbf	Discovery 3/4 (L319)	PCM - Powertrain Control Module	DATA
CH22-12K532-PSE.vbf	Discovery 3/4 (L319)	PCM - Powertrain Control Module	DATA
CH22-12K532-PTE.vbf	Discovery 3/4 (L319)	PCM - Powertrain Control Module	DATA
CH22-12K532-PYB.vbf	Discovery 3/4 (L319)	PCM - Powertrain Control Module	DATA
CH22-14C026-AE.vbf	Discovery 3/4 (L319)	IPC - Instrument Panel Cluster (IPC) Control Module	EXE
CH22-14C026-AG.vbf	Discovery 3/4 (L319)	IPC - Instrument Panel Cluster (IPC) Control Module	EXE
CH22-14C026-AH.vbf	Discovery 3/4 (L319)	IPC - Instrument Panel Cluster (IPC) Control Module	EXE
CH22-14C026-BE.vbf	Discovery 3/4 (L319)	IPC - Instrument Panel Cluster (IPC) Control Module	EXE
CH22-14C026-BH.vbf	Discovery 3/4 (L319)	IPC - Instrument Panel Cluster (IPC) Control Module	EXE
CH22-14C044-AE.vbf	Check in SDD (unconfirmed)	ACM - Audio Front Control Module	EXE
CH22-14C045-AL.vbf	Discovery 3/4 (L319)	ICM - Infotainment Control Module	DATA
CH22-14C045-AN.vbf	Discovery 3/4 (L319)	ICM - Infotainment Control Module	DATA
CH22-14C045-AS.vbf	Discovery 3/4 (L319)	ICM - Infotainment Control Module	DATA
CH22-14C045-AT.vbf	Discovery 3/4 (L319)	ICM - Infotainment Control Module	DATA
CH22-14C045-AV.vbf	Discovery 3/4 (L319)	ICM - Infotainment Control Module	DATA
CH22-14C045-BH.vbf	Discovery 3/4 (L319)	ICM - Infotainment Control Module	DATA
CH22-14C045-BK.vbf	Discovery 3/4 (L319)	ICM - Infotainment Control Module	DATA
CH22-14C045-BL.vbf	Discovery 3/4 (L319)	ICM - Infotainment Control Module	DATA
CH22-14C045-BM.vbf	Discovery 3/4 (L319)	ICM - Infotainment Control Module	DATA
CH22-14C045-BN.vbf	Discovery 3/4 (L319)	ICM - Infotainment Control Module	DATA
CH22-14C045-BP.vbf	Discovery 3/4 (L319)	ICM - Infotainment Control Module	DATA
CH22-14C045-BS.vbf	Discovery 3/4 (L319)	ICM - Infotainment Control Module	DATA
CH22-14C060-AK.vbf	Discovery 3/4 (L319)	FCDIM - Front Control/Display Interface Module	EXE
CH22-14C060-AL.vbf	Discovery 3/4 (L319)	FCDIM - Front Control/Display Interface Module	EXE
CH22-14C061-AJ.vbf	Discovery 3/4 (L319)	FCDIM - Front Control/Display Interface Module	DATA
CH22-14C061-AK.vbf	Discovery 3/4 (L319)	FCDIM - Front Control/Display Interface Module	DATA
CH22-14C063-AB.vbf	Discovery 3/4 (L319)	FCDIM - Front Control/Display Interface Module	SBL
CH22-14C088-AD.vbf	Discovery 3/4 (L319)	IPC - Instrument Panel Cluster (IPC) Control Module	EXE
CH22-14C088-AF.vbf	Discovery 3/4 (L319)	IPC - Instrument Panel Cluster (IPC) Control Module	DATA
CH22-14C088-AG.vbf	Discovery 3/4 (L319)	IPC - Instrument Panel Cluster (IPC) Control Module	DATA
CH22-14C090-AA.vbf	Discovery 3/4 (L319)	PAM - Parking Assist Control Module	EXE
CH22-14C184-AB.vbf	Discovery 3/4 (L319)	BCM - Body Control Module	EXE
CH22-14C184-AE.vbf	Discovery 3/4 (L319)	BCM - Body Control Module	EXE
CH22-14C184-AF.vbf	Discovery 3/4 (L319)	BCM - Body Control Module	EXE
CH22-14C185-AC.vbf	Discovery 3/4 (L319)	BCM - Body Control Module	DATA
CH22-14C204-YAC.vbf	Discovery 3/4 (L319)	PCM - Powertrain Control Module	EXE
CH22-14C204-YCC.vbf	Discovery 3/4 (L319)	PCM - Powertrain Control Module	EXE
CH22-14C204-YEC.vbf	Discovery 3/4 (L319)	PCM - Powertrain Control Module	EXE
CH22-14C204-YTC.vbf	Discovery 3/4 (L319)	PCM - Powertrain Control Module	EXE
CH22-14C341-AE.vbf	Discovery 3/4 (L319)	Not specified	EXE
CH22-14C342-AE.vbf	Discovery 3/4 (L319)	Not specified	DATA
CH22-14C343-AC.vbf	Discovery 3/4 (L319)	Not specified	SBL
CH22-14C355-AE.vbf	Discovery 3/4 (L319)	Not specified	EXE
CH22-14C355-BE.vbf	Discovery 3/4 (L319)	Not specified	EXE
CH22-14C408-AA.vbf	Discovery 3/4 (L319)	BCM - Body Control Module	SIGCFG
CH22-14C408-AC.vbf	Discovery 3/4 (L319)	BCM - Body Control Module	SIGCFG
CH22-14C527-AD.vbf	Discovery 3/4 (L319)	Not specified	DATA
CH22-14C527-AF.vbf	Discovery 3/4 (L319)	Not specified	DATA
CH22-14C527-BD.vbf	Discovery 3/4 (L319)	Not specified	DATA
CH22-14C535-AB.vbf	Discovery 3/4 (L319)	FCIMB - Front Controls Interface Module 'B'	EXE
CH22-14C536-AB.vbf	Discovery 3/4 (L319)	FCIMB - Front Controls Interface Module 'B'	DATA
CH22-14C621-AE.vbf	Discovery 3/4 (L319)	FCDIM - Front Control/Display Interface Module	EXE
CH22-14D071-AA.vbf	Discovery 3/4 (L319)	FCIM - Front Controls Interface Module	EXE
CH22-14D072-AA.vbf	Discovery 3/4 (L319)	FCIM - Front Controls Interface Module	DATA
CH22-14D394-AA.vbf	Discovery 3/4 (L319)	ecu_address = 0x7D3;	EXE
CH22-14D519-BA.vbf	Discovery 3/4 (L319)	HVAC - HVAC Control Module	EXE
CH22-14F016-AB.vbf	Discovery 3/4 (L319)	IPMB - Image Processing Module B	SIGCFG
CH22-14F017-AF.vbf	Discovery 3/4 (L319)	IPMB - Image Processing Module B	EXE
CH22-14F022-AD.vbf	Discovery 3/4 (L319)	IPMB - Image Processing Module B	DATA
CH22-7J105-CE.vbf	Discovery 3/4 (L319)	TCM - Transmission Control Module	DATA
CH22-7J105-GE.vbf	Discovery 3/4 (L319)	TCM - Transmission Control Module	DATA
CH22-7J105-KA.vbf	Discovery 3/4 (L319)	TCM - Transmission Control Module	DATA
CH32-14C036-AD.vbf	Range Rover Sport I (L320)	ABS - Anit-Lock Brake System (ABS) Control Module	EXE
CH32-14C039-AA.vbf	Range Rover Sport I (L320)	ABS - Anit-Lock Brake System (ABS) Control Module	SBL
CH32-14C045-AJ.vbf	Range Rover Sport I (L320)	ICM - Infotainment Control Module	DATA
CH32-14C045-AL.vbf	Range Rover Sport I (L320)	ICM - Infotainment Control Module	DATA
CH32-14C045-AN.vbf	Range Rover Sport I (L320)	ICM - Infotainment Control Module	DATA
CH32-14C045-AR.vbf	Range Rover Sport I (L320)	ICM - Infotainment Control Module	DATA
CH32-14C045-AS.vbf	Range Rover Sport I (L320)	ICM - Infotainment Control Module	DATA

File name	Vehicle line (indicative)	Module (ECU)	Type
CH32-14C045-AT.vbf	Range Rover Sport I (L320)	ICM - Infotainment Control Module	DATA
CH32-14C045-AV.vbf	Range Rover Sport I (L320)	ICM - Infotainment Control Module	DATA
CH32-14C045-BH.vbf	Range Rover Sport I (L320)	ICM - Infotainment Control Module	DATA
CH32-14C045-BK.vbf	Range Rover Sport I (L320)	ICM - Infotainment Control Module	DATA
CH32-14C045-BL.vbf	Range Rover Sport I (L320)	ICM - Infotainment Control Module	DATA
CH32-14C045-BM.vbf	Range Rover Sport I (L320)	ICM - Infotainment Control Module	DATA
CH32-14C045-BN.vbf	Range Rover Sport I (L320)	ICM - Infotainment Control Module	DATA
CH32-14C045-BP.vbf	Range Rover Sport I (L320)	ICM - Infotainment Control Module	DATA
CH32-14C045-BS.vbf	Range Rover Sport I (L320)	ICM - Infotainment Control Module	DATA
CH32-14C060-BK.vbf	Range Rover Sport I (L320)	FCDIM - Front Control/Display Interface Module	EXE
CH32-14C060-BL.vbf	Range Rover Sport I (L320)	FCDIM - Front Control/Display Interface Module	EXE
CH32-14C087-AA.vbf	Range Rover Sport I (L320)	HCM - Headlamp Control Module #1	SBL
CH32-14C121-AE.vbf	Range Rover Sport I (L320)	RGTM - Rear Gate / Trunk Module	EXE
CH32-14C122-AF.vbf	Range Rover Sport I (L320)	RGTM - Rear Gate / Trunk Module	DATA
CH32-14C124-AA.vbf	Range Rover Sport I (L320)	RGTM - Rear Gate / Trunk Module	SBL
CH32-14C204-RAC.vbf	Range Rover Sport I (L320)	PCM - Powertrain Control Module	EXE
CH32-14C204-RCC.vbf	Range Rover Sport I (L320)	PCM - Powertrain Control Module	EXE
CH32-14C204-REC.vbf	Range Rover Sport I (L320)	PCM - Powertrain Control Module	EXE
CH32-14C204-RTC.vbf	Range Rover Sport I (L320)	PCM - Powertrain Control Module	EXE
CH32-14C204-YAC.vbf	Range Rover Sport I (L320)	PCM - Powertrain Control Module	EXE
CH32-14C204-YCC.vbf	Range Rover Sport I (L320)	PCM - Powertrain Control Module	EXE
CH32-14C204-YTC.vbf	Range Rover Sport I (L320)	PCM - Powertrain Control Module	EXE
CH32-14C355-AF.vbf	Range Rover Sport I (L320)	Not specified	EXE
CH32-14C355-BF.vbf	Range Rover Sport I (L320)	Not specified	EXE
CH32-14C526-BD.vbf	Range Rover Sport I (L320)	Not specified	EXE
CH32-14C527-AD.vbf	Range Rover Sport I (L320)	Not specified	DATA
CH32-14C527-BD.vbf	Range Rover Sport I (L320)	Not specified	DATA
CH32-14C527-EA.vbf	Range Rover Sport I (L320)	Not specified	DATA
CH32-14D394-AA.vbf	Range Rover Sport I (L320)	ecu_address = 0x7D3;	EXE
CH32-14D394-BA.vbf	Range Rover Sport I (L320)	ecu_address = 0x7D3;	EXE
CH32-14F022-AD.vbf	Range Rover Sport I (L320)	IPMB - Image Processing Module B	DATA
CH32-7J105-CE.vbf	Range Rover Sport I (L320)	TCM - Transmission Control Module	DATA
CH32-7J105-GE.vbf	Range Rover Sport I (L320)	TCM - Transmission Control Module	DATA
CH3M-14F022-AC.vbf	Range Rover Sport I (L320)	IPMB - Image Processing Module B	DATA
CH42-14C204-RAC.vbf	Range Rover III (L322)	PCM - Powertrain Control Module	EXE
CH42-14C204-RCC.vbf	Range Rover III (L322)	PCM - Powertrain Control Module	EXE
CH42-14C204-REC.vbf	Range Rover III (L322)	PCM - Powertrain Control Module	EXE
CH42-14C204-RTC.vbf	Range Rover III (L322)	PCM - Powertrain Control Module	EXE
CH42-14C204-YAC.vbf	Range Rover III (L322)	PCM - Powertrain Control Module	EXE
CH42-14C204-YCC.vbf	Range Rover III (L322)	PCM - Powertrain Control Module	EXE
CH42-14C204-YEC.vbf	Range Rover III (L322)	PCM - Powertrain Control Module	EXE
CH42-14C204-YTC.vbf	Range Rover III (L322)	PCM - Powertrain Control Module	EXE
CH52-14C036-AC.vbf	Freelander 2 (L359)	ABS - Anit-Lock Brake System (ABS) Control Module	EXE
CH52-14C119-AA.vbf	Freelander 2 (L359)	RDCM - Rear Differential Control Module	EXE
CH52-14C204-MBF.vbf	Freelander 2 (L359)	PCM - Powertrain Control Module	EXE
CH52-14C337-AC.vbf	Freelander 2 (L359)	TCM Transmission Control Module	EXE
CH52-14C388-AA.vbf	Freelander 2 (L359)	RDCM - Rear Differential Control Module	SIGCFG
CH52-14C397-AB.vbf	Freelander 2 (L359)	CPM Combustion Preheater Module	SIGCFG
CH52-18D619-AB.vbf	Freelander 2 (L359)	HVAC - HVAC Control Module	EXE
CH52-4C045-AA.vbf	Freelander 2 (L359)	RDCM - Rear Differential Control Module	EXE
CJ32-14C060-AG.vbf	Range Rover Evoque (L538)	FCDIM - Front Control/Display Interface Module	EXE
CJ32-14C060-AH.vbf	Range Rover Evoque (L538)	FCDIM - Front Control/Display Interface Module	EXE
CJ32-14C060-BG.vbf	Range Rover Evoque (L538)	FCDIM - Front Control/Display Interface Module	EXE
CJ32-14C060-BH.vbf	Range Rover Evoque (L538)	FCDIM - Front Control/Display Interface Module	EXE
CJ32-14C060-CA.vbf	Range Rover Evoque (L538)	FCDIM - Front Control/Display Interface Module	EXE
CJ32-14C060-DA.vbf	Range Rover Evoque (L538)	FCDIM - Front Control/Display Interface Module	EXE
CJ32-14C061-AG.vbf	Range Rover Evoque (L538)	FCDIM - Front Control/Display Interface Module	DATA
CJ32-14C061-AH.vbf	Range Rover Evoque (L538)	FCDIM - Front Control/Display Interface Module	DATA
CJ32-14C061-CA.vbf	Range Rover Evoque (L538)	FCDIM - Front Control/Display Interface Module	DATA
CJ32-14C063-AA.vbf	Range Rover Evoque (L538)	FCDIM - Front Control/Display Interface Module	SBL
CJ32-14C063-CA.vbf	Range Rover Evoque (L538)	FCDIM - Front Control/Display Interface Module	SBL
CJ32-14C355-AA.vbf	Range Rover Evoque (L538)	Not specified	EXE
CJ32-14C355-BA.vbf	Range Rover Evoque (L538)	Not specified	EXE
CJ32-14C621-AG.vbf	Range Rover Evoque (L538)	FCDIM - Front Control/Display Interface Module	EXE
CJ32-14C621-CA.vbf	Range Rover Evoque (L538)	FCDIM - Front Control/Display Interface Module	EXE
CK52-12K532-NAG.vbf	Range Rover (L405)	PCM - Powertrain Control Module	DATA
CK52-12K532-NCC.vbf	Range Rover (L405)	PCM - Powertrain Control Module	DATA
CK52-12K532-NRG.vbf	Range Rover (L405)	PCM - Powertrain Control Module	DATA
CK52-12K532-PAB.vbf	Range Rover (L405)	PCM - Powertrain Control Module	DATA
CK52-12K532-PBB.vbf	Range Rover (L405)	PCM - Powertrain Control Module	DATA
CK52-12K532-PLF.vbf	Range Rover (L405)	PCM - Powertrain Control Module	DATA
CK52-12K532-PME.vbf	Range Rover (L405)	PCM - Powertrain Control Module	DATA
CK52-14C027-AB.vbf	Range Rover (L405)	RCM - Restraints Control Module	SBL
CK52-14C028-AE.vbf	Range Rover (L405)	RCM - Restraints Control Module	EXE
CK52-14C029-AA.vbf	Range Rover (L405)	DSM - Driver Front Seat Module	SBL
CK52-14C030-AB.vbf	Range Rover (L405)	DSM - Driver Front Seat Module	EXE

File name	Vehicle line (indicative)	Module (ECU)	Type
CK52-14C030-AD.vbf	Range Rover (L405)	DSM - Driver Front Seat Module	EXE
CK52-14C037-AD.vbf	Range Rover (L405)	ABS - Anit-Lock Brake System (ABS) Control Module	EXE
CK52-14C037-BH.vbf	Range Rover (L405)	ABS - Anit-Lock Brake System (ABS) Control Module	EXE
CK52-14C037-CD.vbf	Range Rover (L405)	ABS - Anit-Lock Brake System (ABS) Control Module	EXE
CK52-14C037-DH.vbf	Range Rover (L405)	ABS - Anit-Lock Brake System (ABS) Control Module	EXE
CK52-14C037-EH.vbf	Range Rover (L405)	ABS - Anit-Lock Brake System (ABS) Control Module	EXE
CK52-14C037-FH.vbf	Range Rover (L405)	ABS - Anit-Lock Brake System (ABS) Control Module	EXE
CK52-14C098-AH.vbf	Range Rover (L405)	RCM - Restraints Control Module	DATA
CK52-14C098-BH.vbf	Range Rover (L405)	RCM - Restraints Control Module	DATA
CK52-14C098-CE.vbf	Range Rover (L405)	RCM - Restraints Control Module	DATA
CK52-14C204-NAB.vbf	Range Rover (L405)	PCM - Powertrain Control Module	EXE
CK52-14C218-AC.vbf	Range Rover (L405)	Not specified	EXE
CK52-14C218-BB.vbf	Range Rover (L405)	Not specified	EXE
CK52-14C273-NA.vbf	Range Rover (L405)	PCM - Powertrain Control Module	SBL
CK52-14C342-AA.vbf	Range Rover (L405)	Not specified	DATA
CK52-14C386-AA.vbf	Range Rover (L405)	Not specified	EXE
CK52-14C407-AC.vbf	Range Rover (L405)	RCM - Restraints Control Module	SIGCFG
CK52-14C413-AA.vbf	Check in SDD (unconfirmed)	DSM - Driver Front Seat Module	SIGCFG
CK52-14C526-DM.vbf	Range Rover (L405)	Not specified	EXE
CK52-14C527-AD.vbf	Range Rover (L405)	Not specified	DATA
CK52-14C527-AE.vbf	Range Rover (L405)	Not specified	DATA
CK52-14C527-BF.vbf	Range Rover (L405)	Not specified	DATA
CK52-14C527-DK.vbf	Range Rover (L405)	Not specified	DATA
CK52-14C527-EA.vbf	Range Rover (L405)	Not specified	DATA
CK52-14C547-AA.vbf	Range Rover (L405)	PSM - Passenger Front Seat Module	SIGCFG
CK52-14C548-AB.vbf	Range Rover (L405)	PSM - Passenger Front Seat Module	EXE
CK52-14C548-AC.vbf	Range Rover (L405)	PSM - Passenger Front Seat Module	EXE
CK52-14C550-AA.vbf	Range Rover (L405)	PSM - Passenger Front Seat Module	SBL
CK52-14C609-AB.vbf	Range Rover (L405)	Not specified	EXE
CK52-14D048-AB.vbf	Range Rover (L405)	CCM - Cruise Control Module	SIGCFG
CK52-14D181-AA.vbf	Range Rover (L405)	OCS - Restraints Occupant Classification System Module	SIGCFG
CK52-14D183-AC.vbf	Discovery Sport (L550)	OCS - Restraints Occupant Classification System Module	DATA
CK52-14D195-AA.vbf	Range Rover (L405)	HCM2 - Headlamp Control Module #2	SIGCFG
CK52-14D418-AK.vbf	Range Rover (L405)	Not specified	EXE
CK52-14D418-AL.vbf	Range Rover (L405)	Not specified	EXE
CK52-14D419-AK.vbf	Range Rover (L405)	Not specified	EXE
CK52-14D420-AD.vbf	Range Rover (L405)	Not specified	DATA
CK52-14D421-AE.vbf	Range Rover (L405)	Not specified	SBL
CK52-14D520-AC.vbf	Range Rover (L405)	HVAC - HVAC Control Module	DATA
CK52-14D520-AN.vbf	Range Rover (L405)	HVAC - HVAC Control Module	DATA
CK52-14D520-AP.vbf	Range Rover (L405)	HVAC - HVAC Control Module	DATA
CK52-14D520-AR.vbf	Range Rover (L405)	HVAC - HVAC Control Module	DATA
CK52-14D520-AS.vbf	Range Rover (L405)	HVAC - HVAC Control Module	DATA
CK52-14D520-AT.vbf	Range Rover (L405)	HVAC - HVAC Control Module	DATA
CK52-14D564-AD.vbf	Range Rover (L405)	SODL - Side Obstacle Detection Control Module - Left	DATA
CK52-14D564-BD.vbf	Range Rover (L405)	SODR - Side Obstacle Detection Control Module - Right	DATA
CK52-14E094-JAK.vbf	Range Rover (L405)	CHCM - Chassis Control Module	EXE
CK52-14E094-JAL.vbf	Range Rover (L405)	CHCM - Chassis Control Module	EXE
CK52-14E094-JAM.vbf	Range Rover (L405)	CHCM - Chassis Control Module	EXE
CK52-14E094-JBL.vbf	Range Rover (L405)	CHCM - Chassis Control Module	EXE
CK52-14E094-JBM.vbf	Range Rover (L405)	CHCM - Chassis Control Module	EXE
CK52-14E094-JCL.vbf	Range Rover (L405)	CHCM - Chassis Control Module	EXE
CK52-14E094-JCM.vbf	Range Rover (L405)	CHCM - Chassis Control Module	EXE
CK52-14E094-JDL.vbf	Range Rover (L405)	CHCM - Chassis Control Module	EXE
CK52-14E094-JDM.vbf	Range Rover (L405)	CHCM - Chassis Control Module	EXE
CK52-14F352-EF.vbf	Range Rover (L405)	SPMA - Seatbelt Pretensioner Control Module A	EXE
CK52-14F353-EE.vbf	Range Rover (L405)	SPMA - Seatbelt Pretensioner Control Module A	DATA
CK52-14F357-EF.vbf	Range Rover (L405)	SPMA - Seatbelt Pretensioner Control Module A	DATA
CK52-14F366-EE.vbf	Range Rover (L405)	SPMB - Seatbelt Pretensioner Control Module B	DATA
CK52-14F370-EF.vbf	Range Rover (L405)	SPMB - Seatbelt Pretensioner Control Module B	DATA
CK52-14F435-LAH.vbf	Range Rover (L405)	CHCMB - Chassis Control Module B	EXE
CK52-14F435-LAJ.vbf	Range Rover (L405)	CHCMB - Chassis Control Module B	EXE
CK52-14F435-LBH.vbf	Range Rover (L405)	CHCMB - Chassis Control Module B	EXE
CK52-14F435-LBJ.vbf	Range Rover (L405)	CHCMB - Chassis Control Module B	EXE
CK52-14F435-NAB.vbf	Range Rover (L405)	CHCMB - Chassis Control Module B	EXE
CK52-14F435-NBB.vbf	Range Rover (L405)	CHCMB - Chassis Control Module B	EXE
CK52-14G035-AA.vbf	Range Rover (L405)	SCMD - Seat Control Module D	SIGCFG
CK52-14G036-AB.vbf	Range Rover (L405)	SCMD - Seat Control Module D	EXE
CK52-14G036-AE.vbf	Range Rover (L405)	PRSM - Passenger Rear Seat Module	EXE
CK52-14G038-AA.vbf	Range Rover (L405)	SCMD - Seat Control Module D	SBL
CK52-14G045-AA.vbf	Check in SDD (unconfirmed)	SCMC - Seat Control Module C	SIGCFG
CK52-14G046-AB.vbf	Range Rover (L405)	SCMC - Seat Control Module C	EXE
CK52-14G046-AE.vbf	Range Rover (L405)	DRSM - Driver Rear Seat Module	EXE
CK52-14G048-AA.vbf	Range Rover (L405)	SCMC - Seat Control Module C	SBL
CK52-7J104-AAD.vbf	Range Rover (L405)	TCM - Transmission Control Module	EXE
CK52-7J104-ABE.vbf	Range Rover (L405)	TCM - Transmission Control Module	EXE

File name	Vehicle line (indicative)	Module (ECU)	Type
CK52-7J104-ACD.vbf	Range Rover (L405)	TCM - Transmission Control Module	EXE
CK52-7J104-AHD.vbf	Range Rover (L405)	TCM - Transmission Control Module	EXE
CK52-7J104-ASA.vbf	Range Rover (L405)	TCM - Transmission Control Module	EXE
CK52-7J104-ATA.vbf	Range Rover (L405)	TCM - Transmission Control Module	EXE
CK52-7J104-AUB.vbf	Range Rover (L405)	TCM - Transmission Control Module	EXE
CPLA-14C026-AH.vbf	Multiple models (shared module)	IPC - Instrument Panel Cluster (IPC) Control Module	EXE
CPLA-14C026-BH.vbf	Multiple models (shared module)	IPC - Instrument Panel Cluster (IPC) Control Module	EXE
CPLA-14C026-CB.vbf	Multiple models (shared module)	IPC - Instrument Panel Cluster (IPC) Control Module	EXE
CPLA-14C036-AD.vbf	Multiple models (shared module)	ABS - Anit-Lock Brake System (ABS) Control Module	EXE
CPLA-14C036-AH.vbf	Multiple models (shared module)	ABS - Anit-Lock Brake System (ABS) Control Module	EXE
CPLA-14C039-AC.vbf	Multiple models (shared module)	ABS - Anit-Lock Brake System (ABS) Control Module	SBL
CPLA-14C045-AK.vbf	Multiple models (shared module)	ICM - Infotainment Control Module	DATA
CPLA-14C045-AN.vbf	Multiple models (shared module)	ICM - Infotainment Control Module	DATA
CPLA-14C045-AR.vbf	Multiple models (shared module)	ICM - Infotainment Control Module	DATA
CPLA-14C045-AS.vbf	Multiple models (shared module)	ICM - Infotainment Control Module	DATA
CPLA-14C045-AT.vbf	Multiple models (shared module)	ICM - Infotainment Control Module	DATA
CPLA-14C045-BH.vbf	Multiple models (shared module)	ICM - Infotainment Control Module	DATA
CPLA-14C045-BK.vbf	Multiple models (shared module)	ICM - Infotainment Control Module	DATA
CPLA-14C045-BL.vbf	Multiple models (shared module)	ICM - Infotainment Control Module	DATA
CPLA-14C045-BM.vbf	Multiple models (shared module)	ICM - Infotainment Control Module	DATA
CPLA-14C045-BN.vbf	Multiple models (shared module)	ICM - Infotainment Control Module	DATA
CPLA-14C045-BP.vbf	Multiple models (shared module)	ICM - Infotainment Control Module	DATA
CPLA-14C045-BR.vbf	Multiple models (shared module)	ICM - Infotainment Control Module	DATA
CPLA-14C060-AL.vbf	Multiple models (shared module)	FCDIM - Front Control/Display Interface Module	EXE
CPLA-14C060-AM.vbf	Multiple models (shared module)	FCDIM - Front Control/Display Interface Module	EXE
CPLA-14C060-BL.vbf	Multiple models (shared module)	FCDIM - Front Control/Display Interface Module	EXE
CPLA-14C060-BM.vbf	Multiple models (shared module)	FCDIM - Front Control/Display Interface Module	EXE
CPLA-14C060-CA.vbf	Multiple models (shared module)	FCDIM - Front Control/Display Interface Module	EXE
CPLA-14C060-CB.vbf	Multiple models (shared module)	FCDIM - Front Control/Display Interface Module	EXE
CPLA-14C060-DA.vbf	Multiple models (shared module)	FCDIM - Front Control/Display Interface Module	EXE
CPLA-14C060-DB.vbf	Multiple models (shared module)	FCDIM - Front Control/Display Interface Module	EXE
CPLA-14C061-AL.vbf	Multiple models (shared module)	FCDIM - Front Control/Display Interface Module	DATA
CPLA-14C061-AM.vbf	Multiple models (shared module)	FCDIM - Front Control/Display Interface Module	DATA
CPLA-14C061-CA.vbf	Multiple models (shared module)	FCDIM - Front Control/Display Interface Module	DATA
CPLA-14C061-CB.vbf	Multiple models (shared module)	FCDIM - Front Control/Display Interface Module	DATA
CPLA-14C063-AB.vbf	Multiple models (shared module)	FCDIM - Front Control/Display Interface Module	SBL
CPLA-14C063-CA.vbf	Multiple models (shared module)	FCDIM - Front Control/Display Interface Module	SBL
CPLA-14C064-AC.vbf	Multiple models (shared module)	DDM - Driver Front Door Module	EXE
CPLA-14C065-AD.vbf	Multiple models (shared module)	DDM - Driver Front Door Module	DATA
CPLA-14C067-AA.vbf	Multiple models (shared module)	DDM	SBL
CPLA-14C068-AD.vbf	Multiple models (shared module)	DDM - Driver Front Door Module	EXE
CPLA-14C088-AH.vbf	Multiple models (shared module)	IPC - Instrument Panel Cluster (IPC) Control Module	DATA
CPLA-14C088-BH.vbf	Multiple models (shared module)	IPC - Instrument Panel Cluster (IPC) Control Module	DATA
CPLA-14C090-AE.vbf	Range Rover (L405)	PAM - Parking Assist Control Module	EXE
CPLA-14C091-AF.vbf	Range Rover (L405)	PAM - Parking Assist Control Module	DATA
CPLA-14C105-AD.vbf	Range Rover (L405)	TMC Traffic Message Channel Module	DATA
CPLA-14C105-AH.vbf	Range Rover (L405)	TMC Traffic Message Channel Module	DATA
CPLA-14C105-BH.vbf	Range Rover (L405)	TMC Traffic Message Channel Module	DATA
CPLA-14C107-AA.vbf	Multiple models (shared module)	TMC Traffic Message Channel Module	SBL
CPLA-14C108-AC.vbf	Multiple models (shared module)	PDM - Passenger Front Door Module	EXE
CPLA-14C109-AD.vbf	Multiple models (shared module)	PDM - Passenger Front Door Module	DATA
CPLA-14C111-AA.vbf	Multiple models (shared module)	PDM	SBL
CPLA-14C112-AD.vbf	Multiple models (shared module)	PDM - Passenger Front Door Module	EXE
CPLA-14C121-AF.vbf	Range Rover (L405)	RGTM - Rear Gate / Trunk Module	EXE
CPLA-14C122-AF.vbf	Range Rover (L405)	RGTM - Rear Gate / Trunk Module	DATA
CPLA-14C124-AA.vbf	Multiple models (shared module)	RGTM - Rear Gate / Trunk Module	SBL
CPLA-14C168-AC.vbf	Multiple models (shared module)	PBM - Park Brake Control Module	EXE
CPLA-14C184-AF.vbf	Multiple models (shared module)	BCM - Body Control Module	EXE
CPLA-14C185-AF.vbf	Multiple models (shared module)	BCM - Body Control Module	DATA
CPLA-14C204-PAB.vbf	Multiple models (shared module)	PCM - Powertrain Control Module	EXE
CPLA-14C204-RAJ.vbf	Range Rover (L405)	PCM - Powertrain Control Module	EXE
CPLA-14C204-RAK.vbf	Multiple models (shared module)	PCM - Powertrain Control Module	EXE
CPLA-14C204-RCH.vbf	Range Rover (L405)	PCM - Powertrain Control Module	EXE
CPLA-14C204-RCJ.vbf	Range Rover (L405)	PCM - Powertrain Control Module	EXE
CPLA-14C204-RCK.vbf	Multiple models (shared module)	PCM - Powertrain Control Module	EXE
CPLA-14C204-REH.vbf	Range Rover (L405)	PCM - Powertrain Control Module	EXE
CPLA-14C204-REJ.vbf	Multiple models (shared module)	PCM - Powertrain Control Module	EXE
CPLA-14C204-RTJ.vbf	Range Rover (L405)	PCM - Powertrain Control Module	EXE
CPLA-14C204-RTK.vbf	Range Rover (L405)	PCM - Powertrain Control Module	EXE
CPLA-14C204-RTL.vbf	Multiple models (shared module)	PCM - Powertrain Control Module	EXE
CPLA-14C204-YAJ.vbf	Multiple models (shared module)	PCM - Powertrain Control Module	EXE
CPLA-14C204-YCJ.vbf	Multiple models (shared module)	PCM - Powertrain Control Module	EXE
CPLA-14C204-YEC.vbf	Range Rover (L405)	PCM - Powertrain Control Module	EXE
CPLA-14C204-YGA.vbf	Range Rover (L405)	PCM - Powertrain Control Module	EXE
CPLA-14C204-YTJ.vbf	Multiple models (shared module)	PCM - Powertrain Control Module	EXE
CPLA-14C217-AC.vbf	Multiple models (shared module)	Not specified	EXE

File name	Vehicle line (indicative)	Module (ECU)	Type
CPLA-14C273-PB.vbf	Multiple models (shared module)	PCM - Powertrain Control Module	SBL
CPLA-14C273-YB.vbf	Multiple models (shared module)	PCM - Powertrain Control Module	SBL
CPLA-14C309-AA.vbf	Multiple models (shared module)	SASM - Steering Angle Sensor Module	EXE
CPLA-14C320-AA.vbf	Multiple models (shared module)	DDM - Driver Front Door Module	SIGCFG
CPLA-14C321-AA.vbf	Multiple models (shared module)	DDM - Driver Front Door Module	SIGCFG
CPLA-14C355-AE.vbf	Multiple models (shared module)	Not specified	EXE
CPLA-14C355-BE.vbf	Multiple models (shared module)	Not specified	EXE
CPLA-14C355-CB.vbf	Multiple models (shared module)	Not specified	EXE
CPLA-14C366-AD.vbf	Multiple models (shared module)	ecu_address = 0x761;	EXE
CPLA-14C368-AA.vbf	Multiple models (shared module)	ecu_address = 0x761;	SBL
CPLA-14C377-AD.vbf	Multiple models (shared module)	PAM - Parking Assist Control Module	SIGCFG
CPLA-14C383-AD.vbf	Multiple models (shared module)	PBM - Park Brake Control Module	EXE
CPLA-14C387-AB.vbf	Multiple models (shared module)	SASM - Steering Angle Sensor Module	SIGCFG
CPLA-14C395-AB.vbf	Multiple models (shared module)	FCDIM - Front Control/Display Interface Module	EXE
CPLA-14C408-AB.vbf	Multiple models (shared module)	BCM - Body Control Module	SIGCFG
CPLA-14C430-AA.vbf	Check in SDD (unconfirmed)	TMC Traffic Message Channel Module	DATA
CPLA-14C430-AC.vbf	Check in SDD (unconfirmed)	TMC Traffic Message Channel Module	DATA
CPLA-14C430-CA.vbf	Check in SDD (unconfirmed)	TMC Traffic Message Channel Module	DATA
CPLA-14C430-CB.vbf	Discovery 3/4 (L319)	TMC Traffic Message Channel Module	DATA
CPLA-14C433-AB.vbf	Multiple models (shared module)	RGTM - Rear Gate / Trunk Module	SIGCFG
CPLA-14C534-AC.vbf	Multiple models (shared module)	FCIMB - Front Controls Interface Module 'B'	SIGCFG
CPLA-14C535-AB.vbf	Multiple models (shared module)	FCIMB - Front Controls Interface Module 'B'	EXE
CPLA-14C536-AC.vbf	Multiple models (shared module)	FCIMB - Front Controls Interface Module 'B'	CUSTOM
CPLA-14C537-AA.vbf	Multiple models (shared module)	FCIMB - Front Controls Interface Module 'B'	SBL
CPLA-14C561-AC.vbf	Range Rover (L405)	GSM - Gear Shift Module	EXE
CPLA-14C563-AA.vbf	Multiple models (shared module)	GSM - Gear Shift Module	SBL
CPLA-14C578-AA.vbf	Multiple models (shared module)	VIM - Vehicle Immobilizer Control Module	SIGCFG
CPLA-14C621-AK.vbf	Multiple models (shared module)	FCDIM - Front Control/Display Interface Module	EXE
CPLA-14C621-CA.vbf	Multiple models (shared module)	FCDIM - Front Control/Display Interface Module	EXE
CPLA-14D016-AC.vbf	Multiple models (shared module)	FCIM - Front Controls Interface Module	SIGCFG
CPLA-14D017-AC.vbf	Multiple models (shared module)	FCIM - Front Controls Interface Module	EXE
CPLA-14D018-AD.vbf	Multiple models (shared module)	FCIM - Front Controls Interface Module	CUSTOM
CPLA-14D019-AA.vbf	Multiple models (shared module)	FCIM - Front Controls Interface Module	SBL
CPLA-14D023-AA.vbf	Range Rover (L405)	ATCM	SIGCFG
CPLA-14D024-AD.vbf	Range Rover (L405)	ATCM - All Terrain Control Module	EXE
CPLA-14D026-AA.vbf	Multiple models (shared module)	ATCM - All Terrain Control Module	SBL
CPLA-14D049-AE.vbf	Range Rover (L405)	ecu_address = 0x764;	EXE
CPLA-14D049-BC.vbf	Multiple models (shared module)	ecu_address = 0x764;	EXE
CPLA-14D182-AA.vbf	Multiple models (shared module)	OCS - Restraints Occupant Classification System Module	EXE
CPLA-14D182-AB.vbf	Range Rover Evoque (L538)	OCS - Restraints Occupant Classification System Module	EXE
CPLA-14D184-AA.vbf	Multiple models (shared module)	OCS - Restraints Occupant Classification System Module	SBL
CPLA-14D367-AC.vbf	Multiple models (shared module)	SODL - Side Obstacle Detection Control Module - Left	SIGCFG
CPLA-14D367-BC.vbf	Multiple models (shared module)	SODR - Side Obstacle Detection Control Module - Right	SIGCFG
CPLA-14D368-AF.vbf	Multiple models (shared module)	SODL - Side Obstacle Detection Control Module - Left	EXE
CPLA-14D370-AC.vbf	Multiple models (shared module)	SODL - Side Obstacle Detection Control Module - Left	SBL
CPLA-14D402-AM.vbf	Multiple models (shared module)	Not specified	EXE
CPLA-14D403-AM.vbf	Multiple models (shared module)	Not specified	EXE
CPLA-14D403-AN.vbf	Multiple models (shared module)	Not specified	EXE
CPLA-14D404-AJ.vbf	Multiple models (shared module)	Not specified	DATA
CPLA-14D405-AE.vbf	Multiple models (shared module)	Not specified	SBL
CPLA-14D479-AC.vbf	Multiple models (shared module)	IPMB - Image Processing Module B	DATA
CPLA-14D480-AD.vbf	Multiple models (shared module)	IPMB - Image Processing Module B	EXE
CPLA-14D485-AB.vbf	Multiple models (shared module)	IPMB - Image Processing Module B	DATA
CPLA-14D519-AC.vbf	Multiple models (shared module)	HVAC - HVAC Control Module	EXE
CPLA-14D519-AL.vbf	Multiple models (shared module)	HVAC - HVAC Control Module	EXE
CPLA-14D521-AA.vbf	Multiple models (shared module)	HVAC - HVAC Control Module	SBL
CPLA-14D521-AB.vbf	Multiple models (shared module)	HVAC - HVAC Control Module	SBL
CPLA-14E093-BD.vbf	Multiple models (shared module)	CHCM - Chassis Control Module	EXE
CPLA-14E093-BE.vbf	Multiple models (shared module)	CHCM - Chassis Control Module	EXE
CPLA-14E093-BF.vbf	Multiple models (shared module)	CHCM - Chassis Control Module	EXE
CPLA-14E093-SB.vbf	Multiple models (shared module)	CHCM - Chassis Control Module	EXE
CPLA-14E093-SC.vbf	Multiple models (shared module)	CHCM - Chassis Control Module	EXE
CPLA-14E093-SD.vbf	Multiple models (shared module)	CHCM - Chassis Control Module	EXE
CPLA-14E093-SG.vbf	Multiple models (shared module)	CHCM - Chassis Control Module	EXE
CPLA-14E093-SH.vbf	Multiple models (shared module)	CHCM - Chassis Control Module	EXE
CPLA-14E093-SK.vbf	Multiple models (shared module)	CHCM - Chassis Control Module	EXE
CPLA-14E093-SL.vbf	Multiple models (shared module)	CHCM - Chassis Control Module	EXE
CPLA-14E093-ZA.vbf	Multiple models (shared module)	CHCM - Chassis Control Module	EXE
CPLA-14E093-ZB.vbf	Multiple models (shared module)	CHCM - Chassis Control Module	EXE
CPLA-14E093-ZC.vbf	Multiple models (shared module)	CHCM - Chassis Control Module	EXE
CPLA-14E095-AB.vbf	Multiple models (shared module)	CHCM - Chassis Control Module	SBL
CPLA-14F016-AB.vbf	Range Rover (L405)	IPMB - Image Processing Module B	SIGCFG
CPLA-14F017-AG.vbf	Range Rover (L405)	IPMB - Image Processing Module B	EXE
CPLA-14F022-AF.vbf	Range Rover (L405)	IPMB - Image Processing Module B	DATA
CPLA-14F216-AC.vbf	Multiple models (shared module)	RHVAC - Rear HVAC Control Module	SIGCFG
CPLA-14F217-AC.vbf	Multiple models (shared module)	RHVAC - Rear HVAC Control Module	EXE

File name	Vehicle line (indicative)	Module (ECU)	Type
CPLA-14F218-AB.vbf	Multiple models (shared module)	RHVAC - Rear HVAC Control Module	CUSTOM
CPLA-14F219-AA.vbf	Multiple models (shared module)	RHVAC - Rear HVAC Control Module	SBL
CPLA-14F351-AB.vbf	Multiple models (shared module)	SPMA - Seatbelt Pretensioner Control Module A	SIGCFG
CPLA-14F354-EB.vbf	Multiple models (shared module)	SPMA - Seatbelt Pretensioner Control Module A	SBL
CPLA-14F364-AB.vbf	Multiple models (shared module)	SPMB - Seatbelt Pretensioner Control Module B	SIGCFG
CPLA-14F367-EB.vbf	Multiple models (shared module)	SPMB - Seatbelt Pretensioner Control Module B	SBL
CPLA-14F434-LH.vbf	Multiple models (shared module)	CHCMB - Chassis Control Module B	EXE
CPLA-14F434-LJ.vbf	Multiple models (shared module)	CHCMB - Chassis Control Module B	EXE
CPLA-14F434-NB.vbf	Multiple models (shared module)	CHCMB - Chassis Control Module B	EXE
CPLA-14F434-NC.vbf	Multiple models (shared module)	CHCMB - Chassis Control Module B	EXE
CPLA-14F530-AL.vbf	Multiple models (shared module)	GWM - Gateway Module A	EXE
CPLA-14F531-AJ.vbf	Multiple models (shared module)	GWM - Gateway Module A	DATA
CPLA-14F531-BC.vbf	Multiple models (shared module)	GWM - Gateway Module A	DATA
CPLA-14F670-AC.vbf	Range Rover (L405)	RGTMB - Rear Gate / Trunk Module B	SIGCFG
CPLA-14F671-AE.vbf	Range Rover (L405)	RGTM - Rear Gate / Trunk Module	EXE
CPLA-14F672-AE.vbf	Range Rover (L405)	RGTM - Rear Gate / Trunk Module	DATA
CPLA-14F673-AA.vbf	Multiple models (shared module)	RGTMB - Rear Gate / Trunk Module	SBL
CPLA-18A836-AD.vbf	Multiple models (shared module)	FCIMC - Front Controls Interface Module 'C'	SIGCFG
CPLA-18A842-AB.vbf	Multiple models (shared module)	FCIMC - Front Controls Interface Module 'C'	CUSTOM
CPLA-18A842-AC.vbf	Multiple models (shared module)	FCIMC - Front Controls Interface Module 'C'	CUSTOM
CPLA-18A843-AA.vbf	Multiple models (shared module)	FCIMC - Front Controls Interface Module 'C'	SBL
CPLA-18A911-AB.vbf	Multiple models (shared module)	FCIMC - Front Controls Interface Module 'C'	EXE
CPLA-4C044-AA.vbf	Multiple models (shared module)	ecu_address = 0x795;	SBL
CPLA-4C045-AA.vbf	Multiple models (shared module)	ecu_address = 0x795;	EXE
CW83-14C036-BC.vbf	Jaguar XK (X150)	ABS - Anit-Lock Brake System (ABS) Control Module	EXE
CW83-14C204-RAE.vbf	Jaguar XK (X150)	PCM - Powertrain Control Module	EXE
CW83-14C204-RCE.vbf	Jaguar XK (X150)	PCM - Powertrain Control Module	EXE
CW83-14C204-REE.vbf	Jaguar XK (X150)	PCM - Powertrain Control Module	EXE
CW83-14C204-RTE.vbf	Jaguar XK (X150)	PCM - Powertrain Control Module	EXE
CW83-14C204-YAD.vbf	Jaguar XK (X150)	PCM - Powertrain Control Module	EXE
CW83-14C204-YCD.vbf	Jaguar XK (X150)	PCM - Powertrain Control Module	EXE
CW83-14C204-YED.vbf	Jaguar XK (X150)	PCM - Powertrain Control Module	EXE
CW83-14C204-YTD.vbf	Jaguar XK (X150)	PCM - Powertrain Control Module	EXE
CW83-14C542-AB.vbf	Jaguar XK (X150)	ecu_address = 0x786;	EXE
CW8M-14C204-ZAE.vbf	Jaguar XK (X150)	PCM - Powertrain Control Module	EXE
CW8M-14C204-ZCE.vbf	Jaguar XK (X150)	PCM - Powertrain Control Module	EXE
CW8M-14C204-ZEE.vbf	Jaguar XK (X150)	PCM - Powertrain Control Module	EXE
CW8M-14C204-ZTE.vbf	Jaguar XK (X150)	PCM - Powertrain Control Module	EXE
CW93-14C029-AA.vbf	Range Rover (L405)	DSM - Driver Front Seat Module	SBL
CW93-14C030-AB.vbf	Range Rover (L405)	DSM - Driver Front Seat Module	EXE
CW93-14C060-AH.vbf	Jaguar XJ (X351)	FCDIM - Front Control/Display Interface Module	EXE
CW93-14C060-AJ.vbf	Jaguar XJ (X351)	FCDIM - Front Control/Display Interface Module	EXE
CW93-14C060-BH.vbf	Jaguar XJ (X351)	FCDIM - Front Control/Display Interface Module	EXE
CW93-14C060-BJ.vbf	Jaguar XJ (X351)	FCDIM - Front Control/Display Interface Module	EXE
CW93-14C060-CB.vbf	Jaguar XJ (X351)	FCDIM - Front Control/Display Interface Module	EXE
CW93-14C060-CC.vbf	Jaguar XJ (X351)	FCDIM - Front Control/Display Interface Module	EXE
CW93-14C060-CD.vbf	Jaguar XJ (X351)	FCDIM - Front Control/Display Interface Module	EXE
CW93-14C060-DB.vbf	Jaguar XJ (X351)	FCDIM - Front Control/Display Interface Module	EXE
CW93-14C060-DC.vbf	Jaguar XJ (X351)	FCDIM - Front Control/Display Interface Module	EXE
CW93-14C060-DD.vbf	Jaguar XJ (X351)	FCDIM - Front Control/Display Interface Module	EXE
CW93-14C061-AF.vbf	Jaguar XJ (X351)	FCDIM - Front Control/Display Interface Module	DATA
CW93-14C061-AG.vbf	Jaguar XJ (X351)	FCDIM - Front Control/Display Interface Module	DATA
CW93-14C061-CA.vbf	Jaguar XJ (X351)	FCDIM - Front Control/Display Interface Module	DATA
CW93-14C061-CB.vbf	Jaguar XJ (X351)	FCDIM - Front Control/Display Interface Module	DATA
CW93-14C061-CC.vbf	Jaguar XJ (X351)	FCDIM - Front Control/Display Interface Module	DATA
CW93-14C061-DA.vbf	Jaguar XJ (X351)	FCDIM - Front Control/Display Interface Module	DATA
CW93-14C061-DB.vbf	Jaguar XJ (X351)	FCDIM - Front Control/Display Interface Module	DATA
CW93-14C061-DC.vbf	Jaguar XJ (X351)	FCDIM - Front Control/Display Interface Module	DATA
CW93-14C063-AA.vbf	Jaguar XJ (X351)	FCDIM - Front Control/Display Interface Module	SBL
CW93-14C063-AB.vbf	Jaguar XJ (X351)	FCDIM - Front Control/Display Interface Module	SBL
CW93-14C063-BA.vbf	Jaguar XJ (X351)	FCDIM - Front Control/Display Interface Module	SBL
CW93-14C185-AC.vbf	Jaguar XJ (X351)	BCM - Body Control Module	DATA
CW93-14C204-MAE.vbf	Jaguar XJ (X351)	PCM - Powertrain Control Module	EXE
CW93-14C204-MBG.vbf	Jaguar XJ (X351)	PCM - Powertrain Control Module	EXE
CW93-14C204-MCE.vbf	Jaguar XJ (X351)	PCM - Powertrain Control Module	EXE
CW93-14C204-MEE.vbf	Jaguar XJ (X351)	PCM - Powertrain Control Module	EXE
CW93-14C204-RAD.vbf	Jaguar XJ (X351)	PCM - Powertrain Control Module	EXE
CW93-14C204-RCD.vbf	Jaguar XJ (X351)	PCM - Powertrain Control Module	EXE
CW93-14C204-RED.vbf	Jaguar XJ (X351)	PCM - Powertrain Control Module	EXE
CW93-14C204-RTD.vbf	Jaguar XJ (X351)	PCM - Powertrain Control Module	EXE
CW93-14C204-YAD.vbf	Jaguar XJ (X351)	PCM - Powertrain Control Module	EXE
CW93-14C204-YCD.vbf	Jaguar XJ (X351)	PCM - Powertrain Control Module	EXE
CW93-14C204-YED.vbf	Jaguar XJ (X351)	PCM - Powertrain Control Module	EXE
CW93-14C204-YTD.vbf	Jaguar XJ (X351)	PCM - Powertrain Control Module	EXE
CW93-14C204-ZAD.vbf	Jaguar XJ (X351)	PCM - Powertrain Control Module	EXE
CW93-14C204-ZCD.vbf	Jaguar XJ (X351)	PCM - Powertrain Control Module	EXE

File name	Vehicle line (indicative)	Module (ECU)	Type
CW93-14C204-ZED.vbf	Jaguar XJ (X351)	PCM - Powertrain Control Module	EXE
CW93-14C204-ZTD.vbf	Jaguar XJ (X351)	PCM - Powertrain Control Module	EXE
CW93-14C354-DA.vbf	Jaguar XJ (X351)	Not specified	EXE
CW93-14C355-AE.vbf	Jaguar XJ (X351)	Not specified	EXE
CW93-14C355-BE.vbf	Jaguar XJ (X351)	Not specified	EXE
CW93-14C413-AA.vbf	Check in SDD (unconfirmed)	DSM - Driver Front Seat Module	SIGCFG
CW93-14C453-AC.vbf	Jaguar XJ (X351)	FCDIM - Front Control/Display Interface Module	EXE
CW93-14C453-BC.vbf	Jaguar XJ (X351)	FCDIM - Front Control/Display Interface Module	EXE
CW93-14C542-AA.vbf	Jaguar XJ (X351)	ecu_address = 0x786;	EXE
CW93-14C542-BA.vbf	Jaguar XJ (X351)	ecu_address = 0x786;	EXE
CW93-14C547-AB.vbf	Range Rover (L405)	PSM - Passenger Front Seat Module	SIGCFG
CW93-14C548-AB.vbf	Range Rover (L405)	PSM - Passenger Front Seat Module	EXE
CW93-14C550-AA.vbf	Range Rover (L405)	PSM - Passenger Front Seat Module	SBL
CW93-14C621-AE.vbf	Jaguar XJ (X351)	FCDIM - Front Control/Display Interface Module	EXE
CW93-14C621-BB.vbf	Jaguar XJ (X351)	FCDIM - Front Control/Display Interface Module	EXE
CW93-14F306-AA.vbf	Jaguar XJ (X351)	Not specified	EXE
CW93-14G035-AB.vbf	Check in SDD (unconfirmed)	SCMD - Seat Control Module D	SIGCFG
CW93-14G036-AB.vbf	Range Rover (L405)	SCMD - Seat Control Module D	EXE
CW93-14G038-AA.vbf	Range Rover (L405)	SCMD - Seat Control Module D	SBL
CW93-14G045-AB.vbf	Check in SDD (unconfirmed)	SCMC - Seat Control Module C	SIGCFG
CW93-14G046-AB.vbf	Range Rover (L405)	SCMC - Seat Control Module C	EXE
CW93-14G048-AA.vbf	Range Rover (L405)	SCMC - Seat Control Module C	SBL
CW93-7J104-AFE.vbf	Jaguar XJ (X351)	TCM - Transmission Control Module	EXE
CX23-12K532-PRE.vbf	Jaguar XF (X250)	PCM - Powertrain Control Module	DATA
CX23-12K532-PTE.vbf	Jaguar XF (X250)	PCM - Powertrain Control Module	DATA
CX23-12K532-VSC.vbf	Jaguar XF (X250)	PCM - Powertrain Control Module	DATA
CX23-12K532-VTE.vbf	Jaguar XF (X250)	PCM - Powertrain Control Module	DATA
CX23-14C027-AA.vbf	Jaguar XF (X250)	RCM - Restraints Control Module	SBL
CX23-14C028-AC.vbf	Jaguar XF (X250)	RCM - Restraints Control Module	EXE
CX23-14C028-AD.vbf	Jaguar XF (X250)	RCM - Restraints Control Module	EXE
CX23-14C028-AE.vbf	Jaguar XF (X250)	RCM - Restraints Control Module	EXE
CX23-14C036-AE.vbf	Jaguar XF (X250)	ABS - Anit-Lock Brake System (ABS) Control Module	EXE
CX23-14C036-BE.vbf	Jaguar XF (X250)	ABS - Anit-Lock Brake System (ABS) Control Module	EXE
CX23-14C045-AM.vbf	Jaguar XF (X250)	ICM - Infotainment Control Module	DATA
CX23-14C045-AP.vbf	Jaguar XF (X250)	ICM - Infotainment Control Module	DATA
CX23-14C045-AT.vbf	Jaguar XF (X250)	ICM - Infotainment Control Module	DATA
CX23-14C045-AU.vbf	Jaguar XF (X250)	ICM - Infotainment Control Module	DATA
CX23-14C045-AX.vbf	Jaguar XF (X250)	ICM - Infotainment Control Module	DATA
CX23-14C045-BF.vbf	Jaguar XF (X250)	ICM - Infotainment Control Module	DATA
CX23-14C045-BH.vbf	Jaguar XF (X250)	ICM - Infotainment Control Module	DATA
CX23-14C045-BK.vbf	Jaguar XF (X250)	ICM - Infotainment Control Module	DATA
CX23-14C045-BL.vbf	Jaguar XF (X250)	ICM - Infotainment Control Module	DATA
CX23-14C045-BM.vbf	Jaguar XF (X250)	ICM - Infotainment Control Module	DATA
CX23-14C045-BN.vbf	Jaguar XF (X250)	ICM - Infotainment Control Module	DATA
CX23-14C045-BP.vbf	Jaguar XF (X250)	ICM - Infotainment Control Module	DATA
CX23-14C045-BS.vbf	Jaguar XF (X250)	ICM - Infotainment Control Module	DATA
CX23-14C060-AL.vbf	Jaguar XF (X250)	FCDIM - Front Control/Display Interface Module	EXE
CX23-14C060-AM.vbf	Jaguar XF (X250)	FCDIM - Front Control/Display Interface Module	EXE
CX23-14C061-AJ.vbf	Jaguar XF (X250)	FCDIM - Front Control/Display Interface Module	DATA
CX23-14C061-AK.vbf	Jaguar XF (X250)	FCDIM - Front Control/Display Interface Module	DATA
CX23-14C063-AC.vbf	Jaguar XF (X250)	FCDIM - Front Control/Display Interface Module	SBL
CX23-14C084-AE.vbf	Jaguar XF (X250)	HCM - Headlamp Control Module #1	EXE
CX23-14C087-AA.vbf	Jaguar XF (X250)	HCM - Headlamp Control Module #1	SBL
CX23-14C090-AC.vbf	Jaguar XF (X250)	PAM - Parking Assist Control Module	EXE
CX23-14C098-AE.vbf	Jaguar XF (X250)	RCM - Restraints Control Module	DATA
CX23-14C098-AF.vbf	Jaguar XF (X250)	RCM - Restraints Control Module	DATA
CX23-14C098-BE.vbf	Jaguar XF (X250)	RCM - Restraints Control Module	DATA
CX23-14C098-BF.vbf	Jaguar XF (X250)	RCM - Restraints Control Module	DATA
CX23-14C098-CB.vbf	Jaguar XF (X250)	RCM - Restraints Control Module	DATA
CX23-14C098-CC.vbf	Jaguar XF (X250)	RCM - Restraints Control Module	DATA
CX23-14C098-CD.vbf	Jaguar XF (X250)	RCM - Restraints Control Module	DATA
CX23-14C098-DA.vbf	Jaguar XF (X250)	RCM - Restraints Control Module	DATA
CX23-14C098-DB.vbf	Jaguar XF (X250)	RCM - Restraints Control Module	DATA
CX23-14C184-AH.vbf	Jaguar XF (X250)	BCM - Body Control Module	EXE
CX23-14C187-AE.vbf	Jaguar XF (X250)	BCM - Body Control Module	SBL
CX23-14C204-MAH.vbf	Jaguar XF (X250)	PCM - Powertrain Control Module	EXE
CX23-14C204-MAJ.vbf	Jaguar XF (X250)	PCM - Powertrain Control Module	EXE
CX23-14C204-MBG.vbf	Jaguar XF (X250)	PCM - Powertrain Control Module	EXE
CX23-14C204-MBH.vbf	Jaguar XF (X250)	PCM - Powertrain Control Module	EXE
CX23-14C204-MCG.vbf	Jaguar XF (X250)	PCM - Powertrain Control Module	EXE
CX23-14C204-MCH.vbf	Jaguar XF (X250)	PCM - Powertrain Control Module	EXE
CX23-14C204-MEG.vbf	Jaguar XF (X250)	PCM - Powertrain Control Module	EXE
CX23-14C204-MEH.vbf	Jaguar XF (X250)	PCM - Powertrain Control Module	EXE
CX23-14C204-PA.vbf	Jaguar XF (X250)	PCM - Powertrain Control Module	EXE
CX23-14C204-RAD.vbf	Jaguar XF (X250)	PCM - Powertrain Control Module	EXE
CX23-14C204-RCD.vbf	Jaguar XF (X250)	PCM - Powertrain Control Module	EXE

File name	Vehicle line (indicative)	Module (ECU)	Type
CX23-14C204-RED.vbf	Jaguar XF (X250)	PCM - Powertrain Control Module	EXE
CX23-14C204-RTD.vbf	Jaguar XF (X250)	PCM - Powertrain Control Module	EXE
CX23-14C204-VC.vbf	Jaguar XF (X250)	PCM - Powertrain Control Module	EXE
CX23-14C204-YAD.vbf	Jaguar XF (X250)	PCM - Powertrain Control Module	EXE
CX23-14C204-YCD.vbf	Jaguar XF (X250)	PCM - Powertrain Control Module	EXE
CX23-14C204-YED.vbf	Jaguar XF (X250)	PCM - Powertrain Control Module	EXE
CX23-14C204-YTD.vbf	Jaguar XF (X250)	PCM - Powertrain Control Module	EXE
CX23-14C204-ZAD.vbf	Jaguar XF (X250)	PCM - Powertrain Control Module	EXE
CX23-14C204-ZCD.vbf	Jaguar XF (X250)	PCM - Powertrain Control Module	EXE
CX23-14C204-ZED.vbf	Jaguar XF (X250)	PCM - Powertrain Control Module	EXE
CX23-14C204-ZTD.vbf	Jaguar XF (X250)	PCM - Powertrain Control Module	EXE
CX23-14C273-AA.vbf	Jaguar XF (X250)	PCM - Powertrain Control Module	SBL
CX23-14C273-VA.vbf	Jaguar XF (X250)	PCM - Powertrain Control Module	SBL
CX23-14C320-AA.vbf	Jaguar XF (X250)	DDM - Driver Front Door Module	SIGCFG
CX23-14C321-AA.vbf	Jaguar XF (X250)	DDM - Driver Front Door Module	SIGCFG
CX23-14C389-AC.vbf	Jaguar XF (X250)	TCM - Transmission Control Module	SIGCFG
CX23-14C407-AC.vbf	Jaguar XF (X250)	RCM - Restraints Control Module	SIGCFG
CX23-14C408-AB.vbf	Jaguar XF (X250)	BCM - Body Control Module	SIGCFG
CX23-14C413-AA.vbf	Range Rover Evoque (L538)	DSM - Driver Front Seat Module	SIGCFG
CX23-14C527-AD.vbf	Jaguar XF (X250)	Not specified	DATA
CX23-14C527-BD.vbf	Jaguar XF (X250)	Not specified	DATA
CX23-14C527-CD.vbf	Jaguar XF (X250)	Not specified	DATA
CX23-14C534-AB.vbf	Jaguar XF (X250)	FCIMB - Front Controls Interface Module 'B'	SIGCFG
CX23-14C535-AC.vbf	Jaguar XF (X250)	FCIMB - Front Controls Interface Module 'B'	EXE
CX23-14C536-AB.vbf	Jaguar XF (X250)	FCIMB - Front Controls Interface Module 'B'	CUSTOM
CX23-14C537-AA.vbf	Jaguar XF (X250)	FCIMB - Front Controls Interface Module 'B'	SBL
CX23-14C542-AA.vbf	Jaguar XF (X250)	ecu_address = 0x786;	EXE
CX23-14C547-AB.vbf	Jaguar XF (X250)	PSM - Passenger Front Seat Module	SIGCFG
CX23-14C560-AA.vbf	Jaguar XF (X250)	GSM - Gear Shift Module	SIGCFG
CX23-14C570-DBB.vbf	Jaguar XF (X250)	PCM - Powertrain Control Module	EXE
CX23-14C570-DCB.vbf	Jaguar XF (X250)	PCM - Powertrain Control Module	EXE
CX23-14C570-DDA.vbf	Jaguar XF (X250)	PCM - Powertrain Control Module	EXE
CX23-14C570-DEA.vbf	Jaguar XF (X250)	PCM - Powertrain Control Module	EXE
CX23-14C570-DSA.vbf	Jaguar XF (X250)	PCM - Powertrain Control Module	EXE
CX23-14C621-AG.vbf	Jaguar XF (X250)	FCDIM - Front Control/Display Interface Module	EXE
CX23-14D048-AA.vbf	Jaguar XF (X250)	CCM - Cruise Control Module	SIGCFG
CX23-14D049-AD.vbf	Jaguar XF (X250)	CCM - Cruise Control Module	EXE
CX23-14D049-BC.vbf	Jaguar XF (X250)	CCM - Cruise Control Module	EXE
CX23-14D195-AA.vbf	Jaguar XF (X250)	HCM2 - Headlamp Control Module #2	SIGCFG
CX23-14D196-AF.vbf	Jaguar XF (X250)	HCM2 - Headlamp Control Module #2	EXE
CX23-14D197-AD.vbf	Jaguar XF (X250)	HCM2 - Headlamp Control Module #2	DATA
CX23-14D519-BA.vbf	Jaguar XF (X250)	HVAC - HVAC Control Module	EXE
CX23-14D521-AA.vbf	Jaguar XF (X250)	HVAC - HVAC Control Module	SBL
CX23-14D646-AC.vbf	Jaguar XF (X250)	BCMB - Body Control Module Back	SIGCFG
CX23-14D647-AH.vbf	Jaguar XF (X250)	BCMB - Body Control Module Back	EXE
CX23-14D649-AE.vbf	Jaguar XF (X250)	BCMB - Body Control Module B	SBL
CX23-14F353-EA.vbf	Jaguar XF (X250)	SPMA - Seatbelt Pretensioner Control Module "A"	DATA
CX23-14F366-EA.vbf	Jaguar XF (X250)	SPMB - Seatbelt Pretensioner Control Module "B"	DATA
CX23-14F530-AK.vbf	Jaguar XF (X250)	GWM - Gateway Module A	EXE
CX23-14F532-AA.vbf	Jaguar XF (X250)	GWM - Gateway Module A	SBL
CX23-14F532-AB.vbf	Jaguar XF (X250)	GWM - Gateway Module A	SBL
CX23-7J104-AD.vbf	Jaguar XF (X250)	TCM - Transmission Control Module	EXE
CX23-7J104-AFE.vbf	Jaguar XF (X250)	TCM - Transmission Control Module	EXE
CX23-7J105-CE.vbf	Jaguar XF (X250)	TCM - Transmission Control Module	DATA
CX23-7J105-DE.vbf	Jaguar XF (X250)	TCM - Transmission Control Module	DATA
CX23-7J105-EE.vbf	Jaguar XF (X250)	TCM - Transmission Control Module	DATA
CX23-7J105-FA.vbf	Jaguar XF (X250)	TCM - Transmission Control Module	DATA
CX23-7J105-KA.vbf	Jaguar XF (X250)	TCM - Transmission Control Module	DATA
CX23-7J105-LE.vbf	Jaguar XF (X250)	TCM - Transmission Control Module	DATA
CX23-7J105-PC.vbf	Jaguar XF (X250)	TCM - Transmission Control Module	DATA
DH22-12K532-PBD.vbf	Discovery 3/4 (L319)	PCM - Powertrain Control Module	DATA
DH22-12K532-PCD.vbf	Discovery 3/4 (L319)	PCM - Powertrain Control Module	DATA
DH22-12K532-PKC.vbf	Discovery 3/4 (L319)	PCM - Powertrain Control Module	DATA
DH22-12K532-PKD.vbf	Discovery 3/4 (L319)	PCM - Powertrain Control Module	DATA
DH22-12K532-PMC.vbf	Discovery 3/4 (L319)	PCM - Powertrain Control Module	DATA
DH22-12K532-PMD.vbf	Discovery 3/4 (L319)	PCM - Powertrain Control Module	DATA
DH22-12K532-PRD.vbf	Discovery 3/4 (L319)	PCM - Powertrain Control Module	DATA
DH22-12K532-PTC.vbf	Discovery 3/4 (L319)	PCM - Powertrain Control Module	DATA
DH22-12K532-PTD.vbf	Discovery 3/4 (L319)	PCM - Powertrain Control Module	DATA
DH22-12K532-PUC.vbf	Discovery 3/4 (L319)	PCM - Powertrain Control Module	DATA
DH22-12K532-PUD.vbf	Discovery 3/4 (L319)	PCM - Powertrain Control Module	DATA
DH22-14C036-AC.vbf	Discovery 3/4 (L319)	ABS - Anit-Lock Brake System (ABS) Control Module	EXE
DH22-14C060-AE.vbf	Discovery 3/4 (L319)	FCDIM - Front Control/Display Interface Module	EXE
DH22-14C060-AF.vbf	Discovery 3/4 (L319)	FCDIM - Front Control/Display Interface Module	EXE
DH22-14C060-CA.vbf	Discovery 3/4 (L319)	FCDIM - Front Control/Display Interface Module	EXE
DH22-14C061-AE.vbf	Discovery 3/4 (L319)	FCDIM - Front Control/Display Interface Module	DATA

File name	Vehicle line (indicative)	Module (ECU)	Type
DH22-14C061-AF.vbf	Discovery 3/4 (L319)	FCDIM - Front Control/Display Interface Module	DATA
DH22-14C061-CA.vbf	Discovery 3/4 (L319)	FCDIM - Front Control/Display Interface Module	DATA
DH22-14C063-AA.vbf	Discovery 3/4 (L319)	FCDIM - Front Control/Display Interface Module	SBL
DH22-14C063-CA.vbf	Discovery 3/4 (L319)	FCDIM - Front Control/Display Interface Module	SBL
DH22-14C204-PA.vbf	Discovery 3/4 (L319)	PCM - Powertrain Control Module	EXE
DH22-14C273-PA.vbf	Discovery 3/4 (L319)	PCM - Powertrain Control Module	SBL
DH22-14C621-AE.vbf	Discovery 3/4 (L319)	FCDIM - Front Control/Display Interface Module	EXE
DH22-14C621-CA.vbf	Discovery 3/4 (L319)	FCDIM - Front Control/Display Interface Module	EXE
DH22-7J104-AA.vbf	Discovery 3/4 (L319)	TCM - Transmission Control Module	EXE
DH22-7J105-SB.vbf	Discovery 3/4 (L319)	TCM - Transmission Control Module	DATA
DH22-7J105-TB.vbf	Discovery 3/4 (L319)	TCM - Transmission Control Module	DATA
DH32-14C060-AF.vbf	Range Rover Sport I (L320)	FCDIM - Front Control/Display Interface Module	EXE
DH32-14C060-AG.vbf	Range Rover Sport I (L320)	FCDIM - Front Control/Display Interface Module	EXE
DH32-14C060-BF.vbf	Range Rover Sport I (L320)	FCDIM - Front Control/Display Interface Module	EXE
DH32-14C060-BG.vbf	Range Rover Sport I (L320)	FCDIM - Front Control/Display Interface Module	EXE
DH32-14C061-AF.vbf	Range Rover Sport I (L320)	FCDIM - Front Control/Display Interface Module	DATA
DH32-14C061-AG.vbf	Range Rover Sport I (L320)	FCDIM - Front Control/Display Interface Module	DATA
DH32-14C063-AA.vbf	Range Rover Sport I (L320)	FCDIM - Front Control/Display Interface Module	SBL
DH32-14C621-AF.vbf	Range Rover Sport I (L320)	FCDIM - Front Control/Display Interface Module	EXE
DH32-7J105-SB.vbf	Range Rover Sport I (L320)	TCM - Transmission Control Module	DATA
DH32-7J105-TB.vbf	Range Rover Sport I (L320)	TCM - Transmission Control Module	DATA
DH52-12K532-VAD.vbf	Freelander 2 (L359)	PCM - Powertrain Control Module	DATA
DH52-12K532-VBE.vbf	Freelander 2 (L359)	PCM - Powertrain Control Module	DATA
DH52-12K532-VCF.vbf	Freelander 2 (L359)	PCM - Powertrain Control Module	DATA
DH52-12K532-VDD.vbf	Freelander 2 (L359)	PCM - Powertrain Control Module	DATA
DH52-12K532-VFD.vbf	Freelander 2 (L359)	PCM - Powertrain Control Module	DATA
DH52-12K532-VJD.vbf	Freelander 2 (L359)	PCM - Powertrain Control Module	DATA
DH52-12K532-VKD.vbf	Freelander 2 (L359)	PCM - Powertrain Control Module	DATA
DH52-12K532-VLD.vbf	Freelander 2 (L359)	PCM - Powertrain Control Module	DATA
DH52-12K532-VRD.vbf	Freelander 2 (L359)	PCM - Powertrain Control Module	DATA
DH52-12K532-VSD.vbf	Freelander 2 (L359)	PCM - Powertrain Control Module	DATA
DH52-12K532-VTD.vbf	Freelander 2 (L359)	PCM - Powertrain Control Module	DATA
DH52-12K532-VYA.vbf	Freelander 2 (L359)	PCM - Powertrain Control Module	DATA
DH52-14C026-AE.vbf	Freelander 2 (L359)	IPC - Instrument Panel Cluster (IPC) Control Module	EXE
DH52-14C028-AA.vbf	Freelander 2 (L359)	RCM - Restraints Control Module	EXE
DH52-14C036-AE.vbf	Freelander 2 (L359)	ABS - Anit-Lock Brake System (ABS) Control Module	EXE
DH52-14C036-BA.vbf	Freelander 2 (L359)	ABS - Anit-Lock Brake System (ABS) Control Module	EXE
DH52-14C044-AC.vbf	Check in SDD (unconfirmed)	ACM - Audio Front Control Module	EXE
DH52-14C044-BC.vbf	Check in SDD (unconfirmed)	ACM - Audio Front Control Module	EXE
DH52-14C045-AJ.vbf	Freelander 2 (L359)	ICM - Infotainment Control Module	DATA
DH52-14C045-AL.vbf	Freelander 2 (L359)	ICM - Infotainment Control Module	DATA
DH52-14C045-AN.vbf	Freelander 2 (L359)	ICM - Infotainment Control Module	DATA
DH52-14C045-AP.vbf	Freelander 2 (L359)	ICM - Infotainment Control Module	DATA
DH52-14C045-AR.vbf	Freelander 2 (L359)	ICM - Infotainment Control Module	DATA
DH52-14C045-BH.vbf	Freelander 2 (L359)	ICM - Infotainment Control Module	DATA
DH52-14C045-BK.vbf	Freelander 2 (L359)	ICM - Infotainment Control Module	DATA
DH52-14C045-BL.vbf	Freelander 2 (L359)	ICM - Infotainment Control Module	DATA
DH52-14C045-BM.vbf	Freelander 2 (L359)	ICM - Infotainment Control Module	DATA
DH52-14C045-BN.vbf	Freelander 2 (L359)	ICM - Infotainment Control Module	DATA
DH52-14C045-BP.vbf	Freelander 2 (L359)	ICM - Infotainment Control Module	DATA
DH52-14C060-AJ.vbf	Freelander 2 (L359)	FCDIM - Front Control/Display Interface Module	EXE
DH52-14C060-AK.vbf	Freelander 2 (L359)	FCDIM - Front Control/Display Interface Module	EXE
DH52-14C060-CA.vbf	Freelander 2 (L359)	FCDIM - Front Control/Display Interface Module	EXE
DH52-14C061-AJ.vbf	Freelander 2 (L359)	FCDIM - Front Control/Display Interface Module	DATA
DH52-14C061-AK.vbf	Freelander 2 (L359)	FCDIM - Front Control/Display Interface Module	DATA
DH52-14C061-CA.vbf	Freelander 2 (L359)	FCDIM - Front Control/Display Interface Module	DATA
DH52-14C063-AA.vbf	Freelander 2 (L359)	FCDIM - Front Control/Display Interface Module	SBL
DH52-14C063-CA.vbf	Freelander 2 (L359)	FCDIM - Front Control/Display Interface Module	SBL
DH52-14C084-AB.vbf	Freelander 2 (L359)	HCM - Headlamp Control Module #1	EXE
DH52-14C087-AA.vbf	Freelander 2 (L359)	HCM - Headlamp Control Module #1	SBL
DH52-14C098-AA.vbf	Freelander 2 (L359)	RCM - Restraints Control Module	DATA
DH52-14C098-BA.vbf	Freelander 2 (L359)	RCM - Restraints Control Module	DATA
DH52-14C105-AB.vbf	Freelander 2 (L359)	TMC Traffic Message Channel Module	DATA
DH52-14C105-AD.vbf	Freelander 2 (L359)	TMC Traffic Message Channel Module	DATA
DH52-14C119-AA.vbf	Freelander 2 (L359)	ecu_address = 0x795;	DATA
DH52-14C184-AF.vbf	Freelander 2 (L359)	BCM - Body Control Module	EXE
DH52-14C185-AC.vbf	Freelander 2 (L359)	BCM - Body Control Module	DATA
DH52-14C204-MAL.vbf	Freelander 2 (L359)	PCM - Powertrain Control Module	EXE
DH52-14C204-MAM.vbf	Freelander 2 (L359)	PCM - Powertrain Control Module	EXE
DH52-14C204-MBJ.vbf	Freelander 2 (L359)	PCM - Powertrain Control Module	EXE
DH52-14C204-MBK.vbf	Freelander 2 (L359)	PCM - Powertrain Control Module	EXE
DH52-14C204-MCG.vbf	Freelander 2 (L359)	PCM - Powertrain Control Module	EXE
DH52-14C204-MCH.vbf	Freelander 2 (L359)	PCM - Powertrain Control Module	EXE
DH52-14C204-MEG.vbf	Freelander 2 (L359)	PCM - Powertrain Control Module	EXE
DH52-14C204-MEH.vbf	Freelander 2 (L359)	PCM - Powertrain Control Module	EXE
DH52-14C204-VA.vbf	Freelander 2 (L359)	PCM - Powertrain Control Module	EXE

File name	Vehicle line (indicative)	Module (ECU)	Type
DH52-14C319-AA.vbf	Freelander 2 (L359)	HVAC - HVAC Control Module	SIGCFG
DH52-14C337-AC.vbf	Freelander 2 (L359)	TCM Transmission Control Module	EXE
DH52-14C337-BC.vbf	Freelander 2 (L359)	TCM Transmission Control Module	EXE
DH52-14C397-AC.vbf	Freelander 2 (L359)	TCM - Transmission Control Module	SIGCFG
DH52-14C408-AC.vbf	Freelander 2 (L359)	BCM - Body Control Module	SIGCFG
DH52-14C527-AB.vbf	Freelander 2 (L359)	Not specified	DATA
DH52-14C527-AC.vbf	Freelander 2 (L359)	Not specified	DATA
DH52-14C527-BB.vbf	Freelander 2 (L359)	Not specified	DATA
DH52-14C527-DB.vbf	Freelander 2 (L359)	Not specified	DATA
DH52-14C534-AA.vbf	Freelander 2 (L359)	FCIMB - Front Controls Interface Module 'B'	SIGCFG
DH52-14C535-AA.vbf	Freelander 2 (L359)	FCIMB - Front Controls Interface Module 'B'	EXE
DH52-14C536-AA.vbf	Freelander 2 (L359)	FCIMB - Front Controls Interface Module 'B'	DATA
DH52-14C621-AG.vbf	Freelander 2 (L359)	FCDIM - Front Control/Display Interface Module	EXE
DH52-14C621-CA.vbf	Freelander 2 (L359)	FCDIM - Front Control/Display Interface Module	EXE
DH52-14D023-AA.vbf	Freelander 2 (L359)	ATCM - All Terrain Control Module	SIGCFG
DH52-14D024-AB.vbf	Freelander 2 (L359)	ATCM - All Terrain Control Module	EXE
DH52-14D182-AB.vbf	Freelander 2 (L359)	OCS - Restraints Occupant Classification System Module	EXE
DH52-14D184-AA.vbf	Freelander 2 (L359)	OCS - Restraints Occupant Classification System Module	SBL
DH52-14D358-AB.vbf	Freelander 2 (L359)	MFD - Multi functional Display	EXE
DH52-14D358-AC.vbf	Freelander 2 (L359)	MFD - Multi functional Display	EXE
DH52-14D359-AB.vbf	Freelander 2 (L359)	MFD - Multi functional Display	DATA
DH52-14D359-AC.vbf	Freelander 2 (L359)	MFD - Multi functional Display	DATA
DH52-14D479-AA.vbf	Freelander 2 (L359)	IPMB - Image Processing Module B	DATA
DH52-14D480-AD.vbf	Freelander 2 (L359)	IPMB - Image Processing Module B	EXE
DH52-14D485-AB.vbf	Freelander 2 (L359)	IPMB - Image Processing Module B	DATA
DH52-18D619-AF.vbf	Freelander 2 (L359)	HVAC - HVAC Control Module	EXE
DH52-4C045-AC.vbf	Freelander 2 (L359)	ecu_address = 0x795;	EXE
DJ32-14C030-AA.vbf	Range Rover Evoque (L538)	DSM - Driver Front Seat Module	EXE
DJ32-14C065-AA.vbf	Range Rover Evoque (L538)	DDM - Driver Front Door Module	DATA
DJ32-14C109-AA.vbf	Range Rover Evoque (L538)	PDM - Passenger Front Door Module	DATA
DJ32-14C395-AA.vbf	Range Rover Evoque (L538)	FCDIM - Front Control/Display Interface Module	EXE
DJ32-14C548-AA.vbf	Range Rover Evoque (L538)	PSM - Passenger Front Seat Module	EXE
DJ32-14D479-AA.vbf	Range Rover Evoque (L538)	IPMB - Image Processing Module B	DATA
DJ32-14D480-BC.vbf	Range Rover Evoque (L538)	IPMB - Image Processing Module B	EXE
DJ32-14D485-AA.vbf	Range Rover Evoque (L538)	IPMB - Image Processing Module B	DATA
DJ32-14F017-AD.vbf	Range Rover Evoque (L538)	IPMB - Image Processing Module B	EXE
DJ32-14F022-AA.vbf	Range Rover Evoque (L538)	IPMB - Image Processing Module B	DATA
DJ3M-14F022-AA.vbf	Range Rover Evoque (L538)	IPMB - Image Processing Module B	DATA
DK52-12K532-NAE.vbf	Range Rover (L405)	PCM - Powertrain Control Module	DATA
DK52-12K532-NCE.vbf	Range Rover (L405)	PCM - Powertrain Control Module	DATA
DK52-12K532-NRE.vbf	Range Rover (L405)	PCM - Powertrain Control Module	DATA
DK52-12K532-PBD.vbf	Range Rover (L405)	PCM - Powertrain Control Module	DATA
DK52-12K532-PEC.vbf	Range Rover (L405)	PCM - Powertrain Control Module	DATA
DK52-12K532-PLD.vbf	Range Rover (L405)	PCM - Powertrain Control Module	DATA
DK52-12K532-PMD.vbf	Range Rover (L405)	PCM - Powertrain Control Module	DATA
DK52-12K532-PRF.vbf	Range Rover (L405)	PCM - Powertrain Control Module	DATA
DK52-12K532-PSC.vbf	Range Rover (L405)	PCM - Powertrain Control Module	DATA
DK52-14C037-AAK.vbf	Range Rover (L405)	ABS - Anit-Lock Brake System (ABS) Control Module	EXE
DK52-14C037-ABK.vbf	Range Rover (L405)	ABS - Anit-Lock Brake System (ABS) Control Module	EXE
DK52-14C037-ACK.vbf	Range Rover (L405)	ABS - Anit-Lock Brake System (ABS) Control Module	EXE
DK52-14C037-ADK.vbf	Range Rover (L405)	ABS - Anit-Lock Brake System (ABS) Control Module	EXE
DK52-14C037-AEK.vbf	Range Rover (L405)	ABS - Anit-Lock Brake System (ABS) Control Module	EXE
DK52-14C091-AN.vbf	Range Rover (L405)	PAM - Parking Assist Control Module	DATA
DK52-14C091-BB.vbf	Range Rover (L405)	PAM - Parking Assist Control Module	DATA
DK52-14C098-AE.vbf	Range Rover (L405)	RCM - Restraints Control Module	DATA
DK52-14C098-AF.vbf	Range Rover (L405)	RCM - Restraints Control Module	DATA
DK52-14C098-BE.vbf	Range Rover (L405)	RCM - Restraints Control Module	DATA
DK52-14C098-BF.vbf	Range Rover (L405)	RCM - Restraints Control Module	DATA
DK52-14C098-CD.vbf	Range Rover (L405)	RCM - Restraints Control Module	DATA
DK52-14C098-CE.vbf	Range Rover (L405)	RCM - Restraints Control Module	DATA
DK52-14C098-DA.vbf	Range Rover (L405)	RCM - Restraints Control Module	DATA
DK52-14C098-DB.vbf	Range Rover (L405)	RCM - Restraints Control Module	DATA
DK52-14C098-EA.vbf	Range Rover (L405)	RCM - Restraints Control Module	DATA
DK52-14C098-EB.vbf	Range Rover (L405)	RCM - Restraints Control Module	DATA
DK52-14C121-AC.vbf	Range Rover (L405)	RGTM - Rear Gate / Trunk Module	EXE
DK52-14C122-AC.vbf	Range Rover (L405)	RGTM - Rear Gate / Trunk Module	DATA
DK52-14C169-AE.vbf	Range Rover (L405)	PBM - Park Brake Control Module	EXE
DK52-14C185-AE.VBF	Range Rover (L405)	BCM - Body Control Module	DATA
DK52-14C204-RAE.vbf	Range Rover (L405)	PCM - Powertrain Control Module	EXE
DK52-14C204-RAF.vbf	Range Rover (L405)	PCM - Powertrain Control Module	EXE
DK52-14C204-RCC.vbf	Range Rover (L405)	PCM - Powertrain Control Module	EXE
DK52-14C204-RCD.vbf	Range Rover (L405)	PCM - Powertrain Control Module	EXE
DK52-14C204-RCE.vbf	Range Rover (L405)	PCM - Powertrain Control Module	EXE
DK52-14C204-RED.vbf	Range Rover (L405)	PCM - Powertrain Control Module	EXE
DK52-14C204-REE.vbf	Range Rover (L405)	PCM - Powertrain Control Module	EXE
DK52-14C204-RGC.vbf	Range Rover (L405)	PCM - Powertrain Control Module	EXE

File name	Vehicle line (indicative)	Module (ECU)	Type
DK52-14C204-RGD.vbf	Range Rover (L405)	PCM - Powertrain Control Module	EXE
DK52-14C204-RTE.vbf	Range Rover (L405)	PCM - Powertrain Control Module	EXE
DK52-14C204-RTF.vbf	Range Rover (L405)	PCM - Powertrain Control Module	EXE
DK52-14C204-RTG.vbf	Range Rover (L405)	PCM - Powertrain Control Module	EXE
DK52-14C204-TAG.vbf	Range Rover (L405)	PCM - Powertrain Control Module	EXE
DK52-14C204-TAH.vbf	Range Rover (L405)	PCM - Powertrain Control Module	EXE
DK52-14C204-TAJ.vbf	Range Rover (L405)	PCM - Powertrain Control Module	EXE
DK52-14C204-TCE.vbf	Range Rover (L405)	PCM - Powertrain Control Module	EXE
DK52-14C204-TCF.vbf	Range Rover (L405)	PCM - Powertrain Control Module	EXE
DK52-14C204-TCG.vbf	Range Rover (L405)	PCM - Powertrain Control Module	EXE
DK52-14C204-TGD.vbf	Range Rover (L405)	PCM - Powertrain Control Module	EXE
DK52-14C204-TGE.vbf	Range Rover (L405)	PCM - Powertrain Control Module	EXE
DK52-14C204-TGF.vbf	Range Rover (L405)	PCM - Powertrain Control Module	EXE
DK52-14C204-TTF.vbf	Range Rover (L405)	PCM - Powertrain Control Module	EXE
DK52-14C204-TTG.vbf	Range Rover (L405)	PCM - Powertrain Control Module	EXE
DK52-14C204-TTH.vbf	Range Rover (L405)	PCM - Powertrain Control Module	EXE
DK52-14C204-TTJ.vbf	Range Rover (L405)	PCM - Powertrain Control Module	EXE
DK52-14C204-TTK.vbf	Range Rover (L405)	PCM - Powertrain Control Module	EXE
DK52-14C204-YCE.vbf	Range Rover (L405)	PCM - Powertrain Control Module	EXE
DK52-14C204-YCF.vbf	Range Rover (L405)	PCM - Powertrain Control Module	EXE
DK52-14C204-YTD.vbf	Range Rover (L405)	PCM - Powertrain Control Module	EXE
DK52-14C204-YTE.vbf	Range Rover (L405)	PCM - Powertrain Control Module	EXE
DK52-14C218-AC.vbf	Range Rover (L405)	PSCM - Power Steering Control Module	EXE
DK52-14C218-BB.vbf	Range Rover (L405)	PSCM - Power Steering Control Module	EXE
DK52-14C218-CA.vbf	Range Rover (L405)	PSCM - Power Steering Control Module	EXE
DK52-14C609-AC.vbf	Range Rover (L405)	PSCM - Power Steering Control Module	EXE
DK52-14D196-AA.vbf	Range Rover (L405)	HCM2 - Headlamp Control Module #2	EXE
DK52-14D197-AA.vbf	Range Rover (L405)	HCM2 - Headlamp Control Module #2	DATA
DK52-14D480-AD.vbf	Range Rover (L405)	IPMB - Image Processing Module B	EXE
DK52-14D485-AB.vbf	Range Rover (L405)	IPMB - Image Processing Module B	DATA
DK52-14D520-AB.vbf	Range Rover (L405)	HVAC - HVAC Control Module	DATA
DK52-14D520-AK.vbf	Range Rover (L405)	HVAC - HVAC Control Module	DATA
DK52-14D520-AL.vbf	Range Rover (L405)	HVAC - HVAC Control Module	DATA
DK52-14D520-AM.vbf	Range Rover (L405)	HVAC - HVAC Control Module	DATA
DK52-14D520-AN.vbf	Range Rover (L405)	HVAC - HVAC Control Module	DATA
DK52-14D520-AP.vbf	Range Rover (L405)	HVAC - HVAC Control Module	DATA
DK52-14D520-AR.vbf	Range Rover (L405)	HVAC - HVAC Control Module	DATA
DK52-14D520-AS.vbf	Range Rover (L405)	HVAC - HVAC Control Module	DATA
DK52-14D520-AT.vbf	Range Rover (L405)	HVAC - HVAC Control Module	DATA
DK52-14D520-BB.vbf	Range Rover (L405)	HVAC - HVAC Control Module	DATA
DK52-14D520-CA.vbf	Range Rover (L405)	HVAC - HVAC Control Module	DATA
DK52-14D520-CE.vbf	Range Rover (L405)	HVAC - HVAC Control Module	DATA
DK52-14D520-CF.vbf	Range Rover (L405)	HVAC - HVAC Control Module	DATA
DK52-14D564-AG.vbf	Range Rover (L405)	SODL - Side Obstacle Detection Control Module - Left	DATA
DK52-14D564-BG.vbf	Range Rover (L405)	SODR - Side Obstacle Detection Control Module - Right	DATA
DK52-14E094-JAK.vbf	Range Rover (L405)	CHCM - Chassis Control Module	EXE
DK52-14E094-JAL.vbf	Range Rover (L405)	CHCM - Chassis Control Module	EXE
DK52-14E094-JBJ.vbf	Range Rover (L405)	CHCM - Chassis Control Module	EXE
DK52-14E094-JBK.vbf	Range Rover (L405)	CHCM - Chassis Control Module	EXE
DK52-14E094-JCJ.vbf	Range Rover (L405)	CHCM - Chassis Control Module	EXE
DK52-14E094-JCK.vbf	Range Rover (L405)	CHCM - Chassis Control Module	EXE
DK52-14E094-JDJ.vbf	Range Rover (L405)	CHCM - Chassis Control Module	EXE
DK52-14E094-JDK.vbf	Range Rover (L405)	CHCM - Chassis Control Module	EXE
DK52-14E094-JEJ.vbf	Range Rover (L405)	CHCM - Chassis Control Module	EXE
DK52-14E094-JEK.vbf	Range Rover (L405)	CHCM - Chassis Control Module	EXE
DK52-14E094-JNA.vbf	Range Rover (L405)	CHCM - Chassis Control Module	EXE
DK52-14F022-AD.vbf	Check in SDD (unconfirmed)	IPMB - Image Processing Module B	DATA
DK52-14F353-EB.vbf	Range Rover (L405)	SPMA - Seatbelt Pretensioner Control Module A	DATA
DK52-14F366-EB.vbf	Range Rover (L405)	SPMB - Seatbelt Pretensioner Control Module B	DATA
DK52-14F435-LAG.vbf	Range Rover (L405)	CHCMB - Chassis Control Module B	EXE
DK52-14F435-LBG.vbf	Range Rover (L405)	CHCMB - Chassis Control Module B	EXE
DK52-14F435-NAA.vbf	Range Rover (L405)	CHCMB - Chassis Control Module B	EXE
DK52-14F435-NBA.vbf	Range Rover (L405)	CHCMB - Chassis Control Module B	EXE
DK52-14F435-NEC.vbf	Range Rover (L405)	CHCMB - Chassis Control Module B	EXE
DK52-14F435-NFC.vbf	Range Rover (L405)	CHCMB - Chassis Control Module B	EXE
DK52-14F456-AB.vbf	Range Rover (L405)	HCMB - Headlamp Control Module B	DATA
DK52-14F456-BA.vbf	Range Rover (L405)	HCMB - Headlamp Control Module B	DATA
DK52-14F671-AC.vbf	Range Rover (L405)	RGTM - Rear Gate / Trunk Module	EXE
DK52-14F672-AC.vbf	Range Rover (L405)	RGTM - Rear Gate / Trunk Module	DATA
DK52-7J104-BAD.vbf	Range Rover (L405)	TCM - Transmission Control Module	EXE
DK52-7J104-BAE.vbf	Range Rover (L405)	TCM - Transmission Control Module	EXE
DK52-7J104-BBD.vbf	Range Rover (L405)	TCM - Transmission Control Module	EXE
DK52-7J104-BBE.vbf	Range Rover (L405)	TCM - Transmission Control Module	EXE
DK52-7J104-BBF.vbf	Range Rover (L405)	TCM - Transmission Control Module	EXE
DK52-7J104-BCE.vbf	Range Rover (L405)	TCM - Transmission Control Module	EXE
DK52-7J104-BDE.vbf	Range Rover (L405)	TCM - Transmission Control Module	EXE

File name	Vehicle line (indicative)	Module (ECU)	Type
DK52-7J104-BDF.vbf	Range Rover (L405)	TCM - Transmission Control Module	EXE
DK52-7J104-BDG.vbf	Range Rover (L405)	TCM - Transmission Control Module	EXE
DK52-7J104-BHD.vbf	Range Rover (L405)	TCM - Transmission Control Module	EXE
DK52-7J104-BHE.vbf	Range Rover (L405)	TCM - Transmission Control Module	EXE
DK52-7J104-BJC.vbf	Range Rover (L405)	TCM - Transmission Control Module	EXE
DK52-7J104-BLC.vbf	Range Rover (L405)	TCM - Transmission Control Module	EXE
DK52-7J104-BMC.vbf	Range Rover (L405)	TCM - Transmission Control Module	EXE
DK5M-14E094-JPG.vbf	Not specified	CHCM - Chassis Control Module	EXE
DK5M-14E094-JPH.vbf	Not specified	CHCM - Chassis Control Module	EXE
DK5M-14F531-AB.vbf	Not specified	GWM - Gateway Module A	DATA
DK62-12K532-PBD.vbf	Range Rover Sport (L494)	PCM - Powertrain Control Module	DATA
DK62-12K532-PCD.vbf	Range Rover Sport (L494)	PCM - Powertrain Control Module	DATA
DK62-12K532-PDC.vbf	Range Rover Sport (L494)	PCM - Powertrain Control Module	DATA
DK62-12K532-PLE.vbf	Range Rover Sport (L494)	PCM - Powertrain Control Module	DATA
DK62-12K532-PMD.vbf	Range Rover Sport (L494)	PCM - Powertrain Control Module	DATA
DK62-12K532-PRF.vbf	Range Rover Sport (L494)	PCM - Powertrain Control Module	DATA
DK62-12K532-PSC.vbf	Range Rover Sport (L494)	PCM - Powertrain Control Module	DATA
DK62-12K532-PTE.vbf	Range Rover Sport (L494)	PCM - Powertrain Control Module	DATA
DK62-14C028-AF.vbf	Range Rover Sport (L494)	RCM - Restraints Control Module	EXE
DK62-14C028-AG.vbf	Range Rover Sport (L494)	RCM - Restraints Control Module	EXE
DK62-14C030-AA.vbf	Range Rover Sport (L494)	DSM - Driver Front Seat Module	EXE
DK62-14C030-BA.vbf	Range Rover Sport (L494)	DSM - Driver Front Seat Module	EXE
DK62-14C034-CA.vbf	Range Rover Sport (L494)	DSM - Driver Front Seat Module	DATA
DK62-14C034-DA.vbf	Range Rover Sport (L494)	DSM - Driver Front Seat Module	DATA
DK62-14C034-EA.vbf	Range Rover Sport (L494)	DSM - Driver Front Seat Module	DATA
DK62-14C034-FA.vbf	Range Rover Sport (L494)	DSM - Driver Front Seat Module	DATA
DK62-14C034-HA.vbf	Range Rover Sport (L494)	DSM - Driver Front Seat Module	DATA
DK62-14C037-AAK.vbf	Range Rover Sport (L494)	ABS - Anit-Lock Brake System (ABS) Control Module	EXE
DK62-14C037-ABK.vbf	Range Rover Sport (L494)	ABS - Anit-Lock Brake System (ABS) Control Module	EXE
DK62-14C037-ACK.vbf	Range Rover Sport (L494)	ABS - Anit-Lock Brake System (ABS) Control Module	EXE
DK62-14C037-ADK.vbf	Range Rover Sport (L494)	ABS - Anit-Lock Brake System (ABS) Control Module	EXE
DK62-14C037-AEK.vbf	Range Rover Sport (L494)	ABS - Anit-Lock Brake System (ABS) Control Module	EXE
DK62-14C037-AFK.vbf	Range Rover Sport (L494)	ABS - Anit-Lock Brake System (ABS) Control Module	EXE
DK62-14C037-AGK.vbf	Range Rover Sport (L494)	ABS - Anit-Lock Brake System (ABS) Control Module	EXE
DK62-14C060-AH.vbf	Range Rover Sport (L494)	FCDIM - Front Control/Display Interface Module	EXE
DK62-14C060-AJ.vbf	Range Rover Sport (L494)	FCDIM - Front Control/Display Interface Module	EXE
DK62-14C060-AK.vbf	Range Rover Sport (L494)	FCDIM - Front Control/Display Interface Module	EXE
DK62-14C060-BH.vbf	Range Rover Sport (L494)	FCDIM - Front Control/Display Interface Module	EXE
DK62-14C060-BJ.vbf	Range Rover Sport (L494)	FCDIM - Front Control/Display Interface Module	EXE
DK62-14C060-BK.vbf	Range Rover Sport (L494)	FCDIM - Front Control/Display Interface Module	EXE
DK62-14C061-AH.vbf	Range Rover Sport (L494)	FCDIM - Front Control/Display Interface Module	DATA
DK62-14C061-AJ.vbf	Range Rover Sport (L494)	FCDIM - Front Control/Display Interface Module	DATA
DK62-14C061-AK.vbf	Range Rover Sport (L494)	FCDIM - Front Control/Display Interface Module	DATA
DK62-14C063-AB.vbf	Range Rover Sport (L494)	FCDIM - Front Control/Display Interface Module	SBL
DK62-14C084-AD.vbf	Range Rover Sport (L494)	HCM - Headlamp Control Module #1	EXE
DK62-14C087-AA.vbf	Range Rover Sport (L494)	HCM - Headlamp Control Module #1	SBL
DK62-14C091-AN.vbf	Range Rover Sport (L494)	PAM - Parking Assist Control Module	DATA
DK62-14C091-BB.vbf	Range Rover Sport (L494)	PAM - Parking Assist Control Module	DATA
DK62-14C098-AH.vbf	Range Rover Sport (L494)	RCM - Restraints Control Module	DATA
DK62-14C098-AJ.vbf	Range Rover Sport (L494)	RCM - Restraints Control Module	DATA
DK62-14C098-BG.vbf	Range Rover Sport (L494)	RCM - Restraints Control Module	DATA
DK62-14C098-BH.vbf	Range Rover Sport (L494)	RCM - Restraints Control Module	DATA
DK62-14C098-CF.vbf	Range Rover Sport (L494)	RCM - Restraints Control Module	DATA
DK62-14C098-CG.vbf	Range Rover Sport (L494)	RCM - Restraints Control Module	DATA
DK62-14C121-AC.vbf	Range Rover Sport (L494)	RGTM - Rear Gate / Trunk Module	EXE
DK62-14C122-AC.vbf	Range Rover Sport (L494)	RGTM - Rear Gate / Trunk Module	DATA
DK62-14C124-AA.vbf	Range Rover Sport (L494)	RGTM - Rear Gate / Trunk Module	SBL
DK62-14C169-AE.vbf	Range Rover Sport (L494)	PBM - Park Brake Control Module	EXE
DK62-14C185-AG.VBF	Range Rover Sport (L494)	BCM - Body Control Module	DATA
DK62-14C204-RAE.vbf	Range Rover Sport (L494)	PCM - Powertrain Control Module	EXE
DK62-14C204-RAF.vbf	Range Rover Sport (L494)	PCM - Powertrain Control Module	EXE
DK62-14C204-RCE.vbf	Range Rover Sport (L494)	PCM - Powertrain Control Module	EXE
DK62-14C204-RCF.vbf	Range Rover Sport (L494)	PCM - Powertrain Control Module	EXE
DK62-14C204-RCG.vbf	Range Rover Sport (L494)	PCM - Powertrain Control Module	EXE
DK62-14C204-REE.vbf	Range Rover Sport (L494)	PCM - Powertrain Control Module	EXE
DK62-14C204-REF.vbf	Range Rover Sport (L494)	PCM - Powertrain Control Module	EXE
DK62-14C204-RGC.vbf	Range Rover Sport (L494)	PCM - Powertrain Control Module	EXE
DK62-14C204-RGD.vbf	Range Rover Sport (L494)	PCM - Powertrain Control Module	EXE
DK62-14C204-RTE.vbf	Range Rover Sport (L494)	PCM - Powertrain Control Module	EXE
DK62-14C204-RTF.vbf	Range Rover Sport (L494)	PCM - Powertrain Control Module	EXE
DK62-14C204-RTG.vbf	Range Rover Sport (L494)	PCM - Powertrain Control Module	EXE
DK62-14C204-TAG.vbf	Range Rover Sport (L494)	PCM - Powertrain Control Module	EXE
DK62-14C204-TAH.vbf	Range Rover Sport (L494)	PCM - Powertrain Control Module	EXE
DK62-14C204-TAJ.vbf	Range Rover Sport (L494)	PCM - Powertrain Control Module	EXE
DK62-14C204-TCG.vbf	Range Rover Sport (L494)	PCM - Powertrain Control Module	EXE
DK62-14C204-TCH.vbf	Range Rover Sport (L494)	PCM - Powertrain Control Module	EXE

File name	Vehicle line (indicative)	Module (ECU)	Type
DK62-14C204-TCJ.vbf	Range Rover Sport (L494)	PCM - Powertrain Control Module	EXE
DK62-14C204-TEF.vbf	Range Rover Sport (L494)	PCM - Powertrain Control Module	EXE
DK62-14C204-TEG.vbf	Range Rover Sport (L494)	PCM - Powertrain Control Module	EXE
DK62-14C204-TEH.vbf	Range Rover Sport (L494)	PCM - Powertrain Control Module	EXE
DK62-14C204-TGD.vbf	Range Rover Sport (L494)	PCM - Powertrain Control Module	EXE
DK62-14C204-TGE.vbf	Range Rover Sport (L494)	PCM - Powertrain Control Module	EXE
DK62-14C204-TGF.vbf	Range Rover Sport (L494)	PCM - Powertrain Control Module	EXE
DK62-14C204-TTF.vbf	Range Rover Sport (L494)	PCM - Powertrain Control Module	EXE
DK62-14C204-TTG.vbf	Range Rover Sport (L494)	PCM - Powertrain Control Module	EXE
DK62-14C204-TTH.vbf	Range Rover Sport (L494)	PCM - Powertrain Control Module	EXE
DK62-14C204-TTJ.vbf	Range Rover Sport (L494)	PCM - Powertrain Control Module	EXE
DK62-14C204-TTK.vbf	Range Rover Sport (L494)	PCM - Powertrain Control Module	EXE
DK62-14C218-AC.vbf	Range Rover Sport (L494)	PSCM - Power Steering Control Module	EXE
DK62-14C218-BC.vbf	Range Rover Sport (L494)	PSCM - Power Steering Control Module	EXE
DK62-14C218-BD.vbf	Range Rover Sport (L494)	PSCM - Power Steering Control Module	EXE
DK62-14C407-AC.vbf	Range Rover Sport (L494)	RCM - Restraints Control Module	SIGCFG
DK62-14C407-AD.vbf	Range Rover Sport (L494)	RCM - Restraints Control Module	SIGCFG
DK62-14C413-AD.vbf	Range Rover Sport (L494)	DSM - Driver Front Seat Module	SIGCFG
DK62-14C527-BB.vbf	Range Rover Sport (L494)	Not specified	DATA
DK62-14C527-CD.vbf	Range Rover Sport (L494)	Not specified	DATA
DK62-14C527-DG.vbf	Range Rover Sport (L494)	Not specified	DATA
DK62-14C527-EA.vbf	Range Rover Sport (L494)	Not specified	DATA
DK62-14C547-AE.vbf	Range Rover Sport (L494)	PSM - Passenger Front Seat Module	SIGCFG
DK62-14C548-AA.vbf	Range Rover Sport (L494)	PSM - Passenger Front Seat Module	EXE
DK62-14C548-BA.vbf	Range Rover Sport (L494)	PSM - Passenger Front Seat Module	EXE
DK62-14C549-CA.vbf	Range Rover Sport (L494)	PSM - Passenger Front Seat Module	DATA
DK62-14C549-DA.vbf	Range Rover Sport (L494)	PSM - Passenger Front Seat Module	DATA
DK62-14C549-EA.vbf	Range Rover Sport (L494)	PSM - Passenger Front Seat Module	DATA
DK62-14C549-FA.vbf	Range Rover Sport (L494)	PSM - Passenger Front Seat Module	DATA
DK62-14C549-HA.vbf	Range Rover Sport (L494)	PSM - Passenger Front Seat Module	DATA
DK62-14C609-AC.vbf	Range Rover Sport (L494)	PSCM - Power Steering Control Module	EXE
DK62-14C621-AF.vbf	Range Rover Sport (L494)	FCDIM - Front Control/Display Interface Module	EXE
DK62-14D181-AA.vbf	Range Rover Sport (L494)	OCS - Restraints Occupant Classification System Module	SIGCFG
DK62-14D183-AA.vbf	Range Rover Sport (L494)	OCS - Restraints Occupant Classification System Module	DATA
DK62-14D183-AC.vbf	Range Rover Sport (L494)	OCS - Restraints Occupant Classification System Module	DATA
DK62-14D480-AE.vbf	Range Rover Sport (L494)	IPMB - Image Processing Module B	EXE
DK62-14D485-AC.vbf	Range Rover Sport (L494)	IPMB - Image Processing Module B	DATA
DK62-14D520-AB.vbf	Range Rover Sport (L494)	HVAC - HVAC Control Module	DATA
DK62-14D520-AJ.vbf	Range Rover Sport (L494)	HVAC - HVAC Control Module	DATA
DK62-14D520-AK.vbf	Range Rover Sport (L494)	HVAC - HVAC Control Module	DATA
DK62-14D520-AL.vbf	Range Rover Sport (L494)	HVAC - HVAC Control Module	DATA
DK62-14D520-AM.vbf	Range Rover Sport (L494)	HVAC - HVAC Control Module	DATA
DK62-14D520-AN.vbf	Range Rover Sport (L494)	HVAC - HVAC Control Module	DATA
DK62-14D520-AP.vbf	Range Rover Sport (L494)	HVAC - HVAC Control Module	DATA
DK62-14D520-AR.vbf	Range Rover Sport (L494)	HVAC - HVAC Control Module	DATA
DK62-14D520-AS.vbf	Range Rover Sport (L494)	HVAC - HVAC Control Module	DATA
DK62-14D520-AT.vbf	Range Rover Sport (L494)	HVAC - HVAC Control Module	DATA
DK62-14D520-BB.vbf	Range Rover Sport (L494)	HVAC - HVAC Control Module	DATA
DK62-14D520-BF.vbf	Range Rover Sport (L494)	HVAC - HVAC Control Module	DATA
DK62-14D520-BG.vbf	Range Rover Sport (L494)	HVAC - HVAC Control Module	DATA
DK62-14D520-BH.vbf	Range Rover Sport (L494)	HVAC - HVAC Control Module	DATA
DK62-14D520-CA.vbf	Range Rover Sport (L494)	HVAC - HVAC Control Module	DATA
DK62-14D520-CD.vbf	Range Rover Sport (L494)	HVAC - HVAC Control Module	DATA
DK62-14D520-CE.vbf	Range Rover Sport (L494)	HVAC - HVAC Control Module	DATA
DK62-14D520-CF.vbf	Range Rover Sport (L494)	HVAC - HVAC Control Module	DATA
DK62-14D564-AE.vbf	Range Rover Sport (L494)	SODL - Side Obstacle Detection Control Module - Left	DATA
DK62-14D564-BE.vbf	Range Rover Sport (L494)	SODR - Side Obstacle Detection Control Module - Right	DATA
DK62-14E094-HAJ.vbf	Range Rover Sport (L494)	CHCM - Chassis Control Module	EXE
DK62-14E094-HAK.vbf	Range Rover Sport (L494)	CHCM - Chassis Control Module	EXE
DK62-14E094-HBH.vbf	Range Rover Sport (L494)	CHCM - Chassis Control Module	EXE
DK62-14E094-HBJ.vbf	Range Rover Sport (L494)	CHCM - Chassis Control Module	EXE
DK62-14E094-JAG.vbf	Range Rover Sport (L494)	CHCM - Chassis Control Module	EXE
DK62-14E094-JAJ.vbf	Range Rover Sport (L494)	CHCM - Chassis Control Module	EXE
DK62-14E094-JAK.vbf	Range Rover Sport (L494)	CHCM - Chassis Control Module	EXE
DK62-14E094-JBG.vbf	Range Rover Sport (L494)	CHCM - Chassis Control Module	EXE
DK62-14E094-JBJ.vbf	Range Rover Sport (L494)	CHCM - Chassis Control Module	EXE
DK62-14E094-JBK.vbf	Range Rover Sport (L494)	CHCM - Chassis Control Module	EXE
DK62-14E094-JCJ.vbf	Range Rover Sport (L494)	CHCM - Chassis Control Module	EXE
DK62-14E094-JCK.vbf	Range Rover Sport (L494)	CHCM - Chassis Control Module	EXE
DK62-14E094-JDJ.vbf	Range Rover Sport (L494)	CHCM - Chassis Control Module	EXE
DK62-14E094-JDK.vbf	Range Rover Sport (L494)	CHCM - Chassis Control Module	EXE
DK62-14E094-JEJ.vbf	Range Rover Sport (L494)	CHCM - Chassis Control Module	EXE
DK62-14E094-JEK.vbf	Range Rover Sport (L494)	CHCM - Chassis Control Module	EXE
DK62-14F022-AF.vbf	Range Rover Sport (L494)	IPMB - Image Processing Module B	DATA
DK62-14F353-EC.vbf	Range Rover Sport (L494)	SPMA - Seatbelt Pretensioner Control Module A	DATA
DK62-14F366-EC.vbf	Range Rover Sport (L494)	SPMB - Seatbelt Pretensioner Control Module B	DATA

File name	Vehicle line (indicative)	Module (ECU)	Type
DK62-14F435-LAG.vbf	Range Rover Sport (L494)	CHCMB - Chassis Control Module B	EXE
DK62-14F435-LBG.vbf	Range Rover Sport (L494)	CHCMB - Chassis Control Module B	EXE
DK62-14F435-NAA.vbf	Range Rover Sport (L494)	CHCMB - Chassis Control Module B	EXE
DK62-14F435-NBA.vbf	Range Rover Sport (L494)	CHCMB - Chassis Control Module B	EXE
DK62-14F435-NDC.vbf	Range Rover Sport (L494)	CHCMB - Chassis Control Module B	EXE
DK62-14F435-NEC.vbf	Range Rover Sport (L494)	CHCMB - Chassis Control Module B	EXE
DK62-14G035-AD.vbf	Range Rover Sport (L494)	PRSM - Passenger Rear Seat Module	SIGCFG
DK62-14G036-AA.vbf	Range Rover Sport (L494)	PRSM - Passenger Rear Seat Module	EXE
DK62-14G037-BA.vbf	Range Rover Sport (L494)	PRSM - Passenger Rear Seat Module	DATA
DK62-14G037-CA.vbf	Range Rover Sport (L494)	PRSM - Passenger Rear Seat Module	DATA
DK62-14G037-DA.vbf	Range Rover Sport (L494)	PRSM - Passenger Rear Seat Module	DATA
DK62-14G037-EA.vbf	Range Rover Sport (L494)	PRSM - Passenger Rear Seat Module	DATA
DK62-14G045-AD.vbf	Range Rover Sport (L494)	DRSM - Driver Rear Seat Module	SIGCFG
DK62-14G046-AA.vbf	Range Rover Sport (L494)	DRSM - Driver Rear Seat Module	EXE
DK62-14G047-BA.vbf	Range Rover Sport (L494)	DRSM - Driver Rear Seat Module	DATA
DK62-14G047-CA.vbf	Range Rover Sport (L494)	DRSM - Driver Rear Seat Module	DATA
DK62-14G047-DA.vbf	Range Rover Sport (L494)	DRSM - Driver Rear Seat Module	DATA
DK62-14G047-EA.vbf	Range Rover Sport (L494)	DRSM - Driver Rear Seat Module	DATA
DK62-7J104-BBE.vbf	Range Rover Sport (L494)	TCM - Transmission Control Module	EXE
DK62-7J104-BBF.vbf	Range Rover Sport (L494)	TCM - Transmission Control Module	EXE
DK62-7J104-BBG.vbf	Range Rover Sport (L494)	TCM - Transmission Control Module	EXE
DK62-7J104-BCE.vbf	Range Rover Sport (L494)	TCM - Transmission Control Module	EXE
DK62-7J104-BDE.vbf	Range Rover Sport (L494)	TCM - Transmission Control Module	EXE
DK62-7J104-BDF.vbf	Range Rover Sport (L494)	TCM - Transmission Control Module	EXE
DK62-7J104-BDG.vbf	Range Rover Sport (L494)	TCM - Transmission Control Module	EXE
DK62-7J104-BDH.vbf	Range Rover Sport (L494)	TCM - Transmission Control Module	EXE
DK62-7J104-BDJ.vbf	Range Rover Sport (L494)	TCM - Transmission Control Module	EXE
DK62-7J104-BGE.vbf	Range Rover Sport (L494)	TCM - Transmission Control Module	EXE
DK62-7J104-BHD.vbf	Range Rover Sport (L494)	TCM - Transmission Control Module	EXE
DK62-7J104-BHE.vbf	Range Rover Sport (L494)	TCM - Transmission Control Module	EXE
DK62-7J104-BLC.vbf	Range Rover Sport (L494)	TCM - Transmission Control Module	EXE
DK62-7J104-BMC.vbf	Range Rover Sport (L494)	TCM - Transmission Control Module	EXE
DPLA-14C025-AB.vbf	Multiple models (shared module)	IPC - Instrument Panel Cluster (IPC) Control Module	SBL
DPLA-14C026-DB.vbf	Multiple models (shared module)	IPC - Instrument Panel Cluster (IPC) Control Module	EXE
DPLA-14C029-AA.vbf	Range Rover Sport (L494)	DSM - Driver Front Seat Module	SBL
DPLA-14C029-BA.vbf	Range Rover Sport (L494)	DSM - Driver Front Seat Module	SBL
DPLA-14C030-AC.vbf	Range Rover Sport (L494)	DSM - Driver Front Seat Module	EXE
DPLA-14C030-BC.vbf	Range Rover Sport (L494)	DSM - Driver Front Seat Module	EXE
DPLA-14C030-CA.vbf	Range Rover Sport (L494)	DSM - Driver Front Seat Module	EXE
DPLA-14C030-CB.vbf	Range Rover Sport (L494)	DSM - Driver Front Seat Module	EXE
DPLA-14C034-AA.vbf	Range Rover Sport (L494)	DSM - Driver Front Seat Module	DATA
DPLA-14C034-CA.vbf	Range Rover Sport (L494)	DSM - Driver Front Seat Module	DATA
DPLA-14C034-DA.vbf	Range Rover Sport (L494)	DSM - Driver Front Seat Module	DATA
DPLA-14C034-EA.vbf	Range Rover Sport (L494)	DSM - Driver Front Seat Module	DATA
DPLA-14C034-FA.vbf	Range Rover Sport (L494)	DSM - Driver Front Seat Module	DATA
DPLA-14C034-HA.vbf	Range Rover Sport (L494)	DSM - Driver Front Seat Module	DATA
DPLA-14C034-JA.vbf	Range Rover Sport (L494)	DSM - Driver Front Seat Module	DATA
DPLA-14C036-AH.vbf	Multiple models (shared module)	ABS - Anit-Lock Brake System (ABS) Control Module	EXE
DPLA-14C045-AN.vbf	Multiple models (shared module)	ICM - Infotainment Control Module	DATA
DPLA-14C045-AP.vbf	Multiple models (shared module)	ICM - Infotainment Control Module	DATA
DPLA-14C045-BH.vbf	Multiple models (shared module)	ICM - Infotainment Control Module	DATA
DPLA-14C045-BK.vbf	Multiple models (shared module)	ICM - Infotainment Control Module	DATA
DPLA-14C045-BL.vbf	Multiple models (shared module)	ICM - Infotainment Control Module	DATA
DPLA-14C045-BM.vbf	Multiple models (shared module)	ICM - Infotainment Control Module	DATA
DPLA-14C045-BN.vbf	Multiple models (shared module)	ICM - Infotainment Control Module	DATA
DPLA-14C045-BP.vbf	Multiple models (shared module)	ICM - Infotainment Control Module	DATA
DPLA-14C056-AC.vbf	Multiple models (shared module)	NCM - Navigation Control Module	EXE
DPLA-14C056-BB.vbf	Multiple models (shared module)	NCM - Navigation Control Module	EXE
DPLA-14C059-BA.vbf	Multiple models (shared module)	NCM - Navigation Control Module	SBL
DPLA-14C059-CA.vbf	Multiple models (shared module)	NCM - Navigation Control Module	SBL
DPLA-14C060-AH.vbf	Multiple models (shared module)	FCDIM - Front Control/Display Interface Module	EXE
DPLA-14C060-AJ.vbf	Multiple models (shared module)	FCDIM - Front Control/Display Interface Module	EXE
DPLA-14C060-AK.vbf	Multiple models (shared module)	FCDIM - Front Control/Display Interface Module	EXE
DPLA-14C060-BH.vbf	Multiple models (shared module)	FCDIM - Front Control/Display Interface Module	EXE
DPLA-14C060-BJ.vbf	Multiple models (shared module)	FCDIM - Front Control/Display Interface Module	EXE
DPLA-14C060-BK.vbf	Multiple models (shared module)	FCDIM - Front Control/Display Interface Module	EXE
DPLA-14C061-AH.vbf	Multiple models (shared module)	FCDIM - Front Control/Display Interface Module	DATA
DPLA-14C061-AJ.vbf	Multiple models (shared module)	FCDIM - Front Control/Display Interface Module	DATA
DPLA-14C061-AK.vbf	Multiple models (shared module)	FCDIM - Front Control/Display Interface Module	DATA
DPLA-14C063-AB.vbf	Multiple models (shared module)	FCDIM - Front Control/Display Interface Module	SBL
DPLA-14C064-AC.vbf	Check in SDD (unconfirmed)	DDM - Driver Front Door Module	EXE
DPLA-14C065-AC.vbf	Check in SDD (unconfirmed)	DDM - Driver Front Door Module	DATA
DPLA-14C067-AA.vbf	Multiple models (shared module)	DDM - Driver Front Door Module	SBL
DPLA-14C068-AB.vbf	Multiple models (shared module)	DDM - Driver Front Door Module	EXE
DPLA-14C090-DK.vbf	Multiple models (shared module)	PAM - Parking Assist Control Module	EXE
DPLA-14C090-DL.vbf	Multiple models (shared module)	PAM - Parking Assist Control Module	EXE

File name	Vehicle line (indicative)	Module (ECU)	Type
DPLA-14C093-AB.vbf	Multiple models (shared module)	PAM - Parking Assist Control Module	SBL
DPLA-14C104-AA.vbf	Multiple models (shared module)	TMC Traffic Message Channel Module	EXE
DPLA-14C104-AB.vbf	Multiple models (shared module)	TMC Traffic Message Channel Module	EXE
DPLA-14C104-AD.vbf	Multiple models (shared module)	TMC Traffic Message Channel Module	EXE
DPLA-14C104-AG.vbf	Multiple models (shared module)	TMC Traffic Message Channel Module	EXE
DPLA-14C104-CA.vbf	Multiple models (shared module)	TMC Traffic Message Channel Module	EXE
DPLA-14C104-CB.vbf	Multiple models (shared module)	TMC Traffic Message Channel Module	EXE
DPLA-14C104-KG.vbf	Multiple models (shared module)	TMC Traffic Message Channel Module	EXE
DPLA-14C104-LA.vbf	Multiple models (shared module)	TMC Traffic Message Channel Module	EXE
DPLA-14C104-LB.vbf	Multiple models (shared module)	TMC Traffic Message Channel Module	EXE
DPLA-14C105-AE.vbf	Range Rover Sport (L494)	TMC Traffic Message Channel Module	DATA
DPLA-14C105-BE.vbf	Range Rover Sport (L494)	TMC Traffic Message Channel Module	DATA
DPLA-14C108-AC.vbf	Multiple models (shared module)	PDM - Passenger Front Door Module	EXE
DPLA-14C109-AC.vbf	Multiple models (shared module)	PDM - Passenger Front Door Module	DATA
DPLA-14C111-AA.vbf	Multiple models (shared module)	PDM - Passenger Front Door Module	SBL
DPLA-14C112-AB.vbf	Multiple models (shared module)	PDM - Passenger Front Door Module	EXE
DPLA-14C168-AD.vbf	Multiple models (shared module)	PBM - Park Brake Control Module	EXE
DPLA-14C184-AK.vbf	Multiple models (shared module)	BCM - Body Control Module	EXE
DPLA-14C184-AL.vbf	Multiple models (shared module)	BCM - Body Control Module	EXE
DPLA-14C184-AM.vbf	Multiple models (shared module)	BCM - Body Control Module	EXE
DPLA-14C187-AB.vbf	Multiple models (shared module)	BCM - Body Control Module	SBL
DPLA-14C204-NAC.vbf	Multiple models (shared module)	PCM - Powertrain Control Module	EXE
DPLA-14C204-PAC.vbf	Multiple models (shared module)	PCM - Powertrain Control Module	EXE
DPLA-14C217-AB.vbf	Multiple models (shared module)	Not specified	EXE
DPLA-14C309-AA.vbf	Multiple models (shared module)	SASM - Steering Angle Sensor Module	EXE
DPLA-14C320-BB.vbf	Check in SDD (unconfirmed)	PDM - Passeng Front Door Module	SIGCFG
DPLA-14C321-BB.vbf	Check in SDD (unconfirmed)	DDM - Driver Front Door Module	SIGCFG
DPLA-14C341-AA.vbf	Multiple models (shared module)	Not specified	EXE
DPLA-14C342-AA.vbf	Multiple models (shared module)	Not specified	DATA
DPLA-14C342-BA.vbf	Multiple models (shared module)	Not specified	DATA
DPLA-14C342-CA.vbf	Multiple models (shared module)	Not specified	DATA
DPLA-14C366-AC.vbf	Multiple models (shared module)	ecu_address = 0x761;	EXE
DPLA-14C366-BB.vbf	Multiple models (shared module)	ecu_address = 0x761;	EXE
DPLA-14C366-BC.vbf	Multiple models (shared module)	ecu_address = 0x761;	EXE
DPLA-14C377-AG.vbf	Multiple models (shared module)	PAM - Parking Assist Control Module	SIGCFG
DPLA-14C386-AA.vbf	Multiple models (shared module)	Not specified	EXE
DPLA-14C387-AA.vbf	Multiple models (shared module)	SASM - Steering Angle Sensor Module	SIGCFG
DPLA-14C388-AB.vbf	Multiple models (shared module)	ecu_address = 0x795;	EXE
DPLA-14C408-AF.vbf	Multiple models (shared module)	BCM - Body Control Module	SIGCFG
DPLA-14C413-AB.vbf	Range Rover Sport (L494)	DSM - Driver Front Seat Module	SIGCFG
DPLA-14C413-AC.vbf	Range Rover Sport (L494)	DSM - Driver Front Seat Module	SIGCFG
DPLA-14C430-AC.vbf	Range Rover Sport (L494)	TMC Traffic Message Channel Module	DATA
DPLA-14C430-BA.vbf	Check in SDD (unconfirmed)	TMC Traffic Message Channel Module	DATA
DPLA-14C430-BB.vbf	Check in SDD (unconfirmed)	TMC Traffic Message Channel Module	DATA
DPLA-14C433-AA.vbf	Range Rover (L405)	RGTM - Rear Gate / Trunk Module	SIGCFG
DPLA-14C433-AC.vbf	Multiple models (shared module)	RGTM - Rear Gate / Trunk Module	SIGCFG
DPLA-14C534-AA.vbf	Multiple models (shared module)	FCIMB - Front Controls Interface Module 'B'	SIGCFG
DPLA-14C535-AB.vbf	Multiple models (shared module)	FCIMB - Front Controls Interface Module 'B'	EXE
DPLA-14C536-AA.vbf	Multiple models (shared module)	FCIMB - Front Controls Interface Module 'B'	CUSTOM
DPLA-14C547-AB.vbf	Range Rover Sport (L494)	PSM - Passenger Front Seat Module	SIGCFG
DPLA-14C547-AC.vbf	Range Rover Sport (L494)	PSM - Passenger Front Seat Module	SIGCFG
DPLA-14C548-AC.vbf	Range Rover Sport (L494)	PSM - Passenger Front Seat Module	EXE
DPLA-14C548-BC.vbf	Range Rover Sport (L494)	PSM - Passenger Front Seat Module	EXE
DPLA-14C548-CA.vbf	Range Rover Sport (L494)	PSM - Passenger Front Seat Module	EXE
DPLA-14C548-CB.vbf	Range Rover Sport (L494)	PSM - Passenger Front Seat Module	EXE
DPLA-14C549-AA.vbf	Range Rover Sport (L494)	PSM - Passenger Front Seat Module	DATA
DPLA-14C549-CA.vbf	Range Rover Sport (L494)	PSM - Passenger Front Seat Module	DATA
DPLA-14C549-DA.vbf	Range Rover Sport (L494)	PSM - Passenger Front Seat Module	DATA
DPLA-14C549-EA.vbf	Range Rover Sport (L494)	PSM - Passenger Front Seat Module	DATA
DPLA-14C549-FA.vbf	Range Rover Sport (L494)	PSM - Passenger Front Seat Module	DATA
DPLA-14C549-HA.vbf	Range Rover Sport (L494)	PSM - Passenger Front Seat Module	DATA
DPLA-14C549-JA.vbf	Range Rover Sport (L494)	PSM - Passenger Front Seat Module	DATA
DPLA-14C550-AA.vbf	Range Rover Sport (L494)	PSM - Passenger Front Seat Module	SBL
DPLA-14C550-BA.vbf	Range Rover Sport (L494)	PSM - Passenger Front Seat Module	SBL
DPLA-14C554-AF.vbf	Multiple models (shared module)	PCV, TEL - Telephone Control Module	EXE
DPLA-14C554-BE.vbf	Multiple models (shared module)	Not specified	EXE
DPLA-14C556-AB.vbf	Multiple models (shared module)	PCV, TEL - Telephone Control Module	SBL
DPLA-14C560-AB.vbf	Range Rover Sport (L494)	GSM - Gear Shift Module	SIGCFG
DPLA-14C560-CA.vbf	Range Rover (L405)	GSM - Gear Shift Module	SIGCFG
DPLA-14C561-AE.vbf	Range Rover Sport (L494)	GSM - Gear Shift Module	EXE
DPLA-14C561-CC.vbf	Range Rover (L405)	GSM - Gear Shift Module	EXE
DPLA-14C563-CA.vbf	Multiple models (shared module)	GSM - Gear Shift Module	SBL
DPLA-14C578-AA.vbf	Multiple models (shared module)	VIM - Vehicle Immobilizer Control Module	SIGCFG
DPLA-14C621-AF.vbf	Multiple models (shared module)	FCDIM - Front Control/Display Interface Module	EXE
DPLA-14D016-AB.vbf	Multiple models (shared module)	FCIM - Front Controls Interface Module	SIGCFG
DPLA-14D017-AB.vbf	Multiple models (shared module)	FCIM - Front Controls Interface Module	EXE

File name	Vehicle line (indicative)	Module (ECU)	Type
DPLA-14D017-AC.vbf	Multiple models (shared module)	FCIM - Front Controls Interface Module	EXE
DPLA-14D018-AC.vbf	Multiple models (shared module)	FCIM - Front Controls Interface Module	CUSTOM
DPLA-14D023-AB.vbf	Range Rover Sport (L494)	ATCM - All Terrain Control Module	SIGCFG
DPLA-14D024-AF.vbf	Range Rover Sport (L494)	ATCM - All Terrain Control Module	EXE
DPLA-14D024-AH.vbf	Range Rover Sport (L494)	ATCM - All Terrain Control Module	EXE
DPLA-14D026-AA.vbf	Multiple models (shared module)	ATCM - All Terrain Control Module	SBL
DPLA-14D048-AB.vbf	Range Rover Sport (L494)	CCM - Cruise Control Module	SIGCFG
DPLA-14D049-AD.vbf	Range Rover Sport (L494)	CCM - Cruise Control Module	EXE
DPLA-14D049-BD.vbf	Multiple models (shared module)	CCM - Cruise Control Module	EXE
DPLA-14D195-AA.vbf	Multiple models (shared module)	HCM2 - Headlamp Control Module #2	SIGCFG
DPLA-14D196-AA.vbf	Multiple models (shared module)	HCM2 - Headlamp Control Module #2	EXE
DPLA-14D197-AA.vbf	Multiple models (shared module)	HCM2 - Headlamp Control Module #2	DATA
DPLA-14D367-AC.vbf	Multiple models (shared module)	SODL - Side Obstacle Detection Control Module - Left	SIGCFG
DPLA-14D367-BC.vbf	Multiple models (shared module)	SODR - Side Obstacle Detection Control Module - Right	SIGCFG
DPLA-14D368-AD.vbf	Multiple models (shared module)	SODL - Side Obstacle Detection Control Module - Left	EXE
DPLA-14D368-AJ.vbf	Multiple models (shared module)	SODR - Side Obstacle Detection Control Module - Right	EXE
DPLA-14D368-BA.vbf	Multiple models (shared module)	SODL - Side Obstacle Detection Control Module - Left	EXE
DPLA-14D368-BB.vbf	Multiple models (shared module)	SODL - Side Obstacle Detection Control Module - Left	EXE
DPLA-14D368-BD.vbf	Multiple models (shared module)	SODL - Side Obstacle Detection Control Module - Left	EXE
DPLA-14D418-BF.vbf	Multiple models (shared module)	Not specified	EXE
DPLA-14D418-BG.vbf	Multiple models (shared module)	Not specified	EXE
DPLA-14D418-CF.vbf	Multiple models (shared module)	Not specified	EXE
DPLA-14D418-CG.vbf	Multiple models (shared module)	Not specified	EXE
DPLA-14D419-BF.vbf	Multiple models (shared module)	Not specified	EXE
DPLA-14D419-CF.vbf	Multiple models (shared module)	Not specified	EXE
DPLA-14D420-BD.vbf	Multiple models (shared module)	Not specified	DATA
DPLA-14D420-CD.vbf	Multiple models (shared module)	Not specified	DATA
DPLA-14D421-BD.vbf	Multiple models (shared module)	Not specified	SBL
DPLA-14D421-CD.vbf	Multiple models (shared module)	Not specified	SBL
DPLA-14D479-AC.vbf	Multiple models (shared module)	IPMB - Image Processing Module B	DATA
DPLA-14D519-AB.vbf	Multiple models (shared module)	HVAC - HVAC Control Module	EXE
DPLA-14D519-AE.vbf	Multiple models (shared module)	HVAC - HVAC Control Module	EXE
DPLA-14D519-AH.vbf	Multiple models (shared module)	HVAC - HVAC Control Module	EXE
DPLA-14D519-AJ.vbf	Multiple models (shared module)	HVAC - HVAC Control Module	EXE
DPLA-14D519-AK.vbf	Multiple models (shared module)	HVAC - HVAC Control Module	EXE
DPLA-14E093-JD.vbf	Multiple models (shared module)	CHCM - Chassis Control Module	EXE
DPLA-14E093-JF.vbf	Multiple models (shared module)	CHCM - Chassis Control Module	EXE
DPLA-14E093-JG.vbf	Multiple models (shared module)	CHCM - Chassis Control Module	EXE
DPLA-14E093-JH.vbf	Multiple models (shared module)	CHCM - Chassis Control Module	EXE
DPLA-14E093-JJ.vbf	Multiple models (shared module)	CHCM - Chassis Control Module	EXE
DPLA-14F016-AC.vbf	Range Rover Sport (L494)	IPMB - Image Processing Module B	SIGCFG
DPLA-14F017-AF.vbf	Multiple models (shared module)	IPMB - Image Processing Module B	EXE
DPLA-14F019-AB.vbf	Multiple models (shared module)	IPMB - Image Processing Module B	SBL
DPLA-14F216-AA.vbf	Multiple models (shared module)	RHVAC - Rear HVAC Control Module	SIGCFG
DPLA-14F217-AB.vbf	Multiple models (shared module)	RHVAC - Rear HVAC Control Module	EXE
DPLA-14F218-AA.vbf	Multiple models (shared module)	RHVAC - Rear HVAC Control Module	CUSTOM
DPLA-14F352-ED.vbf	Multiple models (shared module)	SPMA - Seatbelt Pretensioner Control Module A	EXE
DPLA-14F357-ED.vbf	Multiple models (shared module)	SPMA - Seatbelt Pretensioner Control Module A	DATA
DPLA-14F370-ED.vbf	Multiple models (shared module)	SPMB - Seatbelt Pretensioner Control Module B	DATA
DPLA-14F434-LG.vbf	Multiple models (shared module)	CHCMB - Chassis Control Module B	EXE
DPLA-14F434-LH.vbf	Multiple models (shared module)	CHCMB - Chassis Control Module B	EXE
DPLA-14F434-LJ.vbf	Multiple models (shared module)	CHCMB - Chassis Control Module B	EXE
DPLA-14F454-AC.vbf	Multiple models (shared module)	HCMB - Headlamp Control Module B	SIGCFG
DPLA-14F455-AC.vbf	Multiple models (shared module)	HCMB - Headlamp Control Module B	EXE
DPLA-14F455-BB.vbf	Multiple models (shared module)	HCM2 - Headlamp Control Module #2	EXE
DPLA-14F456-AC.vbf	Multiple models (shared module)	HCMB - Headlamp Control Module B	DATA
DPLA-14F456-BB.vbf	Multiple models (shared module)	HCMB - Headlamp Control Module B	DATA
DPLA-14F457-AB.vbf	Multiple models (shared module)	HCMB - Headlamp Control Module B	SBL
DPLA-14F530-AK.vbf	Multiple models (shared module)	GWM - Gateway Module A	EXE
DPLA-14F530-AL.vbf	Multiple models (shared module)	GWM - Gateway Module A	EXE
DPLA-14F530-AM.vbf	Multiple models (shared module)	GWM - Gateway Module A	EXE
DPLA-14F530-BC.vbf	Multiple models (shared module)	GWM - Gateway Module A	EXE
DPLA-14F531-AL.vbf	Multiple models (shared module)	GWM - Gateway Module A	DATA
DPLA-14F531-AM.vbf	Multiple models (shared module)	GWM - Gateway Module A	DATA
DPLA-14F531-BE.vbf	Multiple models (shared module)	GWM - Gateway Module A	DATA
DPLA-14F532-AB.vbf	Multiple models (shared module)	GWM - Gateway Module A	SBL
DPLA-14F670-AA.vbf	Range Rover (L405)	RGTMB - Rear Gate / Trunk Module	SIGCFG
DPLA-14F670-AB.vbf	Range Rover (L405)	RGTM - Rear Gate / Trunk Module	SIGCFG
DPLA-14G035-AB.vbf	Range Rover Sport (L494)	PRSM - Passenger Rear Seat Module	SIGCFG
DPLA-14G035-AC.vbf	Range Rover Sport (L494)	PRSM - Passenger Rear Seat Module	SIGCFG
DPLA-14G036-AC.vbf	Range Rover Sport (L494)	PRSM - Passenger Rear Seat Module	EXE
DPLA-14G036-BA.vbf	Range Rover Sport (L494)	PRSM - Passenger Rear Seat Module	EXE
DPLA-14G036-BB.vbf	Range Rover Sport (L494)	PRSM - Passenger Rear Seat Module	EXE
DPLA-14G037-BA.vbf	Range Rover Sport (L494)	DRSM - Driver Rear Seat Module	DATA
DPLA-14G037-CB.vbf	Range Rover Sport (L494)	Not specified	DATA
DPLA-14G037-DB.vbf	Range Rover Sport (L494)	Not specified	DATA

File name	Vehicle line (indicative)	Module (ECU)	Type
DPLA-14G037-EB.vbf	Range Rover Sport (L494)	Not specified	DATA
DPLA-14G037-FA.vbf	Range Rover Sport (L494)	PRSM - Passenger Rear Seat Module	DATA
DPLA-14G038-AA.vbf	Range Rover Sport (L494)	SCMD - Seat Control Module D	SBL
DPLA-14G045-AB.vbf	Range Rover Sport (L494)	DRSM - Driver Rear Seat Module	SIGCFG
DPLA-14G045-AC.vbf	Range Rover Sport (L494)	DRSM - Driver Rear Seat Module	SIGCFG
DPLA-14G046-AC.vbf	Range Rover Sport (L494)	DRSM - Driver Rear Seat Module	EXE
DPLA-14G046-BA.vbf	Range Rover Sport (L494)	DRSM - Driver Rear Seat Module	EXE
DPLA-14G046-BB.vbf	Range Rover Sport (L494)	DRSM - Driver Rear Seat Module	EXE
DPLA-14G047-BA.vbf	Range Rover Sport (L494)	PRSM - Passenger Rear Seat Module	DATA
DPLA-14G047-CB.vbf	Range Rover Sport (L494)	Not specified	DATA
DPLA-14G047-DB.vbf	Range Rover Sport (L494)	Not specified	DATA
DPLA-14G047-EB.vbf	Range Rover Sport (L494)	Not specified	DATA
DPLA-14G047-FA.vbf	Range Rover Sport (L494)	DRSM - Driver Rear Seat Module	DATA
DPLA-14G048-AA.vbf	Range Rover Sport (L494)	SCMC - Seat Control Module C	SBL
DPLA-18A836-AA.vbf	Multiple models (shared module)	FCIMC - Front Controls Interface Module 'C'	SIGCFG
DPLA-18A842-AA.vbf	Multiple models (shared module)	FCIMC - Front Controls Interface Module 'C'	CUSTOM
DPLA-18A911-AA.vbf	Multiple models (shared module)	FCIMC - Front Controls Interface Module 'C'	EXE
DPLA-70712-AAA.vbf	Multiple models (shared module)	TCU - Telematic Control Unit Module	EXE
DPLA-70712-AAB.vbf	Multiple models (shared module)	TCU - Telematic Control Unit Module	EXE
DPLA-70712-AAC.vbf	Multiple models (shared module)	TCU - Telematic Control Unit Module	EXE
DPLA-70712-AN.vbf	Multiple models (shared module)	TCU - Telematic Control Unit Module	EXE
DPLA-70712-AP.vbf	Multiple models (shared module)	TCU - Telematic Control Unit Module	EXE
DPLA-70712-AR.vbf	Multiple models (shared module)	TCU - Telematic Control Unit Module	EXE
DPLA-70712-AS.vbf	Multiple models (shared module)	TCU - Telematic Control Unit Module	EXE
DPLA-70712-AT.vbf	Multiple models (shared module)	TCU - Telematic Control Unit Module	EXE
DPLA-70712-AV.vbf	Multiple models (shared module)	TCU - Telematic Control Unit Module	EXE
DPLA-70712-AX.vbf	Multiple models (shared module)	TCU - Telematic Control Unit Module	EXE
DPLA-70712-AY.vbf	Multiple models (shared module)	TCU - Telematic Control Unit Module	EXE
DPLA-70712-AZ.vbf	Multiple models (shared module)	TCU - Telematic Control Unit Module	EXE
DPLA-70712-BE.vbf	Multiple models (shared module)	TCU - Telematic Control Unit Module	EXE
DPLA-70712-BF.vbf	Multiple models (shared module)	TCU - Telematic Control Unit Module	EXE
DPLA-70712-BG.vbf	Multiple models (shared module)	TCU - Telematic Control Unit Module	EXE
DPLA-70712-BH.vbf	Multiple models (shared module)	TCU - Telematic Control Unit Module	EXE
DPLA-70712-BJ.VBF	Multiple models (shared module)	TCU - Telematic Control Unit Module	EXE
DPLA-70712-CM.vbf	Multiple models (shared module)	TCU - Telematic Control Unit Module	EXE
DPLA-70712-CN.vbf	Multiple models (shared module)	TCU - Telematic Control Unit Module	EXE
DPLA-70712-CP.vbf	Multiple models (shared module)	TCU - Telematic Control Unit Module	EXE
DPLA-70712-CR.vbf	Multiple models (shared module)	TCU - Telematic Control Unit Module	EXE
DPLA-70712-CS.vbf	Multiple models (shared module)	TCU - Telematic Control Unit Module	EXE
DPLA-70712-CT.vbf	Multiple models (shared module)	TCU - Telematic Control Unit Module	EXE
DPLA-70712-CV.vbf	Multiple models (shared module)	TCU - Telematic Control Unit Module	EXE
DPLA-70712-CX.vbf	Multiple models (shared module)	TCU - Telematic Control Unit Module	EXE
DPLA-70712-CY.vbf	Multiple models (shared module)	TCU - Telematic Control Unit Module	EXE
DPLA-70712-CZ.vbf	Multiple models (shared module)	TCU - Telematic Control Unit Module	EXE
DPLA-70712-DE.vbf	Multiple models (shared module)	TCU - Telematic Control Unit Module	EXE
DPLA-70712-DF.vbf	Multiple models (shared module)	TCU - Telematic Control Unit Module	EXE
DPLA-70712-DG.vbf	Multiple models (shared module)	TCU - Telematic Control Unit Module	EXE
DPLA-70712-DH.vbf	Multiple models (shared module)	TCU - Telematic Control Unit Module	EXE
DPLA-70712-DJ.VBF	Multiple models (shared module)	TCU - Telematic Control Unit Module	EXE
DPLA-70713-AN.vbf	Multiple models (shared module)	TCU - Telematic Control Unit Module	DATA
DPLA-70713-BN.vbf	Multiple models (shared module)	TCU - Telematic Control Unit Module	DATA
DPLA-70713-BP.vbf	Multiple models (shared module)	TCU - Telematic Control Unit Module	DATA
DPLA-70713-CN.vbf	Multiple models (shared module)	TCU - Telematic Control Unit Module	DATA
DPLA-70713-CP.vbf	Multiple models (shared module)	TCU - Telematic Control Unit Module	DATA
DPLA-70713-LN.vbf	Multiple models (shared module)	TCU - Telematic Control Unit Module	DATA
DPLA-70713-MN.vbf	Multiple models (shared module)	TCU - Telematic Control Unit Module	DATA
DPLA-70713-MP.vbf	Multiple models (shared module)	TCU - Telematic Control Unit Module	DATA
DPLA-70713-NN.vbf	Multiple models (shared module)	TCU - Telematic Control Unit Module	DATA
DPLA-70713-NP.vbf	Multiple models (shared module)	TCU - Telematic Control Unit Module	DATA
DPLA-70714-AC.vbf	Multiple models (shared module)	TCU - Telematic Control Unit Module	SBL
DPLA-70714-AD.vbf	Multiple models (shared module)	TCU - Telematic Control Unit Module	SBL
DPLA-70714-AE.vbf	Multiple models (shared module)	TCU - Telematic Control Unit Module	SBL
DPLA-9J403-AD.vbf	Multiple models (shared module)	GPSM - Global Positioning System Module	SIGCFG
DPLA-9J404-AJ.vbf	Multiple models (shared module)	GPSM - Global Positioning System Module	EXE
DPLA-9J405-AG.vbf	Multiple models (shared module)	GPSM - Global Positioning System Module	DATA
DPLA-9J406-AB.vbf	Multiple models (shared module)	GPSM - Global Positioning System Module	SBL
DW83-14D402-CA.vbf	Jaguar XK (X150)	Not specified	EXE
DW83-14D403-CA.vbf	Jaguar XK (X150)	Not specified	EXE
DW83-14D404-CA.vbf	Jaguar XK (X150)	Not specified	DATA
DW83-14D405-CA.vbf	Jaguar XK (X150)	Not specified	SBL
DW93-12K532-PCE.vbf	Jaguar XJ (X351)	PCM - Powertrain Control Module	DATA
DW93-12K532-PTF.vbf	Jaguar XJ (X351)	PCM - Powertrain Control Module	DATA
DW93-14C028-AE.vbf	Jaguar XJ (X351)	RCM - Restraints Control Module	EXE
DW93-14C028-BD.vbf	Jaguar XJ (X351)	RCM - Restraints Control Module	EXE
DW93-14C036-BH.vbf	Jaguar XJ (X351)	ABS - Anit-Lock Brake System (ABS) Control Module	EXE
DW93-14C060-AJ.vbf	Jaguar XJ (X351)	FCDIM - Front Control/Display Interface Module	EXE

File name	Vehicle line (indicative)	Module (ECU)	Type
DW93-14C060-BJ.vbf	Jaguar XJ (X351)	FCDIM - Front Control/Display Interface Module	EXE
DW93-14C060-CA.vbf	Jaguar XJ (X351)	FCDIM - Front Control/Display Interface Module	EXE
DW93-14C060-DA.vbf	Jaguar XJ (X351)	FCDIM - Front Control/Display Interface Module	EXE
DW93-14C061-AJ.vbf	Jaguar XJ (X351)	FCDIM - Front Control/Display Interface Module	DATA
DW93-14C061-CA.vbf	Jaguar XJ (X351)	FCDIM - Front Control/Display Interface Module	DATA
DW93-14C063-AB.vbf	Jaguar XJ (X351)	FCDIM - Front Control/Display Interface Module	SBL
DW93-14C063-CA.vbf	Jaguar XJ (X351)	FCDIM - Front Control/Display Interface Module	SBL
DW93-14C098-CA.vbf	Jaguar XJ (X351)	RCM - Restraints Control Module	DATA
DW93-14C098-FF.vbf	Jaguar XJ (X351)	RCM - Restraints Control Module	DATA
DW93-14C098-GD.vbf	Jaguar XJ (X351)	RCM - Restraints Control Module	DATA
DW93-14C184-AE.vbf	Jaguar XJ (X351)	BCM - Body Control Module	EXE
DW93-14C185-AE.vbf	Jaguar XJ (X351)	BCM - Body Control Module	DATA
DW93-14C204-JAF.vbf	Jaguar XJ (X351)	PCM - Powertrain Control Module	EXE
DW93-14C204-JAG.vbf	Jaguar XJ (X351)	PCM - Powertrain Control Module	EXE
DW93-14C204-JCD.vbf	Jaguar XJ (X351)	PCM - Powertrain Control Module	EXE
DW93-14C204-JCE.vbf	Jaguar XJ (X351)	PCM - Powertrain Control Module	EXE
DW93-14C204-JTF.vbf	Jaguar XJ (X351)	PCM - Powertrain Control Module	EXE
DW93-14C204-JTG.vbf	Jaguar XJ (X351)	PCM - Powertrain Control Module	EXE
DW93-14C204-JTH.vbf	Jaguar XJ (X351)	PCM - Powertrain Control Module	EXE
DW93-14C204-RAJ.vbf	Jaguar XJ (X351)	PCM - Powertrain Control Module	EXE
DW93-14C204-RCJ.vbf	Jaguar XJ (X351)	PCM - Powertrain Control Module	EXE
DW93-14C204-REJ.vbf	Jaguar XJ (X351)	PCM - Powertrain Control Module	EXE
DW93-14C204-RGE.vbf	Jaguar XJ (X351)	PCM - Powertrain Control Module	EXE
DW93-14C204-RTK.vbf	Jaguar XJ (X351)	PCM - Powertrain Control Module	EXE
DW93-14C204-TAH.vbf	Jaguar XJ (X351)	PCM - Powertrain Control Module	EXE
DW93-14C204-TAJ.vbf	Jaguar XJ (X351)	PCM - Powertrain Control Module	EXE
DW93-14C204-TCG.vbf	Jaguar XJ (X351)	PCM - Powertrain Control Module	EXE
DW93-14C204-TCH.vbf	Jaguar XJ (X351)	PCM - Powertrain Control Module	EXE
DW93-14C204-TEG.vbf	Jaguar XJ (X351)	PCM - Powertrain Control Module	EXE
DW93-14C204-TEH.vbf	Jaguar XJ (X351)	PCM - Powertrain Control Module	EXE
DW93-14C204-TGE.vbf	Jaguar XJ (X351)	PCM - Powertrain Control Module	EXE
DW93-14C204-TGF.vbf	Jaguar XJ (X351)	PCM - Powertrain Control Module	EXE
DW93-14C204-TTH.vbf	Jaguar XJ (X351)	PCM - Powertrain Control Module	EXE
DW93-14C204-TTJ.vbf	Jaguar XJ (X351)	PCM - Powertrain Control Module	EXE
DW93-14C204-TTK.vbf	Jaguar XJ (X351)	PCM - Powertrain Control Module	EXE
DW93-14C204-YAG.vbf	Jaguar XJ (X351)	PCM - Powertrain Control Module	EXE
DW93-14C204-YCF.vbf	Jaguar XJ (X351)	PCM - Powertrain Control Module	EXE
DW93-14C204-YEE.vbf	Jaguar XJ (X351)	PCM - Powertrain Control Module	EXE
DW93-14C204-YGC.vbf	Jaguar XJ (X351)	PCM - Powertrain Control Module	EXE
DW93-14C204-YTF.vbf	Jaguar XJ (X351)	PCM - Powertrain Control Module	EXE
DW93-14C204-ZAH.vbf	Jaguar XJ (X351)	PCM - Powertrain Control Module	EXE
DW93-14C204-ZCH.vbf	Jaguar XJ (X351)	PCM - Powertrain Control Module	EXE
DW93-14C204-ZEF.vbf	Jaguar XJ (X351)	PCM - Powertrain Control Module	EXE
DW93-14C204-ZGE.vbf	Jaguar XJ (X351)	PCM - Powertrain Control Module	EXE
DW93-14C204-ZTH.vbf	Jaguar XJ (X351)	PCM - Powertrain Control Module	EXE
DW93-14C366-AG.vbf	Jaguar XJ (X351)	TCCM - Transfer Case Control Module	EXE
DW93-14C368-AA.vbf	Jaguar XJ (X351)	TCCM - Transfer Case Control Module	SBL
DW93-14C390-AB.vbf	Jaguar XJ (X351)	TCCM - Transfer Case Control Module	SIGCFG
DW93-14C408-AC.vbf	Jaguar XJ (X351)	BCM - Body Control Module	SIGCFG
DW93-14C413-AA.vbf	Range Rover Evoque (L538)	DSM - Driver Front Seat Module	SIGCFG
DW93-14C527-AB.vbf	Jaguar XJ (X351)	Not specified	DATA
DW93-14C527-BB.vbf	Jaguar XJ (X351)	Not specified	DATA
DW93-14C527-CC.vbf	Jaguar XJ (X351)	Not specified	DATA
DW93-14C527-DB.vbf	Jaguar XJ (X351)	Not specified	DATA
DW93-14C527-EB.vbf	Jaguar XJ (X351)	Not specified	DATA
DW93-14C527-EC.vbf	Jaguar XJ (X351)	Not specified	DATA
DW93-14C527-FC.vbf	Jaguar XJ (X351)	Not specified	DATA
DW93-14C534-AB.vbf	Jaguar XJ (X351)	FCIMB - Front Controls Interface Module 'B'	SIGCFG
DW93-14C535-AB.vbf	Jaguar XJ (X351)	FCIMB - Front Controls Interface Module 'B'	EXE
DW93-14C536-AA.vbf	Jaguar XJ (X351)	FCIMB - Front Controls Interface Module 'B'	CUSTOM
DW93-14C560-AB.vbf	Jaguar XJ (X351)	GSM - Gear Shift Module	SIGCFG
DW93-14C561-AA.vbf	Jaguar XJ (X351)	GSM - Gear Shift Module	EXE
DW93-14C561-AD.vbf	Jaguar XJ (X351)	GSM - Gear Shift Module	EXE
DW93-14C621-AH.vbf	Jaguar XJ (X351)	FCDIM - Front Control/Display Interface Module	EXE
DW93-14C621-CA.vbf	Jaguar XJ (X351)	FCDIM - Front Control/Display Interface Module	EXE
DW93-14D519-AB.vbf	Jaguar XJ (X351)	HVAC - HVAC Control Module	EXE
DW93-14D520-AD.vbf	Jaguar XJ (X351)	HVAC - HVAC Control Module	DATA
DW93-14D520-CA.vbf	Jaguar XJ (X351)	HVAC - HVAC Control Module	DATA
DW93-14E093-AF.vbf	Jaguar XJ (X351)	CHCM - Chassis Control Module	EXE
DW93-14E094-AAE.vbf	Jaguar XJ (X351)	CHCM - Chassis Control Module	EXE
DW93-14E094-ABE.vbf	Jaguar XJ (X351)	CHCM - Chassis Control Module	EXE
DW93-14E094-ACF.vbf	Jaguar XJ (X351)	CHCM - Chassis Control Module	EXE
DW93-14E094-ADF.vbf	Jaguar XJ (X351)	CHCM - Chassis Control Module	EXE
DW93-14E094-AEE.vbf	Jaguar XJ (X351)	CHCM - Chassis Control Module	EXE
DW93-14E094-AFE.vbf	Jaguar XJ (X351)	CHCM - Chassis Control Module	EXE
DW93-14E094-AGE.vbf	Jaguar XJ (X351)	CHCM - Chassis Control Module	EXE

File name	Vehicle line (indicative)	Module (ECU)	Type
DW93-14E094-AHE.vbf	Jaguar XJ (X351)	CHCM - Chassis Control Module	EXE
DW93-14E094-AJE.vbf	Jaguar XJ (X351)	CHCM - Chassis Control Module	EXE
DW93-14E094-AKE.vbf	Jaguar XJ (X351)	CHCM - Chassis Control Module	EXE
DW93-14E094-ALE.vbf	Jaguar XJ (X351)	CHCM - Chassis Control Module	EXE
DW93-14E094-AME.vbf	Jaguar XJ (X351)	CHCM - Chassis Control Module	EXE
DW93-14E094-ANB.vbf	Jaguar XJ (X351)	CHCM - Chassis Control Module	EXE
DW93-14E094-APB.vbf	Jaguar XJ (X351)	CHCM - Chassis Control Module	EXE
DW93-14F530-AK.vbf	Jaguar XJ (X351)	GWM - Gateway Module A	EXE
DW93-14F531-AJ.vbf	Jaguar XJ (X351)	GWM - Gateway Module A	DATA
DW93-7J104-AAE.vbf	Jaguar XJ (X351)	TCM - Transmission Control Module	EXE
DW93-7J104-ABF.vbf	Jaguar XJ (X351)	TCM - Transmission Control Module	EXE
DW93-7J104-ACD.vbf	Jaguar XJ (X351)	TCM - Transmission Control Module	EXE
DW93-7J104-ADH.vbf	Jaguar XJ (X351)	TCM - Transmission Control Module	EXE
DW93-7J104-AEF.vbf	Jaguar XJ (X351)	TCM - Transmission Control Module	EXE
DW93-7J104-AJF.vbf	Jaguar XJ (X351)	TCM - Transmission Control Module	EXE
DW93-7J104-APD.vbf	Jaguar XJ (X351)	TCM - Transmission Control Module	EXE
DW9M-14E093-JA.vbf	Not specified	CHCM - Chassis Control Module	EXE
DW9M-14E094-JCA.vbf	Not specified	CHCM - Chassis Control Module	EXE
DX23-12K532-PCE.vbf	Jaguar XF (X250)	PCM - Powertrain Control Module	DATA
DX23-12K532-PRE.vbf	Jaguar XF (X250)	PCM - Powertrain Control Module	DATA
DX23-12K532-PTE.vbf	Jaguar XF (X250)	PCM - Powertrain Control Module	DATA
DX23-12K532-VCB.vbf	Jaguar XF (X250)	PCM - Powertrain Control Module	DATA
DX23-12K532-VSC.vbf	Jaguar XF (X250)	PCM - Powertrain Control Module	DATA
DX23-12K532-VTC.vbf	Jaguar XF (X250)	PCM - Powertrain Control Module	DATA
DX23-12K532-VYA.vbf	Jaguar XF (X250)	PCM - Powertrain Control Module	DATA
DX23-14C036-BG.vbf	Jaguar XF (X250)	ABS - Anit-Lock Brake System (ABS) Control Module	EXE
DX23-14C060-AG.vbf	Jaguar XF (X250)	FCDIM - Front Control/Display Interface Module	EXE
DX23-14C060-AH.vbf	Jaguar XF (X250)	FCDIM - Front Control/Display Interface Module	EXE
DX23-14C060-CA.vbf	Jaguar XF (X250)	FCDIM - Front Control/Display Interface Module	EXE
DX23-14C061-AG.vbf	Jaguar XF (X250)	FCDIM - Front Control/Display Interface Module	DATA
DX23-14C061-AH.vbf	Jaguar XF (X250)	FCDIM - Front Control/Display Interface Module	DATA
DX23-14C061-CA.vbf	Jaguar XF (X250)	FCDIM - Front Control/Display Interface Module	DATA
DX23-14C063-AB.vbf	Jaguar XF (X250)	FCDIM - Front Control/Display Interface Module	SBL
DX23-14C063-CA.vbf	Jaguar XF (X250)	FCDIM - Front Control/Display Interface Module	SBL
DX23-14C065-BA.vbf	Jaguar XF (X250)	DDM - Driver Front Door Module	DATA
DX23-14C105-AD.vbf	Jaguar XF (X250)	TMC Traffic Message Channel Module	DATA
DX23-14C105-AE.vbf	Jaguar XF (X250)	TMC Traffic Message Channel Module	DATA
DX23-14C109-BA.vbf	Jaguar XF (X250)	PDM - Passenger Front Door Module	DATA
DX23-14C121-AB.vbf	Jaguar XF (X250)	RGTM - Rear Gate / Trunk Module	EXE
DX23-14C122-AC.vbf	Jaguar XF (X250)	RGTM - Rear Gate / Trunk Module	DATA
DX23-14C124-AA.vbf	Jaguar XF (X250)	RGTM - Rear Gate / Trunk Module	SBL
DX23-14C184-AF.vbf	Jaguar XF (X250)	BCM - Body Control Module	EXE
DX23-14C184-AG.vbf	Jaguar XF (X250)	BCM - Body Control Module	EXE
DX23-14C187-AB.vbf	Jaguar XF (X250)	BCM - Body Control Module	SBL
DX23-14C187-BB.vbf	Jaguar XF (X250)	BCM - Body Control Module	SBL
DX23-14C204-EAE.vbf	Jaguar XF (X250)	PCM - Powertrain Control Module	EXE
DX23-14C204-ECC.vbf	Jaguar XF (X250)	PCM - Powertrain Control Module	EXE
DX23-14C204-EED.vbf	Jaguar XF (X250)	PCM - Powertrain Control Module	EXE
DX23-14C204-ETE.vbf	Jaguar XF (X250)	PCM - Powertrain Control Module	EXE
DX23-14C204-JAF.vbf	Jaguar XF (X250)	PCM - Powertrain Control Module	EXE
DX23-14C204-JAG.vbf	Jaguar XF (X250)	PCM - Powertrain Control Module	EXE
DX23-14C204-JCD.vbf	Jaguar XF (X250)	PCM - Powertrain Control Module	EXE
DX23-14C204-JCE.vbf	Jaguar XF (X250)	PCM - Powertrain Control Module	EXE
DX23-14C204-JTG.vbf	Jaguar XF (X250)	PCM - Powertrain Control Module	EXE
DX23-14C204-JTH.vbf	Jaguar XF (X250)	PCM - Powertrain Control Module	EXE
DX23-14C204-RAG.vbf	Jaguar XF (X250)	PCM - Powertrain Control Module	EXE
DX23-14C204-RCF.vbf	Jaguar XF (X250)	PCM - Powertrain Control Module	EXE
DX23-14C204-REG.vbf	Jaguar XF (X250)	PCM - Powertrain Control Module	EXE
DX23-14C204-RGE.vbf	Jaguar XF (X250)	PCM - Powertrain Control Module	EXE
DX23-14C204-RTG.vbf	Jaguar XF (X250)	PCM - Powertrain Control Module	EXE
DX23-14C204-TAG.vbf	Jaguar XF (X250)	PCM - Powertrain Control Module	EXE
DX23-14C204-TAH.vbf	Jaguar XF (X250)	PCM - Powertrain Control Module	EXE
DX23-14C204-TCE.vbf	Jaguar XF (X250)	PCM - Powertrain Control Module	EXE
DX23-14C204-TCF.vbf	Jaguar XF (X250)	PCM - Powertrain Control Module	EXE
DX23-14C204-TEE.vbf	Jaguar XF (X250)	PCM - Powertrain Control Module	EXE
DX23-14C204-TEF.vbf	Jaguar XF (X250)	PCM - Powertrain Control Module	EXE
DX23-14C204-TGE.vbf	Jaguar XF (X250)	PCM - Powertrain Control Module	EXE
DX23-14C204-TGF.vbf	Jaguar XF (X250)	PCM - Powertrain Control Module	EXE
DX23-14C204-TTG.vbf	Jaguar XF (X250)	PCM - Powertrain Control Module	EXE
DX23-14C204-TTH.vbf	Jaguar XF (X250)	PCM - Powertrain Control Module	EXE
DX23-14C204-VA.vbf	Jaguar XF (X250)	PCM - Powertrain Control Module	EXE
DX23-14C204-ZAF.vbf	Jaguar XF (X250)	PCM - Powertrain Control Module	EXE
DX23-14C204-ZCF.vbf	Jaguar XF (X250)	PCM - Powertrain Control Module	EXE
DX23-14C204-ZEG.vbf	Jaguar XF (X250)	PCM - Powertrain Control Module	EXE
DX23-14C204-ZGE.vbf	Jaguar XF (X250)	PCM - Powertrain Control Module	EXE
DX23-14C204-ZTF.vbf	Jaguar XF (X250)	PCM - Powertrain Control Module	EXE

File name	Vehicle line (indicative)	Module (ECU)	Type
DX23-14C320-AA.vbf	Jaguar XF (X250)	PDM - Passenger Front Door Module	SIGCFG
DX23-14C321-AA.vbf	Jaguar XF (X250)	DDM - Driver Front Door Module	SIGCFG
DX23-14C395-AA.vbf	Jaguar XF (X250)	FCDIM - Front Control/Display Interface Module	EXE
DX23-14C395-AB.vbf	Jaguar XF (X250)	FCDIM - Front Control/Display Interface Module	EXE
DX23-14C408-AB.vbf	Jaguar XF (X250)	BCM - Body Control Module	SIGCFG
DX23-14C430-AB.vbf	Jaguar XF (X250)	TMC Traffic Message Channel Module	DATA
DX23-14C430-AD.vbf	Jaguar XF (X250)	TMC Traffic Message Channel Module	DATA
DX23-14C433-AA.vbf	Jaguar XF (X250)	RGTM - Rear Gate / Trunk Module	SIGCFG
DX23-14C434-AA.vbf	Jaguar XF (X250)	TPM - Tire Pressure Monitor Module	SIGCFG
DX23-14C526-BA.vbf	Jaguar XF (X250)	Not specified	EXE
DX23-14C527-AC.vbf	Jaguar XF (X250)	Not specified	DATA
DX23-14C527-AD.vbf	Jaguar XF (X250)	Not specified	DATA
DX23-14C527-BC.vbf	Jaguar XF (X250)	Not specified	DATA
DX23-14C527-CB.vbf	Jaguar XF (X250)	Not specified	DATA
DX23-14C527-CC.vbf	Jaguar XF (X250)	Not specified	DATA
DX23-14C527-DB.vbf	Jaguar XF (X250)	Not specified	DATA
DX23-14C527-DC.vbf	Jaguar XF (X250)	Not specified	DATA
DX23-14C527-EC.vbf	Jaguar XF (X250)	Not specified	DATA
DX23-14C527-FB.vbf	Jaguar XF (X250)	Not specified	DATA
DX23-14C527-FC.vbf	Jaguar XF (X250)	Not specified	DATA
DX23-14C527-GB.vbf	Jaguar XF (X250)	Not specified	DATA
DX23-14C527-HB.vbf	Jaguar XF (X250)	Not specified	DATA
DX23-14C527-JA.vbf	Jaguar XF (X250)	Not specified	DATA
DX23-14C527-KA.vbf	Jaguar XF (X250)	Not specified	DATA
DX23-14C542-AD.vbf	Jaguar XF (X250)	ecu_address = 0x786;	EXE
DX23-14C621-AG.vbf	Jaguar XF (X250)	FCDIM - Front Control/Display Interface Module	EXE
DX23-14C621-CA.vbf	Jaguar XF (X250)	FCDIM - Front Control/Display Interface Module	EXE
DX23-14D049-AC.vbf	Check in SDD (unconfirmed)	ecu_address = 0x764;	EXE
DX23-14D049-BC.vbf	Jaguar XF (X250)	CCM - Cruise Control Module	EXE
DX23-14D519-BA.vbf	Jaguar XF (X250)	HVAC - HVAC Control Module	EXE
DX23-14D646-AB.vbf	Jaguar XF (X250)	BCMB - Body Control Module Back	SIGCFG
DX23-14D647-AG.vbf	Jaguar XF (X250)	BCMB - Body Control Module Back	EXE
DX23-14D647-AH.vbf	Jaguar XF (X250)	BCMB - Body Control Module Back	EXE
DX23-14D649-AB.vbf	Jaguar XF (X250)	BCMB - Body Control Module Back	SBL
DX23-14D649-BB.vbf	Jaguar XF (X250)	BCMB - Body Control Module Back	SBL
DX23-14E094-AAE.vbf	Jaguar XF (X250)	CHCM - Chassis Control Module	EXE
DX23-14E094-ABE.vbf	Jaguar XF (X250)	CHCM - Chassis Control Module	EXE
DX23-14E094-ACC.vbf	Jaguar XF (X250)	CHCM - Chassis Control Module	EXE
DX23-14E094-ADC.vbf	Jaguar XF (X250)	CHCM - Chassis Control Module	EXE
DX23-14F530-AH.vbf	Jaguar XF (X250)	GWM - Gateway Module A	EXE
DX23-14F531-AG.vbf	Jaguar XF (X250)	GWM - Gateway Module A	DATA
DX23-7J104-ABE.vbf	Jaguar XF (X250)	TCM - Transmission Control Module	EXE
DX23-7J104-ACD.vbf	Jaguar XF (X250)	TCM - Transmission Control Module	EXE
DX23-7J104-ADH.vbf	Jaguar XF (X250)	TCM - Transmission Control Module	EXE
DX23-7J104-AEE.vbf	Jaguar XF (X250)	TCM - Transmission Control Module	EXE
DX23-7J104-AGD.vbf	Jaguar XF (X250)	TCM - Transmission Control Module	EXE
DX23-7J104-AJE.vbf	Jaguar XF (X250)	TCM - Transmission Control Module	EXE
DX23-7J104-AKG.vbf	Jaguar XF (X250)	TCM - Transmission Control Module	EXE
DX23-7J104-ALD.vbf	Jaguar XF (X250)	TCM - Transmission Control Module	EXE
DX23-7J104-AMD.vbf	Jaguar XF (X250)	TCM - Transmission Control Module	EXE
DX23-7J104-FB.vbf	Jaguar XF (X250)	TCM - Transmission Control Module	EXE
DX23-7J104-GA.vbf	Jaguar XF (X250)	TCM - Transmission Control Module	EXE
DX23-7J104-KB.vbf	Jaguar XF (X250)	TCM - Transmission Control Module	EXE
DX23-7J104-LB.vbf	Jaguar XF (X250)	TCM - Transmission Control Module	EXE
DX23-7J104-PB.vbf	Jaguar XF (X250)	TCM - Transmission Control Module	EXE
EH22-12K532-PAD.vbf	Discovery 3/4 (L319)	PCM - Powertrain Control Module	DATA
EH22-12K532-PBD.vbf	Discovery 3/4 (L319)	PCM - Powertrain Control Module	DATA
EH22-12K532-PBE.vbf	Discovery 3/4 (L319)	PCM - Powertrain Control Module	DATA
EH22-12K532-PCD.vbf	Discovery 3/4 (L319)	PCM - Powertrain Control Module	DATA
EH22-12K532-PCE.vbf	Discovery 3/4 (L319)	PCM - Powertrain Control Module	DATA
EH22-12K532-PCF.vbf	Discovery 3/4 (L319)	PCM - Powertrain Control Module	DATA
EH22-12K532-PKD.vbf	Discovery 3/4 (L319)	PCM - Powertrain Control Module	DATA
EH22-12K532-PMC.vbf	Discovery 3/4 (L319)	PCM - Powertrain Control Module	DATA
EH22-12K532-PMD.vbf	Discovery 3/4 (L319)	PCM - Powertrain Control Module	DATA
EH22-12K532-PPD.vbf	Discovery 3/4 (L319)	PCM - Powertrain Control Module	DATA
EH22-12K532-PRC.vbf	Discovery 3/4 (L319)	PCM - Powertrain Control Module	DATA
EH22-12K532-PRD.vbf	Discovery 3/4 (L319)	PCM - Powertrain Control Module	DATA
EH22-12K532-PTD.vbf	Discovery 3/4 (L319)	PCM - Powertrain Control Module	DATA
EH22-12K532-PUD.vbf	Discovery 3/4 (L319)	PCM - Powertrain Control Module	DATA
EH22-14C026-AD.vbf	Discovery 3/4 (L319)	IPC - Instrument Panel Cluster (IPC) Control Module	EXE
EH22-14C026-BE.vbf	Discovery 3/4 (L319)	IPC - Instrument Panel Cluster (IPC) Control Module	EXE
EH22-14C036-AD.vbf	Discovery 3/4 (L319)	ABS - Anit-Lock Brake System (ABS) Control Module	EXE
EH22-14C060-CF.vbf	Discovery 3/4 (L319)	FCDIM - Front Control/Display Interface Module	EXE
EH22-14C060-CG.vbf	Discovery 3/4 (L319)	FCDIM - Front Control/Display Interface Module	EXE
EH22-14C060-CH.vbf	Discovery 3/4 (L319)	FCDIM - Front Control/Display Interface Module	EXE
EH22-14C061-CF.vbf	Discovery 3/4 (L319)	FCDIM - Front Control/Display Interface Module	DATA

File name	Vehicle line (indicative)	Module (ECU)	Type
EH22-14C061-CG.vbf	Discovery 3/4 (L319)	FCDIM - Front Control/Display Interface Module	DATA
EH22-14C061-CH.vbf	Discovery 3/4 (L319)	FCDIM - Front Control/Display Interface Module	DATA
EH22-14C063-CA.vbf	Discovery 3/4 (L319)	FCDIM - Front Control/Display Interface Module	SBL
EH22-14C065-AA.vbf	Discovery 3/4 (L319)	DDM - Driver Front Door Module	DATA
EH22-14C088-AC.vbf	Discovery 3/4 (L319)	IPC - Instrument Panel Cluster (IPC) Control Module	DATA
EH22-14C088-BD.vbf	Discovery 3/4 (L319)	IPC - Instrument Panel Cluster (IPC) Control Module	DATA
EH22-14C090-BC.vbf	Discovery 3/4 (L319)	PAM - Parking Assist Control Module	EXE
EH22-14C091-AC.vbf	Discovery 3/4 (L319)	PAM - Parking Assist Control Module	DATA
EH22-14C093-AA.vbf	Discovery 3/4 (L319)	PAM - Parking Assist Control Module	SBL
EH22-14C098-AA.vbf	Discovery 3/4 (L319)	RCM - Restraints Control Module	DATA
EH22-14C098-BA.vbf	Discovery 3/4 (L319)	RCM - Restraints Control Module	DATA
EH22-14C109-AA.vbf	Discovery 3/4 (L319)	PDM - Passenger Front Door Module	DATA
EH22-14C204-PB.vbf	Discovery 3/4 (L319)	PCM - Powertrain Control Module	EXE
EH22-14C204-TAE.vbf	Discovery 3/4 (L319)	PCM - Powertrain Control Module	EXE
EH22-14C204-TAF.vbf	Discovery 3/4 (L319)	PCM - Powertrain Control Module	EXE
EH22-14C204-TAG.vbf	Discovery 3/4 (L319)	PCM - Powertrain Control Module	EXE
EH22-14C204-TCF.vbf	Discovery 3/4 (L319)	PCM - Powertrain Control Module	EXE
EH22-14C204-TCG.vbf	Discovery 3/4 (L319)	PCM - Powertrain Control Module	EXE
EH22-14C204-TCH.vbf	Discovery 3/4 (L319)	PCM - Powertrain Control Module	EXE
EH22-14C204-TEE.vbf	Discovery 3/4 (L319)	PCM - Powertrain Control Module	EXE
EH22-14C204-TEF.vbf	Discovery 3/4 (L319)	PCM - Powertrain Control Module	EXE
EH22-14C204-TTE.vbf	Discovery 3/4 (L319)	PCM - Powertrain Control Module	EXE
EH22-14C204-TTF.vbf	Discovery 3/4 (L319)	PCM - Powertrain Control Module	EXE
EH22-14C204-TTG.vbf	Discovery 3/4 (L319)	PCM - Powertrain Control Module	EXE
EH22-14C204-TTH.vbf	Discovery 3/4 (L319)	PCM - Powertrain Control Module	EXE
EH22-14C273-PA.vbf	Discovery 3/4 (L319)	PCM - Powertrain Control Module	SBL
EH22-14C355-AE.vbf	Discovery 3/4 (L319)	Not specified	EXE
EH22-14C355-BE.vbf	Discovery 3/4 (L319)	Not specified	EXE
EH22-14C366-AA.vbf	Discovery 3/4 (L319)	ecu_address = 0x761;	EXE
EH22-14C377-AA.vbf	Discovery 3/4 (L319)	PAM - Parking Assist Control Module	SIGCFG
EH22-14C527-AD.vbf	Discovery 3/4 (L319)	Not specified	DATA
EH22-14C527-BB.vbf	Discovery 3/4 (L319)	Not specified	DATA
EH22-14C527-DA.vbf	Discovery 3/4 (L319)	Not specified	DATA
EH22-14C534-AB.vbf	Discovery 3/4 (L319)	FCIMB - Front Controls Interface Module 'B'	SIGCFG
EH22-14C535-AB.vbf	Discovery 3/4 (L319)	FCIMB - Front Controls Interface Module 'B'	EXE
EH22-14C561-AA.vbf	Discovery 3/4 (L319)	GSM - Gear Shift Module	EXE
EH22-14C561-AB.vbf	Discovery 3/4 (L319)	GSM - Gear Shift Module	EXE
EH22-14C561-AC.vbf	Discovery 3/4 (L319)	GSM - Gear Shift Module	EXE
EH22-14C621-CF.vbf	Discovery 3/4 (L319)	FCDIM - Front Control/Display Interface Module	EXE
EH22-14D024-AB.vbf	Discovery 3/4 (L319)	ATCM - All Terrain Control Module	EXE
EH22-14D394-BB.vbf	Discovery 3/4 (L319)	ecu_address = 0x7D3;	EXE
EH22-14D394-CA.vbf	Discovery 3/4 (L319)	ecu_address = 0x7D3;	EXE
EH22-14D479-AA.vbf	Discovery 3/4 (L319)	IPMB - Image Processing Module B	DATA
EH22-14D480-AD.vbf	Discovery 3/4 (L319)	IPMB - Image Processing Module B	EXE
EH22-14D485-AB.vbf	Discovery 3/4 (L319)	IPMB - Image Processing Module B	DATA
EH22-14D519-AE.vbf	Discovery 3/4 (L319)	HVAC - HVAC Control Module	EXE
EH22-14D564-AC.vbf	Discovery 3/4 (L319)	SODL - Side Obstacle Detection Control Module - Left	DATA
EH22-14D564-BC.vbf	Discovery 3/4 (L319)	SODR - Side Obstacle Detection Control Module - Right	DATA
EH22-14F016-AB.vbf	Range Rover Sport (L494)	IPMB - Image Processing Module B	SIGCFG
EH22-14F017-AC.vbf	Discovery 3/4 (L319)	IPMB - Image Processing Module B	EXE
EH22-14F019-AA.vbf	Discovery 3/4 (L319)	IPMB - Image Processing Module B	SBL
EH22-14F022-AC.vbf	Check in SDD (unconfirmed)	IPMB - Image Processing Module B	DATA
EH22-14F530-AG.vbf	Discovery 3/4 (L319)	GWM - Gateway Module A	EXE
EH22-14F531-AG.vbf	Discovery 3/4 (L319)	GWM - Gateway Module A	DATA
EH22-14F532-AA.vbf	Discovery 3/4 (L319)	GWM - Gateway Module A	SBL
EH22-7J104-ACE.vbf	Discovery 3/4 (L319)	TCM - Transmission Control Module	EXE
EH22-7J104-ACF.vbf	Discovery 3/4 (L319)	TCM - Transmission Control Module	EXE
EH22-7J104-ADF.vbf	Discovery 3/4 (L319)	TCM - Transmission Control Module	EXE
EH22-7J104-AGE.vbf	Discovery 3/4 (L319)	TCM - Transmission Control Module	EXE
EH22-7J104-AGF.vbf	Discovery 3/4 (L319)	TCM - Transmission Control Module	EXE
EH22-7J104-AKB.vbf	Discovery 3/4 (L319)	TCM - Transmission Control Module	EXE
EH22-7J104-AKC.vbf	Discovery 3/4 (L319)	TCM - Transmission Control Module	EXE
EH22-7J104-ALE.vbf	Discovery 3/4 (L319)	TCM - Transmission Control Module	EXE
EH22-7J104-ALF.vbf	Discovery 3/4 (L319)	TCM - Transmission Control Module	EXE
EH22-7J104-AUC.vbf	Discovery 3/4 (L319)	TCM - Transmission Control Module	EXE
EH22-7J104-AUD.vbf	Discovery 3/4 (L319)	TCM - Transmission Control Module	EXE
EH22-7J104-AVC.vbf	Discovery 3/4 (L319)	TCM - Transmission Control Module	EXE
EH22-7J104-AVD.vbf	Discovery 3/4 (L319)	TCM - Transmission Control Module	EXE
EH22-9J403-AB.vbf	Discovery 3/4 (L319)	GPSM - Global Positioning System Module	SIGCFG
EH22-9J404-AB.vbf	Discovery 3/4 (L319)	GPSM - Global Positioning System Module	EXE
EH22-9J405-AB.vbf	Discovery 3/4 (L319)	GPSM - Global Positioning System Module	DATA
EH22-9J406-AA.vbf	Discovery 3/4 (L319)	GPSM - Global Positioning System Module	SBL
EH2M-14D394-CA.vbf	Not specified	ecu_address = 0x7D3;	EXE
EH52-14C056-AB.vbf	Freelander 2 (L359)	NCM - Navigation Control Module	EXE
EH52-14C060-AE.vbf	Freelander 2 (L359)	FCDIM - Front Control/Display Interface Module	EXE
EH52-14C060-AF.vbf	Freelander 2 (L359)	FCDIM - Front Control/Display Interface Module	EXE

File name	Vehicle line (indicative)	Module (ECU)	Type
EH52-14C060-AG.vbf	Freelander 2 (L359)	FCDIM - Front Control/Display Interface Module	EXE
EH52-14C061-AE.vbf	Freelander 2 (L359)	FCDIM - Front Control/Display Interface Module	DATA
EH52-14C061-AF.vbf	Freelander 2 (L359)	FCDIM - Front Control/Display Interface Module	DATA
EH52-14C061-AG.vbf	Freelander 2 (L359)	FCDIM - Front Control/Display Interface Module	DATA
EH52-14C063-AA.vbf	Freelander 2 (L359)	FCDIM - Front Control/Display Interface Module	SBL
EH52-14C395-AB.vbf	Freelander 2 (L359)	FCDIM - Front Control/Display Interface Module	EXE
EH52-14C553-AD.vbf	Freelander 2 (L359)	PCV, TEL - Telephone Control Module	SIGCFG
EH52-14C621-AF.vbf	Freelander 2 (L359)	FCDIM - Front Control/Display Interface Module	EXE
EJ32-12K532-VBF.vbf	Range Rover Evoque (L538)	PCM - Powertrain Control Module	DATA
EJ32-12K532-VBG.vbf	Range Rover Evoque (L538)	PCM - Powertrain Control Module	DATA
EJ32-12K532-VBH.vbf	Range Rover Evoque (L538)	PCM - Powertrain Control Module	DATA
EJ32-12K532-VCF.vbf	Range Rover Evoque (L538)	PCM - Powertrain Control Module	DATA
EJ32-12K532-VCG.vbf	Range Rover Evoque (L538)	PCM - Powertrain Control Module	DATA
EJ32-12K532-VFD.vbf	Range Rover Evoque (L538)	PCM - Powertrain Control Module	DATA
EJ32-12K532-VHD.vbf	Range Rover Evoque (L538)	PCM - Powertrain Control Module	DATA
EJ32-12K532-VJD.vbf	Range Rover Evoque (L538)	PCM - Powertrain Control Module	DATA
EJ32-12K532-VKE.vbf	Range Rover Evoque (L538)	PCM - Powertrain Control Module	DATA
EJ32-12K532-VMD.vbf	Range Rover Evoque (L538)	PCM - Powertrain Control Module	DATA
EJ32-12K532-VND.vbf	Range Rover Evoque (L538)	PCM - Powertrain Control Module	DATA
EJ32-12K532-VPF.vbf	Range Rover Evoque (L538)	PCM - Powertrain Control Module	DATA
EJ32-12K532-VPG.vbf	Range Rover Evoque (L538)	PCM - Powertrain Control Module	DATA
EJ32-12K532-VRF.vbf	Range Rover Evoque (L538)	PCM - Powertrain Control Module	DATA
EJ32-12K532-VRG.vbf	Range Rover Evoque (L538)	PCM - Powertrain Control Module	DATA
EJ32-12K532-VSE.vbf	Range Rover Evoque (L538)	PCM - Powertrain Control Module	DATA
EJ32-12K532-VSF.vbf	Range Rover Evoque (L538)	PCM - Powertrain Control Module	DATA
EJ32-12K532-VTE.vbf	Range Rover Evoque (L538)	PCM - Powertrain Control Module	DATA
EJ32-12K532-VTF.vbf	Range Rover Evoque (L538)	PCM - Powertrain Control Module	DATA
EJ32-12K532-VYA.vbf	Range Rover Evoque (L538)	PCM - Powertrain Control Module	DATA
EJ32-14C030-AB.vbf	Range Rover Evoque (L538)	DSM - Driver Front Seat Module	EXE
EJ32-14C034-BB.vbf	Range Rover Sport (L494)	DSM - Driver Front Seat Module	DATA
EJ32-14C034-CB.vbf	Range Rover Sport (L494)	DSM - Driver Front Seat Module	DATA
EJ32-14C034-DB.vbf	Range Rover Sport (L494)	DSM - Driver Front Seat Module	DATA
EJ32-14C034-EB.vbf	Range Rover Sport (L494)	DSM - Driver Front Seat Module	DATA
EJ32-14C036-AK.vbf	Range Rover Evoque (L538)	ABS - Anit-Lock Brake System (ABS) Control Module	EXE
EJ32-14C036-AL.vbf	Range Rover Evoque (L538)	ABS - Anit-Lock Brake System (ABS) Control Module	EXE
EJ32-14C036-AM.vbf	Range Rover Evoque (L538)	ABS - Anit-Lock Brake System (ABS) Control Module	EXE
EJ32-14C036-AN.vbf	Range Rover Evoque (L538)	ABS - Anit-Lock Brake System (ABS) Control Module	EXE
EJ32-14C036-AP.vbf	Range Rover Evoque (L538)	ABS - Anit-Lock Brake System (ABS) Control Module	EXE
EJ32-14C039-AB.vbf	Range Rover Evoque (L538)	ABS - Anit-Lock Brake System (ABS) Control Module	SBL
EJ32-14C044-AB.vbf	Check in SDD (unconfirmed)	ACM - Audio Front Control Module	EXE
EJ32-14C044-BB.vbf	Check in SDD (unconfirmed)	ACM - Audio Front Control Module	EXE
EJ32-14C060-AF.vbf	Range Rover Evoque (L538)	FCDIM - Front Control/Display Interface Module	EXE
EJ32-14C060-AG.vbf	Range Rover Evoque (L538)	FCDIM - Front Control/Display Interface Module	EXE
EJ32-14C060-BF.vbf	Range Rover Evoque (L538)	FCDIM - Front Control/Display Interface Module	EXE
EJ32-14C060-BG.vbf	Range Rover Evoque (L538)	FCDIM - Front Control/Display Interface Module	EXE
EJ32-14C060-CA.vbf	Range Rover Evoque (L538)	FCDIM - Front Control/Display Interface Module	EXE
EJ32-14C060-CB.vbf	Range Rover Evoque (L538)	FCDIM - Front Control/Display Interface Module	EXE
EJ32-14C060-DA.vbf	Range Rover Evoque (L538)	FCDIM - Front Control/Display Interface Module	EXE
EJ32-14C060-DB.vbf	Range Rover Evoque (L538)	FCDIM - Front Control/Display Interface Module	EXE
EJ32-14C060-LA.vbf	Range Rover Evoque (L538)	FCDIM - Front Control/Display Interface Module	EXE
EJ32-14C060-LB.vbf	Range Rover Evoque (L538)	FCDIM - Front Control/Display Interface Module	EXE
EJ32-14C060-MA.vbf	Range Rover Evoque (L538)	FCDIM - Front Control/Display Interface Module	EXE
EJ32-14C060-MB.vbf	Range Rover Evoque (L538)	FCDIM - Front Control/Display Interface Module	EXE
EJ32-14C060-NA.vbf	Range Rover Evoque (L538)	FCDIM - Front Control/Display Interface Module	EXE
EJ32-14C060-NB.vbf	Range Rover Evoque (L538)	FCDIM - Front Control/Display Interface Module	EXE
EJ32-14C060-PA.vbf	Range Rover Evoque (L538)	FCDIM - Front Control/Display Interface Module	EXE
EJ32-14C060-PB.vbf	Range Rover Evoque (L538)	FCDIM - Front Control/Display Interface Module	EXE
EJ32-14C061-AF.vbf	Range Rover Evoque (L538)	FCDIM - Front Control/Display Interface Module	DATA
EJ32-14C061-AG.vbf	Range Rover Evoque (L538)	FCDIM - Front Control/Display Interface Module	DATA
EJ32-14C061-CA.vbf	Range Rover Evoque (L538)	FCDIM - Front Control/Display Interface Module	DATA
EJ32-14C061-CB.vbf	Range Rover Evoque (L538)	FCDIM - Front Control/Display Interface Module	DATA
EJ32-14C061-LA.vbf	Range Rover Evoque (L538)	FCDIM - Front Control/Display Interface Module	DATA
EJ32-14C061-LB.vbf	Range Rover Evoque (L538)	FCDIM - Front Control/Display Interface Module	DATA
EJ32-14C061-NA.vbf	Range Rover Evoque (L538)	FCDIM - Front Control/Display Interface Module	DATA
EJ32-14C061-NB.vbf	Range Rover Evoque (L538)	FCDIM - Front Control/Display Interface Module	DATA
EJ32-14C063-AB.vbf	Range Rover Evoque (L538)	FCDIM - Front Control/Display Interface Module	SBL
EJ32-14C063-CA.vbf	Range Rover Evoque (L538)	FCDIM - Front Control/Display Interface Module	SBL
EJ32-14C064-AB.vbf	Check in SDD (unconfirmed)	DDM - Driver Front Door Module	EXE
EJ32-14C065-AB.vbf	Check in SDD (unconfirmed)	DDM - Driver Front Door Module	DATA
EJ32-14C068-AB.vbf	Range Rover Evoque (L538)	DDM - Driver Front Door Module	EXE
EJ32-14C080-AE.VBF	Range Rover Evoque (L538)	AHCM - Auxiliary Heater Control Module	EXE
EJ32-14C081-AG.VBF	Range Rover Evoque (L538)	AHCM - Auxiliary Heater Control Module	DATA
EJ32-14C081-BF.VBF	Range Rover Evoque (L538)	AHCM - Auxiliary Heater Control Module	DATA
EJ32-14C081-CG.VBF	Range Rover Evoque (L538)	AHCM - Auxiliary Heater Control Module	DATA
EJ32-14C081-DF.VBF	Range Rover Evoque (L538)	AHCM - Auxiliary Heater Control Module	DATA
EJ32-14C083-AA.vbf	Range Rover Evoque (L538)	AHCM - Auxiliary Heater Control Module	SBL

File name	Vehicle line (indicative)	Module (ECU)	Type
EJ32-14C088-CJ.vbf	Range Rover Evoque (L538)	IPC - Instrument Panel Cluster (IPC) Control Module	EXE
EJ32-14C091-AM.vbf	Range Rover Evoque (L538)	PAM - Parking Assist Control Module	DATA
EJ32-14C098-AG.vbf	Range Rover Evoque (L538)	RCM - Restraints Control Module	DATA
EJ32-14C098-AH.vbf	Range Rover Evoque (L538)	RCM - Restraints Control Module	DATA
EJ32-14C098-BG.vbf	Range Rover Evoque (L538)	RCM - Restraints Control Module	DATA
EJ32-14C098-BH.vbf	Range Rover Evoque (L538)	RCM - Restraints Control Module	DATA
EJ32-14C108-AB.vbf	Range Rover Evoque (L538)	PDM - Passenger Front Door Module	EXE
EJ32-14C109-AB.vbf	Range Rover Evoque (L538)	PDM - Passenger Front Door Module	DATA
EJ32-14C112-AB.vbf	Range Rover Evoque (L538)	PDM - Passenger Front Door Module	EXE
EJ32-14C121-AB.vbf	Range Rover Evoque (L538)	RGTM - Rear Gate / Trunk Module	EXE
EJ32-14C122-AA.vbf	Range Rover Evoque (L538)	RGTM - Rear Gate / Trunk Module	DATA
EJ32-14C169-AE.vbf	Range Rover Evoque (L538)	PBM - Park Brake Control Module	EXE
EJ32-14C185-AC.vbf	Range Rover Evoque (L538)	BCM - Body Control Module	DATA
EJ32-14C204-MAM.vbf	Range Rover Evoque (L538)	PCM - Powertrain Control Module	EXE
EJ32-14C204-MAN.vbf	Range Rover Evoque (L538)	PCM - Powertrain Control Module	EXE
EJ32-14C204-MAP.vbf	Range Rover Evoque (L538)	PCM - Powertrain Control Module	EXE
EJ32-14C204-MAS.vbf	Range Rover Evoque (L538)	PCM - Powertrain Control Module	EXE
EJ32-14C204-MAT.vbf	Range Rover Evoque (L538)	ECM - Engine Control Module	EXE
EJ32-14C204-MBM.vbf	Range Rover Evoque (L538)	PCM - Powertrain Control Module	EXE
EJ32-14C204-MBN.vbf	Range Rover Evoque (L538)	PCM - Powertrain Control Module	EXE
EJ32-14C204-MBP.vbf	Range Rover Evoque (L538)	PCM - Powertrain Control Module	EXE
EJ32-14C204-MBS.vbf	Range Rover Evoque (L538)	PCM - Powertrain Control Module	EXE
EJ32-14C204-MCL.vbf	Range Rover Evoque (L538)	PCM - Powertrain Control Module	EXE
EJ32-14C204-MCM.vbf	Range Rover Evoque (L538)	PCM - Powertrain Control Module	EXE
EJ32-14C204-MCN.vbf	Range Rover Evoque (L538)	PCM - Powertrain Control Module	EXE
EJ32-14C204-MCR.vbf	Range Rover Evoque (L538)	PCM - Powertrain Control Module	EXE
EJ32-14C204-MEL.vbf	Range Rover Evoque (L538)	PCM - Powertrain Control Module	EXE
EJ32-14C204-MEM.vbf	Range Rover Evoque (L538)	PCM - Powertrain Control Module	EXE
EJ32-14C204-MEN.vbf	Range Rover Evoque (L538)	PCM - Powertrain Control Module	EXE
EJ32-14C204-MER.vbf	Range Rover Evoque (L538)	PCM - Powertrain Control Module	EXE
EJ32-14C204-MKM.vbf	Range Rover Evoque (L538)	PCM - Powertrain Control Module	EXE
EJ32-14C204-MKN.vbf	Range Rover Evoque (L538)	PCM - Powertrain Control Module	EXE
EJ32-14C204-MKP.vbf	Range Rover Evoque (L538)	PCM - Powertrain Control Module	EXE
EJ32-14C204-MKS.vbf	Range Rover Evoque (L538)	PCM - Powertrain Control Module	EXE
EJ32-14C204-VC.vbf	Range Rover Evoque (L538)	PCM - Powertrain Control Module	EXE
EJ32-14C217-AB.vbf	Range Rover Evoque (L538)	Not specified	EXE
EJ32-14C217-AC.vbf	Range Rover Evoque (L538)	PSCM - Power Steering Control Module	EXE
EJ32-14C218-AA.vbf	Range Rover Evoque (L538)	Not specified	EXE
EJ32-14C218-BB.vbf	Range Rover Evoque (L538)	PSCM - Power Steering Control Module	EXE
EJ32-14C273-AC.vbf	Range Rover Evoque (L538)	PCM - Powertrain Control Module	SBL
EJ32-14C273-VA.vbf	Range Rover Evoque (L538)	PCM - Powertrain Control Module	SBL
EJ32-14C319-AD.vbf	Range Rover Evoque (L538)	HVAC - HVAC Control Module	SIGCFG
EJ32-14C337-CAN.vbf	Range Rover Evoque (L538)	TCM - Transmission Control Module	EXE
EJ32-14C337-CAR.vbf	Range Rover Evoque (L538)	TCM - Transmission Control Module	EXE
EJ32-14C337-CAS.vbf	Range Rover Evoque (L538)	TCM - Transmission Control Module	EXE
EJ32-14C337-CAT.vbf	Range Rover Evoque (L538)	TCM - Transmission Control Module	EXE
EJ32-14C337-CBN.vbf	Range Rover Evoque (L538)	TCM - Transmission Control Module	EXE
EJ32-14C337-CBR.vbf	Range Rover Evoque (L538)	TCM - Transmission Control Module	EXE
EJ32-14C337-CBS.vbf	Range Rover Evoque (L538)	TCM - Transmission Control Module	EXE
EJ32-14C337-CBT.vbf	Range Rover Evoque (L538)	TCM - Transmission Control Module	EXE
EJ32-14C337-CCK.vbf	Range Rover Evoque (L538)	TCM - Transmission Control Module	EXE
EJ32-14C337-CCM.vbf	Range Rover Evoque (L538)	TCM - Transmission Control Module	EXE
EJ32-14C337-CCN.vbf	Range Rover Evoque (L538)	TCM - Transmission Control Module	EXE
EJ32-14C337-CCP.vbf	Range Rover Evoque (L538)	TCM - Transmission Control Module	EXE
EJ32-14C337-CDK.vbf	Range Rover Evoque (L538)	TCM - Transmission Control Module	EXE
EJ32-14C337-CDM.vbf	Range Rover Evoque (L538)	TCM - Transmission Control Module	EXE
EJ32-14C337-CDN.vbf	Range Rover Evoque (L538)	TCM - Transmission Control Module	EXE
EJ32-14C337-CDP.vbf	Range Rover Evoque (L538)	TCM - Transmission Control Module	EXE
EJ32-14C337-CRC.vbf	Range Rover Evoque (L538)	TCM - Transmission Control Module	EXE
EJ32-14C337-CSC.vbf	Range Rover Evoque (L538)	TCM - Transmission Control Module	EXE
EJ32-14C337-CTC.vbf	Range Rover Evoque (L538)	TCM - Transmission Control Module	EXE
EJ32-14C337-CUC.vbf	Range Rover Evoque (L538)	TCM - Transmission Control Module	EXE
EJ32-14C337-CUD.vbf	Range Rover Evoque (L538)	TCM - Transmission Control Module	EXE
EJ32-14C337-CUE.vbf	Range Rover Evoque (L538)	TCM - Transmission Control Module	EXE
EJ32-14C337-CVC.vbf	Range Rover Evoque (L538)	TCM - Transmission Control Module	EXE
EJ32-14C337-CXC.vbf	Range Rover Evoque (L538)	TCM - Transmission Control Module	EXE
EJ32-14C337-CXD.vbf	Range Rover Evoque (L538)	TCM - Transmission Control Module	EXE
EJ32-14C337-CXE.vbf	Range Rover Evoque (L538)	TCM - Transmission Control Module	EXE
EJ32-14C337-CYC.vbf	Range Rover Evoque (L538)	TCM - Transmission Control Module	EXE
EJ32-14C337-CYD.vbf	Range Rover Evoque (L538)	TCM - Transmission Control Module	EXE
EJ32-14C337-CYE.vbf	Range Rover Evoque (L538)	TCM - Transmission Control Module	EXE
EJ32-14C337-CZC.vbf	Range Rover Evoque (L538)	TCM - Transmission Control Module	EXE
EJ32-14C337-CZD.vbf	Range Rover Evoque (L538)	TCM - Transmission Control Module	EXE
EJ32-14C337-CZE.vbf	Range Rover Evoque (L538)	TCM - Transmission Control Module	EXE
EJ32-14C339-AD.vbf	Range Rover Evoque (L538)	TCM - Transmission Control Module	SBL
EJ32-14C355-AE.vbf	Range Rover Evoque (L538)	Not specified	EXE

File name	Vehicle line (indicative)	Module (ECU)	Type
EJ32-14C355-BD.vbf	Range Rover Evoque (L538)	Not specified	EXE
EJ32-14C386-AB.vbf	Range Rover Evoque (L538)	Not specified	EXE
EJ32-14C416-AC.vbf	Range Rover Evoque (L538)	AHCM - Auxiliary Heater Control Module	SIGCFG
EJ32-14C527-AA.vbf	Range Rover Evoque (L538)	Not specified	DATA
EJ32-14C527-BA.vbf	Range Rover Evoque (L538)	Not specified	DATA
EJ32-14C534-AA.vbf	Range Rover Evoque (L538)	FCIMB - Front Controls Interface Module 'B'	SIGCFG
EJ32-14C535-AB.vbf	Range Rover Evoque (L538)	FCIMB - Front Controls Interface Module 'B'	EXE
EJ32-14C536-AA.vbf	Range Rover Evoque (L538)	FCIMB - Front Controls Interface Module 'B'	CUSTOM
EJ32-14C542-AF.vbf	Range Rover Evoque (L538)	SUMB - Suspension Control Module B	EXE
EJ32-14C543-AF.vbf	Range Rover Evoque (L538)	SUMB - Suspension Control Module B	DATA
EJ32-14C548-AB.vbf	Range Rover Evoque (L538)	PSM - Passenger Front Seat Module	EXE
EJ32-14C549-BB.vbf	Range Rover Sport (L494)	PSM - Passenger Front Seat Module	DATA
EJ32-14C549-CA.vbf	Range Rover Sport (L494)	Not specified	DATA
EJ32-14C549-DB.vbf	Range Rover Sport (L494)	PSM - Passenger Front Seat Module	DATA
EJ32-14C549-EA.vbf	Range Rover Sport (L494)	Not specified	DATA
EJ32-14C549-FB.vbf	Range Rover Sport (L494)	PSM - Passenger Front Seat Module	DATA
EJ32-14C609-AB.vbf	Range Rover Evoque (L538)	Not specified	EXE
EJ32-14C609-AC.vbf	Range Rover Evoque (L538)	PSCM - Power Steering Control Module	EXE
EJ32-14C621-AE.vbf	Range Rover Evoque (L538)	FCDIM - Front Control/Display Interface Module	EXE
EJ32-14C621-CB.vbf	Range Rover Evoque (L538)	FCDIM - Front Control/Display Interface Module	EXE
EJ32-14D023-AA.vbf	Range Rover Evoque (L538)	ATCM - All Terrain Control Module	SIGCFG
EJ32-14D024-AC.vbf	Range Rover Evoque (L538)	ATCM - All Terrain Control Module	EXE
EJ32-14D183-AB.vbf	Range Rover Evoque (L538)	OCS - Restraints Occupant Classification System Module	DATA
EJ32-14D196-AB.vbf	Range Rover Evoque (L538)	HCMB - Headlamp Control Module B	EXE
EJ32-14D197-AA.vbf	Range Rover Evoque (L538)	HCM2 - Headlamp Control Module #2	DATA
EJ32-14D358-AB.vbf	Range Rover Evoque (L538)	MFD - Multi functional Display	EXE
EJ32-14D358-BB.vbf	Range Rover Evoque (L538)	MFD - Multi functional Display	EXE
EJ32-14D359-AB.vbf	Range Rover Evoque (L538)	MFD - Multi functional Display	DATA
EJ32-14D480-AB.vbf	Range Rover Evoque (L538)	IPMB - Image Processing Module B	EXE
EJ32-14D485-AA.vbf	Range Rover Evoque (L538)	IPMB - Image Processing Module B	DATA
EJ32-14D564-AE.vbf	Range Rover Evoque (L538)	SODL - Side Obstacle Detection Control Module - Left	DATA
EJ32-14D564-BE.vbf	Range Rover Evoque (L538)	SODR - Side Obstacle Detection Control Module - Right	DATA
EJ32-14F022-AC.vbf	Check in SDD (unconfirmed)	IPMB - Image Processing Module B	DATA
EJ32-14F231-AF.vbf	Range Rover Evoque (L538)	HUD - Head Up Display	CUSTOM
EJ32-14F231-BB.vbf	Range Rover Evoque (L538)	HUD - Head Up Display	CUSTOM
EJ32-14F455-AC.vbf	Range Rover Evoque (L538)	HCMB - Headlamp Control Module B	EXE
EJ32-14F455-BA.vbf	Range Rover Evoque (L538)	HCM2 - Headlamp Control Module #2	EXE
EJ32-14F456-AC.vbf	Range Rover Evoque (L538)	HCMB - Headlamp Control Module B	DATA
EJ32-14F456-BB.vbf	Range Rover Evoque (L538)	HCMB - Headlamp Control Module B	DATA
EJ32-14F530-AF.vbf	Range Rover Evoque (L538)	GWM - Gateway Module A	EXE
EJ32-14F530-AG.vbf	Range Rover Evoque (L538)	GWM - Gateway Module A	EXE
EJ32-14F531-AG.vbf	Range Rover Evoque (L538)	GWM - Gateway Module A	DATA
EJ32-18D618-AA.vbf	Range Rover Evoque (L538)	HVAC - HVAC Control Module	SBL
EJ32-18D619-AK.vbf	Range Rover Evoque (L538)	HVAC - HVAC Control Module	EXE
EJ32-18D620-AN.vbf	Range Rover Evoque (L538)	HVAC - HVAC Control Module	DATA
EJ32-70713-LP.vbf	Range Rover Evoque (L538)	TCU - Telematic Control Unit Module	DATA
EJ32-70713-MN.vbf	Range Rover Evoque (L538)	TCU - Telematic Control Unit Module	DATA
EJ32-70713-MP.vbf	Range Rover Evoque (L538)	TCU - Telematic Control Unit Module	DATA
EJ32-70713-NN.vbf	Range Rover Evoque (L538)	TCU - Telematic Control Unit Module	DATA
EJ32-70713-NP.vbf	Range Rover Evoque (L538)	TCU - Telematic Control Unit Module	DATA
EJ32-7B761-AB.vbf	Range Rover Evoque (L538)	LSM Light Switch Module	SIGCFG
EJ32-7B761-CB.vbf	Range Rover Evoque (L538)	LSM Light Switch Module	SIGCFG
EJ32-7B762-AB.vbf	Range Rover Evoque (L538)	LSM Light Switch Module	EXE
EJ32-7B762-CF.vbf	Range Rover Evoque (L538)	LSM Light Switch Module	EXE
EJ32-7B763-AB.vbf	Range Rover Evoque (L538)	LSM Light Switch Module	DATA
EJ32-7B763-CB.vbf	Range Rover Evoque (L538)	LSM Light Switch Module	DATA
EJ32-7B764-AA.vbf	Range Rover Evoque (L538)	AWD - All Wheel Drive Module	SBL
EJ32-7B764-CB.vbf	Range Rover Evoque (L538)	LSM Light Switch Module	SBL
EJ3M-14F022-AC.vbf	Check in SDD (unconfirmed)	IPMB - Image Processing Module B	DATA
EK52-12K532-PNL.vbf	Range Rover (L405)	PCM - Powertrain Control Module	DATA
EK52-12K532-PPJ.vbf	Range Rover (L405)	PCM - Powertrain Control Module	DATA
EK52-14C037-AMJ.vbf	Range Rover (L405)	ABS - Anit-Lock Brake System (ABS) Control Module	EXE
EK52-14C037-ANJ.vbf	Range Rover (L405)	ABS - Anit-Lock Brake System (ABS) Control Module	EXE
EK52-14C037-APJ.vbf	Range Rover (L405)	ABS - Anit-Lock Brake System (ABS) Control Module	EXE
EK52-14C037-ATJ.vbf	Range Rover (L405)	ABS - Anit-Lock Brake System (ABS) Control Module	EXE
EK52-14C037-AVD.vbf	Range Rover (L405)	ABS - Anit-Lock Brake System (ABS) Control Module	EXE
EK52-14C037-AZE.vbf	Range Rover (L405)	ABS - Anit-Lock Brake System (ABS) Control Module	EXE
EK52-14C037-BAJ.vbf	Range Rover (L405)	ABS - Anit-Lock Brake System (ABS) Control Module	EXE
EK52-14C037-CAK.vbf	Range Rover (L405)	ABS - Anit-Lock Brake System (ABS) Control Module	EXE
EK52-14C064-AD.vbf	Check in SDD (unconfirmed)	DDM - Driver Front Door Module	EXE
EK52-14C065-AD.vbf	Check in SDD (unconfirmed)	DDM - Driver Front Door Module	DATA
EK52-14C068-AD.vbf	Range Rover (L405)	DDM - Driver Front Door Module	EXE
EK52-14C108-AD.vbf	Check in SDD (unconfirmed)	PDM - Passenger Front Door Module	EXE
EK52-14C109-AD.vbf	Check in SDD (unconfirmed)	PDM - Passenger Front Door Module	DATA
EK52-14C112-AD.vbf	Range Rover (L405)	PDM - Passenger Front Door Module	EXE
EK52-14C169-AB.vbf	Range Rover (L405)	PBM - Park Brake Control Module	EXE

File name	Vehicle line (indicative)	Module (ECU)	Type
EK52-14C320-AB.vbf	Check in SDD (unconfirmed)	PDM - Passeng Front Door Module	SIGCFG
EK52-14C321-AB.vbf	Check in SDD (unconfirmed)	DDM - Driver Front Door Module	SIGCFG
EK52-14C527-AB.vbf	Range Rover (L405)	Not specified	DATA
EK52-14C527-BB.vbf	Range Rover (L405)	Not specified	DATA
EK52-14C527-DE.vbf	Range Rover (L405)	Not specified	DATA
EK52-14C527-FA.vbf	Range Rover (L405)	Not specified	DATA
EK52-14C561-AB.vbf	Range Rover (L405)	GSM - Gear Shift Module	EXE
EK52-14D480-BA.vbf	Range Rover (L405)	IPMB - Image Processing Module B	EXE
EK52-14D485-BA.vbf	Range Rover (L405)	IPMB - Image Processing Module B	DATA
EK52-14E094-JFE.vbf	Range Rover (L405)	CHCM - Chassis Control Module	EXE
EK52-14E094-JFF.vbf	Range Rover (L405)	CHCM - Chassis Control Module	EXE
EK52-14E094-JGG.vbf	Range Rover (L405)	CHCM - Chassis Control Module	EXE
EK52-14E094-JGH.vbf	Range Rover (L405)	CHCM - Chassis Control Module	EXE
EK52-14E094-JHG.vbf	Range Rover (L405)	CHCM - Chassis Control Module	EXE
EK52-14E094-JHH.vbf	Range Rover (L405)	CHCM - Chassis Control Module	EXE
EK52-14E094-JJG.vbf	Range Rover (L405)	CHCM - Chassis Control Module	EXE
EK52-14E094-JJH.vbf	Range Rover (L405)	CHCM - Chassis Control Module	EXE
EK52-14E094-JKG.vbf	Range Rover (L405)	CHCM - Chassis Control Module	EXE
EK52-14E094-JKH.vbf	Range Rover (L405)	CHCM - Chassis Control Module	EXE
EK52-14E094-JLG.vbf	Range Rover (L405)	CHCM - Chassis Control Module	EXE
EK52-14E094-JLH.vbf	Range Rover (L405)	CHCM - Chassis Control Module	EXE
EK52-14E094-JRA.vbf	Range Rover (L405)	CHCM - Chassis Control Module	EXE
EK52-14F022-AD.vbf	Check in SDD (unconfirmed)	IPMB - Image Processing Module B	DATA
EK52-14F229-AB.vbf	Range Rover (L405)	HUD - Head Up Display	SIGCFG
EK52-14F229-AC.vbf	Range Rover (L405)	HUD - Head Up Display	SIGCFG
EK52-14F230-AF.vbf	Range Rover (L405)	HUD - Head Up Display	EXE
EK52-14F230-BA.vbf	Range Rover (L405)	HUD - Head Up Display	EXE
EK52-14F231-AF.vbf	Range Rover (L405)	HUD - Head Up Display	CUSTOM
EK52-14F231-BA.vbf	Range Rover (L405)	HUD - Head Up Display	CUSTOM
EK52-14F232-AA.vbf	Range Rover (L405)	HUD - Head Up Display	SBL
EK52-14F232-BA.vbf	Range Rover (L405)	HUD - Head Up Display	SBL
EK52-14F435-LCC.vbf	Range Rover (L405)	CHCMB - Chassis Control Module B	EXE
EK52-14F435-LDC.vbf	Range Rover (L405)	CHCMB - Chassis Control Module B	EXE
EK52-14F435-NCA.vbf	Range Rover (L405)	CHCMB - Chassis Control Module B	EXE
EK52-14F435-NDA.vbf	Range Rover (L405)	CHCMB - Chassis Control Module B	EXE
EK52-14F435-NGC.vbf	Range Rover (L405)	CHCMB - Chassis Control Module B	EXE
EK52-14F435-NHC.vbf	Range Rover (L405)	CHCMB - Chassis Control Module B	EXE
EK52-19H527-AC.vbf	Range Rover (L405)	ACCM - Air Conditioning Control Module	EXE
EK52-19H529-AB.vbf	Range Rover (L405)	AUCM - Auxilliary Control Module	SBL
EK52-7J104-CCH.vbf	Range Rover (L405)	TCM - Transmission Control Module	EXE
EK5M-14C064-AA.vbf	Check in SDD (unconfirmed)	DDM - Driver Front Door Module	EXE
EK5M-14C065-AA.vbf	Check in SDD (unconfirmed)	DDM - Driver Front Door Module	DATA
EK5M-14C068-AA.vbf	Not specified	DDM - Driver Front Door Module	EXE
EK5M-14C108-AA.vbf	Not specified	PDM - Passenger Front Door Module	EXE
EK5M-14C109-AA.vbf	Not specified	PDM - Passenger Front Door Module	DATA
EK5M-14C112-AA.vbf	Not specified	PDM - Passenger Front Door Module	EXE
EK5M-14C358-AB.vbf	Not specified	RBM - Running Board Control Module	EXE
EK5M-14C360-AA.vbf	Not specified	RBM - Running Board Control Module	SBL
EK5M-606K42-AB.vbf	Range Rover (L405)	CRTM - Calf Rest Table Module	SIGCFG
EK5M-606K43-AB.vbf	Range Rover (L405)	CRTM - Calf Rest Table Module	EXE
EK5M-606K44-AA.vbf	Range Rover Sport (L494)	YRM - Yaw Rate Sensor Module	DATA
EK5M-606K44-BB.vbf	Range Rover Sport (L494)	CRTM - Calf Rest Table Module	DATA
EK5M-606K44-CA.vbf	Range Rover Sport (L494)	CRTM - Calf Rest Table Module	DATA
EK5M-606K45-AA.vbf	Range Rover (L405)	CRTM - Calf Rest Table Module	SBL
EK62-12K532-NAE.vbf	Range Rover Sport (L494)	PCM - Powertrain Control Module	DATA
EK62-12K532-NCE.vbf	Range Rover Sport (L494)	PCM - Powertrain Control Module	DATA
EK62-12K532-NRE.vbf	Range Rover Sport (L494)	PCM - Powertrain Control Module	DATA
EK62-14C037-AKH.vbf	Range Rover Sport (L494)	ABS - Anit-Lock Brake System (ABS) Control Module	EXE
EK62-14C037-BAJ.vbf	Range Rover Sport (L494)	ABS - Anit-Lock Brake System (ABS) Control Module	EXE
EK62-14C060-AE.vbf	Range Rover Sport (L494)	FCDIM - Front Control/Display Interface Module	EXE
EK62-14C060-AH.vbf	Range Rover Sport (L494)	FCDIM - Front Control/Display Interface Module	EXE
EK62-14C060-AJ.vbf	Range Rover Sport (L494)	FCDIM - Front Control/Display Interface Module	EXE
EK62-14C060-BE.vbf	Range Rover Sport (L494)	FCDIM - Front Control/Display Interface Module	EXE
EK62-14C060-BH.vbf	Range Rover Sport (L494)	FCDIM - Front Control/Display Interface Module	EXE
EK62-14C060-BJ.vbf	Range Rover Sport (L494)	FCDIM - Front Control/Display Interface Module	EXE
EK62-14C061-AE.vbf	Range Rover Sport (L494)	FCDIM - Front Control/Display Interface Module	DATA
EK62-14C061-AH.vbf	Range Rover Sport (L494)	FCDIM - Front Control/Display Interface Module	DATA
EK62-14C061-AJ.vbf	Range Rover Sport (L494)	FCDIM - Front Control/Display Interface Module	DATA
EK62-14C063-AA.vbf	Range Rover Sport (L494)	FCDIM - Front Control/Display Interface Module	SBL
EK62-14C169-AB.vbf	Range Rover Sport (L494)	PBM - Park Brake Control Module	EXE
EK62-14C621-AE.vbf	Range Rover Sport (L494)	FCDIM - Front Control/Display Interface Module	EXE
EK62-14E094-JFE.vbf	Range Rover Sport (L494)	CHCM - Chassis Control Module	EXE
EK62-14E094-JFF.vbf	Range Rover Sport (L494)	CHCM - Chassis Control Module	EXE
EK62-14E094-JGG.vbf	Range Rover Sport (L494)	CHCM - Chassis Control Module	EXE
EK62-14E094-JGH.vbf	Range Rover Sport (L494)	CHCM - Chassis Control Module	EXE
EK62-14E094-JGJ.vbf	Range Rover Sport (L494)	CHCM - Chassis Control Module	EXE

File name	Vehicle line (indicative)	Module (ECU)	Type
EK62-14F231-AF.vbf	Range Rover Sport (L494)	HUD - Head Up Display	CUSTOM
EK62-14F231-BA.vbf	Range Rover Sport (L494)	HUD - Head Up Display	CUSTOM
EK62-14F435-LCC.vbf	Range Rover Sport (L494)	CHCMB - Chassis Control Module B	EXE
EK62-14F435-NCA.vbf	Range Rover Sport (L494)	CHCMB - Chassis Control Module B	EXE
EK62-14F435-NFC.vbf	Range Rover Sport (L494)	CHCMB - Chassis Control Module B	EXE
EK62-7J104-CCH.vbf	Range Rover Sport (L494)	TCM - Transmission Control Module	EXE
EPLA-14C026-AB.vbf	Multiple models (shared module)	IPC - Instrument Panel Cluster (IPC) Control Module	EXE
EPLA-14C026-AC.vbf	Multiple models (shared module)	IPC - Instrument Panel Cluster (IPC) Control Module	EXE
EPLA-14C026-BD.vbf	Multiple models (shared module)	IPC - Instrument Panel Cluster (IPC) Control Module	EXE
EPLA-14C026-CD.vbf	Multiple models (shared module)	IPC - Instrument Panel Cluster (IPC) Control Module	EXE
EPLA-14C034-DA.vbf	Range Rover Sport (L494)	DSM - Driver Front Seat Module	DATA
EPLA-14C034-FA.vbf	Range Rover Sport (L494)	DSM - Driver Front Seat Module	DATA
EPLA-14C034-HA.vbf	Range Rover Sport (L494)	DSM - Driver Front Seat Module	DATA
EPLA-14C034-KA.vbf	Range Rover Sport (L494)	DSM - Driver Front Seat Module	DATA
EPLA-14C034-MA.vbf	Range Rover Sport (L494)	DSM - Driver Front Seat Module	DATA
EPLA-14C036-BJ.vbf	Multiple models (shared module)	ABS - Anit-Lock Brake System (ABS) Control Module	EXE
EPLA-14C039-BA.vbf	Multiple models (shared module)	ABS - Anit-Lock Brake System (ABS) Control Module	SBL
EPLA-14C056-AB.vbf	Multiple models (shared module)	NCM - Navigation Control Module	EXE
EPLA-14C060-AF.vbf	Multiple models (shared module)	FCDIM - Front Control/Display Interface Module	EXE
EPLA-14C060-AH.vbf	Multiple models (shared module)	FCDIM - Front Control/Display Interface Module	EXE
EPLA-14C060-AJ.vbf	Multiple models (shared module)	FCDIM - Front Control/Display Interface Module	EXE
EPLA-14C060-BF.vbf	Multiple models (shared module)	FCDIM - Front Control/Display Interface Module	EXE
EPLA-14C060-BH.vbf	Multiple models (shared module)	FCDIM - Front Control/Display Interface Module	EXE
EPLA-14C060-BJ.vbf	Multiple models (shared module)	FCDIM - Front Control/Display Interface Module	EXE
EPLA-14C061-AF.vbf	Multiple models (shared module)	FCDIM - Front Control/Display Interface Module	DATA
EPLA-14C061-AH.vbf	Multiple models (shared module)	FCDIM - Front Control/Display Interface Module	DATA
EPLA-14C061-AJ.vbf	Multiple models (shared module)	FCDIM - Front Control/Display Interface Module	DATA
EPLA-14C063-AA.vbf	Multiple models (shared module)	FCDIM - Front Control/Display Interface Module	SBL
EPLA-14C064-AC.vbf	Check in SDD (unconfirmed)	DDM - Driver Front Door Module	EXE
EPLA-14C065-AC.vbf	Check in SDD (unconfirmed)	DDM - Driver Front Door Module	DATA
EPLA-14C067-AA.vbf	Multiple models (shared module)	DDM - Driver Front Door Module	SBL
EPLA-14C068-AC.vbf	Multiple models (shared module)	DDM - Driver Front Door Module	EXE
EPLA-14C088-JD.vbf	Multiple models (shared module)	IPC - Instrument Panel Cluster (IPC) Control Module	DATA
EPLA-14C088-KD.vbf	Multiple models (shared module)	IPC - Instrument Panel Cluster (IPC) Control Module	DATA
EPLA-14C108-AC.vbf	Multiple models (shared module)	PDM - Passenger Front Door Module	EXE
EPLA-14C109-AC.vbf	Multiple models (shared module)	PDM - Passenger Front Door Module	DATA
EPLA-14C111-AA.vbf	Multiple models (shared module)	PDM - Passenger Front Door Module	SBL
EPLA-14C112-AC.vbf	Multiple models (shared module)	PDM - Passenger Front Door Module	EXE
EPLA-14C197-AF.vbf	Multiple models (shared module)	BECM - Battery Energy Control Module	EXE
EPLA-14C198-AH.VBF	Multiple models (shared module)	BECM - Battery Energy Control Module	EXE
EPLA-14C200-AB.vbf	Multiple models (shared module)	BECM - Battery Energy Control Module	SBL
EPLA-14C204-PNG.vbf	Multiple models (shared module)	PCM - Powertrain Control Module	EXE
EPLA-14C273-PA.vbf	Multiple models (shared module)	PCM - Powertrain Control Module	SBL
EPLA-14C354-AD.vbf	Multiple models (shared module)	Not specified	EXE
EPLA-14C354-BA.vbf	Multiple models (shared module)	Not specified	EXE
EPLA-14C354-CC.vbf	Multiple models (shared module)	Not specified	EXE
EPLA-14C354-DB.vbf	Multiple models (shared module)	Not specified	EXE
EPLA-14C354-ED.vbf	Multiple models (shared module)	Not specified	EXE
EPLA-14C354-FC.vbf	Multiple models (shared module)	Not specified	EXE
EPLA-14C355-AF.vbf	Multiple models (shared module)	Not specified	EXE
EPLA-14C355-BE.vbf	Multiple models (shared module)	Not specified	EXE
EPLA-14C355-CF.vbf	Multiple models (shared module)	Not specified	EXE
EPLA-14C355-DF.vbf	Multiple models (shared module)	Not specified	EXE
EPLA-14C355-EE.vbf	Multiple models (shared module)	Not specified	EXE
EPLA-14C355-FE.vbf	Multiple models (shared module)	Not specified	EXE
EPLA-14C355-GF.vbf	Multiple models (shared module)	Not specified	EXE
EPLA-14C355-HF.vbf	Multiple models (shared module)	Not specified	EXE
EPLA-14C356-AB.vbf	Multiple models (shared module)	Not specified	SBL
EPLA-14C356-BA.vbf	Multiple models (shared module)	Not specified	SBL
EPLA-14C395-AD.vbf	Multiple models (shared module)	FCDIM - Front Control/Display Interface Module	EXE
EPLA-14C395-AE.vbf	Multiple models (shared module)	FCDIM - Front Control/Display Interface Module	EXE
EPLA-14C395-AF.vbf	Multiple models (shared module)	FCDIM - Front Control/Display Interface Module	EXE
EPLA-14C395-AG.vbf	Multiple models (shared module)	FCDIM - Front Control/Display Interface Module	EXE
EPLA-14C549-DA.vbf	Range Rover Sport (L494)	PSM - Passenger Front Seat Module	DATA
EPLA-14C549-FA.vbf	Range Rover Sport (L494)	PSM - Passenger Front Seat Module	DATA
EPLA-14C549-HA.vbf	Range Rover Sport (L494)	PSM - Passenger Front Seat Module	DATA
EPLA-14C549-KA.vbf	Range Rover Sport (L494)	PSM - Passenger Front Seat Module	DATA
EPLA-14C549-MA.vbf	Range Rover Sport (L494)	PSM - Passenger Front Seat Module	DATA
EPLA-14C621-AE.vbf	Multiple models (shared module)	FCDIM - Front Control/Display Interface Module	EXE
EPLA-14D418-DF.vbf	Multiple models (shared module)	Not specified	EXE
EPLA-14D419-DD.vbf	Multiple models (shared module)	Not specified	EXE
EPLA-14D420-DC.vbf	Multiple models (shared module)	Not specified	DATA
EPLA-14D421-DA.vbf	Multiple models (shared module)	Not specified	SBL
EPLA-14D519-AC.vbf	Multiple models (shared module)	HVAC - HVAC Control Module	EXE
EPLA-14D520-AC.vbf	Multiple models (shared module)	HVAC - HVAC Control Module	DATA
EPLA-14D520-BC.vbf	Multiple models (shared module)	HVAC - HVAC Control Module	DATA

File name	Vehicle line (indicative)	Module (ECU)	Type
EPLA-14D520-CC.vbf	Multiple models (shared module)	HVAC - HVAC Control Module	DATA
EPLA-14D520-DA.vbf	Multiple models (shared module)	HVAC - HVAC Control Module	DATA
EPLA-14D520-EA.vbf	Multiple models (shared module)	HVAC - HVAC Control Module	DATA
EPLA-14F520-AH.vbf	Multiple models (shared module)	SOBDMB - Secondary OBD Control Module B	EXE
EPLA-14F522-AB.vbf	Multiple models (shared module)	SOBDMB - Secondary OBD Control Module B	SBL
EPLA-14G037-BA.vbf	Range Rover Sport (L494)	PRSM - Passenger Rear Seat Module	DATA
EPLA-14G037-CA.vbf	Range Rover Sport (L494)	PRSM - Passenger Rear Seat Module	DATA
EPLA-14G037-DA.vbf	Range Rover Sport (L494)	PRSM - Passenger Rear Seat Module	DATA
EPLA-14G037-EA.vbf	Range Rover Sport (L494)	PRSM - Passenger Rear Seat Module	DATA
EPLA-14G037-GA.vbf	Range Rover Sport (L494)	PRSM - Passenger Rear Seat Module	DATA
EPLA-14G037-HA.vbf	Range Rover Sport (L494)	PRSM - Passenger Rear Seat Module	DATA
EPLA-14G037-JB.vbf	Range Rover Sport (L494)	PRSM - Passenger Rear Seat Module	DATA
EPLA-14G037-KA.vbf	Range Rover Sport (L494)	PRSM - Passenger Rear Seat Module	DATA
EPLA-14G037-LA.vbf	Range Rover Sport (L494)	PRSM - Passenger Rear Seat Module	DATA
EPLA-14G037-MA.vbf	Range Rover Sport (L494)	PRSM - Passenger Rear Seat Module	DATA
EPLA-14G047-BA.vbf	Range Rover Sport (L494)	DRSM - Driver Rear Seat Module	DATA
EPLA-14G047-CA.vbf	Range Rover Sport (L494)	DRSM - Driver Rear Seat Module	DATA
EPLA-14G047-DA.vbf	Range Rover Sport (L494)	DRSM - Driver Rear Seat Module	DATA
EPLA-14G047-EA.vbf	Range Rover Sport (L494)	DRSM - Driver Rear Seat Module	DATA
EPLA-14G047-GA.vbf	Range Rover Sport (L494)	DRSM - Driver Rear Seat Module	DATA
EPLA-14G047-HA.vbf	Range Rover Sport (L494)	DRSM - Driver Rear Seat Module	DATA
EPLA-14G047-JB.vbf	Range Rover Sport (L494)	DRSM - Driver Rear Seat Module	DATA
EPLA-14G047-KA.vbf	Range Rover Sport (L494)	DRSM - Driver Rear Seat Module	DATA
EPLA-14G047-LA.vbf	Range Rover Sport (L494)	DRSM - Driver Rear Seat Module	DATA
EPLA-14G047-MA.vbf	Range Rover Sport (L494)	DRSM - Driver Rear Seat Module	DATA
EW8M-14C036-AA.vbf	Check in SDD (unconfirmed)	ABS - Anit-Lock Brake System (ABS) Control Module	EXE
EW8M-14C542-AA.vbf	Check in SDD (unconfirmed)	ecu_address = 0x786;	EXE
EW93-14C026-AC.vbf	Jaguar XJ (X351)	IPC - Instrument Panel Cluster (IPC) Control Module	EXE
EW93-14C026-AE.vbf	Jaguar XJ (X351)	IPC - Instrument Panel Cluster (IPC) Control Module	EXE
EW93-14C026-BC.vbf	Jaguar XJ (X351)	IPC - Instrument Panel Cluster (IPC) Control Module	EXE
EW93-14C026-BD.vbf	Jaguar XJ (X351)	IPC - Instrument Panel Cluster (IPC) Control Module	EXE
EW93-14C026-CA.vbf	Jaguar XJ (X351)	IPC - Instrument Panel Cluster (IPC) Control Module	EXE
EW93-14C029-BA.vbf	Jaguar XJ (X351)	DSM - Driver Front Seat Module	SBL
EW93-14C030-AA.vbf	Jaguar XJ (X351)	DSM - Driver Front Seat Module	EXE
EW93-14C030-BD.vbf	Jaguar XJ (X351)	DSM - Driver Front Seat Module	EXE
EW93-14C056-BA.vbf	Jaguar XJ (X351)	NCM - Navigation Control Module	EXE
EW93-14C060-AG.vbf	Jaguar XJ (X351)	FCDIM - Front Control/Display Interface Module	EXE
EW93-14C060-AH.vbf	Jaguar XJ (X351)	FCDIM - Front Control/Display Interface Module	EXE
EW93-14C060-AJ.vbf	Jaguar XJ (X351)	FCDIM - Front Control/Display Interface Module	EXE
EW93-14C060-BG.vbf	Jaguar XJ (X351)	FCDIM - Front Control/Display Interface Module	EXE
EW93-14C060-BH.vbf	Jaguar XJ (X351)	FCDIM - Front Control/Display Interface Module	EXE
EW93-14C060-BJ.vbf	Jaguar XJ (X351)	FCDIM - Front Control/Display Interface Module	EXE
EW93-14C060-CA.vbf	Jaguar XJ (X351)	FCDIM - Front Control/Display Interface Module	EXE
EW93-14C060-CB.vbf	Jaguar XJ (X351)	FCDIM - Front Control/Display Interface Module	EXE
EW93-14C060-CC.vbf	Jaguar XJ (X351)	FCDIM - Front Control/Display Interface Module	EXE
EW93-14C060-DA.vbf	Jaguar XJ (X351)	FCDIM - Front Control/Display Interface Module	EXE
EW93-14C060-DB.vbf	Jaguar XJ (X351)	FCDIM - Front Control/Display Interface Module	EXE
EW93-14C060-DC.vbf	Jaguar XJ (X351)	FCDIM - Front Control/Display Interface Module	EXE
EW93-14C061-AG.vbf	Jaguar XJ (X351)	FCDIM - Front Control/Display Interface Module	DATA
EW93-14C061-AH.vbf	Jaguar XJ (X351)	FCDIM - Front Control/Display Interface Module	DATA
EW93-14C061-AJ.vbf	Jaguar XJ (X351)	FCDIM - Front Control/Display Interface Module	DATA
EW93-14C061-CA.vbf	Jaguar XJ (X351)	FCDIM - Front Control/Display Interface Module	DATA
EW93-14C061-CB.vbf	Jaguar XJ (X351)	FCDIM - Front Control/Display Interface Module	DATA
EW93-14C061-CC.vbf	Jaguar XJ (X351)	FCDIM - Front Control/Display Interface Module	DATA
EW93-14C063-AB.vbf	Jaguar XJ (X351)	FCDIM - Front Control/Display Interface Module	SBL
EW93-14C063-CA.vbf	Jaguar XJ (X351)	FCDIM - Front Control/Display Interface Module	SBL
EW93-14C064-AC.vbf	Jaguar XJ (X351)	DDM - Driver Front Door Module	EXE
EW93-14C065-AB.vbf	Jaguar XJ (X351)	DDM - Driver Front Door Module	DATA
EW93-14C068-AC.vbf	Jaguar XJ (X351)	DDM - Driver Front Door Module	EXE
EW93-14C088-AC.vbf	Jaguar XJ (X351)	IPC - Instrument Panel Cluster (IPC) Control Module	DATA
EW93-14C088-AE.vbf	Jaguar XJ (X351)	IPC - Instrument Panel Cluster (IPC) Control Module	DATA
EW93-14C088-BC.vbf	Jaguar XJ (X351)	IPC - Instrument Panel Cluster (IPC) Control Module	DATA
EW93-14C088-BD.vbf	Jaguar XJ (X351)	IPC - Instrument Panel Cluster (IPC) Control Module	DATA
EW93-14C108-AC.vbf	Jaguar XJ (X351)	PDM - Passenger Front Door Module	EXE
EW93-14C109-AB.vbf	Jaguar XJ (X351)	PDM - Passenger Front Door Module	DATA
EW93-14C112-AC.vbf	Jaguar XJ (X351)	PDM - Passenger Front Door Module	EXE
EW93-14C184-AF.vbf	Jaguar XJ (X351)	BCM - Body Control Module	EXE
EW93-14C185-AC.vbf	Jaguar XJ (X351)	BCM - Body Control Module	DATA
EW93-14C204-EAE.vbf	Jaguar XJ (X351)	PCM - Powertrain Control Module	EXE
EW93-14C204-ECD.vbf	Jaguar XJ (X351)	PCM - Powertrain Control Module	EXE
EW93-14C204-EEE.vbf	Jaguar XJ (X351)	PCM - Powertrain Control Module	EXE
EW93-14C204-ETE.vbf	Jaguar XJ (X351)	PCM - Powertrain Control Module	EXE
EW93-14C204-MAE.vbf	Jaguar XJ (X351)	PCM - Powertrain Control Module	EXE
EW93-14C204-MBG.vbf	Jaguar XJ (X351)	PCM - Powertrain Control Module	EXE
EW93-14C204-MCE.vbf	Jaguar XJ (X351)	PCM - Powertrain Control Module	EXE
EW93-14C204-MEE.vbf	Jaguar XJ (X351)	PCM - Powertrain Control Module	EXE

File name	Vehicle line (indicative)	Module (ECU)	Type
EW93-14C355-AE.vbf	Jaguar XJ (X351)	Not specified	EXE
EW93-14C355-BE.vbf	Jaguar XJ (X351)	Not specified	EXE
EW93-14C355-CF.vbf	Jaguar XJ (X351)	Not specified	EXE
EW93-14C355-DF.vbf	Jaguar XJ (X351)	Not specified	EXE
EW93-14C395-AA.vbf	Jaguar XJ (X351)	FCDIM - Front Control/Display Interface Module	EXE
EW93-14C395-AE.vbf	Jaguar XJ (X351)	FCDIM - Front Control/Display Interface Module	EXE
EW93-14C413-AB.vbf	Jaguar XJ (X351)	DSM - Driver Front Seat Module	SIGCFG
EW93-14C526-AA.vbf	Jaguar XJ (X351)	Not specified	EXE
EW93-14C526-AB.vbf	Jaguar XJ (X351)	Not specified	EXE
EW93-14C526-CA.vbf	Jaguar XJ (X351)	Not specified	EXE
EW93-14C526-CB.vbf	Jaguar XJ (X351)	Not specified	EXE
EW93-14C527-AB.vbf	Jaguar XJ (X351)	Not specified	DATA
EW93-14C527-CB.vbf	Jaguar XJ (X351)	Not specified	DATA
EW93-14C527-DB.vbf	Jaguar XJ (X351)	Not specified	DATA
EW93-14C527-FB.vbf	Jaguar XJ (X351)	Not specified	DATA
EW93-14C527-GE.vbf	Jaguar XJ (X351)	Not specified	DATA
EW93-14C527-HF.vbf	Jaguar XJ (X351)	Not specified	DATA
EW93-14C527-JA.vbf	Jaguar XJ (X351)	Not specified	DATA
EW93-14C527-KA.vbf	Jaguar XJ (X351)	Not specified	DATA
EW93-14C527-LA.vbf	Jaguar XJ (X351)	Not specified	DATA
EW93-14C527-MA.vbf	Jaguar XJ (X351)	Not specified	DATA
EW93-14C547-AA.vbf	Jaguar XJ (X351)	PSM - Passenger Front Seat Module	SIGCFG
EW93-14C548-BD.vbf	Jaguar XJ (X351)	PSM - Passenger Front Seat Module	EXE
EW93-14C550-BA.vbf	Jaguar XJ (X351)	PSM - Passenger Front Seat Module	SBL
EW93-14C621-AE.vbf	Jaguar XJ (X351)	FCDIM - Front Control/Display Interface Module	EXE
EW93-14C621-AF.vbf	Jaguar XJ (X351)	FCDIM - Front Control/Display Interface Module	EXE
EW93-14C621-CB.vbf	Jaguar XJ (X351)	FCDIM - Front Control/Display Interface Module	EXE
EW93-14E094-ARA.vbf	Jaguar XJ (X351)	CHCM - Chassis Control Module	EXE
EW93-14E094-ASA.vbf	Jaguar XJ (X351)	CHCM - Chassis Control Module	EXE
EW93-14E094-ATB.vbf	Jaguar XJ (X351)	CHCM - Chassis Control Module	EXE
EW93-14E094-AUB.vbf	Jaguar XJ (X351)	CHCM - Chassis Control Module	EXE
EW93-14E094-AVB.vbf	Jaguar XJ (X351)	CHCM - Chassis Control Module	EXE
EW93-14G035-AB.vbf	Jaguar XJ (X351)	PRSM - Passenger Rear Seat Module	SIGCFG
EW93-14G036-AD.vbf	Jaguar XJ (X351)	PRSM - Passenger Rear Seat Module	EXE
EW93-14G038-AA.vbf	Jaguar XJ (X351)	SCMD - Seat Control Module D	SBL
EW93-14G045-AB.vbf	Jaguar XJ (X351)	DRSM - Driver Rear Seat Module	SIGCFG
EW93-14G046-AD.vbf	Jaguar XJ (X351)	DRSM - Driver Rear Seat Module	EXE
EW93-14G048-AA.vbf	Jaguar XJ (X351)	SCMC - Seat Control Module C	SBL
EW93-7J104-AFD.vbf	Jaguar XJ (X351)	TCM - Transmission Control Module	EXE
EW93-7J104-AKC.vbf	Jaguar XJ (X351)	TCM - Transmission Control Module	EXE
EW93-7J104-ASA.vbf	Jaguar XJ (X351)	TCM - Transmission Control Module	EXE
EW9M-14E093-JB.vbf	Not specified	CHCM - Chassis Control Module	EXE
EW9M-14E094-ABA.vbf	Not specified	CHCM - Chassis Control Module	EXE
EX23-12K532-VCA.vbf	Jaguar XF (X250)	PCM - Powertrain Control Module	DATA
EX23-12K532-VGD.vbf	Jaguar XF (X250)	PCM - Powertrain Control Module	DATA
EX23-12K532-VSA.vbf	Jaguar XF (X250)	PCM - Powertrain Control Module	DATA
EX23-12K532-VTB.vbf	Jaguar XF (X250)	PCM - Powertrain Control Module	DATA
EX23-12K532-VYA.vbf	Jaguar XF (X250)	PCM - Powertrain Control Module	DATA
EX23-14C026-AA.vbf	Jaguar XF (X250)	IPC - Instrument Panel Cluster (IPC) Control Module	EXE
EX23-14C026-AB.vbf	Jaguar XF (X250)	IPC - Instrument Panel Cluster (IPC) Control Module	EXE
EX23-14C056-AA.vbf	Jaguar XF (X250)	NCM - Navigation Control Module	EXE
EX23-14C056-BA.vbf	Jaguar XF (X250)	NCM - Navigation Control Module	EXE
EX23-14C060-AD.vbf	Jaguar XF (X250)	FCDIM - Front Control/Display Interface Module	EXE
EX23-14C060-AE.vbf	Jaguar XF (X250)	FCDIM - Front Control/Display Interface Module	EXE
EX23-14C060-AF.vbf	Jaguar XF (X250)	FCDIM - Front Control/Display Interface Module	EXE
EX23-14C060-CA.vbf	Jaguar XF (X250)	FCDIM - Front Control/Display Interface Module	EXE
EX23-14C060-CB.vbf	Jaguar XF (X250)	FCDIM - Front Control/Display Interface Module	EXE
EX23-14C060-CC.vbf	Jaguar XF (X250)	FCDIM - Front Control/Display Interface Module	EXE
EX23-14C061-AD.vbf	Jaguar XF (X250)	FCDIM - Front Control/Display Interface Module	DATA
EX23-14C061-AE.vbf	Jaguar XF (X250)	FCDIM - Front Control/Display Interface Module	DATA
EX23-14C061-AF.vbf	Jaguar XF (X250)	FCDIM - Front Control/Display Interface Module	DATA
EX23-14C061-CA.vbf	Jaguar XF (X250)	FCDIM - Front Control/Display Interface Module	DATA
EX23-14C061-CB.vbf	Jaguar XF (X250)	FCDIM - Front Control/Display Interface Module	DATA
EX23-14C061-CC.vbf	Jaguar XF (X250)	FCDIM - Front Control/Display Interface Module	DATA
EX23-14C063-AA.vbf	Jaguar XF (X250)	FCDIM - Front Control/Display Interface Module	SBL
EX23-14C063-CA.vbf	Jaguar XF (X250)	FCDIM - Front Control/Display Interface Module	SBL
EX23-14C204-MAD.vbf	Jaguar XF (X250)	PCM - Powertrain Control Module	EXE
EX23-14C204-MBE.vbf	Jaguar XF (X250)	PCM - Powertrain Control Module	EXE
EX23-14C204-MCD.vbf	Jaguar XF (X250)	PCM - Powertrain Control Module	EXE
EX23-14C204-MEF.vbf	Jaguar XF (X250)	PCM - Powertrain Control Module	EXE
EX23-14C204-VA.vbf	Jaguar XF (X250)	PCM - Powertrain Control Module	EXE
EX23-14C395-AB.vbf	Jaguar XF (X250)	FCDIM - Front Control/Display Interface Module	EXE
EX23-14C621-AD.vbf	Jaguar XF (X250)	FCDIM - Front Control/Display Interface Module	EXE
EX23-14C621-CB.vbf	Jaguar XF (X250)	FCDIM - Front Control/Display Interface Module	EXE
EX23-14D519-AA.vbf	Jaguar XF (X250)	HVAC - HVAC Control Module	EXE
EX23-14D519-BA.vbf	Jaguar XF (X250)	HVAC - HVAC Control Module	EXE

File name	Vehicle line (indicative)	Module (ECU)	Type
EX23-7J104-AFC.vbf	Jaguar XF (X250)	TCM - Transmission Control Module	EXE
EX23-7J104-AMB.vbf	Jaguar XF (X250)	TCM - Transmission Control Module	EXE
EX23-7J104-ANB.vbf	Jaguar XF (X250)	TCM - Transmission Control Module	EXE
EX53-14C025-AB.vbf	Jaguar F-Type (X152)	IPC - Instrument Panel Cluster (IPC) Control Module	SBL
EX53-14C026-AG.vbf	Jaguar F-Type (X152)	IPC - Instrument Panel Cluster (IPC) Control Module	EXE
EX53-14C026-ZB.vbf	Jaguar F-Type (X152)	IPC - Instrument Panel Cluster (IPC) Control Module	EXE
EX53-14C027-AA.vbf	Jaguar F-Type (X152)	RCM - Restraints Control Module	SBL
EX53-14C028-AE.vbf	Jaguar F-Type (X152)	RCM - Restraints Control Module	EXE
EX53-14C030-AA.vbf	Jaguar F-Type (X152)	DSM - Driver Front Seat Module	EXE
EX53-14C030-BA.vbf	Jaguar F-Type (X152)	DSM - Driver Front Seat Module	EXE
EX53-14C036-AE.vbf	Jaguar F-Type (X152)	ABS - Anit-Lock Brake System (ABS) Control Module	EXE
EX53-14C036-BC.vbf	Jaguar F-Type (X152)	ABS - Anit-Lock Brake System (ABS) Control Module	EXE
EX53-14C037-AAC.vbf	Jaguar F-Type (X152)	ABS - Anit-Lock Brake System (ABS) Control Module	EXE
EX53-14C037-AD.vbf	Jaguar F-Type (X152)	ABS - Anit-Lock Brake System (ABS) Control Module	EXE
EX53-14C037-BD.vbf	Jaguar F-Type (X152)	ABS - Anit-Lock Brake System (ABS) Control Module	EXE
EX53-14C037-CAC.vbf	Jaguar F-Type (X152)	ABS - Anit-Lock Brake System (ABS) Control Module	EXE
EX53-14C037-CD.vbf	Jaguar F-Type (X152)	ABS - Anit-Lock Brake System (ABS) Control Module	EXE
EX53-14C037-DAC.vbf	Jaguar F-Type (X152)	ABS - Anit-Lock Brake System (ABS) Control Module	EXE
EX53-14C037-DD.vbf	Jaguar F-Type (X152)	ABS - Anit-Lock Brake System (ABS) Control Module	EXE
EX53-14C037-EAC.vbf	Jaguar F-Type (X152)	ABS - Anit-Lock Brake System (ABS) Control Module	EXE
EX53-14C037-ED.vbf	Jaguar F-Type (X152)	ABS - Anit-Lock Brake System (ABS) Control Module	EXE
EX53-14C037-FAC.vbf	Jaguar F-Type (X152)	ABS - Anit-Lock Brake System (ABS) Control Module	EXE
EX53-14C037-GAC.vbf	Jaguar F-Type (X152)	ABS - Anit-Lock Brake System (ABS) Control Module	EXE
EX53-14C037-HAC.vbf	Jaguar F-Type (X152)	ABS - Anit-Lock Brake System (ABS) Control Module	EXE
EX53-14C037-JAC.vbf	Jaguar F-Type (X152)	ABS - Anit-Lock Brake System (ABS) Control Module	EXE
EX53-14C039-AA.vbf	Jaguar F-Type (X152)	ABS - Anit-Lock Brake System (ABS) Control Module	SBL
EX53-14C045-AR.vbf	Jaguar F-Type (X152)	ICM - Infotainment Control Module	DATA
EX53-14C045-AS.vbf	Jaguar F-Type (X152)	ICM - Infotainment Control Module	DATA
EX53-14C045-BH.vbf	Jaguar F-Type (X152)	ICM - Infotainment Control Module	DATA
EX53-14C045-BK.vbf	Jaguar F-Type (X152)	ICM - Infotainment Control Module	DATA
EX53-14C045-BL.vbf	Jaguar F-Type (X152)	ICM - Infotainment Control Module	DATA
EX53-14C045-BM.vbf	Jaguar F-Type (X152)	ICM - Infotainment Control Module	DATA
EX53-14C045-BN.vbf	Jaguar F-Type (X152)	ICM - Infotainment Control Module	DATA
EX53-14C045-BP.vbf	Jaguar F-Type (X152)	ICM - Infotainment Control Module	DATA
EX53-14C056-AA.vbf	Jaguar F-Type (X152)	NCM - Navigation Control Module	EXE
EX53-14C060-AH.vbf	Jaguar F-Type (X152)	FCDIM - Front Control/Display Interface Module	EXE
EX53-14C060-AJ.vbf	Jaguar F-Type (X152)	FCDIM - Front Control/Display Interface Module	EXE
EX53-14C060-CF.vbf	Jaguar F-Type (X152)	FCDIM - Front Control/Display Interface Module	EXE
EX53-14C060-CG.vbf	Jaguar F-Type (X152)	FCDIM - Front Control/Display Interface Module	EXE
EX53-14C060-CH.vbf	Jaguar F-Type (X152)	FCDIM - Front Control/Display Interface Module	EXE
EX53-14C061-AF.vbf	Jaguar F-Type (X152)	FCDIM - Front Control/Display Interface Module	DATA
EX53-14C061-AG.vbf	Jaguar F-Type (X152)	FCDIM - Front Control/Display Interface Module	DATA
EX53-14C061-CF.vbf	Jaguar F-Type (X152)	FCDIM - Front Control/Display Interface Module	DATA
EX53-14C061-CG.vbf	Jaguar F-Type (X152)	FCDIM - Front Control/Display Interface Module	DATA
EX53-14C061-CH.vbf	Jaguar F-Type (X152)	FCDIM - Front Control/Display Interface Module	DATA
EX53-14C063-AA.vbf	Jaguar F-Type (X152)	FCDIM - Front Control/Display Interface Module	SBL
EX53-14C063-CA.vbf	Jaguar F-Type (X152)	FCDIM - Front Control/Display Interface Module	SBL
EX53-14C064-AD.vbf	Jaguar F-Type (X152)	DDM - Driver Front Door Module	EXE
EX53-14C065-AD.vbf	Jaguar F-Type (X152)	DDM - Driver Front Door Module	DATA
EX53-14C065-BC.vbf	Jaguar F-Type (X152)	DDM - Driver Front Door Module	DATA
EX53-14C067-AA.vbf	Jaguar F-Type (X152)	DDM	SBL
EX53-14C084-AD.vbf	Jaguar F-Type (X152)	HCM - Headlamp Control Module #1	EXE
EX53-14C087-AA.vbf	Jaguar F-Type (X152)	HCM - Headlamp Control Module #1	SBL
EX53-14C098-CC.vbf	Jaguar F-Type (X152)	RCM - Restraints Control Module	DATA
EX53-14C098-DC.vbf	Jaguar F-Type (X152)	RCM - Restraints Control Module	DATA
EX53-14C105-AD.vbf	Jaguar F-Type (X152)	TMC Traffic Message Channel Module	DATA
EX53-14C105-AH.vbf	Jaguar F-Type (X152)	TMC Traffic Message Channel Module	DATA
EX53-14C108-AD.vbf	Jaguar F-Type (X152)	PDM - Passenger Front Door Module	EXE
EX53-14C109-AD.vbf	Jaguar F-Type (X152)	PDM - Passenger Front Door Module	DATA
EX53-14C109-BC.vbf	Jaguar F-Type (X152)	PDM - Passenger Front Door Module	DATA
EX53-14C111-AA.vbf	Jaguar F-Type (X152)	PDM	SBL
EX53-14C121-AB.vbf	Jaguar F-Type (X152)	RGTM - Rear Gate / Trunk Module	EXE
EX53-14C122-AB.vbf	Jaguar F-Type (X152)	RGTM - Rear Gate / Trunk Module	DATA
EX53-14C124-AA.vbf	Jaguar F-Type (X152)	RGTM - Rear Gate / Trunk Module	SBL
EX53-14C168-AC.vbf	Jaguar F-Type (X152)	PBM - Park Brake Control Module	EXE
EX53-14C184-AJ.vbf	Jaguar F-Type (X152)	BCM - Body Control Module	EXE
EX53-14C185-AE.vbf	Jaguar F-Type (X152)	BCM - Body Control Module	DATA
EX53-14C185-BA.vbf	Jaguar F-Type (X152)	BCM - Body Control Module	DATA
EX53-14C204-EAF.vbf	Jaguar F-Type (X152)	PCM - Powertrain Control Module	EXE
EX53-14C204-EAG.vbf	Jaguar F-Type (X152)	PCM - Powertrain Control Module	EXE
EX53-14C204-ECE.vbf	Jaguar F-Type (X152)	PCM - Powertrain Control Module	EXE
EX53-14C204-ECF.vbf	Jaguar F-Type (X152)	PCM - Powertrain Control Module	EXE
EX53-14C204-EED.vbf	Jaguar F-Type (X152)	PCM - Powertrain Control Module	EXE
EX53-14C204-EEE.vbf	Jaguar F-Type (X152)	PCM - Powertrain Control Module	EXE
EX53-14C204-ETE.vbf	Jaguar F-Type (X152)	PCM - Powertrain Control Module	EXE
EX53-14C204-ETF.vbf	Jaguar F-Type (X152)	PCM - Powertrain Control Module	EXE

File name	Vehicle line (indicative)	Module (ECU)	Type
EX53-14C204-RAG.vbf	Jaguar F-Type (X152)	PCM - Powertrain Control Module	EXE
EX53-14C204-RAH.vbf	Jaguar F-Type (X152)	PCM - Powertrain Control Module	EXE
EX53-14C204-RAJ.vbf	Jaguar F-Type (X152)	PCM - Powertrain Control Module	EXE
EX53-14C204-RCF.vbf	Jaguar F-Type (X152)	PCM - Powertrain Control Module	EXE
EX53-14C204-RCG.vbf	Jaguar F-Type (X152)	PCM - Powertrain Control Module	EXE
EX53-14C204-RCH.vbf	Jaguar F-Type (X152)	PCM - Powertrain Control Module	EXE
EX53-14C204-REE.vbf	Jaguar F-Type (X152)	PCM - Powertrain Control Module	EXE
EX53-14C204-REF.vbf	Jaguar F-Type (X152)	PCM - Powertrain Control Module	EXE
EX53-14C204-REG.vbf	Jaguar F-Type (X152)	PCM - Powertrain Control Module	EXE
EX53-14C204-RTF.vbf	Jaguar F-Type (X152)	PCM - Powertrain Control Module	EXE
EX53-14C204-RTG.vbf	Jaguar F-Type (X152)	PCM - Powertrain Control Module	EXE
EX53-14C204-RTH.vbf	Jaguar F-Type (X152)	PCM - Powertrain Control Module	EXE
EX53-14C204-TAH.vbf	Jaguar F-Type (X152)	PCM - Powertrain Control Module	EXE
EX53-14C204-TAJ.vbf	Jaguar F-Type (X152)	PCM - Powertrain Control Module	EXE
EX53-14C204-TCH.vbf	Jaguar F-Type (X152)	PCM - Powertrain Control Module	EXE
EX53-14C204-TCJ.vbf	Jaguar F-Type (X152)	PCM - Powertrain Control Module	EXE
EX53-14C204-TEH.vbf	Jaguar F-Type (X152)	PCM - Powertrain Control Module	EXE
EX53-14C204-TEJ.vbf	Jaguar F-Type (X152)	PCM - Powertrain Control Module	EXE
EX53-14C204-TTK.vbf	Jaguar F-Type (X152)	PCM - Powertrain Control Module	EXE
EX53-14C204-TTL.vbf	Jaguar F-Type (X152)	PCM - Powertrain Control Module	EXE
EX53-14C204-UAJ.vbf	Jaguar F-Type (X152)	PCM - Powertrain Control Module	EXE
EX53-14C204-UAK.vbf	Jaguar F-Type (X152)	PCM - Powertrain Control Module	EXE
EX53-14C204-UCH.vbf	Jaguar F-Type (X152)	PCM - Powertrain Control Module	EXE
EX53-14C204-UCJ.vbf	Jaguar F-Type (X152)	PCM - Powertrain Control Module	EXE
EX53-14C204-UEJ.vbf	Jaguar F-Type (X152)	PCM - Powertrain Control Module	EXE
EX53-14C204-UEK.vbf	Jaguar F-Type (X152)	PCM - Powertrain Control Module	EXE
EX53-14C204-UTJ.vbf	Jaguar F-Type (X152)	PCM - Powertrain Control Module	EXE
EX53-14C204-UTK.vbf	Jaguar F-Type (X152)	PCM - Powertrain Control Module	EXE
EX53-14C320-AB.vbf	Jaguar F-Type (X152)	DDM - Driver Front Door Module	SIGCFG
EX53-14C321-AB.vbf	Jaguar F-Type (X152)	DDM - Driver Front Door Module	SIGCFG
EX53-14C388-AB.vbf	Jaguar F-Type (X152)	ecu_address = 0x795;	EXE
EX53-14C395-AB.vbf	Jaguar F-Type (X152)	FCDIM - Front Control/Display Interface Module	EXE
EX53-14C395-AE.vbf	Jaguar F-Type (X152)	FCDIM - Front Control/Display Interface Module	EXE
EX53-14C407-AB.vbf	Jaguar F-Type (X152)	RCM - Restraints Control Module	SIGCFG
EX53-14C408-AC.vbf	Jaguar F-Type (X152)	BCM - Body Control Module	SIGCFG
EX53-14C527-AD.vbf	Jaguar F-Type (X152)	Not specified	DATA
EX53-14C527-AF.vbf	Jaguar F-Type (X152)	Not specified	DATA
EX53-14C527-BE.vbf	Jaguar F-Type (X152)	Not specified	DATA
EX53-14C527-CC.vbf	Jaguar F-Type (X152)	Not specified	DATA
EX53-14C527-CF.vbf	Jaguar F-Type (X152)	Not specified	DATA
EX53-14C527-DA.vbf	Jaguar F-Type (X152)	Not specified	DATA
EX53-14C527-EA.vbf	Jaguar F-Type (X152)	Not specified	DATA
EX53-14C527-FB.vbf	Jaguar F-Type (X152)	Not specified	DATA
EX53-14C527-GB.vbf	Jaguar F-Type (X152)	Not specified	DATA
EX53-14C527-JD.vbf	Jaguar F-Type (X152)	Not specified	DATA
EX53-14C527-JF.vbf	Jaguar F-Type (X152)	Not specified	DATA
EX53-14C527-KA.vbf	Jaguar F-Type (X152)	Not specified	DATA
EX53-14C527-LC.VBF	Jaguar F-Type (X152)	Not specified	DATA
EX53-14C527-PB.vbf	Jaguar F-Type (X152)	Not specified	DATA
EX53-14C527-RC.vbf	Jaguar F-Type (X152)	Not specified	DATA
EX53-14C527-SE.vbf	Jaguar F-Type (X152)	Not specified	DATA
EX53-14C527-SF.vbf	Jaguar F-Type (X152)	Not specified	DATA
EX53-14C527-UB.vbf	Jaguar F-Type (X152)	Not specified	DATA
EX53-14C534-AB.vbf	Jaguar F-Type (X152)	FCIM - Front Controls Interface Module	SIGCFG
EX53-14C535-AF.vbf	Jaguar F-Type (X152)	FCIM - Front Controls Interface Module	EXE
EX53-14C536-AF.vbf	Jaguar F-Type (X152)	FCIM - Front Controls Interface Module	DATA
EX53-14C537-AB.vbf	Jaguar F-Type (X152)	FCIM - Front Controls Interface Module	SBL
EX53-14C548-AA.vbf	Jaguar F-Type (X152)	PSM - Passenger Front Seat Module	EXE
EX53-14C548-BA.vbf	Jaguar F-Type (X152)	PSM - Passenger Front Seat Module	EXE
EX53-14C560-AC.vbf	Jaguar F-Type (X152)	GSM - Gear Shift Module	SIGCFG
EX53-14C561-AD.vbf	Jaguar F-Type (X152)	GSM - Gear Shift Module	EXE
EX53-14C563-AA.vbf	Jaguar F-Type (X152)	GSM - Gear Shift Module	SBL
EX53-14C621-AC.vbf	Jaguar F-Type (X152)	FCDIM - Front Control/Display Interface Module	EXE
EX53-14C621-CD.vbf	Jaguar F-Type (X152)	FCDIM - Front Control/Display Interface Module	EXE
EX53-14C658-AA.vbf	Jaguar F-Type (X152)	FCIM - Front Controls Interface Module	EXE
EX53-14D023-AB.vbf	Jaguar F-Type (X152)	ATCM - All Terrain Control Module	SIGCFG
EX53-14D024-AC.vbf	Jaguar F-Type (X152)	ATCM - All Terrain Control Module	EXE
EX53-14D026-AA.vbf	Jaguar F-Type (X152)	ATCM - All Terrain Control Module	SBL
EX53-14D183-AA.vbf	Jaguar F-Type (X152)	OCS - Restraints Occupant Classification System Module	DATA
EX53-14D183-AB.vbf	Jaguar F-Type (X152)	OCS - Restraints Occupant Classification System Module	DATA
EX53-14D196-AA.vbf	Jaguar F-Type (X152)	HCM2 - Headlamp Control Module #2	EXE
EX53-14D197-AA.vbf	Jaguar F-Type (X152)	HCM2 - Headlamp Control Module #2	DATA
EX53-14D367-AC.vbf	Jaguar F-Type (X152)	SODL - Side Obstacle Detection Control Module - Left	SIGCFG
EX53-14D367-AD.vbf	Jaguar F-Type (X152)	SODL - Side Obstacle Detection Control Module - Left	SIGCFG
EX53-14D367-BC.vbf	Jaguar F-Type (X152)	SODR - Side Obstacle Detection Control Module - Right	SIGCFG
EX53-14D367-BD.vbf	Jaguar F-Type (X152)	SODR - Side Obstacle Detection Control Module - Right	SIGCFG

File name	Vehicle line (indicative)	Module (ECU)	Type
EX53-14D479-AC.vbf	Jaguar F-Type (X152)	IPMB - Image Processing Module B	DATA
EX53-14D480-AG.vbf	Jaguar F-Type (X152)	IPMB - Image Processing Module B	EXE
EX53-14D485-AE.vbf	Jaguar F-Type (X152)	IPMB - Image Processing Module B	DATA
EX53-14D519-AC.vbf	Jaguar F-Type (X152)	HVAC - HVAC Control Module	EXE
EX53-14D520-AE.vbf	Jaguar F-Type (X152)	HVAC - HVAC Control Module	DATA
EX53-14D521-AA.vbf	Jaguar F-Type (X152)	HVAC - HVAC Control Module	SBL
EX53-14D564-AD.vbf	Jaguar F-Type (X152)	SODL - Side Obstacle Detection Control Module - Left	DATA
EX53-14D564-AE.vbf	Jaguar F-Type (X152)	SODL - Side Obstacle Detection Control Module - Left	DATA
EX53-14D564-BD.vbf	Jaguar F-Type (X152)	SODR - Side Obstacle Detection Control Module - Right	DATA
EX53-14D564-BE.vbf	Jaguar F-Type (X152)	SODR - Side Obstacle Detection Control Module - Right	DATA
EX53-14E093-BC.vbf	Jaguar F-Type (X152)	CHCM - Chassis Control Module	EXE
EX53-14E093-BE.vbf	Jaguar F-Type (X152)	CHCM - Chassis Control Module	EXE
EX53-14E093-DA.vbf	Jaguar F-Type (X152)	CHCM - Chassis Control Module	EXE
EX53-14E093-DB.vbf	Jaguar F-Type (X152)	CHCM - Chassis Control Module	EXE
EX53-14E093-DC.vbf	Jaguar F-Type (X152)	CHCM - Chassis Control Module	EXE
EX53-14E093-DD.vbf	Jaguar F-Type (X152)	CHCM - Chassis Control Module	EXE
EX53-14E093-PC.vbf	Jaguar F-Type (X152)	CHCM - Chassis Control Module	EXE
EX53-14E094-BAD.vbf	Jaguar F-Type (X152)	CHCM - Chassis Control Module	EXE
EX53-14E094-BBE.vbf	Jaguar F-Type (X152)	CHCM - Chassis Control Module	EXE
EX53-14E094-BCG.vbf	Jaguar F-Type (X152)	CHCM - Chassis Control Module	EXE
EX53-14E094-BGC.vbf	Jaguar F-Type (X152)	CHCM - Chassis Control Module	EXE
EX53-14E094-BHD.vbf	Jaguar F-Type (X152)	CHCM - Chassis Control Module	EXE
EX53-14E094-BJF.vbf	Jaguar F-Type (X152)	CHCM - Chassis Control Module	EXE
EX53-14E094-PAF.vbf	Jaguar F-Type (X152)	CHCM - Chassis Control Module	EXE
EX53-14E094-PBF.vbf	Jaguar F-Type (X152)	CHCM - Chassis Control Module	EXE
EX53-14E094-PCF.vbf	Jaguar F-Type (X152)	CHCM - Chassis Control Module	EXE
EX53-14E094-PGA.vbf	Jaguar F-Type (X152)	CHCM - Chassis Control Module	EXE
EX53-14E094-PHA.vbf	Jaguar F-Type (X152)	CHCM - Chassis Control Module	EXE
EX53-14E094-PJA.vbf	Jaguar F-Type (X152)	CHCM - Chassis Control Module	EXE
EX53-14E095-AA.vbf	Jaguar F-Type (X152)	CHCM - Chassis Control Module	SBL
EX53-14F530-AF.vbf	Jaguar F-Type (X152)	GWM - Gateway Module A	EXE
EX53-14F530-BE.vbf	Jaguar F-Type (X152)	GWM - Gateway Module A	EXE
EX53-14F531-AF.vbf	Jaguar F-Type (X152)	GWM - Gateway Module A	DATA
EX53-14F531-BD.vbf	Jaguar F-Type (X152)	GWM - Gateway Module A	DATA
EX53-157012-AC.vbf	Jaguar F-Type (X152)	FTCMB - Folding Top Control Module (Slave)	EXE
EX53-157013-AA.vbf	Jaguar F-Type (X152)	FTCMB - Folding Top Control Module (Slave)	DATA
EX53-157014-AA.vbf	Jaguar F-Type (X152)	FTCMB - Folding Top Control Module (Slave)	SBL
EX53-4C044-AA.vbf	Jaguar F-Type (X152)	ecu_address = 0x795;	SBL
EX53-4C045-AD.vbf	Jaguar F-Type (X152)	ecu_address = 0x795;	EXE
EX53-7J104-ABG.vbf	Jaguar F-Type (X152)	TCM - Transmission Control Module	EXE
EX53-7J104-ADK.vbf	Jaguar F-Type (X152)	TCM - Transmission Control Module	EXE
EX53-7J104-AKD.vbf	Jaguar F-Type (X152)	TCM - Transmission Control Module	EXE
EX53-7J104-AMK.vbf	Jaguar F-Type (X152)	TCM - Transmission Control Module	EXE
F2C2-14C065-AA.vbf	Discovery Sport (L550)	DDM - Driver Front Door Module	DATA
F2C2-14C069-AA.vbf	Discovery Sport (L550)	DRDM - Driver Rear Door Module	DATA
F2C2-14C109-AA.vbf	Discovery Sport (L550)	PDM - Passenger Front Door Module	DATA
F2C2-14C113-AA.vbf	Discovery Sport (L550)	PRDM - Passenger Rear Door Module	DATA
F2C2-14C218-AA.vbf	Discovery Sport (L550)	PSCM - Power Steering Control Module	EXE
F2C2-14C609-AA.vbf	Discovery Sport (L550)	PSCM - Power Steering Control Module	EXE
FCH2-14C065-AB.vbf	Range Rover Evoque (L538)	DDM - Driver Front Door Module	DATA
FCH2-14C109-AB.vbf	Range Rover Evoque (L538)	PDM - Passenger Front Door Module	DATA
FF6N-14C044-AAA.vbf	Not specified	Not specified	EXE
FF6N-14C044-FAA.vbf	Not specified	Not specified	EXE
FF6N-14C044-KAA.vbf	Not specified	Not specified	EXE
FF6N-14C044-LAA.vbf	Not specified	Not specified	EXE
FF6N-14C044-NAA.vbf	Not specified	Not specified	EXE
FF6N-14C044-RAA.vbf	Not specified	Not specified	EXE
FF6N-14C047-CA.vbf	Not specified	Not specified	SBL
FH22-12K532-PKB.vbf	Discovery 3/4 (L319)	PCM - Powertrain Control Module	DATA
FH22-12K532-PTA.vbf	Discovery 3/4 (L319)	PCM - Powertrain Control Module	DATA
FH22-12K532-PUB.vbf	Discovery 3/4 (L319)	PCM - Powertrain Control Module	DATA
FH22-14C026-AD.vbf	Discovery 3/4 (L319)	IPC - Instrument Panel Cluster (IPC) Control Module	EXE
FH22-14C026-BC.vbf	Discovery 3/4 (L319)	IPC - Instrument Panel Cluster (IPC) Control Module	EXE
FH22-14C028-AC.vbf	Discovery 3/4 (L319)	RCM - Restraints Control Module	EXE
FH22-14C036-AD.vbf	Discovery 3/4 (L319)	ABS - Anit-Lock Brake System (ABS) Control Module	EXE
FH22-14C056-CA.vbf	Discovery 3/4 (L319)	NCM - Navigation Control Module	EXE
FH22-14C060-AD.vbf	Discovery 3/4 (L319)	FCDIM - Front Control/Display Interface Module	EXE
FH22-14C060-AE.vbf	Discovery 3/4 (L319)	FCDIM - Front Control/Display Interface Module	EXE
FH22-14C060-AF.vbf	Discovery 3/4 (L319)	FCDIM - Front Control/Display Interface Module	EXE
FH22-14C060-AG.vbf	Discovery 3/4 (L319)	FCDIM - Front Control/Display Interface Module	EXE
FH22-14C060-AH.vbf	Discovery 3/4 (L319)	FCDIM - Front Control/Display Interface Module	EXE
FH22-14C061-AD.vbf	Discovery 3/4 (L319)	FCDIM - Front Control/Display Interface Module	DATA
FH22-14C061-AE.vbf	Discovery 3/4 (L319)	FCDIM - Front Control/Display Interface Module	DATA
FH22-14C061-AF.vbf	Discovery 3/4 (L319)	FCDIM - Front Control/Display Interface Module	DATA
FH22-14C061-AG.vbf	Discovery 3/4 (L319)	FCDIM - Front Control/Display Interface Module	DATA
FH22-14C061-AH.vbf	Discovery 3/4 (L319)	FCDIM - Front Control/Display Interface Module	DATA

File name	Vehicle line (indicative)	Module (ECU)	Type
FH22-14C063-AA.vbf	Discovery 3/4 (L319)	FCDIM - Front Control/Display Interface Module	SBL
FH22-14C088-AC.vbf	Discovery 3/4 (L319)	IPC - Instrument Panel Cluster (IPC) Control Module	DATA
FH22-14C088-AD.vbf	Discovery 3/4 (L319)	IPC - Instrument Panel Cluster (IPC) Control Module	DATA
FH22-14C098-AE.vbf	Discovery 3/4 (L319)	RCM - Restraints Control Module	DATA
FH22-14C184-AD.vbf	Discovery 3/4 (L319)	BCM - Body Control Module	EXE
FH22-14C184-AE.vbf	Discovery 3/4 (L319)	BCM - Body Control Module	EXE
FH22-14C185-AC.VBF	Discovery 3/4 (L319)	BCM - Body Control Module	DATA
FH22-14C204-TAD.vbf	Discovery 3/4 (L319)	PCM - Powertrain Control Module	EXE
FH22-14C204-TAE.vbf	Discovery 3/4 (L319)	PCM - Powertrain Control Module	EXE
FH22-14C204-TAF.vbf	Discovery 3/4 (L319)	PCM - Powertrain Control Module	EXE
FH22-14C204-TAH.vbf	Discovery 3/4 (L319)	PCM - Powertrain Control Module	EXE
FH22-14C204-TCB.vbf	Discovery 3/4 (L319)	PCM - Powertrain Control Module	EXE
FH22-14C204-TCC.vbf	Discovery 3/4 (L319)	PCM - Powertrain Control Module	EXE
FH22-14C204-TEA.vbf	Discovery 3/4 (L319)	PCM - Powertrain Control Module	EXE
FH22-14C204-TTD.vbf	Discovery 3/4 (L319)	PCM - Powertrain Control Module	EXE
FH22-14C204-TTE.vbf	Discovery 3/4 (L319)	PCM - Powertrain Control Module	EXE
FH22-14C204-TTG.vbf	Discovery 3/4 (L319)	PCM - Powertrain Control Module	EXE
FH22-14C407-AB.vbf	Discovery 3/4 (L319)	RCM - Restraints Control Module	SIGCFG
FH22-14C408-AA.vbf	Discovery 3/4 (L319)	BCM - Body Control Module	SIGCFG
FH22-14C621-AE.vbf	Discovery 3/4 (L319)	FCDIM - Front Control/Display Interface Module	EXE
FH22-14D048-AB.vbf	Discovery 3/4 (L319)	CCM - Cruise Control Module	SIGCFG
FH22-14D049-AC.vbf	Discovery 3/4 (L319)	CCM - Cruise Control Module	EXE
FH22-14D049-BA.vbf	Discovery 3/4 (L319)	CCM - Cruise Control Module	EXE
FH22-14D049-CA.vbf	Discovery 3/4 (L319)	CCM - Cruise Control Module	EXE
FH22-14D049-CB.vbf	Discovery 3/4 (L319)	CCM - Cruise Control Module	EXE
FH22-14D519-AB.vbf	Discovery 3/4 (L319)	HVAC - HVAC Control Module	EXE
FH22-7J104-ADB.vbf	Discovery 3/4 (L319)	TCM - Transmission Control Module	EXE
FH22-7J104-ADC.vbf	Discovery 3/4 (L319)	TCM - Transmission Control Module	EXE
FH52-14C026-AB.vbf	Freelander 2 (L359)	IPC - Instrument Panel Cluster (IPC) Control Module	EXE
FH52-14C184-AB.vbf	Freelander 2 (L359)	BCM - Body Control Module	EXE
FH52-14C185-AB.VBF	Freelander 2 (L359)	BCM - Body Control Module	DATA
FJ32-14C026-AB.vbf	Range Rover Evoque (L538)	IPC - Instrument Panel Cluster (IPC) Control Module	EXE
FJ32-14C026-AD.vbf	Range Rover Evoque (L538)	IPC - Instrument Panel Cluster (IPC) Control Module	EXE
FJ32-14C060-AD.vbf	Range Rover Evoque (L538)	FCDIM - Front Control/Display Interface Module	EXE
FJ32-14C060-AE.vbf	Range Rover Evoque (L538)	FCDIM - Front Control/Display Interface Module	EXE
FJ32-14C060-AF.vbf	Range Rover Evoque (L538)	FCDIM - Front Control/Display Interface Module	EXE
FJ32-14C060-AG.vbf	Range Rover Evoque (L538)	FCDIM - Front Control/Display Interface Module	EXE
FJ32-14C060-AH.vbf	Range Rover Evoque (L538)	FCDIM - Front Control/Display Interface Module	EXE
FJ32-14C060-AJ.vbf	Range Rover Evoque (L538)	FCDIM - Front Control/Display Interface Module	EXE
FJ32-14C060-AK.vbf	Range Rover Evoque (L538)	FCDIM - Front Control/Display Interface Module	EXE
FJ32-14C060-BD.vbf	Range Rover Evoque (L538)	FCDIM - Front Control/Display Interface Module	EXE
FJ32-14C060-BE.vbf	Range Rover Evoque (L538)	FCDIM - Front Control/Display Interface Module	EXE
FJ32-14C060-BF.vbf	Range Rover Evoque (L538)	FCDIM - Front Control/Display Interface Module	EXE
FJ32-14C060-BG.vbf	Range Rover Evoque (L538)	FCDIM - Front Control/Display Interface Module	EXE
FJ32-14C060-BH.vbf	Range Rover Evoque (L538)	FCDIM - Front Control/Display Interface Module	EXE
FJ32-14C060-BJ.vbf	Range Rover Evoque (L538)	FCDIM - Front Control/Display Interface Module	EXE
FJ32-14C060-BK.vbf	Range Rover Evoque (L538)	FCDIM - Front Control/Display Interface Module	EXE
FJ32-14C061-AD.vbf	Range Rover Evoque (L538)	FCDIM - Front Control/Display Interface Module	DATA
FJ32-14C061-AE.vbf	Range Rover Evoque (L538)	FCDIM - Front Control/Display Interface Module	DATA
FJ32-14C061-AF.vbf	Range Rover Evoque (L538)	FCDIM - Front Control/Display Interface Module	DATA
FJ32-14C061-AG.vbf	Range Rover Evoque (L538)	FCDIM - Front Control/Display Interface Module	DATA
FJ32-14C061-AH.vbf	Range Rover Evoque (L538)	FCDIM - Front Control/Display Interface Module	DATA
FJ32-14C061-AJ.vbf	Range Rover Evoque (L538)	FCDIM - Front Control/Display Interface Module	DATA
FJ32-14C061-AK.vbf	Range Rover Evoque (L538)	FCDIM - Front Control/Display Interface Module	DATA
FJ32-14C063-AA.vbf	Range Rover Evoque (L538)	FCDIM - Front Control/Display Interface Module	SBL
FJ32-14C088-CB.vbf	Range Rover Evoque (L538)	IPC - Instrument Panel Cluster (IPC) Control Module	EXE
FJ32-14C088-CC.vbf	Range Rover Evoque (L538)	IPC - Instrument Panel Cluster (IPC) Control Module	EXE
FJ32-14C105-AB.vbf	Range Rover Evoque (L538)	TMC Traffic Message Channel Module	DATA
FJ32-14C105-AC.vbf	Range Rover Evoque (L538)	TMC Traffic Message Channel Module	DATA
FJ32-14C105-AE.vbf	Range Rover Evoque (L538)	TMC Traffic Message Channel Module	DATA
FJ32-14C105-BB.vbf	Range Rover Evoque (L538)	TMC Traffic Message Channel Module	DATA
FJ32-14C105-BC.vbf	Range Rover Evoque (L538)	TMC Traffic Message Channel Module	DATA
FJ32-14C105-BD.vbf	Range Rover Evoque (L538)	TMC Traffic Message Channel Module	DATA
FJ32-14C105-BF.vbf	Range Rover Evoque (L538)	TMC Traffic Message Channel Module	DATA
FJ32-14C121-AA.vbf	Range Rover Evoque (L538)	RGTM - Rear Gate / Trunk Module	EXE
FJ32-14C122-AA.vbf	Range Rover Evoque (L538)	RGTM - Rear Gate / Trunk Module	DATA
FJ32-14C124-AA.vbf	Range Rover Evoque (L538)	RGTM - Rear Gate / Trunk Module	SBL
FJ32-14C185-AB.vbf	Range Rover Evoque (L538)	BCM - Body Control Module	DATA
FJ32-14C337-CGC.vbf	Range Rover Evoque (L538)	TCM - Transmission Control Module	EXE
FJ32-14C621-AD.vbf	Range Rover Evoque (L538)	FCDIM - Front Control/Display Interface Module	EXE
FJ3M-14C204-MAA.vbf	Check in SDD (unconfirmed)	PCM - Powertrain Control Module	EXE
FJ3M-14C204-MKB.vbf	Range Rover Evoque (L538)	PCM - Powertrain Control Module	EXE
FJ3M-14C218-AA.vbf	Check in SDD (unconfirmed)	PSCM - Power Steering Control Module	EXE
FJ3M-14C543-AA.vbf	Check in SDD (unconfirmed)	SUMB - Suspension Control Module B	DATA
FK52-12K532-NAC.vbf	Range Rover (L405)	PCM - Powertrain Control Module	DATA
FK52-12K532-NCC.vbf	Range Rover (L405)	PCM - Powertrain Control Module	DATA

File name	Vehicle line (indicative)	Module (ECU)	Type
FK52-12K532-NRC.vbf	Range Rover (L405)	PCM - Powertrain Control Module	DATA
FK52-14C037-AAD.vbf	Range Rover (L405)	SPCM - Secondary Powertrain Control Module	EXE
FK52-14C037-AAF.vbf	Range Rover (L405)	SPCM - Secondary Powertrain Control Module	EXE
FK52-14C037-AAH.vbf	Range Rover (L405)	SPCM - Secondary Powertrain Control Module	EXE
FK52-14C037-ABD.vbf	Range Rover (L405)	SPCM - Secondary Powertrain Control Module	EXE
FK52-14C037-ABF.vbf	Range Rover (L405)	SPCM - Secondary Powertrain Control Module	EXE
FK52-14C037-ABH.vbf	Range Rover (L405)	SPCM - Secondary Powertrain Control Module	EXE
FK52-14C037-ACD.vbf	Range Rover (L405)	SPCM - Secondary Powertrain Control Module	EXE
FK52-14C037-ACF.vbf	Range Rover (L405)	SPCM - Secondary Powertrain Control Module	EXE
FK52-14C037-ACH.vbf	Range Rover (L405)	SPCM - Secondary Powertrain Control Module	EXE
FK52-14C037-ADD.vbf	Range Rover (L405)	SPCM - Secondary Powertrain Control Module	EXE
FK52-14C037-ADF.vbf	Range Rover (L405)	SPCM - Secondary Powertrain Control Module	EXE
FK52-14C037-ADH.vbf	Range Rover (L405)	SPCM - Secondary Powertrain Control Module	EXE
FK52-14C037-AED.vbf	Range Rover (L405)	SPCM - Secondary Powertrain Control Module	EXE
FK52-14C037-AEF.vbf	Range Rover (L405)	SPCM - Secondary Powertrain Control Module	EXE
FK52-14C037-AEH.vbf	Range Rover (L405)	SPCM - Secondary Powertrain Control Module	EXE
FK52-14C037-AMD.vbf	Range Rover (L405)	SPCM - Secondary Powertrain Control Module	EXE
FK52-14C037-AMF.vbf	Range Rover (L405)	SPCM - Secondary Powertrain Control Module	EXE
FK52-14C037-AMH.vbf	Range Rover (L405)	SPCM - Secondary Powertrain Control Module	EXE
FK52-14C037-AND.vbf	Range Rover (L405)	SPCM - Secondary Powertrain Control Module	EXE
FK52-14C037-ANF.vbf	Range Rover (L405)	SPCM - Secondary Powertrain Control Module	EXE
FK52-14C037-ANH.vbf	Range Rover (L405)	SPCM - Secondary Powertrain Control Module	EXE
FK52-14C037-APD.vbf	Range Rover (L405)	SPCM - Secondary Powertrain Control Module	EXE
FK52-14C037-APF.vbf	Range Rover (L405)	SPCM - Secondary Powertrain Control Module	EXE
FK52-14C037-APH.vbf	Range Rover (L405)	SPCM - Secondary Powertrain Control Module	EXE
FK52-14C037-ATD.vbf	Range Rover (L405)	SPCM - Secondary Powertrain Control Module	EXE
FK52-14C037-ATF.vbf	Range Rover (L405)	SPCM - Secondary Powertrain Control Module	EXE
FK52-14C037-ATH.vbf	Range Rover (L405)	SPCM - Secondary Powertrain Control Module	EXE
FK52-14C037-AUE.vbf	Range Rover (L405)	ABS - Anit-Lock Brake System (ABS) Control Module	EXE
FK52-14C037-AVD.vbf	Range Rover (L405)	SPCM - Secondary Powertrain Control Module	EXE
FK52-14C037-AVF.vbf	Range Rover (L405)	SPCM - Secondary Powertrain Control Module	EXE
FK52-14C037-AVH.vbf	Range Rover (L405)	SPCM - Secondary Powertrain Control Module	EXE
FK52-14C037-DAD.vbf	Range Rover (L405)	SPCM - Secondary Powertrain Control Module	EXE
FK52-14C037-DAF.vbf	Range Rover (L405)	SPCM - Secondary Powertrain Control Module	EXE
FK52-14C037-DAH.vbf	Range Rover (L405)	SPCM - Secondary Powertrain Control Module	EXE
FK52-14C037-DKD.vbf	Range Rover (L405)	SPCM - Secondary Powertrain Control Module	EXE
FK52-14C037-DKF.vbf	Range Rover (L405)	SPCM - Secondary Powertrain Control Module	EXE
FK52-14C037-DKH.vbf	Range Rover (L405)	SPCM - Secondary Powertrain Control Module	EXE
FK52-14C037-YAA.vbf	Range Rover (L405)	SPCM - Secondary Powertrain Control Module	EXE
FK52-14C037-YBA.vbf	Range Rover (L405)	SPCM - Secondary Powertrain Control Module	EXE
FK52-14C037-YCA.vbf	Range Rover (L405)	SPCM - Secondary Powertrain Control Module	EXE
FK52-14C037-YDA.vbf	Range Rover (L405)	SPCM - Secondary Powertrain Control Module	EXE
FK52-14C037-YEA.vbf	Range Rover (L405)	SPCM - Secondary Powertrain Control Module	EXE
FK52-14C037-YMA.vbf	Range Rover (L405)	SPCM - Secondary Powertrain Control Module	EXE
FK52-14C037-YNA.vbf	Range Rover (L405)	SPCM - Secondary Powertrain Control Module	EXE
FK52-14C037-YPA.vbf	Range Rover (L405)	SPCM - Secondary Powertrain Control Module	EXE
FK52-14C037-YTA.vbf	Range Rover (L405)	SPCM - Secondary Powertrain Control Module	EXE
FK52-14C037-YVA.vbf	Range Rover (L405)	SPCM - Secondary Powertrain Control Module	EXE
FK52-14C037-ZAA.vbf	Range Rover (L405)	SPCM - Secondary Powertrain Control Module	EXE
FK52-14C037-ZKA.vbf	Range Rover (L405)	SPCM - Secondary Powertrain Control Module	EXE
FK52-14C045-BA.vbf	Range Rover (L405)	ICM - Infotainment Control Module	DATA
FK52-14C091-AE.vbf	Range Rover (L405)	PAM - Parking Assist Control Module	DATA
FK52-14C091-AJ.vbf	Range Rover (L405)	PAM - Parking Assist Control Module	DATA
FK52-14C105-AC.vbf	Range Rover (L405)	TMC Traffic Message Channel Module	DATA
FK52-14C105-AE.vbf	Range Rover (L405)	TMC Traffic Message Channel Module	DATA
FK52-14C105-BC.vbf	Range Rover (L405)	TMC Traffic Message Channel Module	DATA
FK52-14C105-BE.vbf	Range Rover (L405)	TMC Traffic Message Channel Module	DATA
FK52-14C121-AA.vbf	Range Rover (L405)	RGTM - Rear Gate / Trunk Module	EXE
FK52-14C121-AB.vbf	Range Rover (L405)	RGTM - Rear Gate / Trunk Module	EXE
FK52-14C122-AA.vbf	Range Rover (L405)	RGTM - Rear Gate / Trunk Module	DATA
FK52-14C122-AB.vbf	Range Rover (L405)	RGTM - Rear Gate / Trunk Module	DATA
FK52-14C124-AA.vbf	Range Rover (L405)	RGTM - Rear Gate / Trunk Module	SBL
FK52-14C169-AA.vbf	Range Rover (L405)	PBM - Park Brake Control Module	EXE
FK52-14C185-AB.vbf	Range Rover (L405)	BCM - Body Control Module	DATA
FK52-14C204-MBA.vbf	Range Rover (L405)	PCM - Powertrain Control Module	EXE
FK52-14C204-RAB.vbf	Range Rover (L405)	PCM - Powertrain Control Module	EXE
FK52-14C204-RAC.vbf	Range Rover (L405)	PCM - Powertrain Control Module	EXE
FK52-14C204-RAD.vbf	Range Rover (L405)	PCM - Powertrain Control Module	EXE
FK52-14C204-RCB.vbf	Range Rover (L405)	PCM - Powertrain Control Module	EXE
FK52-14C204-RCC.vbf	Range Rover (L405)	PCM - Powertrain Control Module	EXE
FK52-14C204-RCD.vbf	Range Rover (L405)	PCM - Powertrain Control Module	EXE
FK52-14C204-RCE.vbf	Range Rover (L405)	PCM - Powertrain Control Module	EXE
FK52-14C204-REB.vbf	Range Rover (L405)	PCM - Powertrain Control Module	EXE
FK52-14C204-REC.vbf	Range Rover (L405)	PCM - Powertrain Control Module	EXE
FK52-14C204-RED.vbf	Range Rover (L405)	PCM - Powertrain Control Module	EXE
FK52-14C204-RGB.vbf	Range Rover (L405)	PCM - Powertrain Control Module	EXE

File name	Vehicle line (indicative)	Module (ECU)	Type
FK52-14C204-RGC.vbf	Range Rover (L405)	PCM - Powertrain Control Module	EXE
FK52-14C204-RGD.vbf	Range Rover (L405)	PCM - Powertrain Control Module	EXE
FK52-14C204-RTB.vbf	Range Rover (L405)	PCM - Powertrain Control Module	EXE
FK52-14C204-RTC.vbf	Range Rover (L405)	PCM - Powertrain Control Module	EXE
FK52-14C204-RTD.vbf	Range Rover (L405)	PCM - Powertrain Control Module	EXE
FK52-14C204-RTE.vbf	Range Rover (L405)	PCM - Powertrain Control Module	EXE
FK52-14D049-AA.vbf	Range Rover (L405)	CCM - Cruise Control Module	EXE
FK52-14D520-AA.vbf	Range Rover (L405)	HVAC - HVAC Control Module	DATA
FK52-14E094-JAC.vbf	Range Rover (L405)	CHCM - Chassis Control Module	EXE
FK52-14E094-JAD.vbf	Range Rover (L405)	CHCM - Chassis Control Module	EXE
FK52-14E094-JBC.vbf	Range Rover (L405)	CHCM - Chassis Control Module	EXE
FK52-14E094-JBD.vbf	Range Rover (L405)	CHCM - Chassis Control Module	EXE
FK52-14E094-JCC.vbf	Range Rover (L405)	CHCM - Chassis Control Module	EXE
FK52-14E094-JCD.vbf	Range Rover (L405)	CHCM - Chassis Control Module	EXE
FK52-14E094-JDC.vbf	Range Rover (L405)	CHCM - Chassis Control Module	EXE
FK52-14E094-JDD.vbf	Range Rover (L405)	CHCM - Chassis Control Module	EXE
FK52-14E094-JEC.vbf	Range Rover (L405)	CHCM - Chassis Control Module	EXE
FK52-14E094-JED.vbf	Range Rover (L405)	CHCM - Chassis Control Module	EXE
FK52-14E094-JFD.vbf	Range Rover (L405)	CHCM - Chassis Control Module	EXE
FK52-14E094-JFE.vbf	Range Rover (L405)	CHCM - Chassis Control Module	EXE
FK52-14E094-JGC.vbf	Range Rover (L405)	CHCM - Chassis Control Module	EXE
FK52-14E094-JGD.vbf	Range Rover (L405)	CHCM - Chassis Control Module	EXE
FK52-14E094-JHC.vbf	Range Rover (L405)	CHCM - Chassis Control Module	EXE
FK52-14E094-JHD.vbf	Range Rover (L405)	CHCM - Chassis Control Module	EXE
FK52-14E094-JJC.vbf	Range Rover (L405)	CHCM - Chassis Control Module	EXE
FK52-14E094-JJD.vbf	Range Rover (L405)	CHCM - Chassis Control Module	EXE
FK52-14E094-JKC.vbf	Range Rover (L405)	CHCM - Chassis Control Module	EXE
FK52-14E094-JKD.vbf	Range Rover (L405)	CHCM - Chassis Control Module	EXE
FK52-14E094-JLD.vbf	Range Rover (L405)	CHCM - Chassis Control Module	EXE
FK52-14E094-JLE.vbf	Range Rover (L405)	CHCM - Chassis Control Module	EXE
FK52-14E094-JMF.vbf	Range Rover (L405)	CHCM - Chassis Control Module	EXE
FK52-14E094-JMG.vbf	Range Rover (L405)	CHCM - Chassis Control Module	EXE
FK52-14E094-JRA.vbf	Range Rover (L405)	CHCM - Chassis Control Module	EXE
FK52-14F435-LAA.vbf	Range Rover (L405)	CHCMB - Chassis Control Module B	EXE
FK52-14F435-LBA.vbf	Range Rover (L405)	CHCMB - Chassis Control Module B	EXE
FK52-14F435-LCA.vbf	Range Rover (L405)	CHCMB - Chassis Control Module B	EXE
FK52-14F435-LDA.vbf	Range Rover (L405)	CHCMB - Chassis Control Module B	EXE
FK52-14F435-NAB.vbf	Range Rover (L405)	CHCMB - Chassis Control Module B	EXE
FK52-14F435-NBB.vbf	Range Rover (L405)	CHCMB - Chassis Control Module B	EXE
FK52-14F435-NCB.vbf	Range Rover (L405)	CHCMB - Chassis Control Module B	EXE
FK52-14F435-NDB.vbf	Range Rover (L405)	CHCMB - Chassis Control Module B	EXE
FK52-14F671-AA.vbf	Range Rover (L405)	RGTMB - Rear Gate / Trunk Module	EXE
FK52-14F671-AC.vbf	Range Rover (L405)	RGTMB - Rear Gate / Trunk Module	EXE
FK52-14F672-AA.vbf	Range Rover (L405)	RGTMB - Rear Gate / Trunk Module	DATA
FK52-14F672-AB.vbf	Range Rover (L405)	RGTM - Rear Gate / Trunk Module	DATA
FK52-14F673-AA.vbf	Range Rover (L405)	RGTMB - Rear Gate / Trunk Module	SBL
FK52-7J104-BAC.vbf	Range Rover (L405)	TCM - Transmission Control Module	EXE
FK52-7J104-BAD.vbf	Range Rover (L405)	TCM - Transmission Control Module	EXE
FK52-7J104-BBC.vbf	Range Rover (L405)	TCM - Transmission Control Module	EXE
FK52-7J104-BBD.vbf	Range Rover (L405)	TCM - Transmission Control Module	EXE
FK52-7J104-BBE.vbf	Range Rover (L405)	TCM - Transmission Control Module	EXE
FK52-7J104-BBF.vbf	Range Rover (L405)	TCM - Transmission Control Module	EXE
FK52-7J104-BDE.vbf	Range Rover (L405)	TCM - Transmission Control Module	EXE
FK52-7J104-BDF.vbf	Range Rover (L405)	TCM - Transmission Control Module	EXE
FK52-7J104-BDG.vbf	Range Rover (L405)	TCM - Transmission Control Module	EXE
FK52-7J104-BFD.vbf	Range Rover (L405)	TCM - Transmission Control Module	EXE
FK52-7J104-BFE.vbf	Range Rover (L405)	TCM - Transmission Control Module	EXE
FK52-7J104-BGB.vbf	Range Rover (L405)	TCM - Transmission Control Module	EXE
FK52-7J104-BGD.vbf	Range Rover (L405)	TCM - Transmission Control Module	EXE
FK52-7J104-BGE.vbf	Range Rover (L405)	TCM - Transmission Control Module	EXE
FK52-7J104-BHD.vbf	Range Rover (L405)	TCM - Transmission Control Module	EXE
FK52-7J104-BHE.vbf	Range Rover (L405)	TCM - Transmission Control Module	EXE
FK5M-14E094-JPC.vbf	Not specified	CHCM - Chassis Control Module	EXE
FK5M-14E094-JPD.vbf	Not specified	CHCM - Chassis Control Module	EXE
FK5M-14F531-AA.vbf	Not specified	GWM - Gateway Module A	DATA
FK62-12K532-NAC.vbf	Range Rover Sport (L494)	PCM - Powertrain Control Module	DATA
FK62-12K532-NCC.vbf	Range Rover Sport (L494)	PCM - Powertrain Control Module	DATA
FK62-12K532-NRC.vbf	Range Rover Sport (L494)	PCM - Powertrain Control Module	DATA
FK62-12K532-PEE.vbf	Range Rover Sport (L494)	PCM - Powertrain Control Module	DATA
FK62-12K532-PEF.vbf	Range Rover Sport (L494)	PCM - Powertrain Control Module	DATA
FK62-12K532-PEG.vbf	Range Rover Sport (L494)	PCM - Powertrain Control Module	DATA
FK62-12K532-PEH.vbf	Range Rover Sport (L494)	PCM - Powertrain Control Module	DATA
FK62-12K532-PFE.vbf	Range Rover Sport (L494)	PCM - Powertrain Control Module	DATA
FK62-12K532-PFF.vbf	Range Rover Sport (L494)	PCM - Powertrain Control Module	DATA
FK62-12K532-PFG.vbf	Range Rover Sport (L494)	PCM - Powertrain Control Module	DATA
FK62-12K532-PFH.vbf	Range Rover Sport (L494)	PCM - Powertrain Control Module	DATA

File name	Vehicle line (indicative)	Module (ECU)	Type
FK62-12K532-PGE.vbf	Range Rover Sport (L494)	PCM - Powertrain Control Module	DATA
FK62-12K532-PGF.vbf	Range Rover Sport (L494)	PCM - Powertrain Control Module	DATA
FK62-12K532-PGG.vbf	Range Rover Sport (L494)	PCM - Powertrain Control Module	DATA
FK62-12K532-PGH.vbf	Range Rover Sport (L494)	PCM - Powertrain Control Module	DATA
FK62-12K532-PHE.vbf	Range Rover Sport (L494)	PCM - Powertrain Control Module	DATA
FK62-12K532-PHF.vbf	Range Rover Sport (L494)	PCM - Powertrain Control Module	DATA
FK62-12K532-PHG.vbf	Range Rover Sport (L494)	PCM - Powertrain Control Module	DATA
FK62-12K532-PHH.vbf	Range Rover Sport (L494)	PCM - Powertrain Control Module	DATA
FK62-12K532-PUE.vbf	Range Rover Sport (L494)	PCM - Powertrain Control Module	DATA
FK62-12K532-PUF.vbf	Range Rover Sport (L494)	PCM - Powertrain Control Module	DATA
FK62-12K532-PUG.vbf	Range Rover Sport (L494)	PCM - Powertrain Control Module	DATA
FK62-12K532-PUH.vbf	Range Rover Sport (L494)	PCM - Powertrain Control Module	DATA
FK62-14C037-AAD.vbf	Range Rover Sport (L494)	SPCM - Secondary Powertrain Control Module	EXE
FK62-14C037-AAF.vbf	Range Rover Sport (L494)	SPCM - Secondary Powertrain Control Module	EXE
FK62-14C037-AAH.vbf	Range Rover Sport (L494)	SPCM - Secondary Powertrain Control Module	EXE
FK62-14C037-ABD.vbf	Range Rover Sport (L494)	SPCM - Secondary Powertrain Control Module	EXE
FK62-14C037-ABF.vbf	Range Rover Sport (L494)	SPCM - Secondary Powertrain Control Module	EXE
FK62-14C037-ABH.vbf	Range Rover Sport (L494)	SPCM - Secondary Powertrain Control Module	EXE
FK62-14C037-ACD.vbf	Range Rover Sport (L494)	SPCM - Secondary Powertrain Control Module	EXE
FK62-14C037-ACF.vbf	Range Rover Sport (L494)	SPCM - Secondary Powertrain Control Module	EXE
FK62-14C037-ACH.vbf	Range Rover Sport (L494)	SPCM - Secondary Powertrain Control Module	EXE
FK62-14C037-ADD.vbf	Range Rover Sport (L494)	SPCM - Secondary Powertrain Control Module	EXE
FK62-14C037-ADF.vbf	Range Rover Sport (L494)	SPCM - Secondary Powertrain Control Module	EXE
FK62-14C037-ADH.vbf	Range Rover Sport (L494)	SPCM - Secondary Powertrain Control Module	EXE
FK62-14C037-AED.vbf	Range Rover Sport (L494)	SPCM - Secondary Powertrain Control Module	EXE
FK62-14C037-AEF.vbf	Range Rover Sport (L494)	SPCM - Secondary Powertrain Control Module	EXE
FK62-14C037-AEH.vbf	Range Rover Sport (L494)	SPCM - Secondary Powertrain Control Module	EXE
FK62-14C037-AFD.vbf	Range Rover Sport (L494)	SPCM - Secondary Powertrain Control Module	EXE
FK62-14C037-AFF.vbf	Range Rover Sport (L494)	SPCM - Secondary Powertrain Control Module	EXE
FK62-14C037-AFH.vbf	Range Rover Sport (L494)	SPCM - Secondary Powertrain Control Module	EXE
FK62-14C037-AGD.vbf	Range Rover Sport (L494)	SPCM - Secondary Powertrain Control Module	EXE
FK62-14C037-AGF.vbf	Range Rover Sport (L494)	SPCM - Secondary Powertrain Control Module	EXE
FK62-14C037-AGH.vbf	Range Rover Sport (L494)	SPCM - Secondary Powertrain Control Module	EXE
FK62-14C037-AKD.vbf	Range Rover Sport (L494)	SPCM - Secondary Powertrain Control Module	EXE
FK62-14C037-AKF.vbf	Range Rover Sport (L494)	SPCM - Secondary Powertrain Control Module	EXE
FK62-14C037-AKH.vbf	Range Rover Sport (L494)	SPCM - Secondary Powertrain Control Module	EXE
FK62-14C037-ARE.vbf	Range Rover Sport (L494)	ABS - Anit-Lock Brake System (ABS) Control Module	EXE
FK62-14C037-AVD.vbf	Range Rover Sport (L494)	SPCM - Secondary Powertrain Control Module	EXE
FK62-14C037-AVF.vbf	Range Rover Sport (L494)	SPCM - Secondary Powertrain Control Module	EXE
FK62-14C037-AVH.vbf	Range Rover Sport (L494)	SPCM - Secondary Powertrain Control Module	EXE
FK62-14C037-DJD.vbf	Range Rover Sport (L494)	SPCM - Secondary Powertrain Control Module	EXE
FK62-14C037-DJF.vbf	Range Rover Sport (L494)	SPCM - Secondary Powertrain Control Module	EXE
FK62-14C037-DJH.vbf	Range Rover Sport (L494)	SPCM - Secondary Powertrain Control Module	EXE
FK62-14C037-YAA.vbf	Range Rover Sport (L494)	SPCM - Secondary Powertrain Control Module	EXE
FK62-14C037-YBA.vbf	Range Rover Sport (L494)	SPCM - Secondary Powertrain Control Module	EXE
FK62-14C037-YCA.vbf	Range Rover Sport (L494)	SPCM - Secondary Powertrain Control Module	EXE
FK62-14C037-YDA.vbf	Range Rover Sport (L494)	SPCM - Secondary Powertrain Control Module	EXE
FK62-14C037-YEA.vbf	Range Rover Sport (L494)	SPCM - Secondary Powertrain Control Module	EXE
FK62-14C037-YFA.vbf	Range Rover Sport (L494)	SPCM - Secondary Powertrain Control Module	EXE
FK62-14C037-YGA.vbf	Range Rover Sport (L494)	SPCM - Secondary Powertrain Control Module	EXE
FK62-14C037-YKA.vbf	Range Rover Sport (L494)	SPCM - Secondary Powertrain Control Module	EXE
FK62-14C037-YVA.vbf	Range Rover Sport (L494)	SPCM - Secondary Powertrain Control Module	EXE
FK62-14C037-ZJA.vbf	Range Rover Sport (L494)	SPCM - Secondary Powertrain Control Module	EXE
FK62-14C045-BA.vbf	Range Rover Sport (L494)	ICM - Infotainment Control Module	DATA
FK62-14C060-AD.vbf	Range Rover Sport (L494)	FCDIM - Front Control/Display Interface Module	EXE
FK62-14C060-AE.vbf	Range Rover Sport (L494)	FCDIM - Front Control/Display Interface Module	EXE
FK62-14C060-AF.vbf	Range Rover Sport (L494)	FCDIM - Front Control/Display Interface Module	EXE
FK62-14C060-AG.vbf	Range Rover Sport (L494)	FCDIM - Front Control/Display Interface Module	EXE
FK62-14C060-AH.vbf	Range Rover Sport (L494)	FCDIM - Front Control/Display Interface Module	EXE
FK62-14C060-AJ.vbf	Range Rover Sport (L494)	FCDIM - Front Control/Display Interface Module	EXE
FK62-14C060-AK.vbf	Range Rover Sport (L494)	FCDIM - Front Control/Display Interface Module	EXE
FK62-14C060-BD.vbf	Range Rover Sport (L494)	FCDIM - Front Control/Display Interface Module	EXE
FK62-14C060-BE.vbf	Range Rover Sport (L494)	FCDIM - Front Control/Display Interface Module	EXE
FK62-14C060-BF.vbf	Range Rover Sport (L494)	FCDIM - Front Control/Display Interface Module	EXE
FK62-14C060-BG.vbf	Range Rover Sport (L494)	FCDIM - Front Control/Display Interface Module	EXE
FK62-14C060-BH.vbf	Range Rover Sport (L494)	FCDIM - Front Control/Display Interface Module	EXE
FK62-14C060-BJ.vbf	Range Rover Sport (L494)	FCDIM - Front Control/Display Interface Module	EXE
FK62-14C060-BK.vbf	Range Rover Sport (L494)	FCDIM - Front Control/Display Interface Module	EXE
FK62-14C060-CB.vbf	Range Rover Sport (L494)	FCDIM - Front Control/Display Interface Module	EXE
FK62-14C060-CC.vbf	Range Rover Sport (L494)	FCDIM - Front Control/Display Interface Module	EXE
FK62-14C060-CD.vbf	Range Rover Sport (L494)	FCDIM - Front Control/Display Interface Module	EXE
FK62-14C060-CE.vbf	Range Rover Sport (L494)	FCDIM - Front Control/Display Interface Module	EXE
FK62-14C060-CF.vbf	Range Rover Sport (L494)	FCDIM - Front Control/Display Interface Module	EXE
FK62-14C060-CG.vbf	Range Rover Sport (L494)	FCDIM - Front Control/Display Interface Module	EXE
FK62-14C060-CH.vbf	Range Rover Sport (L494)	FCDIM - Front Control/Display Interface Module	EXE
FK62-14C060-DB.vbf	Range Rover Sport (L494)	FCDIM - Front Control/Display Interface Module	EXE

File name	Vehicle line (indicative)	Module (ECU)	Type
FK62-14C060-DC.vbf	Range Rover Sport (L494)	FCDIM - Front Control/Display Interface Module	EXE
FK62-14C060-DD.vbf	Range Rover Sport (L494)	FCDIM - Front Control/Display Interface Module	EXE
FK62-14C060-DE.vbf	Range Rover Sport (L494)	FCDIM - Front Control/Display Interface Module	EXE
FK62-14C060-DF.vbf	Range Rover Sport (L494)	FCDIM - Front Control/Display Interface Module	EXE
FK62-14C060-DG.vbf	Range Rover Sport (L494)	FCDIM - Front Control/Display Interface Module	EXE
FK62-14C060-DH.vbf	Range Rover Sport (L494)	FCDIM - Front Control/Display Interface Module	EXE
FK62-14C061-AD.vbf	Range Rover Sport (L494)	FCDIM - Front Control/Display Interface Module	DATA
FK62-14C061-AF.vbf	Range Rover Sport (L494)	FCDIM - Front Control/Display Interface Module	DATA
FK62-14C061-AG.vbf	Range Rover Sport (L494)	FCDIM - Front Control/Display Interface Module	DATA
FK62-14C061-AH.vbf	Range Rover Sport (L494)	FCDIM - Front Control/Display Interface Module	DATA
FK62-14C061-AJ.vbf	Range Rover Sport (L494)	FCDIM - Front Control/Display Interface Module	DATA
FK62-14C061-AK.vbf	Range Rover Sport (L494)	FCDIM - Front Control/Display Interface Module	DATA
FK62-14C061-CB.vbf	Range Rover Sport (L494)	FCDIM - Front Control/Display Interface Module	DATA
FK62-14C061-CD.vbf	Range Rover Sport (L494)	FCDIM - Front Control/Display Interface Module	DATA
FK62-14C061-CE.vbf	Range Rover Sport (L494)	FCDIM - Front Control/Display Interface Module	DATA
FK62-14C061-CF.vbf	Range Rover Sport (L494)	FCDIM - Front Control/Display Interface Module	DATA
FK62-14C061-CG.vbf	Range Rover Sport (L494)	FCDIM - Front Control/Display Interface Module	DATA
FK62-14C061-CH.vbf	Range Rover Sport (L494)	FCDIM - Front Control/Display Interface Module	DATA
FK62-14C063-AA.vbf	Range Rover Sport (L494)	FCDIM - Front Control/Display Interface Module	SBL
FK62-14C063-CA.vbf	Range Rover Sport (L494)	FCDIM - Front Control/Display Interface Module	SBL
FK62-14C091-AE.vbf	Range Rover Sport (L494)	PAM - Parking Assist Control Module	DATA
FK62-14C091-AH.vbf	Range Rover Sport (L494)	PAM - Parking Assist Control Module	DATA
FK62-14C105-AB.vbf	Range Rover Sport (L494)	TMC Traffic Message Channel Module	DATA
FK62-14C105-AD.vbf	Range Rover Sport (L494)	TMC Traffic Message Channel Module	DATA
FK62-14C105-BB.vbf	Range Rover Sport (L494)	TMC Traffic Message Channel Module	DATA
FK62-14C105-BD.vbf	Range Rover Sport (L494)	TMC Traffic Message Channel Module	DATA
FK62-14C121-AB.vbf	Range Rover Sport (L494)	RGTM - Rear Gate / Trunk Module	EXE
FK62-14C122-AB.vbf	Range Rover Sport (L494)	RGTM - Rear Gate / Trunk Module	DATA
FK62-14C124-AA.vbf	Range Rover Sport (L494)	RGTM - Rear Gate / Trunk Module	SBL
FK62-14C169-AA.vbf	Range Rover Sport (L494)	PBM - Park Brake Control Module	EXE
FK62-14C185-AB.vbf	Range Rover Sport (L494)	BCM - Body Control Module	DATA
FK62-14C204-EAE.vbf	Range Rover Sport (L494)	PCM - Powertrain Control Module	EXE
FK62-14C204-EAF.vbf	Range Rover Sport (L494)	PCM - Powertrain Control Module	EXE
FK62-14C204-ECC.vbf	Range Rover Sport (L494)	PCM - Powertrain Control Module	EXE
FK62-14C204-ECD.vbf	Range Rover Sport (L494)	PCM - Powertrain Control Module	EXE
FK62-14C204-ECE.vbf	Range Rover Sport (L494)	PCM - Powertrain Control Module	EXE
FK62-14C204-EED.vbf	Range Rover Sport (L494)	PCM - Powertrain Control Module	EXE
FK62-14C204-EEE.vbf	Range Rover Sport (L494)	PCM - Powertrain Control Module	EXE
FK62-14C204-ETE.vbf	Range Rover Sport (L494)	PCM - Powertrain Control Module	EXE
FK62-14C204-ETF.vbf	Range Rover Sport (L494)	PCM - Powertrain Control Module	EXE
FK62-14C204-ETG.vbf	Range Rover Sport (L494)	PCM - Powertrain Control Module	EXE
FK62-14C204-MBA.vbf	Range Rover Sport (L494)	PCM - Powertrain Control Module	EXE
FK62-14C204-TEC.vbf	Range Rover Sport (L494)	PCM - Powertrain Control Module	EXE
FK62-14C204-TED.vbf	Range Rover Sport (L494)	PCM - Powertrain Control Module	EXE
FK62-14C204-TEE.vbf	Range Rover Sport (L494)	PCM - Powertrain Control Module	EXE
FK62-14C621-AD.vbf	Range Rover Sport (L494)	FCDIM - Front Control/Display Interface Module	EXE
FK62-14C621-CA.vbf	Range Rover Sport (L494)	FCDIM - Front Control/Display Interface Module	EXE
FK62-14D520-AA.vbf	Range Rover Sport (L494)	HVAC - HVAC Control Module	DATA
FK62-14E094-HAC.vbf	Range Rover Sport (L494)	CHCM - Chassis Control Module	EXE
FK62-14E094-HAD.vbf	Range Rover Sport (L494)	CHCM - Chassis Control Module	EXE
FK62-14E094-HBC.vbf	Range Rover Sport (L494)	CHCM - Chassis Control Module	EXE
FK62-14E094-HBD.vbf	Range Rover Sport (L494)	CHCM - Chassis Control Module	EXE
FK62-14E094-HCF.vbf	Range Rover Sport (L494)	CHCM - Chassis Control Module	EXE
FK62-14E094-HCG.vbf	Range Rover Sport (L494)	CHCM - Chassis Control Module	EXE
FK62-14E094-JAC.vbf	Range Rover Sport (L494)	CHCM - Chassis Control Module	EXE
FK62-14E094-JAD.vbf	Range Rover Sport (L494)	CHCM - Chassis Control Module	EXE
FK62-14E094-JBC.vbf	Range Rover Sport (L494)	CHCM - Chassis Control Module	EXE
FK62-14E094-JBD.vbf	Range Rover Sport (L494)	CHCM - Chassis Control Module	EXE
FK62-14E094-JCC.vbf	Range Rover Sport (L494)	CHCM - Chassis Control Module	EXE
FK62-14E094-JCD.vbf	Range Rover Sport (L494)	CHCM - Chassis Control Module	EXE
FK62-14E094-JDC.vbf	Range Rover Sport (L494)	CHCM - Chassis Control Module	EXE
FK62-14E094-JDD.vbf	Range Rover Sport (L494)	CHCM - Chassis Control Module	EXE
FK62-14E094-JEC.vbf	Range Rover Sport (L494)	CHCM - Chassis Control Module	EXE
FK62-14E094-JED.vbf	Range Rover Sport (L494)	CHCM - Chassis Control Module	EXE
FK62-14E094-JFD.vbf	Range Rover Sport (L494)	CHCM - Chassis Control Module	EXE
FK62-14E094-JFE.vbf	Range Rover Sport (L494)	CHCM - Chassis Control Module	EXE
FK62-14E094-JGC.vbf	Range Rover Sport (L494)	CHCM - Chassis Control Module	EXE
FK62-14E094-JGD.vbf	Range Rover Sport (L494)	CHCM - Chassis Control Module	EXE
FK62-14E094-JGE.vbf	Range Rover Sport (L494)	CHCM - Chassis Control Module	EXE
FK62-14F435-LAA.vbf	Range Rover Sport (L494)	CHCMB - Chassis Control Module B	EXE
FK62-14F435-LBA.vbf	Range Rover Sport (L494)	CHCMB - Chassis Control Module B	EXE
FK62-14F435-LCA.vbf	Range Rover Sport (L494)	CHCMB - Chassis Control Module B	EXE
FK62-14F435-NAB.vbf	Range Rover Sport (L494)	CHCMB - Chassis Control Module B	EXE
FK62-14F435-NBB.vbf	Range Rover Sport (L494)	CHCMB - Chassis Control Module B	EXE
FK62-14F435-NCB.vbf	Range Rover Sport (L494)	CHCMB - Chassis Control Module B	EXE
FK62-7J104-BBC.vbf	Range Rover Sport (L494)	TCM - Transmission Control Module	EXE

File name	Vehicle line (indicative)	Module (ECU)	Type
FK62-7J104-BBD.vbf	Range Rover Sport (L494)	TCM - Transmission Control Module	EXE
FK62-7J104-BBE.vbf	Range Rover Sport (L494)	TCM - Transmission Control Module	EXE
FK62-7J104-BCD.vbf	Range Rover Sport (L494)	TCM - Transmission Control Module	EXE
FK62-7J104-BCE.vbf	Range Rover Sport (L494)	TCM - Transmission Control Module	EXE
FK62-7J104-BDE.vbf	Range Rover Sport (L494)	TCM - Transmission Control Module	EXE
FK62-7J104-BDF.vbf	Range Rover Sport (L494)	TCM - Transmission Control Module	EXE
FK62-7J104-BDG.vbf	Range Rover Sport (L494)	TCM - Transmission Control Module	EXE
FK62-7J104-BFD.vbf	Range Rover Sport (L494)	TCM - Transmission Control Module	EXE
FK62-7J104-BFE.vbf	Range Rover Sport (L494)	TCM - Transmission Control Module	EXE
FK62-7J104-BGD.vbf	Range Rover Sport (L494)	TCM - Transmission Control Module	EXE
FK62-7J104-BGE.vbf	Range Rover Sport (L494)	TCM - Transmission Control Module	EXE
FK62-7J104-BHD.vbf	Range Rover Sport (L494)	TCM - Transmission Control Module	EXE
FK62-7J104-BHE.vbf	Range Rover Sport (L494)	TCM - Transmission Control Module	EXE
FK62-7J104-BKE.vbf	Range Rover Sport (L494)	TCM - Transmission Control Module	EXE
FK62-7J104-BKF.vbf	Range Rover Sport (L494)	TCM - Transmission Control Module	EXE
FK62-7J104-BKG.vbf	Range Rover Sport (L494)	TCM - Transmission Control Module	EXE
FK62-7J104-BMB.vbf	Range Rover Sport (L494)	TCM - Transmission Control Module	EXE
FK6M-14C034-AC.vbf	Range Rover Sport (L494)	DSM - Driver Front Seat Module	DATA
FK6M-14C034-BA.vbf	Range Rover Sport (L494)	DSM - Driver Front Seat Module	DATA
FK6M-14C218-AA.vbf	Range Rover Sport (L494)	PSCM - Power Steering Control Module	EXE
FK6M-14C549-AC.vbf	Range Rover Sport (L494)	PSM - Passenger Front Seat Module	DATA
FK6M-14C549-BA.vbf	Range Rover Sport (L494)	PSM - Passenger Front Seat Module	DATA
FK6M-14D023-AA.vbf	Range Rover Sport (L494)	ATCM - All Terrain Control Module	SIGCFG
FK6M-14D024-AA.vbf	Range Rover Sport (L494)	ATCM - All Terrain Control Module	EXE
FK6M-14E094-JHC.vbf	Range Rover Sport (L494)	CHCM - Chassis Control Module	EXE
FK6M-14F022-AA.vbf	Range Rover Sport (L494)	IPMB - Image Processing Module B	DATA
FK6M-14F435-NEB.vbf	Range Rover Sport (L494)	CHCMB - Chassis Control Module B	EXE
FK72-12K532-VAD.vbf	Discovery Sport (L550)	PCM - Powertrain Control Module	DATA
FK72-12K532-VAE.vbf	Discovery Sport (L550)	PCM - Powertrain Control Module	DATA
FK72-12K532-VBC.vbf	Discovery Sport (L550)	PCM - Powertrain Control Module	DATA
FK72-12K532-VCC.vbf	Discovery Sport (L550)	PCM - Powertrain Control Module	DATA
FK72-12K532-VDD.vbf	Discovery Sport (L550)	PCM - Powertrain Control Module	DATA
FK72-12K532-VDE.vbf	Discovery Sport (L550)	PCM - Powertrain Control Module	DATA
FK72-12K532-VED.vbf	Discovery Sport (L550)	PCM - Powertrain Control Module	DATA
FK72-12K532-VEE.vbf	Discovery Sport (L550)	PCM - Powertrain Control Module	DATA
FK72-12K532-VFC.vbf	Discovery Sport (L550)	PCM - Powertrain Control Module	DATA
FK72-12K532-VHC.vbf	Discovery Sport (L550)	PCM - Powertrain Control Module	DATA
FK72-12K532-VJD.vbf	Discovery Sport (L550)	PCM - Powertrain Control Module	DATA
FK72-12K532-VJE.vbf	Discovery Sport (L550)	PCM - Powertrain Control Module	DATA
FK72-12K532-VKD.vbf	Discovery Sport (L550)	PCM - Powertrain Control Module	DATA
FK72-12K532-VKE.vbf	Discovery Sport (L550)	PCM - Powertrain Control Module	DATA
FK72-12K532-VMD.vbf	Discovery Sport (L550)	PCM - Powertrain Control Module	DATA
FK72-12K532-VME.vbf	Discovery Sport (L550)	PCM - Powertrain Control Module	DATA
FK72-12K532-VND.vbf	Discovery Sport (L550)	PCM - Powertrain Control Module	DATA
FK72-12K532-VNE.vbf	Discovery Sport (L550)	PCM - Powertrain Control Module	DATA
FK72-12K532-VPD.vbf	Discovery Sport (L550)	PCM - Powertrain Control Module	DATA
FK72-12K532-VPE.vbf	Discovery Sport (L550)	PCM - Powertrain Control Module	DATA
FK72-12K532-VRE.vbf	Discovery Sport (L550)	PCM - Powertrain Control Module	DATA
FK72-12K532-VRF.vbf	Discovery Sport (L550)	PCM - Powertrain Control Module	DATA
FK72-12K532-VSD.vbf	Discovery Sport (L550)	PCM - Powertrain Control Module	DATA
FK72-12K532-VSE.vbf	Discovery Sport (L550)	PCM - Powertrain Control Module	DATA
FK72-12K532-VTD.vbf	Discovery Sport (L550)	PCM - Powertrain Control Module	DATA
FK72-12K532-VTE.vbf	Discovery Sport (L550)	PCM - Powertrain Control Module	DATA
FK72-14C026-AF.vbf	Discovery Sport (L550)	IPC - Instrument Panel Cluster (IPC) Control Module	EXE
FK72-14C026-AH.vbf	Discovery Sport (L550)	IPC - Instrument Panel Cluster (IPC) Control Module	EXE
FK72-14C026-AJ.vbf	Discovery Sport (L550)	IPC - Instrument Panel Cluster (IPC) Control Module	EXE
FK72-14C026-AK.vbf	Discovery Sport (L550)	IPC - Instrument Panel Cluster (IPC) Control Module	EXE
FK72-14C027-AA.vbf	Discovery Sport (L550)	RCM - Restraints Control Module	SBL
FK72-14C028-AG.vbf	Discovery Sport (L550)	RCM - Restraints Control Module	EXE
FK72-14C028-AH.vbf	Discovery Sport (L550)	RCM - Restraints Control Module	EXE
FK72-14C028-AJ.vbf	Discovery Sport (L550)	RCM - Restraints Control Module	EXE
FK72-14C028-AK.vbf	Discovery Sport (L550)	RCM - Restraints Control Module	EXE
FK72-14C028-AL.VBF	Discovery Sport (L550)	RCM - Restraints Control Module	EXE
FK72-14C030-AE.vbf	Discovery Sport (L550)	DSM - Driver Front Seat Module	EXE
FK72-14C034-AA.vbf	Discovery Sport (L550)	DSM - Driver Front Seat Module	DATA
FK72-14C036-AG.vbf	Discovery Sport (L550)	ABS - Anit-Lock Brake System (ABS) Control Module	EXE
FK72-14C036-AH.vbf	Discovery Sport (L550)	ABS - Anit-Lock Brake System (ABS) Control Module	EXE
FK72-14C036-AJ.vbf	Discovery Sport (L550)	ABS - Anit-Lock Brake System (ABS) Control Module	EXE
FK72-14C036-AK.vbf	Discovery Sport (L550)	ABS - Anit-Lock Brake System (ABS) Control Module	EXE
FK72-14C039-AA.vbf	Discovery Sport (L550)	ABS - Anit-Lock Brake System (ABS) Control Module	SBL
FK72-14C045-BM.vbf	Discovery Sport (L550)	ICM - Infotainment Control Module	DATA
FK72-14C045-BN.vbf	Discovery Sport (L550)	ICM - Infotainment Control Module	DATA
FK72-14C045-BP.vbf	Discovery Sport (L550)	ICM - Infotainment Control Module	DATA
FK72-14C045-BR.vbf	Discovery Sport (L550)	ICM - Infotainment Control Module	DATA
FK72-14C045-BS.vbf	Discovery Sport (L550)	ICM - Infotainment Control Module	DATA
FK72-14C060-AD.vbf	Discovery Sport (L550)	FCDIM - Front Control/Display Interface Module	EXE

File name	Vehicle line (indicative)	Module (ECU)	Type
FK72-14C060-AE.vbf	Discovery Sport (L550)	FCDIM - Front Control/Display Interface Module	EXE
FK72-14C060-AF.vbf	Discovery Sport (L550)	FCDIM - Front Control/Display Interface Module	EXE
FK72-14C060-AG.vbf	Discovery Sport (L550)	FCDIM - Front Control/Display Interface Module	EXE
FK72-14C060-AH.vbf	Discovery Sport (L550)	FCDIM - Front Control/Display Interface Module	EXE
FK72-14C060-AJ.vbf	Discovery Sport (L550)	FCDIM - Front Control/Display Interface Module	EXE
FK72-14C060-BD.vbf	Discovery Sport (L550)	FCDIM - Front Control/Display Interface Module	EXE
FK72-14C060-BE.vbf	Discovery Sport (L550)	FCDIM - Front Control/Display Interface Module	EXE
FK72-14C060-BF.vbf	Discovery Sport (L550)	FCDIM - Front Control/Display Interface Module	EXE
FK72-14C060-BG.vbf	Discovery Sport (L550)	FCDIM - Front Control/Display Interface Module	EXE
FK72-14C060-BH.vbf	Discovery Sport (L550)	FCDIM - Front Control/Display Interface Module	EXE
FK72-14C060-BJ.vbf	Discovery Sport (L550)	FCDIM - Front Control/Display Interface Module	EXE
FK72-14C061-AD.vbf	Discovery Sport (L550)	FCDIM - Front Control/Display Interface Module	DATA
FK72-14C061-AE.vbf	Discovery Sport (L550)	FCDIM - Front Control/Display Interface Module	DATA
FK72-14C061-AF.vbf	Discovery Sport (L550)	FCDIM - Front Control/Display Interface Module	DATA
FK72-14C061-AG.vbf	Discovery Sport (L550)	FCDIM - Front Control/Display Interface Module	DATA
FK72-14C061-AH.vbf	Discovery Sport (L550)	FCDIM - Front Control/Display Interface Module	DATA
FK72-14C061-AJ.vbf	Discovery Sport (L550)	FCDIM - Front Control/Display Interface Module	DATA
FK72-14C063-AB.vbf	Discovery Sport (L550)	FCDIM - Front Control/Display Interface Module	SBL
FK72-14C064-AE.vbf	Discovery Sport (L550)	DDM - Driver Front Door Module	EXE
FK72-14C064-BE.vbf	Discovery Sport (L550)	DDM - Driver Front Door Module	EXE
FK72-14C065-AF.vbf	Discovery Sport (L550)	DDM - Driver Front Door Module	DATA
FK72-14C065-AG.vbf	Discovery Sport (L550)	DDM - Driver Front Door Module	DATA
FK72-14C065-AH.vbf	Discovery Sport (L550)	DDM - Driver Front Door Module	DATA
FK72-14C065-AJ.vbf	Discovery Sport (L550)	DDM - Driver Front Door Module	DATA
FK72-14C065-AK.vbf	Discovery Sport (L550)	DDM - Driver Front Door Module	DATA
FK72-14C068-AD.vbf	Discovery Sport (L550)	DRDM - Driver Rear Door Module	EXE
FK72-14C068-BD.vbf	Discovery Sport (L550)	DRDM - Driver Rear Door Module	EXE
FK72-14C069-AE.vbf	Discovery Sport (L550)	DRDM - Driver Rear Door Module	DATA
FK72-14C069-AF.vbf	Discovery Sport (L550)	DRDM - Driver Rear Door Module	DATA
FK72-14C069-AG.vbf	Discovery Sport (L550)	DRDM - Driver Rear Door Module	DATA
FK72-14C069-AH.vbf	Discovery Sport (L550)	DRDM - Driver Rear Door Module	DATA
FK72-14C069-AJ.vbf	Discovery Sport (L550)	DRDM - Driver Rear Door Module	DATA
FK72-14C088-CF.vbf	Discovery Sport (L550)	IPC - Instrument Panel Cluster (IPC) Control Module	EXE
FK72-14C088-CH.vbf	Discovery Sport (L550)	IPC - Instrument Panel Cluster (IPC) Control Module	EXE
FK72-14C088-CJ.vbf	Discovery Sport (L550)	IPC - Instrument Panel Cluster (IPC) Control Module	EXE
FK72-14C088-DA.vbf	Discovery Sport (L550)	IPC - Instrument Panel Cluster (IPC) Control Module	EXE
FK72-14C088-DB.vbf	Discovery Sport (L550)	IPC - Instrument Panel Cluster (IPC) Control Module	EXE
FK72-14C091-AN.vbf	Discovery Sport (L550)	PAM - Parking Assist Control Module	DATA
FK72-14C091-AP.vbf	Discovery Sport (L550)	PAM - Parking Assist Control Module	DATA
FK72-14C091-AR.vbf	Discovery Sport (L550)	PAM - Parking Assist Control Module	DATA
FK72-14C091-AS.vbf	Discovery Sport (L550)	PAM - Parking Assist Control Module	DATA
FK72-14C091-AU.vbf	Discovery Sport (L550)	PAM - Parking Assist Control Module	DATA
FK72-14C091-AV.vbf	Discovery Sport (L550)	PAM - Parking Assist Control Module	DATA
FK72-14C098-AE.vbf	Discovery Sport (L550)	RCM - Restraints Control Module	DATA
FK72-14C098-AF.vbf	Discovery Sport (L550)	RCM - Restraints Control Module	DATA
FK72-14C098-AG.vbf	Discovery Sport (L550)	RCM - Restraints Control Module	DATA
FK72-14C098-BF.vbf	Discovery Sport (L550)	RCM - Restraints Control Module	DATA
FK72-14C098-BG.vbf	Discovery Sport (L550)	RCM - Restraints Control Module	DATA
FK72-14C098-BH.vbf	Discovery Sport (L550)	RCM - Restraints Control Module	DATA
FK72-14C098-BJ.VBF	Discovery Sport (L550)	RCM - Restraints Control Module	DATA
FK72-14C104-AD.vbf	Discovery Sport (L550)	TMC Traffic Message Channel Module	EXE
FK72-14C104-AF.vbf	Discovery Sport (L550)	TMC Traffic Message Channel Module	EXE
FK72-14C104-AG.vbf	Discovery Sport (L550)	TMC Traffic Message Channel Module	EXE
FK72-14C104-AH.vbf	Discovery Sport (L550)	TMC Traffic Message Channel Module	EXE
FK72-14C104-AM.vbf	Discovery Sport (L550)	TMC Traffic Message Channel Module	EXE
FK72-14C104-AN.vbf	Discovery Sport (L550)	TMC Traffic Message Channel Module	EXE
FK72-14C104-AP.vbf	Discovery Sport (L550)	TMC Traffic Message Channel Module	EXE
FK72-14C104-AR.vbf	Discovery Sport (L550)	TMC Traffic Message Channel Module	EXE
FK72-14C104-BB.vbf	Discovery Sport (L550)	TMC Traffic Message Channel Module	EXE
FK72-14C104-KC.vbf	Discovery Sport (L550)	TMC Traffic Message Channel Module	EXE
FK72-14C104-KF.vbf	Discovery Sport (L550)	TMC Traffic Message Channel Module	EXE
FK72-14C104-KG.vbf	Discovery Sport (L550)	TMC Traffic Message Channel Module	EXE
FK72-14C104-KH.vbf	Discovery Sport (L550)	TMC Traffic Message Channel Module	EXE
FK72-14C104-KM.vbf	Discovery Sport (L550)	TMC Traffic Message Channel Module	EXE
FK72-14C104-KN.vbf	Discovery Sport (L550)	TMC Traffic Message Channel Module	EXE
FK72-14C104-KP.vbf	Discovery Sport (L550)	TMC Traffic Message Channel Module	EXE
FK72-14C104-KR.vbf	Discovery Sport (L550)	TMC Traffic Message Channel Module	EXE
FK72-14C104-SB.vbf	Discovery Sport (L550)	TMC Traffic Message Channel Module	EXE
FK72-14C105-AE.vbf	Discovery Sport (L550)	TMC Traffic Message Channel Module	DATA
FK72-14C105-AF.vbf	Discovery Sport (L550)	TMC Traffic Message Channel Module	DATA
FK72-14C105-AG.vbf	Discovery Sport (L550)	TMC Traffic Message Channel Module	DATA
FK72-14C105-BD.vbf	Discovery Sport (L550)	TMC Traffic Message Channel Module	DATA
FK72-14C105-CB.vbf	Discovery Sport (L550)	TMC Traffic Message Channel Module	DATA
FK72-14C105-CC.vbf	Discovery Sport (L550)	TMC Traffic Message Channel Module	DATA
FK72-14C105-CD.vbf	Discovery Sport (L550)	TMC Traffic Message Channel Module	DATA
FK72-14C105-DB.vbf	Discovery Sport (L550)	TMC Traffic Message Channel Module	DATA

File name	Vehicle line (indicative)	Module (ECU)	Type
FK72-14C107-AA.vbf	Discovery Sport (L550)	TMC Traffic Message Channel Module	SBL
FK72-14C107-AB.vbf	Discovery Sport (L550)	TMC Traffic Message Channel Module	SBL
FK72-14C107-AC.vbf	Discovery Sport (L550)	TMC Traffic Message Channel Module	SBL
FK72-14C108-AD.vbf	Discovery Sport (L550)	PDM - Passenger Front Door Module	EXE
FK72-14C108-BD.vbf	Discovery Sport (L550)	PDM - Passenger Front Door Module	EXE
FK72-14C109-AE.vbf	Discovery Sport (L550)	PDM - Passenger Front Door Module	DATA
FK72-14C109-AF.vbf	Discovery Sport (L550)	PDM - Passenger Front Door Module	DATA
FK72-14C109-AG.vbf	Discovery Sport (L550)	PDM - Passenger Front Door Module	DATA
FK72-14C109-AH.vbf	Discovery Sport (L550)	PDM - Passenger Front Door Module	DATA
FK72-14C109-AJ.vbf	Discovery Sport (L550)	PDM - Passenger Front Door Module	DATA
FK72-14C112-AD.vbf	Discovery Sport (L550)	PRDM - Passenger Rear Door Module	EXE
FK72-14C112-BD.vbf	Discovery Sport (L550)	PRDM - Passenger Rear Door Module	EXE
FK72-14C113-AE.vbf	Discovery Sport (L550)	PRDM - Passenger Rear Door Module	DATA
FK72-14C113-AF.vbf	Discovery Sport (L550)	PRDM - Passenger Rear Door Module	DATA
FK72-14C113-AG.vbf	Discovery Sport (L550)	PRDM - Passenger Rear Door Module	DATA
FK72-14C113-AH.vbf	Discovery Sport (L550)	PRDM - Passenger Rear Door Module	DATA
FK72-14C113-AJ.vbf	Discovery Sport (L550)	PRDM - Passenger Rear Door Module	DATA
FK72-14C121-AC.vbf	Discovery Sport (L550)	RGTM - Rear Gate / Trunk Module	EXE
FK72-14C122-AC.vbf	Discovery Sport (L550)	RGTM - Rear Gate / Trunk Module	DATA
FK72-14C122-AD.vbf	Discovery Sport (L550)	RGTM - Rear Gate / Trunk Module	DATA
FK72-14C124-AA.vbf	Discovery Sport (L550)	RGTM - Rear Gate / Trunk Module	SBL
FK72-14C152-AD.vbf	Discovery Sport (L550)	TPM - Tire Pressure Monitor Module	DATA
FK72-14C152-AE.vbf	Discovery Sport (L550)	TPM - Tire Pressure Monitor Module	DATA
FK72-14C185-AE.VBF	Discovery Sport (L550)	BCM - Body Control Module	DATA
FK72-14C204-MAF.vbf	Discovery Sport (L550)	PCM - Powertrain Control Module	EXE
FK72-14C204-MAG.vbf	Discovery Sport (L550)	PCM - Powertrain Control Module	EXE
FK72-14C204-MAH.vbf	Discovery Sport (L550)	ECM - Engine Control Module	EXE
FK72-14C204-MBF.vbf	Discovery Sport (L550)	PCM - Powertrain Control Module	EXE
FK72-14C204-MCF.vbf	Discovery Sport (L550)	PCM - Powertrain Control Module	EXE
FK72-14C204-MEF.vbf	Discovery Sport (L550)	PCM - Powertrain Control Module	EXE
FK72-14C204-MKF.vbf	Discovery Sport (L550)	PCM - Powertrain Control Module	EXE
FK72-14C204-MZF.vbf	Discovery Sport (L550)	PCM - Powertrain Control Module	EXE
FK72-14C204-MZG.vbf	Discovery Sport (L550)	PCM - Powertrain Control Module	EXE
FK72-14C204-MZH.vbf	Discovery Sport (L550)	ECM - Engine Control Module	EXE
FK72-14C204-VB.vbf	Discovery Sport (L550)	PCM - Powertrain Control Module	EXE
FK72-14C217-AB.vbf	Discovery Sport (L550)	PSCM - Power Steering Control Module	EXE
FK72-14C218-AB.vbf	Discovery Sport (L550)	PSCM - Power Steering Control Module	EXE
FK72-14C218-BA.vbf	Discovery Sport (L550)	PSCM - Power Steering Control Module	EXE
FK72-14C305-AB.vbf	Discovery Sport (L550)	ACM - Audio Front Control Module	SBL
FK72-14C305-AD.vbf	Discovery Sport (L550)	ACM - Audio Front Control Module	SBL
FK72-14C305-AE.vbf	Discovery Sport (L550)	ACM - Audio Front Control Module	SBL
FK72-14C305-AF.vbf	Discovery Sport (L550)	ACM - Audio Front Control Module	SBL
FK72-14C337-CAD.vbf	Discovery Sport (L550)	TCM - Transmission Control Module	EXE
FK72-14C337-CAE.vbf	Discovery Sport (L550)	TCM - Transmission Control Module	EXE
FK72-14C337-CAF.vbf	Discovery Sport (L550)	TCM - Transmission Control Module	EXE
FK72-14C337-CAG.vbf	Discovery Sport (L550)	TCM - Transmission Control Module	EXE
FK72-14C337-CAH.vbf	Discovery Sport (L550)	TCM - Transmission Control Module	EXE
FK72-14C337-CAJ.vbf	Discovery Sport (L550)	TCM - Transmission Control Module	EXE
FK72-14C337-CBD.vbf	Discovery Sport (L550)	TCM - Transmission Control Module	EXE
FK72-14C337-CBE.vbf	Discovery Sport (L550)	TCM - Transmission Control Module	EXE
FK72-14C337-CBF.vbf	Discovery Sport (L550)	TCM - Transmission Control Module	EXE
FK72-14C337-CBG.vbf	Discovery Sport (L550)	TCM - Transmission Control Module	EXE
FK72-14C337-CBH.vbf	Discovery Sport (L550)	TCM - Transmission Control Module	EXE
FK72-14C337-CBJ.vbf	Discovery Sport (L550)	TCM - Transmission Control Module	EXE
FK72-14C355-AD.vbf	Discovery Sport (L550)	Not specified	EXE
FK72-14C355-BD.vbf	Discovery Sport (L550)	Not specified	EXE
FK72-14C407-AF.vbf	Discovery Sport (L550)	RCM - Restraints Control Module	SIGCFG
FK72-14C417-AF.vbf	Discovery Sport (L550)	ACM - Audio Front Control Module	SIGCFG
FK72-14C417-AG.vbf	Discovery Sport (L550)	ACM - Audio Front Control Module	SIGCFG
FK72-14C417-AH.vbf	Discovery Sport (L550)	ACM - Audio Front Control Module	SIGCFG
FK72-14C417-BG.vbf	Discovery Sport (L550)	ACM - Audio Front Control Module	SIGCFG
FK72-14C417-BH.vbf	Discovery Sport (L550)	ACM - Audio Front Control Module	SIGCFG
FK72-14C417-BJ.vbf	Discovery Sport (L550)	ACM - Audio Front Control Module	SIGCFG
FK72-14C417-BK.vbf	Discovery Sport (L550)	ACM - Audio Front Control Module	SIGCFG
FK72-14C527-AD.vbf	Discovery Sport (L550)	Not specified	DATA
FK72-14C527-BD.vbf	Discovery Sport (L550)	Not specified	DATA
FK72-14C534-AC.vbf	Discovery Sport (L550)	HVAC - HVAC Control Module	SIGCFG
FK72-14C534-AD.vbf	Range Rover Evoque (L538)	HVAC - HVAC Control Module	SIGCFG
FK72-14C535-AF.vbf	Discovery Sport (L550)	HVAC - HVAC Control Module	EXE
FK72-14C535-AG.vbf	Discovery Sport (L550)	HVAC - HVAC Control Module	EXE
FK72-14C536-AG.vbf	Discovery Sport (L550)	HVAC - HVAC Control Module	DATA
FK72-14C536-AH.vbf	Discovery Sport (L550)	HVAC - HVAC Control Module	DATA
FK72-14C536-BB.vbf	Discovery Sport (L550)	HVAC - HVAC Control Module	DATA
FK72-14C536-BC.vbf	Discovery Sport (L550)	HVAC - HVAC Control Module	DATA
FK72-14C542-AB.vbf	Discovery Sport (L550)	SUMB - Suspension Control Module B	EXE
FK72-14C543-AE.vbf	Discovery Sport (L550)	SUMB - Suspension Control Module B	DATA

File name	Vehicle line (indicative)	Module (ECU)	Type
FK72-14C548-AE.vbf	Discovery Sport (L550)	PSM - Passenger Front Seat Module	EXE
FK72-14C549-AA.vbf	Discovery Sport (L550)	PSM - Passenger Front Seat Module	DATA
FK72-14C609-AB.vbf	Discovery Sport (L550)	PSCM - Power Steering Control Module	EXE
FK72-14C621-AD.vbf	Discovery Sport (L550)	FCDIM - Front Control/Display Interface Module	EXE
FK72-14C653-AG.vbf	Discovery Sport (L550)	ACM - Audio Front Control Module	DATA
FK72-14C653-AJ.vbf	Discovery Sport (L550)	ACM - Audio Front Control Module	DATA
FK72-14C653-AK.vbf	Discovery Sport (L550)	ACM - Audio Front Control Module	DATA
FK72-14C653-AL.vbf	Discovery Sport (L550)	ACM - Audio Front Control Module	DATA
FK72-14C653-AM.vbf	Discovery Sport (L550)	ACM - Audio Front Control Module	DATA
FK72-14D023-AC.VBF	Discovery Sport (L550)	ATCM - All Terrain Control Module	SIGCFG
FK72-14D023-AD.vbf	Discovery Sport (L550)	ATCM - All Terrain Control Module	SIGCFG
FK72-14D024-AG.vbf	Discovery Sport (L550)	ATCM - All Terrain Control Module	EXE
FK72-14D024-AH.vbf	Discovery Sport (L550)	ATCM - All Terrain Control Module	EXE
FK72-14D026-AF.vbf	Discovery Sport (L550)	ATCM - All Terrain Control Module	SBL
FK72-14D181-AB.vbf	Discovery Sport (L550)	OCS - Restraints Occupant Classification System Module	DATA
FK72-14D182-AB.vbf	Discovery Sport (L550)	OCS - Restraints Occupant Classification System Module	EXE
FK72-14D183-BB.vbf	Discovery Sport (L550)	OCS - Restraints Occupant Classification System Module	DATA
FK72-14D368-AC.vbf	Discovery Sport (L550)	SODL - Side Obstacle Detection Control Module - Left	EXE
FK72-14D480-CC.vbf	Discovery Sport (L550)	IPMB - Image Processing Module B	EXE
FK72-14D480-CH.vbf	Discovery Sport (L550)	IPMB - Image Processing Module B	EXE
FK72-14D480-CJ.vbf	Discovery Sport (L550)	IPMB - Image Processing Module B	EXE
FK72-14D481-BB.vbf	Discovery Sport (L550)	IPMB - Image Processing Module B	DATA
FK72-14D481-DB.vbf	Discovery Sport (L550)	IPMB - Image Processing Module B	DATA
FK72-14D485-AB.vbf	Discovery Sport (L550)	IPMB - Image Processing Module B	DATA
FK72-14D485-AD.vbf	Discovery Sport (L550)	IPMB - Image Processing Module B	DATA
FK72-14D564-AA.vbf	Discovery Sport (L550)	SODL - Side Obstacle Detection Control Module - Left	DATA
FK72-14D564-BA.vbf	Discovery Sport (L550)	SODR - Side Obstacle Detection Control Module - Right	DATA
FK72-14F019-AB.vbf	Discovery Sport (L550)	IPMB - Image Processing Module B	SBL
FK72-14F022-AE.vbf	Discovery Sport (L550)	IPMB - Image Processing Module B	DATA
FK72-14F022-AF.vbf	Discovery Sport (L550)	IPMB - Image Processing Module B	DATA
FK72-14F022-AG.vbf	Discovery Sport (L550)	IPMB - Image Processing Module B	DATA
FK72-14F022-AJ.vbf	Discovery Sport (L550)	IPMB - Image Processing Module B	DATA
FK72-14F022-BD.vbf	Discovery Sport (L550)	IPMB - Image Processing Module B	DATA
FK72-14F022-BE.vbf	Discovery Sport (L550)	IPMB - Image Processing Module B	DATA
FK72-14F022-BF.vbf	Discovery Sport (L550)	IPMB - Image Processing Module B	DATA
FK72-14F022-BG.vbf	Discovery Sport (L550)	IPMB - Image Processing Module B	DATA
FK72-14F022-BH.vbf	Discovery Sport (L550)	IPMB - Image Processing Module B	DATA
FK72-14F231-AB.vbf	Discovery Sport (L550)	HUD - Head Up Display	CUSTOM
FK72-14F231-AC.vbf	Discovery Sport (L550)	HUD - Head Up Display	CUSTOM
FK72-14F231-BA.vbf	Discovery Sport (L550)	HUD - Head Up Display	CUSTOM
FK72-14F397-AG.vbf	Discovery Sport (L550)	IPMA - Image Processing Module A	EXE
FK72-14F397-AH.vbf	Discovery Sport (L550)	IPMA - Image Processing Module A	EXE
FK72-14F397-AJ.vbf	Discovery Sport (L550)	IPMA - Image Processing Module A	EXE
FK72-14F397-AK.vbf	Discovery Sport (L550)	IPMA - Image Processing Module A	EXE
FK72-14F397-BG.vbf	Discovery Sport (L550)	IPMA - Image Processing Module A	EXE
FK72-14F397-BH.vbf	Discovery Sport (L550)	IPMA - Image Processing Module A	EXE
FK72-14F397-BJ.vbf	Discovery Sport (L550)	IPMA - Image Processing Module A	EXE
FK72-14F397-BK.vbf	Discovery Sport (L550)	IPMA - Image Processing Module A	EXE
FK72-14F397-CF.vbf	Discovery Sport (L550)	IPMA - Image Processing Module A	EXE
FK72-14F397-CG.vbf	Discovery Sport (L550)	IPMA - Image Processing Module A	EXE
FK72-14F397-CH.vbf	Discovery Sport (L550)	IPMA - Image Processing Module A	EXE
FK72-14F397-CJ.vbf	Discovery Sport (L550)	IPMA - Image Processing Module A	EXE
FK72-14F397-DF.vbf	Discovery Sport (L550)	IPMA - Image Processing Module A	EXE
FK72-14F397-DG.vbf	Discovery Sport (L550)	IPMA - Image Processing Module A	EXE
FK72-14F397-DH.vbf	Discovery Sport (L550)	IPMA - Image Processing Module A	EXE
FK72-14F397-DJ.vbf	Discovery Sport (L550)	IPMA - Image Processing Module A	EXE
FK72-14F398-AF.vbf	Discovery Sport (L550)	IPMA - Image Processing Module A	EXE
FK72-14F398-AG.vbf	Discovery Sport (L550)	IPMA - Image Processing Module A	EXE
FK72-14F398-AJ.vbf	Discovery Sport (L550)	IPMA - Image Processing Module A	EXE
FK72-14F398-AK.vbf	Discovery Sport (L550)	IPMA - Image Processing Module A	EXE
FK72-14F398-AL.vbf	Discovery Sport (L550)	IPMA - Image Processing Module A	EXE
FK72-14F398-BF.vbf	Discovery Sport (L550)	IPMA - Image Processing Module A	EXE
FK72-14F398-BG.vbf	Discovery Sport (L550)	IPMA - Image Processing Module A	EXE
FK72-14F398-BJ.vbf	Discovery Sport (L550)	IPMA - Image Processing Module A	EXE
FK72-14F398-BK.vbf	Discovery Sport (L550)	IPMA - Image Processing Module A	EXE
FK72-14F398-BL.vbf	Discovery Sport (L550)	IPMA - Image Processing Module A	EXE
FK72-14F530-AF.vbf	Discovery Sport (L550)	GWM - Gateway Module A	EXE
FK72-14F530-AG.vbf	Discovery Sport (L550)	GWM - Gateway Module A	EXE
FK72-14F530-AH.vbf	Discovery Sport (L550)	GWM - Gateway Module A	EXE
FK72-14F530-AJ.vbf	Discovery Sport (L550)	GWM - Gateway Module A	EXE
FK72-14F531-AE.vbf	Discovery Sport (L550)	GWM - Gateway Module A	DATA
FK72-14F531-AF.vbf	Discovery Sport (L550)	GWM - Gateway Module A	DATA
FK72-14F531-AG.vbf	Discovery Sport (L550)	GWM - Gateway Module A	DATA
FK72-14F532-AA.vbf	Discovery Sport (L550)	GWM - Gateway Module A	SBL
FK72-19C293-AB.vbf	Discovery Sport (L550)	ACM - Audio Front Control Module	EXE
FK72-19C293-AC.vbf	Discovery Sport (L550)	ACM - Audio Front Control Module	EXE

File name	Vehicle line (indicative)	Module (ECU)	Type
FK72-19C293-AE.vbf	Discovery Sport (L550)	ACM - Audio Front Control Module	EXE
FK72-19C293-CB.vbf	Discovery Sport (L550)	ACM - Audio Front Control Module	DATA
FK72-19C293-CC.vbf	Discovery Sport (L550)	ACM - Audio Front Control Module	DATA
FK72-19C293-CE.vbf	Discovery Sport (L550)	ACM - Audio Front Control Module	DATA
FK72-19C295-AB.vbf	Discovery Sport (L550)	ACM - Audio Front Control Module	SBL
FK72-19C295-AE.vbf	Discovery Sport (L550)	ACM - Audio Front Control Module	SBL
FK72-70713-BN.vbf	Discovery Sport (L550)	TCU - Telematic Control Unit Module	DATA
FK72-70713-BP.vbf	Discovery Sport (L550)	TCU - Telematic Control Unit Module	DATA
FK72-70713-CN.vbf	Discovery Sport (L550)	TCU - Telematic Control Unit Module	DATA
FK72-70713-CP.vbf	Discovery Sport (L550)	TCU - Telematic Control Unit Module	DATA
FK72-70713-MN.vbf	Discovery Sport (L550)	TCU - Telematic Control Unit Module	DATA
FK72-70713-MP.vbf	Discovery Sport (L550)	TCU - Telematic Control Unit Module	DATA
FK72-70713-NN.vbf	Discovery Sport (L550)	TCU - Telematic Control Unit Module	DATA
FK72-70713-NP.vbf	Discovery Sport (L550)	TCU - Telematic Control Unit Module	DATA
FK72-7B761-AA.vbf	Discovery Sport (L550)	LSM Light Switch Module	SIGCFG
FK72-7B761-BA.vbf	Discovery Sport (L550)	LSM Light Switch Module	SIGCFG
FK72-7B762-AC.vbf	Discovery Sport (L550)	LSM Light Switch Module	EXE
FK72-7B762-AD.vbf	Discovery Sport (L550)	LSM Light Switch Module	EXE
FK72-7B762-AE.vbf	Discovery Sport (L550)	LSM Light Switch Module	EXE
FK72-7B762-BC.vbf	Jaguar X400	LSM Light Switch Module	EXE
FK72-7B762-BD.vbf	Jaguar X400	LSM Light Switch Module	EXE
FK72-7B762-BE.vbf	Jaguar X400	FLM - Front Lighting Control Module	EXE
FK72-7B763-AC.vbf	Discovery Sport (L550)	LSM Light Switch Module	DATA
FK72-7B763-AD.vbf	Discovery Sport (L550)	LSM Light Switch Module	DATA
FK72-7B763-BD.vbf	Discovery Sport (L550)	LSM Light Switch Module	DATA
FK72-7B763-BE.vbf	Discovery Sport (L550)	LSM Light Switch Module	DATA
FK72-7B763-BF.vbf	Discovery Sport (L550)	LSM Light Switch Module	DATA
FK72-7B763-BG.vbf	Discovery Sport (L550)	FLM - Front Lighting Control Module	DATA
FK72-7B763-BH.vbf	Discovery Sport (L550)	FLM - Front Lighting Control Module	DATA
FK72-7B763-BJ.vbf	Discovery Sport (L550)	FLM - Front Lighting Control Module	DATA
FK72-7B764-AA.vbf	Discovery Sport (L550)	LSM Light Switch Module	SBL
FK72-7B764-BA.vbf	Range Rover Evoque (L538)	LSM Light Switch Module	SBL
FK72-9J403-AA.vbf	Discovery Sport (L550)	GPSM - Global Positioning System Module	SIGCFG
FK72-9J404-AB.vbf	Discovery Sport (L550)	GPSM - Global Positioning System Module	EXE
FK72-9J405-AB.vbf	Discovery Sport (L550)	GPSM - Global Positioning System Module	DATA
FNDU-19C204-AA.vbf	Not specified	IMC - Infotainment Master Controller	EXE
FPLA-12K532-PEC.vbf	Multiple models (shared module)	PCM - Powertrain Control Module	DATA
FPLA-12K532-PEE.vbf	Multiple models (shared module)	PCM - Powertrain Control Module	DATA
FPLA-12K532-PEF.vbf	Multiple models (shared module)	PCM - Powertrain Control Module	DATA
FPLA-12K532-PEG.vbf	Multiple models (shared module)	PCM - Powertrain Control Module	DATA
FPLA-12K532-PEH.vbf	Multiple models (shared module)	PCM - Powertrain Control Module	DATA
FPLA-12K532-PGC.vbf	Multiple models (shared module)	PCM - Powertrain Control Module	DATA
FPLA-12K532-PGE.vbf	Multiple models (shared module)	PCM - Powertrain Control Module	DATA
FPLA-12K532-PGF.vbf	Multiple models (shared module)	PCM - Powertrain Control Module	DATA
FPLA-12K532-PGG.vbf	Multiple models (shared module)	PCM - Powertrain Control Module	DATA
FPLA-12K532-PGH.vbf	Multiple models (shared module)	PCM - Powertrain Control Module	DATA
FPLA-12K532-PHC.vbf	Multiple models (shared module)	PCM - Powertrain Control Module	DATA
FPLA-12K532-PHE.vbf	Multiple models (shared module)	PCM - Powertrain Control Module	DATA
FPLA-12K532-PHF.vbf	Multiple models (shared module)	PCM - Powertrain Control Module	DATA
FPLA-12K532-PHG.vbf	Multiple models (shared module)	PCM - Powertrain Control Module	DATA
FPLA-12K532-PHH.vbf	Multiple models (shared module)	PCM - Powertrain Control Module	DATA
FPLA-12K532-PVC.vbf	Multiple models (shared module)	PCM - Powertrain Control Module	DATA
FPLA-12K532-PVE.vbf	Multiple models (shared module)	PCM - Powertrain Control Module	DATA
FPLA-12K532-PVF.vbf	Multiple models (shared module)	PCM - Powertrain Control Module	DATA
FPLA-12K532-PVG.vbf	Multiple models (shared module)	PCM - Powertrain Control Module	DATA
FPLA-12K532-PVH.vbf	Multiple models (shared module)	PCM - Powertrain Control Module	DATA
FPLA-14C026-AC.vbf	Multiple models (shared module)	IPC - Instrument Panel Cluster (IPC) Control Module	EXE
FPLA-14C026-AD.vbf	Multiple models (shared module)	IPC - Instrument Panel Cluster (IPC) Control Module	EXE
FPLA-14C026-BA.vbf	Multiple models (shared module)	IPC - Instrument Panel Cluster (IPC) Control Module	EXE
FPLA-14C026-CA.vbf	Multiple models (shared module)	IPC - Instrument Panel Cluster (IPC) Control Module	EXE
FPLA-14C026-EB.vbf	Multiple models (shared module)	IPC - Instrument Panel Cluster (IPC) Control Module	EXE
FPLA-14C030-BC.vbf	Range Rover Sport (L494)	DSM - Driver Front Seat Module	EXE
FPLA-14C034-CA.vbf	Range Rover Sport (L494)	DSM - Driver Front Seat Module	DATA
FPLA-14C034-DA.vbf	Range Rover Sport (L494)	DSM - Driver Front Seat Module	DATA
FPLA-14C034-EA.vbf	Range Rover Sport (L494)	DSM - Driver Front Seat Module	DATA
FPLA-14C034-FA.vbf	Range Rover Sport (L494)	DSM - Driver Front Seat Module	DATA
FPLA-14C034-GA.vbf	Range Rover Sport (L494)	DSM - Driver Front Seat Module	DATA
FPLA-14C034-HA.vbf	Range Rover Sport (L494)	DSM - Driver Front Seat Module	DATA
FPLA-14C034-KA.vbf	Range Rover Sport (L494)	DSM - Driver Front Seat Module	DATA
FPLA-14C034-LA.vbf	Range Rover Sport (L494)	DSM - Driver Front Seat Module	DATA
FPLA-14C034-MA.vbf	Range Rover Sport (L494)	DSM - Driver Front Seat Module	DATA
FPLA-14C036-AD.vbf	Multiple models (shared module)	SPCM - Secondary Powertrain Control Module	EXE
FPLA-14C036-AF.vbf	Multiple models (shared module)	SPCM - Secondary Powertrain Control Module	EXE
FPLA-14C036-AH.vbf	Multiple models (shared module)	SPCM - Secondary Powertrain Control Module	EXE
FPLA-14C036-YA.vbf	Multiple models (shared module)	SPCM - Secondary Powertrain Control Module	EXE
FPLA-14C039-AB.vbf	Multiple models (shared module)	SPCM - Secondary Powertrain Control Module	SBL

File name	Vehicle line (indicative)	Module (ECU)	Type
FPLA-14C060-AD.vbf	Multiple models (shared module)	FCDIM - Front Control/Display Interface Module	EXE
FPLA-14C060-AF.vbf	Multiple models (shared module)	FCDIM - Front Control/Display Interface Module	EXE
FPLA-14C060-AG.vbf	Multiple models (shared module)	FCDIM - Front Control/Display Interface Module	EXE
FPLA-14C060-AH.vbf	Multiple models (shared module)	FCDIM - Front Control/Display Interface Module	EXE
FPLA-14C060-AJ.vbf	Multiple models (shared module)	FCDIM - Front Control/Display Interface Module	EXE
FPLA-14C060-AK.vbf	Multiple models (shared module)	FCDIM - Front Control/Display Interface Module	EXE
FPLA-14C060-BD.vbf	Multiple models (shared module)	FCDIM - Front Control/Display Interface Module	EXE
FPLA-14C060-BE.vbf	Multiple models (shared module)	FCDIM - Front Control/Display Interface Module	EXE
FPLA-14C060-BF.vbf	Multiple models (shared module)	FCDIM - Front Control/Display Interface Module	EXE
FPLA-14C060-BG.vbf	Multiple models (shared module)	FCDIM - Front Control/Display Interface Module	EXE
FPLA-14C060-BH.vbf	Multiple models (shared module)	FCDIM - Front Control/Display Interface Module	EXE
FPLA-14C060-BJ.vbf	Multiple models (shared module)	FCDIM - Front Control/Display Interface Module	EXE
FPLA-14C060-BK.vbf	Multiple models (shared module)	FCDIM - Front Control/Display Interface Module	EXE
FPLA-14C060-CB.vbf	Multiple models (shared module)	FCDIM - Front Control/Display Interface Module	EXE
FPLA-14C060-CC.vbf	Multiple models (shared module)	FCDIM - Front Control/Display Interface Module	EXE
FPLA-14C060-CD.vbf	Multiple models (shared module)	FCDIM - Front Control/Display Interface Module	EXE
FPLA-14C060-CE.vbf	Multiple models (shared module)	FCDIM - Front Control/Display Interface Module	EXE
FPLA-14C060-CF.vbf	Multiple models (shared module)	FCDIM - Front Control/Display Interface Module	EXE
FPLA-14C060-CG.vbf	Multiple models (shared module)	FCDIM - Front Control/Display Interface Module	EXE
FPLA-14C060-CH.vbf	Multiple models (shared module)	FCDIM - Front Control/Display Interface Module	EXE
FPLA-14C060-DB.vbf	Multiple models (shared module)	FCDIM - Front Control/Display Interface Module	EXE
FPLA-14C060-DC.vbf	Multiple models (shared module)	FCDIM - Front Control/Display Interface Module	EXE
FPLA-14C060-DD.vbf	Multiple models (shared module)	FCDIM - Front Control/Display Interface Module	EXE
FPLA-14C060-DE.vbf	Multiple models (shared module)	FCDIM - Front Control/Display Interface Module	EXE
FPLA-14C060-DF.vbf	Multiple models (shared module)	FCDIM - Front Control/Display Interface Module	EXE
FPLA-14C060-DG.vbf	Multiple models (shared module)	FCDIM - Front Control/Display Interface Module	EXE
FPLA-14C060-DH.vbf	Multiple models (shared module)	FCDIM - Front Control/Display Interface Module	EXE
FPLA-14C061-AD.vbf	Multiple models (shared module)	FCDIM - Front Control/Display Interface Module	DATA
FPLA-14C061-AF.vbf	Multiple models (shared module)	FCDIM - Front Control/Display Interface Module	DATA
FPLA-14C061-AG.vbf	Multiple models (shared module)	FCDIM - Front Control/Display Interface Module	DATA
FPLA-14C061-AH.vbf	Multiple models (shared module)	FCDIM - Front Control/Display Interface Module	DATA
FPLA-14C061-AJ.vbf	Multiple models (shared module)	FCDIM - Front Control/Display Interface Module	DATA
FPLA-14C061-AK.vbf	Multiple models (shared module)	FCDIM - Front Control/Display Interface Module	DATA
FPLA-14C061-CB.vbf	Multiple models (shared module)	FCDIM - Front Control/Display Interface Module	DATA
FPLA-14C061-CD.vbf	Multiple models (shared module)	FCDIM - Front Control/Display Interface Module	DATA
FPLA-14C061-CE.vbf	Multiple models (shared module)	FCDIM - Front Control/Display Interface Module	DATA
FPLA-14C061-CF.vbf	Multiple models (shared module)	FCDIM - Front Control/Display Interface Module	DATA
FPLA-14C061-CG.vbf	Multiple models (shared module)	FCDIM - Front Control/Display Interface Module	DATA
FPLA-14C061-CH.vbf	Multiple models (shared module)	FCDIM - Front Control/Display Interface Module	DATA
FPLA-14C063-AA.vbf	Multiple models (shared module)	FCDIM - Front Control/Display Interface Module	SBL
FPLA-14C063-CA.vbf	Multiple models (shared module)	FCDIM - Front Control/Display Interface Module	SBL
FPLA-14C088-CD.vbf	Multiple models (shared module)	IPC - Instrument Panel Cluster (IPC) Control Module	EXE
FPLA-14C088-JA.vbf	Multiple models (shared module)	IPC - Instrument Panel Cluster (IPC) Control Module	DATA
FPLA-14C088-KA.vbf	Multiple models (shared module)	IPC - Instrument Panel Cluster (IPC) Control Module	DATA
FPLA-14C204-MBC.vbf	Range Rover Sport (L494)	PCM - Powertrain Control Module	EXE
FPLA-14C204-RAB.vbf	Multiple models (shared module)	PCM - Powertrain Control Module	EXE
FPLA-14C204-RAC.vbf	Multiple models (shared module)	PCM - Powertrain Control Module	EXE
FPLA-14C204-RAD.vbf	Multiple models (shared module)	PCM - Powertrain Control Module	EXE
FPLA-14C204-RCC.vbf	Multiple models (shared module)	PCM - Powertrain Control Module	EXE
FPLA-14C204-RCD.vbf	Multiple models (shared module)	PCM - Powertrain Control Module	EXE
FPLA-14C204-RCE.vbf	Multiple models (shared module)	PCM - Powertrain Control Module	EXE
FPLA-14C204-RCF.vbf	Multiple models (shared module)	PCM - Powertrain Control Module	EXE
FPLA-14C204-REC.vbf	Multiple models (shared module)	PCM - Powertrain Control Module	EXE
FPLA-14C204-RED.vbf	Multiple models (shared module)	PCM - Powertrain Control Module	EXE
FPLA-14C204-REE.vbf	Multiple models (shared module)	PCM - Powertrain Control Module	EXE
FPLA-14C204-RGC.vbf	Multiple models (shared module)	PCM - Powertrain Control Module	EXE
FPLA-14C204-RGD.vbf	Multiple models (shared module)	PCM - Powertrain Control Module	EXE
FPLA-14C204-RGE.vbf	Multiple models (shared module)	PCM - Powertrain Control Module	EXE
FPLA-14C204-RTC.vbf	Multiple models (shared module)	PCM - Powertrain Control Module	EXE
FPLA-14C204-RTD.vbf	Multiple models (shared module)	PCM - Powertrain Control Module	EXE
FPLA-14C204-RTE.vbf	Multiple models (shared module)	PCM - Powertrain Control Module	EXE
FPLA-14C204-RTF.vbf	Multiple models (shared module)	PCM - Powertrain Control Module	EXE
FPLA-14C204-TAE.vbf	Multiple models (shared module)	PCM - Powertrain Control Module	EXE
FPLA-14C204-TAF.vbf	Multiple models (shared module)	PCM - Powertrain Control Module	EXE
FPLA-14C204-TAG.vbf	Multiple models (shared module)	PCM - Powertrain Control Module	EXE
FPLA-14C204-TCD.vbf	Multiple models (shared module)	PCM - Powertrain Control Module	EXE
FPLA-14C204-TCE.vbf	Multiple models (shared module)	PCM - Powertrain Control Module	EXE
FPLA-14C204-TCF.vbf	Multiple models (shared module)	PCM - Powertrain Control Module	EXE
FPLA-14C204-TTD.vbf	Multiple models (shared module)	PCM - Powertrain Control Module	EXE
FPLA-14C204-TTE.vbf	Multiple models (shared module)	PCM - Powertrain Control Module	EXE
FPLA-14C204-TTF.vbf	Multiple models (shared module)	PCM - Powertrain Control Module	EXE
FPLA-14C204-TTG.vbf	Multiple models (shared module)	PCM - Powertrain Control Module	EXE
FPLA-14C408-AA.vbf	Multiple models (shared module)	BCM - Body Control Module	SIGCFG
FPLA-14C413-AA.vbf	Range Rover Sport (L494)	DSM - Driver Front Seat Module	SIGCFG
FPLA-14C547-AA.vbf	Range Rover Sport (L494)	PSM - Passenger Front Seat Module	SIGCFG
FPLA-14C548-BC.vbf	Range Rover Sport (L494)	PSM - Passenger Front Seat Module	EXE

File name	Vehicle line (indicative)	Module (ECU)	Type
FPLA-14C549-CA.vbf	Range Rover Sport (L494)	PSM - Passenger Front Seat Module	DATA
FPLA-14C549-DA.vbf	Range Rover Sport (L494)	PSM - Passenger Front Seat Module	DATA
FPLA-14C549-EA.vbf	Range Rover Sport (L494)	PSM - Passenger Front Seat Module	DATA
FPLA-14C549-FA.vbf	Range Rover Sport (L494)	PSM - Passenger Front Seat Module	DATA
FPLA-14C549-GA.vbf	Range Rover Sport (L494)	PSM - Passenger Front Seat Module	DATA
FPLA-14C549-HA.vbf	Range Rover Sport (L494)	PSM - Passenger Front Seat Module	DATA
FPLA-14C549-KA.vbf	Range Rover Sport (L494)	PSM - Passenger Front Seat Module	DATA
FPLA-14C549-LA.vbf	Range Rover Sport (L494)	PSM - Passenger Front Seat Module	DATA
FPLA-14C549-MA.vbf	Range Rover Sport (L494)	PSM - Passenger Front Seat Module	DATA
FPLA-14C621-AD.vbf	Multiple models (shared module)	FCDIM - Front Control/Display Interface Module	EXE
FPLA-14C621-CA.vbf	Multiple models (shared module)	FCDIM - Front Control/Display Interface Module	EXE
FPLA-14D023-AA.vbf	Range Rover Sport (L494)	ATCM - All Terrain Control Module	SIGCFG
FPLA-14D024-AB.vbf	Range Rover Sport (L494)	ATCM - All Terrain Control Module	EXE
FPLA-14D048-AA.vbf	Range Rover Sport (L494)	CCM - Cruise Control Module	SIGCFG
FPLA-14D049-AC.vbf	Discovery Sport (L550)	CCM - Cruise Control Module	EXE
FPLA-14D049-BA.vbf	Multiple models (shared module)	CCM - Cruise Control Module	EXE
FPLA-14D519-AE.vbf	Multiple models (shared module)	HVAC - HVAC Control Module	EXE
FPLA-14D519-BA.vbf	Multiple models (shared module)	HVAC - HVAC Control Module	EXE
FPLA-14D519-BB.vbf	Multiple models (shared module)	HVAC - HVAC Control Module	EXE
FPLA-14D520-AF.vbf	Multiple models (shared module)	HVAC - HVAC Control Module	DATA
FPLA-14D520-AG.vbf	Multiple models (shared module)	HVAC - HVAC Control Module	DATA
FPLA-14D520-AH.vbf	Multiple models (shared module)	HVAC - HVAC Control Module	DATA
FPLA-14D520-AJ.vbf	Multiple models (shared module)	HVAC - HVAC Control Module	DATA
FPLA-14D520-AK.vbf	Multiple models (shared module)	HVAC - HVAC Control Module	DATA
FPLA-14D520-AL.vbf	Multiple models (shared module)	HVAC - HVAC Control Module	DATA
FPLA-14D520-AM.vbf	Multiple models (shared module)	HVAC - HVAC Control Module	DATA
FPLA-14D520-AN.vbf	Multiple models (shared module)	HVAC - HVAC Control Module	DATA
FPLA-14D520-BF.vbf	Multiple models (shared module)	HVAC - HVAC Control Module	DATA
FPLA-14D520-BG.vbf	Multiple models (shared module)	HVAC - HVAC Control Module	DATA
FPLA-14D520-CF.vbf	Multiple models (shared module)	HVAC - HVAC Control Module	DATA
FPLA-14D520-CG.vbf	Multiple models (shared module)	HVAC - HVAC Control Module	DATA
FPLA-14D520-DE.vbf	Multiple models (shared module)	HVAC - HVAC Control Module	DATA
FPLA-14D520-EE.vbf	Multiple models (shared module)	HVAC - HVAC Control Module	DATA
FPLA-14E093-JA.vbf	Multiple models (shared module)	CHCM - Chassis Control Module	EXE
FPLA-14E093-JB.vbf	Multiple models (shared module)	CHCM - Chassis Control Module	EXE
FPLA-14E093-JC.vbf	Multiple models (shared module)	CHCM - Chassis Control Module	EXE
FPLA-14F434-NA.vbf	Multiple models (shared module)	CHCMB - Chassis Control Module B	EXE
FPLA-14F434-NB.vbf	Multiple models (shared module)	CHCMB - Chassis Control Module B	EXE
FPLA-14F530-AA.vbf	Multiple models (shared module)	GWM - Gateway Module A	EXE
FPLA-14F530-AB.vbf	Multiple models (shared module)	GWM - Gateway Module A	EXE
FPLA-14F530-AC.vbf	Multiple models (shared module)	GWM - Gateway Module A	EXE
FPLA-14F531-AB.vbf	Multiple models (shared module)	GWM - Gateway Module A	DATA
FPLA-14F531-AC.vbf	Multiple models (shared module)	GWM - Gateway Module A	DATA
FPLA-14F531-AD.vbf	Multiple models (shared module)	GWM - Gateway Module A	DATA
FPLA-14F531-BA.vbf	Multiple models (shared module)	GWM - Gateway Module A	DATA
FPLA-14G035-AA.vbf	Range Rover Sport (L494)	PRSM - Passenger Rear Seat Module	SIGCFG
FPLA-14G036-AC.vbf	Range Rover Sport (L494)	PRSM - Passenger Rear Seat Module	EXE
FPLA-14G037-BB.vbf	Range Rover Sport (L494)	PRSM - Passenger Rear Seat Module	DATA
FPLA-14G037-CA.vbf	Range Rover Sport (L494)	PRSM - Passenger Rear Seat Module	DATA
FPLA-14G037-DA.vbf	Range Rover Sport (L494)	PRSM - Passenger Rear Seat Module	DATA
FPLA-14G037-EB.vbf	Range Rover Sport (L494)	PRSM - Passenger Rear Seat Module	DATA
FPLA-14G037-GA.vbf	Range Rover Sport (L494)	PRSM - Passenger Rear Seat Module	DATA
FPLA-14G037-HB.vbf	Range Rover Sport (L494)	PRSM - Passenger Rear Seat Module	DATA
FPLA-14G037-JB.vbf	Range Rover Sport (L494)	PRSM - Passenger Rear Seat Module	DATA
FPLA-14G037-KA.vbf	Range Rover Sport (L494)	PRSM - Passenger Rear Seat Module	DATA
FPLA-14G037-LA.vbf	Range Rover Sport (L494)	PRSM - Passenger Rear Seat Module	DATA
FPLA-14G037-MB.vbf	Range Rover Sport (L494)	PRSM - Passenger Rear Seat Module	DATA
FPLA-14G037-NA.vbf	Range Rover Sport (L494)	PRSM - Passenger Rear Seat Module	DATA
FPLA-14G045-AA.vbf	Range Rover Sport (L494)	DRSM - Driver Rear Seat Module	SIGCFG
FPLA-14G046-AC.vbf	Range Rover Sport (L494)	DRSM - Driver Rear Seat Module	EXE
FPLA-14G047-BB.vbf	Range Rover Sport (L494)	DRSM - Driver Rear Seat Module	DATA
FPLA-14G047-CA.vbf	Range Rover Sport (L494)	DRSM - Driver Rear Seat Module	DATA
FPLA-14G047-DA.vbf	Range Rover Sport (L494)	DRSM - Driver Rear Seat Module	DATA
FPLA-14G047-EB.vbf	Range Rover Sport (L494)	DRSM - Driver Rear Seat Module	DATA
FPLA-14G047-GA.vbf	Range Rover Sport (L494)	DRSM - Driver Rear Seat Module	DATA
FPLA-14G047-HB.vbf	Range Rover Sport (L494)	DRSM - Driver Rear Seat Module	DATA
FPLA-14G047-JB.vbf	Range Rover Sport (L494)	DRSM - Driver Rear Seat Module	DATA
FPLA-14G047-KA.vbf	Range Rover Sport (L494)	DRSM - Driver Rear Seat Module	DATA
FPLA-14G047-LA.vbf	Range Rover Sport (L494)	DRSM - Driver Rear Seat Module	DATA
FPLA-14G047-MB.vbf	Range Rover Sport (L494)	DRSM - Driver Rear Seat Module	DATA
FPLA-14G047-NA.vbf	Range Rover Sport (L494)	DRSM - Driver Rear Seat Module	DATA
FW93-12K532-PAB.vbf	Jaguar XJ (X351)	PCM - Powertrain Control Module	DATA
FW93-12K532-PHB.vbf	Jaguar XJ (X351)	PCM - Powertrain Control Module	DATA
FW93-12K532-PKB.vbf	Jaguar XJ (X351)	PCM - Powertrain Control Module	DATA
FW93-12K532-PRA.vbf	Jaguar XJ (X351)	PCM - Powertrain Control Module	DATA
FW93-14C025-AA.vbf	Jaguar XJ (X351)	IPC - Instrument Panel Cluster (IPC) Control Module	SBL

File name	Vehicle line (indicative)	Module (ECU)	Type
FW93-14C025-AD.vbf	Jaguar XJ (X351)	IPC - Instrument Panel Cluster (IPC) Control Module	SBL
FW93-14C026-BC.vbf	Jaguar XJ (X351)	IPC - Instrument Panel Cluster (IPC) Control Module	EXE
FW93-14C026-DC.vbf	Jaguar XJ (X351)	IPC - Instrument Panel Cluster (IPC) Control Module	EXE
FW93-14C026-EC.vbf	Jaguar XJ (X351)	IPC - Instrument Panel Cluster (IPC) Control Module	EXE
FW93-14C028-AB.vbf	Jaguar XJ (X351)	RCM - Restraints Control Module	EXE
FW93-14C028-BA.vbf	Jaguar XJ (X351)	RCM - Restraints Control Module	EXE
FW93-14C029-AA.vbf	Jaguar XJ (X351)	DSM - Driver Front Seat Module	SBL
FW93-14C029-BA.vbf	Jaguar XJ (X351)	DSM - Driver Front Seat Module	SBL
FW93-14C030-AA.vbf	Jaguar XJ (X351)	DSM - Driver Front Seat Module	EXE
FW93-14C030-BB.vbf	Jaguar XJ (X351)	DSM - Driver Front Seat Module	EXE
FW93-14C034-AA.vbf	Jaguar XJ (X351)	DSM - Driver Front Seat Module	DATA
FW93-14C034-BA.vbf	Jaguar XJ (X351)	DSM - Driver Front Seat Module	DATA
FW93-14C034-CA.vbf	Range Rover Sport (L494)	DSM - Driver Front Seat Module	DATA
FW93-14C036-AD.vbf	Jaguar XJ (X351)	SPCM - Secondary Powertrain Control Module	EXE
FW93-14C037-AD.vbf	Jaguar XJ (X351)	SPCM - Secondary Powertrain Control Module	EXE
FW93-14C037-BD.vbf	Jaguar XJ (X351)	SPCM - Secondary Powertrain Control Module	EXE
FW93-14C037-CD.vbf	Jaguar XJ (X351)	SPCM - Secondary Powertrain Control Module	EXE
FW93-14C037-DD.vbf	Jaguar XJ (X351)	SPCM - Secondary Powertrain Control Module	EXE
FW93-14C037-ED.vbf	Jaguar XJ (X351)	SPCM - Secondary Powertrain Control Module	EXE
FW93-14C037-FD.vbf	Jaguar XJ (X351)	SPCM - Secondary Powertrain Control Module	EXE
FW93-14C037-JD.vbf	Jaguar XJ (X351)	SPCM - Secondary Powertrain Control Module	EXE
FW93-14C037-KD.vbf	Jaguar XJ (X351)	SPCM - Secondary Powertrain Control Module	EXE
FW93-14C037-LD.vbf	Jaguar XJ (X351)	SPCM - Secondary Powertrain Control Module	EXE
FW93-14C037-MD.vbf	Jaguar XJ (X351)	SPCM - Secondary Powertrain Control Module	EXE
FW93-14C037-ND.vbf	Jaguar XJ (X351)	SPCM - Secondary Powertrain Control Module	EXE
FW93-14C037-PD.vbf	Jaguar XJ (X351)	SPCM - Secondary Powertrain Control Module	EXE
FW93-14C039-AA.vbf	Jaguar XJ (X351)	SPCM - Secondary Powertrain Control Module	SBL
FW93-14C039-AB.vbf	Jaguar XJ (X351)	SPCM - Secondary Powertrain Control Module	SBL
FW93-14C060-AB.vbf	Jaguar XJ (X351)	Not specified	EXE
FW93-14C060-AC.vbf	Jaguar XJ (X351)	Not specified	EXE
FW93-14C060-CB.vbf	Jaguar XJ (X351)	Not specified	DATA
FW93-14C060-CC.vbf	Jaguar XJ (X351)	Not specified	DATA
FW93-14C060-GA.vbf	Jaguar XJ (X351)	FCDIM - Front Control/Display Interface Module	EXE
FW93-14C060-GB.vbf	Jaguar XJ (X351)	FCDIM - Front Control/Display Interface Module	EXE
FW93-14C060-GC.vbf	Jaguar XJ (X351)	FCDIM - Front Control/Display Interface Module	EXE
FW93-14C060-GD.vbf	Jaguar XJ (X351)	FCDIM - Front Control/Display Interface Module	EXE
FW93-14C060-GE.vbf	Jaguar XJ (X351)	FCDIM - Front Control/Display Interface Module	EXE
FW93-14C060-HA.vbf	Jaguar XJ (X351)	FCDIM - Front Control/Display Interface Module	EXE
FW93-14C060-HB.vbf	Jaguar XJ (X351)	FCDIM - Front Control/Display Interface Module	EXE
FW93-14C060-HC.vbf	Jaguar XJ (X351)	FCDIM - Front Control/Display Interface Module	EXE
FW93-14C060-HD.vbf	Jaguar XJ (X351)	FCDIM - Front Control/Display Interface Module	EXE
FW93-14C060-HE.vbf	Jaguar XJ (X351)	FCDIM - Front Control/Display Interface Module	EXE
FW93-14C061-CA.vbf	Jaguar XJ (X351)	FCDIM - Front Control/Display Interface Module	DATA
FW93-14C061-CB.vbf	Jaguar XJ (X351)	FCDIM - Front Control/Display Interface Module	DATA
FW93-14C061-CC.vbf	Jaguar XJ (X351)	FCDIM - Front Control/Display Interface Module	DATA
FW93-14C061-CD.vbf	Jaguar XJ (X351)	FCDIM - Front Control/Display Interface Module	DATA
FW93-14C061-CE.vbf	Jaguar XJ (X351)	FCDIM - Front Control/Display Interface Module	DATA
FW93-14C063-CA.vbf	Jaguar XJ (X351)	FCDIM - Front Control/Display Interface Module	SBL
FW93-14C088-AC.vbf	Jaguar XJ (X351)	IPC - Instrument Panel Cluster (IPC) Control Module	DATA
FW93-14C091-AK.vbf	Jaguar XJ (X351)	PAM - Parking Assist Control Module	DATA
FW93-14C098-AA.vbf	Jaguar XJ (X351)	RCM - Restraints Control Module	DATA
FW93-14C098-BA.vbf	Jaguar XJ (X351)	RCM - Restraints Control Module	DATA
FW93-14C098-CA.vbf	Jaguar XJ (X351)	RCM - Restraints Control Module	DATA
FW93-14C098-FB.vbf	Jaguar XJ (X351)	RCM - Restraints Control Module	DATA
FW93-14C098-GB.vbf	Jaguar XJ (X351)	RCM - Restraints Control Module	DATA
FW93-14C121-AB.vbf	Jaguar XJ (X351)	RGTM - Rear Gate / Trunk Module	EXE
FW93-14C122-AB.vbf	Jaguar XJ (X351)	RGTM - Rear Gate / Trunk Module	DATA
FW93-14C151-AE.vbf	Jaguar XJ (X351)	TPM - Tire Pressure Monitor Module	EXE
FW93-14C151-AF.vbf	Jaguar XJ (X351)	TPM - Tire Pressure Monitor Module	EXE
FW93-14C151-AG.vbf	Jaguar XJ (X351)	TPM - Tire Pressure Monitor Module	EXE
FW93-14C151-AH.vbf	Jaguar XJ (X351)	TPM - Tire Pressure Monitor Module	EXE
FW93-14C152-AC.vbf	Jaguar XJ (X351)	TPM - Tire Pressure Monitor Module	DATA
FW93-14C154-AB.VBF	Jaguar XJ (X351)	TPM - Tire Pressure Monitor Module	SBL
FW93-14C155-AC.vbf	Jaguar XJ (X351)	VDM - Vehicle Dynamics Control Module	EXE
FW93-14C156-AB.vbf	Jaguar XJ (X351)	RCM - Restraints Control Module	DATA
FW93-14C158-AA.vbf	Jaguar XJ (X351)	VDM - Vehicle Dynamics Control Module	SBL
FW93-14C168-AB.vbf	Jaguar XJ (X351)	PBM - Park Brake Control Module	EXE
FW93-14C169-AF.vbf	Jaguar XJ (X351)	PBM - Park Brake Control Module	EXE
FW93-14C184-AC.vbf	Jaguar XJ (X351)	BCM - Body Control Module	EXE
FW93-14C184-AD.vbf	Jaguar XJ (X351)	BCM - Body Control Module	EXE
FW93-14C184-AE.vbf	Jaguar XJ (X351)	BCM - Body Control Module	EXE
FW93-14C184-AF.vbf	Jaguar XJ (X351)	BCM - Body Control Module	EXE
FW93-14C184-AG.vbf	Jaguar XJ (X351)	BCM - Body Control Module	EXE
FW93-14C184-AH.vbf	Jaguar XJ (X351)	BCM - Body Control Module	EXE
FW93-14C184-AJ.vbf	Jaguar XJ (X351)	BCM - Body Control Module	EXE
FW93-14C185-AC.vbf	Jaguar XJ (X351)	BCM - Body Control Module	DATA

File name	Vehicle line (indicative)	Module (ECU)	Type
FW93-14C185-AD.VBF	Jaguar XJ (X351)	BCM - Body Control Module	DATA
FW93-14C185-AE.VBF	Jaguar XJ (X351)	BCM - Body Control Module	DATA
FW93-14C185-AF.vbf	Jaguar XJ (X351)	BCM - Body Control Module	DATA
FW93-14C185-AG.VBF	Jaguar XJ (X351)	BCM - Body Control Module	DATA
FW93-14C204-EAA.vbf	Jaguar XJ (X351)	PCM - Powertrain Control Module	EXE
FW93-14C204-ETA.vbf	Jaguar XJ (X351)	PCM - Powertrain Control Module	EXE
FW93-14C204-JAC.vbf	Jaguar XJ (X351)	PCM - Powertrain Control Module	EXE
FW93-14C204-JAD.vbf	Jaguar XJ (X351)	PCM - Powertrain Control Module	EXE
FW93-14C204-JAE.vbf	Jaguar XJ (X351)	PCM - Powertrain Control Module	EXE
FW93-14C204-JCB.vbf	Jaguar XJ (X351)	PCM - Powertrain Control Module	EXE
FW93-14C204-JCC.vbf	Jaguar XJ (X351)	PCM - Powertrain Control Module	EXE
FW93-14C204-JTC.vbf	Jaguar XJ (X351)	PCM - Powertrain Control Module	EXE
FW93-14C204-JTD.vbf	Jaguar XJ (X351)	PCM - Powertrain Control Module	EXE
FW93-14C204-JTE.vbf	Jaguar XJ (X351)	PCM - Powertrain Control Module	EXE
FW93-14C204-PAB.vbf	Jaguar XJ (X351)	PCM - Powertrain Control Module	EXE
FW93-14C204-PAD.vbf	Jaguar XJ (X351)	PCM - Powertrain Control Module	EXE
FW93-14C204-RTA.vbf	Jaguar XJ (X351)	PCM - Powertrain Control Module	EXE
FW93-14C204-TAC.vbf	Jaguar XJ (X351)	PCM - Powertrain Control Module	EXE
FW93-14C204-TAD.vbf	Jaguar XJ (X351)	PCM - Powertrain Control Module	EXE
FW93-14C204-TAE.vbf	Jaguar XJ (X351)	PCM - Powertrain Control Module	EXE
FW93-14C204-TCB.vbf	Jaguar XJ (X351)	PCM - Powertrain Control Module	EXE
FW93-14C204-TCC.vbf	Jaguar XJ (X351)	PCM - Powertrain Control Module	EXE
FW93-14C204-TEC.vbf	Jaguar XJ (X351)	PCM - Powertrain Control Module	EXE
FW93-14C204-TTC.vbf	Jaguar XJ (X351)	PCM - Powertrain Control Module	EXE
FW93-14C204-TTD.vbf	Jaguar XJ (X351)	PCM - Powertrain Control Module	EXE
FW93-14C204-TTE.vbf	Jaguar XJ (X351)	PCM - Powertrain Control Module	EXE
FW93-14C204-ZCA.vbf	Jaguar XJ (X351)	PCM - Powertrain Control Module	EXE
FW93-14C204-ZGA.vbf	Jaguar XJ (X351)	PCM - Powertrain Control Module	EXE
FW93-14C273-PAB.vbf	Jaguar XJ (X351)	PCM - Powertrain Control Module	SBL
FW93-14C273-PAC.vbf	Jaguar XJ (X351)	PCM - Powertrain Control Module	SBL
FW93-14C366-AC.vbf	Jaguar XJ (X351)	TCCM - Transfer Case Control Module	EXE
FW93-14C366-AD.vbf	Jaguar XJ (X351)	TCCM - Transfer Case Control Module	EXE
FW93-14C368-AA.vbf	Jaguar XJ (X351)	TCCM - Transfer Case Control Module	SBL
FW93-14C384-AA.vbf	Jaguar XJ (X351)	VDM - Vehicle Dynamics Control Module	SIGCFG
FW93-14C390-AF.vbf	Jaguar XJ (X351)	TCCM - Transfer Case Control Module	SIGCFG
FW93-14C407-AC.vbf	Jaguar XJ (X351)	RCM - Restraints Control Module	SIGCFG
FW93-14C408-AN.vbf	Jaguar XJ (X351)	BCM - Body Control Module	SIGCFG
FW93-14C434-AC.vbf	Jaguar XJ (X351)	TPM - Tire Pressure Monitor Module	SIGCFG
FW93-14C526-AC.vbf	Jaguar XJ (X351)	AAM - Audio Amplifier Module	EXE
FW93-14C526-AD.vbf	Jaguar XJ (X351)	AAM - Audio Amplifier Module	EXE
FW93-14C526-AE.vbf	Jaguar XJ (X351)	AAM - Audio Amplifier Module	EXE
FW93-14C526-AF.vbf	Jaguar XJ (X351)	AAM - Audio Amplifier Module	EXE
FW93-14C526-AG.vbf	Jaguar XJ (X351)	AAM - Audio Amplifier Module	EXE
FW93-14C526-AH.vbf	Jaguar XJ (X351)	AAM - Audio Amplifier Module	EXE
FW93-14C526-BC.vbf	Jaguar XJ (X351)	AAM - Audio Amplifier Module	EXE
FW93-14C526-BD.vbf	Jaguar XJ (X351)	AAM - Audio Amplifier Module	EXE
FW93-14C526-BE.vbf	Jaguar XJ (X351)	AAM - Audio Amplifier Module	EXE
FW93-14C526-BF.vbf	Jaguar XJ (X351)	AAM - Audio Amplifier Module	EXE
FW93-14C526-BG.vbf	Jaguar XJ (X351)	AAM - Audio Amplifier Module	EXE
FW93-14C526-BH.vbf	Jaguar XJ (X351)	AAM - Audio Amplifier Module	EXE
FW93-14C526-CC.vbf	Jaguar XJ (X351)	AAM - Audio Amplifier Module	EXE
FW93-14C526-CD.vbf	Jaguar XJ (X351)	AAM - Audio Amplifier Module	EXE
FW93-14C526-CE.vbf	Jaguar XJ (X351)	AAM - Audio Amplifier Module	EXE
FW93-14C526-CF.vbf	Jaguar XJ (X351)	AAM - Audio Amplifier Module	EXE
FW93-14C526-CG.vbf	Jaguar XJ (X351)	AAM - Audio Amplifier Module	EXE
FW93-14C526-CH.vbf	Jaguar XJ (X351)	AAM - Audio Amplifier Module	EXE
FW93-14C526-DC.vbf	Jaguar XJ (X351)	AAM - Audio Amplifier Module	EXE
FW93-14C526-DD.vbf	Jaguar XJ (X351)	AAM - Audio Amplifier Module	EXE
FW93-14C526-DE.vbf	Jaguar XJ (X351)	AAM - Audio Amplifier Module	EXE
FW93-14C526-DF.vbf	Jaguar XJ (X351)	AAM - Audio Amplifier Module	EXE
FW93-14C526-DG.vbf	Jaguar XJ (X351)	AAM - Audio Amplifier Module	EXE
FW93-14C526-DH.vbf	Jaguar XJ (X351)	AAM - Audio Amplifier Module	EXE
FW93-14C527-AC.vbf	Jaguar XJ (X351)	AAM - Audio Amplifier Module	DATA
FW93-14C527-AD.vbf	Jaguar XJ (X351)	AAM - Audio Amplifier Module	DATA
FW93-14C527-AE.vbf	Jaguar XJ (X351)	AAM - Audio Amplifier Module	DATA
FW93-14C527-AG.vbf	Jaguar XJ (X351)	AAM - Audio Amplifier Module	DATA
FW93-14C527-AH.vbf	Jaguar XJ (X351)	AAM - Audio Amplifier Module	DATA
FW93-14C527-BC.vbf	Jaguar XJ (X351)	AAM - Audio Amplifier Module	DATA
FW93-14C527-BE.vbf	Jaguar XJ (X351)	AAM - Audio Amplifier Module	DATA
FW93-14C527-BG.vbf	Jaguar XJ (X351)	AAM - Audio Amplifier Module	DATA
FW93-14C527-BH.vbf	Jaguar XJ (X351)	AAM - Audio Amplifier Module	DATA
FW93-14C527-CC.vbf	Jaguar XJ (X351)	AAM - Audio Amplifier Module	DATA
FW93-14C527-CD.vbf	Jaguar XJ (X351)	AAM - Audio Amplifier Module	DATA
FW93-14C527-CE.vbf	Jaguar XJ (X351)	AAM - Audio Amplifier Module	DATA
FW93-14C527-CG.vbf	Jaguar XJ (X351)	AAM - Audio Amplifier Module	DATA
FW93-14C527-CH.vbf	Jaguar XJ (X351)	AAM - Audio Amplifier Module	DATA

File name	Vehicle line (indicative)	Module (ECU)	Type
FW93-14C527-DC.vbf	Jaguar XJ (X351)	AAM - Audio Amplifier Module	DATA
FW93-14C527-DD.vbf	Jaguar XJ (X351)	AAM - Audio Amplifier Module	DATA
FW93-14C527-DE.vbf	Jaguar XJ (X351)	AAM - Audio Amplifier Module	DATA
FW93-14C527-DG.vbf	Jaguar XJ (X351)	AAM - Audio Amplifier Module	DATA
FW93-14C527-DH.vbf	Jaguar XJ (X351)	AAM - Audio Amplifier Module	DATA
FW93-14C527-DJ.vbf	Jaguar XJ (X351)	AAM - Audio Amplifier Module	DATA
FW93-14C527-EE.vbf	Jaguar XJ (X351)	AAM - Audio Amplifier Module	DATA
FW93-14C527-EG.vbf	Jaguar XJ (X351)	AAM - Audio Amplifier Module	DATA
FW93-14C527-EH.vbf	Jaguar XJ (X351)	AAM - Audio Amplifier Module	DATA
FW93-14C527-FC.vbf	Jaguar XJ (X351)	AAM - Audio Amplifier Module	DATA
FW93-14C527-FE.vbf	Jaguar XJ (X351)	AAM - Audio Amplifier Module	DATA
FW93-14C527-FG.vbf	Jaguar XJ (X351)	AAM - Audio Amplifier Module	DATA
FW93-14C527-FH.vbf	Jaguar XJ (X351)	AAM - Audio Amplifier Module	DATA
FW93-14C527-GC.vbf	Jaguar XJ (X351)	AAM - Audio Amplifier Module	DATA
FW93-14C527-GD.vbf	Jaguar XJ (X351)	AAM - Audio Amplifier Module	DATA
FW93-14C527-GE.vbf	Jaguar XJ (X351)	AAM - Audio Amplifier Module	DATA
FW93-14C527-GG.vbf	Jaguar XJ (X351)	AAM - Audio Amplifier Module	DATA
FW93-14C527-GH.vbf	Jaguar XJ (X351)	AAM - Audio Amplifier Module	DATA
FW93-14C527-HC.vbf	Jaguar XJ (X351)	AAM - Audio Amplifier Module	DATA
FW93-14C527-HD.vbf	Jaguar XJ (X351)	AAM - Audio Amplifier Module	DATA
FW93-14C527-HE.vbf	Jaguar XJ (X351)	AAM - Audio Amplifier Module	DATA
FW93-14C527-HG.vbf	Jaguar XJ (X351)	AAM - Audio Amplifier Module	DATA
FW93-14C527-HH.vbf	Jaguar XJ (X351)	AAM - Audio Amplifier Module	DATA
FW93-14C527-HJ.vbf	Jaguar XJ (X351)	AAM - Audio Amplifier Module	DATA
FW93-14C528-AB.vbf	Jaguar XJ (X351)	AAM - Audio Amplifier Module	SBL
FW93-14C528-AC.vbf	Jaguar XJ (X351)	AAM - Audio Amplifier Module	SBL
FW93-14C528-AD.vbf	Jaguar XJ (X351)	AAM - Audio Amplifier Module	SBL
FW93-14C534-AB.vbf	Jaguar XJ (X351)	FCIM - Front Controls Interface Module	SIGCFG
FW93-14C535-AB.vbf	Jaguar XJ (X351)	FCIM - Front Controls Interface Module	EXE
FW93-14C535-AD.vbf	Jaguar XJ (X351)	FCIM - Front Controls Interface Module	EXE
FW93-14C536-AB.vbf	Jaguar XJ (X351)	FCIM - Front Controls Interface Module	CUSTOM
FW93-14C537-AB.vbf	Jaguar XJ (X351)	FCIM - Front Controls Interface Module	SBL
FW93-14C548-BB.vbf	Jaguar XJ (X351)	PSM - Passenger Front Seat Module	EXE
FW93-14C549-CA.vbf	Range Rover Sport (L494)	PSM - Passenger Front Seat Module	DATA
FW93-14C549-DA.vbf	Range Rover Sport (L494)	PSM - Passenger Front Seat Module	DATA
FW93-14C550-BA.vbf	Jaguar XJ (X351)	PSM - Passenger Front Seat Module	SBL
FW93-14C560-AB.vbf	Jaguar XJ (X351)	GSM - Gear Shift Module	SIGCFG
FW93-14C561-AB.vbf	Jaguar XJ (X351)	GSM - Gear Shift Module	EXE
FW93-14C563-AA.vbf	Jaguar XJ (X351)	GSM - Gear Shift Module	SBL
FW93-14C621-CA.vbf	Jaguar XJ (X351)	FCDIM - Front Control/Display Interface Module	EXE
FW93-14D183-AB.vbf	Jaguar XJ (X351)	OCS - Restraints Occupant Classification System Module	DATA
FW93-14D195-AA.vbf	Jaguar XJ (X351)	IPMA - Image Processing Module A	SIGCFG
FW93-14D196-AB.vbf	Jaguar XJ (X351)	IPMA - Image Processing Module A	EXE
FW93-14D197-AB.vbf	Jaguar XJ (X351)	IPMA - Image Processing Module A	DATA
FW93-14D198-AA.vbf	Jaguar XJ (X351)	IPMA - Image Processing Module A	SBL
FW93-14D367-AA.vbf	Jaguar XJ (X351)	SODL - Side Obstacle Detection Control Module - Left	SIGCFG
FW93-14D367-BA.vbf	Jaguar XJ (X351)	SODR - Side Obstacle Detection Control Module - Right	SIGCFG
FW93-14D367-CB.vbf	Jaguar XJ (X351)	SODL - Side Obstacle Detection Control Module - Left	SIGCFG
FW93-14D367-DB.vbf	Jaguar XJ (X351)	SODR - Side Obstacle Detection Control Module - Right	SIGCFG
FW93-14D368-AD.vbf	Jaguar XJ (X351)	SODL - Side Obstacle Detection Control Module - Left	EXE
FW93-14D368-AF.vbf	Jaguar XJ (X351)	SODL - Side Obstacle Detection Control Module - Left	EXE
FW93-14D368-BC.vbf	Jaguar XJ (X351)	SODL - Side Obstacle Detection Control Module - Left	EXE
FW93-14D368-CA.vbf	Jaguar XJ (X351)	SODL - Side Obstacle Detection Control Module - Left	EXE
FW93-14D368-CC.vbf	Jaguar XJ (X351)	SODL - Side Obstacle Detection Control Module - Left	EXE
FW93-14D370-AA.vbf	Jaguar XJ (X351)	SODL - Side Obstacle Detection Control Module - Left	SBL
FW93-14D479-AE.vbf	Jaguar XJ (X351)	IPMB - Image Processing Module B	SIGCFG
FW93-14D479-BE.vbf	Jaguar XJ (X351)	IPMB - Image Processing Module B	SIGCFG
FW93-14D480-BC.vbf	Jaguar XJ (X351)	IPMB - Image Processing Module B	EXE
FW93-14D480-BH.vbf	Jaguar XJ (X351)	IPMB - Image Processing Module B	EXE
FW93-14D480-BJ.vbf	Jaguar XJ (X351)	IPMB - Image Processing Module B	EXE
FW93-14D480-BK.vbf	Jaguar XJ (X351)	IPMB - Image Processing Module B	EXE
FW93-14D519-AD.vbf	Jaguar XJ (X351)	HVAC - HVAC Control Module	EXE
FW93-14D520-AD.vbf	Jaguar XJ (X351)	HVAC - HVAC Control Module	DATA
FW93-14D520-BD.vbf	Jaguar XJ (X351)	HVAC - HVAC Control Module	DATA
FW93-14D521-AB.vbf	Jaguar XJ (X351)	HVAC - HVAC Control Module	SBL
FW93-14D564-AA.vbf	Jaguar XJ (X351)	SODL - Side Obstacle Detection Control Module - Left	DATA
FW93-14D564-BA.vbf	Jaguar XJ (X351)	SODR - Side Obstacle Detection Control Module - Right	DATA
FW93-14E093-RB.vbf	Jaguar XJ (X351)	CHCM - Chassis Control Module	EXE
FW93-14E093-RD.vbf	Jaguar XJ (X351)	CHCM - Chassis Control Module	EXE
FW93-14E093-RE.vbf	Jaguar XJ (X351)	CHCM - Chassis Control Module	EXE
FW93-14E093-RF.vbf	Jaguar XJ (X351)	CHCM - Chassis Control Module	EXE
FW93-14E094-RAC.vbf	Jaguar XJ (X351)	CHCM - Chassis Control Module	EXE
FW93-14E094-RBC.vbf	Jaguar XJ (X351)	CHCM - Chassis Control Module	EXE
FW93-14E094-RCC.vbf	Jaguar XJ (X351)	CHCM - Chassis Control Module	EXE
FW93-14E094-RCD.vbf	Jaguar XJ (X351)	CHCM - Chassis Control Module	EXE
FW93-14E094-RDD.vbf	Jaguar XJ (X351)	CHCM - Chassis Control Module	EXE

File name	Vehicle line (indicative)	Module (ECU)	Type
FW93-14E094-RED.vbf	Jaguar XJ (X351)	CHCM - Chassis Control Module	EXE
FW93-14E094-RGD.vbf	Jaguar XJ (X351)	CHCM - Chassis Control Module	EXE
FW93-14E094-RJD.vbf	Jaguar XJ (X351)	CHCM - Chassis Control Module	EXE
FW93-14E094-RKD.vbf	Jaguar XJ (X351)	CHCM - Chassis Control Module	EXE
FW93-14E094-RLD.vbf	Jaguar XJ (X351)	CHCM - Chassis Control Module	EXE
FW93-14E094-RNC.vbf	Jaguar XJ (X351)	CHCM - Chassis Control Module	EXE
FW93-14E094-RND.vbf	Jaguar XJ (X351)	CHCM - Chassis Control Module	EXE
FW93-14E094-RPC.vbf	Jaguar XJ (X351)	CHCM - Chassis Control Module	EXE
FW93-14E094-RPD.vbf	Jaguar XJ (X351)	CHCM - Chassis Control Module	EXE
FW93-14E094-RRC.vbf	Jaguar XJ (X351)	CHCM - Chassis Control Module	EXE
FW93-14E094-RSC.vbf	Jaguar XJ (X351)	CHCM - Chassis Control Module	EXE
FW93-14E094-RTC.vbf	Jaguar XJ (X351)	CHCM - Chassis Control Module	EXE
FW93-14E094-RUC.vbf	Jaguar XJ (X351)	CHCM - Chassis Control Module	EXE
FW93-14E094-RVC.vbf	Jaguar XJ (X351)	CHCM - Chassis Control Module	EXE
FW93-14F016-AB.vbf	Jaguar XJ (X351)	IPMB - Image Processing Module B	SIGCFG
FW93-14F016-BB.vbf	Jaguar XJ (X351)	IPMB - Image Processing Module B	SIGCFG
FW93-14F017-AB.vbf	Jaguar XJ (X351)	IPMB - Image Processing Module B	EXE
FW93-14F017-AD.vbf	Jaguar XJ (X351)	IPMB - Image Processing Module B	EXE
FW93-14F017-AE.vbf	Jaguar XJ (X351)	IPMB - Image Processing Module B	EXE
FW93-14F017-AF.vbf	Jaguar XJ (X351)	IPMB - Image Processing Module B	EXE
FW93-14F017-AG.vbf	Jaguar XJ (X351)	IPMB - Image Processing Module B	EXE
FW93-14F017-AH.vbf	Jaguar XJ (X351)	IPMB - Image Processing Module B	EXE
FW93-14F017-AJ.vbf	Jaguar XJ (X351)	IPMB - Image Processing Module B	EXE
FW93-14F017-BF.vbf	Jaguar XJ (X351)	IPMB - Image Processing Module B	EXE
FW93-14F017-BG.vbf	Jaguar XJ (X351)	IPMB - Image Processing Module B	EXE
FW93-14F017-BH.vbf	Jaguar XJ (X351)	IPMB - Image Processing Module B	EXE
FW93-14F017-BJ.vbf	Jaguar XJ (X351)	IPMB - Image Processing Module B	EXE
FW93-14F017-BK.vbf	Jaguar XJ (X351)	IPMB - Image Processing Module B	EXE
FW93-14F017-BM.vbf	Jaguar XJ (X351)	IPMB - Image Processing Module B	EXE
FW93-14F017-CF.vbf	Jaguar XJ (X351)	IPMB - Image Processing Module B	EXE
FW93-14F017-CG.vbf	Jaguar XJ (X351)	IPMB - Image Processing Module B	EXE
FW93-14F017-CH.vbf	Jaguar XJ (X351)	IPMB - Image Processing Module B	EXE
FW93-14F017-CJ.vbf	Jaguar XJ (X351)	IPMB - Image Processing Module B	EXE
FW93-14F017-CK.vbf	Jaguar XJ (X351)	IPMB - Image Processing Module B	EXE
FW93-14F019-AB.vbf	Jaguar XJ (X351)	IPMB - Image Processing Module B	SBL
FW93-14F019-AC.vbf	Jaguar XJ (X351)	IPMB - Image Processing Module B	SBL
FW93-14F022-AD.vbf	Jaguar XJ (X351)	IPMB - Image Processing Module B	DATA
FW93-14F022-AE.vbf	Jaguar XJ (X351)	IPMB - Image Processing Module B	DATA
FW93-14F022-AF.vbf	Jaguar XJ (X351)	IPMB - Image Processing Module B	DATA
FW93-14F022-AG.vbf	Jaguar XJ (X351)	IPMB - Image Processing Module B	DATA
FW93-14F022-BB.vbf	Jaguar XJ (X351)	IPMB - Image Processing Module B	DATA
FW93-14F022-BC.vbf	Jaguar XJ (X351)	IPMB - Image Processing Module B	DATA
FW93-14F022-BD.vbf	Jaguar XJ (X351)	IPMB - Image Processing Module B	DATA
FW93-14F022-BE.vbf	Jaguar XJ (X351)	IPMB - Image Processing Module B	DATA
FW93-14F022-BF.vbf	Jaguar XJ (X351)	IPMB - Image Processing Module B	DATA
FW93-14F216-AB.vbf	Jaguar XJ (X351)	RHVAC - Rear HVAC Control Module	SIGCFG
FW93-14F217-AD.vbf	Jaguar XJ (X351)	RHVAC - Rear HVAC Control Module	EXE
FW93-14F218-AA.vbf	Jaguar XJ (X351)	RHVAC - Rear HVAC Control Module	CUSTOM
FW93-14F219-AA.vbf	Jaguar XJ (X351)	RHVAC - Rear HVAC Control Module	SBL
FW93-14F454-AB.vbf	Jaguar XJ (X351)	IPMA - Image Processing Module A	SIGCFG
FW93-14F455-AC.vbf	Jaguar XJ (X351)	IPMA - Image Processing Module A	EXE
FW93-14F455-BC.vbf	Jaguar XJ (X351)	IPMA - Image Processing Module A	EXE
FW93-14F456-AC.vbf	Jaguar XJ (X351)	IPMA - Image Processing Module A	DATA
FW93-14F456-BC.vbf	Jaguar XJ (X351)	IPMA - Image Processing Module A	DATA
FW93-14F457-AA.vbf	Jaguar XJ (X351)	IPMA - Image Processing Module A	SBL
FW93-14F530-AC.vbf	Jaguar XJ (X351)	GWM - Gateway Module A	EXE
FW93-14F530-BA.vbf	Jaguar XJ (X351)	GWM - Gateway Module A	EXE
FW93-14F530-BB.vbf	Jaguar XJ (X351)	GWM - Gateway Module A	EXE
FW93-14F530-BC.vbf	Jaguar XJ (X351)	GWM - Gateway Module A	EXE
FW93-14F530-BD.vbf	Jaguar XJ (X351)	GWM - Gateway Module A	EXE
FW93-14F530-BF.vbf	Jaguar XJ (X351)	GWM - Gateway Module A	EXE
FW93-14F531-AC.vbf	Jaguar XJ (X351)	GWM - Gateway Module A	DATA
FW93-14F531-BA.vbf	Jaguar XJ (X351)	GWM - Gateway Module A	DATA
FW93-14F531-BB.vbf	Jaguar XJ (X351)	GWM - Gateway Module A	DATA
FW93-14F531-BC.vbf	Jaguar XJ (X351)	GWM - Gateway Module A	DATA
FW93-14F531-BD.vbf	Jaguar XJ (X351)	GWM - Gateway Module A	DATA
FW93-14F532-AA.vbf	Jaguar XJ (X351)	GWM - Gateway Module A	SBL
FW93-14F532-BA.vbf	Jaguar XJ (X351)	GWM - Gateway Module A	SBL
FW93-14F532-BB.vbf	Jaguar XJ (X351)	GWM - Gateway Module A	SBL
FW93-14F532-DA.vbf	Jaguar XJ (X351)	GWM - Gateway Module A	SBL
FW93-14G036-AB.vbf	Jaguar XJ (X351)	PRSM - Passenger Rear Seat Module	EXE
FW93-14G037-AA.vbf	Jaguar XJ (X351)	PRSM - Passenger Rear Seat Module	DATA
FW93-14G038-AA.vbf	Jaguar XJ (X351)	PRSM - Passenger Rear Seat Module	SBL
FW93-14G046-AB.vbf	Jaguar XJ (X351)	DRSM - Driver Rear Seat Module	EXE
FW93-14G047-AA.vbf	Jaguar XJ (X351)	DRSM - Driver Rear Seat Module	DATA
FW93-14G048-AA.vbf	Jaguar XJ (X351)	DRSM - Driver Rear Seat Module	SBL

File name	Vehicle line (indicative)	Module (ECU)	Type
FW93-19C204-AF.vbf	Jaguar XJ (X351)	IMC - Infotainment Master Controller	EXE
FW93-19C204-AG.vbf	Jaguar XJ (X351)	IMC - Infotainment Master Controller	EXE
FW93-19C204-AJ.vbf	Jaguar XJ (X351)	IMC - Infotainment Master Controller	EXE
FW93-19C206-AC.vbf	Jaguar XJ (X351)	IMC - Infotainment Master Controller	SBL
FW93-70711-AC.vbf	Jaguar XJ (X351)	TCU - Telematic Control Unit Module	SIGCFG
FW93-70711-AD.vbf	Jaguar XJ (X351)	TCU - Telematic Control Unit Module	SIGCFG
FW93-70711-AE.vbf	Jaguar XJ (X351)	TCU - Telematic Control Unit Module	SIGCFG
FW93-70711-AF.vbf	Jaguar XJ (X351)	TCU - Telematic Control Unit Module	SIGCFG
FW93-70711-AG.vbf	Jaguar XJ (X351)	TCU - Telematic Control Unit Module	SIGCFG
FW93-70712-AF.vbf	Jaguar XJ (X351)	TCU - Telematic Control Unit Module	EXE
FW93-70712-AG.vbf	Jaguar XJ (X351)	TCU - Telematic Control Unit Module	EXE
FW93-70712-AH.vbf	Jaguar XJ (X351)	TCU - Telematic Control Unit Module	EXE
FW93-70712-AJ.vbf	Jaguar XJ (X351)	TCU - Telematic Control Unit Module	EXE
FW93-70712-AK.vbf	Jaguar XJ (X351)	TCU - Telematic Control Unit Module	EXE
FW93-70712-AL.vbf	Jaguar XJ (X351)	TCU - Telematic Control Unit Module	EXE
FW93-70712-AM.vbf	Jaguar XJ (X351)	TCU - Telematic Control Unit Module	EXE
FW93-70712-AN.vbf	Jaguar XJ (X351)	TCU - Telematic Control Unit Module	EXE
FW93-70712-AP.vbf	Jaguar XJ (X351)	TCU - Telematic Control Unit Module	EXE
FW93-70712-AR.vbf	Jaguar XJ (X351)	TCU - Telematic Control Unit Module	EXE
FW93-70712-AS.vbf	Jaguar XJ (X351)	TCU - Telematic Control Unit Module	EXE
FW93-70712-CF.vbf	Jaguar XJ (X351)	TCU - Telematic Control Unit Module	EXE
FW93-70712-CG.vbf	Jaguar XJ (X351)	TCU - Telematic Control Unit Module	EXE
FW93-70712-CH.vbf	Jaguar XJ (X351)	TCU - Telematic Control Unit Module	EXE
FW93-70712-CJ.vbf	Jaguar XJ (X351)	TCU - Telematic Control Unit Module	EXE
FW93-70712-CK.vbf	Jaguar XJ (X351)	TCU - Telematic Control Unit Module	EXE
FW93-70712-CL.vbf	Jaguar XJ (X351)	TCU - Telematic Control Unit Module	EXE
FW93-70712-CM.vbf	Jaguar XJ (X351)	TCU - Telematic Control Unit Module	EXE
FW93-70712-CN.vbf	Jaguar XJ (X351)	TCU - Telematic Control Unit Module	EXE
FW93-70712-CP.vbf	Jaguar XJ (X351)	TCU - Telematic Control Unit Module	EXE
FW93-70712-CR.vbf	Jaguar XJ (X351)	TCU - Telematic Control Unit Module	EXE
FW93-70712-CS.vbf	Jaguar XJ (X351)	TCU - Telematic Control Unit Module	EXE
FW93-70713-KC.vbf	Jaguar XJ (X351)	TCU - Telematic Control Unit Module	DATA
FW93-70713-KD.vbf	Jaguar XJ (X351)	TCU - Telematic Control Unit Module	DATA
FW93-70713-KE.vbf	Jaguar XJ (X351)	TCU - Telematic Control Unit Module	DATA
FW93-70713-KF.vbf	Jaguar XJ (X351)	TCU - Telematic Control Unit Module	DATA
FW93-70713-KG.vbf	Jaguar XJ (X351)	TCU - Telematic Control Unit Module	DATA
FW93-70713-KH.vbf	Jaguar XJ (X351)	TCU - Telematic Control Unit Module	DATA
FW93-70713-KJ.vbf	Jaguar XJ (X351)	TCU - Telematic Control Unit Module	DATA
FW93-70713-KK.vbf	Jaguar XJ (X351)	TCU - Telematic Control Unit Module	DATA
FW93-70713-KL.vbf	Jaguar XJ (X351)	TCU - Telematic Control Unit Module	DATA
FW93-70713-KM.vbf	Jaguar XJ (X351)	TCU - Telematic Control Unit Module	DATA
FW93-70713-MN.vbf	Jaguar XJ (X351)	TCU - Telematic Control Unit Module	DATA
FW93-70713-MP.vbf	Jaguar XJ (X351)	TCU - Telematic Control Unit Module	DATA
FW93-70713-MR.vbf	Jaguar XJ (X351)	TCU - Telematic Control Unit Module	DATA
FW93-70713-MS.vbf	Jaguar XJ (X351)	TCU - Telematic Control Unit Module	DATA
FW93-70713-MT.vbf	Jaguar XJ (X351)	TCU - Telematic Control Unit Module	DATA
FW93-70713-MV.vbf	Jaguar XJ (X351)	TCU - Telematic Control Unit Module	DATA
FW93-70713-MX.vbf	Jaguar XJ (X351)	TCU - Telematic Control Unit Module	DATA
FW93-70713-MY.vbf	Jaguar XJ (X351)	TCU - Telematic Control Unit Module	DATA
FW93-70713-MZ.vbf	Jaguar XJ (X351)	TCU - Telematic Control Unit Module	DATA
FW93-70713-NN.vbf	Jaguar XJ (X351)	TCU - Telematic Control Unit Module	DATA
FW93-70713-NP.vbf	Jaguar XJ (X351)	TCU - Telematic Control Unit Module	DATA
FW93-70713-NR.vbf	Jaguar XJ (X351)	TCU - Telematic Control Unit Module	DATA
FW93-70713-NS.vbf	Jaguar XJ (X351)	TCU - Telematic Control Unit Module	DATA
FW93-70713-NT.vbf	Jaguar XJ (X351)	TCU - Telematic Control Unit Module	DATA
FW93-70713-NV.vbf	Jaguar XJ (X351)	TCU - Telematic Control Unit Module	DATA
FW93-70713-NX.vbf	Jaguar XJ (X351)	TCU - Telematic Control Unit Module	DATA
FW93-70713-NY.vbf	Jaguar XJ (X351)	TCU - Telematic Control Unit Module	DATA
FW93-70713-NZ.vbf	Jaguar XJ (X351)	TCU - Telematic Control Unit Module	DATA
FW93-70713-PG.vbf	Jaguar XJ (X351)	TCU - Telematic Control Unit Module	DATA
FW93-70713-RG.vbf	Jaguar XJ (X351)	TCU - Telematic Control Unit Module	DATA
FW93-70713-RH.vbf	Jaguar XJ (X351)	TCU - Telematic Control Unit Module	DATA
FW93-70713-RJ.vbf	Jaguar XJ (X351)	TCU - Telematic Control Unit Module	DATA
FW93-70713-RK.vbf	Jaguar XJ (X351)	TCU - Telematic Control Unit Module	DATA
FW93-70713-RL.vbf	Jaguar XJ (X351)	TCU - Telematic Control Unit Module	DATA
FW93-70713-RM.vbf	Jaguar XJ (X351)	TCU - Telematic Control Unit Module	DATA
FW93-70713-RN.vbf	Jaguar XJ (X351)	TCU - Telematic Control Unit Module	DATA
FW93-70713-RP.vbf	Jaguar XJ (X351)	TCU - Telematic Control Unit Module	DATA
FW93-70713-RR.vbf	Jaguar XJ (X351)	TCU - Telematic Control Unit Module	DATA
FW93-70713-RS.vbf	Jaguar XJ (X351)	TCU - Telematic Control Unit Module	DATA
FW93-70713-RT.vbf	Jaguar XJ (X351)	TCU - Telematic Control Unit Module	DATA
FW93-70713-RV.vbf	Jaguar XJ (X351)	TCU - Telematic Control Unit Module	DATA
FW93-70713-SG.vbf	Jaguar XJ (X351)	TCU - Telematic Control Unit Module	DATA
FW93-70713-SH.vbf	Jaguar XJ (X351)	TCU - Telematic Control Unit Module	DATA
FW93-70713-SK.vbf	Jaguar XJ (X351)	TCU - Telematic Control Unit Module	DATA
FW93-70713-SL.vbf	Jaguar XJ (X351)	TCU - Telematic Control Unit Module	DATA

File name	Vehicle line (indicative)	Module (ECU)	Type
FW93-70713-SM.vbf	Jaguar XJ (X351)	TCU - Telematic Control Unit Module	DATA
FW93-70713-SN.vbf	Jaguar XJ (X351)	TCU - Telematic Control Unit Module	DATA
FW93-70713-SP.vbf	Jaguar XJ (X351)	TCU - Telematic Control Unit Module	DATA
FW93-70713-SR.vbf	Jaguar XJ (X351)	TCU - Telematic Control Unit Module	DATA
FW93-70713-SS.vbf	Jaguar XJ (X351)	TCU - Telematic Control Unit Module	DATA
FW93-70713-ST.vbf	Jaguar XJ (X351)	TCU - Telematic Control Unit Module	DATA
FW93-70713-SV.vbf	Jaguar XJ (X351)	TCU - Telematic Control Unit Module	DATA
FW93-70713-TA.VBF	Jaguar XJ (X351)	TCU - Telematic Control Unit Module	DATA
FW93-70713-TC.vbf	Jaguar XJ (X351)	TCU - Telematic Control Unit Module	DATA
FW93-70713-TD.vbf	Jaguar XJ (X351)	TCU - Telematic Control Unit Module	DATA
FW93-70713-TE.vbf	Jaguar XJ (X351)	TCU - Telematic Control Unit Module	DATA
FW93-70713-TF.vbf	Jaguar XJ (X351)	TCU - Telematic Control Unit Module	DATA
FW93-70713-TG.vbf	Jaguar XJ (X351)	TCU - Telematic Control Unit Module	DATA
FW93-70713-TH.vbf	Jaguar XJ (X351)	TCU - Telematic Control Unit Module	DATA
FW93-70713-TJ.vbf	Jaguar XJ (X351)	TCU - Telematic Control Unit Module	DATA
FW93-70713-TK.vbf	Jaguar XJ (X351)	TCU - Telematic Control Unit Module	DATA
FW93-70713-TL.vbf	Jaguar XJ (X351)	TCU - Telematic Control Unit Module	DATA
FW93-70713-TM.vbf	Jaguar XJ (X351)	TCU - Telematic Control Unit Module	DATA
FW93-70713-VA.vbf	Jaguar XJ (X351)	TCU - Telematic Control Unit Module	DATA
FW93-70713-VC.vbf	Jaguar XJ (X351)	TCU - Telematic Control Unit Module	DATA
FW93-70713-VD.vbf	Jaguar XJ (X351)	TCU - Telematic Control Unit Module	DATA
FW93-70713-VE.vbf	Jaguar XJ (X351)	TCU - Telematic Control Unit Module	DATA
FW93-70713-VF.vbf	Jaguar XJ (X351)	TCU - Telematic Control Unit Module	DATA
FW93-70713-VG.vbf	Jaguar XJ (X351)	TCU - Telematic Control Unit Module	DATA
FW93-7J104-BBB.vbf	Jaguar XJ (X351)	TCM - Transmission Control Module	EXE
FW93-7J104-BBC.vbf	Jaguar XJ (X351)	TCM - Transmission Control Module	EXE
FW93-7J104-BBD.vbf	Jaguar XJ (X351)	TCM - Transmission Control Module	EXE
FW93-7J104-BBE.vbf	Jaguar XJ (X351)	TCM - Transmission Control Module	EXE
FW93-7J104-BCB.vbf	Jaguar XJ (X351)	TCM - Transmission Control Module	EXE
FW93-7J104-BCC.vbf	Jaguar XJ (X351)	TCM - Transmission Control Module	EXE
FW93-7J104-BCD.vbf	Jaguar XJ (X351)	TCM - Transmission Control Module	EXE
FW93-7J104-BCE.vbf	Jaguar XJ (X351)	TCM - Transmission Control Module	EXE
FW93-7J104-BCF.vbf	Jaguar XJ (X351)	TCM - Transmission Control Module	EXE
FW93-7J104-BDC.vbf	Jaguar XJ (X351)	TCM - Transmission Control Module	EXE
FW93-7J104-BDD.vbf	Jaguar XJ (X351)	TCM - Transmission Control Module	EXE
FW93-7J104-BDE.vbf	Jaguar XJ (X351)	TCM - Transmission Control Module	EXE
FW93-7J104-BDF.vbf	Jaguar XJ (X351)	TCM - Transmission Control Module	EXE
FW93-7J104-BED.vbf	Jaguar XJ (X351)	TCM - Transmission Control Module	EXE
FW93-7J104-BFB.vbf	Jaguar XJ (X351)	TCM - Transmission Control Module	EXE
FW93-7J104-BFC.vbf	Jaguar XJ (X351)	TCM - Transmission Control Module	EXE
FW93-7J104-BFD.vbf	Jaguar XJ (X351)	TCM - Transmission Control Module	EXE
FW93-7J104-BFE.vbf	Jaguar XJ (X351)	TCM - Transmission Control Module	EXE
FW93-7J104-BJB.vbf	Jaguar XJ (X351)	TCM - Transmission Control Module	EXE
FW93-7J104-BJC.vbf	Jaguar XJ (X351)	TCM - Transmission Control Module	EXE
FW93-7J104-BJD.vbf	Jaguar XJ (X351)	TCM - Transmission Control Module	EXE
FW93-7J104-BJE.vbf	Jaguar XJ (X351)	TCM - Transmission Control Module	EXE
FW93-7J104-BKC.vbf	Jaguar XJ (X351)	TCM - Transmission Control Module	EXE
FW93-7J104-BKD.vbf	Jaguar XJ (X351)	TCM - Transmission Control Module	EXE
FW93-7J104-BKE.vbf	Jaguar XJ (X351)	TCM - Transmission Control Module	EXE
FW93-7J104-BKF.vbf	Jaguar XJ (X351)	TCM - Transmission Control Module	EXE
FW93-7J104-BMC.vbf	Jaguar XJ (X351)	TCM - Transmission Control Module	EXE
FW93-7J104-BMD.vbf	Jaguar XJ (X351)	TCM - Transmission Control Module	EXE
FW93-7J104-BME.vbf	Jaguar XJ (X351)	TCM - Transmission Control Module	EXE
FW93-7J104-BMF.vbf	Jaguar XJ (X351)	TCM - Transmission Control Module	EXE
FW93-7J104-BPB.vbf	Jaguar XJ (X351)	TCM - Transmission Control Module	EXE
FW93-7J104-BPD.vbf	Jaguar XJ (X351)	TCM - Transmission Control Module	EXE
FW93-7J104-BPE.vbf	Jaguar XJ (X351)	TCM - Transmission Control Module	EXE
FX23-12K532-PCB.vbf	Jaguar XF (X250)	PCM - Powertrain Control Module	DATA
FX23-12K532-PRA.vbf	Jaguar XF (X250)	PCM - Powertrain Control Module	DATA
FX23-12K532-PTA.vbf	Jaguar XF (X250)	PCM - Powertrain Control Module	DATA
FX23-14C036-AB.vbf	Jaguar XF (X250)	ABS - Anit-Lock Brake System (ABS) Control Module	EXE
FX23-14C060-AD.vbf	Jaguar XF (X250)	FCDIM - Front Control/Display Interface Module	EXE
FX23-14C060-AE.vbf	Jaguar XF (X250)	FCDIM - Front Control/Display Interface Module	EXE
FX23-14C060-AF.vbf	Jaguar XF (X250)	FCDIM - Front Control/Display Interface Module	EXE
FX23-14C060-AG.vbf	Jaguar XF (X250)	FCDIM - Front Control/Display Interface Module	EXE
FX23-14C060-AH.vbf	Jaguar XF (X250)	FCDIM - Front Control/Display Interface Module	EXE
FX23-14C061-AD.vbf	Jaguar XF (X250)	FCDIM - Front Control/Display Interface Module	DATA
FX23-14C061-AE.vbf	Jaguar XF (X250)	FCDIM - Front Control/Display Interface Module	DATA
FX23-14C061-AF.vbf	Jaguar XF (X250)	FCDIM - Front Control/Display Interface Module	DATA
FX23-14C061-AG.vbf	Jaguar XF (X250)	FCDIM - Front Control/Display Interface Module	DATA
FX23-14C061-AH.vbf	Jaguar XF (X250)	FCDIM - Front Control/Display Interface Module	DATA
FX23-14C063-AA.vbf	Jaguar XF (X250)	FCDIM - Front Control/Display Interface Module	SBL
FX23-14C151-AB.vbf	Jaguar XF (X250)	TPM - Tire Pressure Monitor Module	EXE
FX23-14C204-JAD.vbf	Jaguar XF (X250)	PCM - Powertrain Control Module	EXE
FX23-14C204-JAE.vbf	Jaguar XF (X250)	PCM - Powertrain Control Module	EXE
FX23-14C204-JCC.vbf	Jaguar XF (X250)	PCM - Powertrain Control Module	EXE

File name	Vehicle line (indicative)	Module (ECU)	Type
FX23-14C204-JCD.vbf	Jaguar XF (X250)	PCM - Powertrain Control Module	EXE
FX23-14C204-JTD.vbf	Jaguar XF (X250)	PCM - Powertrain Control Module	EXE
FX23-14C204-JTE.vbf	Jaguar XF (X250)	PCM - Powertrain Control Module	EXE
FX23-14C204-TAD.vbf	Jaguar XF (X250)	PCM - Powertrain Control Module	EXE
FX23-14C204-TAE.vbf	Jaguar XF (X250)	PCM - Powertrain Control Module	EXE
FX23-14C204-TCC.vbf	Jaguar XF (X250)	PCM - Powertrain Control Module	EXE
FX23-14C204-TCD.vbf	Jaguar XF (X250)	PCM - Powertrain Control Module	EXE
FX23-14C204-TEC.vbf	Jaguar XF (X250)	PCM - Powertrain Control Module	EXE
FX23-14C204-TED.vbf	Jaguar XF (X250)	PCM - Powertrain Control Module	EXE
FX23-14C204-TTD.vbf	Jaguar XF (X250)	PCM - Powertrain Control Module	EXE
FX23-14C204-TTE.vbf	Jaguar XF (X250)	PCM - Powertrain Control Module	EXE
FX23-14C273-TA.vbf	Jaguar XF (X250)	PCM - Powertrain Control Module	SBL
FX23-14C273-TB.vbf	Jaguar XF (X250)	PCM - Powertrain Control Module	SBL
FX23-14C434-AA.vbf	Jaguar XF (X250)	TPM - Tire Pressure Monitor Module	SIGCFG
FX23-14C621-AD.vbf	Jaguar XF (X250)	FCDIM - Front Control/Display Interface Module	EXE
FX23-14E093-AA.vbf	Jaguar XF (X250)	CHCM - Chassis Control Module	EXE
FX23-14E094-AFB.vbf	Jaguar XF (X250)	CHCM - Chassis Control Module	EXE
FX23-14E094-AXA.vbf	Jaguar XF (X250)	CHCM - Chassis Control Module	EXE
FX23-7J104-ADE.vbf	Jaguar XF (X250)	TCM - Transmission Control Module	EXE
FX53-14C060-AD.vbf	Jaguar F-Type (X152)	FCDIM - Front Control/Display Interface Module	EXE
FX53-14C060-AE.vbf	Jaguar F-Type (X152)	FCDIM - Front Control/Display Interface Module	EXE
FX53-14C060-AF.vbf	Jaguar F-Type (X152)	FCDIM - Front Control/Display Interface Module	EXE
FX53-14C060-AG.vbf	Jaguar F-Type (X152)	FCDIM - Front Control/Display Interface Module	EXE
FX53-14C060-AH.vbf	Jaguar F-Type (X152)	FCDIM - Front Control/Display Interface Module	EXE
FX53-14C061-AD.vbf	Jaguar F-Type (X152)	FCDIM - Front Control/Display Interface Module	DATA
FX53-14C061-AE.vbf	Jaguar F-Type (X152)	FCDIM - Front Control/Display Interface Module	DATA
FX53-14C061-AF.vbf	Jaguar F-Type (X152)	FCDIM - Front Control/Display Interface Module	DATA
FX53-14C061-AG.vbf	Jaguar F-Type (X152)	FCDIM - Front Control/Display Interface Module	DATA
FX53-14C061-AH.vbf	Jaguar F-Type (X152)	FCDIM - Front Control/Display Interface Module	DATA
FX53-14C063-AA.vbf	Jaguar F-Type (X152)	FCDIM - Front Control/Display Interface Module	SBL
FX53-14C204-TAD.vbf	Jaguar F-Type (X152)	PCM - Powertrain Control Module	EXE
FX53-14C204-TAE.vbf	Jaguar F-Type (X152)	PCM - Powertrain Control Module	EXE
FX53-14C204-TCC.vbf	Jaguar F-Type (X152)	PCM - Powertrain Control Module	EXE
FX53-14C204-TCD.vbf	Jaguar F-Type (X152)	PCM - Powertrain Control Module	EXE
FX53-14C204-TEC.vbf	Jaguar F-Type (X152)	PCM - Powertrain Control Module	EXE
FX53-14C204-TED.vbf	Jaguar F-Type (X152)	PCM - Powertrain Control Module	EXE
FX53-14C204-TTE.vbf	Jaguar F-Type (X152)	PCM - Powertrain Control Module	EXE
FX53-14C204-TTF.vbf	Jaguar F-Type (X152)	PCM - Powertrain Control Module	EXE
FX53-14C204-UAE.vbf	Jaguar F-Type (X152)	PCM - Powertrain Control Module	EXE
FX53-14C204-UAF.vbf	Jaguar F-Type (X152)	PCM - Powertrain Control Module	EXE
FX53-14C204-UCC.vbf	Jaguar F-Type (X152)	PCM - Powertrain Control Module	EXE
FX53-14C204-UCD.vbf	Jaguar F-Type (X152)	PCM - Powertrain Control Module	EXE
FX53-14C204-UEC.vbf	Jaguar F-Type (X152)	PCM - Powertrain Control Module	EXE
FX53-14C204-UED.vbf	Jaguar F-Type (X152)	PCM - Powertrain Control Module	EXE
FX53-14C204-UTE.vbf	Jaguar F-Type (X152)	PCM - Powertrain Control Module	EXE
FX53-14C204-UTF.vbf	Jaguar F-Type (X152)	PCM - Powertrain Control Module	EXE
FX53-14C621-AD.vbf	Jaguar F-Type (X152)	FCDIM - Front Control/Display Interface Module	EXE
G2C2-14C065-AA.vbf	Discovery Sport (L550)	DDM - Driver Front Door Module	DATA
G2C2-14C065-AB.vbf	Discovery Sport (L550)	DDM - Driver Front Door Module	DATA
G2C2-14C065-AC.vbf	Discovery Sport (L550)	DDM - Driver Front Door Module	DATA
G2C2-14C069-AA.vbf	Discovery Sport (L550)	DRDM - Driver Rear Door Module	DATA
G2C2-14C069-AB.vbf	Discovery Sport (L550)	DRDM - Driver Rear Door Module	DATA
G2C2-14C069-AC.vbf	Discovery Sport (L550)	DRDM - Driver Rear Door Module	DATA
G2C2-14C109-AA.vbf	Discovery Sport (L550)	PDM - Passenger Front Door Module	DATA
G2C2-14C109-AB.vbf	Discovery Sport (L550)	PDM - Passenger Front Door Module	DATA
G2C2-14C109-AC.vbf	Discovery Sport (L550)	PDM - Passenger Front Door Module	DATA
G2C2-14C113-AA.vbf	Discovery Sport (L550)	PRDM - Passenger Rear Door Module	DATA
G2C2-14C113-AB.vbf	Discovery Sport (L550)	PRDM - Passenger Rear Door Module	DATA
G2C2-14C113-AC.vbf	Discovery Sport (L550)	PRDM - Passenger Rear Door Module	DATA
G2C2-14D564-AA.vbf	Discovery Sport (L550)	SODL - Side Obstacle Detection Control Module - Left	DATA
G2C2-14D564-BA.vbf	Discovery Sport (L550)	SODR - Side Obstacle Detection Control Module - Right	DATA
GCH2-14C065-AA.vbf	Range Rover Evoque (L538)	DDM - Driver Front Door Module	DATA
GCH2-14C065-AB.vbf	Range Rover Evoque (L538)	DDM - Driver Front Door Module	DATA
GCH2-14C065-AC.vbf	Range Rover Evoque (L538)	DDM - Driver Front Door Module	DATA
GCH2-14C065-AD.vbf	Range Rover Evoque (L538)	DDM - Driver Front Door Module	DATA
GCH2-14C069-AA.vbf	Range Rover Evoque (L538)	DRDM - Driver Rear Door Module	DATA
GCH2-14C069-AB.vbf	Range Rover Evoque (L538)	DRDM - Driver Rear Door Module	DATA
GCH2-14C069-AC.vbf	Range Rover Evoque (L538)	DRDM - Driver Rear Door Module	DATA
GCH2-14C069-AD.vbf	Range Rover Evoque (L538)	DRDM - Driver Rear Door Module	DATA
GCH2-14C109-AA.vbf	Range Rover Evoque (L538)	PDM - Passenger Front Door Module	DATA
GCH2-14C109-AB.vbf	Range Rover Evoque (L538)	PDM - Passenger Front Door Module	DATA
GCH2-14C109-AC.vbf	Range Rover Evoque (L538)	PDM - Passenger Front Door Module	DATA
GCH2-14C109-AD.vbf	Range Rover Evoque (L538)	PDM - Passenger Front Door Module	DATA
GCH2-14C113-AA.vbf	Range Rover Evoque (L538)	PRDM - Passenger Rear Door Module	DATA
GCH2-14C113-AB.vbf	Range Rover Evoque (L538)	PRDM - Passenger Rear Door Module	DATA
GCH2-14C113-AC.vbf	Range Rover Evoque (L538)	PRDM - Passenger Rear Door Module	DATA

File name	Vehicle line (indicative)	Module (ECU)	Type
GCH2-14C113-AD.vbf	Range Rover Evoque (L538)	PRDM - Passenger Rear Door Module	DATA
GH22-12K532-PAA.vbf	Discovery 3/4 (L319)	PCM - Powertrain Control Module	DATA
GH22-12K532-PAB.vbf	Discovery 3/4 (L319)	PCM - Powertrain Control Module	DATA
GH22-12K532-PAC.vbf	Discovery 3/4 (L319)	PCM - Powertrain Control Module	DATA
GH22-12K532-PAD.vbf	Discovery 3/4 (L319)	PCM - Powertrain Control Module	DATA
GH22-12K532-PBA.vbf	Discovery 3/4 (L319)	PCM - Powertrain Control Module	DATA
GH22-12K532-PBB.vbf	Discovery 3/4 (L319)	PCM - Powertrain Control Module	DATA
GH22-12K532-PBC.vbf	Discovery 3/4 (L319)	PCM - Powertrain Control Module	DATA
GH22-12K532-PBD.vbf	Discovery 3/4 (L319)	PCM - Powertrain Control Module	DATA
GH22-12K532-PCA.vbf	Discovery 3/4 (L319)	PCM - Powertrain Control Module	DATA
GH22-12K532-PCB.vbf	Discovery 3/4 (L319)	PCM - Powertrain Control Module	DATA
GH22-12K532-PCC.vbf	Discovery 3/4 (L319)	PCM - Powertrain Control Module	DATA
GH22-12K532-PCD.vbf	Discovery 3/4 (L319)	PCM - Powertrain Control Module	DATA
GH22-12K532-PLA.vbf	Discovery 3/4 (L319)	PCM - Powertrain Control Module	DATA
GH22-12K532-PLB.vbf	Discovery 3/4 (L319)	PCM - Powertrain Control Module	DATA
GH22-12K532-PLC.vbf	Discovery 3/4 (L319)	PCM - Powertrain Control Module	DATA
GH22-12K532-PLD.vbf	Discovery 3/4 (L319)	PCM - Powertrain Control Module	DATA
GH22-12K532-PLE.vbf	Discovery 3/4 (L319)	PCM - Powertrain Control Module	DATA
GH22-12K532-PLF.vbf	Discovery 3/4 (L319)	PCM - Powertrain Control Module	DATA
GH22-12K532-PMA.vbf	Discovery 3/4 (L319)	PCM - Powertrain Control Module	DATA
GH22-12K532-PMB.vbf	Discovery 3/4 (L319)	PCM - Powertrain Control Module	DATA
GH22-12K532-PMC.vbf	Discovery 3/4 (L319)	PCM - Powertrain Control Module	DATA
GH22-12K532-PMD.vbf	Discovery 3/4 (L319)	PCM - Powertrain Control Module	DATA
GH22-12K532-PME.vbf	Discovery 3/4 (L319)	PCM - Powertrain Control Module	DATA
GH22-12K532-PMF.vbf	Discovery 3/4 (L319)	PCM - Powertrain Control Module	DATA
GH22-12K532-PNA.vbf	Discovery 3/4 (L319)	PCM - Powertrain Control Module	DATA
GH22-12K532-PNB.vbf	Discovery 3/4 (L319)	PCM - Powertrain Control Module	DATA
GH22-12K532-PNC.vbf	Discovery 3/4 (L319)	PCM - Powertrain Control Module	DATA
GH22-12K532-PND.vbf	Discovery 3/4 (L319)	PCM - Powertrain Control Module	DATA
GH22-12K532-PNE.vbf	Discovery 3/4 (L319)	PCM - Powertrain Control Module	DATA
GH22-12K532-PNF.vbf	Discovery 3/4 (L319)	PCM - Powertrain Control Module	DATA
GH22-14C026-AA.vbf	Discovery 3/4 (L319)	IPC - Instrument Panel Cluster (IPC) Control Module	EXE
GH22-14C026-AB.vbf	Discovery 3/4 (L319)	IPC - Instrument Panel Cluster (IPC) Control Module	EXE
GH22-14C026-AC.vbf	Discovery 3/4 (L319)	IPC - Instrument Panel Cluster (IPC) Control Module	EXE
GH22-14C026-BA.vbf	Discovery 3/4 (L319)	IPC - Instrument Panel Cluster (IPC) Control Module	EXE
GH22-14C026-BB.vbf	Discovery 3/4 (L319)	IPC - Instrument Panel Cluster (IPC) Control Module	EXE
GH22-14C026-BC.vbf	Discovery 3/4 (L319)	IPC - Instrument Panel Cluster (IPC) Control Module	EXE
GH22-14C036-AB.vbf	Discovery 3/4 (L319)	ABS - Anit-Lock Brake System (ABS) Control Module	EXE
GH22-14C036-AC.vbf	Discovery 3/4 (L319)	ABS - Anit-Lock Brake System (ABS) Control Module	EXE
GH22-14C060-AB.vbf	Discovery 3/4 (L319)	FCDIM - Front Control/Display Interface Module	EXE
GH22-14C060-AC.vbf	Discovery 3/4 (L319)	FCDIM - Front Control/Display Interface Module	EXE
GH22-14C060-AD.vbf	Discovery 3/4 (L319)	FCDIM - Front Control/Display Interface Module	EXE
GH22-14C060-AE.vbf	Discovery 3/4 (L319)	FCDIM - Front Control/Display Interface Module	EXE
GH22-14C060-AF.vbf	Discovery 3/4 (L319)	FCDIM - Front Control/Display Interface Module	EXE
GH22-14C061-AB.vbf	Discovery 3/4 (L319)	FCDIM - Front Control/Display Interface Module	DATA
GH22-14C061-AC.vbf	Discovery 3/4 (L319)	FCDIM - Front Control/Display Interface Module	DATA
GH22-14C061-AD.vbf	Discovery 3/4 (L319)	FCDIM - Front Control/Display Interface Module	DATA
GH22-14C061-AE.vbf	Discovery 3/4 (L319)	FCDIM - Front Control/Display Interface Module	DATA
GH22-14C061-AF.vbf	Discovery 3/4 (L319)	FCDIM - Front Control/Display Interface Module	DATA
GH22-14C063-AA.vbf	Discovery 3/4 (L319)	FCDIM - Front Control/Display Interface Module	SBL
GH22-14C088-AA.vbf	Discovery 3/4 (L319)	IPC - Instrument Panel Cluster (IPC) Control Module	DATA
GH22-14C088-AB.vbf	Discovery 3/4 (L319)	IPC - Instrument Panel Cluster (IPC) Control Module	DATA
GH22-14C088-AC.vbf	Discovery 3/4 (L319)	IPC - Instrument Panel Cluster (IPC) Control Module	DATA
GH22-14C105-AA.vbf	Discovery 3/4 (L319)	TMC Traffic Message Channel Module	DATA
GH22-14C105-AC.vbf	Discovery 3/4 (L319)	TMC Traffic Message Channel Module	DATA
GH22-14C185-AA.VBF	Discovery 3/4 (L319)	BCM - Body Control Module	DATA
GH22-14C204-PAA.vbf	Discovery 3/4 (L319)	PCM - Powertrain Control Module	EXE
GH22-14C204-PAB.vbf	Discovery 3/4 (L319)	PCM - Powertrain Control Module	EXE
GH22-14C204-PAC.vbf	Discovery 3/4 (L319)	PCM - Powertrain Control Module	EXE
GH22-14C527-AA.vbf	Discovery 3/4 (L319)	Not specified	DATA
GH22-14C621-AB.vbf	Discovery 3/4 (L319)	FCDIM - Front Control/Display Interface Module	EXE
GH22-14F530-AA.vbf	Discovery 3/4 (L319)	GWM - Gateway Module A	EXE
GH22-14F530-AB.vbf	Discovery 3/4 (L319)	GWM - Gateway Module A	EXE
GH22-14F531-AA.vbf	Discovery 3/4 (L319)	GWM - Gateway Module A	DATA
GH22-14F531-AB.vbf	Discovery 3/4 (L319)	GWM - Gateway Module A	DATA
GH22-14F531-AC.vbf	Discovery 3/4 (L319)	GWM - Gateway Module A	DATA
GH22-14F531-AD.vbf	Discovery 3/4 (L319)	GWM - Gateway Module A	DATA
GH22-7J104-ACB.vbf	Discovery 3/4 (L319)	TCM - Transmission Control Module	EXE
GH22-7J104-ACC.vbf	Discovery 3/4 (L319)	TCM - Transmission Control Module	EXE
GH22-7J104-ACD.vbf	Discovery 3/4 (L319)	TCM - Transmission Control Module	EXE
GH22-7J104-AJB.vbf	Discovery 3/4 (L319)	TCM - Transmission Control Module	EXE
GH22-7J104-AKB.vbf	Discovery 3/4 (L319)	TCM - Transmission Control Module	EXE
GH22-7J104-AVA.vbf	Discovery 3/4 (L319)	TCM - Transmission Control Module	EXE
GH22-7J104-AVB.vbf	Discovery 3/4 (L319)	TCM - Transmission Control Module	EXE
GH2M-14C098-XA.vbf	Not specified	RCM - Restraints Control Module	DATA
GH2M-14C527-AA.vbf	Not specified	Not specified	DATA

File name	Vehicle line (indicative)	Module (ECU)	Type
GH2M-14C527-BA.vbf	Not specified	Not specified	DATA
GJ32-12K532-FBA.vbf	Range Rover Evoque (L538)	PCM - Powertrain Control Module	DATA
GJ32-12K532-FBB.vbf	Range Rover Evoque (L538)	PCM - Powertrain Control Module	DATA
GJ32-12K532-FBC.vbf	Range Rover Evoque (L538)	PCM - Powertrain Control Module	DATA
GJ32-12K532-FBD.vbf	Range Rover Evoque (L538)	PCM - Powertrain Control Module	DATA
GJ32-12K532-FBE.vbf	Range Rover Evoque (L538)	PCM - Powertrain Control Module	DATA
GJ32-12K532-FBF.vbf	Range Rover Evoque (L538)	PCM - Powertrain Control Module	DATA
GJ32-12K532-FBG.vbf	Range Rover Evoque (L538)	PCM - Powertrain Control Module	DATA
GJ32-12K532-FBH.vbf	Range Rover Evoque (L538)	PCM - Powertrain Control Module	DATA
GJ32-12K532-FBJ.vbf	Range Rover Evoque (L538)	PCM - Powertrain Control Module	DATA
GJ32-12K532-FBK.vbf	Range Rover Evoque (L538)	PCM - Powertrain Control Module	DATA
GJ32-12K532-FSA.vbf	Range Rover Evoque (L538)	PCM - Powertrain Control Module	DATA
GJ32-12K532-FTA.vbf	Range Rover Evoque (L538)	PCM - Powertrain Control Module	DATA
GJ32-12K532-FUA.vbf	Range Rover Evoque (L538)	PCM - Powertrain Control Module	DATA
GJ32-12K532-FVA.vbf	Range Rover Evoque (L538)	PCM - Powertrain Control Module	DATA
GJ32-12K532-FXA.vbf	Range Rover Evoque (L538)	PCM - Powertrain Control Module	DATA
GJ32-12K532-FYA.vbf	Range Rover Evoque (L538)	PCM - Powertrain Control Module	DATA
GJ32-12K532-FZA.vbf	Range Rover Evoque (L538)	PCM - Powertrain Control Module	DATA
GJ32-12K532-GAA.vbf	Range Rover Evoque (L538)	PCM - Powertrain Control Module	DATA
GJ32-12K532-GAB.vbf	Range Rover Evoque (L538)	PCM - Powertrain Control Module	DATA
GJ32-12K532-GAC.vbf	Range Rover Evoque (L538)	PCM - Powertrain Control Module	DATA
GJ32-12K532-GAD.vbf	Range Rover Evoque (L538)	PCM - Powertrain Control Module	DATA
GJ32-12K532-GAE.vbf	Range Rover Evoque (L538)	PCM - Powertrain Control Module	DATA
GJ32-12K532-GAF.vbf	Range Rover Evoque (L538)	PCM - Powertrain Control Module	DATA
GJ32-12K532-GAG.vbf	Range Rover Evoque (L538)	PCM - Powertrain Control Module	DATA
GJ32-12K532-GAH.vbf	Range Rover Evoque (L538)	PCM - Powertrain Control Module	DATA
GJ32-12K532-GAJ.vbf	Range Rover Evoque (L538)	PCM - Powertrain Control Module	DATA
GJ32-12K532-GAK.vbf	Range Rover Evoque (L538)	PCM - Powertrain Control Module	DATA
GJ32-12K532-GAL.vbf	Range Rover Evoque (L538)	PCM - Powertrain Control Module	DATA
GJ32-12K532-GBA.vbf	Range Rover Evoque (L538)	PCM - Powertrain Control Module	DATA
GJ32-12K532-GBB.vbf	Range Rover Evoque (L538)	PCM - Powertrain Control Module	DATA
GJ32-12K532-GBC.vbf	Range Rover Evoque (L538)	PCM - Powertrain Control Module	DATA
GJ32-12K532-GBD.vbf	Range Rover Evoque (L538)	PCM - Powertrain Control Module	DATA
GJ32-12K532-GBE.vbf	Range Rover Evoque (L538)	PCM - Powertrain Control Module	DATA
GJ32-12K532-GBF.vbf	Range Rover Evoque (L538)	PCM - Powertrain Control Module	DATA
GJ32-12K532-GBG.vbf	Range Rover Evoque (L538)	PCM - Powertrain Control Module	DATA
GJ32-12K532-GBH.vbf	Range Rover Evoque (L538)	PCM - Powertrain Control Module	DATA
GJ32-12K532-GBJ.vbf	Range Rover Evoque (L538)	PCM - Powertrain Control Module	DATA
GJ32-12K532-GBK.vbf	Range Rover Evoque (L538)	PCM - Powertrain Control Module	DATA
GJ32-12K532-GBL.vbf	Range Rover Evoque (L538)	PCM - Powertrain Control Module	DATA
GJ32-12K532-GCA.vbf	Range Rover Evoque (L538)	PCM - Powertrain Control Module	DATA
GJ32-12K532-GCB.vbf	Range Rover Evoque (L538)	PCM - Powertrain Control Module	DATA
GJ32-12K532-GCD.vbf	Range Rover Evoque (L538)	PCM - Powertrain Control Module	DATA
GJ32-12K532-GCE.vbf	Range Rover Evoque (L538)	PCM - Powertrain Control Module	DATA
GJ32-12K532-GCF.vbf	Range Rover Evoque (L538)	PCM - Powertrain Control Module	DATA
GJ32-12K532-GCG.vbf	Range Rover Evoque (L538)	PCM - Powertrain Control Module	DATA
GJ32-12K532-GCH.vbf	Range Rover Evoque (L538)	PCM - Powertrain Control Module	DATA
GJ32-12K532-GCJ.vbf	Range Rover Evoque (L538)	PCM - Powertrain Control Module	DATA
GJ32-12K532-GCK.vbf	Range Rover Evoque (L538)	PCM - Powertrain Control Module	DATA
GJ32-12K532-GCL.vbf	Range Rover Evoque (L538)	PCM - Powertrain Control Module	DATA
GJ32-12K532-GDA.vbf	Range Rover Evoque (L538)	PCM - Powertrain Control Module	DATA
GJ32-12K532-GDB.vbf	Range Rover Evoque (L538)	PCM - Powertrain Control Module	DATA
GJ32-12K532-GDC.vbf	Range Rover Evoque (L538)	PCM - Powertrain Control Module	DATA
GJ32-12K532-GDD.vbf	Range Rover Evoque (L538)	PCM - Powertrain Control Module	DATA
GJ32-12K532-GDE.vbf	Range Rover Evoque (L538)	PCM - Powertrain Control Module	DATA
GJ32-12K532-GDF.vbf	Range Rover Evoque (L538)	PCM - Powertrain Control Module	DATA
GJ32-12K532-GDG.vbf	Range Rover Evoque (L538)	PCM - Powertrain Control Module	DATA
GJ32-12K532-GDH.vbf	Range Rover Evoque (L538)	PCM - Powertrain Control Module	DATA
GJ32-12K532-GDJ.vbf	Range Rover Evoque (L538)	PCM - Powertrain Control Module	DATA
GJ32-12K532-GDK.vbf	Range Rover Evoque (L538)	PCM - Powertrain Control Module	DATA
GJ32-12K532-GDL.vbf	Range Rover Evoque (L538)	PCM - Powertrain Control Module	DATA
GJ32-12K532-GEB.vbf	Range Rover Evoque (L538)	PCM - Powertrain Control Module	DATA
GJ32-12K532-GEC.vbf	Range Rover Evoque (L538)	PCM - Powertrain Control Module	DATA
GJ32-12K532-GED.vbf	Range Rover Evoque (L538)	PCM - Powertrain Control Module	DATA
GJ32-12K532-GFB.vbf	Range Rover Evoque (L538)	PCM - Powertrain Control Module	DATA
GJ32-12K532-GFC.vbf	Range Rover Evoque (L538)	PCM - Powertrain Control Module	DATA
GJ32-12K532-GFD.vbf	Range Rover Evoque (L538)	PCM - Powertrain Control Module	DATA
GJ32-12K532-GLB.vbf	Range Rover Evoque (L538)	PCM - Powertrain Control Module	DATA
GJ32-12K532-GLC.vbf	Range Rover Evoque (L538)	PCM - Powertrain Control Module	DATA
GJ32-12K532-GLD.vbf	Range Rover Evoque (L538)	PCM - Powertrain Control Module	DATA
GJ32-12K532-GLE.vbf	Range Rover Evoque (L538)	PCM - Powertrain Control Module	DATA
GJ32-12K532-GLF.vbf	Range Rover Evoque (L538)	PCM - Powertrain Control Module	DATA
GJ32-12K532-GLG.vbf	Range Rover Evoque (L538)	PCM - Powertrain Control Module	DATA
GJ32-12K532-GLH.vbf	Range Rover Evoque (L538)	PCM - Powertrain Control Module	DATA
GJ32-12K532-GLJ.vbf	Range Rover Evoque (L538)	PCM - Powertrain Control Module	DATA
GJ32-12K532-GLK.vbf	Range Rover Evoque (L538)	PCM - Powertrain Control Module	DATA

File name	Vehicle line (indicative)	Module (ECU)	Type
GJ32-12K532-GLL.vbf	Range Rover Evoque (L538)	PCM - Powertrain Control Module	DATA
GJ32-12K532-GTA.vbf	Range Rover Evoque (L538)	PCM - Powertrain Control Module	DATA
GJ32-12K532-GTB.vbf	Range Rover Evoque (L538)	PCM - Powertrain Control Module	DATA
GJ32-12K532-GTC.vbf	Range Rover Evoque (L538)	PCM - Powertrain Control Module	DATA
GJ32-12K532-GTD.vbf	Range Rover Evoque (L538)	PCM - Powertrain Control Module	DATA
GJ32-12K532-GTE.vbf	Range Rover Evoque (L538)	PCM - Powertrain Control Module	DATA
GJ32-12K532-GTF.vbf	Range Rover Evoque (L538)	PCM - Powertrain Control Module	DATA
GJ32-12K532-GTG.vbf	Range Rover Evoque (L538)	PCM - Powertrain Control Module	DATA
GJ32-12K532-GTH.vbf	Range Rover Evoque (L538)	PCM - Powertrain Control Module	DATA
GJ32-12K532-GTJ.vbf	Range Rover Evoque (L538)	PCM - Powertrain Control Module	DATA
GJ32-12K532-GTK.vbf	Range Rover Evoque (L538)	PCM - Powertrain Control Module	DATA
GJ32-12K532-GTL.vbf	Range Rover Evoque (L538)	PCM - Powertrain Control Module	DATA
GJ32-12K532-VEA.vbf	Range Rover Evoque (L538)	PCM - Powertrain Control Module	DATA
GJ32-12K532-VEB.vbf	Range Rover Evoque (L538)	PCM - Powertrain Control Module	DATA
GJ32-14C025-AA.vbf	Range Rover Evoque (L538)	IPC - Instrument Panel Cluster (IPC) Control Module	SBL
GJ32-14C025-AB.vbf	Range Rover Evoque (L538)	IPC - Instrument Panel Cluster (IPC) Control Module	SBL
GJ32-14C026-AE.vbf	Range Rover Evoque (L538)	IPC - Instrument Panel Cluster (IPC) Control Module	EXE
GJ32-14C026-AF.vbf	Range Rover Evoque (L538)	IPC - Instrument Panel Cluster (IPC) Control Module	EXE
GJ32-14C026-AG.vbf	Range Rover Evoque (L538)	IPC - Instrument Panel Cluster (IPC) Control Module	EXE
GJ32-14C026-AH.vbf	Range Rover Evoque (L538)	IPC - Instrument Panel Cluster (IPC) Control Module	EXE
GJ32-14C026-PA.vbf	Range Rover Evoque (L538)	IPC - Instrument Panel Cluster (IPC) Control Module	EXE
GJ32-14C026-PB.vbf	Range Rover Evoque (L538)	IPC - Instrument Panel Cluster (IPC) Control Module	EXE
GJ32-14C026-PC.vbf	Range Rover Evoque (L538)	IPC - Instrument Panel Cluster (IPC) Control Module	EXE
GJ32-14C026-PD.vbf	Range Rover Evoque (L538)	IPC - Instrument Panel Cluster (IPC) Control Module	EXE
GJ32-14C026-PE.vbf	Range Rover Evoque (L538)	IPC - Instrument Panel Cluster (IPC) Control Module	EXE
GJ32-14C026-PF.vbf	Range Rover Evoque (L538)	IPC - Instrument Panel Cluster (IPC) Control Module	EXE
GJ32-14C028-AB.vbf	Range Rover Evoque (L538)	RCM - Restraints Control Module	EXE
GJ32-14C028-AC.vbf	Range Rover Evoque (L538)	RCM - Restraints Control Module	EXE
GJ32-14C029-AA.vbf	Range Rover Evoque (L538)	DSM - Driver Front Seat Module	SBL
GJ32-14C030-BB.vbf	Range Rover Evoque (L538)	DSM - Driver Front Seat Module	EXE
GJ32-14C030-BC.vbf	Range Rover Evoque (L538)	DSM - Driver Front Seat Module	EXE
GJ32-14C030-BD.vbf	Range Rover Evoque (L538)	DSM - Driver Front Seat Module	EXE
GJ32-14C030-BE.vbf	Range Rover Evoque (L538)	DSM - Driver Front Seat Module	EXE
GJ32-14C030-BF.vbf	Range Rover Evoque (L538)	DSM - Driver Front Seat Module	EXE
GJ32-14C030-BG.vbf	Range Rover Evoque (L538)	DSM - Driver Front Seat Module	EXE
GJ32-14C030-BH.vbf	Range Rover Evoque (L538)	DSM - Driver Front Seat Module	EXE
GJ32-14C034-BB.vbf	Range Rover Evoque (L538)	DSM - Driver Front Seat Module	EXE
GJ32-14C034-BC.vbf	Range Rover Evoque (L538)	DSM - Driver Front Seat Module	EXE
GJ32-14C034-BD.vbf	Range Rover Evoque (L538)	DSM - Driver Front Seat Module	EXE
GJ32-14C034-CB.vbf	Range Rover Evoque (L538)	DSM - Driver Front Seat Module	EXE
GJ32-14C034-CC.vbf	Range Rover Evoque (L538)	DSM - Driver Front Seat Module	EXE
GJ32-14C034-CD.vbf	Range Rover Evoque (L538)	DSM - Driver Front Seat Module	EXE
GJ32-14C034-DB.vbf	Range Rover Evoque (L538)	DSM - Driver Front Seat Module	EXE
GJ32-14C034-DC.vbf	Range Rover Evoque (L538)	DSM - Driver Front Seat Module	EXE
GJ32-14C034-DD.vbf	Range Rover Evoque (L538)	DSM - Driver Front Seat Module	EXE
GJ32-14C036-AD.vbf	Range Rover Evoque (L538)	ABS - Anit-Lock Brake System (ABS) Control Module	EXE
GJ32-14C036-AE.vbf	Range Rover Evoque (L538)	ABS - Anit-Lock Brake System (ABS) Control Module	EXE
GJ32-14C036-AF.vbf	Range Rover Evoque (L538)	ABS - Anit-Lock Brake System (ABS) Control Module	EXE
GJ32-14C036-AG.vbf	Discovery Sport (L550)	ABS - Anit-Lock Brake System (ABS) Control Module	EXE
GJ32-14C036-AH.vbf	Range Rover Evoque (L538)	ABS - Anit-Lock Brake System (ABS) Control Module	EXE
GJ32-14C036-AK.vbf	Range Rover Evoque (L538)	ABS - Anit-Lock Brake System (ABS) Control Module	EXE
GJ32-14C036-AL.vbf	Range Rover Evoque (L538)	ABS - Anit-Lock Brake System (ABS) Control Module	EXE
GJ32-14C036-AM.vbf	Range Rover Evoque (L538)	ABS - Anit-Lock Brake System (ABS) Control Module	EXE
GJ32-14C036-AN.vbf	Range Rover Evoque (L538)	ABS - Anit-Lock Brake System (ABS) Control Module	EXE
GJ32-14C036-AP.vbf	Range Rover Evoque (L538)	ABS - Anit-Lock Brake System (ABS) Control Module	EXE
GJ32-14C039-AA.vbf	Range Rover Evoque (L538)	ABS - Anit-Lock Brake System (ABS) Control Module	SBL
GJ32-14C060-AC.vbf	Range Rover Evoque (L538)	FCDIM - Front Control/Display Interface Module	EXE
GJ32-14C060-AD.vbf	Range Rover Evoque (L538)	FCDIM - Front Control/Display Interface Module	EXE
GJ32-14C060-AE.vbf	Range Rover Evoque (L538)	FCDIM - Front Control/Display Interface Module	EXE
GJ32-14C060-AF.vbf	Range Rover Evoque (L538)	FCDIM - Front Control/Display Interface Module	EXE
GJ32-14C060-AG.vbf	Range Rover Evoque (L538)	FCDIM - Front Control/Display Interface Module	EXE
GJ32-14C060-AH.vbf	Range Rover Evoque (L538)	FCDIM - Front Control/Display Interface Module	EXE
GJ32-14C060-BC.vbf	Range Rover Evoque (L538)	FCDIM - Front Control/Display Interface Module	EXE
GJ32-14C060-BD.vbf	Range Rover Evoque (L538)	FCDIM - Front Control/Display Interface Module	EXE
GJ32-14C060-BE.vbf	Range Rover Evoque (L538)	FCDIM - Front Control/Display Interface Module	EXE
GJ32-14C060-BF.vbf	Range Rover Evoque (L538)	FCDIM - Front Control/Display Interface Module	EXE
GJ32-14C060-BG.vbf	Range Rover Evoque (L538)	FCDIM - Front Control/Display Interface Module	EXE
GJ32-14C060-BH.vbf	Range Rover Evoque (L538)	FCDIM - Front Control/Display Interface Module	EXE
GJ32-14C061-AB.vbf	Range Rover Evoque (L538)	FCDIM - Front Control/Display Interface Module	DATA
GJ32-14C061-AC.vbf	Range Rover Evoque (L538)	FCDIM - Front Control/Display Interface Module	DATA
GJ32-14C061-AD.vbf	Range Rover Evoque (L538)	FCDIM - Front Control/Display Interface Module	DATA
GJ32-14C061-AE.vbf	Range Rover Evoque (L538)	FCDIM - Front Control/Display Interface Module	DATA
GJ32-14C061-AF.vbf	Range Rover Evoque (L538)	FCDIM - Front Control/Display Interface Module	DATA
GJ32-14C061-AG.vbf	Range Rover Evoque (L538)	FCDIM - Front Control/Display Interface Module	DATA
GJ32-14C061-AH.vbf	Range Rover Evoque (L538)	FCDIM - Front Control/Display Interface Module	DATA
GJ32-14C063-AA.vbf	Range Rover Evoque (L538)	FCDIM - Front Control/Display Interface Module	SBL

File name	Vehicle line (indicative)	Module (ECU)	Type
GJ32-14C064-AA.vbf	Range Rover Evoque (L538)	DDM - Driver Front Door Module	EXE
GJ32-14C064-BA.vbf	Range Rover Evoque (L538)	DDM - Driver Front Door Module	EXE
GJ32-14C064-CA.vbf	Range Rover Evoque (L538)	DDM - Driver Front Door Module	EXE
GJ32-14C064-DA.vbf	Range Rover Evoque (L538)	DDM - Driver Front Door Module	EXE
GJ32-14C065-AB.vbf	Range Rover Evoque (L538)	DDM - Driver Front Door Module	DATA
GJ32-14C065-AC.vbf	Range Rover Evoque (L538)	DDM - Driver Front Door Module	DATA
GJ32-14C065-AD.vbf	Range Rover Evoque (L538)	DDM - Driver Front Door Module	DATA
GJ32-14C065-AE.vbf	Range Rover Evoque (L538)	DDM - Driver Front Door Module	DATA
GJ32-14C065-AF.vbf	Range Rover Evoque (L538)	DDM - Driver Front Door Module	DATA
GJ32-14C065-BB.vbf	Range Rover Evoque (L538)	DDM - Driver Front Door Module	DATA
GJ32-14C065-BC.vbf	Range Rover Evoque (L538)	DDM - Driver Front Door Module	DATA
GJ32-14C065-BD.vbf	Range Rover Evoque (L538)	DDM - Driver Front Door Module	DATA
GJ32-14C065-BE.vbf	Range Rover Evoque (L538)	DDM - Driver Front Door Module	DATA
GJ32-14C065-BF.vbf	Range Rover Evoque (L538)	DDM - Driver Front Door Module	DATA
GJ32-14C065-CD.vbf	Range Rover Evoque (L538)	DDM - Driver Front Door Module	DATA
GJ32-14C065-CE.vbf	Range Rover Evoque (L538)	DDM - Driver Front Door Module	DATA
GJ32-14C065-CF.vbf	Range Rover Evoque (L538)	DDM - Driver Front Door Module	DATA
GJ32-14C065-CG.vbf	Range Rover Evoque (L538)	DDM - Driver Front Door Module	DATA
GJ32-14C065-CH.vbf	Range Rover Evoque (L538)	DDM - Driver Front Door Module	DATA
GJ32-14C065-CJ.vbf	Range Rover Evoque (L538)	DDM - Driver Front Door Module	DATA
GJ32-14C068-AA.vbf	Range Rover Evoque (L538)	DRDM - Driver Rear Door Module	EXE
GJ32-14C068-BA.vbf	Range Rover Evoque (L538)	DRDM - Driver Rear Door Module	EXE
GJ32-14C068-CA.vbf	Range Rover Evoque (L538)	DRDM - Driver Rear Door Module	EXE
GJ32-14C068-DA.vbf	Range Rover Evoque (L538)	DRDM - Driver Rear Door Module	EXE
GJ32-14C069-BB.vbf	Range Rover Evoque (L538)	DRDM - Driver Rear Door Module	DATA
GJ32-14C069-BC.vbf	Range Rover Evoque (L538)	DRDM - Driver Rear Door Module	DATA
GJ32-14C069-BD.vbf	Range Rover Evoque (L538)	DRDM - Driver Rear Door Module	DATA
GJ32-14C069-BE.vbf	Range Rover Evoque (L538)	DRDM - Driver Rear Door Module	DATA
GJ32-14C069-BF.vbf	Range Rover Evoque (L538)	DRDM - Driver Rear Door Module	DATA
GJ32-14C069-CD.vbf	Range Rover Evoque (L538)	DRDM - Driver Rear Door Module	DATA
GJ32-14C069-CE.vbf	Range Rover Evoque (L538)	DRDM - Driver Rear Door Module	DATA
GJ32-14C069-CF.vbf	Range Rover Evoque (L538)	DRDM - Driver Rear Door Module	DATA
GJ32-14C069-CG.vbf	Range Rover Evoque (L538)	DRDM - Driver Rear Door Module	DATA
GJ32-14C069-CH.vbf	Range Rover Evoque (L538)	DRDM - Driver Rear Door Module	DATA
GJ32-14C069-CJ.vbf	Range Rover Evoque (L538)	DRDM - Driver Rear Door Module	DATA
GJ32-14C088-BD.vbf	Range Rover Evoque (L538)	IPC - Instrument Panel Cluster (IPC) Control Module	DATA
GJ32-14C088-CC.vbf	Range Rover Evoque (L538)	IPC - Instrument Panel Cluster (IPC) Control Module	EXE
GJ32-14C088-CD.vbf	Range Rover Evoque (L538)	IPC - Instrument Panel Cluster (IPC) Control Module	EXE
GJ32-14C088-CE.vbf	Range Rover Evoque (L538)	IPC - Instrument Panel Cluster (IPC) Control Module	EXE
GJ32-14C088-DA.vbf	Range Rover Evoque (L538)	IPC - Instrument Panel Cluster (IPC) Control Module	DATA
GJ32-14C088-RA.vbf	Range Rover Evoque (L538)	IPC - Instrument Panel Cluster (IPC) Control Module	DATA
GJ32-14C088-RB.vbf	Range Rover Evoque (L538)	IPC - Instrument Panel Cluster (IPC) Control Module	DATA
GJ32-14C088-SA.vbf	Range Rover Evoque (L538)	IPC - Instrument Panel Cluster (IPC) Control Module	EXE
GJ32-14C088-SB.vbf	Range Rover Evoque (L538)	IPC - Instrument Panel Cluster (IPC) Control Module	EXE
GJ32-14C088-SC.vbf	Range Rover Evoque (L538)	IPC - Instrument Panel Cluster (IPC) Control Module	EXE
GJ32-14C088-SD.vbf	Range Rover Evoque (L538)	IPC - Instrument Panel Cluster (IPC) Control Module	EXE
GJ32-14C088-SE.vbf	Range Rover Evoque (L538)	IPC - Instrument Panel Cluster (IPC) Control Module	EXE
GJ32-14C091-AB.vbf	Range Rover Evoque (L538)	PAM - Parking Assist Control Module	DATA
GJ32-14C091-AC.vbf	Range Rover Evoque (L538)	PAM - Parking Assist Control Module	DATA
GJ32-14C091-AD.vbf	Range Rover Evoque (L538)	PAM - Parking Assist Control Module	DATA
GJ32-14C091-AE.vbf	Range Rover Evoque (L538)	PAM - Parking Assist Control Module	DATA
GJ32-14C091-AF.vbf	Range Rover Evoque (L538)	PAM - Parking Assist Control Module	DATA
GJ32-14C091-AG.vbf	Range Rover Evoque (L538)	PAM - Parking Assist Control Module	DATA
GJ32-14C091-AH.vbf	Range Rover Evoque (L538)	PAM - Parking Assist Control Module	DATA
GJ32-14C091-AJ.vbf	Range Rover Evoque (L538)	PAM - Parking Assist Control Module	DATA
GJ32-14C098-AB.vbf	Range Rover Evoque (L538)	RCM - Restraints Control Module	DATA
GJ32-14C098-AD.vbf	Range Rover Evoque (L538)	SRS - Airbag	DATA
GJ32-14C098-AE.vbf	Range Rover Evoque (L538)	SRS - Airbag	DATA
GJ32-14C098-BB.vbf	Range Rover Evoque (L538)	RCM - Restraints Control Module	DATA
GJ32-14C098-BC.vbf	Range Rover Evoque (L538)	SRS - Airbag	DATA
GJ32-14C098-BD.vbf	Range Rover Evoque (L538)	SRS - Airbag	DATA
GJ32-14C098-CB.vbf	Range Rover Evoque (L538)	RCM - Restraints Control Module	DATA
GJ32-14C098-CC.vbf	Range Rover Evoque (L538)	RCM - Restraints Control Module	DATA
GJ32-14C098-CD.vbf	Range Rover Evoque (L538)	SRS - Airbag	DATA
GJ32-14C098-CE.vbf	Range Rover Evoque (L538)	SRS - Airbag	DATA
GJ32-14C098-CF.vbf	Range Rover Evoque (L538)	SRS - Airbag	DATA
GJ32-14C098-DB.vbf	Range Rover Evoque (L538)	RCM - Restraints Control Module	DATA
GJ32-14C098-DC.vbf	Range Rover Evoque (L538)	RCM - Restraints Control Module	DATA
GJ32-14C098-DD.vbf	Range Rover Evoque (L538)	RCM - Restraints Control Module	DATA
GJ32-14C098-DE.vbf	Range Rover Evoque (L538)	SRS - Airbag	DATA
GJ32-14C098-DF.vbf	Range Rover Evoque (L538)	SRS - Airbag	DATA
GJ32-14C098-DG.vbf	Range Rover Evoque (L538)	SRS - Airbag	DATA
GJ32-14C105-EA.vbf	Range Rover Evoque (L538)	TMC Traffic Message Channel Module	DATA
GJ32-14C105-FA.vbf	Range Rover Evoque (L538)	TMC Traffic Message Channel Module	DATA
GJ32-14C108-AA.vbf	Range Rover Evoque (L538)	PDM - Passenger Front Door Module	EXE
GJ32-14C108-BA.vbf	Range Rover Evoque (L538)	PDM - Passenger Front Door Module	EXE

File name	Vehicle line (indicative)	Module (ECU)	Type
GJ32-14C108-CA.vbf	Range Rover Evoque (L538)	PDM - Passenger Front Door Module	EXE
GJ32-14C108-DA.vbf	Range Rover Evoque (L538)	PDM - Passenger Front Door Module	EXE
GJ32-14C109-AB.vbf	Range Rover Evoque (L538)	PDM - Passenger Front Door Module	DATA
GJ32-14C109-AC.vbf	Range Rover Evoque (L538)	PDM - Passenger Front Door Module	DATA
GJ32-14C109-AD.vbf	Range Rover Evoque (L538)	PDM - Passenger Front Door Module	DATA
GJ32-14C109-AE.vbf	Range Rover Evoque (L538)	PDM - Passenger Front Door Module	DATA
GJ32-14C109-AF.vbf	Range Rover Evoque (L538)	PDM - Passenger Front Door Module	DATA
GJ32-14C109-BB.vbf	Range Rover Evoque (L538)	PDM - Passenger Front Door Module	DATA
GJ32-14C109-BC.vbf	Range Rover Evoque (L538)	PDM - Passenger Front Door Module	DATA
GJ32-14C109-BD.vbf	Range Rover Evoque (L538)	PDM - Passenger Front Door Module	DATA
GJ32-14C109-BE.vbf	Range Rover Evoque (L538)	PDM - Passenger Front Door Module	DATA
GJ32-14C109-BF.vbf	Range Rover Evoque (L538)	PDM - Passenger Front Door Module	DATA
GJ32-14C109-CD.vbf	Range Rover Evoque (L538)	PDM - Passenger Front Door Module	DATA
GJ32-14C109-CE.vbf	Range Rover Evoque (L538)	PDM - Passenger Front Door Module	DATA
GJ32-14C109-CF.vbf	Range Rover Evoque (L538)	PDM - Passenger Front Door Module	DATA
GJ32-14C109-CG.vbf	Range Rover Evoque (L538)	PDM - Passenger Front Door Module	DATA
GJ32-14C109-CH.vbf	Range Rover Evoque (L538)	PDM - Passenger Front Door Module	DATA
GJ32-14C109-CJ.vbf	Range Rover Evoque (L538)	PDM - Passenger Front Door Module	DATA
GJ32-14C112-AA.vbf	Range Rover Evoque (L538)	PRDM - Passenger Rear Door Module	EXE
GJ32-14C112-BA.vbf	Range Rover Evoque (L538)	PRDM - Passenger Rear Door Module	EXE
GJ32-14C112-CA.vbf	Range Rover Evoque (L538)	PRDM - Passenger Rear Door Module	EXE
GJ32-14C112-DA.vbf	Range Rover Evoque (L538)	PRDM - Passenger Rear Door Module	EXE
GJ32-14C113-BB.vbf	Range Rover Evoque (L538)	PRDM - Passenger Rear Door Module	DATA
GJ32-14C113-BC.vbf	Range Rover Evoque (L538)	PRDM - Passenger Rear Door Module	DATA
GJ32-14C113-BD.vbf	Range Rover Evoque (L538)	PRDM - Passenger Rear Door Module	DATA
GJ32-14C113-BE.vbf	Range Rover Evoque (L538)	PRDM - Passenger Rear Door Module	DATA
GJ32-14C113-BF.vbf	Range Rover Evoque (L538)	PRDM - Passenger Rear Door Module	DATA
GJ32-14C113-CD.vbf	Range Rover Evoque (L538)	PRDM - Passenger Rear Door Module	DATA
GJ32-14C113-CE.vbf	Range Rover Evoque (L538)	PRDM - Passenger Rear Door Module	DATA
GJ32-14C113-CF.vbf	Range Rover Evoque (L538)	PRDM - Passenger Rear Door Module	DATA
GJ32-14C113-CG.vbf	Range Rover Evoque (L538)	PRDM - Passenger Rear Door Module	DATA
GJ32-14C113-CH.vbf	Range Rover Evoque (L538)	PRDM - Passenger Rear Door Module	DATA
GJ32-14C113-CJ.vbf	Range Rover Evoque (L538)	PRDM - Passenger Rear Door Module	DATA
GJ32-14C152-AC.vbf	Range Rover Evoque (L538)	TPM - Tire Pressure Monitor Module	DATA
GJ32-14C152-AD.vbf	Range Rover Evoque (L538)	TPM - Tire Pressure Monitor Module	DATA
GJ32-14C152-AE.vbf	Range Rover Evoque (L538)	TPM - Tire Pressure Monitor Module	DATA
GJ32-14C152-AF.vbf	Range Rover Evoque (L538)	TPM - Tire Pressure Monitor Module	DATA
GJ32-14C152-AG.vbf	Range Rover Evoque (L538)	TPM - Tire Pressure Monitor Module	DATA
GJ32-14C185-AA.VBF	Range Rover Evoque (L538)	BCM - Body Control Module	DATA
GJ32-14C185-AB.vbf	Range Rover Evoque (L538)	BCM - Body Control Module	DATA
GJ32-14C185-AC.VBF	Range Rover Evoque (L538)	BCM - Body Control Module	DATA
GJ32-14C185-AD.VBF	Range Rover Evoque (L538)	BCM - Body Control Module	DATA
GJ32-14C185-AE.vbf	Range Rover Evoque (L538)	BCM - Body Control Module	DATA
GJ32-14C204-MAA.vbf	Range Rover Evoque (L538)	PCM - Powertrain Control Module	EXE
GJ32-14C204-MAB.vbf	Range Rover Evoque (L538)	PCM - Powertrain Control Module	EXE
GJ32-14C204-MAC.vbf	Range Rover Evoque (L538)	PCM - Powertrain Control Module	EXE
GJ32-14C204-MAD.vbf	Range Rover Evoque (L538)	PCM - Powertrain Control Module	EXE
GJ32-14C204-MBA.vbf	Range Rover Evoque (L538)	PCM - Powertrain Control Module	EXE
GJ32-14C204-MBB.vbf	Range Rover Evoque (L538)	PCM - Powertrain Control Module	EXE
GJ32-14C204-MBC.vbf	Range Rover Evoque (L538)	PCM - Powertrain Control Module	EXE
GJ32-14C204-MBE.vbf	Range Rover Evoque (L538)	PCM - Powertrain Control Module	EXE
GJ32-14C204-MBF.vbf	Range Rover Evoque (L538)	PCM - Powertrain Control Module	EXE
GJ32-14C204-MCA.vbf	Range Rover Evoque (L538)	PCM - Powertrain Control Module	EXE
GJ32-14C204-MCB.vbf	Range Rover Evoque (L538)	PCM - Powertrain Control Module	EXE
GJ32-14C204-MCC.vbf	Range Rover Evoque (L538)	PCM - Powertrain Control Module	EXE
GJ32-14C204-MCE.vbf	Range Rover Evoque (L538)	PCM - Powertrain Control Module	EXE
GJ32-14C204-MCF.vbf	Range Rover Evoque (L538)	PCM - Powertrain Control Module	EXE
GJ32-14C204-MEA.vbf	Range Rover Evoque (L538)	PCM - Powertrain Control Module	EXE
GJ32-14C204-MEB.vbf	Range Rover Evoque (L538)	PCM - Powertrain Control Module	EXE
GJ32-14C204-MEC.vbf	Range Rover Evoque (L538)	PCM - Powertrain Control Module	EXE
GJ32-14C204-MEE.vbf	Range Rover Evoque (L538)	PCM - Powertrain Control Module	EXE
GJ32-14C204-MKA.vbf	Range Rover Evoque (L538)	PCM - Powertrain Control Module	EXE
GJ32-14C204-MKB.vbf	Range Rover Evoque (L538)	PCM - Powertrain Control Module	EXE
GJ32-14C204-MKC.vbf	Range Rover Evoque (L538)	PCM - Powertrain Control Module	EXE
GJ32-14C204-MKE.vbf	Range Rover Evoque (L538)	PCM - Powertrain Control Module	EXE
GJ32-14C204-MKF.vbf	Range Rover Evoque (L538)	PCM - Powertrain Control Module	EXE
GJ32-14C204-MNB.vbf	Range Rover Evoque (L538)	PCM - Powertrain Control Module	EXE
GJ32-14C204-MNC.vbf	Range Rover Evoque (L538)	PCM - Powertrain Control Module	EXE
GJ32-14C204-MNE.vbf	Range Rover Evoque (L538)	PCM - Powertrain Control Module	EXE
GJ32-14C204-MXA.vbf	Range Rover Evoque (L538)	PCM - Powertrain Control Module	EXE
GJ32-14C204-MXB.vbf	Range Rover Evoque (L538)	PCM - Powertrain Control Module	EXE
GJ32-14C204-MXC.vbf	Range Rover Evoque (L538)	PCM - Powertrain Control Module	EXE
GJ32-14C204-MXD.vbf	Range Rover Evoque (L538)	ECM - Engine Control Module	EXE
GJ32-14C217-AB.vbf	Range Rover Evoque (L538)	PSCM - Power Steering Control Module	EXE
GJ32-14C217-AC.vbf	Range Rover Evoque (L538)	PSCM - Power Steering Control Module	EXE
GJ32-14C218-AB.vbf	Range Rover Evoque (L538)	PSCM - Power Steering Control Module	EXE

File name	Vehicle line (indicative)	Module (ECU)	Type
GJ32-14C218-AC.vbf	Range Rover Evoque (L538)	PSCM - Power Steering Control Module	EXE
GJ32-14C218-BA.vbf	Range Rover Evoque (L538)	PSCM - Power Steering Control Module	EXE
GJ32-14C218-BB.vbf	Range Rover Evoque (L538)	PSCM - Power Steering Control Module	EXE
GJ32-14C218-CA.vbf	Range Rover Evoque (L538)	PSCM - Power Steering Control Module	EXE
GJ32-14C319-AB.vbf	Range Rover Evoque (L538)	HVAC - HVAC Control Module	SIGCFG
GJ32-14C319-AC.vbf	Range Rover Evoque (L538)	HVAC - HVAC Control Module	SIGCFG
GJ32-14C337-CAA.vbf	Range Rover Evoque (L538)	TCM - Transmission Control Module	EXE
GJ32-14C337-CAB.vbf	Range Rover Evoque (L538)	TCM - Transmission Control Module	EXE
GJ32-14C337-CAC.vbf	Range Rover Evoque (L538)	TCM - Transmission Control Module	EXE
GJ32-14C337-CAE.vbf	Range Rover Evoque (L538)	TCM - Transmission Control Module	EXE
GJ32-14C337-CBA.vbf	Range Rover Evoque (L538)	TCM - Transmission Control Module	EXE
GJ32-14C337-CBB.vbf	Range Rover Evoque (L538)	TCM - Transmission Control Module	EXE
GJ32-14C337-CBC.vbf	Range Rover Evoque (L538)	TCM - Transmission Control Module	EXE
GJ32-14C337-CBD.vbf	Range Rover Evoque (L538)	TCM - Transmission Control Module	EXE
GJ32-14C337-CLA.vbf	Range Rover Evoque (L538)	TCM - Transmission Control Module	EXE
GJ32-14C337-CLB.vbf	Range Rover Evoque (L538)	TCM - Transmission Control Module	EXE
GJ32-14C337-CLC.vbf	Range Rover Evoque (L538)	TCM - Transmission Control Module	EXE
GJ32-14C337-CLD.vbf	Range Rover Evoque (L538)	TCM - Transmission Control Module	EXE
GJ32-14C337-CLH.vbf	Range Rover Evoque (L538)	TCM - Transmission Control Module	EXE
GJ32-14C337-CLJ.vbf	Range Rover Evoque (L538)	TCM - Transmission Control Module	EXE
GJ32-14C339-AA.vbf	Range Rover Evoque (L538)	TCM - Transmission Control Module	SBL
GJ32-14C386-AC.vbf	Range Rover Evoque (L538)	PSCM - Power Steering Control Module	EXE
GJ32-14C386-BA.vbf	Range Rover Evoque (L538)	PSCM - Power Steering Control Module	EXE
GJ32-14C407-AA.vbf	Range Rover Evoque (L538)	RCM - Restraints Control Module	SIGCFG
GJ32-14C527-AA.vbf	Range Rover Evoque (L538)	Not specified	DATA
GJ32-14C527-BF.vbf	Range Rover Evoque (L538)	AAM - Audio Amplifier Module	DATA
GJ32-14C527-BG.vbf	Range Rover Evoque (L538)	AAM - Audio Amplifier Module	DATA
GJ32-14C527-BH.vbf	Range Rover Evoque (L538)	AAM - Audio Amplifier Module	DATA
GJ32-14C527-CF.vbf	Range Rover Evoque (L538)	AAM - Audio Amplifier Module	DATA
GJ32-14C527-FC.vbf	Range Rover Evoque (L538)	AAM - Audio Amplifier Module	DATA
GJ32-14C527-FD.vbf	Range Rover Evoque (L538)	AAM - Audio Amplifier Module	DATA
GJ32-14C527-FE.vbf	Range Rover Evoque (L538)	AAM - Audio Amplifier Module	DATA
GJ32-14C527-FF.vbf	Range Rover Evoque (L538)	AAM - Audio Amplifier Module	DATA
GJ32-14C527-GC.vbf	Range Rover Evoque (L538)	AAM - Audio Amplifier Module	DATA
GJ32-14C527-GD.vbf	Range Rover Evoque (L538)	AAM - Audio Amplifier Module	DATA
GJ32-14C527-GE.vbf	Range Rover Evoque (L538)	AAM - Audio Amplifier Module	DATA
GJ32-14C542-AB.vbf	Range Rover Evoque (L538)	SUMB - Suspension Control Module B	EXE
GJ32-14C542-AC.vbf	Range Rover Evoque (L538)	SUMB - Suspension Control Module B	EXE
GJ32-14C543-AB.vbf	Range Rover Evoque (L538)	SUMB - Suspension Control Module B	DATA
GJ32-14C543-AC.vbf	Range Rover Evoque (L538)	SUMB - Suspension Control Module B	DATA
GJ32-14C548-BB.vbf	Range Rover Evoque (L538)	PSM - Passenger Front Seat Module	EXE
GJ32-14C548-BC.vbf	Range Rover Evoque (L538)	PSM - Passenger Front Seat Module	EXE
GJ32-14C548-BD.vbf	Range Rover Evoque (L538)	PSM - Passenger Front Seat Module	EXE
GJ32-14C548-BE.vbf	Range Rover Evoque (L538)	PSM - Passenger Front Seat Module	EXE
GJ32-14C548-BF.vbf	Range Rover Evoque (L538)	PSM - Passenger Front Seat Module	EXE
GJ32-14C548-BG.vbf	Range Rover Evoque (L538)	PSM - Passenger Front Seat Module	EXE
GJ32-14C548-BH.vbf	Range Rover Evoque (L538)	PSM - Passenger Front Seat Module	EXE
GJ32-14C549-BB.vbf	Range Rover Evoque (L538)	PSM - Passenger Front Seat Module	EXE
GJ32-14C549-BC.vbf	Range Rover Evoque (L538)	PSM - Passenger Front Seat Module	EXE
GJ32-14C549-BD.vbf	Range Rover Evoque (L538)	PSM - Passenger Front Seat Module	EXE
GJ32-14C549-CB.vbf	Range Rover Evoque (L538)	PSM - Passenger Front Seat Module	EXE
GJ32-14C549-CC.vbf	Range Rover Evoque (L538)	PSM - Passenger Front Seat Module	EXE
GJ32-14C549-CD.vbf	Range Rover Evoque (L538)	PSM - Passenger Front Seat Module	EXE
GJ32-14C549-DB.vbf	Range Rover Evoque (L538)	PSM - Passenger Front Seat Module	EXE
GJ32-14C549-DC.vbf	Range Rover Evoque (L538)	PSM - Passenger Front Seat Module	EXE
GJ32-14C549-DD.vbf	Range Rover Evoque (L538)	PSM - Passenger Front Seat Module	EXE
GJ32-14C550-AA.vbf	Range Rover Evoque (L538)	PSM - Passenger Front Seat Module	SBL
GJ32-14C609-AB.vbf	Range Rover Evoque (L538)	PSCM - Power Steering Control Module	EXE
GJ32-14C609-AC.vbf	Range Rover Evoque (L538)	PSCM - Power Steering Control Module	EXE
GJ32-14C621-AA.vbf	Range Rover Evoque (L538)	FCDIM - Front Control/Display Interface Module	EXE
GJ32-14C621-AB.vbf	Range Rover Evoque (L538)	FCDIM - Front Control/Display Interface Module	EXE
GJ32-14C653-AJ.vbf	Range Rover Evoque (L538)	ACM - Audio Front Control Module	DATA
GJ32-14C653-AK.vbf	Range Rover Evoque (L538)	ACM - Audio Front Control Module	DATA
GJ32-14C653-AL.vbf	Range Rover Evoque (L538)	ACM - Audio Front Control Module	DATA
GJ32-14C653-AM.vbf	Range Rover Evoque (L538)	ACM - Audio Front Control Module	DATA
GJ32-14D023-AA.vbf	Range Rover Evoque (L538)	ATCM - All Terrain Control Module	SIGCFG
GJ32-14D024-AA.vbf	Range Rover Evoque (L538)	ATCM - All Terrain Control Module	EXE
GJ32-14D183-BA.vbf	Range Rover Evoque (L538)	OCS - Restraints Occupant Classification System Module	DATA
GJ32-14D183-BB.vbf	Range Rover Evoque (L538)	OCS - Restraints Occupant Classification System Module	DATA
GJ32-14D481-BA.vbf	Range Rover Evoque (L538)	IPMB - Image Processing Module B	DATA
GJ32-14D485-BC.vbf	Range Rover Evoque (L538)	IPMB - Image Processing Module B	DATA
GJ32-14D485-BD.vbf	Range Rover Evoque (L538)	IPMB - Image Processing Module B	DATA
GJ32-14D564-AA.vbf	Range Rover Evoque (L538)	SODL - Side Obstacle Detection Control Module - Left	DATA
GJ32-14D564-BA.vbf	Range Rover Evoque (L538)	SODR - Side Obstacle Detection Control Module - Right	DATA
GJ32-14D564-CA.vbf	Range Rover Evoque (L538)	SODL - Side Obstacle Detection Control Module - Left	DATA
GJ32-14D564-DA.vbf	Range Rover Evoque (L538)	SODR - Side Obstacle Detection Control Module - Right	DATA

File name	Vehicle line (indicative)	Module (ECU)	Type
GJ32-14F022-BA.vbf	Range Rover Evoque (L538)	IPMB - Image Processing Module B	DATA
GJ32-14F022-BB.vbf	Range Rover Evoque (L538)	IPMB - Image Processing Module B	DATA
GJ32-14F022-BC.vbf	Range Rover Evoque (L538)	IPMB - Image Processing Module B	DATA
GJ32-14F022-BD.vbf	Range Rover Evoque (L538)	IPMB - Image Processing Module B	DATA
GJ32-14F022-BE.vbf	Range Rover Evoque (L538)	IPMB - Image Processing Module B	DATA
GJ32-14F022-BF.vbf	Range Rover Evoque (L538)	IPMB - Image Processing Module B	DATA
GJ32-14F022-EC.vbf	Range Rover Evoque (L538)	IPMB - Image Processing Module B	DATA
GJ32-14F022-ED.vbf	Range Rover Evoque (L538)	IPMB - Image Processing Module B	DATA
GJ32-14F022-EF.vbf	Range Rover Evoque (L538)	IPMB - Image Processing Module B	DATA
GJ32-14F022-FC.vbf	Range Rover Evoque (L538)	IPMB - Image Processing Module B	DATA
GJ32-14F022-FD.vbf	Range Rover Evoque (L538)	IPMB - Image Processing Module B	DATA
GJ32-14F022-FF.vbf	Range Rover Evoque (L538)	IPMB - Image Processing Module B	DATA
GJ32-14F231-AB.vbf	Range Rover Evoque (L538)	HUD - Head Up Display	CUSTOM
GJ32-14F231-AC.vbf	Range Rover Evoque (L538)	HUD - Head Up Display	CUSTOM
GJ32-14F397-AB.vbf	Range Rover Evoque (L538)	IPMA - Image Processing Module A	EXE
GJ32-14F397-AC.vbf	Range Rover Evoque (L538)	IPMA - Image Processing Module A	EXE
GJ32-14F397-AE.vbf	Range Rover Evoque (L538)	IPMA - Image Processing Module A	EXE
GJ32-14F397-BB.vbf	Range Rover Evoque (L538)	IPMA - Image Processing Module A	EXE
GJ32-14F397-BC.vbf	Range Rover Evoque (L538)	IPMA - Image Processing Module A	EXE
GJ32-14F397-BE.vbf	Range Rover Evoque (L538)	IPMA - Image Processing Module A	EXE
GJ32-14F397-CB.vbf	Range Rover Evoque (L538)	IPMA - Image Processing Module A	EXE
GJ32-14F397-CC.vbf	Range Rover Evoque (L538)	IPMA - Image Processing Module A	EXE
GJ32-14F397-CE.vbf	Range Rover Evoque (L538)	IPMA - Image Processing Module A	EXE
GJ32-14F397-DB.vbf	Range Rover Evoque (L538)	IPMA - Image Processing Module A	EXE
GJ32-14F397-DC.vbf	Range Rover Evoque (L538)	IPMA - Image Processing Module A	EXE
GJ32-14F397-DE.vbf	Range Rover Evoque (L538)	IPMA - Image Processing Module A	EXE
GJ32-14F398-AB.vbf	Range Rover Evoque (L538)	IPMA - Image Processing Module A	EXE
GJ32-14F398-AC.vbf	Range Rover Evoque (L538)	IPMA - Image Processing Module A	EXE
GJ32-14F398-AE.vbf	Range Rover Evoque (L538)	IPMA - Image Processing Module A	EXE
GJ32-14F398-AF.vbf	Range Rover Evoque (L538)	IPMA - Image Processing Module A	EXE
GJ32-14F398-AG.vbf	Range Rover Evoque (L538)	IPMA - Image Processing Module A	EXE
GJ32-14F398-BB.vbf	Range Rover Evoque (L538)	IPMA - Image Processing Module A	EXE
GJ32-14F398-BC.vbf	Range Rover Evoque (L538)	IPMA - Image Processing Module A	EXE
GJ32-14F398-BE.vbf	Range Rover Evoque (L538)	IPMA - Image Processing Module A	EXE
GJ32-14F398-BF.vbf	Range Rover Evoque (L538)	IPMA - Image Processing Module A	EXE
GJ32-14F398-BG.vbf	Range Rover Evoque (L538)	IPMA - Image Processing Module A	EXE
GJ32-14F530-AB.vbf	Range Rover Evoque (L538)	GWM - Gateway Module A	EXE
GJ32-14F530-AC.vbf	Range Rover Evoque (L538)	GWM - Gateway Module A	EXE
GJ32-14F530-AD.vbf	Range Rover Evoque (L538)	GWM - Gateway Module A	EXE
GJ32-14F530-AE.vbf	Range Rover Evoque (L538)	GWM - Gateway Module A	EXE
GJ32-14F530-AF.vbf	Range Rover Evoque (L538)	GWM - Gateway Module A	EXE
GJ32-14F530-AG.vbf	Range Rover Evoque (L538)	GWM - Gateway Module A	EXE
GJ32-14F530-AH.vbf	Range Rover Evoque (L538)	GWM - Gateway Module A	EXE
GJ32-14F530-AJ.vbf	Range Rover Evoque (L538)	GWM - Gateway Module A	EXE
GJ32-14F530-BC.vbf	Range Rover Evoque (L538)	GWM - Gateway Module A	EXE
GJ32-14F530-BD.vbf	Range Rover Evoque (L538)	GWM - Gateway Module A	EXE
GJ32-14F530-BE.vbf	Range Rover Evoque (L538)	GWM - Gateway Module A	EXE
GJ32-14F530-BF.vbf	Range Rover Evoque (L538)	GWM - Gateway Module A	EXE
GJ32-14F530-BG.vbf	Range Rover Evoque (L538)	GWM - Gateway Module A	EXE
GJ32-14F530-BH.vbf	Range Rover Evoque (L538)	GWM - Gateway Module A	EXE
GJ32-14F531-AB.vbf	Range Rover Evoque (L538)	GWM - Gateway Module A	DATA
GJ32-14F531-AC.vbf	Range Rover Evoque (L538)	GWM - Gateway Module A	DATA
GJ32-14F531-AD.vbf	Range Rover Evoque (L538)	GWM - Gateway Module A	DATA
GJ32-14F531-AE.vbf	Range Rover Evoque (L538)	GWM - Gateway Module A	DATA
GJ32-14F531-AF.vbf	Range Rover Evoque (L538)	GWM - Gateway Module A	DATA
GJ32-14F531-BB.vbf	Range Rover Evoque (L538)	GWM - Gateway Module A	DATA
GJ32-14F531-BC.vbf	Range Rover Evoque (L538)	GWM - Gateway Module A	DATA
GJ32-14F531-BD.vbf	Range Rover Evoque (L538)	GWM - Gateway Module A	DATA
GJ32-14F531-BE.vbf	Range Rover Evoque (L538)	GWM - Gateway Module A	DATA
GJ32-14F531-CA.vbf	Range Rover Evoque (L538)	GWM - Gateway Module A	DATA
GJ32-14F531-CB.vbf	Range Rover Evoque (L538)	GWM - Gateway Module A	DATA
GJ32-157012-AB.vbf	Range Rover Evoque (L538)	FTCMB - Folding Top Control Module (Slave)	EXE
GJ32-157012-AC.vbf	Range Rover Evoque (L538)	FTCM - Folding Top Control Module (Master)	EXE
GJ32-157012-AD.vbf	Range Rover Evoque (L538)	FTCM - Folding Top Control Module (Master)	EXE
GJ32-157012-AE.vbf	Range Rover Evoque (L538)	FTCM - Folding Top Control Module (Master)	EXE
GJ32-157012-AF.vbf	Range Rover Evoque (L538)	FTCM - Folding Top Control Module (Master)	EXE
GJ32-157013-AB.vbf	Range Rover Evoque (L538)	FTCMB - Folding Top Control Module (Slave)	DATA
GJ32-157013-AC.vbf	Range Rover Evoque (L538)	FTCM - Folding Top Control Module (Master)	DATA
GJ32-157013-AD.vbf	Range Rover Evoque (L538)	FTCM - Folding Top Control Module (Master)	DATA
GJ32-157014-AA.vbf	Range Rover Evoque (L538)	FTCMB - Folding Top Control Module (Slave)	SBL
GJ32-18D618-AA.vbf	Range Rover Evoque (L538)	HVAC - HVAC Control Module	SBL
GJ32-18D619-AC.vbf	Range Rover Evoque (L538)	HVAC - HVAC Control Module	EXE
GJ32-18D619-AD.vbf	Range Rover Evoque (L538)	HVAC - HVAC Control Module	EXE
GJ32-18D619-BA.vbf	Range Rover Evoque (L538)	HVAC - HVAC Control Module	EXE
GJ32-18D619-BB.vbf	Range Rover Evoque (L538)	HVAC - HVAC Control Module	EXE
GJ32-18D619-BD.vbf	Range Rover Evoque (L538)	HVAC - HVAC Control Module	EXE

File name	Vehicle line (indicative)	Module (ECU)	Type
GJ32-18D619-BF.vbf	Range Rover Evoque (L538)	HVAC - HVAC Control Module	EXE
GJ32-18D619-BG.vbf	Range Rover Evoque (L538)	HVAC - HVAC Control Module	EXE
GJ32-18D619-BH.vbf	Range Rover Evoque (L538)	HVAC - HVAC Control Module	EXE
GJ32-18D619-BJ.vbf	Range Rover Evoque (L538)	HVAC - HVAC Control Module	EXE
GJ32-18D619-BK.vbf	Range Rover Evoque (L538)	HVAC - HVAC Control Module	EXE
GJ32-18D619-BM.vbf	Range Rover Evoque (L538)	HVAC - HVAC Control Module	EXE
GJ32-18D620-AC.vbf	Range Rover Evoque (L538)	HVAC - HVAC Control Module	DATA
GJ32-18D620-AD.vbf	Range Rover Evoque (L538)	HVAC - HVAC Control Module	DATA
GJ32-18D620-AE.vbf	Range Rover Evoque (L538)	HVAC - HVAC Control Module	DATA
GJ32-18D620-BA.vbf	Range Rover Evoque (L538)	HVAC - HVAC Control Module	DATA
GJ32-18D620-BB.vbf	Range Rover Evoque (L538)	HVAC - HVAC Control Module	DATA
GJ32-18D620-BD.vbf	Range Rover Evoque (L538)	HVAC - HVAC Control Module	DATA
GJ32-18D620-BF.vbf	Range Rover Evoque (L538)	HVAC - HVAC Control Module	DATA
GJ32-18D620-BG.vbf	Range Rover Evoque (L538)	HVAC - HVAC Control Module	DATA
GJ32-18D620-BH.vbf	Range Rover Evoque (L538)	HVAC - HVAC Control Module	DATA
GJ32-18D620-BJ.vbf	Range Rover Evoque (L538)	HVAC - HVAC Control Module	DATA
GJ32-18D620-BK.vbf	Range Rover Evoque (L538)	HVAC - HVAC Control Module	DATA
GJ32-18D620-BL.vbf	Range Rover Evoque (L538)	HVAC - HVAC Control Module	DATA
GJ32-18D620-BM.vbf	Range Rover Evoque (L538)	HVAC - HVAC Control Module	DATA
GJ32-18D620-BN.vbf	Range Rover Evoque (L538)	HVAC - HVAC Control Module	DATA
GJ32-18D620-BR.vbf	Range Rover Evoque (L538)	HVAC - HVAC Control Module	DATA
GJ32-18D620-CC.vbf	Range Rover Evoque (L538)	HVAC - HVAC Control Module	DATA
GJ32-18D620-CD.vbf	Range Rover Evoque (L538)	HVAC - HVAC Control Module	DATA
GJ32-18D620-CE.vbf	Range Rover Evoque (L538)	HVAC - HVAC Control Module	DATA
GJ32-18D620-DB.vbf	Range Rover Evoque (L538)	HVAC - HVAC Control Module	DATA
GJ32-18D620-DD.vbf	Range Rover Evoque (L538)	HVAC - HVAC Control Module	DATA
GJ32-18D620-DF.vbf	Range Rover Evoque (L538)	HVAC - HVAC Control Module	DATA
GJ32-18D620-DG.vbf	Range Rover Evoque (L538)	HVAC - HVAC Control Module	DATA
GJ32-18D620-DH.vbf	Range Rover Evoque (L538)	HVAC - HVAC Control Module	DATA
GJ32-18D620-DJ.vbf	Range Rover Evoque (L538)	HVAC - HVAC Control Module	DATA
GJ32-18D620-DK.vbf	Range Rover Evoque (L538)	HVAC - HVAC Control Module	DATA
GJ32-18D620-DL.vbf	Range Rover Evoque (L538)	HVAC - HVAC Control Module	DATA
GJ32-18D620-DM.vbf	Range Rover Evoque (L538)	HVAC - HVAC Control Module	DATA
GJ32-18D620-DN.vbf	Range Rover Evoque (L538)	HVAC - HVAC Control Module	DATA
GJ32-18D620-DR.vbf	Range Rover Evoque (L538)	HVAC - HVAC Control Module	DATA
GJ32-70713-AF.vbf	Range Rover Evoque (L538)	TCU - Telematic Control Unit Module	DATA
GJ32-70713-BF.vbf	Range Rover Evoque (L538)	TCU - Telematic Control Unit Module	DATA
GJ32-70713-BG.vbf	Range Rover Evoque (L538)	TCU - Telematic Control Unit Module	DATA
GJ32-70713-BJ.vbf	Range Rover Evoque (L538)	TCU - Telematic Control Unit Module	DATA
GJ32-70713-BK.vbf	Range Rover Evoque (L538)	TCU - Telematic Control Unit Module	DATA
GJ32-70713-BL.vbf	Range Rover Evoque (L538)	TCU - Telematic Control Unit Module	DATA
GJ32-70713-BM.vbf	Range Rover Evoque (L538)	TCU - Telematic Control Unit Module	DATA
GJ32-70713-BN.vbf	Range Rover Evoque (L538)	TCU - Telematic Control Unit Module	DATA
GJ32-70713-BP.vbf	Range Rover Evoque (L538)	TCU - Telematic Control Unit Module	DATA
GJ32-70713-BR.vbf	Range Rover Evoque (L538)	TCU - Telematic Control Unit Module	DATA
GJ32-70713-BS.vbf	Range Rover Evoque (L538)	TCU - Telematic Control Unit Module	DATA
GJ32-70713-CF.vbf	Range Rover Evoque (L538)	TCU - Telematic Control Unit Module	DATA
GJ32-70713-CG.vbf	Range Rover Evoque (L538)	TCU - Telematic Control Unit Module	DATA
GJ32-70713-CJ.vbf	Range Rover Evoque (L538)	TCU - Telematic Control Unit Module	DATA
GJ32-70713-CK.vbf	Range Rover Evoque (L538)	TCU - Telematic Control Unit Module	DATA
GJ32-70713-CL.vbf	Range Rover Evoque (L538)	TCU - Telematic Control Unit Module	DATA
GJ32-70713-CM.vbf	Range Rover Evoque (L538)	TCU - Telematic Control Unit Module	DATA
GJ32-70713-CN.vbf	Range Rover Evoque (L538)	TCU - Telematic Control Unit Module	DATA
GJ32-70713-CP.vbf	Range Rover Evoque (L538)	TCU - Telematic Control Unit Module	DATA
GJ32-70713-CR.vbf	Range Rover Evoque (L538)	TCU - Telematic Control Unit Module	DATA
GJ32-70713-CS.vbf	Range Rover Evoque (L538)	TCU - Telematic Control Unit Module	DATA
GJ32-70713-MA.vbf	Range Rover Evoque (L538)	TCU - Telematic Control Unit Module	DATA
GJ32-70713-MB.vbf	Range Rover Evoque (L538)	TCU - Telematic Control Unit Module	DATA
GJ32-70713-MC.vbf	Range Rover Evoque (L538)	TCU - Telematic Control Unit Module	DATA
GJ32-70713-MD.vbf	Range Rover Evoque (L538)	TCU - Telematic Control Unit Module	DATA
GJ32-70713-ME.vbf	Range Rover Evoque (L538)	TCU - Telematic Control Unit Module	DATA
GJ32-70713-MF.vbf	Range Rover Evoque (L538)	TCU - Telematic Control Unit Module	DATA
GJ32-70713-MG.vbf	Range Rover Evoque (L538)	TCU - Telematic Control Unit Module	DATA
GJ32-70713-MH.vbf	Range Rover Evoque (L538)	TCU - Telematic Control Unit Module	DATA
GJ32-70713-NA.vbf	Range Rover Evoque (L538)	TCU - Telematic Control Unit Module	DATA
GJ32-70713-NB.vbf	Range Rover Evoque (L538)	TCU - Telematic Control Unit Module	DATA
GJ32-70713-NC.vbf	Range Rover Evoque (L538)	TCU - Telematic Control Unit Module	DATA
GJ32-70713-ND.vbf	Range Rover Evoque (L538)	TCU - Telematic Control Unit Module	DATA
GJ32-70713-NE.vbf	Range Rover Evoque (L538)	TCU - Telematic Control Unit Module	DATA
GJ32-70713-NF.vbf	Range Rover Evoque (L538)	TCU - Telematic Control Unit Module	DATA
GJ32-70713-NG.vbf	Range Rover Evoque (L538)	TCU - Telematic Control Unit Module	DATA
GJ32-70713-NH.vbf	Range Rover Evoque (L538)	TCU - Telematic Control Unit Module	DATA
GJ32-70713-RK.vbf	Range Rover Evoque (L538)	TCU - Telematic Control Unit Module	DATA
GJ32-70713-RL.vbf	Range Rover Evoque (L538)	TCU - Telematic Control Unit Module	DATA
GJ32-70713-RM.vbf	Range Rover Evoque (L538)	TCU - Telematic Control Unit Module	DATA
GJ32-70713-SK.vbf	Range Rover Evoque (L538)	TCU - Telematic Control Unit Module	DATA

File name	Vehicle line (indicative)	Module (ECU)	Type
GJ32-70713-SL.vbf	Range Rover Evoque (L538)	TCU - Telematic Control Unit Module	DATA
GJ32-70713-SM.vbf	Range Rover Evoque (L538)	TCU - Telematic Control Unit Module	DATA
GK52-12K532-PCB.vbf	Range Rover (L405)	PCM - Powertrain Control Module	DATA
GK52-12K532-PCC.vbf	Range Rover (L405)	PCM - Powertrain Control Module	DATA
GK52-12K532-PCD.vbf	Range Rover (L405)	PCM - Powertrain Control Module	DATA
GK52-12K532-PCE.vbf	Range Rover (L405)	PCM - Powertrain Control Module	DATA
GK52-12K532-PCF.vbf	Range Rover (L405)	PCM - Powertrain Control Module	DATA
GK52-12K532-PCG.vbf	Range Rover (L405)	PCM - Powertrain Control Module	DATA
GK52-12K532-PCH.vbf	Range Rover (L405)	PCM - Powertrain Control Module	DATA
GK52-12K532-PCJ.vbf	Range Rover (L405)	PCM - Powertrain Control Module	DATA
GK52-12K532-PDB.vbf	Range Rover (L405)	PCM - Powertrain Control Module	DATA
GK52-12K532-PDC.vbf	Range Rover (L405)	PCM - Powertrain Control Module	DATA
GK52-12K532-PDD.vbf	Range Rover (L405)	PCM - Powertrain Control Module	DATA
GK52-12K532-PDE.vbf	Range Rover (L405)	PCM - Powertrain Control Module	DATA
GK52-12K532-PDF.vbf	Range Rover (L405)	PCM - Powertrain Control Module	DATA
GK52-12K532-PDG.vbf	Range Rover (L405)	PCM - Powertrain Control Module	DATA
GK52-12K532-PDH.vbf	Range Rover (L405)	PCM - Powertrain Control Module	DATA
GK52-12K532-PDJ.vbf	Range Rover (L405)	PCM - Powertrain Control Module	DATA
GK52-12K532-PEC.vbf	Range Rover (L405)	PCM - Powertrain Control Module	DATA
GK52-12K532-PED.vbf	Range Rover (L405)	PCM - Powertrain Control Module	DATA
GK52-12K532-PEE.vbf	Range Rover (L405)	PCM - Powertrain Control Module	DATA
GK52-12K532-PEF.vbf	Range Rover (L405)	PCM - Powertrain Control Module	DATA
GK52-12K532-PGC.vbf	Range Rover (L405)	PCM - Powertrain Control Module	DATA
GK52-12K532-PGD.vbf	Range Rover (L405)	PCM - Powertrain Control Module	DATA
GK52-12K532-PGE.vbf	Range Rover (L405)	PCM - Powertrain Control Module	DATA
GK52-12K532-PGF.vbf	Range Rover (L405)	PCM - Powertrain Control Module	DATA
GK52-12K532-PHC.vbf	Range Rover (L405)	PCM - Powertrain Control Module	DATA
GK52-12K532-PHD.vbf	Range Rover (L405)	PCM - Powertrain Control Module	DATA
GK52-12K532-PHE.vbf	Range Rover (L405)	PCM - Powertrain Control Module	DATA
GK52-12K532-PHF.vbf	Range Rover (L405)	PCM - Powertrain Control Module	DATA
GK52-12K532-PPB.vbf	Range Rover (L405)	PCM - Powertrain Control Module	DATA
GK52-12K532-PPC.vbf	Range Rover (L405)	PCM - Powertrain Control Module	DATA
GK52-12K532-PPD.vbf	Range Rover (L405)	PCM - Powertrain Control Module	DATA
GK52-12K532-PPE.vbf	Range Rover (L405)	PCM - Powertrain Control Module	DATA
GK52-12K532-PPF.vbf	Range Rover (L405)	PCM - Powertrain Control Module	DATA
GK52-12K532-PPG.vbf	Range Rover (L405)	PCM - Powertrain Control Module	DATA
GK52-12K532-PPH.vbf	Range Rover (L405)	PCM - Powertrain Control Module	DATA
GK52-12K532-PPJ.vbf	Range Rover (L405)	PCM - Powertrain Control Module	DATA
GK52-12K532-PRA.vbf	Range Rover (L405)	PCM - Powertrain Control Module	DATA
GK52-12K532-PRB.vbf	Range Rover (L405)	PCM - Powertrain Control Module	DATA
GK52-12K532-PRC.vbf	Range Rover (L405)	PCM - Powertrain Control Module	DATA
GK52-12K532-PRD.vbf	Range Rover (L405)	PCM - Powertrain Control Module	DATA
GK52-12K532-PRE.vbf	Range Rover (L405)	PCM - Powertrain Control Module	DATA
GK52-12K532-PRF.vbf	Range Rover (L405)	PCM - Powertrain Control Module	DATA
GK52-12K532-PRG.vbf	Range Rover (L405)	PCM - Powertrain Control Module	DATA
GK52-12K532-PRH.vbf	Range Rover (L405)	PCM - Powertrain Control Module	DATA
GK52-12K532-PRJ.vbf	Range Rover (L405)	PCM - Powertrain Control Module	DATA
GK52-12K532-PRK.vbf	Range Rover (L405)	PCM - Powertrain Control Module	DATA
GK52-12K532-PRL.vbf	Range Rover (L405)	PCM - Powertrain Control Module	DATA
GK52-12K532-PRM.vbf	Range Rover (L405)	PCM - Powertrain Control Module	DATA
GK52-12K532-PRN.vbf	Range Rover (L405)	PCM - Powertrain Control Module	DATA
GK52-12K532-PVC.vbf	Range Rover (L405)	PCM - Powertrain Control Module	DATA
GK52-12K532-PVD.vbf	Range Rover (L405)	PCM - Powertrain Control Module	DATA
GK52-12K532-PVE.vbf	Range Rover (L405)	PCM - Powertrain Control Module	DATA
GK52-12K532-PVF.vbf	Range Rover (L405)	PCM - Powertrain Control Module	DATA
GK52-14C034-AAA.vbf	Range Rover (L405)	DSM - Driver Front Seat Module	EXE
GK52-14C034-AAB.vbf	Range Rover (L405)	DSM - Driver Front Seat Module	EXE
GK52-14C034-AAC.vbf	Range Rover (L405)	DSM - Driver Front Seat Module	EXE
GK52-14C034-ABA.vbf	Range Rover (L405)	DSM - Driver Front Seat Module	EXE
GK52-14C034-ABB.vbf	Range Rover (L405)	DSM - Driver Front Seat Module	EXE
GK52-14C034-ABC.vbf	Range Rover (L405)	DSM - Driver Front Seat Module	EXE
GK52-14C034-BAA.vbf	Range Rover (L405)	DSM - Driver Front Seat Module	EXE
GK52-14C034-BAB.vbf	Range Rover (L405)	DSM - Driver Front Seat Module	EXE
GK52-14C034-BAC.vbf	Range Rover (L405)	DSM - Driver Front Seat Module	EXE
GK52-14C034-BBA.vbf	Range Rover (L405)	DSM - Driver Front Seat Module	EXE
GK52-14C034-BBB.vbf	Range Rover (L405)	DSM - Driver Front Seat Module	EXE
GK52-14C034-BBC.vbf	Range Rover (L405)	DSM - Driver Front Seat Module	EXE
GK52-14C034-BCA.vbf	Range Rover (L405)	DSM - Driver Front Seat Module	EXE
GK52-14C034-BCB.vbf	Range Rover (L405)	DSM - Driver Front Seat Module	EXE
GK52-14C034-BCC.vbf	Range Rover (L405)	DSM - Driver Front Seat Module	EXE
GK52-14C034-BDA.vbf	Range Rover (L405)	DSM - Driver Front Seat Module	EXE
GK52-14C034-BDB.vbf	Range Rover (L405)	DSM - Driver Front Seat Module	EXE
GK52-14C034-BDC.vbf	Range Rover (L405)	DSM - Driver Front Seat Module	EXE
GK52-14C034-BEA.vbf	Range Rover (L405)	DSM - Driver Front Seat Module	EXE
GK52-14C034-BEB.vbf	Range Rover (L405)	DSM - Driver Front Seat Module	EXE
GK52-14C034-BEC.vbf	Range Rover (L405)	DSM - Driver Front Seat Module	EXE

File name	Vehicle line (indicative)	Module (ECU)	Type
GK52-14C034-CAA.vbf	Range Rover (L405)	DSM - Driver Front Seat Module	EXE
GK52-14C034-CAB.vbf	Range Rover (L405)	DSM - Driver Front Seat Module	EXE
GK52-14C034-CAC.vbf	Range Rover (L405)	DSM - Driver Front Seat Module	EXE
GK52-14C034-CAD.vbf	Range Rover (L405)	DSM - Driver Front Seat Module	EXE
GK52-14C034-CBA.vbf	Range Rover (L405)	DSM - Driver Front Seat Module	EXE
GK52-14C034-CBB.vbf	Range Rover (L405)	DSM - Driver Front Seat Module	EXE
GK52-14C034-CBC.vbf	Range Rover (L405)	DSM - Driver Front Seat Module	EXE
GK52-14C034-CBD.vbf	Range Rover (L405)	DSM - Driver Front Seat Module	EXE
GK52-14C034-CCA.vbf	Range Rover (L405)	DSM - Driver Front Seat Module	EXE
GK52-14C034-CCB.vbf	Range Rover (L405)	DSM - Driver Front Seat Module	EXE
GK52-14C034-CCC.vbf	Range Rover (L405)	DSM - Driver Front Seat Module	EXE
GK52-14C034-CCD.vbf	Range Rover (L405)	DSM - Driver Front Seat Module	EXE
GK52-14C034-CDA.vbf	Range Rover (L405)	DSM - Driver Front Seat Module	EXE
GK52-14C034-CDB.vbf	Range Rover (L405)	DSM - Driver Front Seat Module	EXE
GK52-14C034-CDC.vbf	Range Rover (L405)	DSM - Driver Front Seat Module	EXE
GK52-14C034-CDD.vbf	Range Rover (L405)	DSM - Driver Front Seat Module	EXE
GK52-14C034-CEA.vbf	Range Rover (L405)	DSM - Driver Front Seat Module	EXE
GK52-14C034-CEB.vbf	Range Rover (L405)	DSM - Driver Front Seat Module	EXE
GK52-14C034-CEC.vbf	Range Rover (L405)	DSM - Driver Front Seat Module	EXE
GK52-14C034-CED.vbf	Range Rover (L405)	DSM - Driver Front Seat Module	EXE
GK52-14C034-DAA.vbf	Range Rover (L405)	DSM - Driver Front Seat Module	EXE
GK52-14C034-DAB.vbf	Range Rover (L405)	DSM - Driver Front Seat Module	EXE
GK52-14C034-DAC.vbf	Range Rover (L405)	DSM - Driver Front Seat Module	EXE
GK52-14C034-DBA.vbf	Range Rover (L405)	DSM - Driver Front Seat Module	EXE
GK52-14C034-DBB.vbf	Range Rover (L405)	DSM - Driver Front Seat Module	EXE
GK52-14C034-DBC.vbf	Range Rover (L405)	DSM - Driver Front Seat Module	EXE
GK52-14C034-DCA.vbf	Range Rover (L405)	DSM - Driver Front Seat Module	EXE
GK52-14C034-DCB.vbf	Range Rover (L405)	DSM - Driver Front Seat Module	EXE
GK52-14C034-DCC.vbf	Range Rover (L405)	DSM - Driver Front Seat Module	EXE
GK52-14C034-DDA.vbf	Range Rover (L405)	DSM - Driver Front Seat Module	EXE
GK52-14C034-DDB.vbf	Range Rover (L405)	DSM - Driver Front Seat Module	EXE
GK52-14C034-DDC.vbf	Range Rover (L405)	DSM - Driver Front Seat Module	EXE
GK52-14C034-DEA.vbf	Range Rover (L405)	DSM - Driver Front Seat Module	EXE
GK52-14C034-DEB.vbf	Range Rover (L405)	DSM - Driver Front Seat Module	EXE
GK52-14C034-DEC.vbf	Range Rover (L405)	DSM - Driver Front Seat Module	EXE
GK52-14C034-EAA.vbf	Range Rover (L405)	DSM - Driver Front Seat Module	EXE
GK52-14C034-EAB.vbf	Range Rover (L405)	DSM - Driver Front Seat Module	EXE
GK52-14C034-EBA.vbf	Range Rover (L405)	DSM - Driver Front Seat Module	EXE
GK52-14C034-EBB.vbf	Range Rover (L405)	DSM - Driver Front Seat Module	EXE
GK52-14C034-ECA.vbf	Range Rover (L405)	DSM - Driver Front Seat Module	EXE
GK52-14C034-ECB.vbf	Range Rover (L405)	DSM - Driver Front Seat Module	EXE
GK52-14C034-EDA.vbf	Range Rover (L405)	DSM - Driver Front Seat Module	EXE
GK52-14C034-EDB.vbf	Range Rover (L405)	DSM - Driver Front Seat Module	EXE
GK52-14C034-EEA.vbf	Range Rover (L405)	DSM - Driver Front Seat Module	EXE
GK52-14C034-EEB.vbf	Range Rover (L405)	DSM - Driver Front Seat Module	EXE
GK52-14C034-FAB.vbf	Range Rover (L405)	DSM - Driver Front Seat Module	EXE
GK52-14C034-FBB.vbf	Range Rover (L405)	DSM - Driver Front Seat Module	EXE
GK52-14C034-FCB.vbf	Range Rover (L405)	DSM - Driver Front Seat Module	EXE
GK52-14C034-FDB.vbf	Range Rover (L405)	DSM - Driver Front Seat Module	EXE
GK52-14C034-FEB.vbf	Range Rover (L405)	DSM - Driver Front Seat Module	EXE
GK52-14C034-FFB.vbf	Range Rover (L405)	DSM - Driver Front Seat Module	EXE
GK52-14C034-FGB.vbf	Range Rover (L405)	DSM - Driver Front Seat Module	EXE
GK52-14C034-FHB.vbf	Range Rover (L405)	DSM - Driver Front Seat Module	EXE
GK52-14C034-FJB.vbf	Range Rover (L405)	DSM - Driver Front Seat Module	EXE
GK52-14C034-FKB.vbf	Range Rover (L405)	DSM - Driver Front Seat Module	EXE
GK52-14C037-AAC.vbf	Range Rover (L405)	SPCM - Secondary Powertrain Control Module	EXE
GK52-14C037-AAD.vbf	Range Rover (L405)	SPCM - Secondary Powertrain Control Module	EXE
GK52-14C037-AAE.vbf	Range Rover (L405)	SPCM - Secondary Powertrain Control Module	EXE
GK52-14C037-AAF.vbf	Range Rover (L405)	SPCM - Secondary Powertrain Control Module	EXE
GK52-14C037-ABB.vbf	Range Rover (L405)	SPCM - Secondary Powertrain Control Module	EXE
GK52-14C037-ABC.vbf	Range Rover (L405)	SPCM - Secondary Powertrain Control Module	EXE
GK52-14C037-ABD.vbf	Range Rover (L405)	SPCM - Secondary Powertrain Control Module	EXE
GK52-14C037-ABE.vbf	Range Rover (L405)	SPCM - Secondary Powertrain Control Module	EXE
GK52-14C037-ABF.vbf	Range Rover (L405)	SPCM - Secondary Powertrain Control Module	EXE
GK52-14C037-ACB.vbf	Range Rover (L405)	SPCM - Secondary Powertrain Control Module	EXE
GK52-14C037-ACC.vbf	Range Rover (L405)	SPCM - Secondary Powertrain Control Module	EXE
GK52-14C037-ACD.vbf	Range Rover (L405)	SPCM - Secondary Powertrain Control Module	EXE
GK52-14C037-ACE.vbf	Range Rover (L405)	SPCM - Secondary Powertrain Control Module	EXE
GK52-14C037-ACF.vbf	Range Rover (L405)	SPCM - Secondary Powertrain Control Module	EXE
GK52-14C037-ADB.vbf	Range Rover (L405)	SPCM - Secondary Powertrain Control Module	EXE
GK52-14C037-ADC.vbf	Range Rover (L405)	SPCM - Secondary Powertrain Control Module	EXE
GK52-14C037-ADD.vbf	Range Rover (L405)	SPCM - Secondary Powertrain Control Module	EXE
GK52-14C037-ADE.vbf	Range Rover (L405)	SPCM - Secondary Powertrain Control Module	EXE
GK52-14C037-ADF.vbf	Range Rover (L405)	SPCM - Secondary Powertrain Control Module	EXE
GK52-14C037-AEB.vbf	Range Rover (L405)	SPCM - Secondary Powertrain Control Module	EXE
GK52-14C037-AEC.vbf	Range Rover (L405)	SPCM - Secondary Powertrain Control Module	EXE

File name	Vehicle line (indicative)	Module (ECU)	Type
GK52-14C037-AED.vbf	Range Rover (L405)	SPCM - Secondary Powertrain Control Module	EXE
GK52-14C037-AEE.vbf	Range Rover (L405)	SPCM - Secondary Powertrain Control Module	EXE
GK52-14C037-AEF.vbf	Range Rover (L405)	SPCM - Secondary Powertrain Control Module	EXE
GK52-14C037-AFB.vbf	Range Rover (L405)	SPCM - Secondary Powertrain Control Module	EXE
GK52-14C037-AFC.vbf	Range Rover (L405)	SPCM - Secondary Powertrain Control Module	EXE
GK52-14C037-AFE.vbf	Range Rover (L405)	SPCM - Secondary Powertrain Control Module	EXE
GK52-14C037-AFF.vbf	Range Rover (L405)	SPCM - Secondary Powertrain Control Module	EXE
GK52-14C037-AFG.vbf	Range Rover (L405)	SPCM - Secondary Powertrain Control Module	EXE
GK52-14C037-AMB.vbf	Range Rover (L405)	SPCM - Secondary Powertrain Control Module	EXE
GK52-14C037-AMC.vbf	Range Rover (L405)	SPCM - Secondary Powertrain Control Module	EXE
GK52-14C037-AMD.vbf	Range Rover (L405)	SPCM - Secondary Powertrain Control Module	EXE
GK52-14C037-AME.vbf	Range Rover (L405)	SPCM - Secondary Powertrain Control Module	EXE
GK52-14C037-AMF.vbf	Range Rover (L405)	SPCM - Secondary Powertrain Control Module	EXE
GK52-14C037-ANB.vbf	Range Rover (L405)	SPCM - Secondary Powertrain Control Module	EXE
GK52-14C037-ANC.vbf	Range Rover (L405)	SPCM - Secondary Powertrain Control Module	EXE
GK52-14C037-AND.vbf	Range Rover (L405)	SPCM - Secondary Powertrain Control Module	EXE
GK52-14C037-ANE.vbf	Range Rover (L405)	SPCM - Secondary Powertrain Control Module	EXE
GK52-14C037-ANF.vbf	Range Rover (L405)	SPCM - Secondary Powertrain Control Module	EXE
GK52-14C037-APB.vbf	Range Rover (L405)	SPCM - Secondary Powertrain Control Module	EXE
GK52-14C037-APC.vbf	Range Rover (L405)	SPCM - Secondary Powertrain Control Module	EXE
GK52-14C037-APD.vbf	Range Rover (L405)	SPCM - Secondary Powertrain Control Module	EXE
GK52-14C037-APE.vbf	Range Rover (L405)	SPCM - Secondary Powertrain Control Module	EXE
GK52-14C037-APF.vbf	Range Rover (L405)	SPCM - Secondary Powertrain Control Module	EXE
GK52-14C037-ARB.vbf	Range Rover (L405)	SPCM - Secondary Powertrain Control Module	EXE
GK52-14C037-ARC.vbf	Range Rover (L405)	SPCM - Secondary Powertrain Control Module	EXE
GK52-14C037-ARE.vbf	Range Rover (L405)	SPCM - Secondary Powertrain Control Module	EXE
GK52-14C037-ARF.vbf	Range Rover (L405)	SPCM - Secondary Powertrain Control Module	EXE
GK52-14C037-ARG.vbf	Range Rover (L405)	SPCM - Secondary Powertrain Control Module	EXE
GK52-14C037-ATB.vbf	Range Rover (L405)	SPCM - Secondary Powertrain Control Module	EXE
GK52-14C037-ATC.vbf	Range Rover (L405)	SPCM - Secondary Powertrain Control Module	EXE
GK52-14C037-ATD.vbf	Range Rover (L405)	SPCM - Secondary Powertrain Control Module	EXE
GK52-14C037-ATE.vbf	Range Rover (L405)	SPCM - Secondary Powertrain Control Module	EXE
GK52-14C037-ATF.vbf	Range Rover (L405)	SPCM - Secondary Powertrain Control Module	EXE
GK52-14C037-AVB.vbf	Range Rover (L405)	SPCM - Secondary Powertrain Control Module	EXE
GK52-14C037-AVC.vbf	Range Rover (L405)	SPCM - Secondary Powertrain Control Module	EXE
GK52-14C037-AVD.vbf	Range Rover (L405)	SPCM - Secondary Powertrain Control Module	EXE
GK52-14C037-AVE.vbf	Range Rover (L405)	SPCM - Secondary Powertrain Control Module	EXE
GK52-14C037-AVF.vbf	Range Rover (L405)	SPCM - Secondary Powertrain Control Module	EXE
GK52-14C037-BAB.vbf	Range Rover (L405)	ABS - Anit-Lock Brake System (ABS) Control Module	EXE
GK52-14C037-BAC.vbf	Range Rover (L405)	ABS - Anit-Lock Brake System (ABS) Control Module	EXE
GK52-14C037-BBB.vbf	Range Rover (L405)	ABS - Anit-Lock Brake System (ABS) Control Module	EXE
GK52-14C037-BBC.vbf	Range Rover (L405)	ABS - Anit-Lock Brake System (ABS) Control Module	EXE
GK52-14C037-DKB.vbf	Range Rover (L405)	SPCM - Secondary Powertrain Control Module	EXE
GK52-14C037-DKC.vbf	Range Rover (L405)	SPCM - Secondary Powertrain Control Module	EXE
GK52-14C037-DKD.vbf	Range Rover (L405)	SPCM - Secondary Powertrain Control Module	EXE
GK52-14C037-DKE.vbf	Range Rover (L405)	SPCM - Secondary Powertrain Control Module	EXE
GK52-14C037-DKF.vbf	Range Rover (L405)	SPCM - Secondary Powertrain Control Module	EXE
GK52-14C037-DLB.vbf	Range Rover (L405)	SPCM - Secondary Powertrain Control Module	EXE
GK52-14C037-DLC.vbf	Range Rover (L405)	SPCM - Secondary Powertrain Control Module	EXE
GK52-14C037-DLE.vbf	Range Rover (L405)	SPCM - Secondary Powertrain Control Module	EXE
GK52-14C037-DLF.vbf	Range Rover (L405)	SPCM - Secondary Powertrain Control Module	EXE
GK52-14C037-DLG.vbf	Range Rover (L405)	SPCM - Secondary Powertrain Control Module	EXE
GK52-14C037-DMB.vbf	Range Rover (L405)	SPCM - Secondary Powertrain Control Module	EXE
GK52-14C037-DMC.vbf	Range Rover (L405)	SPCM - Secondary Powertrain Control Module	EXE
GK52-14C037-DME.vbf	Range Rover (L405)	SPCM - Secondary Powertrain Control Module	EXE
GK52-14C037-DMF.vbf	Range Rover (L405)	SPCM - Secondary Powertrain Control Module	EXE
GK52-14C037-DMG.vbf	Range Rover (L405)	SPCM - Secondary Powertrain Control Module	EXE
GK52-14C037-FAA.vbf	Range Rover (L405)	SPCM - Secondary Powertrain Control Module	EXE
GK52-14C037-FBA.vbf	Range Rover (L405)	SPCM - Secondary Powertrain Control Module	EXE
GK52-14C090-AA.vbf	Range Rover (L405)	PAM - Parking Assist Control Module	EXE
GK52-14C090-AB.vbf	Range Rover (L405)	PAM - Parking Assist Control Module	EXE
GK52-14C091-AA.vbf	Range Rover (L405)	PAM - Parking Assist Control Module	DATA
GK52-14C091-AB.vbf	Range Rover (L405)	PAM - Parking Assist Control Module	DATA
GK52-14C091-AC.vbf	Range Rover (L405)	PAM - Parking Assist Control Module	DATA
GK52-14C091-AD.vbf	Range Rover (L405)	PAM - Parking Assist Control Module	DATA
GK52-14C098-AA.vbf	Range Rover (L405)	RCM - Restraints Control Module	DATA
GK52-14C098-BA.vbf	Range Rover (L405)	RCM - Restraints Control Module	DATA
GK52-14C098-CA.vbf	Range Rover (L405)	RCM - Restraints Control Module	DATA
GK52-14C098-DA.vbf	Range Rover (L405)	RCM - Restraints Control Module	DATA
GK52-14C098-EA.vbf	Range Rover (L405)	RCM - Restraints Control Module	DATA
GK52-14C152-AA.vbf	Range Rover (L405)	TPM - Tire Pressure Monitor Module	DATA
GK52-14C152-AB.vbf	Range Rover (L405)	TPM - Tire Pressure Monitor Module	DATA
GK52-14C185-AA.vbf	Range Rover (L405)	BCM - Body Control Module	DATA
GK52-14C185-AC.vbf	Range Rover (L405)	BCM - Body Control Module	DATA
GK52-14C185-AD.vbf	Range Rover (L405)	BCM - Body Control Module	DATA
GK52-14C185-AE.vbf	Range Rover (L405)	BCM - Body Control Module	DATA

File name	Vehicle line (indicative)	Module (ECU)	Type
GK52-14C185-AJ.vbf	Range Rover (L405)	BCM - Body Control Module	DATA
GK52-14C204-EAA.vbf	Range Rover (L405)	PCM - Powertrain Control Module	EXE
GK52-14C204-EAB.vbf	Range Rover (L405)	PCM - Powertrain Control Module	EXE
GK52-14C204-EAC.vbf	Range Rover (L405)	PCM - Powertrain Control Module	EXE
GK52-14C204-EAD.vbf	Range Rover (L405)	PCM - Powertrain Control Module	EXE
GK52-14C204-EAE.vbf	Range Rover (L405)	PCM - Powertrain Control Module	EXE
GK52-14C204-ECA.vbf	Range Rover (L405)	PCM - Powertrain Control Module	EXE
GK52-14C204-ECB.vbf	Range Rover (L405)	PCM - Powertrain Control Module	EXE
GK52-14C204-ECC.vbf	Range Rover (L405)	PCM - Powertrain Control Module	EXE
GK52-14C204-EEA.vbf	Range Rover (L405)	PCM - Powertrain Control Module	EXE
GK52-14C204-EEB.vbf	Range Rover (L405)	PCM - Powertrain Control Module	EXE
GK52-14C204-EEC.vbf	Range Rover (L405)	PCM - Powertrain Control Module	EXE
GK52-14C204-ETA.vbf	Range Rover (L405)	PCM - Powertrain Control Module	EXE
GK52-14C204-ETB.vbf	Range Rover (L405)	PCM - Powertrain Control Module	EXE
GK52-14C204-ETC.vbf	Range Rover (L405)	PCM - Powertrain Control Module	EXE
GK52-14C204-ETD.vbf	Range Rover (L405)	PCM - Powertrain Control Module	EXE
GK52-14C204-ETE.vbf	Range Rover (L405)	PCM - Powertrain Control Module	EXE
GK52-14C204-ETF.vbf	Range Rover (L405)	PCM - Powertrain Control Module	EXE
GK52-14C204-YCA.vbf	Range Rover (L405)	PCM - Powertrain Control Module	EXE
GK52-14C204-YCB.vbf	Range Rover (L405)	PCM - Powertrain Control Module	EXE
GK52-14C204-YCC.vbf	Range Rover (L405)	PCM - Powertrain Control Module	EXE
GK52-14C204-YTA.vbf	Range Rover (L405)	PCM - Powertrain Control Module	EXE
GK52-14C204-YTB.vbf	Range Rover (L405)	PCM - Powertrain Control Module	EXE
GK52-14C204-YTC.vbf	Range Rover (L405)	PCM - Powertrain Control Module	EXE
GK52-14C218-AA.vbf	Range Rover (L405)	PSCM - Power Steering Control Module	EXE
GK52-14C218-BA.vbf	Range Rover (L405)	PSCM - Power Steering Control Module	EXE
GK52-14C218-CA.vbf	Range Rover (L405)	PSCM - Power Steering Control Module	EXE
GK52-14C526-BA.vbf	Range Rover (L405)	Not specified	EXE
GK52-14C527-AA.vbf	Range Rover (L405)	Not specified	DATA
GK52-14C527-JA.vbf	Range Rover (L405)	Not specified	DATA
GK52-14C549-AAA.vbf	Range Rover (L405)	PSM - Passenger Front Seat Module	EXE
GK52-14C549-AAB.vbf	Range Rover (L405)	PSM - Passenger Front Seat Module	EXE
GK52-14C549-AAC.vbf	Range Rover (L405)	PSM - Passenger Front Seat Module	EXE
GK52-14C549-ABA.vbf	Range Rover (L405)	PSM - Passenger Front Seat Module	EXE
GK52-14C549-ABB.vbf	Range Rover (L405)	PSM - Passenger Front Seat Module	EXE
GK52-14C549-ABC.vbf	Range Rover (L405)	PSM - Passenger Front Seat Module	EXE
GK52-14C549-BAA.vbf	Range Rover (L405)	PSM - Passenger Front Seat Module	EXE
GK52-14C549-BAB.vbf	Range Rover (L405)	PSM - Passenger Front Seat Module	EXE
GK52-14C549-BAC.vbf	Range Rover (L405)	PSM - Passenger Front Seat Module	EXE
GK52-14C549-BBA.vbf	Range Rover (L405)	PSM - Passenger Front Seat Module	EXE
GK52-14C549-BBB.vbf	Range Rover (L405)	PSM - Passenger Front Seat Module	EXE
GK52-14C549-BBC.vbf	Range Rover (L405)	PSM - Passenger Front Seat Module	EXE
GK52-14C549-BCA.vbf	Range Rover (L405)	PSM - Passenger Front Seat Module	EXE
GK52-14C549-BCB.vbf	Range Rover (L405)	PSM - Passenger Front Seat Module	EXE
GK52-14C549-BCC.vbf	Range Rover (L405)	PSM - Passenger Front Seat Module	EXE
GK52-14C549-BDA.vbf	Range Rover (L405)	PSM - Passenger Front Seat Module	EXE
GK52-14C549-BDB.vbf	Range Rover (L405)	PSM - Passenger Front Seat Module	EXE
GK52-14C549-BDC.vbf	Range Rover (L405)	PSM - Passenger Front Seat Module	EXE
GK52-14C549-BEA.vbf	Range Rover (L405)	PSM - Passenger Front Seat Module	EXE
GK52-14C549-BEB.vbf	Range Rover (L405)	PSM - Passenger Front Seat Module	EXE
GK52-14C549-BEC.vbf	Range Rover (L405)	PSM - Passenger Front Seat Module	EXE
GK52-14C549-CAA.vbf	Range Rover (L405)	PSM - Passenger Front Seat Module	EXE
GK52-14C549-CAB.vbf	Range Rover (L405)	PSM - Passenger Front Seat Module	EXE
GK52-14C549-CAD.vbf	Range Rover (L405)	PSM - Passenger Front Seat Module	EXE
GK52-14C549-CBA.vbf	Range Rover (L405)	PSM - Passenger Front Seat Module	EXE
GK52-14C549-CBB.vbf	Range Rover (L405)	PSM - Passenger Front Seat Module	EXE
GK52-14C549-CBD.vbf	Range Rover (L405)	PSM - Passenger Front Seat Module	EXE
GK52-14C549-CCA.vbf	Range Rover (L405)	PSM - Passenger Front Seat Module	EXE
GK52-14C549-CCB.vbf	Range Rover (L405)	PSM - Passenger Front Seat Module	EXE
GK52-14C549-CCD.vbf	Range Rover (L405)	PSM - Passenger Front Seat Module	EXE
GK52-14C549-CDA.vbf	Range Rover (L405)	PSM - Passenger Front Seat Module	EXE
GK52-14C549-CDB.vbf	Range Rover (L405)	PSM - Passenger Front Seat Module	EXE
GK52-14C549-CDD.vbf	Range Rover (L405)	PSM - Passenger Front Seat Module	EXE
GK52-14C549-CEA.vbf	Range Rover (L405)	PSM - Passenger Front Seat Module	EXE
GK52-14C549-CEB.vbf	Range Rover (L405)	PSM - Passenger Front Seat Module	EXE
GK52-14C549-CED.vbf	Range Rover (L405)	PSM - Passenger Front Seat Module	EXE
GK52-14C549-DAA.vbf	Range Rover (L405)	PSM - Passenger Front Seat Module	EXE
GK52-14C549-DAB.vbf	Range Rover (L405)	PSM - Passenger Front Seat Module	EXE
GK52-14C549-DAD.vbf	Range Rover (L405)	PSM - Passenger Front Seat Module	EXE
GK52-14C549-DBA.vbf	Range Rover (L405)	PSM - Passenger Front Seat Module	EXE
GK52-14C549-DBB.vbf	Range Rover (L405)	PSM - Passenger Front Seat Module	EXE
GK52-14C549-DBD.vbf	Range Rover (L405)	PSM - Passenger Front Seat Module	EXE
GK52-14C549-DCA.vbf	Range Rover (L405)	PSM - Passenger Front Seat Module	EXE
GK52-14C549-DCB.vbf	Range Rover (L405)	PSM - Passenger Front Seat Module	EXE
GK52-14C549-DCD.vbf	Range Rover (L405)	PSM - Passenger Front Seat Module	EXE
GK52-14C549-DDA.vbf	Range Rover (L405)	PSM - Passenger Front Seat Module	EXE

File name	Vehicle line (indicative)	Module (ECU)	Type
GK52-14C549-DDB.vbf	Range Rover (L405)	PSM - Passenger Front Seat Module	EXE
GK52-14C549-DDD.vbf	Range Rover (L405)	PSM - Passenger Front Seat Module	EXE
GK52-14C549-DEA.vbf	Range Rover (L405)	PSM - Passenger Front Seat Module	EXE
GK52-14C549-DEB.vbf	Range Rover (L405)	PSM - Passenger Front Seat Module	EXE
GK52-14C549-DED.vbf	Range Rover (L405)	PSM - Passenger Front Seat Module	EXE
GK52-14C549-EAA.vbf	Range Rover (L405)	PSM - Passenger Front Seat Module	EXE
GK52-14C549-EAB.vbf	Range Rover (L405)	PSM - Passenger Front Seat Module	EXE
GK52-14C549-EBA.vbf	Range Rover (L405)	PSM - Passenger Front Seat Module	EXE
GK52-14C549-EBB.vbf	Range Rover (L405)	PSM - Passenger Front Seat Module	EXE
GK52-14C549-ECA.vbf	Range Rover (L405)	PSM - Passenger Front Seat Module	EXE
GK52-14C549-ECB.vbf	Range Rover (L405)	PSM - Passenger Front Seat Module	EXE
GK52-14C549-EDA.vbf	Range Rover (L405)	PSM - Passenger Front Seat Module	EXE
GK52-14C549-EDB.vbf	Range Rover (L405)	PSM - Passenger Front Seat Module	EXE
GK52-14C549-EEA.vbf	Range Rover (L405)	PSM - Passenger Front Seat Module	EXE
GK52-14C549-EEB.vbf	Range Rover (L405)	PSM - Passenger Front Seat Module	EXE
GK52-14C549-FAA.vbf	Range Rover (L405)	PSM - Passenger Front Seat Module	EXE
GK52-14C549-FAB.vbf	Range Rover (L405)	PSM - Passenger Front Seat Module	EXE
GK52-14C549-FBA.vbf	Range Rover (L405)	PSM - Passenger Front Seat Module	EXE
GK52-14C549-FBB.vbf	Range Rover (L405)	PSM - Passenger Front Seat Module	EXE
GK52-14C549-FCA.vbf	Range Rover (L405)	PSM - Passenger Front Seat Module	EXE
GK52-14C549-FCB.vbf	Range Rover (L405)	PSM - Passenger Front Seat Module	EXE
GK52-14C549-FDA.vbf	Range Rover (L405)	PSM - Passenger Front Seat Module	EXE
GK52-14C549-FDB.vbf	Range Rover (L405)	PSM - Passenger Front Seat Module	EXE
GK52-14C549-FEA.vbf	Range Rover (L405)	PSM - Passenger Front Seat Module	EXE
GK52-14C549-FEB.vbf	Range Rover (L405)	PSM - Passenger Front Seat Module	EXE
GK52-14C549-FFA.vbf	Range Rover (L405)	PSM - Passenger Front Seat Module	EXE
GK52-14C549-FFB.vbf	Range Rover (L405)	PSM - Passenger Front Seat Module	EXE
GK52-14C549-FGA.vbf	Range Rover (L405)	PSM - Passenger Front Seat Module	EXE
GK52-14C549-FGB.vbf	Range Rover (L405)	PSM - Passenger Front Seat Module	EXE
GK52-14C549-FHA.vbf	Range Rover (L405)	PSM - Passenger Front Seat Module	EXE
GK52-14C549-FHB.vbf	Range Rover (L405)	PSM - Passenger Front Seat Module	EXE
GK52-14C549-FJA.vbf	Range Rover (L405)	PSM - Passenger Front Seat Module	EXE
GK52-14C549-FJB.vbf	Range Rover (L405)	PSM - Passenger Front Seat Module	EXE
GK52-14C549-FKA.vbf	Range Rover (L405)	PSM - Passenger Front Seat Module	EXE
GK52-14C549-FKB.vbf	Range Rover (L405)	PSM - Passenger Front Seat Module	EXE
GK52-14C609-AA.vbf	Range Rover (L405)	PSCM - Power Steering Control Module	EXE
GK52-14C609-AB.vbf	Range Rover (L405)	PSCM - Power Steering Control Module	EXE
GK52-14C609-AD.vbf	Range Rover (L405)	PSCM - Power Steering Control Module	EXE
GK52-14D196-AA.vbf	Range Rover (L405)	IPMA - Image Processing Module A	EXE
GK52-14D197-AA.vbf	Range Rover (L405)	IPMA - Image Processing Module A	DATA
GK52-14D198-AA.vbf	Range Rover (L405)	IPMA - Image Processing Module A	SBL
GK52-14D481-BA.vbf	Range Rover (L405)	IPMB - Image Processing Module B	DATA
GK52-14D481-CA.vbf	Range Rover (L405)	IPMB - Image Processing Module B	DATA
GK52-14D485-BA.vbf	Range Rover (L405)	IPMB - Image Processing Module B	DATA
GK52-14D485-BB.vbf	Range Rover (L405)	IPMB - Image Processing Module B	DATA
GK52-14D485-BC.vbf	Range Rover (L405)	IPMB - Image Processing Module B	DATA
GK52-14D485-CA.vbf	Range Rover (L405)	IPMB - Image Processing Module B	DATA
GK52-14D485-CB.vbf	Range Rover (L405)	IPMB - Image Processing Module B	DATA
GK52-14D485-CC.vbf	Range Rover (L405)	IPMB - Image Processing Module B	DATA
GK52-14D564-AB.vbf	Range Rover (L405)	SODL - Side Obstacle Detection Control Module - Left	DATA
GK52-14D564-BB.vbf	Range Rover (L405)	SODR - Side Obstacle Detection Control Module - Right	DATA
GK52-14E094-JAB.vbf	Range Rover (L405)	CHCM - Chassis Control Module	EXE
GK52-14E094-JAC.vbf	Range Rover (L405)	CHCM - Chassis Control Module	EXE
GK52-14E094-JAD.vbf	Range Rover (L405)	CHCM - Chassis Control Module	EXE
GK52-14E094-JAE.vbf	Range Rover (L405)	CHCM - Chassis Control Module	EXE
GK52-14E094-JAF.vbf	Range Rover (L405)	CHCM - Chassis Control Module	EXE
GK52-14E094-JBB.vbf	Range Rover (L405)	CHCM - Chassis Control Module	EXE
GK52-14E094-JBC.vbf	Range Rover (L405)	CHCM - Chassis Control Module	EXE
GK52-14E094-JBD.vbf	Range Rover (L405)	CHCM - Chassis Control Module	EXE
GK52-14E094-JBF.vbf	Range Rover (L405)	CHCM - Chassis Control Module	EXE
GK52-14E094-JBG.vbf	Range Rover (L405)	CHCM - Chassis Control Module	EXE
GK52-14E094-JBH.vbf	Range Rover (L405)	CHCM - Chassis Control Module	EXE
GK52-14E094-JBJ.vbf	Range Rover (L405)	CHCM - Chassis Control Module	EXE
GK52-14E094-JCB.vbf	Range Rover (L405)	CHCM - Chassis Control Module	EXE
GK52-14E094-JCC.vbf	Range Rover (L405)	CHCM - Chassis Control Module	EXE
GK52-14E094-JCD.vbf	Range Rover (L405)	CHCM - Chassis Control Module	EXE
GK52-14E094-JCE.vbf	Range Rover (L405)	CHCM - Chassis Control Module	EXE
GK52-14E094-JCF.vbf	Range Rover (L405)	CHCM - Chassis Control Module	EXE
GK52-14E094-JDB.vbf	Range Rover (L405)	CHCM - Chassis Control Module	EXE
GK52-14E094-JDC.vbf	Range Rover (L405)	CHCM - Chassis Control Module	EXE
GK52-14E094-JDD.vbf	Range Rover (L405)	CHCM - Chassis Control Module	EXE
GK52-14E094-JDE.vbf	Range Rover (L405)	CHCM - Chassis Control Module	EXE
GK52-14E094-JDF.vbf	Range Rover (L405)	CHCM - Chassis Control Module	EXE
GK52-14E094-JEB.vbf	Range Rover (L405)	CHCM - Chassis Control Module	EXE
GK52-14E094-JEC.vbf	Range Rover (L405)	CHCM - Chassis Control Module	EXE
GK52-14E094-JED.vbf	Range Rover (L405)	CHCM - Chassis Control Module	EXE

File name	Vehicle line (indicative)	Module (ECU)	Type
GK52-14E094-JEE.vbf	Range Rover (L405)	CHCM - Chassis Control Module	EXE
GK52-14E094-JEF.vbf	Range Rover (L405)	CHCM - Chassis Control Module	EXE
GK52-14E094-JEG.vbf	Range Rover (L405)	CHCM - Chassis Control Module	EXE
GK52-14E094-JFB.vbf	Range Rover (L405)	CHCM - Chassis Control Module	EXE
GK52-14E094-JFC.vbf	Range Rover (L405)	CHCM - Chassis Control Module	EXE
GK52-14E094-JFD.vbf	Range Rover (L405)	CHCM - Chassis Control Module	EXE
GK52-14E094-JFE.vbf	Range Rover (L405)	CHCM - Chassis Control Module	EXE
GK52-14E094-JFF.vbf	Range Rover (L405)	CHCM - Chassis Control Module	EXE
GK52-14E094-JGB.vbf	Range Rover (L405)	CHCM - Chassis Control Module	EXE
GK52-14E094-JGC.vbf	Range Rover (L405)	CHCM - Chassis Control Module	EXE
GK52-14E094-JGD.vbf	Range Rover (L405)	CHCM - Chassis Control Module	EXE
GK52-14E094-JGE.vbf	Range Rover (L405)	CHCM - Chassis Control Module	EXE
GK52-14E094-JGF.vbf	Range Rover (L405)	CHCM - Chassis Control Module	EXE
GK52-14E094-JHB.vbf	Range Rover (L405)	CHCM - Chassis Control Module	EXE
GK52-14E094-JHC.vbf	Range Rover (L405)	CHCM - Chassis Control Module	EXE
GK52-14E094-JHE.vbf	Range Rover (L405)	CHCM - Chassis Control Module	EXE
GK52-14E094-JHF.vbf	Range Rover (L405)	CHCM - Chassis Control Module	EXE
GK52-14E094-JHG.vbf	Range Rover (L405)	CHCM - Chassis Control Module	EXE
GK52-14E094-JHH.vbf	Range Rover (L405)	CHCM - Chassis Control Module	EXE
GK52-14E094-JJB.vbf	Range Rover (L405)	CHCM - Chassis Control Module	EXE
GK52-14E094-JJC.vbf	Range Rover (L405)	CHCM - Chassis Control Module	EXE
GK52-14E094-JJD.vbf	Range Rover (L405)	CHCM - Chassis Control Module	EXE
GK52-14E094-JJE.vbf	Range Rover (L405)	CHCM - Chassis Control Module	EXE
GK52-14E094-JJF.vbf	Range Rover (L405)	CHCM - Chassis Control Module	EXE
GK52-14E094-JKB.vbf	Range Rover (L405)	CHCM - Chassis Control Module	EXE
GK52-14E094-JKC.vbf	Range Rover (L405)	CHCM - Chassis Control Module	EXE
GK52-14E094-JKD.vbf	Range Rover (L405)	CHCM - Chassis Control Module	EXE
GK52-14E094-JKE.vbf	Range Rover (L405)	CHCM - Chassis Control Module	EXE
GK52-14E094-JKF.vbf	Range Rover (L405)	CHCM - Chassis Control Module	EXE
GK52-14E094-JKG.vbf	Range Rover (L405)	CHCM - Chassis Control Module	EXE
GK52-14E094-JLB.vbf	Range Rover (L405)	CHCM - Chassis Control Module	EXE
GK52-14E094-JLC.vbf	Range Rover (L405)	CHCM - Chassis Control Module	EXE
GK52-14E094-JLD.vbf	Range Rover (L405)	CHCM - Chassis Control Module	EXE
GK52-14E094-JLE.vbf	Range Rover (L405)	CHCM - Chassis Control Module	EXE
GK52-14E094-JLF.vbf	Range Rover (L405)	CHCM - Chassis Control Module	EXE
GK52-14E094-JMB.vbf	Range Rover (L405)	CHCM - Chassis Control Module	EXE
GK52-14E094-JRB.vbf	Range Rover (L405)	CHCM - Chassis Control Module	EXE
GK52-14E094-JRC.vbf	Range Rover (L405)	CHCM - Chassis Control Module	EXE
GK52-14E094-JRD.vbf	Range Rover (L405)	CHCM - Chassis Control Module	EXE
GK52-14E094-JRE.vbf	Range Rover (L405)	CHCM - Chassis Control Module	EXE
GK52-14E094-JRF.vbf	Range Rover (L405)	CHCM - Chassis Control Module	EXE
GK52-14E094-JSB.vbf	Range Rover (L405)	CHCM - Chassis Control Module	EXE
GK52-14E094-JSC.vbf	Range Rover (L405)	CHCM - Chassis Control Module	EXE
GK52-14E094-JSD.vbf	Range Rover (L405)	CHCM - Chassis Control Module	EXE
GK52-14E094-JSE.vbf	Range Rover (L405)	CHCM - Chassis Control Module	EXE
GK52-14E094-JSF.vbf	Range Rover (L405)	CHCM - Chassis Control Module	EXE
GK52-14F022-EA.vbf	Range Rover (L405)	IPMB - Image Processing Module B	DATA
GK52-14F022-EB.vbf	Range Rover (L405)	IPMB - Image Processing Module B	DATA
GK52-14F022-EC.vbf	Range Rover (L405)	IPMB - Image Processing Module B	DATA
GK52-14F022-EE.vbf	Range Rover (L405)	IPMB - Image Processing Module B	DATA
GK52-14F022-FA.vbf	Range Rover (L405)	IPMB - Image Processing Module B	DATA
GK52-14F022-FB.vbf	Range Rover (L405)	IPMB - Image Processing Module B	DATA
GK52-14F022-FC.vbf	Range Rover (L405)	IPMB - Image Processing Module B	DATA
GK52-14F022-FE.vbf	Range Rover (L405)	IPMB - Image Processing Module B	DATA
GK52-14F435-NAB.vbf	Range Rover (L405)	CHCMB - Chassis Control Module B	EXE
GK52-14F435-NAC.vbf	Range Rover (L405)	CHCMB - Chassis Control Module B	EXE
GK52-14F435-NAD.vbf	Range Rover (L405)	CHCMB - Chassis Control Module B	EXE
GK52-14F435-NBB.vbf	Range Rover (L405)	CHCMB - Chassis Control Module B	EXE
GK52-14F435-NBC.vbf	Range Rover (L405)	CHCMB - Chassis Control Module B	EXE
GK52-14F435-NBD.vbf	Range Rover (L405)	CHCMB - Chassis Control Module B	EXE
GK52-14F435-NBE.vbf	Range Rover (L405)	CHCMB - Chassis Control Module B	EXE
GK52-14F435-NCB.vbf	Range Rover (L405)	CHCMB - Chassis Control Module B	EXE
GK52-14F435-NCC.vbf	Range Rover (L405)	CHCMB - Chassis Control Module B	EXE
GK52-14F435-NCD.vbf	Range Rover (L405)	CHCMB - Chassis Control Module B	EXE
GK52-14F435-NDB.vbf	Range Rover (L405)	CHCMB - Chassis Control Module B	EXE
GK52-14F435-NDC.vbf	Range Rover (L405)	CHCMB - Chassis Control Module B	EXE
GK52-14F435-NDD.vbf	Range Rover (L405)	CHCMB - Chassis Control Module B	EXE
GK52-14F456-AA.vbf	Range Rover (L405)	IPMA - Image Processing Module A	DATA
GK52-14F456-BB.vbf	Range Rover (L405)	IPMA - Image Processing Module A	DATA
GK52-14F456-BC.vbf	Range Rover (L405)	IPMA - Image Processing Module A	DATA
GK52-7J104-BAA.vbf	Range Rover (L405)	TCM - Transmission Control Module	EXE
GK52-7J104-BAB.vbf	Range Rover (L405)	TCM - Transmission Control Module	EXE
GK52-7J104-BAD.vbf	Range Rover (L405)	TCM - Transmission Control Module	EXE
GK52-7J104-BBA.vbf	Range Rover (L405)	TCM - Transmission Control Module	EXE
GK52-7J104-BBB.vbf	Range Rover (L405)	TCM - Transmission Control Module	EXE
GK52-7J104-BBC.vbf	Range Rover (L405)	TCM - Transmission Control Module	EXE

File name	Vehicle line (indicative)	Module (ECU)	Type
GK52-7J104-BBD.vbf	Range Rover (L405)	TCM - Transmission Control Module	EXE
GK52-7J104-BBE.vbf	Range Rover (L405)	TCM - Transmission Control Module	EXE
GK52-7J104-BGA.vbf	Range Rover (L405)	TCM - Transmission Control Module	EXE
GK52-7J104-BGB.vbf	Range Rover (L405)	TCM - Transmission Control Module	EXE
GK52-7J104-BGC.vbf	Range Rover (L405)	TCM - Transmission Control Module	EXE
GK52-7J104-BGD.vbf	Range Rover (L405)	TCM - Transmission Control Module	EXE
GK52-7J104-BGE.vbf	Range Rover (L405)	TCM - Transmission Control Module	EXE
GK52-7J104-BHA.vbf	Range Rover (L405)	TCM - Transmission Control Module	EXE
GK52-7J104-BHB.vbf	Range Rover (L405)	TCM - Transmission Control Module	EXE
GK52-7J104-BHC.vbf	Range Rover (L405)	TCM - Transmission Control Module	EXE
GK52-7J104-BHD.vbf	Range Rover (L405)	TCM - Transmission Control Module	EXE
GK52-7J104-BJA.vbf	Range Rover (L405)	TCM - Transmission Control Module	EXE
GK52-7J104-BJB.vbf	Range Rover (L405)	TCM - Transmission Control Module	EXE
GK52-7J104-BKA.vbf	Range Rover (L405)	TCM - Transmission Control Module	EXE
GK52-7J104-BKB.vbf	Range Rover (L405)	TCM - Transmission Control Module	EXE
GK52-7J104-BKC.vbf	Range Rover (L405)	TCM - Transmission Control Module	EXE
GK52-7J104-BKD.vbf	Range Rover (L405)	TCM - Transmission Control Module	EXE
GK52-7J104-BKE.vbf	Range Rover (L405)	TCM - Transmission Control Module	EXE
GK52-7J104-BLA.vbf	Range Rover (L405)	TCM - Transmission Control Module	EXE
GK52-7J104-BLB.vbf	Range Rover (L405)	TCM - Transmission Control Module	EXE
GK52-7J104-BLC.vbf	Range Rover (L405)	TCM - Transmission Control Module	EXE
GK52-7J104-BLD.vbf	Range Rover (L405)	TCM - Transmission Control Module	EXE
GK52-7J104-BLE.vbf	Range Rover (L405)	TCM - Transmission Control Module	EXE
GK52-7J104-BMA.vbf	Range Rover (L405)	TCM - Transmission Control Module	EXE
GK52-7J104-BMB.vbf	Range Rover (L405)	TCM - Transmission Control Module	EXE
GK52-7J104-BMC.vbf	Range Rover (L405)	TCM - Transmission Control Module	EXE
GK52-7J104-BMD.vbf	Range Rover (L405)	TCM - Transmission Control Module	EXE
GK52-7J104-BME.vbf	Range Rover (L405)	TCM - Transmission Control Module	EXE
GK5M-14C152-AA.vbf	Not specified	TPM - Tire Pressure Monitor Module	DATA
GK5M-14C218-AA.vbf	Not specified	PSCM - Power Steering Control Module	EXE
GK5M-14E094-JPB.vbf	Not specified	CHCM - Chassis Control Module	EXE
GK5M-14E094-JPC.vbf	Not specified	CHCM - Chassis Control Module	EXE
GK5M-14E094-JPD.vbf	Not specified	CHCM - Chassis Control Module	EXE
GK5M-14E094-JPE.vbf	Not specified	CHCM - Chassis Control Module	EXE
GK5M-14E094-JPF.vbf	Not specified	CHCM - Chassis Control Module	EXE
GK5M-14E094-JRB.vbf	Not specified	CHCM - Chassis Control Module	EXE
GK5M-14E094-JRC.vbf	Not specified	CHCM - Chassis Control Module	EXE
GK5M-14E094-JRE.vbf	Not specified	CHCM - Chassis Control Module	EXE
GK5M-14E094-JRF.vbf	Not specified	CHCM - Chassis Control Module	EXE
GK5M-14E094-JRG.vbf	Not specified	CHCM - Chassis Control Module	EXE
GK5M-14E094-JRH.vbf	Not specified	CHCM - Chassis Control Module	EXE
GK5M-14F435-NEA.vbf	Not specified	CHCMB - Chassis Control Module B	EXE
GK5M-14F435-NEB.vbf	Not specified	CHCMB - Chassis Control Module B	EXE
GK5M-14F435-NEC.vbf	Not specified	CHCMB - Chassis Control Module B	EXE
GK5M-606K42-AA.vbf	Not specified	YRM - Yaw Rate Sensor Module	EXE
GK5M-606K42-AB.vbf	Not specified	YRM - Yaw Rate Sensor Module	EXE
GK5M-606K43-AB.vbf	Not specified	YRM - Yaw Rate Sensor Module	EXE
GK5M-606K43-AC.vbf	Not specified	YRM - Yaw Rate Sensor Module	EXE
GK5M-606K43-AD.vbf	Not specified	YRM - Yaw Rate Sensor Module	EXE
GK5M-606K44-AB.vbf	Not specified	YRM - Yaw Rate Sensor Module	EXE
GK5M-606K44-AC.vbf	Not specified	YRM - Yaw Rate Sensor Module	EXE
GK5M-606K44-BB.vbf	Not specified	YRM - Yaw Rate Sensor Module	EXE
GK5M-606K44-BC.vbf	Not specified	YRM - Yaw Rate Sensor Module	EXE
GK5M-606K44-CA.vbf	Not specified	YRM - Yaw Rate Sensor Module	EXE
GK5M-606K45-AA.vbf	Not specified	CRM - Calf Rest Module	SBL
GK62-12K532-PBA.vbf	Range Rover Sport (L494)	PCM - Powertrain Control Module	DATA
GK62-12K532-PBB.vbf	Range Rover Sport (L494)	PCM - Powertrain Control Module	DATA
GK62-12K532-PBC.vbf	Range Rover Sport (L494)	PCM - Powertrain Control Module	DATA
GK62-12K532-PBD.vbf	Range Rover Sport (L494)	PCM - Powertrain Control Module	DATA
GK62-12K532-PBE.vbf	Range Rover Sport (L494)	PCM - Powertrain Control Module	DATA
GK62-12K532-PBF.vbf	Range Rover Sport (L494)	PCM - Powertrain Control Module	DATA
GK62-12K532-PBG.vbf	Range Rover Sport (L494)	PCM - Powertrain Control Module	DATA
GK62-12K532-PBH.vbf	Range Rover Sport (L494)	PCM - Powertrain Control Module	DATA
GK62-12K532-PBJ.vbf	Range Rover Sport (L494)	PCM - Powertrain Control Module	DATA
GK62-12K532-PBK.vbf	Range Rover Sport (L494)	PCM - Powertrain Control Module	DATA
GK62-12K532-PCA.vbf	Range Rover Sport (L494)	PCM - Powertrain Control Module	DATA
GK62-12K532-PCB.vbf	Range Rover Sport (L494)	PCM - Powertrain Control Module	DATA
GK62-12K532-PCC.vbf	Range Rover Sport (L494)	PCM - Powertrain Control Module	DATA
GK62-12K532-PCD.vbf	Range Rover Sport (L494)	PCM - Powertrain Control Module	DATA
GK62-12K532-PCE.vbf	Range Rover Sport (L494)	PCM - Powertrain Control Module	DATA
GK62-12K532-PCF.vbf	Range Rover Sport (L494)	PCM - Powertrain Control Module	DATA
GK62-12K532-PCG.vbf	Range Rover Sport (L494)	PCM - Powertrain Control Module	DATA
GK62-12K532-PCH.vbf	Range Rover Sport (L494)	PCM - Powertrain Control Module	DATA
GK62-12K532-PCJ.vbf	Range Rover Sport (L494)	PCM - Powertrain Control Module	DATA
GK62-12K532-PDA.vbf	Range Rover Sport (L494)	PCM - Powertrain Control Module	DATA
GK62-12K532-PDB.vbf	Range Rover Sport (L494)	PCM - Powertrain Control Module	DATA

File name	Vehicle line (indicative)	Module (ECU)	Type
GK62-12K532-PDC.vbf	Range Rover Sport (L494)	PCM - Powertrain Control Module	DATA
GK62-12K532-PDD.vbf	Range Rover Sport (L494)	PCM - Powertrain Control Module	DATA
GK62-12K532-PDE.vbf	Range Rover Sport (L494)	PCM - Powertrain Control Module	DATA
GK62-12K532-PDF.vbf	Range Rover Sport (L494)	PCM - Powertrain Control Module	DATA
GK62-12K532-PDG.vbf	Range Rover Sport (L494)	PCM - Powertrain Control Module	DATA
GK62-12K532-PDH.vbf	Range Rover Sport (L494)	PCM - Powertrain Control Module	DATA
GK62-12K532-PDJ.vbf	Range Rover Sport (L494)	PCM - Powertrain Control Module	DATA
GK62-12K532-PEC.vbf	Range Rover Sport (L494)	PCM - Powertrain Control Module	DATA
GK62-12K532-PED.vbf	Range Rover Sport (L494)	PCM - Powertrain Control Module	DATA
GK62-12K532-PEE.vbf	Range Rover Sport (L494)	PCM - Powertrain Control Module	DATA
GK62-12K532-PEF.vbf	Range Rover Sport (L494)	PCM - Powertrain Control Module	DATA
GK62-12K532-PFC.vbf	Range Rover Sport (L494)	PCM - Powertrain Control Module	DATA
GK62-12K532-PFD.vbf	Range Rover Sport (L494)	PCM - Powertrain Control Module	DATA
GK62-12K532-PFE.vbf	Range Rover Sport (L494)	PCM - Powertrain Control Module	DATA
GK62-12K532-PFF.vbf	Range Rover Sport (L494)	PCM - Powertrain Control Module	DATA
GK62-12K532-PGC.vbf	Range Rover Sport (L494)	PCM - Powertrain Control Module	DATA
GK62-12K532-PGD.vbf	Range Rover Sport (L494)	PCM - Powertrain Control Module	DATA
GK62-12K532-PGE.vbf	Range Rover Sport (L494)	PCM - Powertrain Control Module	DATA
GK62-12K532-PGF.vbf	Range Rover Sport (L494)	PCM - Powertrain Control Module	DATA
GK62-12K532-PHC.vbf	Range Rover Sport (L494)	PCM - Powertrain Control Module	DATA
GK62-12K532-PHD.vbf	Range Rover Sport (L494)	PCM - Powertrain Control Module	DATA
GK62-12K532-PHE.vbf	Range Rover Sport (L494)	PCM - Powertrain Control Module	DATA
GK62-12K532-PHF.vbf	Range Rover Sport (L494)	PCM - Powertrain Control Module	DATA
GK62-12K532-PPA.vbf	Range Rover Sport (L494)	PCM - Powertrain Control Module	DATA
GK62-12K532-PPB.vbf	Range Rover Sport (L494)	PCM - Powertrain Control Module	DATA
GK62-12K532-PPC.vbf	Range Rover Sport (L494)	PCM - Powertrain Control Module	DATA
GK62-12K532-PPD.vbf	Range Rover Sport (L494)	PCM - Powertrain Control Module	DATA
GK62-12K532-PPE.vbf	Range Rover Sport (L494)	PCM - Powertrain Control Module	DATA
GK62-12K532-PPF.vbf	Range Rover Sport (L494)	PCM - Powertrain Control Module	DATA
GK62-12K532-PPG.vbf	Range Rover Sport (L494)	PCM - Powertrain Control Module	DATA
GK62-12K532-PPH.vbf	Range Rover Sport (L494)	PCM - Powertrain Control Module	DATA
GK62-12K532-PPJ.vbf	Range Rover Sport (L494)	PCM - Powertrain Control Module	DATA
GK62-12K532-PRA.vbf	Range Rover Sport (L494)	PCM - Powertrain Control Module	DATA
GK62-12K532-PRB.vbf	Range Rover Sport (L494)	PCM - Powertrain Control Module	DATA
GK62-12K532-PRC.vbf	Range Rover Sport (L494)	PCM - Powertrain Control Module	DATA
GK62-12K532-PRD.vbf	Range Rover Sport (L494)	PCM - Powertrain Control Module	DATA
GK62-12K532-PRE.vbf	Range Rover Sport (L494)	PCM - Powertrain Control Module	DATA
GK62-12K532-PRF.vbf	Range Rover Sport (L494)	PCM - Powertrain Control Module	DATA
GK62-12K532-PRG.vbf	Range Rover Sport (L494)	PCM - Powertrain Control Module	DATA
GK62-12K532-PRH.vbf	Range Rover Sport (L494)	PCM - Powertrain Control Module	DATA
GK62-12K532-PRJ.vbf	Range Rover Sport (L494)	PCM - Powertrain Control Module	DATA
GK62-12K532-PRK.vbf	Range Rover Sport (L494)	PCM - Powertrain Control Module	DATA
GK62-12K532-PRL.vbf	Range Rover Sport (L494)	PCM - Powertrain Control Module	DATA
GK62-12K532-PRM.vbf	Range Rover Sport (L494)	PCM - Powertrain Control Module	DATA
GK62-12K532-PRN.vbf	Range Rover Sport (L494)	PCM - Powertrain Control Module	DATA
GK62-12K532-PUC.vbf	Range Rover Sport (L494)	PCM - Powertrain Control Module	DATA
GK62-12K532-PUD.vbf	Range Rover Sport (L494)	PCM - Powertrain Control Module	DATA
GK62-12K532-PUE.vbf	Range Rover Sport (L494)	PCM - Powertrain Control Module	DATA
GK62-12K532-PUF.vbf	Range Rover Sport (L494)	PCM - Powertrain Control Module	DATA
GK62-14C028-AA.vbf	Range Rover Sport (L494)	RCM - Restraints Control Module	EXE
GK62-14C034-AAA.vbf	Range Rover Sport (L494)	DSM - Driver Front Seat Module	EXE
GK62-14C034-AAB.vbf	Range Rover Sport (L494)	DSM - Driver Front Seat Module	EXE
GK62-14C034-AAC.vbf	Range Rover Sport (L494)	DSM - Driver Front Seat Module	EXE
GK62-14C034-ABA.vbf	Range Rover Sport (L494)	DSM - Driver Front Seat Module	EXE
GK62-14C034-ABB.vbf	Range Rover Sport (L494)	DSM - Driver Front Seat Module	EXE
GK62-14C034-ABC.vbf	Range Rover Sport (L494)	DSM - Driver Front Seat Module	EXE
GK62-14C034-ACA.vbf	Range Rover Sport (L494)	DSM - Driver Front Seat Module	EXE
GK62-14C034-ACB.vbf	Range Rover Sport (L494)	DSM - Driver Front Seat Module	EXE
GK62-14C034-ACC.vbf	Range Rover Sport (L494)	DSM - Driver Front Seat Module	EXE
GK62-14C034-ADA.vbf	Range Rover Sport (L494)	DSM - Driver Front Seat Module	EXE
GK62-14C034-ADB.vbf	Range Rover Sport (L494)	DSM - Driver Front Seat Module	EXE
GK62-14C034-ADC.vbf	Range Rover Sport (L494)	DSM - Driver Front Seat Module	EXE
GK62-14C034-AEA.vbf	Range Rover Sport (L494)	DSM - Driver Front Seat Module	EXE
GK62-14C034-AEB.vbf	Range Rover Sport (L494)	DSM - Driver Front Seat Module	EXE
GK62-14C034-AEC.vbf	Range Rover Sport (L494)	DSM - Driver Front Seat Module	EXE
GK62-14C034-AFA.vbf	Range Rover Sport (L494)	DSM - Driver Front Seat Module	EXE
GK62-14C034-BAA.vbf	Range Rover Sport (L494)	DSM - Driver Front Seat Module	EXE
GK62-14C034-BAB.vbf	Range Rover Sport (L494)	DSM - Driver Front Seat Module	EXE
GK62-14C034-BAC.vbf	Range Rover Sport (L494)	DSM - Driver Front Seat Module	EXE
GK62-14C034-BAD.vbf	Range Rover Sport (L494)	DSM - Driver Front Seat Module	EXE
GK62-14C034-BBA.vbf	Range Rover Sport (L494)	DSM - Driver Front Seat Module	EXE
GK62-14C034-BBB.vbf	Range Rover Sport (L494)	DSM - Driver Front Seat Module	EXE
GK62-14C034-BBC.vbf	Range Rover Sport (L494)	DSM - Driver Front Seat Module	EXE
GK62-14C034-BBD.vbf	Range Rover Sport (L494)	DSM - Driver Front Seat Module	EXE
GK62-14C034-BCA.vbf	Range Rover Sport (L494)	DSM - Driver Front Seat Module	EXE
GK62-14C034-BCB.vbf	Range Rover Sport (L494)	DSM - Driver Front Seat Module	EXE

File name	Vehicle line (indicative)	Module (ECU)	Type
GK62-14C034-BCC.vbf	Range Rover Sport (L494)	DSM - Driver Front Seat Module	EXE
GK62-14C034-BCD.vbf	Range Rover Sport (L494)	DSM - Driver Front Seat Module	EXE
GK62-14C034-BDA.vbf	Range Rover Sport (L494)	DSM - Driver Front Seat Module	EXE
GK62-14C034-BDB.vbf	Range Rover Sport (L494)	DSM - Driver Front Seat Module	EXE
GK62-14C034-BDC.vbf	Range Rover Sport (L494)	DSM - Driver Front Seat Module	EXE
GK62-14C034-BDD.vbf	Range Rover Sport (L494)	DSM - Driver Front Seat Module	EXE
GK62-14C034-BEA.vbf	Range Rover Sport (L494)	DSM - Driver Front Seat Module	EXE
GK62-14C034-BEB.vbf	Range Rover Sport (L494)	DSM - Driver Front Seat Module	EXE
GK62-14C034-BEC.vbf	Range Rover Sport (L494)	DSM - Driver Front Seat Module	EXE
GK62-14C034-BED.vbf	Range Rover Sport (L494)	DSM - Driver Front Seat Module	EXE
GK62-14C037-AAB.vbf	Range Rover Sport (L494)	SPCM - Secondary Powertrain Control Module	EXE
GK62-14C037-AAC.vbf	Range Rover Sport (L494)	SPCM - Secondary Powertrain Control Module	EXE
GK62-14C037-AAD.vbf	Range Rover Sport (L494)	SPCM - Secondary Powertrain Control Module	EXE
GK62-14C037-AAE.vbf	Range Rover Sport (L494)	SPCM - Secondary Powertrain Control Module	EXE
GK62-14C037-AAF.vbf	Range Rover Sport (L494)	SPCM - Secondary Powertrain Control Module	EXE
GK62-14C037-ABB.vbf	Range Rover Sport (L494)	SPCM - Secondary Powertrain Control Module	EXE
GK62-14C037-ABC.vbf	Range Rover Sport (L494)	SPCM - Secondary Powertrain Control Module	EXE
GK62-14C037-ABD.vbf	Range Rover Sport (L494)	SPCM - Secondary Powertrain Control Module	EXE
GK62-14C037-ABE.vbf	Range Rover Sport (L494)	SPCM - Secondary Powertrain Control Module	EXE
GK62-14C037-ABF.vbf	Range Rover Sport (L494)	SPCM - Secondary Powertrain Control Module	EXE
GK62-14C037-ACB.vbf	Range Rover Sport (L494)	SPCM - Secondary Powertrain Control Module	EXE
GK62-14C037-ACC.vbf	Range Rover Sport (L494)	SPCM - Secondary Powertrain Control Module	EXE
GK62-14C037-ACD.vbf	Range Rover Sport (L494)	SPCM - Secondary Powertrain Control Module	EXE
GK62-14C037-ACE.vbf	Range Rover Sport (L494)	SPCM - Secondary Powertrain Control Module	EXE
GK62-14C037-ACF.vbf	Range Rover Sport (L494)	SPCM - Secondary Powertrain Control Module	EXE
GK62-14C037-ADB.vbf	Range Rover Sport (L494)	SPCM - Secondary Powertrain Control Module	EXE
GK62-14C037-ADC.vbf	Range Rover Sport (L494)	SPCM - Secondary Powertrain Control Module	EXE
GK62-14C037-ADD.vbf	Range Rover Sport (L494)	SPCM - Secondary Powertrain Control Module	EXE
GK62-14C037-ADE.vbf	Range Rover Sport (L494)	SPCM - Secondary Powertrain Control Module	EXE
GK62-14C037-ADF.vbf	Range Rover Sport (L494)	SPCM - Secondary Powertrain Control Module	EXE
GK62-14C037-AEB.vbf	Range Rover Sport (L494)	SPCM - Secondary Powertrain Control Module	EXE
GK62-14C037-AEC.vbf	Range Rover Sport (L494)	SPCM - Secondary Powertrain Control Module	EXE
GK62-14C037-AED.vbf	Range Rover Sport (L494)	SPCM - Secondary Powertrain Control Module	EXE
GK62-14C037-AEE.vbf	Range Rover Sport (L494)	SPCM - Secondary Powertrain Control Module	EXE
GK62-14C037-AEF.vbf	Range Rover Sport (L494)	SPCM - Secondary Powertrain Control Module	EXE
GK62-14C037-AFB.vbf	Range Rover Sport (L494)	SPCM - Secondary Powertrain Control Module	EXE
GK62-14C037-AFC.vbf	Range Rover Sport (L494)	SPCM - Secondary Powertrain Control Module	EXE
GK62-14C037-AFD.vbf	Range Rover Sport (L494)	SPCM - Secondary Powertrain Control Module	EXE
GK62-14C037-AFE.vbf	Range Rover Sport (L494)	SPCM - Secondary Powertrain Control Module	EXE
GK62-14C037-AFF.vbf	Range Rover Sport (L494)	SPCM - Secondary Powertrain Control Module	EXE
GK62-14C037-AGB.vbf	Range Rover Sport (L494)	SPCM - Secondary Powertrain Control Module	EXE
GK62-14C037-AGC.vbf	Range Rover Sport (L494)	SPCM - Secondary Powertrain Control Module	EXE
GK62-14C037-AGD.vbf	Range Rover Sport (L494)	SPCM - Secondary Powertrain Control Module	EXE
GK62-14C037-AGE.vbf	Range Rover Sport (L494)	SPCM - Secondary Powertrain Control Module	EXE
GK62-14C037-AGF.vbf	Range Rover Sport (L494)	SPCM - Secondary Powertrain Control Module	EXE
GK62-14C037-AHB.vbf	Range Rover Sport (L494)	SPCM - Secondary Powertrain Control Module	EXE
GK62-14C037-AHC.vbf	Range Rover Sport (L494)	SPCM - Secondary Powertrain Control Module	EXE
GK62-14C037-AHD.vbf	Range Rover Sport (L494)	SPCM - Secondary Powertrain Control Module	EXE
GK62-14C037-AHE.vbf	Range Rover Sport (L494)	SPCM - Secondary Powertrain Control Module	EXE
GK62-14C037-AHF.vbf	Range Rover Sport (L494)	SPCM - Secondary Powertrain Control Module	EXE
GK62-14C037-AHG.vbf	Range Rover Sport (L494)	SPCM - Secondary Powertrain Control Module	EXE
GK62-14C037-AKB.vbf	Range Rover Sport (L494)	SPCM - Secondary Powertrain Control Module	EXE
GK62-14C037-AKC.vbf	Range Rover Sport (L494)	SPCM - Secondary Powertrain Control Module	EXE
GK62-14C037-AKD.vbf	Range Rover Sport (L494)	SPCM - Secondary Powertrain Control Module	EXE
GK62-14C037-AKE.vbf	Range Rover Sport (L494)	SPCM - Secondary Powertrain Control Module	EXE
GK62-14C037-AKF.vbf	Range Rover Sport (L494)	SPCM - Secondary Powertrain Control Module	EXE
GK62-14C037-AVB.vbf	Range Rover Sport (L494)	SPCM - Secondary Powertrain Control Module	EXE
GK62-14C037-AVC.vbf	Range Rover Sport (L494)	SPCM - Secondary Powertrain Control Module	EXE
GK62-14C037-AVD.vbf	Range Rover Sport (L494)	SPCM - Secondary Powertrain Control Module	EXE
GK62-14C037-AVE.vbf	Range Rover Sport (L494)	SPCM - Secondary Powertrain Control Module	EXE
GK62-14C037-AVF.vbf	Range Rover Sport (L494)	SPCM - Secondary Powertrain Control Module	EXE
GK62-14C037-BAB.vbf	Range Rover Sport (L494)	ABS - Anit-Lock Brake System (ABS) Control Module	EXE
GK62-14C037-BAC.vbf	Range Rover Sport (L494)	ABS - Anit-Lock Brake System (ABS) Control Module	EXE
GK62-14C037-DJB.vbf	Range Rover Sport (L494)	SPCM - Secondary Powertrain Control Module	EXE
GK62-14C037-DJC.vbf	Range Rover Sport (L494)	SPCM - Secondary Powertrain Control Module	EXE
GK62-14C037-DJD.vbf	Range Rover Sport (L494)	SPCM - Secondary Powertrain Control Module	EXE
GK62-14C037-DJE.vbf	Range Rover Sport (L494)	SPCM - Secondary Powertrain Control Module	EXE
GK62-14C037-DJF.vbf	Range Rover Sport (L494)	SPCM - Secondary Powertrain Control Module	EXE
GK62-14C037-DKB.vbf	Range Rover Sport (L494)	SPCM - Secondary Powertrain Control Module	EXE
GK62-14C037-DKC.vbf	Range Rover Sport (L494)	SPCM - Secondary Powertrain Control Module	EXE
GK62-14C037-DKD.vbf	Range Rover Sport (L494)	SPCM - Secondary Powertrain Control Module	EXE
GK62-14C037-DKE.vbf	Range Rover Sport (L494)	SPCM - Secondary Powertrain Control Module	EXE
GK62-14C037-DKF.vbf	Range Rover Sport (L494)	SPCM - Secondary Powertrain Control Module	EXE
GK62-14C037-DKG.vbf	Range Rover Sport (L494)	SPCM - Secondary Powertrain Control Module	EXE
GK62-14C037-DNB.vbf	Range Rover Sport (L494)	SPCM - Secondary Powertrain Control Module	EXE
GK62-14C037-DNC.vbf	Range Rover Sport (L494)	SPCM - Secondary Powertrain Control Module	EXE

File name	Vehicle line (indicative)	Module (ECU)	Type
GK62-14C037-DND.vbf	Range Rover Sport (L494)	SPCM - Secondary Powertrain Control Module	EXE
GK62-14C037-DNE.vbf	Range Rover Sport (L494)	SPCM - Secondary Powertrain Control Module	EXE
GK62-14C037-DNF.vbf	Range Rover Sport (L494)	SPCM - Secondary Powertrain Control Module	EXE
GK62-14C037-DNG.vbf	Range Rover Sport (L494)	SPCM - Secondary Powertrain Control Module	EXE
GK62-14C037-FAA.vbf	Range Rover Sport (L494)	SPCM - Secondary Powertrain Control Module	EXE
GK62-14C037-FBA.vbf	Range Rover Sport (L494)	SPCM - Secondary Powertrain Control Module	EXE
GK62-14C060-AB.vbf	Range Rover Sport (L494)	FCDIM - Front Control/Display Interface Module	EXE
GK62-14C060-AD.vbf	Range Rover Sport (L494)	FCDIM - Front Control/Display Interface Module	EXE
GK62-14C060-AE.vbf	Range Rover Sport (L494)	FCDIM - Front Control/Display Interface Module	EXE
GK62-14C060-AF.vbf	Range Rover Sport (L494)	FCDIM - Front Control/Display Interface Module	EXE
GK62-14C060-AG.vbf	Range Rover Sport (L494)	FCDIM - Front Control/Display Interface Module	EXE
GK62-14C060-AH.vbf	Range Rover Sport (L494)	FCDIM - Front Control/Display Interface Module	EXE
GK62-14C060-AJ.vbf	Range Rover Sport (L494)	FCDIM - Front Control/Display Interface Module	EXE
GK62-14C060-AK.vbf	Range Rover Sport (L494)	FCDIM - Front Control/Display Interface Module	EXE
GK62-14C060-BB.vbf	Range Rover Sport (L494)	FCDIM - Front Control/Display Interface Module	EXE
GK62-14C060-BD.vbf	Range Rover Sport (L494)	FCDIM - Front Control/Display Interface Module	EXE
GK62-14C060-BE.vbf	Range Rover Sport (L494)	FCDIM - Front Control/Display Interface Module	EXE
GK62-14C060-BF.vbf	Range Rover Sport (L494)	FCDIM - Front Control/Display Interface Module	EXE
GK62-14C060-BG.vbf	Range Rover Sport (L494)	FCDIM - Front Control/Display Interface Module	EXE
GK62-14C060-BH.vbf	Range Rover Sport (L494)	FCDIM - Front Control/Display Interface Module	EXE
GK62-14C060-BJ.vbf	Range Rover Sport (L494)	FCDIM - Front Control/Display Interface Module	EXE
GK62-14C060-BK.vbf	Range Rover Sport (L494)	FCDIM - Front Control/Display Interface Module	EXE
GK62-14C061-AB.vbf	Range Rover Sport (L494)	FCDIM - Front Control/Display Interface Module	DATA
GK62-14C061-AC.vbf	Range Rover Sport (L494)	FCDIM - Front Control/Display Interface Module	DATA
GK62-14C061-AD.vbf	Range Rover Sport (L494)	FCDIM - Front Control/Display Interface Module	DATA
GK62-14C061-AE.vbf	Range Rover Sport (L494)	FCDIM - Front Control/Display Interface Module	DATA
GK62-14C061-AF.vbf	Range Rover Sport (L494)	FCDIM - Front Control/Display Interface Module	DATA
GK62-14C061-AG.vbf	Range Rover Sport (L494)	FCDIM - Front Control/Display Interface Module	DATA
GK62-14C061-AH.vbf	Range Rover Sport (L494)	FCDIM - Front Control/Display Interface Module	DATA
GK62-14C061-AJ.vbf	Range Rover Sport (L494)	FCDIM - Front Control/Display Interface Module	DATA
GK62-14C061-AK.vbf	Range Rover Sport (L494)	FCDIM - Front Control/Display Interface Module	DATA
GK62-14C063-AA.vbf	Range Rover Sport (L494)	FCDIM - Front Control/Display Interface Module	SBL
GK62-14C065-AA.vbf	Range Rover Sport (L494)	DDM - Driver Front Door Module	DATA
GK62-14C065-AB.vbf	Range Rover Sport (L494)	DDM - Driver Front Door Module	DATA
GK62-14C065-AC.vbf	Range Rover Sport (L494)	DDM - Driver Front Door Module	DATA
GK62-14C065-AD.vbf	Range Rover Sport (L494)	DDM - Driver Front Door Module	DATA
GK62-14C065-AE.vbf	Range Rover Sport (L494)	DDM - Driver Front Door Module	DATA
GK62-14C069-AA.vbf	Range Rover Sport (L494)	DRDM - Driver Rear Door Module	DATA
GK62-14C069-AB.vbf	Range Rover Sport (L494)	DRDM - Driver Rear Door Module	DATA
GK62-14C069-AC.vbf	Range Rover Sport (L494)	DRDM - Driver Rear Door Module	DATA
GK62-14C069-AD.vbf	Range Rover Sport (L494)	DRDM - Driver Rear Door Module	DATA
GK62-14C069-AE.vbf	Range Rover Sport (L494)	DRDM - Driver Rear Door Module	DATA
GK62-14C091-AA.vbf	Range Rover Sport (L494)	PAM - Parking Assist Control Module	DATA
GK62-14C091-AB.vbf	Range Rover Sport (L494)	PAM - Parking Assist Control Module	DATA
GK62-14C091-AC.vbf	Range Rover Sport (L494)	PAM - Parking Assist Control Module	DATA
GK62-14C098-AA.vbf	Range Rover Sport (L494)	RCM - Restraints Control Module	DATA
GK62-14C098-AB.vbf	Range Rover Sport (L494)	RCM - Restraints Control Module	DATA
GK62-14C098-BA.vbf	Range Rover Sport (L494)	RCM - Restraints Control Module	DATA
GK62-14C098-BB.vbf	Range Rover Sport (L494)	RCM - Restraints Control Module	DATA
GK62-14C098-CA.vbf	Range Rover Sport (L494)	RCM - Restraints Control Module	DATA
GK62-14C098-CB.vbf	Range Rover Sport (L494)	RCM - Restraints Control Module	DATA
GK62-14C109-AA.vbf	Range Rover Sport (L494)	PDM - Passenger Front Door Module	EXE
GK62-14C109-AB.vbf	Range Rover Sport (L494)	PDM - Passenger Front Door Module	EXE
GK62-14C109-AC.vbf	Range Rover Sport (L494)	PDM - Passenger Front Door Module	DATA
GK62-14C109-AD.vbf	Range Rover Sport (L494)	PDM - Passenger Front Door Module	DATA
GK62-14C109-AE.vbf	Range Rover Sport (L494)	PDM - Passenger Front Door Module	DATA
GK62-14C113-AA.vbf	Range Rover Sport (L494)	PRDM - Passenger Rear Door Module	DATA
GK62-14C113-AB.vbf	Range Rover Sport (L494)	PRDM - Passenger Rear Door Module	DATA
GK62-14C113-AC.vbf	Range Rover Sport (L494)	PRDM - Passenger Rear Door Module	DATA
GK62-14C113-AD.vbf	Range Rover Sport (L494)	PRDM - Passenger Rear Door Module	DATA
GK62-14C113-AE.vbf	Range Rover Sport (L494)	PRDM - Passenger Rear Door Module	DATA
GK62-14C152-AA.vbf	Range Rover Sport (L494)	TPM - Tire Pressure Monitor Module	DATA
GK62-14C152-AB.vbf	Range Rover Sport (L494)	TPM - Tire Pressure Monitor Module	DATA
GK62-14C169-AA.vbf	Range Rover Sport (L494)	PBM - Park Brake Control Module	EXE
GK62-14C169-BA.vbf	Range Rover Sport (L494)	PBM - Park Brake Control Module	EXE
GK62-14C169-BB.vbf	Range Rover Sport (L494)	PBM - Park Brake Control Module	EXE
GK62-14C185-AA.vbf	Range Rover Sport (L494)	BCM - Body Control Module	DATA
GK62-14C185-AC.vbf	Range Rover Sport (L494)	BCM - Body Control Module	DATA
GK62-14C185-AD.vbf	Range Rover Sport (L494)	BCM - Body Control Module	DATA
GK62-14C185-AE.vbf	Range Rover Sport (L494)	BCM - Body Control Module	DATA
GK62-14C185-AJ.vbf	Range Rover Sport (L494)	BCM - Body Control Module	DATA
GK62-14C204-EAA.vbf	Range Rover Sport (L494)	PCM - Powertrain Control Module	EXE
GK62-14C204-EAB.vbf	Range Rover Sport (L494)	PCM - Powertrain Control Module	EXE
GK62-14C204-EAC.vbf	Range Rover Sport (L494)	PCM - Powertrain Control Module	EXE
GK62-14C204-EAD.vbf	Range Rover Sport (L494)	PCM - Powertrain Control Module	EXE
GK62-14C204-EBA.vbf	Range Rover Sport (L494)	PCM - Powertrain Control Module	EXE

File name	Vehicle line (indicative)	Module (ECU)	Type
GK62-14C204-EBB.vbf	Range Rover Sport (L494)	PCM - Powertrain Control Module	EXE
GK62-14C204-EBC.vbf	Range Rover Sport (L494)	PCM - Powertrain Control Module	EXE
GK62-14C204-ECA.vbf	Range Rover Sport (L494)	PCM - Powertrain Control Module	EXE
GK62-14C204-ECB.vbf	Range Rover Sport (L494)	PCM - Powertrain Control Module	EXE
GK62-14C204-EDA.vbf	Range Rover Sport (L494)	PCM - Powertrain Control Module	EXE
GK62-14C204-EDB.vbf	Range Rover Sport (L494)	PCM - Powertrain Control Module	EXE
GK62-14C204-EDC.vbf	Range Rover Sport (L494)	PCM - Powertrain Control Module	EXE
GK62-14C204-EEA.vbf	Range Rover Sport (L494)	PCM - Powertrain Control Module	EXE
GK62-14C204-EEB.vbf	Range Rover Sport (L494)	PCM - Powertrain Control Module	EXE
GK62-14C204-ETA.vbf	Range Rover Sport (L494)	PCM - Powertrain Control Module	EXE
GK62-14C204-ETB.vbf	Range Rover Sport (L494)	PCM - Powertrain Control Module	EXE
GK62-14C204-ETC.vbf	Range Rover Sport (L494)	PCM - Powertrain Control Module	EXE
GK62-14C204-ETD.vbf	Range Rover Sport (L494)	PCM - Powertrain Control Module	EXE
GK62-14C204-ETE.vbf	Range Rover Sport (L494)	PCM - Powertrain Control Module	EXE
GK62-14C218-AA.vbf	Range Rover Sport (L494)	PSCM - Power Steering Control Module	EXE
GK62-14C218-BA.vbf	Range Rover Sport (L494)	PSCM - Power Steering Control Module	EXE
GK62-14C407-AA.vbf	Range Rover Sport (L494)	RCM - Restraints Control Module	SIGCFG
GK62-14C527-EA.vbf	Range Rover Sport (L494)	Not specified	DATA
GK62-14C549-AAA.vbf	Range Rover Sport (L494)	PSM - Passenger Front Seat Module	EXE
GK62-14C549-AAB.vbf	Range Rover Sport (L494)	PSM - Passenger Front Seat Module	EXE
GK62-14C549-AAC.vbf	Range Rover Sport (L494)	PSM - Passenger Front Seat Module	EXE
GK62-14C549-ABA.vbf	Range Rover Sport (L494)	PSM - Passenger Front Seat Module	EXE
GK62-14C549-ABB.vbf	Range Rover Sport (L494)	PSM - Passenger Front Seat Module	EXE
GK62-14C549-ABC.vbf	Range Rover Sport (L494)	PSM - Passenger Front Seat Module	EXE
GK62-14C549-ACA.vbf	Range Rover Sport (L494)	PSM - Passenger Front Seat Module	EXE
GK62-14C549-ACB.vbf	Range Rover Sport (L494)	PSM - Passenger Front Seat Module	EXE
GK62-14C549-ACC.vbf	Range Rover Sport (L494)	PSM - Passenger Front Seat Module	EXE
GK62-14C549-ADA.vbf	Range Rover Sport (L494)	PSM - Passenger Front Seat Module	EXE
GK62-14C549-ADB.vbf	Range Rover Sport (L494)	PSM - Passenger Front Seat Module	EXE
GK62-14C549-ADC.vbf	Range Rover Sport (L494)	PSM - Passenger Front Seat Module	EXE
GK62-14C549-AEA.vbf	Range Rover Sport (L494)	PSM - Passenger Front Seat Module	EXE
GK62-14C549-AEB.vbf	Range Rover Sport (L494)	PSM - Passenger Front Seat Module	EXE
GK62-14C549-AEC.vbf	Range Rover Sport (L494)	PSM - Passenger Front Seat Module	EXE
GK62-14C549-AFA.vbf	Range Rover Sport (L494)	PSM - Passenger Front Seat Module	EXE
GK62-14C549-BAA.vbf	Range Rover Sport (L494)	PSM - Passenger Front Seat Module	EXE
GK62-14C549-BAB.vbf	Range Rover Sport (L494)	PSM - Passenger Front Seat Module	EXE
GK62-14C549-BAC.vbf	Range Rover Sport (L494)	PSM - Passenger Front Seat Module	EXE
GK62-14C549-BAD.vbf	Range Rover Sport (L494)	PSM - Passenger Front Seat Module	EXE
GK62-14C549-BBA.vbf	Range Rover Sport (L494)	PSM - Passenger Front Seat Module	EXE
GK62-14C549-BBB.vbf	Range Rover Sport (L494)	PSM - Passenger Front Seat Module	EXE
GK62-14C549-BBC.vbf	Range Rover Sport (L494)	PSM - Passenger Front Seat Module	EXE
GK62-14C549-BBD.vbf	Range Rover Sport (L494)	PSM - Passenger Front Seat Module	EXE
GK62-14C549-BCA.vbf	Range Rover Sport (L494)	PSM - Passenger Front Seat Module	EXE
GK62-14C549-BCB.vbf	Range Rover Sport (L494)	PSM - Passenger Front Seat Module	EXE
GK62-14C549-BCC.vbf	Range Rover Sport (L494)	PSM - Passenger Front Seat Module	EXE
GK62-14C549-BCD.vbf	Range Rover Sport (L494)	PSM - Passenger Front Seat Module	EXE
GK62-14C549-BDA.vbf	Range Rover Sport (L494)	PSM - Passenger Front Seat Module	EXE
GK62-14C549-BDB.vbf	Range Rover Sport (L494)	PSM - Passenger Front Seat Module	EXE
GK62-14C549-BDC.vbf	Range Rover Sport (L494)	PSM - Passenger Front Seat Module	EXE
GK62-14C549-BDD.vbf	Range Rover Sport (L494)	PSM - Passenger Front Seat Module	EXE
GK62-14C549-BEA.vbf	Range Rover Sport (L494)	PSM - Passenger Front Seat Module	EXE
GK62-14C549-BEB.vbf	Range Rover Sport (L494)	PSM - Passenger Front Seat Module	EXE
GK62-14C549-BEC.vbf	Range Rover Sport (L494)	PSM - Passenger Front Seat Module	EXE
GK62-14C549-BED.vbf	Range Rover Sport (L494)	PSM - Passenger Front Seat Module	EXE
GK62-14C609-AA.vbf	Range Rover Sport (L494)	PSCM - Power Steering Control Module	EXE
GK62-14C609-AB.vbf	Range Rover Sport (L494)	PSCM - Power Steering Control Module	EXE
GK62-14C609-AD.vbf	Range Rover Sport (L494)	PSCM - Power Steering Control Module	EXE
GK62-14C621-AA.vbf	Range Rover Sport (L494)	FCDIM - Front Control/Display Interface Module	EXE
GK62-14C621-AB.vbf	Range Rover Sport (L494)	FCDIM - Front Control/Display Interface Module	EXE
GK62-14D481-BA.vbf	Range Rover Sport (L494)	IPMB - Image Processing Module B	DATA
GK62-14D481-BB.vbf	Range Rover Sport (L494)	IPMB - Image Processing Module B	DATA
GK62-14D485-BA.vbf	Range Rover Sport (L494)	IPMB - Image Processing Module B	DATA
GK62-14D485-BB.vbf	Range Rover Sport (L494)	IPMB - Image Processing Module B	DATA
GK62-14D485-BC.vbf	Range Rover Sport (L494)	IPMB - Image Processing Module B	DATA
GK62-14D564-AB.vbf	Range Rover Sport (L494)	SODL - Side Obstacle Detection Control Module - Left	DATA
GK62-14D564-BB.vbf	Range Rover Sport (L494)	SODR - Side Obstacle Detection Control Module - Right	DATA
GK62-14E094-HAB.vbf	Range Rover Sport (L494)	CHCM - Chassis Control Module	EXE
GK62-14E094-HAC.vbf	Range Rover Sport (L494)	CHCM - Chassis Control Module	EXE
GK62-14E094-HAD.vbf	Range Rover Sport (L494)	CHCM - Chassis Control Module	EXE
GK62-14E094-HAE.vbf	Range Rover Sport (L494)	CHCM - Chassis Control Module	EXE
GK62-14E094-HAF.vbf	Range Rover Sport (L494)	CHCM - Chassis Control Module	EXE
GK62-14E094-HBB.vbf	Range Rover Sport (L494)	CHCM - Chassis Control Module	EXE
GK62-14E094-HBC.vbf	Range Rover Sport (L494)	CHCM - Chassis Control Module	EXE
GK62-14E094-HBD.vbf	Range Rover Sport (L494)	CHCM - Chassis Control Module	EXE
GK62-14E094-HBE.vbf	Range Rover Sport (L494)	CHCM - Chassis Control Module	EXE
GK62-14E094-HBF.vbf	Range Rover Sport (L494)	CHCM - Chassis Control Module	EXE

File name	Vehicle line (indicative)	Module (ECU)	Type
GK62-14E094-HCB.vbf	Range Rover Sport (L494)	CHCM - Chassis Control Module	EXE
GK62-14E094-HCC.vbf	Range Rover Sport (L494)	CHCM - Chassis Control Module	EXE
GK62-14E094-HCD.vbf	Range Rover Sport (L494)	CHCM - Chassis Control Module	EXE
GK62-14E094-HCE.vbf	Range Rover Sport (L494)	CHCM - Chassis Control Module	EXE
GK62-14E094-HCF.vbf	Range Rover Sport (L494)	CHCM - Chassis Control Module	EXE
GK62-14E094-JAB.vbf	Range Rover Sport (L494)	CHCM - Chassis Control Module	EXE
GK62-14E094-JAC.vbf	Range Rover Sport (L494)	CHCM - Chassis Control Module	EXE
GK62-14E094-JAD.vbf	Range Rover Sport (L494)	CHCM - Chassis Control Module	EXE
GK62-14E094-JAE.vbf	Range Rover Sport (L494)	CHCM - Chassis Control Module	EXE
GK62-14E094-JAF.vbf	Range Rover Sport (L494)	CHCM - Chassis Control Module	EXE
GK62-14E094-JBB.vbf	Range Rover Sport (L494)	CHCM - Chassis Control Module	EXE
GK62-14E094-JBC.vbf	Range Rover Sport (L494)	CHCM - Chassis Control Module	EXE
GK62-14E094-JBD.vbf	Range Rover Sport (L494)	CHCM - Chassis Control Module	EXE
GK62-14E094-JBE.vbf	Range Rover Sport (L494)	CHCM - Chassis Control Module	EXE
GK62-14E094-JBF.vbf	Range Rover Sport (L494)	CHCM - Chassis Control Module	EXE
GK62-14E094-JCB.vbf	Range Rover Sport (L494)	CHCM - Chassis Control Module	EXE
GK62-14E094-JCC.vbf	Range Rover Sport (L494)	CHCM - Chassis Control Module	EXE
GK62-14E094-JCD.vbf	Range Rover Sport (L494)	CHCM - Chassis Control Module	EXE
GK62-14E094-JCE.vbf	Range Rover Sport (L494)	CHCM - Chassis Control Module	EXE
GK62-14E094-JCF.vbf	Range Rover Sport (L494)	CHCM - Chassis Control Module	EXE
GK62-14E094-JDB.vbf	Range Rover Sport (L494)	CHCM - Chassis Control Module	EXE
GK62-14E094-JDC.vbf	Range Rover Sport (L494)	CHCM - Chassis Control Module	EXE
GK62-14E094-JDD.vbf	Range Rover Sport (L494)	CHCM - Chassis Control Module	EXE
GK62-14E094-JDE.vbf	Range Rover Sport (L494)	CHCM - Chassis Control Module	EXE
GK62-14E094-JDF.vbf	Range Rover Sport (L494)	CHCM - Chassis Control Module	EXE
GK62-14E094-JDG.vbf	Range Rover Sport (L494)	CHCM - Chassis Control Module	EXE
GK62-14E094-JEB.vbf	Range Rover Sport (L494)	CHCM - Chassis Control Module	EXE
GK62-14E094-JEC.vbf	Range Rover Sport (L494)	CHCM - Chassis Control Module	EXE
GK62-14E094-JED.vbf	Range Rover Sport (L494)	CHCM - Chassis Control Module	EXE
GK62-14E094-JEE.vbf	Range Rover Sport (L494)	CHCM - Chassis Control Module	EXE
GK62-14E094-JEF.vbf	Range Rover Sport (L494)	CHCM - Chassis Control Module	EXE
GK62-14E094-JFB.vbf	Range Rover Sport (L494)	CHCM - Chassis Control Module	EXE
GK62-14E094-JFC.vbf	Range Rover Sport (L494)	CHCM - Chassis Control Module	EXE
GK62-14E094-JFD.vbf	Range Rover Sport (L494)	CHCM - Chassis Control Module	EXE
GK62-14E094-JFE.vbf	Range Rover Sport (L494)	CHCM - Chassis Control Module	EXE
GK62-14E094-JFF.vbf	Range Rover Sport (L494)	CHCM - Chassis Control Module	EXE
GK62-14E094-JGB.vbf	Range Rover Sport (L494)	CHCM - Chassis Control Module	EXE
GK62-14E094-JGC.vbf	Range Rover Sport (L494)	CHCM - Chassis Control Module	EXE
GK62-14E094-JGD.vbf	Range Rover Sport (L494)	CHCM - Chassis Control Module	EXE
GK62-14E094-JGE.vbf	Range Rover Sport (L494)	CHCM - Chassis Control Module	EXE
GK62-14E094-JGF.vbf	Range Rover Sport (L494)	CHCM - Chassis Control Module	EXE
GK62-14E094-JJB.vbf	Range Rover Sport (L494)	CHCM - Chassis Control Module	EXE
GK62-14E094-JJC.vbf	Range Rover Sport (L494)	CHCM - Chassis Control Module	EXE
GK62-14E094-JJD.vbf	Range Rover Sport (L494)	CHCM - Chassis Control Module	EXE
GK62-14E094-JJE.vbf	Range Rover Sport (L494)	CHCM - Chassis Control Module	EXE
GK62-14E094-JJF.vbf	Range Rover Sport (L494)	CHCM - Chassis Control Module	EXE
GK62-14F022-EA.vbf	Range Rover Sport (L494)	IPMB - Image Processing Module B	DATA
GK62-14F022-EB.vbf	Range Rover Sport (L494)	IPMB - Image Processing Module B	DATA
GK62-14F022-EC.vbf	Range Rover Sport (L494)	IPMB - Image Processing Module B	DATA
GK62-14F022-EE.vbf	Range Rover Sport (L494)	IPMB - Image Processing Module B	DATA
GK62-14F435-NAB.vbf	Range Rover Sport (L494)	CHCMB - Chassis Control Module B	EXE
GK62-14F435-NAC.vbf	Range Rover Sport (L494)	CHCMB - Chassis Control Module B	EXE
GK62-14F435-NAD.vbf	Range Rover Sport (L494)	CHCMB - Chassis Control Module B	EXE
GK62-14F435-NBB.vbf	Range Rover Sport (L494)	CHCMB - Chassis Control Module B	EXE
GK62-14F435-NBC.vbf	Range Rover Sport (L494)	CHCMB - Chassis Control Module B	EXE
GK62-14F435-NBD.vbf	Range Rover Sport (L494)	CHCMB - Chassis Control Module B	EXE
GK62-14F435-NCB.vbf	Range Rover Sport (L494)	CHCMB - Chassis Control Module B	EXE
GK62-14F435-NCC.vbf	Range Rover Sport (L494)	CHCMB - Chassis Control Module B	EXE
GK62-14F435-NCD.vbf	Range Rover Sport (L494)	CHCMB - Chassis Control Module B	EXE
GK62-7J104-BBA.vbf	Range Rover Sport (L494)	TCM - Transmission Control Module	EXE
GK62-7J104-BBB.vbf	Range Rover Sport (L494)	TCM - Transmission Control Module	EXE
GK62-7J104-BBC.vbf	Range Rover Sport (L494)	TCM - Transmission Control Module	EXE
GK62-7J104-BBD.vbf	Range Rover Sport (L494)	TCM - Transmission Control Module	EXE
GK62-7J104-BBE.vbf	Range Rover Sport (L494)	TCM - Transmission Control Module	EXE
GK62-7J104-BCA.vbf	Range Rover Sport (L494)	TCM - Transmission Control Module	EXE
GK62-7J104-BCB.vbf	Range Rover Sport (L494)	TCM - Transmission Control Module	EXE
GK62-7J104-BCC.vbf	Range Rover Sport (L494)	TCM - Transmission Control Module	EXE
GK62-7J104-BCD.vbf	Range Rover Sport (L494)	TCM - Transmission Control Module	EXE
GK62-7J104-BCE.vbf	Range Rover Sport (L494)	TCM - Transmission Control Module	EXE
GK62-7J104-BCF.vbf	Range Rover Sport (L494)	TCM - Transmission Control Module	EXE
GK62-7J104-BGA.vbf	Range Rover Sport (L494)	TCM - Transmission Control Module	EXE
GK62-7J104-BGB.vbf	Range Rover Sport (L494)	TCM - Transmission Control Module	EXE
GK62-7J104-BGC.vbf	Range Rover Sport (L494)	TCM - Transmission Control Module	EXE
GK62-7J104-BGD.vbf	Range Rover Sport (L494)	TCM - Transmission Control Module	EXE
GK62-7J104-BGE.vbf	Range Rover Sport (L494)	TCM - Transmission Control Module	EXE
GK62-7J104-BGF.vbf	Range Rover Sport (L494)	TCM - Transmission Control Module	EXE

File name	Vehicle line (indicative)	Module (ECU)	Type
GK62-7J104-BHA.vbf	Range Rover Sport (L494)	TCM - Transmission Control Module	EXE
GK62-7J104-BHB.vbf	Range Rover Sport (L494)	TCM - Transmission Control Module	EXE
GK62-7J104-BHC.vbf	Range Rover Sport (L494)	TCM - Transmission Control Module	EXE
GK62-7J104-BHD.vbf	Range Rover Sport (L494)	TCM - Transmission Control Module	EXE
GK62-7J104-BKA.vbf	Range Rover Sport (L494)	TCM - Transmission Control Module	EXE
GK62-7J104-BKB.vbf	Range Rover Sport (L494)	TCM - Transmission Control Module	EXE
GK62-7J104-BKD.vbf	Range Rover Sport (L494)	TCM - Transmission Control Module	EXE
GK62-7J104-BLA.vbf	Range Rover Sport (L494)	TCM - Transmission Control Module	EXE
GK62-7J104-BLB.vbf	Range Rover Sport (L494)	TCM - Transmission Control Module	EXE
GK62-7J104-BLC.vbf	Range Rover Sport (L494)	TCM - Transmission Control Module	EXE
GK62-7J104-BLD.vbf	Range Rover Sport (L494)	TCM - Transmission Control Module	EXE
GK62-7J104-BLE.vbf	Range Rover Sport (L494)	TCM - Transmission Control Module	EXE
GK62-7J104-BLF.vbf	Range Rover Sport (L494)	TCM - Transmission Control Module	EXE
GK62-7J104-BMA.vbf	Range Rover Sport (L494)	TCM - Transmission Control Module	EXE
GK62-7J104-BMB.vbf	Range Rover Sport (L494)	TCM - Transmission Control Module	EXE
GK62-7J104-BMC.vbf	Range Rover Sport (L494)	TCM - Transmission Control Module	EXE
GK62-7J104-BMD.vbf	Range Rover Sport (L494)	TCM - Transmission Control Module	EXE
GK62-7J104-BME.vbf	Range Rover Sport (L494)	TCM - Transmission Control Module	EXE
GK6M-14C034-AAA.vbf	Range Rover Sport (L494)	DSM - Driver Front Seat Module	EXE
GK6M-14C034-AAB.vbf	Range Rover Sport (L494)	DSM - Driver Front Seat Module	EXE
GK6M-14C034-AAC.vbf	Range Rover Sport (L494)	DSM - Driver Front Seat Module	EXE
GK6M-14C218-AB.vbf	Range Rover Sport (L494)	PSCM - Power Steering Control Module	EXE
GK6M-14C549-AAA.vbf	Range Rover Sport (L494)	PSM - Passenger Front Seat Module	EXE
GK6M-14C549-AAB.vbf	Range Rover Sport (L494)	PSM - Passenger Front Seat Module	EXE
GK6M-14C549-AAC.vbf	Range Rover Sport (L494)	PSM - Passenger Front Seat Module	EXE
GK6M-14D024-AA.vbf	Range Rover Sport (L494)	ATCM - All Terrain Control Module	EXE
GK6M-14E094-JHB.vbf	Range Rover Sport (L494)	CHCM - Chassis Control Module	EXE
GK6M-14E094-JHC.vbf	Range Rover Sport (L494)	CHCM - Chassis Control Module	EXE
GK6M-14E094-JHD.vbf	Range Rover Sport (L494)	CHCM - Chassis Control Module	EXE
GK6M-14E094-JHE.vbf	Range Rover Sport (L494)	CHCM - Chassis Control Module	EXE
GK6M-14E094-JHF.vbf	Range Rover Sport (L494)	CHCM - Chassis Control Module	EXE
GK6M-14E094-JHG.vbf	Range Rover Sport (L494)	CHCM - Chassis Control Module	EXE
GK6M-14F435-NEB.vbf	Range Rover Sport (L494)	CHCMB - Chassis Control Module B	EXE
GK6M-14F435-NEC.vbf	Range Rover Sport (L494)	CHCMB - Chassis Control Module B	EXE
GK6M-14F435-NED.vbf	Range Rover Sport (L494)	CHCMB - Chassis Control Module B	EXE
GK72-12K532-FBA.vbf	Discovery Sport (L550)	PCM - Powertrain Control Module	DATA
GK72-12K532-FBB.vbf	Discovery Sport (L550)	PCM - Powertrain Control Module	DATA
GK72-12K532-FBC.vbf	Discovery Sport (L550)	PCM - Powertrain Control Module	DATA
GK72-12K532-FBD.vbf	Discovery Sport (L550)	PCM - Powertrain Control Module	DATA
GK72-12K532-FBE.vbf	Discovery Sport (L550)	PCM - Powertrain Control Module	DATA
GK72-12K532-FBF.vbf	Discovery Sport (L550)	PCM - Powertrain Control Module	DATA
GK72-12K532-FBG.vbf	Discovery Sport (L550)	PCM - Powertrain Control Module	DATA
GK72-12K532-FBH.vbf	Discovery Sport (L550)	PCM - Powertrain Control Module	DATA
GK72-12K532-FBJ.vbf	Discovery Sport (L550)	PCM - Powertrain Control Module	DATA
GK72-12K532-FBK.vbf	Discovery Sport (L550)	PCM - Powertrain Control Module	DATA
GK72-12K532-FBL.vbf	Discovery Sport (L550)	PCM - Powertrain Control Module	DATA
GK72-12K532-FSA.vbf	Discovery Sport (L550)	PCM - Powertrain Control Module	DATA
GK72-12K532-FTA.vbf	Discovery Sport (L550)	PCM - Powertrain Control Module	DATA
GK72-12K532-FUA.vbf	Discovery Sport (L550)	PCM - Powertrain Control Module	DATA
GK72-12K532-FVA.vbf	Discovery Sport (L550)	PCM - Powertrain Control Module	DATA
GK72-12K532-FXA.vbf	Discovery Sport (L550)	PCM - Powertrain Control Module	DATA
GK72-12K532-GAA.vbf	Discovery Sport (L550)	PCM - Powertrain Control Module	DATA
GK72-12K532-GAB.vbf	Discovery Sport (L550)	PCM - Powertrain Control Module	DATA
GK72-12K532-GAC.vbf	Discovery Sport (L550)	PCM - Powertrain Control Module	DATA
GK72-12K532-GAD.vbf	Discovery Sport (L550)	PCM - Powertrain Control Module	DATA
GK72-12K532-GAE.vbf	Discovery Sport (L550)	PCM - Powertrain Control Module	DATA
GK72-12K532-GAF.vbf	Discovery Sport (L550)	PCM - Powertrain Control Module	DATA
GK72-12K532-GAG.vbf	Discovery Sport (L550)	PCM - Powertrain Control Module	DATA
GK72-12K532-GAH.vbf	Discovery Sport (L550)	PCM - Powertrain Control Module	DATA
GK72-12K532-GAJ.vbf	Discovery Sport (L550)	PCM - Powertrain Control Module	DATA
GK72-12K532-GAK.vbf	Discovery Sport (L550)	PCM - Powertrain Control Module	DATA
GK72-12K532-GAL.vbf	Discovery Sport (L550)	PCM - Powertrain Control Module	DATA
GK72-12K532-GBB.vbf	Discovery Sport (L550)	PCM - Powertrain Control Module	DATA
GK72-12K532-GBC.vbf	Discovery Sport (L550)	PCM - Powertrain Control Module	DATA
GK72-12K532-GBD.vbf	Discovery Sport (L550)	PCM - Powertrain Control Module	DATA
GK72-12K532-GBE.vbf	Discovery Sport (L550)	PCM - Powertrain Control Module	DATA
GK72-12K532-GBF.vbf	Discovery Sport (L550)	PCM - Powertrain Control Module	DATA
GK72-12K532-GBG.vbf	Discovery Sport (L550)	PCM - Powertrain Control Module	DATA
GK72-12K532-GBH.vbf	Discovery Sport (L550)	PCM - Powertrain Control Module	DATA
GK72-12K532-GBJ.vbf	Discovery Sport (L550)	PCM - Powertrain Control Module	DATA
GK72-12K532-GBK.vbf	Discovery Sport (L550)	PCM - Powertrain Control Module	DATA
GK72-12K532-GBL.vbf	Discovery Sport (L550)	PCM - Powertrain Control Module	DATA
GK72-12K532-GCA.vbf	Discovery Sport (L550)	PCM - Powertrain Control Module	DATA
GK72-12K532-GCB.vbf	Discovery Sport (L550)	PCM - Powertrain Control Module	DATA
GK72-12K532-GCD.vbf	Discovery Sport (L550)	PCM - Powertrain Control Module	DATA
GK72-12K532-GCE.vbf	Discovery Sport (L550)	PCM - Powertrain Control Module	DATA

File name	Vehicle line (indicative)	Module (ECU)	Type
GK72-12K532-GCF.vbf	Discovery Sport (L550)	PCM - Powertrain Control Module	DATA
GK72-12K532-GCG.vbf	Discovery Sport (L550)	PCM - Powertrain Control Module	DATA
GK72-12K532-GCH.vbf	Discovery Sport (L550)	PCM - Powertrain Control Module	DATA
GK72-12K532-GCJ.vbf	Discovery Sport (L550)	PCM - Powertrain Control Module	DATA
GK72-12K532-GCK.vbf	Discovery Sport (L550)	PCM - Powertrain Control Module	DATA
GK72-12K532-GCL.vbf	Discovery Sport (L550)	PCM - Powertrain Control Module	DATA
GK72-12K532-GDA.vbf	Discovery Sport (L550)	PCM - Powertrain Control Module	DATA
GK72-12K532-GDB.vbf	Discovery Sport (L550)	PCM - Powertrain Control Module	DATA
GK72-12K532-GDD.vbf	Discovery Sport (L550)	PCM - Powertrain Control Module	DATA
GK72-12K532-GDE.vbf	Discovery Sport (L550)	PCM - Powertrain Control Module	DATA
GK72-12K532-GDF.vbf	Discovery Sport (L550)	PCM - Powertrain Control Module	DATA
GK72-12K532-GDG.vbf	Discovery Sport (L550)	PCM - Powertrain Control Module	DATA
GK72-12K532-GDH.vbf	Discovery Sport (L550)	PCM - Powertrain Control Module	DATA
GK72-12K532-GDJ.vbf	Discovery Sport (L550)	PCM - Powertrain Control Module	DATA
GK72-12K532-GDK.vbf	Discovery Sport (L550)	PCM - Powertrain Control Module	DATA
GK72-12K532-GDL.vbf	Discovery Sport (L550)	PCM - Powertrain Control Module	DATA
GK72-12K532-GEB.vbf	Discovery Sport (L550)	PCM - Powertrain Control Module	DATA
GK72-12K532-GEC.vbf	Discovery Sport (L550)	PCM - Powertrain Control Module	DATA
GK72-12K532-GED.vbf	Discovery Sport (L550)	PCM - Powertrain Control Module	DATA
GK72-12K532-GEE.vbf	Discovery Sport (L550)	PCM - Powertrain Control Module	DATA
GK72-12K532-GFB.vbf	Discovery Sport (L550)	PCM - Powertrain Control Module	DATA
GK72-12K532-GLB.vbf	Discovery Sport (L550)	PCM - Powertrain Control Module	DATA
GK72-12K532-GLC.vbf	Discovery Sport (L550)	PCM - Powertrain Control Module	DATA
GK72-12K532-GLD.vbf	Discovery Sport (L550)	PCM - Powertrain Control Module	DATA
GK72-12K532-GLE.vbf	Discovery Sport (L550)	PCM - Powertrain Control Module	DATA
GK72-12K532-GLF.vbf	Discovery Sport (L550)	PCM - Powertrain Control Module	DATA
GK72-12K532-GLG.vbf	Discovery Sport (L550)	PCM - Powertrain Control Module	DATA
GK72-12K532-GLH.vbf	Discovery Sport (L550)	PCM - Powertrain Control Module	DATA
GK72-12K532-GLJ.vbf	Discovery Sport (L550)	PCM - Powertrain Control Module	DATA
GK72-12K532-GLK.vbf	Discovery Sport (L550)	PCM - Powertrain Control Module	DATA
GK72-12K532-GLL.vbf	Discovery Sport (L550)	PCM - Powertrain Control Module	DATA
GK72-12K532-GNA.vbf	Discovery Sport (L550)	PCM - Powertrain Control Module	DATA
GK72-12K532-GNB.vbf	Discovery Sport (L550)	PCM - Powertrain Control Module	DATA
GK72-12K532-GNC.vbf	Discovery Sport (L550)	PCM - Powertrain Control Module	DATA
GK72-12K532-GND.vbf	Discovery Sport (L550)	PCM - Powertrain Control Module	DATA
GK72-12K532-GNE.vbf	Discovery Sport (L550)	PCM - Powertrain Control Module	DATA
GK72-12K532-GNF.vbf	Discovery Sport (L550)	PCM - Powertrain Control Module	DATA
GK72-12K532-GNG.vbf	Discovery Sport (L550)	PCM - Powertrain Control Module	DATA
GK72-12K532-GNH.vbf	Discovery Sport (L550)	PCM - Powertrain Control Module	DATA
GK72-12K532-GNJ.vbf	Discovery Sport (L550)	PCM - Powertrain Control Module	DATA
GK72-12K532-GNK.vbf	Discovery Sport (L550)	PCM - Powertrain Control Module	DATA
GK72-12K532-GPA.vbf	Discovery Sport (L550)	PCM - Powertrain Control Module	DATA
GK72-12K532-GPB.vbf	Discovery Sport (L550)	PCM - Powertrain Control Module	DATA
GK72-12K532-GPC.vbf	Discovery Sport (L550)	PCM - Powertrain Control Module	DATA
GK72-12K532-GPD.vbf	Discovery Sport (L550)	PCM - Powertrain Control Module	DATA
GK72-12K532-GTA.vbf	Discovery Sport (L550)	PCM - Powertrain Control Module	DATA
GK72-12K532-GTB.vbf	Discovery Sport (L550)	PCM - Powertrain Control Module	DATA
GK72-12K532-GTC.vbf	Discovery Sport (L550)	PCM - Powertrain Control Module	DATA
GK72-12K532-GTD.vbf	Discovery Sport (L550)	PCM - Powertrain Control Module	DATA
GK72-12K532-GTE.vbf	Discovery Sport (L550)	PCM - Powertrain Control Module	DATA
GK72-12K532-GTF.vbf	Discovery Sport (L550)	PCM - Powertrain Control Module	DATA
GK72-12K532-GTG.vbf	Discovery Sport (L550)	PCM - Powertrain Control Module	DATA
GK72-12K532-GTH.vbf	Discovery Sport (L550)	PCM - Powertrain Control Module	DATA
GK72-12K532-GTJ.vbf	Discovery Sport (L550)	PCM - Powertrain Control Module	DATA
GK72-12K532-GTK.vbf	Discovery Sport (L550)	PCM - Powertrain Control Module	DATA
GK72-12K532-GTL.vbf	Discovery Sport (L550)	PCM - Powertrain Control Module	DATA
GK72-14C026-AA.vbf	Discovery Sport (L550)	IPC - Instrument Panel Cluster (IPC) Control Module	EXE
GK72-14C026-AB.vbf	Discovery Sport (L550)	IPC - Instrument Panel Cluster (IPC) Control Module	EXE
GK72-14C026-AC.vbf	Discovery Sport (L550)	IPC - Instrument Panel Cluster (IPC) Control Module	EXE
GK72-14C026-AD.vbf	Discovery Sport (L550)	IPC - Instrument Panel Cluster (IPC) Control Module	EXE
GK72-14C026-AE.vbf	Discovery Sport (L550)	IPC - Instrument Panel Cluster (IPC) Control Module	EXE
GK72-14C034-AB.vbf	Discovery Sport (L550)	DSM - Driver Front Seat Module	EXE
GK72-14C034-AC.vbf	Discovery Sport (L550)	DSM - Driver Front Seat Module	EXE
GK72-14C034-AD.vbf	Discovery Sport (L550)	DSM - Driver Front Seat Module	EXE
GK72-14C060-AC.vbf	Discovery Sport (L550)	FCDIM - Front Control/Display Interface Module	EXE
GK72-14C060-AD.vbf	Discovery Sport (L550)	FCDIM - Front Control/Display Interface Module	EXE
GK72-14C060-AE.vbf	Discovery Sport (L550)	FCDIM - Front Control/Display Interface Module	EXE
GK72-14C060-AF.vbf	Discovery Sport (L550)	FCDIM - Front Control/Display Interface Module	EXE
GK72-14C060-AG.vbf	Discovery Sport (L550)	FCDIM - Front Control/Display Interface Module	EXE
GK72-14C060-BC.vbf	Discovery Sport (L550)	FCDIM - Front Control/Display Interface Module	EXE
GK72-14C060-BD.vbf	Discovery Sport (L550)	FCDIM - Front Control/Display Interface Module	EXE
GK72-14C060-BE.vbf	Discovery Sport (L550)	FCDIM - Front Control/Display Interface Module	EXE
GK72-14C060-BF.vbf	Discovery Sport (L550)	FCDIM - Front Control/Display Interface Module	EXE
GK72-14C060-BG.vbf	Discovery Sport (L550)	FCDIM - Front Control/Display Interface Module	EXE
GK72-14C061-AA.vbf	Discovery Sport (L550)	FCDIM - Front Control/Display Interface Module	DATA
GK72-14C061-AB.vbf	Discovery Sport (L550)	FCDIM - Front Control/Display Interface Module	DATA

File name	Vehicle line (indicative)	Module (ECU)	Type
GK72-14C061-AC.vbf	Discovery Sport (L550)	FCDIM - Front Control/Display Interface Module	DATA
GK72-14C061-AD.vbf	Discovery Sport (L550)	FCDIM - Front Control/Display Interface Module	DATA
GK72-14C061-AE.vbf	Discovery Sport (L550)	FCDIM - Front Control/Display Interface Module	DATA
GK72-14C061-AF.vbf	Discovery Sport (L550)	FCDIM - Front Control/Display Interface Module	DATA
GK72-14C061-AG.vbf	Discovery Sport (L550)	FCDIM - Front Control/Display Interface Module	DATA
GK72-14C063-AA.vbf	Discovery Sport (L550)	FCDIM - Front Control/Display Interface Module	SBL
GK72-14C088-CA.vbf	Discovery Sport (L550)	IPC - Instrument Panel Cluster (IPC) Control Module	EXE
GK72-14C088-CB.vbf	Discovery Sport (L550)	IPC - Instrument Panel Cluster (IPC) Control Module	EXE
GK72-14C088-CC.vbf	Discovery Sport (L550)	IPC - Instrument Panel Cluster (IPC) Control Module	EXE
GK72-14C088-CD.vbf	Discovery Sport (L550)	IPC - Instrument Panel Cluster (IPC) Control Module	EXE
GK72-14C088-YA.vbf	Discovery Sport (L550)	IPC - Instrument Panel Cluster (IPC) Control Module	CARCFG
GK72-14C104-SB.vbf	Discovery Sport (L550)	TMC Traffic Message Channel Module	EXE
GK72-14C105-AA.VBF	Discovery Sport (L550)	TMC Traffic Message Channel Module	DATA
GK72-14C105-AB.vbf	Discovery Sport (L550)	TMC Traffic Message Channel Module	DATA
GK72-14C105-AC.vbf	Discovery Sport (L550)	TMC Traffic Message Channel Module	DATA
GK72-14C105-BA.VBF	Discovery Sport (L550)	TMC Traffic Message Channel Module	DATA
GK72-14C105-BB.vbf	Discovery Sport (L550)	TMC Traffic Message Channel Module	DATA
GK72-14C105-BC.vbf	Discovery Sport (L550)	TMC Traffic Message Channel Module	DATA
GK72-14C185-AA.VBF	Discovery Sport (L550)	BCM - Body Control Module	DATA
GK72-14C185-AC.VBF	Discovery Sport (L550)	BCM - Body Control Module	DATA
GK72-14C185-AD.vbf	Discovery Sport (L550)	BCM - Body Control Module	DATA
GK72-14C204-MAA.vbf	Discovery Sport (L550)	PCM - Powertrain Control Module	EXE
GK72-14C204-MAB.vbf	Discovery Sport (L550)	PCM - Powertrain Control Module	EXE
GK72-14C204-MAC.vbf	Discovery Sport (L550)	PCM - Powertrain Control Module	EXE
GK72-14C204-MAD.vbf	Discovery Sport (L550)	PCM - Powertrain Control Module	EXE
GK72-14C204-MBA.vbf	Discovery Sport (L550)	PCM - Powertrain Control Module	EXE
GK72-14C204-MBB.vbf	Discovery Sport (L550)	PCM - Powertrain Control Module	EXE
GK72-14C204-MBC.vbf	Discovery Sport (L550)	PCM - Powertrain Control Module	EXE
GK72-14C204-MBE.vbf	Discovery Sport (L550)	PCM - Powertrain Control Module	EXE
GK72-14C204-MCA.vbf	Discovery Sport (L550)	PCM - Powertrain Control Module	EXE
GK72-14C204-MCB.vbf	Discovery Sport (L550)	PCM - Powertrain Control Module	EXE
GK72-14C204-MCC.vbf	Discovery Sport (L550)	PCM - Powertrain Control Module	EXE
GK72-14C204-MCE.vbf	Discovery Sport (L550)	PCM - Powertrain Control Module	EXE
GK72-14C204-MEA.vbf	Discovery Sport (L550)	PCM - Powertrain Control Module	EXE
GK72-14C204-MEB.vbf	Discovery Sport (L550)	PCM - Powertrain Control Module	EXE
GK72-14C204-MEC.vbf	Discovery Sport (L550)	PCM - Powertrain Control Module	EXE
GK72-14C204-MEE.vbf	Discovery Sport (L550)	PCM - Powertrain Control Module	EXE
GK72-14C204-MKA.vbf	Discovery Sport (L550)	PCM - Powertrain Control Module	EXE
GK72-14C204-MKB.vbf	Discovery Sport (L550)	PCM - Powertrain Control Module	EXE
GK72-14C204-MKC.vbf	Discovery Sport (L550)	PCM - Powertrain Control Module	EXE
GK72-14C204-MKE.vbf	Discovery Sport (L550)	PCM - Powertrain Control Module	EXE
GK72-14C204-MNB.vbf	Discovery Sport (L550)	PCM - Powertrain Control Module	EXE
GK72-14C204-MNC.vbf	Discovery Sport (L550)	PCM - Powertrain Control Module	EXE
GK72-14C204-MNE.vbf	Discovery Sport (L550)	PCM - Powertrain Control Module	EXE
GK72-14C204-MXA.vbf	Discovery Sport (L550)	PCM - Powertrain Control Module	EXE
GK72-14C204-MXB.vbf	Discovery Sport (L550)	PCM - Powertrain Control Module	EXE
GK72-14C204-MXC.vbf	Discovery Sport (L550)	PCM - Powertrain Control Module	EXE
GK72-14C204-MXD.vbf	Discovery Sport (L550)	ECM - Engine Control Module	EXE
GK72-14C204-MYA.vbf	Discovery Sport (L550)	PCM - Powertrain Control Module	EXE
GK72-14C204-MYB.vbf	Discovery Sport (L550)	PCM - Powertrain Control Module	EXE
GK72-14C204-MYC.vbf	Discovery Sport (L550)	PCM - Powertrain Control Module	EXE
GK72-14C204-MYD.vbf	Discovery Sport (L550)	ECM - Engine Control Module	EXE
GK72-14C204-MZA.vbf	Discovery Sport (L550)	PCM - Powertrain Control Module	EXE
GK72-14C204-MZB.vbf	Discovery Sport (L550)	PCM - Powertrain Control Module	EXE
GK72-14C204-MZC.vbf	Discovery Sport (L550)	PCM - Powertrain Control Module	EXE
GK72-14C204-MZD.vbf	Discovery Sport (L550)	PCM - Powertrain Control Module	EXE
GK72-14C337-CAA.vbf	Discovery Sport (L550)	TCM - Transmission Control Module	EXE
GK72-14C337-CAB.vbf	Discovery Sport (L550)	TCM - Transmission Control Module	EXE
GK72-14C337-CAC.vbf	Discovery Sport (L550)	TCM - Transmission Control Module	EXE
GK72-14C337-CAD.vbf	Discovery Sport (L550)	TCM - Transmission Control Module	EXE
GK72-14C337-CBA.vbf	Discovery Sport (L550)	TCM - Transmission Control Module	EXE
GK72-14C337-CBB.vbf	Discovery Sport (L550)	TCM - Transmission Control Module	EXE
GK72-14C337-CBC.vbf	Discovery Sport (L550)	TCM - Transmission Control Module	EXE
GK72-14C337-CBD.vbf	Discovery Sport (L550)	TCM - Transmission Control Module	EXE
GK72-14C337-CLA.vbf	Discovery Sport (L550)	TCM - Transmission Control Module	EXE
GK72-14C337-CLB.vbf	Discovery Sport (L550)	TCM - Transmission Control Module	EXE
GK72-14C337-CLC.vbf	Discovery Sport (L550)	TCM - Transmission Control Module	EXE
GK72-14C337-CLD.vbf	Discovery Sport (L550)	TCM - Transmission Control Module	EXE
GK72-14C337-CLH.vbf	Discovery Sport (L550)	TCM - Transmission Control Module	EXE
GK72-14C337-CLJ.vbf	Discovery Sport (L550)	TCM - Transmission Control Module	EXE
GK72-14C527-AA.vbf	Discovery Sport (L550)	Not specified	DATA
GK72-14C535-AA.vbf	Discovery Sport (L550)	HVAC - HVAC Control Module	EXE
GK72-14C535-AC.vbf	Discovery Sport (L550)	HVAC - HVAC Control Module	EXE
GK72-14C535-AD.vbf	Discovery Sport (L550)	HVAC - HVAC Control Module	EXE
GK72-14C535-AF.vbf	Discovery Sport (L550)	HVAC - HVAC Control Module	EXE
GK72-14C535-AG.vbf	Discovery Sport (L550)	HVAC - HVAC Control Module	EXE

File name	Vehicle line (indicative)	Module (ECU)	Type
GK72-14C535-AH.vbf	Discovery Sport (L550)	HVAC - HVAC Control Module	EXE
GK72-14C535-AJ.vbf	Discovery Sport (L550)	HVAC - HVAC Control Module	EXE
GK72-14C535-AK.vbf	Discovery Sport (L550)	HVAC - HVAC Control Module	EXE
GK72-14C535-AL.vbf	Discovery Sport (L550)	HVAC - HVAC Control Module	EXE
GK72-14C535-AM.vbf	Discovery Sport (L550)	HVAC - HVAC Control Module	EXE
GK72-14C535-AP.vbf	Discovery Sport (L550)	HVAC - HVAC Control Module	EXE
GK72-14C536-AA.vbf	Discovery Sport (L550)	HVAC - HVAC Control Module	DATA
GK72-14C536-AC.vbf	Discovery Sport (L550)	HVAC - HVAC Control Module	DATA
GK72-14C536-AD.vbf	Discovery Sport (L550)	HVAC - HVAC Control Module	DATA
GK72-14C536-AE.vbf	Discovery Sport (L550)	HVAC - HVAC Control Module	DATA
GK72-14C536-AG.vbf	Discovery Sport (L550)	HVAC - HVAC Control Module	DATA
GK72-14C536-AH.vbf	Discovery Sport (L550)	HVAC - HVAC Control Module	DATA
GK72-14C536-AK.vbf	Discovery Sport (L550)	HVAC - HVAC Control Module	DATA
GK72-14C536-AL.vbf	Discovery Sport (L550)	HVAC - HVAC Control Module	DATA
GK72-14C536-AM.vbf	Discovery Sport (L550)	HVAC - HVAC Control Module	DATA
GK72-14C536-AN.vbf	Discovery Sport (L550)	HVAC - HVAC Control Module	DATA
GK72-14C536-AP.vbf	Discovery Sport (L550)	HVAC - HVAC Control Module	DATA
GK72-14C536-AR.vbf	Discovery Sport (L550)	HVAC - HVAC Control Module	DATA
GK72-14C536-AT.vbf	Discovery Sport (L550)	HVAC - HVAC Control Module	DATA
GK72-14C536-BA.vbf	Discovery Sport (L550)	HVAC - HVAC Control Module	DATA
GK72-14C536-BC.vbf	Discovery Sport (L550)	HVAC - HVAC Control Module	DATA
GK72-14C536-BD.vbf	Discovery Sport (L550)	HVAC - HVAC Control Module	DATA
GK72-14C536-BE.vbf	Discovery Sport (L550)	HVAC - HVAC Control Module	DATA
GK72-14C536-BG.vbf	Discovery Sport (L550)	HVAC - HVAC Control Module	DATA
GK72-14C536-BH.vbf	Discovery Sport (L550)	HVAC - HVAC Control Module	DATA
GK72-14C536-BJ.vbf	Discovery Sport (L550)	HVAC - HVAC Control Module	DATA
GK72-14C536-BK.vbf	Discovery Sport (L550)	HVAC - HVAC Control Module	DATA
GK72-14C536-BL.vbf	Discovery Sport (L550)	HVAC - HVAC Control Module	DATA
GK72-14C536-BM.vbf	Discovery Sport (L550)	HVAC - HVAC Control Module	DATA
GK72-14C536-BN.vbf	Discovery Sport (L550)	HVAC - HVAC Control Module	DATA
GK72-14C536-BP.vbf	Discovery Sport (L550)	HVAC - HVAC Control Module	DATA
GK72-14C536-BR.vbf	Discovery Sport (L550)	HVAC - HVAC Control Module	DATA
GK72-14C536-BT.vbf	Discovery Sport (L550)	HVAC - HVAC Control Module	DATA
GK72-14C543-AB.vbf	Discovery Sport (L550)	SUMB - Suspension Control Module B	DATA
GK72-14C543-AC.vbf	Discovery Sport (L550)	SUMB - Suspension Control Module B	DATA
GK72-14C543-AD.vbf	Discovery Sport (L550)	SUMB - Suspension Control Module B	DATA
GK72-14C549-AB.vbf	Discovery Sport (L550)	PSM - Passenger Front Seat Module	EXE
GK72-14C549-AC.vbf	Discovery Sport (L550)	PSM - Passenger Front Seat Module	EXE
GK72-14C549-AD.vbf	Discovery Sport (L550)	PSM - Passenger Front Seat Module	EXE
GK72-14C621-AA.vbf	Discovery Sport (L550)	FCDIM - Front Control/Display Interface Module	EXE
GK72-14C621-AB.vbf	Discovery Sport (L550)	FCDIM - Front Control/Display Interface Module	EXE
GK72-14D480-BA.vbf	Discovery Sport (L550)	IPMB - Image Processing Module B	EXE
GK72-14D480-CA.vbf	Discovery Sport (L550)	IPMB - Image Processing Module B	EXE
GK72-14F530-BA.vbf	Discovery Sport (L550)	GWM - Gateway Module A	EXE
GK72-14F530-BB.vbf	Discovery Sport (L550)	GWM - Gateway Module A	EXE
GK72-14F531-BA.vbf	Discovery Sport (L550)	GWM - Gateway Module A	DATA
GK72-14F531-BB.vbf	Discovery Sport (L550)	GWM - Gateway Module A	DATA
GK72-70713-BA.vbf	Discovery Sport (L550)	TCU - Telematic Control Unit Module	DATA
GK72-70713-BB.vbf	Discovery Sport (L550)	TCU - Telematic Control Unit Module	DATA
GK72-70713-BC.vbf	Discovery Sport (L550)	TCU - Telematic Control Unit Module	DATA
GK72-70713-CA.vbf	Discovery Sport (L550)	TCU - Telematic Control Unit Module	DATA
GK72-70713-CB.vbf	Discovery Sport (L550)	TCU - Telematic Control Unit Module	DATA
GK72-70713-CC.vbf	Discovery Sport (L550)	TCU - Telematic Control Unit Module	DATA
GK72-70713-MA.vbf	Discovery Sport (L550)	TCU - Telematic Control Unit Module	DATA
GK72-70713-MB.vbf	Discovery Sport (L550)	TCU - Telematic Control Unit Module	DATA
GK72-70713-MC.vbf	Discovery Sport (L550)	TCU - Telematic Control Unit Module	DATA
GK72-70713-NA.vbf	Discovery Sport (L550)	TCU - Telematic Control Unit Module	DATA
GK72-70713-NB.vbf	Discovery Sport (L550)	TCU - Telematic Control Unit Module	DATA
GK72-70713-NC.vbf	Discovery Sport (L550)	TCU - Telematic Control Unit Module	DATA
GPLA-12K532-HBA.vbf	Multiple models (shared module)	PCM - Powertrain Control Module	DATA
GPLA-12K532-HBC.vbf	Multiple models (shared module)	PCM - Powertrain Control Module	DATA
GPLA-12K532-HBD.vbf	Multiple models (shared module)	PCM - Powertrain Control Module	DATA
GPLA-12K532-HBE.vbf	Multiple models (shared module)	PCM - Powertrain Control Module	DATA
GPLA-12K532-HBF.vbf	Multiple models (shared module)	PCM - Powertrain Control Module	DATA
GPLA-12K532-HBG.vbf	Multiple models (shared module)	PCM - Powertrain Control Module	DATA
GPLA-12K532-HBH.vbf	Multiple models (shared module)	PCM - Powertrain Control Module	DATA
GPLA-12K532-HBJ.vbf	Multiple models (shared module)	PCM - Powertrain Control Module	DATA
GPLA-12K532-HBK.vbf	Multiple models (shared module)	PCM - Powertrain Control Module	DATA
GPLA-12K532-HFE.vbf	Multiple models (shared module)	PCM - Powertrain Control Module	DATA
GPLA-12K532-HFF.vbf	Multiple models (shared module)	PCM - Powertrain Control Module	DATA
GPLA-12K532-HFG.vbf	Multiple models (shared module)	PCM - Powertrain Control Module	DATA
GPLA-12K532-HFH.vbf	Multiple models (shared module)	PCM - Powertrain Control Module	DATA
GPLA-12K532-NAC.vbf	Multiple models (shared module)	PCM - Powertrain Control Module	DATA
GPLA-12K532-NAD.vbf	Multiple models (shared module)	PCM - Powertrain Control Module	DATA
GPLA-12K532-NAE.vbf	Multiple models (shared module)	PCM - Powertrain Control Module	DATA
GPLA-12K532-NBA.vbf	Multiple models (shared module)	PCM - Powertrain Control Module	DATA

File name	Vehicle line (indicative)	Module (ECU)	Type
GPLA-12K532-NBB.vbf	Multiple models (shared module)	PCM - Powertrain Control Module	DATA
GPLA-12K532-NBC.vbf	Multiple models (shared module)	PCM - Powertrain Control Module	DATA
GPLA-12K532-NBD.vbf	Multiple models (shared module)	PCM - Powertrain Control Module	DATA
GPLA-12K532-NBE.vbf	Multiple models (shared module)	PCM - Powertrain Control Module	DATA
GPLA-12K532-NBG.vbf	Multiple models (shared module)	PCM - Powertrain Control Module	DATA
GPLA-12K532-NCA.vbf	Multiple models (shared module)	PCM - Powertrain Control Module	DATA
GPLA-12K532-NCB.vbf	Multiple models (shared module)	PCM - Powertrain Control Module	DATA
GPLA-12K532-NCC.vbf	Multiple models (shared module)	PCM - Powertrain Control Module	DATA
GPLA-12K532-NCD.vbf	Multiple models (shared module)	PCM - Powertrain Control Module	DATA
GPLA-12K532-NCE.vbf	Multiple models (shared module)	PCM - Powertrain Control Module	DATA
GPLA-12K532-NCF.vbf	Multiple models (shared module)	PCM - Powertrain Control Module	DATA
GPLA-12K532-NCG.vbf	Multiple models (shared module)	PCM - Powertrain Control Module	DATA
GPLA-12K532-NCH.vbf	Multiple models (shared module)	PCM - Powertrain Control Module	DATA
GPLA-12K532-NCJ.vbf	Multiple models (shared module)	PCM - Powertrain Control Module	DATA
GPLA-12K532-NRC.vbf	Multiple models (shared module)	PCM - Powertrain Control Module	DATA
GPLA-12K532-NRD.vbf	Multiple models (shared module)	PCM - Powertrain Control Module	DATA
GPLA-12K532-NRE.vbf	Multiple models (shared module)	PCM - Powertrain Control Module	DATA
GPLA-12K532-NRF.vbf	Multiple models (shared module)	PCM - Powertrain Control Module	DATA
GPLA-14C026-AB.vbf	Multiple models (shared module)	IPC - Instrument Panel Cluster (IPC) Control Module	EXE
GPLA-14C026-AC.vbf	Multiple models (shared module)	IPC - Instrument Panel Cluster (IPC) Control Module	EXE
GPLA-14C026-AD.vbf	Multiple models (shared module)	IPC - Instrument Panel Cluster (IPC) Control Module	EXE
GPLA-14C026-AE.vbf	Multiple models (shared module)	IPC - Instrument Panel Cluster (IPC) Control Module	EXE
GPLA-14C026-AF.vbf	Multiple models (shared module)	IPC - Instrument Panel Cluster (IPC) Control Module	EXE
GPLA-14C026-AG.vbf	Multiple models (shared module)	IPC - Instrument Panel Cluster (IPC) Control Module	EXE
GPLA-14C026-AH.vbf	Multiple models (shared module)	IPC - Instrument Panel Cluster (IPC) Control Module	EXE
GPLA-14C026-MA.vbf	Multiple models (shared module)	IPC - Instrument Panel Cluster (IPC) Control Module	EXE
GPLA-14C026-MB.vbf	Multiple models (shared module)	IPC - Instrument Panel Cluster (IPC) Control Module	EXE
GPLA-14C026-MC.vbf	Multiple models (shared module)	AUM - Audio Module	EXE
GPLA-14C026-MD.vbf	Multiple models (shared module)	IPC - Instrument Panel Cluster (IPC) Control Module	EXE
GPLA-14C026-ME.vbf	Multiple models (shared module)	IPC - Instrument Panel Cluster (IPC) Control Module	EXE
GPLA-14C026-NA.vbf	Multiple models (shared module)	IPC - Instrument Panel Cluster (IPC) Control Module	EXE
GPLA-14C026-NB.vbf	Multiple models (shared module)	IPC - Instrument Panel Cluster (IPC) Control Module	EXE
GPLA-14C026-NC.vbf	Multiple models (shared module)	IPC - Instrument Panel Cluster (IPC) Control Module	EXE
GPLA-14C026-ND.vbf	Multiple models (shared module)	IPC - Instrument Panel Cluster (IPC) Control Module	EXE
GPLA-14C026-XA.vbf	Multiple models (shared module)	IPC - Instrument Panel Cluster (IPC) Control Module	EXE
GPLA-14C030-BB.vbf	Multiple models (shared module)	DSM - Driver Front Seat Module	EXE
GPLA-14C030-BC.vbf	Multiple models (shared module)	DSM - Driver Front Seat Module	EXE
GPLA-14C030-BD.vbf	Multiple models (shared module)	DSM - Driver Front Seat Module	EXE
GPLA-14C030-BF.vbf	Multiple models (shared module)	DSM - Driver Front Seat Module	EXE
GPLA-14C030-BG.vbf	Multiple models (shared module)	DSM - Driver Front Seat Module	EXE
GPLA-14C030-BH.vbf	Multiple models (shared module)	DSM - Driver Front Seat Module	EXE
GPLA-14C036-AB.vbf	Multiple models (shared module)	SPCM - Secondary Powertrain Control Module	EXE
GPLA-14C036-AC.vbf	Multiple models (shared module)	SPCM - Secondary Powertrain Control Module	EXE
GPLA-14C036-AD.vbf	Multiple models (shared module)	SPCM - Secondary Powertrain Control Module	EXE
GPLA-14C036-AE.vbf	Multiple models (shared module)	SPCM - Secondary Powertrain Control Module	EXE
GPLA-14C036-AF.vbf	Multiple models (shared module)	SPCM - Secondary Powertrain Control Module	EXE
GPLA-14C036-BB.vbf	Multiple models (shared module)	ABS - Anit-Lock Brake System (ABS) Control Module	EXE
GPLA-14C039-AA.vbf	Multiple models (shared module)	Not specified	SBL
GPLA-14C039-BA.vbf	Multiple models (shared module)	ABS - Anit-Lock Brake System (ABS) Control Module	SBL
GPLA-14C060-AB.vbf	Multiple models (shared module)	FCDIM - Front Control/Display Interface Module	EXE
GPLA-14C060-AD.vbf	Multiple models (shared module)	FCDIM - Front Control/Display Interface Module	EXE
GPLA-14C060-AE.vbf	Multiple models (shared module)	FCDIM - Front Control/Display Interface Module	EXE
GPLA-14C060-AF.vbf	Multiple models (shared module)	FCDIM - Front Control/Display Interface Module	EXE
GPLA-14C060-AG.vbf	Multiple models (shared module)	FCDIM - Front Control/Display Interface Module	EXE
GPLA-14C060-AH.vbf	Multiple models (shared module)	FCDIM - Front Control/Display Interface Module	EXE
GPLA-14C060-AJ.vbf	Multiple models (shared module)	FCDIM - Front Control/Display Interface Module	EXE
GPLA-14C060-AK.vbf	Multiple models (shared module)	FCDIM - Front Control/Display Interface Module	EXE
GPLA-14C060-BD.vbf	Multiple models (shared module)	FCDIM - Front Control/Display Interface Module	EXE
GPLA-14C060-BE.vbf	Multiple models (shared module)	FCDIM - Front Control/Display Interface Module	EXE
GPLA-14C060-BF.vbf	Multiple models (shared module)	FCDIM - Front Control/Display Interface Module	EXE
GPLA-14C060-BG.vbf	Multiple models (shared module)	FCDIM - Front Control/Display Interface Module	EXE
GPLA-14C060-BH.vbf	Multiple models (shared module)	FCDIM - Front Control/Display Interface Module	EXE
GPLA-14C060-BJ.vbf	Multiple models (shared module)	FCDIM - Front Control/Display Interface Module	EXE
GPLA-14C060-BK.vbf	Multiple models (shared module)	FCDIM - Front Control/Display Interface Module	EXE
GPLA-14C061-AB.vbf	Multiple models (shared module)	FCDIM - Front Control/Display Interface Module	DATA
GPLA-14C061-AC.vbf	Multiple models (shared module)	FCDIM - Front Control/Display Interface Module	DATA
GPLA-14C061-AD.vbf	Multiple models (shared module)	FCDIM - Front Control/Display Interface Module	DATA
GPLA-14C061-AE.vbf	Multiple models (shared module)	FCDIM - Front Control/Display Interface Module	DATA
GPLA-14C061-AF.vbf	Multiple models (shared module)	FCDIM - Front Control/Display Interface Module	DATA
GPLA-14C061-AG.vbf	Multiple models (shared module)	FCDIM - Front Control/Display Interface Module	DATA
GPLA-14C061-AH.vbf	Multiple models (shared module)	FCDIM - Front Control/Display Interface Module	DATA
GPLA-14C061-AJ.vbf	Multiple models (shared module)	FCDIM - Front Control/Display Interface Module	DATA
GPLA-14C061-AK.vbf	Multiple models (shared module)	FCDIM - Front Control/Display Interface Module	DATA
GPLA-14C063-AA.vbf	Multiple models (shared module)	FCDIM - Front Control/Display Interface Module	SBL
GPLA-14C065-AB.vbf	Range Rover (L405)	DDM - Driver Front Door Module	DATA
GPLA-14C065-AC.vbf	Range Rover (L405)	DDM - Driver Front Door Module	DATA

File name	Vehicle line (indicative)	Module (ECU)	Type
GPLA-14C065-AD.vbf	Range Rover (L405)	DDM - Driver Front Door Module	DATA
GPLA-14C065-AE.vbf	Range Rover (L405)	DDM - Driver Front Door Module	DATA
GPLA-14C065-AF.vbf	Range Rover (L405)	DDM - Driver Front Door Module	DATA
GPLA-14C065-CA.vbf	Range Rover (L405)	DDM - Driver Front Door Module	DATA
GPLA-14C065-CB.vbf	Range Rover (L405)	DDM - Driver Front Door Module	DATA
GPLA-14C065-CC.vbf	Range Rover (L405)	DDM - Driver Front Door Module	DATA
GPLA-14C065-CD.vbf	Range Rover (L405)	DDM - Driver Front Door Module	DATA
GPLA-14C065-CE.vbf	Range Rover (L405)	DDM - Driver Front Door Module	DATA
GPLA-14C069-AB.vbf	Range Rover (L405)	DRDM - Driver Rear Door Module	DATA
GPLA-14C069-AC.vbf	Range Rover (L405)	DRDM - Driver Rear Door Module	DATA
GPLA-14C069-AD.vbf	Range Rover (L405)	DRDM - Driver Rear Door Module	DATA
GPLA-14C069-AE.vbf	Range Rover (L405)	DRDM - Driver Rear Door Module	DATA
GPLA-14C069-AF.vbf	Range Rover (L405)	DRDM - Driver Rear Door Module	DATA
GPLA-14C069-CA.vbf	Range Rover (L405)	DRDM - Driver Rear Door Module	DATA
GPLA-14C069-CB.vbf	Range Rover (L405)	DRDM - Driver Rear Door Module	DATA
GPLA-14C069-CC.vbf	Range Rover (L405)	DRDM - Driver Rear Door Module	DATA
GPLA-14C069-CD.vbf	Range Rover (L405)	DRDM - Driver Rear Door Module	DATA
GPLA-14C069-CE.vbf	Range Rover (L405)	DRDM - Driver Rear Door Module	DATA
GPLA-14C088-CB.vbf	Multiple models (shared module)	IPC - Instrument Panel Cluster (IPC) Control Module	EXE
GPLA-14C088-CC.vbf	Multiple models (shared module)	IPC - Instrument Panel Cluster (IPC) Control Module	EXE
GPLA-14C088-CD.vbf	Multiple models (shared module)	IPC - Instrument Panel Cluster (IPC) Control Module	EXE
GPLA-14C088-CE.vbf	Multiple models (shared module)	IPC - Instrument Panel Cluster (IPC) Control Module	EXE
GPLA-14C088-CF.vbf	Multiple models (shared module)	IPC - Instrument Panel Cluster (IPC) Control Module	EXE
GPLA-14C088-CG.vbf	Multiple models (shared module)	IPC - Instrument Panel Cluster (IPC) Control Module	EXE
GPLA-14C088-MA.vbf	Multiple models (shared module)	IPC - Instrument Panel Cluster (IPC) Control Module	DATA
GPLA-14C088-MB.vbf	Multiple models (shared module)	IPC - Instrument Panel Cluster (IPC) Control Module	DATA
GPLA-14C088-MC.vbf	Multiple models (shared module)	AUM - Audio Module	DATA
GPLA-14C088-MD.vbf	Multiple models (shared module)	IPC - Instrument Panel Cluster (IPC) Control Module	DATA
GPLA-14C088-ME.vbf	Multiple models (shared module)	IPC - Instrument Panel Cluster (IPC) Control Module	DATA
GPLA-14C088-NA.vbf	Multiple models (shared module)	IPC - Instrument Panel Cluster (IPC) Control Module	DATA
GPLA-14C088-NB.vbf	Multiple models (shared module)	IPC - Instrument Panel Cluster (IPC) Control Module	DATA
GPLA-14C088-NC.vbf	Multiple models (shared module)	IPC - Instrument Panel Cluster (IPC) Control Module	DATA
GPLA-14C088-ND.vbf	Multiple models (shared module)	IPC - Instrument Panel Cluster (IPC) Control Module	DATA
GPLA-14C109-AB.vbf	Range Rover (L405)	PDM - Passenger Front Door Module	EXE
GPLA-14C109-AC.vbf	Range Rover (L405)	PDM - Passenger Front Door Module	EXE
GPLA-14C109-AD.vbf	Range Rover (L405)	PDM - Passenger Front Door Module	DATA
GPLA-14C109-AE.vbf	Range Rover (L405)	PDM - Passenger Front Door Module	DATA
GPLA-14C109-AF.vbf	Range Rover (L405)	PDM - Passenger Front Door Module	DATA
GPLA-14C109-CA.vbf	Range Rover (L405)	PDM - Passenger Front Door Module	DATA
GPLA-14C109-CB.vbf	Range Rover (L405)	PDM - Passenger Front Door Module	DATA
GPLA-14C109-CC.vbf	Range Rover (L405)	PDM - Passenger Front Door Module	DATA
GPLA-14C109-CD.vbf	Range Rover (L405)	PDM - Passenger Front Door Module	DATA
GPLA-14C109-CE.vbf	Range Rover (L405)	PDM - Passenger Front Door Module	DATA
GPLA-14C113-AB.vbf	Range Rover (L405)	PRDM - Passenger Rear Door Module	DATA
GPLA-14C113-AC.vbf	Range Rover (L405)	PRDM - Passenger Rear Door Module	DATA
GPLA-14C113-AD.vbf	Multiple models (shared module)	PRDM - Passenger Rear Door Module	DATA
GPLA-14C113-AE.vbf	Multiple models (shared module)	PRDM - Passenger Rear Door Module	DATA
GPLA-14C113-AF.vbf	Range Rover (L405)	PRDM - Passenger Rear Door Module	DATA
GPLA-14C113-CA.vbf	Range Rover (L405)	PRDM - Passenger Rear Door Module	DATA
GPLA-14C113-CB.vbf	Range Rover (L405)	PRDM - Passenger Rear Door Module	DATA
GPLA-14C113-CC.vbf	Range Rover (L405)	PRDM - Passenger Rear Door Module	DATA
GPLA-14C113-CD.vbf	Range Rover (L405)	PRDM - Passenger Rear Door Module	DATA
GPLA-14C113-CE.vbf	Range Rover (L405)	PRDM - Passenger Rear Door Module	DATA
GPLA-14C197-AC.vbf	Multiple models (shared module)	BECM - Battery Energy Control Module	EXE
GPLA-14C198-AC.vbf	Multiple models (shared module)	BECM - Battery Energy Control Module	EXE
GPLA-14C198-AD.vbf	Multiple models (shared module)	BECM - Battery Energy Control Module	EXE
GPLA-14C198-AE.vbf	Multiple models (shared module)	BECM - Battery Energy Control Module	EXE
GPLA-14C204-HAA.vbf	Multiple models (shared module)	PCM - Powertrain Control Module	EXE
GPLA-14C204-HAC.vbf	Multiple models (shared module)	PCM - Powertrain Control Module	EXE
GPLA-14C204-HAD.vbf	Multiple models (shared module)	PCM - Powertrain Control Module	EXE
GPLA-14C204-HAE.vbf	Multiple models (shared module)	PCM - Powertrain Control Module	EXE
GPLA-14C204-MBA.vbf	Range Rover Sport (L494)	PCM - Powertrain Control Module	EXE
GPLA-14C204-MBB.vbf	Range Rover Sport (L494)	PCM - Powertrain Control Module	EXE
GPLA-14C204-MBC.vbf	Range Rover Sport (L494)	PCM - Powertrain Control Module	EXE
GPLA-14C204-NAA.vbf	Multiple models (shared module)	PCM - Powertrain Control Module	EXE
GPLA-14C204-NAB.vbf	Multiple models (shared module)	PCM - Powertrain Control Module	EXE
GPLA-14C204-NAC.vbf	Multiple models (shared module)	PCM - Powertrain Control Module	EXE
GPLA-14C204-NAD.vbf	Multiple models (shared module)	PCM - Powertrain Control Module	EXE
GPLA-14C204-PAA.vbf	Multiple models (shared module)	PCM - Powertrain Control Module	EXE
GPLA-14C204-PAB.vbf	Multiple models (shared module)	PCM - Powertrain Control Module	EXE
GPLA-14C204-PAC.vbf	Multiple models (shared module)	PCM - Powertrain Control Module	EXE
GPLA-14C204-RAA.vbf	Range Rover (L405)	PCM - Powertrain Control Module	EXE
GPLA-14C204-RAB.vbf	Range Rover (L405)	PCM - Powertrain Control Module	EXE
GPLA-14C204-RAC.vbf	Multiple models (shared module)	PCM - Powertrain Control Module	EXE
GPLA-14C204-RAD.vbf	Check in SDD (unconfirmed)	PCM - Powertrain Control Module	EXE
GPLA-14C204-RAE.vbf	Multiple models (shared module)	PCM - Powertrain Control Module	EXE

File name	Vehicle line (indicative)	Module (ECU)	Type
GPLA-14C204-RCA.vbf	Range Rover (L405)	PCM - Powertrain Control Module	EXE
GPLA-14C204-RCB.vbf	Check in SDD (unconfirmed)	PCM - Powertrain Control Module	EXE
GPLA-14C204-RCC.vbf	Multiple models (shared module)	PCM - Powertrain Control Module	EXE
GPLA-14C204-REA.vbf	Range Rover (L405)	PCM - Powertrain Control Module	EXE
GPLA-14C204-REB.vbf	Check in SDD (unconfirmed)	PCM - Powertrain Control Module	EXE
GPLA-14C204-REC.vbf	Multiple models (shared module)	PCM - Powertrain Control Module	EXE
GPLA-14C204-RTA.vbf	Range Rover (L405)	PCM - Powertrain Control Module	EXE
GPLA-14C204-RTB.vbf	Range Rover (L405)	PCM - Powertrain Control Module	EXE
GPLA-14C204-RTC.vbf	Range Rover (L405)	PCM - Powertrain Control Module	EXE
GPLA-14C204-RTD.vbf	Check in SDD (unconfirmed)	PCM - Powertrain Control Module	EXE
GPLA-14C204-RTE.vbf	Multiple models (shared module)	PCM - Powertrain Control Module	EXE
GPLA-14C204-RTF.vbf	Multiple models (shared module)	PCM - Powertrain Control Module	EXE
GPLA-14C204-TAA.vbf	Multiple models (shared module)	PCM - Powertrain Control Module	EXE
GPLA-14C204-TAB.vbf	Multiple models (shared module)	PCM - Powertrain Control Module	EXE
GPLA-14C204-TAC.vbf	Multiple models (shared module)	PCM - Powertrain Control Module	EXE
GPLA-14C204-TAD.vbf	Multiple models (shared module)	PCM - Powertrain Control Module	EXE
GPLA-14C204-TAE.vbf	Multiple models (shared module)	PCM - Powertrain Control Module	EXE
GPLA-14C204-TCA.vbf	Multiple models (shared module)	PCM - Powertrain Control Module	EXE
GPLA-14C204-TCB.vbf	Multiple models (shared module)	PCM - Powertrain Control Module	EXE
GPLA-14C204-TCC.vbf	Multiple models (shared module)	PCM - Powertrain Control Module	EXE
GPLA-14C204-TEA.vbf	Multiple models (shared module)	PCM - Powertrain Control Module	EXE
GPLA-14C204-TEB.vbf	Multiple models (shared module)	PCM - Powertrain Control Module	EXE
GPLA-14C204-TEC.vbf	Multiple models (shared module)	PCM - Powertrain Control Module	EXE
GPLA-14C204-TTA.vbf	Multiple models (shared module)	PCM - Powertrain Control Module	EXE
GPLA-14C204-TTB.vbf	Multiple models (shared module)	PCM - Powertrain Control Module	EXE
GPLA-14C204-TTC.vbf	Multiple models (shared module)	PCM - Powertrain Control Module	EXE
GPLA-14C204-TTD.vbf	Multiple models (shared module)	PCM - Powertrain Control Module	EXE
GPLA-14C204-TTE.vbf	Multiple models (shared module)	PCM - Powertrain Control Module	EXE
GPLA-14C204-UAA.vbf	Multiple models (shared module)	PCM - Powertrain Control Module	EXE
GPLA-14C204-UAB.vbf	Multiple models (shared module)	PCM - Powertrain Control Module	EXE
GPLA-14C204-UAC.vbf	Multiple models (shared module)	PCM - Powertrain Control Module	EXE
GPLA-14C204-UAD.vbf	Multiple models (shared module)	PCM - Powertrain Control Module	EXE
GPLA-14C204-UAE.vbf	Multiple models (shared module)	PCM - Powertrain Control Module	EXE
GPLA-14C204-UAF.vbf	Multiple models (shared module)	PCM - Powertrain Control Module	EXE
GPLA-14C204-UCA.vbf	Multiple models (shared module)	PCM - Powertrain Control Module	EXE
GPLA-14C204-UCB.vbf	Multiple models (shared module)	PCM - Powertrain Control Module	EXE
GPLA-14C204-UCC.vbf	Multiple models (shared module)	PCM - Powertrain Control Module	EXE
GPLA-14C204-UEA.vbf	Multiple models (shared module)	PCM - Powertrain Control Module	EXE
GPLA-14C204-UEB.vbf	Multiple models (shared module)	PCM - Powertrain Control Module	EXE
GPLA-14C204-UEC.vbf	Multiple models (shared module)	PCM - Powertrain Control Module	EXE
GPLA-14C204-UED.vbf	Multiple models (shared module)	PCM - Powertrain Control Module	EXE
GPLA-14C204-UEE.vbf	Multiple models (shared module)	PCM - Powertrain Control Module	EXE
GPLA-14C204-UTA.vbf	Multiple models (shared module)	PCM - Powertrain Control Module	EXE
GPLA-14C204-UTB.vbf	Multiple models (shared module)	PCM - Powertrain Control Module	EXE
GPLA-14C204-UTC.vbf	Multiple models (shared module)	PCM - Powertrain Control Module	EXE
GPLA-14C204-UTD.vbf	Multiple models (shared module)	PCM - Powertrain Control Module	EXE
GPLA-14C204-UTE.vbf	Multiple models (shared module)	PCM - Powertrain Control Module	EXE
GPLA-14C204-UTF.vbf	Multiple models (shared module)	PCM - Powertrain Control Module	EXE
GPLA-14C217-AA.vbf	Multiple models (shared module)	PSCM - Power Steering Control Module	EXE
GPLA-14C217-AB.vbf	Multiple models (shared module)	PSCM - Power Steering Control Module	EXE
GPLA-14C217-AD.vbf	Multiple models (shared module)	PSCM - Power Steering Control Module	EXE
GPLA-14C273-HAA.vbf	Multiple models (shared module)	PCM - Powertrain Control Module	SBL
GPLA-14C342-AA.vbf	Multiple models (shared module)	Not specified	DATA
GPLA-14C386-AA.vbf	Multiple models (shared module)	PSCM - Power Steering Control Module	EXE
GPLA-14C386-AB.vbf	Multiple models (shared module)	PSCM - Power Steering Control Module	EXE
GPLA-14C413-AA.vbf	Multiple models (shared module)	DSM - Driver Front Seat Module	EXE
GPLA-14C413-AB.vbf	Multiple models (shared module)	DSM - Driver Front Seat Module	EXE
GPLA-14C534-AB.vbf	Multiple models (shared module)	FCIMB - Front Controls Interface Module 'B'	SIGCFG
GPLA-14C535-AB.vbf	Multiple models (shared module)	FCIMB - Front Controls Interface Module 'B'	EXE
GPLA-14C535-BA.vbf	Multiple models (shared module)	FCIMB - Front Controls Interface Module 'B'	EXE
GPLA-14C536-AA.vbf	Multiple models (shared module)	FCIMB - Front Controls Interface Module 'B'	CUSTOM
GPLA-14C537-AB.vbf	Multiple models (shared module)	FCIMB - Front Controls Interface Module 'B'	SBL
GPLA-14C547-AA.vbf	Multiple models (shared module)	PSM - Passenger Front Seat Module	EXE
GPLA-14C547-AB.vbf	Multiple models (shared module)	PSM - Passenger Front Seat Module	EXE
GPLA-14C548-BB.vbf	Multiple models (shared module)	PSM - Passenger Front Seat Module	EXE
GPLA-14C548-BC.vbf	Multiple models (shared module)	PSM - Passenger Front Seat Module	EXE
GPLA-14C548-BD.vbf	Multiple models (shared module)	PSM - Passenger Front Seat Module	EXE
GPLA-14C548-BF.vbf	Multiple models (shared module)	PSM - Passenger Front Seat Module	EXE
GPLA-14C548-BG.vbf	Multiple models (shared module)	PSM - Passenger Front Seat Module	EXE
GPLA-14C621-AA.vbf	Multiple models (shared module)	FCDIM - Front Control/Display Interface Module	EXE
GPLA-14C621-AB.vbf	Multiple models (shared module)	FCDIM - Front Control/Display Interface Module	EXE
GPLA-14D016-AB.vbf	Multiple models (shared module)	FCIM - Front Controls Interface Module	SIGCFG
GPLA-14D017-AB.vbf	Multiple models (shared module)	FCIM - Front Controls Interface Module	EXE
GPLA-14D017-AC.vbf	Multiple models (shared module)	FCIM - Front Controls Interface Module	EXE
GPLA-14D017-AF.vbf	Multiple models (shared module)	FCIM - Front Controls Interface Module	EXE
GPLA-14D017-AG.vbf	Multiple models (shared module)	FCIM - Front Controls Interface Module	EXE

File name	Vehicle line (indicative)	Module (ECU)	Type
GPLA-14D018-AA.vbf	Multiple models (shared module)	FCIM - Front Controls Interface Module	CUSTOM
GPLA-14D018-AC.vbf	Multiple models (shared module)	FCIM - Front Controls Interface Module	CUSTOM
GPLA-14D019-AB.vbf	Multiple models (shared module)	FCIM - Front Controls Interface Module	SBL
GPLA-14D023-AA.vbf	Range Rover Sport (L494)	ATCM - All Terrain Control Module	SIGCFG
GPLA-14D024-AA.vbf	Range Rover Sport (L494)	ATCM - All Terrain Control Module	EXE
GPLA-14D196-AA.vbf	Multiple models (shared module)	IPMA - Image Processing Module A	EXE
GPLA-14D197-AA.vbf	Multiple models (shared module)	IPMA - Image Processing Module A	DATA
GPLA-14D198-AA.vbf	Multiple models (shared module)	IPMA - Image Processing Module A	SBL
GPLA-14D519-BA.vbf	Multiple models (shared module)	HVAC - HVAC Control Module	EXE
GPLA-14D519-BB.vbf	Multiple models (shared module)	HVAC - HVAC Control Module	EXE
GPLA-14D519-BC.vbf	Multiple models (shared module)	HVAC - HVAC Control Module	EXE
GPLA-14D519-BD.vbf	Multiple models (shared module)	HVAC - HVAC Control Module	EXE
GPLA-14D519-BE.vbf	Multiple models (shared module)	HVAC - HVAC Control Module	EXE
GPLA-14D519-CA.vbf	Multiple models (shared module)	HVAC - HVAC Control Module	EXE
GPLA-14D519-CB.vbf	Multiple models (shared module)	HVAC - HVAC Control Module	EXE
GPLA-14D519-CC.vbf	Multiple models (shared module)	HVAC - HVAC Control Module	EXE
GPLA-14D520-FA.vbf	Multiple models (shared module)	HVAC - HVAC Control Module	DATA
GPLA-14D520-FB.vbf	Multiple models (shared module)	HVAC - HVAC Control Module	DATA
GPLA-14D520-FC.vbf	Multiple models (shared module)	HVAC - HVAC Control Module	DATA
GPLA-14D520-FD.vbf	Multiple models (shared module)	HVAC - HVAC Control Module	DATA
GPLA-14D520-FE.vbf	Multiple models (shared module)	HVAC - HVAC Control Module	DATA
GPLA-14D520-FF.vbf	Multiple models (shared module)	HVAC - HVAC Control Module	DATA
GPLA-14D520-FG.vbf	Multiple models (shared module)	HVAC - HVAC Control Module	DATA
GPLA-14D520-FH.vbf	Multiple models (shared module)	HVAC - HVAC Control Module	DATA
GPLA-14D520-FJ.vbf	Multiple models (shared module)	HVAC - HVAC Control Module	DATA
GPLA-14D520-FK.vbf	Multiple models (shared module)	HVAC - HVAC Control Module	DATA
GPLA-14D520-FL.vbf	Multiple models (shared module)	HVAC - HVAC Control Module	DATA
GPLA-14D520-FM.vbf	Multiple models (shared module)	HVAC - HVAC Control Module	DATA
GPLA-14D520-FN.vbf	Multiple models (shared module)	HVAC - HVAC Control Module	DATA
GPLA-14D520-GA.vbf	Multiple models (shared module)	HVAC - HVAC Control Module	DATA
GPLA-14D520-GB.vbf	Multiple models (shared module)	HVAC - HVAC Control Module	DATA
GPLA-14D520-GC.vbf	Multiple models (shared module)	HVAC - HVAC Control Module	DATA
GPLA-14D520-GD.vbf	Multiple models (shared module)	HVAC - HVAC Control Module	DATA
GPLA-14D520-GE.vbf	Multiple models (shared module)	HVAC - HVAC Control Module	DATA
GPLA-14D520-GF.vbf	Multiple models (shared module)	HVAC - HVAC Control Module	DATA
GPLA-14D520-GG.vbf	Multiple models (shared module)	HVAC - HVAC Control Module	DATA
GPLA-14D520-GH.vbf	Multiple models (shared module)	HVAC - HVAC Control Module	DATA
GPLA-14D520-HA.vbf	Multiple models (shared module)	HVAC - HVAC Control Module	DATA
GPLA-14D520-HB.vbf	Multiple models (shared module)	HVAC - HVAC Control Module	DATA
GPLA-14D520-HC.vbf	Multiple models (shared module)	HVAC - HVAC Control Module	DATA
GPLA-14D520-HD.vbf	Multiple models (shared module)	HVAC - HVAC Control Module	DATA
GPLA-14D520-HE.vbf	Multiple models (shared module)	HVAC - HVAC Control Module	DATA
GPLA-14D520-HF.vbf	Multiple models (shared module)	HVAC - HVAC Control Module	DATA
GPLA-14D520-JA.vbf	Multiple models (shared module)	HVAC - HVAC Control Module	DATA
GPLA-14D520-JB.vbf	Multiple models (shared module)	HVAC - HVAC Control Module	DATA
GPLA-14D520-JC.vbf	Multiple models (shared module)	HVAC - HVAC Control Module	DATA
GPLA-14D520-JD.vbf	Multiple models (shared module)	HVAC - HVAC Control Module	DATA
GPLA-14D520-JE.vbf	Multiple models (shared module)	HVAC - HVAC Control Module	DATA
GPLA-14D520-KA.vbf	Multiple models (shared module)	HVAC - HVAC Control Module	DATA
GPLA-14D520-KB.vbf	Multiple models (shared module)	HVAC - HVAC Control Module	DATA
GPLA-14D520-KC.vbf	Multiple models (shared module)	HVAC - HVAC Control Module	DATA
GPLA-14D520-KD.vbf	Multiple models (shared module)	HVAC - HVAC Control Module	DATA
GPLA-14D520-KE.vbf	Multiple models (shared module)	HVAC - HVAC Control Module	DATA
GPLA-14D520-LA.vbf	Multiple models (shared module)	HVAC - HVAC Control Module	DATA
GPLA-14D520-LB.vbf	Multiple models (shared module)	HVAC - HVAC Control Module	DATA
GPLA-14D520-LC.vbf	Multiple models (shared module)	HVAC - HVAC Control Module	DATA
GPLA-14D520-LD.vbf	Multiple models (shared module)	HVAC - HVAC Control Module	DATA
GPLA-14D520-LE.vbf	Multiple models (shared module)	HVAC - HVAC Control Module	DATA
GPLA-14D520-LF.vbf	Multiple models (shared module)	HVAC - HVAC Control Module	DATA
GPLA-14D520-LG.vbf	Multiple models (shared module)	HVAC - HVAC Control Module	DATA
GPLA-14D520-MA.vbf	Multiple models (shared module)	HVAC - HVAC Control Module	DATA
GPLA-14E093-JB.vbf	Multiple models (shared module)	CHCM - Chassis Control Module	EXE
GPLA-14E093-JC.vbf	Multiple models (shared module)	CHCM - Chassis Control Module	EXE
GPLA-14E093-JD.vbf	Multiple models (shared module)	CHCM - Chassis Control Module	EXE
GPLA-14E093-JE.vbf	Multiple models (shared module)	CHCM - Chassis Control Module	EXE
GPLA-14E093-JF.vbf	Multiple models (shared module)	CHCM - Chassis Control Module	EXE
GPLA-14E093-JG.vbf	Multiple models (shared module)	CHCM - Chassis Control Module	EXE
GPLA-14F216-AB.vbf	Multiple models (shared module)	RHVAC - Rear HVAC Control Module	SIGCFG
GPLA-14F217-AB.vbf	Multiple models (shared module)	RHVAC - Rear HVAC Control Module	EXE
GPLA-14F218-AA.vbf	Multiple models (shared module)	RHVAC - Rear HVAC Control Module	CUSTOM
GPLA-14F219-AB.vbf	Multiple models (shared module)	RHVAC - Rear HVAC Control Module	SBL
GPLA-14F434-NB.vbf	Multiple models (shared module)	CHCMB - Chassis Control Module B	EXE
GPLA-14F434-NC.vbf	Multiple models (shared module)	CHCMB - Chassis Control Module B	EXE
GPLA-14F434-ND.vbf	Multiple models (shared module)	CHCMB - Chassis Control Module B	EXE
GPLA-14F455-AA.vbf	Multiple models (shared module)	IPMA - Image Processing Module A	EXE
GPLA-14F455-BB.vbf	Multiple models (shared module)	IPMA - Image Processing Module A	EXE

File name	Vehicle line (indicative)	Module (ECU)	Type
GPLA-14F455-BC.vbf	Multiple models (shared module)	IPMA - Image Processing Module A	EXE
GPLA-14F456-AA.vbf	Multiple models (shared module)	IPMA - Image Processing Module A	DATA
GPLA-14F456-BB.vbf	Multiple models (shared module)	IPMA - Image Processing Module A	DATA
GPLA-14F456-BC.vbf	Multiple models (shared module)	IPMA - Image Processing Module A	DATA
GPLA-14F457-AA.vbf	Multiple models (shared module)	IPMA - Image Processing Module A	SBL
GPLA-14F520-AA.vbf	Multiple models (shared module)	SOBDMB - Secondary OBD Control Module B	EXE
GPLA-14F520-AB.vbf	Multiple models (shared module)	SOBDMB - Secondary OBD Control Module B	EXE
GPLA-14F530-AC.vbf	Multiple models (shared module)	GWM - Gateway Module A	EXE
GPLA-14F530-AD.vbf	Multiple models (shared module)	GWM - Gateway Module A	EXE
GPLA-14F530-AE.vbf	Multiple models (shared module)	GWM - Gateway Module A	EXE
GPLA-14F530-AF.vbf	Multiple models (shared module)	GWM - Gateway Module A	EXE
GPLA-14F530-AG.vbf	Multiple models (shared module)	GWM - Gateway Module A	EXE
GPLA-14F530-AJ.vbf	Multiple models (shared module)	GWM - Gateway Module A	EXE
GPLA-14F531-AB.vbf	Multiple models (shared module)	GWM - Gateway Module A	DATA
GPLA-14F531-AC.vbf	Multiple models (shared module)	GWM - Gateway Module A	DATA
GPLA-14F531-AD.vbf	Multiple models (shared module)	GWM - Gateway Module A	DATA
GPLA-14F531-AE.vbf	Multiple models (shared module)	GWM - Gateway Module A	DATA
GPLA-14F531-BA.vbf	Multiple models (shared module)	GWM - Gateway Module A	DATA
GPLA-14F531-BB.vbf	Multiple models (shared module)	GWM - Gateway Module A	DATA
GPLA-14F531-BC.vbf	Multiple models (shared module)	GWM - Gateway Module A	DATA
GPLA-14F531-BD.vbf	Multiple models (shared module)	GWM - Gateway Module A	DATA
GPLA-14F531-BE.vbf	Multiple models (shared module)	GWM - Gateway Module A	DATA
GPLA-18A836-AB.vbf	Multiple models (shared module)	FCIMC - Front Controls Interface Module 'C'	SIGCFG
GPLA-18A842-AA.vbf	Multiple models (shared module)	FCIMC - Front Controls Interface Module 'C'	CUSTOM
GPLA-18A843-AB.vbf	Multiple models (shared module)	FCIMC - Front Controls Interface Module 'C'	SBL
GPLA-18A911-AB.vbf	Multiple models (shared module)	FCIMC - Front Controls Interface Module 'C'	EXE
GPLA-70713-BA.vbf	Multiple models (shared module)	TCU - Telematic Control Unit Module	DATA
GPLA-70713-BB.vbf	Multiple models (shared module)	TCU - Telematic Control Unit Module	DATA
GPLA-70713-BC.vbf	Multiple models (shared module)	TCU - Telematic Control Unit Module	DATA
GPLA-70713-BD.vbf	Multiple models (shared module)	TCU - Telematic Control Unit Module	DATA
GPLA-70713-CA.vbf	Multiple models (shared module)	TCU - Telematic Control Unit Module	DATA
GPLA-70713-CB.vbf	Multiple models (shared module)	TCU - Telematic Control Unit Module	DATA
GPLA-70713-CC.vbf	Multiple models (shared module)	TCU - Telematic Control Unit Module	DATA
GPLA-70713-CD.vbf	Multiple models (shared module)	TCU - Telematic Control Unit Module	DATA
GPLA-70713-MA.vbf	Multiple models (shared module)	TCU - Telematic Control Unit Module	DATA
GPLA-70713-MB.vbf	Multiple models (shared module)	TCU - Telematic Control Unit Module	DATA
GPLA-70713-MC.vbf	Multiple models (shared module)	TCU - Telematic Control Unit Module	DATA
GPLA-70713-MD.vbf	Multiple models (shared module)	TCU - Telematic Control Unit Module	DATA
GPLA-70713-NA.vbf	Multiple models (shared module)	TCU - Telematic Control Unit Module	DATA
GPLA-70713-NB.vbf	Multiple models (shared module)	TCU - Telematic Control Unit Module	DATA
GPLA-70713-NC.vbf	Multiple models (shared module)	TCU - Telematic Control Unit Module	DATA
GPLA-70713-ND.vbf	Multiple models (shared module)	TCU - Telematic Control Unit Module	DATA
GPLA-7J104-CDA.vbf	Multiple models (shared module)	TCM - Transmission Control Module	EXE
GPLA-7J104-CDB.vbf	Multiple models (shared module)	TCM - Transmission Control Module	EXE
GPLA-7J104-CDC.vbf	Multiple models (shared module)	TCM - Transmission Control Module	EXE
GPLA-7J104-CDD.vbf	Multiple models (shared module)	TCM - Transmission Control Module	EXE
GW93-12K532-PCB.vbf	Jaguar XJ (X351)	PCM - Powertrain Control Module	DATA
GW93-12K532-PCD.vbf	Jaguar XJ (X351)	PCM - Powertrain Control Module	DATA
GW93-12K532-PCE.vbf	Jaguar XJ (X351)	PCM - Powertrain Control Module	DATA
GW93-12K532-PCF.vbf	Jaguar XJ (X351)	PCM - Powertrain Control Module	DATA
GW93-12K532-PCG.vbf	Jaguar XJ (X351)	PCM - Powertrain Control Module	DATA
GW93-12K532-PCH.vbf	Jaguar XJ (X351)	PCM - Powertrain Control Module	DATA
GW93-12K532-PCJ.vbf	Jaguar XJ (X351)	PCM - Powertrain Control Module	DATA
GW93-12K532-PHD.vbf	Jaguar XJ (X351)	PCM - Powertrain Control Module	DATA
GW93-12K532-PHE.vbf	Jaguar XJ (X351)	PCM - Powertrain Control Module	DATA
GW93-12K532-PHF.vbf	Jaguar XJ (X351)	PCM - Powertrain Control Module	DATA
GW93-12K532-PKD.vbf	Jaguar XJ (X351)	PCM - Powertrain Control Module	DATA
GW93-12K532-PKE.vbf	Jaguar XJ (X351)	PCM - Powertrain Control Module	DATA
GW93-12K532-PLB.vbf	Jaguar XJ (X351)	PCM - Powertrain Control Module	DATA
GW93-12K532-PLD.vbf	Jaguar XJ (X351)	PCM - Powertrain Control Module	DATA
GW93-12K532-PLE.vbf	Jaguar XJ (X351)	PCM - Powertrain Control Module	DATA
GW93-12K532-PLF.vbf	Jaguar XJ (X351)	PCM - Powertrain Control Module	DATA
GW93-14C026-AB.vbf	Jaguar XJ (X351)	IPC - Instrument Panel Cluster (IPC) Control Module	EXE
GW93-14C026-AE.vbf	Jaguar XJ (X351)	IPC - Instrument Panel Cluster (IPC) Control Module	EXE
GW93-14C026-AF.vbf	Jaguar XJ (X351)	IPC - Instrument Panel Cluster (IPC) Control Module	EXE
GW93-14C026-BB.vbf	Jaguar XJ (X351)	IPC - Instrument Panel Cluster (IPC) Control Module	EXE
GW93-14C026-BC.vbf	Jaguar XJ (X351)	IPC - Instrument Panel Cluster (IPC) Control Module	EXE
GW93-14C026-BF.vbf	Jaguar XJ (X351)	IPC - Instrument Panel Cluster (IPC) Control Module	EXE
GW93-14C026-BG.vbf	Jaguar XJ (X351)	IPC - Instrument Panel Cluster (IPC) Control Module	DATA
GW93-14C026-BH.vbf	Jaguar XJ (X351)	IPC - Instrument Panel Cluster (IPC) Control Module	DATA
GW93-14C026-CB.vbf	Jaguar XJ (X351)	IPC - Instrument Panel Cluster (IPC) Control Module	EXE
GW93-14C026-DA.vbf	Jaguar XJ (X351)	IPC - Instrument Panel Cluster (IPC) Control Module	EXE
GW93-14C026-JA.vbf	Jaguar XJ (X351)	IPC - Instrument Panel Cluster (IPC) Control Module	EXE
GW93-14C030-DE.vbf	Jaguar XJ (X351)	DSM - Driver Front Seat Module	EXE
GW93-14C030-DF.vbf	Jaguar XJ (X351)	DSM - Driver Front Seat Module	EXE
GW93-14C030-DG.vbf	Jaguar XJ (X351)	DSM - Driver Front Seat Module	EXE

File name	Vehicle line (indicative)	Module (ECU)	Type
GW93-14C030-ZA.vbf	Jaguar XJ (X351)	DSM - Driver Front Seat Module	EXE
GW93-14C034-AD.vbf	Jaguar XJ (X351)	DSM - Driver Front Seat Module	EXE
GW93-14C034-AF.vbf	Jaguar XJ (X351)	DSM - Driver Front Seat Module	EXE
GW93-14C034-BD.vbf	Jaguar XJ (X351)	DSM - Driver Front Seat Module	EXE
GW93-14C034-BF.vbf	Jaguar XJ (X351)	DSM - Driver Front Seat Module	EXE
GW93-14C034-CD.vbf	Jaguar XJ (X351)	DSM - Driver Front Seat Module	EXE
GW93-14C034-CF.vbf	Jaguar XJ (X351)	DSM - Driver Front Seat Module	EXE
GW93-14C036-AC.vbf	Jaguar XJ (X351)	SPCM - Secondary Powertrain Control Module	EXE
GW93-14C037-AC.vbf	Jaguar XJ (X351)	SPCM - Secondary Powertrain Control Module	EXE
GW93-14C037-BC.vbf	Jaguar XJ (X351)	SPCM - Secondary Powertrain Control Module	EXE
GW93-14C037-CC.vbf	Jaguar XJ (X351)	SPCM - Secondary Powertrain Control Module	EXE
GW93-14C037-DC.vbf	Jaguar XJ (X351)	SPCM - Secondary Powertrain Control Module	EXE
GW93-14C037-EC.vbf	Jaguar XJ (X351)	SPCM - Secondary Powertrain Control Module	EXE
GW93-14C037-FC.vbf	Jaguar XJ (X351)	SPCM - Secondary Powertrain Control Module	EXE
GW93-14C037-JC.vbf	Jaguar XJ (X351)	SPCM - Secondary Powertrain Control Module	EXE
GW93-14C037-KC.vbf	Jaguar XJ (X351)	SPCM - Secondary Powertrain Control Module	EXE
GW93-14C037-LC.vbf	Jaguar XJ (X351)	SPCM - Secondary Powertrain Control Module	EXE
GW93-14C037-MC.vbf	Jaguar XJ (X351)	SPCM - Secondary Powertrain Control Module	EXE
GW93-14C037-NC.vbf	Jaguar XJ (X351)	SPCM - Secondary Powertrain Control Module	EXE
GW93-14C037-PC.vbf	Jaguar XJ (X351)	SPCM - Secondary Powertrain Control Module	EXE
GW93-14C088-AB.vbf	Jaguar XJ (X351)	IPC - Instrument Panel Cluster (IPC) Control Module	DATA
GW93-14C088-AC.vbf	Jaguar XJ (X351)	IPC - Instrument Panel Cluster (IPC) Control Module	DATA
GW93-14C088-AE.vbf	Jaguar XJ (X351)	IPC - Instrument Panel Cluster (IPC) Control Module	DATA
GW93-14C088-JA.vbf	Jaguar XJ (X351)	IPC - Instrument Panel Cluster (IPC) Control Module	DATA
GW93-14C091-AD.vbf	Jaguar XJ (X351)	PAM - Parking Assist Control Module	DATA
GW93-14C091-AE.vbf	Jaguar XJ (X351)	PAM - Parking Assist Control Module	DATA
GW93-14C091-AF.vbf	Jaguar XJ (X351)	PAM - Parking Assist Control Module	DATA
GW93-14C091-AH.vbf	Jaguar XJ (X351)	PAM - Parking Assist Control Module	DATA
GW93-14C091-AJ.vbf	Jaguar XJ (X351)	PAM - Parking Assist Control Module	DATA
GW93-14C091-AK.vbf	Jaguar XJ (X351)	PAM - Parking Assist Control Module	DATA
GW93-14C105-AC.vbf	Jaguar XJ (X351)	TMC Traffic Message Channel Module	DATA
GW93-14C204-EAB.vbf	Jaguar XJ (X351)	PCM - Powertrain Control Module	EXE
GW93-14C204-EAC.vbf	Jaguar XJ (X351)	PCM - Powertrain Control Module	EXE
GW93-14C204-EAD.vbf	Jaguar XJ (X351)	PCM - Powertrain Control Module	EXE
GW93-14C204-ECA.vbf	Jaguar XJ (X351)	PCM - Powertrain Control Module	EXE
GW93-14C204-ECB.vbf	Jaguar XJ (X351)	PCM - Powertrain Control Module	EXE
GW93-14C204-EEA.vbf	Jaguar XJ (X351)	PCM - Powertrain Control Module	EXE
GW93-14C204-ETB.vbf	Jaguar XJ (X351)	PCM - Powertrain Control Module	EXE
GW93-14C204-ETC.vbf	Jaguar XJ (X351)	PCM - Powertrain Control Module	EXE
GW93-14C204-ETD.vbf	Jaguar XJ (X351)	PCM - Powertrain Control Module	EXE
GW93-14C204-MCC.vbf	Jaguar XJ (X351)	PCM - Powertrain Control Module	EXE
GW93-14C204-MEC.vbf	Jaguar XJ (X351)	PCM - Powertrain Control Module	EXE
GW93-14C204-MHB.vbf	Jaguar XJ (X351)	PCM - Powertrain Control Module	EXE
GW93-14C204-MHC.vbf	Jaguar XJ (X351)	PCM - Powertrain Control Module	EXE
GW93-14C204-PAB.vbf	Jaguar XJ (X351)	PCM - Powertrain Control Module	EXE
GW93-14C204-PAC.vbf	Jaguar XJ (X351)	PCM - Powertrain Control Module	EXE
GW93-14C204-RAB.vbf	Jaguar XJ (X351)	PCM - Powertrain Control Module	EXE
GW93-14C204-RAC.vbf	Jaguar XJ (X351)	PCM - Powertrain Control Module	EXE
GW93-14C204-RAD.vbf	Jaguar XJ (X351)	PCM - Powertrain Control Module	EXE
GW93-14C204-RCA.vbf	Jaguar XJ (X351)	PCM - Powertrain Control Module	EXE
GW93-14C204-RCB.vbf	Jaguar XJ (X351)	PCM - Powertrain Control Module	EXE
GW93-14C204-REA.vbf	Jaguar XJ (X351)	PCM - Powertrain Control Module	EXE
GW93-14C204-REB.vbf	Jaguar XJ (X351)	PCM - Powertrain Control Module	EXE
GW93-14C204-RTB.vbf	Jaguar XJ (X351)	PCM - Powertrain Control Module	EXE
GW93-14C204-RTC.vbf	Jaguar XJ (X351)	PCM - Powertrain Control Module	EXE
GW93-14C204-RTD.vbf	Jaguar XJ (X351)	PCM - Powertrain Control Module	EXE
GW93-14C204-ZAA.vbf	Jaguar XJ (X351)	PCM - Powertrain Control Module	EXE
GW93-14C204-ZAB.vbf	Jaguar XJ (X351)	PCM - Powertrain Control Module	EXE
GW93-14C204-ZCA.vbf	Jaguar XJ (X351)	PCM - Powertrain Control Module	EXE
GW93-14C204-ZCB.vbf	Jaguar XJ (X351)	PCM - Powertrain Control Module	EXE
GW93-14C204-ZTA.vbf	Jaguar XJ (X351)	PCM - Powertrain Control Module	EXE
GW93-14C204-ZTB.vbf	Jaguar XJ (X351)	PCM - Powertrain Control Module	EXE
GW93-14C217-AB.vbf	Jaguar XJ (X351)	PSCM - Power Steering Control Module	EXE
GW93-14C218-AC.vbf	Jaguar XJ (X351)	PSCM - Power Steering Control Module	DATA
GW93-14C218-BB.vbf	Jaguar XJ (X351)	PSCM - Power Steering Control Module	DATA
GW93-14C218-CA.vbf	Jaguar XJ (X351)	PSCM - Power Steering Control Module	DATA
GW93-14C218-DA.vbf	Jaguar XJ (X351)	PSCM - Power Steering Control Module	DATA
GW93-14C218-EA.vbf	Jaguar XJ (X351)	PSCM - Power Steering Control Module	DATA
GW93-14C218-FA.vbf	Jaguar XJ (X351)	PSCM - Power Steering Control Module	DATA
GW93-14C218-GA.vbf	Jaguar XJ (X351)	PSCM - Power Steering Control Module	DATA
GW93-14C218-HA.vbf	Jaguar XJ (X351)	PSCM - Power Steering Control Module	DATA
GW93-14C218-JA.vbf	Jaguar XJ (X351)	PSCM - Power Steering Control Module	DATA
GW93-14C218-KA.vbf	Jaguar XJ (X351)	PSCM - Power Steering Control Module	DATA
GW93-14C386-AA.vbf	Jaguar XJ (X351)	PSCM - Power Steering Control Module	SIGCFG
GW93-14C413-AC.vbf	Jaguar XJ (X351)	DSM - Driver Front Seat Module	EXE
GW93-14C547-AB.vbf	Jaguar XJ (X351)	PSM - Passenger Front Seat Module	EXE

File name	Vehicle line (indicative)	Module (ECU)	Type
GW93-14C548-DE.vbf	Jaguar XJ (X351)	PSM - Passenger Front Seat Module	EXE
GW93-14C548-DF.vbf	Jaguar XJ (X351)	PSM - Passenger Front Seat Module	EXE
GW93-14C548-DG.vbf	Jaguar XJ (X351)	PSM - Passenger Front Seat Module	EXE
GW93-14C548-ZA.vbf	Jaguar XJ (X351)	PSM - Passenger Front Seat Module	EXE
GW93-14C549-BD.vbf	Jaguar XJ (X351)	PSM - Passenger Front Seat Module	EXE
GW93-14C549-BF.vbf	Jaguar XJ (X351)	PSM - Passenger Front Seat Module	EXE
GW93-14C549-CD.vbf	Jaguar XJ (X351)	PSM - Passenger Front Seat Module	EXE
GW93-14C549-CF.vbf	Jaguar XJ (X351)	PSM - Passenger Front Seat Module	EXE
GW93-14C560-AA.vbf	Jaguar XJ (X351)	GSM - Gear Shift Module	SIGCFG
GW93-14C561-AA.vbf	Jaguar XJ (X351)	GSM - Gear Shift Module	EXE
GW93-14C609-AB.vbf	Jaguar XJ (X351)	PSCM - Power Steering Control Module	DATA
GW9M-14C152-AA.vbf	Not specified	TPM - Tire Pressure Monitor Module	DATA
GW9M-14E094-JCA.vbf	Not specified	CHCM - Chassis Control Module	EXE
GX53-14C025-BA.vbf	Jaguar F-Type (X152)	Not specified	SBL
GX53-14C026-AB.vbf	Jaguar F-Type (X152)	IPC - Instrument Panel Cluster (IPC) Control Module	EXE
GX53-14C026-AC.vbf	Jaguar F-Type (X152)	IPC - Instrument Panel Cluster (IPC) Control Module	EXE
GX53-14C026-AD.vbf	Jaguar F-Type (X152)	IPC - Instrument Panel Cluster (IPC) Control Module	EXE
GX53-14C026-AE.vbf	Jaguar F-Type (X152)	IPC - Instrument Panel Cluster (IPC) Control Module	EXE
GX53-14C026-AF.vbf	Jaguar F-Type (X152)	IPC - Instrument Panel Cluster (IPC) Control Module	EXE
GX53-14C028-AC.vbf	Jaguar F-Type (X152)	RCM - Restraints Control Module	EXE
GX53-14C030-AB.vbf	Jaguar F-Type (X152)	DSM - Driver Front Seat Module	EXE
GX53-14C034-AB.vbf	Range Rover Sport (L494)	DSM - Driver Front Seat Module	DATA
GX53-14C034-BB.vbf	Range Rover Sport (L494)	DSM - Driver Front Seat Module	DATA
GX53-14C034-CB.vbf	Range Rover Sport (L494)	DSM - Driver Front Seat Module	DATA
GX53-14C034-DB.vbf	Range Rover Sport (L494)	DSM - Driver Front Seat Module	DATA
GX53-14C036-AH.vbf	Jaguar F-Type (X152)	SPCM - Secondary Powertrain Control Module	EXE
GX53-14C037-AAF.vbf	Jaguar F-Type (X152)	SPCM - Secondary Powertrain Control Module	EXE
GX53-14C037-AAJ.vbf	Jaguar F-Type (X152)	SPCM - Secondary Powertrain Control Module	EXE
GX53-14C037-AH.vbf	Jaguar F-Type (X152)	SPCM - Secondary Powertrain Control Module	EXE
GX53-14C037-AL.vbf	Jaguar F-Type (X152)	SPCM - Secondary Powertrain Control Module	EXE
GX53-14C037-BAF.vbf	Jaguar F-Type (X152)	SPCM - Secondary Powertrain Control Module	EXE
GX53-14C037-BAJ.vbf	Jaguar F-Type (X152)	SPCM - Secondary Powertrain Control Module	EXE
GX53-14C037-BH.vbf	Jaguar F-Type (X152)	SPCM - Secondary Powertrain Control Module	EXE
GX53-14C037-BL.vbf	Jaguar F-Type (X152)	SPCM - Secondary Powertrain Control Module	EXE
GX53-14C037-CAF.vbf	Jaguar F-Type (X152)	SPCM - Secondary Powertrain Control Module	EXE
GX53-14C037-CAJ.vbf	Jaguar F-Type (X152)	SPCM - Secondary Powertrain Control Module	EXE
GX53-14C037-CH.vbf	Jaguar F-Type (X152)	SPCM - Secondary Powertrain Control Module	EXE
GX53-14C037-CL.vbf	Jaguar F-Type (X152)	SPCM - Secondary Powertrain Control Module	EXE
GX53-14C037-DAF.vbf	Jaguar F-Type (X152)	SPCM - Secondary Powertrain Control Module	EXE
GX53-14C037-DAJ.vbf	Jaguar F-Type (X152)	SPCM - Secondary Powertrain Control Module	EXE
GX53-14C037-DH.vbf	Jaguar F-Type (X152)	SPCM - Secondary Powertrain Control Module	EXE
GX53-14C037-DL.vbf	Jaguar F-Type (X152)	SPCM - Secondary Powertrain Control Module	EXE
GX53-14C037-EAF.vbf	Jaguar F-Type (X152)	SPCM - Secondary Powertrain Control Module	EXE
GX53-14C037-EAJ.vbf	Jaguar F-Type (X152)	SPCM - Secondary Powertrain Control Module	EXE
GX53-14C037-EH.vbf	Jaguar F-Type (X152)	SPCM - Secondary Powertrain Control Module	EXE
GX53-14C037-EL.vbf	Jaguar F-Type (X152)	SPCM - Secondary Powertrain Control Module	EXE
GX53-14C037-FAF.vbf	Jaguar F-Type (X152)	SPCM - Secondary Powertrain Control Module	EXE
GX53-14C037-FAJ.vbf	Jaguar F-Type (X152)	SPCM - Secondary Powertrain Control Module	EXE
GX53-14C037-FH.vbf	Jaguar F-Type (X152)	SPCM - Secondary Powertrain Control Module	EXE
GX53-14C037-FL.vbf	Jaguar F-Type (X152)	SPCM - Secondary Powertrain Control Module	EXE
GX53-14C037-GAF.vbf	Jaguar F-Type (X152)	SPCM - Secondary Powertrain Control Module	EXE
GX53-14C037-GAJ.vbf	Jaguar F-Type (X152)	SPCM - Secondary Powertrain Control Module	EXE
GX53-14C037-GH.vbf	Jaguar F-Type (X152)	SPCM - Secondary Powertrain Control Module	EXE
GX53-14C037-GL.vbf	Jaguar F-Type (X152)	SPCM - Secondary Powertrain Control Module	EXE
GX53-14C037-HH.vbf	Jaguar F-Type (X152)	SPCM - Secondary Powertrain Control Module	EXE
GX53-14C037-HL.vbf	Jaguar F-Type (X152)	SPCM - Secondary Powertrain Control Module	EXE
GX53-14C037-JAF.vbf	Jaguar F-Type (X152)	SPCM - Secondary Powertrain Control Module	EXE
GX53-14C037-JAJ.vbf	Jaguar F-Type (X152)	SPCM - Secondary Powertrain Control Module	EXE
GX53-14C037-JH.vbf	Jaguar F-Type (X152)	SPCM - Secondary Powertrain Control Module	EXE
GX53-14C037-JL.vbf	Jaguar F-Type (X152)	SPCM - Secondary Powertrain Control Module	EXE
GX53-14C037-KAF.vbf	Jaguar F-Type (X152)	SPCM - Secondary Powertrain Control Module	EXE
GX53-14C037-KAJ.vbf	Jaguar F-Type (X152)	SPCM - Secondary Powertrain Control Module	EXE
GX53-14C037-KH.vbf	Jaguar F-Type (X152)	SPCM - Secondary Powertrain Control Module	EXE
GX53-14C037-KL.vbf	Jaguar F-Type (X152)	SPCM - Secondary Powertrain Control Module	EXE
GX53-14C037-LAF.vbf	Jaguar F-Type (X152)	SPCM - Secondary Powertrain Control Module	EXE
GX53-14C037-LAJ.vbf	Jaguar F-Type (X152)	SPCM - Secondary Powertrain Control Module	EXE
GX53-14C037-LH.vbf	Jaguar F-Type (X152)	SPCM - Secondary Powertrain Control Module	EXE
GX53-14C037-LL.vbf	Jaguar F-Type (X152)	SPCM - Secondary Powertrain Control Module	EXE
GX53-14C037-MAF.vbf	Jaguar F-Type (X152)	SPCM - Secondary Powertrain Control Module	EXE
GX53-14C037-MAJ.vbf	Jaguar F-Type (X152)	SPCM - Secondary Powertrain Control Module	EXE
GX53-14C037-NAF.vbf	Jaguar F-Type (X152)	SPCM - Secondary Powertrain Control Module	EXE
GX53-14C037-NAJ.vbf	Jaguar F-Type (X152)	SPCM - Secondary Powertrain Control Module	EXE
GX53-14C037-NAK.vbf	Jaguar F-Type (X152)	SPCM - Secondary Powertrain Control Module	DATA
GX53-14C037-NH.vbf	Jaguar F-Type (X152)	SPCM - Secondary Powertrain Control Module	EXE
GX53-14C037-NL.vbf	Jaguar F-Type (X152)	SPCM - Secondary Powertrain Control Module	EXE
GX53-14C037-PAF.vbf	Jaguar F-Type (X152)	SPCM - Secondary Powertrain Control Module	EXE

File name	Vehicle line (indicative)	Module (ECU)	Type
GX53-14C037-PAJ.vbf	Jaguar F-Type (X152)	SPCM - Secondary Powertrain Control Module	EXE
GX53-14C037-PAK.vbf	Jaguar F-Type (X152)	SPCM - Secondary Powertrain Control Module	DATA
GX53-14C037-PH.vbf	Jaguar F-Type (X152)	SPCM - Secondary Powertrain Control Module	EXE
GX53-14C037-PL.vbf	Jaguar F-Type (X152)	SPCM - Secondary Powertrain Control Module	EXE
GX53-14C037-RAF.vbf	Jaguar F-Type (X152)	SPCM - Secondary Powertrain Control Module	EXE
GX53-14C037-RAJ.vbf	Jaguar F-Type (X152)	SPCM - Secondary Powertrain Control Module	EXE
GX53-14C037-RH.vbf	Jaguar F-Type (X152)	SPCM - Secondary Powertrain Control Module	EXE
GX53-14C037-RL.vbf	Jaguar F-Type (X152)	SPCM - Secondary Powertrain Control Module	EXE
GX53-14C037-SAF.vbf	Jaguar F-Type (X152)	SPCM - Secondary Powertrain Control Module	EXE
GX53-14C037-SAJ.vbf	Jaguar F-Type (X152)	SPCM - Secondary Powertrain Control Module	EXE
GX53-14C037-SH.vbf	Jaguar F-Type (X152)	SPCM - Secondary Powertrain Control Module	EXE
GX53-14C037-SL.vbf	Jaguar F-Type (X152)	SPCM - Secondary Powertrain Control Module	EXE
GX53-14C037-TAF.vbf	Jaguar F-Type (X152)	SPCM - Secondary Powertrain Control Module	EXE
GX53-14C037-TAJ.vbf	Jaguar F-Type (X152)	SPCM - Secondary Powertrain Control Module	EXE
GX53-14C037-TH.vbf	Jaguar F-Type (X152)	SPCM - Secondary Powertrain Control Module	EXE
GX53-14C037-TL.vbf	Jaguar F-Type (X152)	SPCM - Secondary Powertrain Control Module	EXE
GX53-14C037-UAF.vbf	Jaguar F-Type (X152)	SPCM - Secondary Powertrain Control Module	EXE
GX53-14C037-UAJ.vbf	Jaguar F-Type (X152)	SPCM - Secondary Powertrain Control Module	EXE
GX53-14C037-UH.vbf	Jaguar F-Type (X152)	SPCM - Secondary Powertrain Control Module	EXE
GX53-14C037-UL.vbf	Jaguar F-Type (X152)	SPCM - Secondary Powertrain Control Module	EXE
GX53-14C037-VAF.vbf	Jaguar F-Type (X152)	SPCM - Secondary Powertrain Control Module	EXE
GX53-14C037-VAJ.vbf	Jaguar F-Type (X152)	SPCM - Secondary Powertrain Control Module	EXE
GX53-14C037-VH.vbf	Jaguar F-Type (X152)	SPCM - Secondary Powertrain Control Module	EXE
GX53-14C037-VL.vbf	Jaguar F-Type (X152)	SPCM - Secondary Powertrain Control Module	EXE
GX53-14C037-XAF.vbf	Jaguar F-Type (X152)	SPCM - Secondary Powertrain Control Module	EXE
GX53-14C037-XAJ.vbf	Jaguar F-Type (X152)	SPCM - Secondary Powertrain Control Module	EXE
GX53-14C037-YAF.vbf	Jaguar F-Type (X152)	SPCM - Secondary Powertrain Control Module	EXE
GX53-14C037-YAJ.vbf	Jaguar F-Type (X152)	SPCM - Secondary Powertrain Control Module	EXE
GX53-14C037-YH.vbf	Jaguar F-Type (X152)	SPCM - Secondary Powertrain Control Module	EXE
GX53-14C037-YL.vbf	Jaguar F-Type (X152)	SPCM - Secondary Powertrain Control Module	EXE
GX53-14C037-YM.vbf	Jaguar F-Type (X152)	SPCM - Secondary Powertrain Control Module	DATA
GX53-14C037-ZAF.vbf	Jaguar F-Type (X152)	SPCM - Secondary Powertrain Control Module	EXE
GX53-14C037-ZAG.vbf	Jaguar F-Type (X152)	SPCM - Secondary Powertrain Control Module	EXE
GX53-14C037-ZAJ.vbf	Jaguar F-Type (X152)	SPCM - Secondary Powertrain Control Module	EXE
GX53-14C037-ZH.vbf	Jaguar F-Type (X152)	SPCM - Secondary Powertrain Control Module	EXE
GX53-14C037-ZL.vbf	Jaguar F-Type (X152)	SPCM - Secondary Powertrain Control Module	EXE
GX53-14C037-ZM.vbf	Jaguar F-Type (X152)	SPCM - Secondary Powertrain Control Module	DATA
GX53-14C039-AB.vbf	Jaguar F-Type (X152)	SPCM - Secondary Powertrain Control Module	SBL
GX53-14C060-AC.vbf	Jaguar F-Type (X152)	FCDIM - Front Control/Display Interface Module	EXE
GX53-14C060-AD.vbf	Jaguar F-Type (X152)	FCDIM - Front Control/Display Interface Module	EXE
GX53-14C060-AE.vbf	Jaguar F-Type (X152)	FCDIM - Front Control/Display Interface Module	EXE
GX53-14C060-AF.vbf	Jaguar F-Type (X152)	FCDIM - Front Control/Display Interface Module	EXE
GX53-14C060-AG.vbf	Jaguar F-Type (X152)	FCDIM - Front Control/Display Interface Module	EXE
GX53-14C060-AH.vbf	Jaguar F-Type (X152)	FCDIM - Front Control/Display Interface Module	EXE
GX53-14C060-AJ.vbf	Jaguar F-Type (X152)	FCDIM - Front Control/Display Interface Module	EXE
GX53-14C061-AC.vbf	Jaguar F-Type (X152)	FCDIM - Front Control/Display Interface Module	DATA
GX53-14C061-AD.vbf	Jaguar F-Type (X152)	FCDIM - Front Control/Display Interface Module	DATA
GX53-14C061-AE.vbf	Jaguar F-Type (X152)	FCDIM - Front Control/Display Interface Module	DATA
GX53-14C061-AF.vbf	Jaguar F-Type (X152)	FCDIM - Front Control/Display Interface Module	DATA
GX53-14C061-AG.vbf	Jaguar F-Type (X152)	FCDIM - Front Control/Display Interface Module	DATA
GX53-14C061-AH.vbf	Jaguar F-Type (X152)	FCDIM - Front Control/Display Interface Module	DATA
GX53-14C061-AJ.vbf	Jaguar F-Type (X152)	FCDIM - Front Control/Display Interface Module	DATA
GX53-14C063-AA.vbf	Jaguar F-Type (X152)	FCDIM - Front Control/Display Interface Module	SBL
GX53-14C064-AC.vbf	Jaguar F-Type (X152)	DDM - Driver Front Door Module	EXE
GX53-14C065-AC.vbf	Jaguar F-Type (X152)	DDM - Driver Front Door Module	DATA
GX53-14C067-AA.vbf	Jaguar F-Type (X152)	DDM - Driver Front Door Module	SBL
GX53-14C088-CE.vbf	Jaguar F-Type (X152)	IPC - Instrument Panel Cluster (IPC) Control Module	EXE
GX53-14C091-AD.vbf	Jaguar F-Type (X152)	PAM - Parking Assist Control Module	DATA
GX53-14C091-AF.vbf	Jaguar F-Type (X152)	PAM - Parking Assist Control Module	DATA
GX53-14C098-AE.vbf	Jaguar F-Type (X152)	RCM - Restraints Control Module	DATA
GX53-14C098-BE.vbf	Jaguar F-Type (X152)	RCM - Restraints Control Module	DATA
GX53-14C105-BE.vbf	Jaguar F-Type (X152)	TMC Traffic Message Channel Module	DATA
GX53-14C105-BF.vbf	Jaguar F-Type (X152)	TMC Traffic Message Channel Module	DATA
GX53-14C108-AC.vbf	Jaguar F-Type (X152)	PDM - Passenger Front Door Module	EXE
GX53-14C109-AC.vbf	Jaguar F-Type (X152)	PDM - Passenger Front Door Module	DATA
GX53-14C111-AA.vbf	Jaguar F-Type (X152)	PDM - Passenger Front Door Module	SBL
GX53-14C121-AB.vbf	Jaguar F-Type (X152)	RGTM - Rear Gate / Trunk Module	EXE
GX53-14C121-AC.vbf	Jaguar F-Type (X152)	RGTM - Rear Gate / Trunk Module	EXE
GX53-14C122-AB.vbf	Jaguar F-Type (X152)	RGTM - Rear Gate / Trunk Module	DATA
GX53-14C122-AC.vbf	Jaguar F-Type (X152)	RGTM - Rear Gate / Trunk Module	DATA
GX53-14C124-AA.vbf	Jaguar F-Type (X152)	RGTM - Rear Gate / Trunk Module	SBL
GX53-14C152-AB.vbf	Jaguar F-Type (X152)	TPM - Tire Pressure Monitor Module	DATA
GX53-14C152-AC.vbf	Jaguar F-Type (X152)	TPM - Tire Pressure Monitor Module	DATA
GX53-14C169-AA.vbf	Jaguar F-Type (X152)	PBM - Park Brake Control Module	EXE
GX53-14C185-AC.vbf	Jaguar F-Type (X152)	BCM - Body Control Module	DATA
GX53-14C185-AD.vbf	Jaguar F-Type (X152)	BCM - Body Control Module	DATA

File name	Vehicle line (indicative)	Module (ECU)	Type
GX53-14C185-AG.VBF	Jaguar F-Type (X152)	BCM - Body Control Module	DATA
GX53-14C204-AAB.vbf	Jaguar F-Type (X152)	PCM - Powertrain Control Module	EXE
GX53-14C204-AAC.vbf	Jaguar F-Type (X152)	PCM - Powertrain Control Module	EXE
GX53-14C204-AAD.vbf	Jaguar F-Type (X152)	PCM - Powertrain Control Module	EXE
GX53-14C204-AAE.vbf	Jaguar F-Type (X152)	PCM - Powertrain Control Module	EXE
GX53-14C204-AAF.vbf	Jaguar F-Type (X152)	PCM - Powertrain Control Module	EXE
GX53-14C204-AAG.vbf	Jaguar F-Type (X152)	PCM - Powertrain Control Module	EXE
GX53-14C204-AAH.vbf	Jaguar F-Type (X152)	PCM - Powertrain Control Module	EXE
GX53-14C204-ACA.vbf	Jaguar F-Type (X152)	PCM - Powertrain Control Module	EXE
GX53-14C204-ACB.vbf	Jaguar F-Type (X152)	PCM - Powertrain Control Module	EXE
GX53-14C204-ACC.vbf	Jaguar F-Type (X152)	PCM - Powertrain Control Module	EXE
GX53-14C204-ACD.vbf	Jaguar F-Type (X152)	PCM - Powertrain Control Module	EXE
GX53-14C204-ACE.vbf	Jaguar F-Type (X152)	PCM - Powertrain Control Module	EXE
GX53-14C204-ADA.vbf	Jaguar F-Type (X152)	PCM - Powertrain Control Module	EXE
GX53-14C204-ADB.vbf	Jaguar F-Type (X152)	PCM - Powertrain Control Module	EXE
GX53-14C204-ADC.vbf	Jaguar F-Type (X152)	PCM - Powertrain Control Module	EXE
GX53-14C204-ADD.vbf	Jaguar F-Type (X152)	PCM - Powertrain Control Module	EXE
GX53-14C204-ADE.vbf	Jaguar F-Type (X152)	PCM - Powertrain Control Module	EXE
GX53-14C204-ATB.vbf	Jaguar F-Type (X152)	PCM - Powertrain Control Module	EXE
GX53-14C204-ATC.vbf	Jaguar F-Type (X152)	PCM - Powertrain Control Module	EXE
GX53-14C204-ATD.vbf	Jaguar F-Type (X152)	PCM - Powertrain Control Module	EXE
GX53-14C204-ATE.vbf	Jaguar F-Type (X152)	PCM - Powertrain Control Module	EXE
GX53-14C204-ATF.vbf	Jaguar F-Type (X152)	PCM - Powertrain Control Module	EXE
GX53-14C204-ATG.vbf	Jaguar F-Type (X152)	PCM - Powertrain Control Module	EXE
GX53-14C204-BAB.vbf	Jaguar F-Type (X152)	PCM - Powertrain Control Module	EXE
GX53-14C204-BAC.vbf	Jaguar F-Type (X152)	PCM - Powertrain Control Module	EXE
GX53-14C204-BAD.vbf	Jaguar F-Type (X152)	PCM - Powertrain Control Module	EXE
GX53-14C204-BAE.vbf	Jaguar F-Type (X152)	PCM - Powertrain Control Module	EXE
GX53-14C204-BAF.vbf	Jaguar F-Type (X152)	PCM - Powertrain Control Module	EXE
GX53-14C204-BCA.vbf	Jaguar F-Type (X152)	PCM - Powertrain Control Module	EXE
GX53-14C204-BCB.vbf	Jaguar F-Type (X152)	PCM - Powertrain Control Module	EXE
GX53-14C204-BCC.vbf	Jaguar F-Type (X152)	PCM - Powertrain Control Module	EXE
GX53-14C204-BCD.vbf	Jaguar F-Type (X152)	PCM - Powertrain Control Module	EXE
GX53-14C204-BEA.vbf	Jaguar F-Type (X152)	PCM - Powertrain Control Module	EXE
GX53-14C204-BEB.vbf	Jaguar F-Type (X152)	PCM - Powertrain Control Module	EXE
GX53-14C204-BEC.vbf	Jaguar F-Type (X152)	PCM - Powertrain Control Module	EXE
GX53-14C204-BED.vbf	Jaguar F-Type (X152)	PCM - Powertrain Control Module	EXE
GX53-14C204-BTB.vbf	Jaguar F-Type (X152)	PCM - Powertrain Control Module	EXE
GX53-14C204-BTC.vbf	Jaguar F-Type (X152)	PCM - Powertrain Control Module	EXE
GX53-14C204-BTD.vbf	Jaguar F-Type (X152)	PCM - Powertrain Control Module	EXE
GX53-14C204-BTE.vbf	Jaguar F-Type (X152)	PCM - Powertrain Control Module	EXE
GX53-14C204-BTF.vbf	Jaguar F-Type (X152)	PCM - Powertrain Control Module	EXE
GX53-14C204-CAB.vbf	Jaguar F-Type (X152)	PCM - Powertrain Control Module	EXE
GX53-14C204-CAC.vbf	Jaguar F-Type (X152)	PCM - Powertrain Control Module	EXE
GX53-14C204-CAD.vbf	Jaguar F-Type (X152)	PCM - Powertrain Control Module	EXE
GX53-14C204-CAE.vbf	Jaguar F-Type (X152)	PCM - Powertrain Control Module	EXE
GX53-14C204-CCA.vbf	Jaguar F-Type (X152)	PCM - Powertrain Control Module	EXE
GX53-14C204-CCB.vbf	Jaguar F-Type (X152)	PCM - Powertrain Control Module	EXE
GX53-14C204-CCC.vbf	Jaguar F-Type (X152)	PCM - Powertrain Control Module	EXE
GX53-14C204-CTB.vbf	Jaguar F-Type (X152)	PCM - Powertrain Control Module	EXE
GX53-14C204-CTC.vbf	Jaguar F-Type (X152)	PCM - Powertrain Control Module	EXE
GX53-14C204-CTD.vbf	Jaguar F-Type (X152)	PCM - Powertrain Control Module	EXE
GX53-14C204-CTE.vbf	Jaguar F-Type (X152)	PCM - Powertrain Control Module	EXE
GX53-14C204-EAA.vbf	Jaguar F-Type (X152)	PCM - Powertrain Control Module	EXE
GX53-14C204-EAB.vbf	Jaguar F-Type (X152)	PCM - Powertrain Control Module	EXE
GX53-14C204-EAC.vbf	Jaguar F-Type (X152)	PCM - Powertrain Control Module	EXE
GX53-14C204-EAD.vbf	Jaguar F-Type (X152)	PCM - Powertrain Control Module	EXE
GX53-14C204-ECA.vbf	Jaguar F-Type (X152)	PCM - Powertrain Control Module	EXE
GX53-14C204-ECB.vbf	Jaguar F-Type (X152)	PCM - Powertrain Control Module	EXE
GX53-14C204-ECC.vbf	Jaguar F-Type (X152)	PCM - Powertrain Control Module	EXE
GX53-14C204-ECD.vbf	Jaguar F-Type (X152)	PCM - Powertrain Control Module	EXE
GX53-14C204-ETB.vbf	Jaguar F-Type (X152)	PCM - Powertrain Control Module	EXE
GX53-14C204-ETC.vbf	Jaguar F-Type (X152)	PCM - Powertrain Control Module	EXE
GX53-14C204-ETD.vbf	Jaguar F-Type (X152)	PCM - Powertrain Control Module	EXE
GX53-14C204-ETE.vbf	Jaguar F-Type (X152)	PCM - Powertrain Control Module	EXE
GX53-14C204-ETF.vbf	Jaguar F-Type (X152)	PCM - Powertrain Control Module	EXE
GX53-14C204-TAA.vbf	Jaguar F-Type (X152)	PCM - Powertrain Control Module	EXE
GX53-14C204-TAB.vbf	Jaguar F-Type (X152)	PCM - Powertrain Control Module	EXE
GX53-14C204-TAC.vbf	Jaguar F-Type (X152)	PCM - Powertrain Control Module	EXE
GX53-14C204-TAD.vbf	Jaguar F-Type (X152)	PCM - Powertrain Control Module	EXE
GX53-14C204-TAE.vbf	Jaguar F-Type (X152)	PCM - Powertrain Control Module	EXE
GX53-14C204-TCA.vbf	Jaguar F-Type (X152)	PCM - Powertrain Control Module	EXE
GX53-14C204-TCB.vbf	Jaguar F-Type (X152)	PCM - Powertrain Control Module	EXE
GX53-14C204-TCC.vbf	Jaguar F-Type (X152)	PCM - Powertrain Control Module	EXE
GX53-14C204-TEA.vbf	Jaguar F-Type (X152)	PCM - Powertrain Control Module	EXE
GX53-14C204-TEB.vbf	Jaguar F-Type (X152)	PCM - Powertrain Control Module	EXE

File name	Vehicle line (indicative)	Module (ECU)	Type
GX53-14C204-TEC.vbf	Jaguar F-Type (X152)	PCM - Powertrain Control Module	EXE
GX53-14C204-TTB.vbf	Jaguar F-Type (X152)	PCM - Powertrain Control Module	EXE
GX53-14C204-TTC.vbf	Jaguar F-Type (X152)	PCM - Powertrain Control Module	EXE
GX53-14C204-TTD.vbf	Jaguar F-Type (X152)	PCM - Powertrain Control Module	EXE
GX53-14C204-TTE.vbf	Jaguar F-Type (X152)	PCM - Powertrain Control Module	EXE
GX53-14C204-UAB.vbf	Jaguar F-Type (X152)	PCM - Powertrain Control Module	EXE
GX53-14C204-UAC.vbf	Jaguar F-Type (X152)	PCM - Powertrain Control Module	EXE
GX53-14C204-UAD.vbf	Jaguar F-Type (X152)	PCM - Powertrain Control Module	EXE
GX53-14C204-UAE.vbf	Jaguar F-Type (X152)	PCM - Powertrain Control Module	EXE
GX53-14C204-UCA.vbf	Jaguar F-Type (X152)	PCM - Powertrain Control Module	EXE
GX53-14C204-UCB.vbf	Jaguar F-Type (X152)	PCM - Powertrain Control Module	EXE
GX53-14C204-UCC.vbf	Jaguar F-Type (X152)	PCM - Powertrain Control Module	EXE
GX53-14C204-UEA.vbf	Jaguar F-Type (X152)	PCM - Powertrain Control Module	EXE
GX53-14C204-UEB.vbf	Jaguar F-Type (X152)	PCM - Powertrain Control Module	EXE
GX53-14C204-UEC.vbf	Jaguar F-Type (X152)	PCM - Powertrain Control Module	EXE
GX53-14C204-UTB.vbf	Jaguar F-Type (X152)	PCM - Powertrain Control Module	EXE
GX53-14C204-UTC.vbf	Jaguar F-Type (X152)	PCM - Powertrain Control Module	EXE
GX53-14C204-UTD.vbf	Jaguar F-Type (X152)	PCM - Powertrain Control Module	EXE
GX53-14C204-UTE.vbf	Jaguar F-Type (X152)	PCM - Powertrain Control Module	EXE
GX53-14C204-XAB.vbf	Jaguar F-Type (X152)	PCM - Powertrain Control Module	EXE
GX53-14C204-XAC.vbf	Jaguar F-Type (X152)	PCM - Powertrain Control Module	EXE
GX53-14C204-XAD.vbf	Jaguar F-Type (X152)	PCM - Powertrain Control Module	EXE
GX53-14C204-XAE.vbf	Jaguar F-Type (X152)	PCM - Powertrain Control Module	EXE
GX53-14C204-XAF.vbf	Jaguar F-Type (X152)	PCM - Powertrain Control Module	EXE
GX53-14C204-XAG.vbf	Jaguar F-Type (X152)	PCM - Powertrain Control Module	EXE
GX53-14C204-XAH.vbf	Jaguar F-Type (X152)	PCM - Powertrain Control Module	EXE
GX53-14C204-XCA.vbf	Jaguar F-Type (X152)	PCM - Powertrain Control Module	EXE
GX53-14C204-XCB.vbf	Jaguar F-Type (X152)	PCM - Powertrain Control Module	EXE
GX53-14C204-XCC.vbf	Jaguar F-Type (X152)	PCM - Powertrain Control Module	EXE
GX53-14C204-XCD.vbf	Jaguar F-Type (X152)	PCM - Powertrain Control Module	EXE
GX53-14C204-XCE.vbf	Jaguar F-Type (X152)	PCM - Powertrain Control Module	EXE
GX53-14C204-XTB.vbf	Jaguar F-Type (X152)	PCM - Powertrain Control Module	EXE
GX53-14C204-XTC.vbf	Jaguar F-Type (X152)	PCM - Powertrain Control Module	EXE
GX53-14C204-XTD.vbf	Jaguar F-Type (X152)	PCM - Powertrain Control Module	EXE
GX53-14C204-XTE.vbf	Jaguar F-Type (X152)	PCM - Powertrain Control Module	EXE
GX53-14C204-XTF.vbf	Jaguar F-Type (X152)	PCM - Powertrain Control Module	EXE
GX53-14C204-XTG.vbf	Jaguar F-Type (X152)	PCM - Powertrain Control Module	EXE
GX53-14C217-AB.vbf	Jaguar F-Type (X152)	PSCM - Power Steering Control Module	EXE
GX53-14C217-AD.vbf	Jaguar F-Type (X152)	PSCM - Power Steering Control Module	EXE
GX53-14C218-AB.vbf	Jaguar F-Type (X152)	PSCM - Power Steering Control Module	DATA
GX53-14C218-BB.vbf	Jaguar F-Type (X152)	PSCM - Power Steering Control Module	DATA
GX53-14C218-BD.vbf	Jaguar F-Type (X152)	PSCM - Power Steering Control Module	DATA
GX53-14C218-CB.vbf	Jaguar F-Type (X152)	PSCM - Power Steering Control Module	DATA
GX53-14C218-DA.vbf	Jaguar F-Type (X152)	PSCM - Power Steering Control Module	DATA
GX53-14C218-EA.vbf	Jaguar F-Type (X152)	PSCM - Power Steering Control Module	DATA
GX53-14C218-EB.vbf	Jaguar F-Type (X152)	PSCM - Power Steering Control Module	DATA
GX53-14C302-AR.iso	Jaguar F-Type (X152)	-	-
GX53-14C302-BS.iso	Jaguar F-Type (X152)	-	-
GX53-14C320-AB.vbf	Check in SDD (unconfirmed)	PDM - Passeng Front Door Module	SIGCFG
GX53-14C321-AB.vbf	Check in SDD (unconfirmed)	DDM - Driver Front Door Module	SIGCFG
GX53-14C386-AA.vbf	Jaguar F-Type (X152)	PSCM - Power Steering Control Module	SIGCFG
GX53-14C407-AC.vbf	Jaguar F-Type (X152)	RCM - Restraints Control Module	SIGCFG
GX53-14C527-AA.vbf	Jaguar F-Type (X152)	Not specified	DATA
GX53-14C527-BA.vbf	Jaguar F-Type (X152)	Not specified	DATA
GX53-14C527-BB.vbf	Jaguar F-Type (X152)	Not specified	DATA
GX53-14C534-AA.vbf	Jaguar F-Type (X152)	FCIM - Front Controls Interface Module	SIGCFG
GX53-14C535-AB.vbf	Jaguar F-Type (X152)	FCIM - Front Controls Interface Module	EXE
GX53-14C535-AC.vbf	Jaguar F-Type (X152)	FCIM - Front Controls Interface Module	EXE
GX53-14C535-AD.vbf	Jaguar F-Type (X152)	FCIM - Front Controls Interface Module	EXE
GX53-14C536-AB.vbf	Jaguar F-Type (X152)	FCIM - Front Controls Interface Module	DATA
GX53-14C536-AC.vbf	Jaguar F-Type (X152)	FCIM - Front Controls Interface Module	DATA
GX53-14C536-AD.vbf	Jaguar F-Type (X152)	FCIM - Front Controls Interface Module	DATA
GX53-14C548-AB.vbf	Jaguar F-Type (X152)	PSM - Passenger Front Seat Module	EXE
GX53-14C549-AB.vbf	Range Rover Sport (L494)	PSM - Passenger Front Seat Module	DATA
GX53-14C549-BB.vbf	Range Rover Sport (L494)	PSM - Passenger Front Seat Module	DATA
GX53-14C549-CB.vbf	Range Rover Sport (L494)	PSM - Passenger Front Seat Module	DATA
GX53-14C549-DB.vbf	Range Rover Sport (L494)	PSM - Passenger Front Seat Module	DATA
GX53-14C560-AB.vbf	Jaguar F-Type (X152)	GSM - Gear Shift Module	SIGCFG
GX53-14C561-AC.vbf	Range Rover Sport (L494)	GSM - Gear Shift Module	EXE
GX53-14C609-AB.vbf	Jaguar F-Type (X152)	PSCM - Power Steering Control Module	DATA
GX53-14C609-AD.vbf	Jaguar F-Type (X152)	PSCM - Power Steering Control Module	DATA
GX53-14C621-AB.vbf	Jaguar F-Type (X152)	FCDIM - Front Control/Display Interface Module	EXE
GX53-14C653-AE.vbf	Jaguar F-Type (X152)	ACM - Audio Front Control Module	DATA
GX53-14C653-AJ.vbf	Jaguar F-Type (X152)	ACM - Audio Front Control Module	DATA
GX53-14C653-AK.vbf	Jaguar F-Type (X152)	ACM - Audio Front Control Module	DATA
GX53-14C653-AL.vbf	Jaguar F-Type (X152)	ACM - Audio Front Control Module	DATA

File name	Vehicle line (indicative)	Module (ECU)	Type
GX53-14C653-AM.vbf	Jaguar F-Type (X152)	ACM - Audio Front Control Module	DATA
GX53-14D023-AB.vbf	Jaguar F-Type (X152)	ATCM - All Terrain Control Module	SIGCFG
GX53-14D024-AF.vbf	Jaguar F-Type (X152)	ATCM - All Terrain Control Module	EXE
GX53-14D024-AG.vbf	Jaguar F-Type (X152)	ATCM - All Terrain Control Module	EXE
GX53-14D196-AA.vbf	Jaguar F-Type (X152)	IPMA - Image Processing Module A	EXE
GX53-14D197-AA.vbf	Jaguar F-Type (X152)	IPMA - Image Processing Module A	DATA
GX53-14D198-AA.vbf	Jaguar F-Type (X152)	IPMA - Image Processing Module A	SBL
GX53-14D479-AA.vbf	Jaguar F-Type (X152)	IPMB - Image Processing Module B	DATA
GX53-14D480-AC.vbf	Jaguar F-Type (X152)	IPMB - Image Processing Module B	EXE
GX53-14D480-AD.vbf	Jaguar F-Type (X152)	IPMB - Image Processing Module B	EXE
GX53-14D485-AB.vbf	Jaguar F-Type (X152)	IPMB - Image Processing Module B	DATA
GX53-14D485-AC.vbf	Jaguar F-Type (X152)	IPMB - Image Processing Module B	DATA
GX53-14D519-AD.vbf	Jaguar F-Type (X152)	HVAC - HVAC Control Module	EXE
GX53-14D520-AC.vbf	Jaguar F-Type (X152)	HVAC - HVAC Control Module	DATA
GX53-14D520-AD.vbf	Jaguar F-Type (X152)	HVAC - HVAC Control Module	DATA
GX53-14D520-AE.vbf	Jaguar F-Type (X152)	HVAC - HVAC Control Module	DATA
GX53-14D520-BD.vbf	Jaguar F-Type (X152)	HVAC - HVAC Control Module	DATA
GX53-14E093-BA.vbf	Jaguar F-Type (X152)	CHCM - Chassis Control Module	EXE
GX53-14E093-BB.vbf	Jaguar F-Type (X152)	CHCM - Chassis Control Module	EXE
GX53-14E093-BC.vbf	Jaguar F-Type (X152)	CHCM - Chassis Control Module	EXE
GX53-14E093-BD.vbf	Jaguar F-Type (X152)	CHCM - Chassis Control Module	EXE
GX53-14E094-DAD.vbf	Jaguar F-Type (X152)	CHCM - Chassis Control Module	EXE
GX53-14E094-DAE.vbf	Jaguar F-Type (X152)	CHCM - Chassis Control Module	EXE
GX53-14E094-DBD.vbf	Jaguar F-Type (X152)	CHCM - Chassis Control Module	EXE
GX53-14E094-DBE.vbf	Jaguar F-Type (X152)	CHCM - Chassis Control Module	EXE
GX53-14E094-DCD.vbf	Jaguar F-Type (X152)	CHCM - Chassis Control Module	EXE
GX53-14E094-DCE.vbf	Jaguar F-Type (X152)	CHCM - Chassis Control Module	EXE
GX53-14E094-DCF.vbf	Jaguar F-Type (X152)	CHCM - Chassis Control Module	EXE
GX53-14E094-DDD.vbf	Jaguar F-Type (X152)	CHCM - Chassis Control Module	EXE
GX53-14E094-DDE.vbf	Jaguar F-Type (X152)	CHCM - Chassis Control Module	EXE
GX53-14E094-DDF.vbf	Jaguar F-Type (X152)	CHCM - Chassis Control Module	EXE
GX53-14E094-DED.vbf	Jaguar F-Type (X152)	CHCM - Chassis Control Module	EXE
GX53-14E094-DEE.vbf	Jaguar F-Type (X152)	CHCM - Chassis Control Module	EXE
GX53-14E094-DEF.vbf	Jaguar F-Type (X152)	CHCM - Chassis Control Module	EXE
GX53-14E094-DFD.vbf	Jaguar F-Type (X152)	CHCM - Chassis Control Module	EXE
GX53-14E094-DFE.vbf	Jaguar F-Type (X152)	CHCM - Chassis Control Module	EXE
GX53-14E094-DGD.vbf	Jaguar F-Type (X152)	CHCM - Chassis Control Module	EXE
GX53-14E094-DGE.vbf	Jaguar F-Type (X152)	CHCM - Chassis Control Module	EXE
GX53-14E094-DHD.vbf	Jaguar F-Type (X152)	CHCM - Chassis Control Module	EXE
GX53-14E094-DHE.vbf	Jaguar F-Type (X152)	CHCM - Chassis Control Module	EXE
GX53-14E094-DHF.vbf	Jaguar F-Type (X152)	CHCM - Chassis Control Module	EXE
GX53-14E094-DJD.vbf	Jaguar F-Type (X152)	CHCM - Chassis Control Module	EXE
GX53-14E094-DJE.vbf	Jaguar F-Type (X152)	CHCM - Chassis Control Module	EXE
GX53-14E094-DJF.vbf	Jaguar F-Type (X152)	CHCM - Chassis Control Module	EXE
GX53-14E094-DKD.vbf	Jaguar F-Type (X152)	CHCM - Chassis Control Module	EXE
GX53-14E094-DKE.vbf	Jaguar F-Type (X152)	CHCM - Chassis Control Module	EXE
GX53-14E094-DKF.vbf	Jaguar F-Type (X152)	CHCM - Chassis Control Module	EXE
GX53-14E094-DLB.vbf	Jaguar F-Type (X152)	CHCM - Chassis Control Module	EXE
GX53-14E094-DLC.vbf	Jaguar F-Type (X152)	CHCM - Chassis Control Module	EXE
GX53-14E094-DLD.vbf	Jaguar F-Type (X152)	CHCM - Chassis Control Module	EXE
GX53-14E094-DMB.vbf	Jaguar F-Type (X152)	CHCM - Chassis Control Module	EXE
GX53-14E094-DMC.vbf	Jaguar F-Type (X152)	CHCM - Chassis Control Module	EXE
GX53-14E094-DMD.vbf	Jaguar F-Type (X152)	CHCM - Chassis Control Module	EXE
GX53-14E095-AB.vbf	Jaguar F-Type (X152)	CHCM - Chassis Control Module	SBL
GX53-14F530-AC.vbf	Jaguar F-Type (X152)	GWM - Gateway Module A	EXE
GX53-14F530-AD.vbf	Jaguar F-Type (X152)	GWM - Gateway Module A	EXE
GX53-14F530-AE.vbf	Jaguar F-Type (X152)	GWM - Gateway Module A	EXE
GX53-14F530-AF.vbf	Jaguar F-Type (X152)	GWM - Gateway Module A	EXE
GX53-14F530-AG.vbf	Jaguar F-Type (X152)	GWM - Gateway Module A	EXE
GX53-14F531-AC.vbf	Jaguar F-Type (X152)	GWM - Gateway Module A	DATA
GX53-14F531-AD.vbf	Jaguar F-Type (X152)	GWM - Gateway Module A	DATA
GX53-14F531-AE.vbf	Jaguar F-Type (X152)	GWM - Gateway Module A	DATA
GX53-14F531-AF.vbf	Jaguar F-Type (X152)	GWM - Gateway Module A	DATA
GX53-157012-AB.vbf	Jaguar F-Type (X152)	FTCM - Folding Top Control Module (Master)	EXE
GX53-157013-AA.vbf	Jaguar F-Type (X152)	FTCMB - Folding Top Control Module (Slave)	DATA
GX53-157014-AA.vbf	Jaguar F-Type (X152)	FTCMB - Folding Top Control Module (Slave)	SBL
GX53-70713-KC.vbf	Jaguar F-Type (X152)	TCU - Telematic Control Unit Module	DATA
GX53-70713-LM.vbf	Jaguar F-Type (X152)	TCU - Telematic Control Unit Module	DATA
GX53-70713-MAA.vbf	Jaguar F-Type (X152)	TCU - Telematic Control Unit Module	DATA
GX53-70713-MAB.vbf	Jaguar F-Type (X152)	TCU - Telematic Control Unit Module	DATA
GX53-70713-MN.vbf	Jaguar F-Type (X152)	TCU - Telematic Control Unit Module	DATA
GX53-70713-MP.vbf	Jaguar F-Type (X152)	TCU - Telematic Control Unit Module	DATA
GX53-70713-MS.vbf	Jaguar F-Type (X152)	TCU - Telematic Control Unit Module	DATA
GX53-70713-MT.vbf	Jaguar F-Type (X152)	TCU - Telematic Control Unit Module	DATA
GX53-70713-MV.vbf	Jaguar F-Type (X152)	TCU - Telematic Control Unit Module	DATA
GX53-70713-MX.vbf	Jaguar F-Type (X152)	TCU - Telematic Control Unit Module	DATA

File name	Vehicle line (indicative)	Module (ECU)	Type
GX53-70713-MZ.vbf	Jaguar F-Type (X152)	TCU - Telematic Control Unit Module	DATA
GX53-70713-NAA.vbf	Jaguar F-Type (X152)	TCU - Telematic Control Unit Module	DATA
GX53-70713-NAB.vbf	Jaguar F-Type (X152)	TCU - Telematic Control Unit Module	DATA
GX53-70713-NN.vbf	Jaguar F-Type (X152)	TCU - Telematic Control Unit Module	DATA
GX53-70713-NP.vbf	Jaguar F-Type (X152)	TCU - Telematic Control Unit Module	DATA
GX53-70713-NS.vbf	Jaguar F-Type (X152)	TCU - Telematic Control Unit Module	DATA
GX53-70713-NT.vbf	Jaguar F-Type (X152)	TCU - Telematic Control Unit Module	DATA
GX53-70713-NV.vbf	Jaguar F-Type (X152)	TCU - Telematic Control Unit Module	DATA
GX53-70713-NX.vbf	Jaguar F-Type (X152)	TCU - Telematic Control Unit Module	DATA
GX53-70713-NZ.vbf	Jaguar F-Type (X152)	TCU - Telematic Control Unit Module	DATA
GX53-7J104-BDC.vbf	Jaguar F-Type (X152)	TCM - Transmission Control Module	EXE
GX53-7J104-BDD.vbf	Jaguar F-Type (X152)	TCM - Transmission Control Module	EXE
GX53-7J104-BDE.vbf	Jaguar F-Type (X152)	TCM - Transmission Control Module	EXE
GX53-7J104-BDF.vbf	Jaguar F-Type (X152)	TCM - Transmission Control Module	EXE
GX53-7J104-BDG.vbf	Jaguar F-Type (X152)	TCM - Transmission Control Module	EXE
GX53-7J104-BKC.vbf	Jaguar F-Type (X152)	TCM - Transmission Control Module	EXE
GX53-7J104-BKD.vbf	Jaguar F-Type (X152)	TCM - Transmission Control Module	EXE
GX53-7J104-BKE.vbf	Jaguar F-Type (X152)	TCM - Transmission Control Module	EXE
GX53-7J104-BKF.vbf	Jaguar F-Type (X152)	TCM - Transmission Control Module	EXE
GX53-7J104-BKH.vbf	Jaguar F-Type (X152)	TCM - Transmission Control Module	EXE
GX53-7J104-BMC.vbf	Jaguar F-Type (X152)	TCM - Transmission Control Module	EXE
GX53-7J104-BMD.vbf	Jaguar F-Type (X152)	TCM - Transmission Control Module	EXE
GX53-7J104-BME.vbf	Jaguar F-Type (X152)	TCM - Transmission Control Module	EXE
GX53-7J104-BMF.vbf	Jaguar F-Type (X152)	TCM - Transmission Control Module	EXE
GX53-7J104-BMG.vbf	Jaguar F-Type (X152)	TCM - Transmission Control Module	EXE
GX53-7J104-BNA.vbf	Jaguar F-Type (X152)	TCM - Transmission Control Module	EXE
GX53-7J104-BNB.vbf	Jaguar F-Type (X152)	TCM - Transmission Control Module	EXE
GX5M-14C034-AA.vbf	Range Rover Sport (L494)	Not specified	DATA
GX5M-14C098-BA.vbf	Not specified	RCM - Restraints Control Module	DATA
GX5M-14C098-BB.vbf	Not specified	RCM - Restraints Control Module	DATA
GX5M-14C204-YAA.vbf	Not specified	PCM - Powertrain Control Module	EXE
GX5M-14C204-YAB.vbf	Not specified	PCM - Powertrain Control Module	EXE
GX5M-14C204-YAC.vbf	Jaguar F-Type (X152)	PCM - Powertrain Control Module	EXE
GX5M-14C204-YAD.vbf	Not specified	PCM - Powertrain Control Module	EXE
GX5M-14C204-YCA.vbf	Not specified	PCM - Powertrain Control Module	EXE
GX5M-14C204-YCB.vbf	Not specified	PCM - Powertrain Control Module	EXE
GX5M-14C204-YCC.vbf	Jaguar F-Type (X152)	PCM - Powertrain Control Module	EXE
GX5M-14C204-YCD.vbf	Not specified	PCM - Powertrain Control Module	EXE
GX5M-14C204-YTA.vbf	Not specified	PCM - Powertrain Control Module	EXE
GX5M-14C204-YTB.vbf	Not specified	PCM - Powertrain Control Module	EXE
GX5M-14C204-YTC.vbf	Jaguar F-Type (X152)	PCM - Powertrain Control Module	EXE
GX5M-14C204-YTD.vbf	Not specified	PCM - Powertrain Control Module	EXE
GX5M-14C535-AA.vbf	Not specified	FCIM - Front Controls Interface Module	EXE
GX5M-14C536-AA.vbf	Not specified	FCIM - Front Controls Interface Module	DATA
GX5M-14C549-AA.vbf	Range Rover Sport (L494)	Not specified	DATA
GX5M-14E094-DNA.vbf	Not specified	CHCM - Chassis Control Module	EXE
GX5M-14E094-DNB.vbf	Not specified	CHCM - Chassis Control Module	EXE
GX5M-157012-AA.vbf	Not specified	FTCM - Folding Top Control Module (Master)	EXE
GX5M-157013-AA.vbf	Not specified	FTCM - Folding Top Control Module (Master)	DATA
GX63-12K532-FAA.vbf	Jaguar XF (X260)	PCM - Powertrain Control Module	DATA
GX63-12K532-FAB.vbf	Jaguar XF (X260)	PCM - Powertrain Control Module	DATA
GX63-12K532-FAC.vbf	Jaguar XF (X260)	PCM - Powertrain Control Module	DATA
GX63-12K532-FAD.vbf	Jaguar XF (X260)	PCM - Powertrain Control Module	DATA
GX63-12K532-FAE.vbf	Jaguar XF (X260)	PCM - Powertrain Control Module	DATA
GX63-12K532-FAF.vbf	Jaguar XF (X260)	PCM - Powertrain Control Module	DATA
GX63-12K532-FAG.vbf	Jaguar XF (X260)	PCM - Powertrain Control Module	DATA
GX63-12K532-FBB.vbf	Jaguar XF (X260)	PCM - Powertrain Control Module	DATA
GX63-12K532-FBC.vbf	Jaguar XF (X260)	PCM - Powertrain Control Module	DATA
GX63-12K532-FBD.vbf	Jaguar XF (X260)	PCM - Powertrain Control Module	DATA
GX63-12K532-FBE.vbf	Jaguar XF (X260)	PCM - Powertrain Control Module	DATA
GX63-12K532-FBF.vbf	Jaguar XF (X260)	PCM - Powertrain Control Module	DATA
GX63-12K532-FBG.vbf	Jaguar XF (X260)	PCM - Powertrain Control Module	DATA
GX63-12K532-FCA.vbf	Jaguar XF (X260)	PCM - Powertrain Control Module	DATA
GX63-12K532-FCB.vbf	Jaguar XF (X260)	PCM - Powertrain Control Module	DATA
GX63-12K532-FCC.vbf	Jaguar XF (X260)	PCM - Powertrain Control Module	DATA
GX63-12K532-FCD.vbf	Jaguar XF (X260)	PCM - Powertrain Control Module	DATA
GX63-12K532-FCE.vbf	Jaguar XF (X260)	PCM - Powertrain Control Module	DATA
GX63-12K532-FDA.vbf	Jaguar XF (X260)	PCM - Powertrain Control Module	DATA
GX63-12K532-FDB.vbf	Jaguar XF (X260)	PCM - Powertrain Control Module	DATA
GX63-12K532-FDC.vbf	Jaguar XF (X260)	PCM - Powertrain Control Module	DATA
GX63-12K532-FGA.vbf	Jaguar XF (X260)	PCM - Powertrain Control Module	DATA
GX63-12K532-FGB.vbf	Jaguar XF (X260)	PCM - Powertrain Control Module	DATA
GX63-12K532-FGC.vbf	Jaguar XF (X260)	PCM - Powertrain Control Module	DATA
GX63-12K532-FGD.vbf	Jaguar XF (X260)	PCM - Powertrain Control Module	DATA
GX63-12K532-FGE.vbf	Jaguar XF (X260)	PCM - Powertrain Control Module	DATA
GX63-12K532-FGF.vbf	Jaguar XF (X260)	PCM - Powertrain Control Module	DATA

File name	Vehicle line (indicative)	Module (ECU)	Type
GX63-12K532-FHA.vbf	Jaguar XF (X260)	PCM - Powertrain Control Module	DATA
GX63-12K532-FHB.vbf	Jaguar XF (X260)	PCM - Powertrain Control Module	DATA
GX63-12K532-FHC.vbf	Jaguar XF (X260)	PCM - Powertrain Control Module	DATA
GX63-12K532-FHD.vbf	Jaguar XF (X260)	PCM - Powertrain Control Module	DATA
GX63-12K532-FHE.vbf	Jaguar XF (X260)	PCM - Powertrain Control Module	DATA
GX63-12K532-FHF.vbf	Jaguar XF (X260)	PCM - Powertrain Control Module	DATA
GX63-12K532-FJA.vbf	Jaguar XF (X260)	PCM - Powertrain Control Module	DATA
GX63-12K532-FJB.vbf	Jaguar XF (X260)	PCM - Powertrain Control Module	DATA
GX63-12K532-FJC.vbf	Jaguar XF (X260)	PCM - Powertrain Control Module	DATA
GX63-12K532-FJD.vbf	Jaguar XF (X260)	PCM - Powertrain Control Module	DATA
GX63-12K532-FJE.vbf	Jaguar XF (X260)	PCM - Powertrain Control Module	DATA
GX63-12K532-FJF.vbf	Jaguar XF (X260)	PCM - Powertrain Control Module	DATA
GX63-12K532-FKA.vbf	Jaguar XF (X260)	PCM - Powertrain Control Module	DATA
GX63-12K532-FKB.vbf	Jaguar XF (X260)	PCM - Powertrain Control Module	DATA
GX63-12K532-FKC.vbf	Jaguar XF (X260)	PCM - Powertrain Control Module	DATA
GX63-12K532-FKD.vbf	Jaguar XF (X260)	PCM - Powertrain Control Module	DATA
GX63-12K532-FKE.vbf	Jaguar XF (X260)	PCM - Powertrain Control Module	DATA
GX63-12K532-FKF.vbf	Jaguar XF (X260)	PCM - Powertrain Control Module	DATA
GX63-12K532-FLA.vbf	Jaguar XF (X260)	PCM - Powertrain Control Module	DATA
GX63-12K532-FLB.vbf	Jaguar XF (X260)	PCM - Powertrain Control Module	DATA
GX63-12K532-FLC.vbf	Jaguar XF (X260)	PCM - Powertrain Control Module	DATA
GX63-12K532-FLD.vbf	Jaguar XF (X260)	PCM - Powertrain Control Module	DATA
GX63-12K532-FLE.vbf	Jaguar XF (X260)	PCM - Powertrain Control Module	DATA
GX63-12K532-FLF.vbf	Jaguar XF (X260)	PCM - Powertrain Control Module	DATA
GX63-12K532-FTA.vbf	Jaguar XF (X260)	PCM - Powertrain Control Module	DATA
GX63-12K532-FVA.vbf	Jaguar XF (X260)	PCM - Powertrain Control Module	DATA
GX63-12K532-FXA.vbf	Jaguar XF (X260)	PCM - Powertrain Control Module	DATA
GX63-12K532-FYA.vbf	Jaguar XF (X260)	PCM - Powertrain Control Module	DATA
GX63-12K532-FZA.vbf	Jaguar XF (X260)	PCM - Powertrain Control Module	DATA
GX63-12K532-PCB.vbf	Jaguar XF (X260)	PCM - Powertrain Control Module	DATA
GX63-12K532-PCC.vbf	Jaguar XF (X260)	PCM - Powertrain Control Module	DATA
GX63-12K532-PCD.vbf	Jaguar XF (X260)	PCM - Powertrain Control Module	DATA
GX63-12K532-PCE.vbf	Jaguar XF (X260)	PCM - Powertrain Control Module	DATA
GX63-12K532-PCF.vbf	Jaguar XF (X260)	PCM - Powertrain Control Module	DATA
GX63-12K532-PHB.vbf	Jaguar XF (X260)	PCM - Powertrain Control Module	DATA
GX63-12K532-PHC.vbf	Jaguar XF (X260)	PCM - Powertrain Control Module	DATA
GX63-12K532-PHD.vbf	Jaguar XF (X260)	PCM - Powertrain Control Module	DATA
GX63-12K532-PHE.vbf	Jaguar XF (X260)	PCM - Powertrain Control Module	DATA
GX63-12K532-SAB.vbf	Jaguar XF (X260)	PCM - Powertrain Control Module	DATA
GX63-12K532-SAC.vbf	Jaguar XF (X260)	PCM - Powertrain Control Module	DATA
GX63-12K532-SAD.vbf	Jaguar XF (X260)	PCM - Powertrain Control Module	DATA
GX63-12K532-SAE.vbf	Jaguar XF (X260)	PCM - Powertrain Control Module	DATA
GX63-12K532-SAF.vbf	Jaguar XF (X260)	PCM - Powertrain Control Module	DATA
GX63-12K532-SAG.vbf	Jaguar XF (X260)	PCM - Powertrain Control Module	DATA
GX63-12K532-SBB.vbf	Jaguar XF (X260)	PCM - Powertrain Control Module	DATA
GX63-12K532-SBC.vbf	Jaguar XF (X260)	PCM - Powertrain Control Module	DATA
GX63-12K532-SBD.vbf	Jaguar XF (X260)	PCM - Powertrain Control Module	DATA
GX63-12K532-SBE.vbf	Jaguar XF (X260)	PCM - Powertrain Control Module	DATA
GX63-12K532-SBF.vbf	Jaguar XF (X260)	PCM - Powertrain Control Module	DATA
GX63-12K532-SBG.vbf	Jaguar XF (X260)	PCM - Powertrain Control Module	DATA
GX63-14C025-AB.vbf	Jaguar XF (X260)	Not specified	SBL
GX63-14C025-CA.vbf	Jaguar XF (X260)	IPC - Instrument Panel Cluster (IPC) Control Module	SBL
GX63-14C026-AC.vbf	Jaguar XF (X260)	IPC - Instrument Panel Cluster (IPC) Control Module	EXE
GX63-14C026-AD.vbf	Jaguar XF (X260)	IPC - Instrument Panel Cluster (IPC) Control Module	EXE
GX63-14C026-AE.vbf	Jaguar XF (X260)	IPC - Instrument Panel Cluster (IPC) Control Module	EXE
GX63-14C026-AF.vbf	Jaguar XF (X260)	IPC - Instrument Panel Cluster (IPC) Control Module	EXE
GX63-14C026-AG.vbf	Jaguar XF (X260)	IPC - Instrument Panel Cluster (IPC) Control Module	EXE
GX63-14C026-AH.vbf	Jaguar XF (X260)	IPC - Instrument Panel Cluster (IPC) Control Module	EXE
GX63-14C026-AJ.vbf	Jaguar XF (X260)	IPC - Instrument Panel Cluster (IPC) Control Module	EXE
GX63-14C026-AK.vbf	Jaguar XF (X260)	IPC - Instrument Panel Cluster (IPC) Control Module	EXE
GX63-14C026-CA.vbf	Jaguar XF (X260)	IPC - Instrument Panel Cluster (IPC) Control Module	EXE
GX63-14C026-CB.vbf	Jaguar XF (X260)	IPC - Instrument Panel Cluster (IPC) Control Module	DATA
GX63-14C026-JC.vbf	Jaguar XF (X260)	IPC - Instrument Panel Cluster (IPC) Control Module	EXE
GX63-14C026-JD.vbf	Jaguar XF (X260)	IPC - Instrument Panel Cluster (IPC) Control Module	EXE
GX63-14C026-JE.vbf	Jaguar XF (X260)	IPC - Instrument Panel Cluster (IPC) Control Module	EXE
GX63-14C026-JEX.vbf	Jaguar XF (X260)	IPC - Instrument Panel Cluster (IPC) Control Module	EXE
GX63-14C026-KE.vbf	Jaguar XF (X260)	IPC - Instrument Panel Cluster (IPC) Control Module	EXE
GX63-14C026-KF.vbf	Jaguar XF (X260)	IPC - Instrument Panel Cluster (IPC) Control Module	EXE
GX63-14C026-KG.vbf	Jaguar XF (X260)	IPC - Instrument Panel Cluster (IPC) Control Module	EXE
GX63-14C026-KH.vbf	Jaguar XF (X260)	IPC - Instrument Panel Cluster (IPC) Control Module	DATA
GX63-14C026-LA.vbf	Jaguar XF (X260)	IPC - Instrument Panel Cluster (IPC) Control Module	EXE
GX63-14C026-LAX.vbf	Jaguar XF (X260)	IPC - Instrument Panel Cluster (IPC) Control Module	EXE
GX63-14C034-CA.vbf	Range Rover Sport (L494)	DSM - Driver Front Seat Module	DATA
GX63-14C036-AE.vbf	Jaguar XF (X260)	SPCM - Secondary Powertrain Control Module	EXE
GX63-14C036-AF.vbf	Jaguar XF (X260)	SPCM - Secondary Powertrain Control Module	EXE
GX63-14C036-AG.vbf	Jaguar XF (X260)	SPCM - Secondary Powertrain Control Module	EXE

File name	Vehicle line (indicative)	Module (ECU)	Type
GX63-14C036-AH.vbf	Jaguar XF (X260)	SPCM - Secondary Powertrain Control Module	EXE
GX63-14C036-BE.vbf	Jaguar XF (X260)	SPCM - Secondary Powertrain Control Module	EXE
GX63-14C036-BF.vbf	Jaguar XF (X260)	SPCM - Secondary Powertrain Control Module	EXE
GX63-14C036-BG.vbf	Jaguar XF (X260)	SPCM - Secondary Powertrain Control Module	EXE
GX63-14C036-BH.vbf	Jaguar XF (X260)	SPCM - Secondary Powertrain Control Module	EXE
GX63-14C037-AAE.vbf	Jaguar XF (X260)	SPCM - Secondary Powertrain Control Module	EXE
GX63-14C037-AAF.vbf	Jaguar XF (X260)	SPCM - Secondary Powertrain Control Module	EXE
GX63-14C037-AAG.vbf	Jaguar XF (X260)	SPCM - Secondary Powertrain Control Module	EXE
GX63-14C037-AAH.vbf	Jaguar XF (X260)	SPCM - Secondary Powertrain Control Module	DATA
GX63-14C037-AEE.vbf	Jaguar XF (X260)	SPCM - Secondary Powertrain Control Module	EXE
GX63-14C037-AEF.vbf	Jaguar XF (X260)	SPCM - Secondary Powertrain Control Module	EXE
GX63-14C037-AEG.vbf	Jaguar XF (X260)	SPCM - Secondary Powertrain Control Module	EXE
GX63-14C037-AEH.vbf	Jaguar XF (X260)	SPCM - Secondary Powertrain Control Module	DATA
GX63-14C037-AGE.vbf	Jaguar XF (X260)	SPCM - Secondary Powertrain Control Module	EXE
GX63-14C037-AGF.vbf	Jaguar XF (X260)	SPCM - Secondary Powertrain Control Module	EXE
GX63-14C037-AGG.vbf	Jaguar XF (X260)	SPCM - Secondary Powertrain Control Module	EXE
GX63-14C037-AGH.vbf	Jaguar XF (X260)	SPCM - Secondary Powertrain Control Module	DATA
GX63-14C037-ALE.vbf	Jaguar XF (X260)	SPCM - Secondary Powertrain Control Module	EXE
GX63-14C037-ALF.vbf	Jaguar XF (X260)	SPCM - Secondary Powertrain Control Module	EXE
GX63-14C037-ALG.vbf	Jaguar XF (X260)	SPCM - Secondary Powertrain Control Module	EXE
GX63-14C037-ALH.vbf	Jaguar XF (X260)	SPCM - Secondary Powertrain Control Module	DATA
GX63-14C037-ANE.vbf	Jaguar XF (X260)	SPCM - Secondary Powertrain Control Module	EXE
GX63-14C037-ANF.vbf	Jaguar XF (X260)	SPCM - Secondary Powertrain Control Module	EXE
GX63-14C037-ANG.vbf	Jaguar XF (X260)	SPCM - Secondary Powertrain Control Module	EXE
GX63-14C037-ANH.vbf	Jaguar XF (X260)	SPCM - Secondary Powertrain Control Module	DATA
GX63-14C037-ATF.vbf	Jaguar XF (X260)	SPCM - Secondary Powertrain Control Module	EXE
GX63-14C037-ATG.vbf	Jaguar XF (X260)	SPCM - Secondary Powertrain Control Module	EXE
GX63-14C037-ATH.vbf	Jaguar XF (X260)	SPCM - Secondary Powertrain Control Module	DATA
GX63-14C037-AVE.vbf	Jaguar XF (X260)	SPCM - Secondary Powertrain Control Module	EXE
GX63-14C037-AVF.vbf	Jaguar XF (X260)	SPCM - Secondary Powertrain Control Module	EXE
GX63-14C037-AVG.vbf	Jaguar XF (X260)	SPCM - Secondary Powertrain Control Module	EXE
GX63-14C037-AVH.vbf	Jaguar XF (X260)	SPCM - Secondary Powertrain Control Module	DATA
GX63-14C037-BAF.vbf	Jaguar XF (X260)	SPCM - Secondary Powertrain Control Module	EXE
GX63-14C037-BAG.vbf	Jaguar XF (X260)	SPCM - Secondary Powertrain Control Module	EXE
GX63-14C037-BAH.vbf	Jaguar XF (X260)	SPCM - Secondary Powertrain Control Module	DATA
GX63-14C037-BCE.vbf	Jaguar XF (X260)	SPCM - Secondary Powertrain Control Module	EXE
GX63-14C037-BCF.vbf	Jaguar XF (X260)	SPCM - Secondary Powertrain Control Module	EXE
GX63-14C037-BCG.vbf	Jaguar XF (X260)	SPCM - Secondary Powertrain Control Module	EXE
GX63-14C037-BCH.vbf	Jaguar XF (X260)	SPCM - Secondary Powertrain Control Module	DATA
GX63-14C037-BJF.vbf	Jaguar XF (X260)	SPCM - Secondary Powertrain Control Module	EXE
GX63-14C037-BJG.vbf	Jaguar XF (X260)	SPCM - Secondary Powertrain Control Module	EXE
GX63-14C037-BJH.vbf	Jaguar XF (X260)	SPCM - Secondary Powertrain Control Module	DATA
GX63-14C037-BLF.vbf	Jaguar XF (X260)	SPCM - Secondary Powertrain Control Module	EXE
GX63-14C037-BLG.vbf	Jaguar XF (X260)	SPCM - Secondary Powertrain Control Module	EXE
GX63-14C037-BLH.vbf	Jaguar XF (X260)	SPCM - Secondary Powertrain Control Module	DATA
GX63-14C037-BVE.vbf	Jaguar XF (X260)	SPCM - Secondary Powertrain Control Module	EXE
GX63-14C037-BVF.vbf	Jaguar XF (X260)	SPCM - Secondary Powertrain Control Module	EXE
GX63-14C037-BVG.vbf	Jaguar XF (X260)	SPCM - Secondary Powertrain Control Module	EXE
GX63-14C037-BVH.vbf	Jaguar XF (X260)	SPCM - Secondary Powertrain Control Module	DATA
GX63-14C037-BXE.vbf	Jaguar XF (X260)	SPCM - Secondary Powertrain Control Module	EXE
GX63-14C037-BXF.vbf	Jaguar XF (X260)	SPCM - Secondary Powertrain Control Module	EXE
GX63-14C037-BXG.vbf	Jaguar XF (X260)	SPCM - Secondary Powertrain Control Module	EXE
GX63-14C037-BXH.vbf	Jaguar XF (X260)	SPCM - Secondary Powertrain Control Module	DATA
GX63-14C037-CAF.vbf	Jaguar XF (X260)	SPCM - Secondary Powertrain Control Module	EXE
GX63-14C037-CAG.vbf	Jaguar XF (X260)	SPCM - Secondary Powertrain Control Module	EXE
GX63-14C037-CAH.vbf	Jaguar XF (X260)	SPCM - Secondary Powertrain Control Module	DATA
GX63-14C037-CBF.vbf	Jaguar XF (X260)	SPCM - Secondary Powertrain Control Module	EXE
GX63-14C037-CBG.vbf	Jaguar XF (X260)	SPCM - Secondary Powertrain Control Module	EXE
GX63-14C037-CBH.vbf	Jaguar XF (X260)	SPCM - Secondary Powertrain Control Module	DATA
GX63-14C037-CFE.vbf	Jaguar XF (X260)	SPCM - Secondary Powertrain Control Module	EXE
GX63-14C037-CFF.vbf	Jaguar XF (X260)	SPCM - Secondary Powertrain Control Module	EXE
GX63-14C037-CFG.vbf	Jaguar XF (X260)	SPCM - Secondary Powertrain Control Module	EXE
GX63-14C037-CFH.vbf	Jaguar XF (X260)	SPCM - Secondary Powertrain Control Module	DATA
GX63-14C037-CXF.vbf	Jaguar XF (X260)	SPCM - Secondary Powertrain Control Module	EXE
GX63-14C037-CXG.vbf	Jaguar XF (X260)	SPCM - Secondary Powertrain Control Module	EXE
GX63-14C037-CXH.vbf	Jaguar XF (X260)	SPCM - Secondary Powertrain Control Module	DATA
GX63-14C037-MAE.vbf	Jaguar XF (X260)	SPCM - Secondary Powertrain Control Module	EXE
GX63-14C037-MAF.vbf	Jaguar XF (X260)	SPCM - Secondary Powertrain Control Module	EXE
GX63-14C037-MAG.vbf	Jaguar XF (X260)	SPCM - Secondary Powertrain Control Module	EXE
GX63-14C037-MAH.vbf	Jaguar XF (X260)	SPCM - Secondary Powertrain Control Module	DATA
GX63-14C037-MEE.vbf	Jaguar XF (X260)	SPCM - Secondary Powertrain Control Module	EXE
GX63-14C037-MEF.vbf	Jaguar XF (X260)	SPCM - Secondary Powertrain Control Module	EXE
GX63-14C037-MEG.vbf	Jaguar XF (X260)	SPCM - Secondary Powertrain Control Module	EXE
GX63-14C037-MEH.vbf	Jaguar XF (X260)	SPCM - Secondary Powertrain Control Module	DATA
GX63-14C037-MGF.vbf	Jaguar XF (X260)	SPCM - Secondary Powertrain Control Module	EXE
GX63-14C037-MGG.vbf	Jaguar XF (X260)	SPCM - Secondary Powertrain Control Module	EXE

File name	Vehicle line (indicative)	Module (ECU)	Type
GX63-14C037-MGH.vbf	Jaguar XF (X260)	SPCM - Secondary Powertrain Control Module	DATA
GX63-14C037-MLE.vbf	Jaguar XF (X260)	SPCM - Secondary Powertrain Control Module	EXE
GX63-14C037-MLF.vbf	Jaguar XF (X260)	SPCM - Secondary Powertrain Control Module	EXE
GX63-14C037-MLG.vbf	Jaguar XF (X260)	SPCM - Secondary Powertrain Control Module	EXE
GX63-14C037-MLH.vbf	Jaguar XF (X260)	SPCM - Secondary Powertrain Control Module	DATA
GX63-14C037-MNE.vbf	Jaguar XF (X260)	SPCM - Secondary Powertrain Control Module	EXE
GX63-14C037-MNF.vbf	Jaguar XF (X260)	SPCM - Secondary Powertrain Control Module	EXE
GX63-14C037-MNG.vbf	Jaguar XF (X260)	SPCM - Secondary Powertrain Control Module	EXE
GX63-14C037-MNH.vbf	Jaguar XF (X260)	SPCM - Secondary Powertrain Control Module	DATA
GX63-14C037-MTF.vbf	Jaguar XF (X260)	SPCM - Secondary Powertrain Control Module	EXE
GX63-14C037-MTG.vbf	Jaguar XF (X260)	SPCM - Secondary Powertrain Control Module	EXE
GX63-14C037-MTH.vbf	Jaguar XF (X260)	SPCM - Secondary Powertrain Control Module	DATA
GX63-14C037-MVE.vbf	Jaguar XF (X260)	SPCM - Secondary Powertrain Control Module	EXE
GX63-14C037-MVF.vbf	Jaguar XF (X260)	SPCM - Secondary Powertrain Control Module	EXE
GX63-14C037-MVG.vbf	Jaguar XF (X260)	SPCM - Secondary Powertrain Control Module	EXE
GX63-14C037-NAE.vbf	Jaguar XF (X260)	SPCM - Secondary Powertrain Control Module	EXE
GX63-14C037-NAF.vbf	Jaguar XF (X260)	SPCM - Secondary Powertrain Control Module	EXE
GX63-14C037-NAG.vbf	Jaguar XF (X260)	SPCM - Secondary Powertrain Control Module	EXE
GX63-14C037-NAH.vbf	Jaguar XF (X260)	SPCM - Secondary Powertrain Control Module	DATA
GX63-14C037-NCE.vbf	Jaguar XF (X260)	SPCM - Secondary Powertrain Control Module	EXE
GX63-14C037-NCF.vbf	Jaguar XF (X260)	SPCM - Secondary Powertrain Control Module	EXE
GX63-14C037-NCG.vbf	Jaguar XF (X260)	SPCM - Secondary Powertrain Control Module	EXE
GX63-14C037-NCH.vbf	Jaguar XF (X260)	SPCM - Secondary Powertrain Control Module	DATA
GX63-14C037-NJF.vbf	Jaguar XF (X260)	SPCM - Secondary Powertrain Control Module	EXE
GX63-14C037-NJG.vbf	Jaguar XF (X260)	SPCM - Secondary Powertrain Control Module	EXE
GX63-14C037-NJH.vbf	Jaguar XF (X260)	SPCM - Secondary Powertrain Control Module	DATA
GX63-14C037-NLF.vbf	Jaguar XF (X260)	SPCM - Secondary Powertrain Control Module	EXE
GX63-14C037-NLG.vbf	Jaguar XF (X260)	SPCM - Secondary Powertrain Control Module	EXE
GX63-14C037-NLH.vbf	Jaguar XF (X260)	SPCM - Secondary Powertrain Control Module	DATA
GX63-14C037-PBE.vbf	Jaguar XF (X260)	SPCM - Secondary Powertrain Control Module	EXE
GX63-14C037-PBF.vbf	Jaguar XF (X260)	SPCM - Secondary Powertrain Control Module	EXE
GX63-14C037-PBG.vbf	Jaguar XF (X260)	SPCM - Secondary Powertrain Control Module	EXE
GX63-14C037-PBH.vbf	Jaguar XF (X260)	SPCM - Secondary Powertrain Control Module	DATA
GX63-14C037-PFE.vbf	Jaguar XF (X260)	SPCM - Secondary Powertrain Control Module	EXE
GX63-14C037-PFF.vbf	Jaguar XF (X260)	SPCM - Secondary Powertrain Control Module	EXE
GX63-14C037-PFG.vbf	Jaguar XF (X260)	SPCM - Secondary Powertrain Control Module	EXE
GX63-14C037-PFH.vbf	Jaguar XF (X260)	SPCM - Secondary Powertrain Control Module	DATA
GX63-14C065-AB.vbf	Jaguar XF (X260)	DDM - Driver Front Door Module	DATA
GX63-14C065-AC.vbf	Jaguar XF (X260)	DDM - Driver Front Door Module	DATA
GX63-14C065-BA.vbf	Jaguar XF (X260)	DDM - Driver Front Door Module	DATA
GX63-14C065-BB.vbf	Jaguar XF (X260)	DDM - Driver Front Door Module	DATA
GX63-14C065-BC.vbf	Jaguar XF (X260)	DDM - Driver Front Door Module	DATA
GX63-14C065-BD.vbf	Jaguar XF (X260)	DDM - Driver Front Door Module	DATA
GX63-14C065-BE.vbf	Jaguar XF (X260)	DDM - Driver Front Door Module	DATA
GX63-14C065-BF.vbf	Jaguar XF (X260)	DDM - Driver Front Door Module	DATA
GX63-14C069-AB.vbf	Jaguar XF (X260)	DRDM - Driver Rear Door Module	DATA
GX63-14C069-AC.vbf	Jaguar XF (X260)	DRDM - Driver Rear Door Module	DATA
GX63-14C069-BA.vbf	Jaguar XF (X260)	DRDM - Driver Rear Door Module	DATA
GX63-14C069-BB.vbf	Jaguar XF (X260)	DRDM - Driver Rear Door Module	DATA
GX63-14C069-BC.vbf	Jaguar XF (X260)	DRDM - Driver Rear Door Module	DATA
GX63-14C069-BD.vbf	Jaguar XF (X260)	DRDM - Driver Rear Door Module	DATA
GX63-14C069-BE.vbf	Jaguar XF (X260)	DRDM - Driver Rear Door Module	DATA
GX63-14C069-BF.vbf	Jaguar XF (X260)	DRDM - Driver Rear Door Module	DATA
GX63-14C088-CC.vbf	Jaguar XF (X260)	IPC - Instrument Panel Cluster (IPC) Control Module	EXE
GX63-14C088-CD.vbf	Jaguar XF (X260)	IPC - Instrument Panel Cluster (IPC) Control Module	EXE
GX63-14C088-CE.vbf	Jaguar XF (X260)	IPC - Instrument Panel Cluster (IPC) Control Module	EXE
GX63-14C088-CF.vbf	Jaguar XF (X260)	IPC - Instrument Panel Cluster (IPC) Control Module	EXE
GX63-14C088-CG.vbf	Jaguar XF (X260)	IPC - Instrument Panel Cluster (IPC) Control Module	EXE
GX63-14C088-CH.vbf	Jaguar XF (X260)	IPC - Instrument Panel Cluster (IPC) Control Module	EXE
GX63-14C088-CJ.vbf	Jaguar XF (X260)	IPC - Instrument Panel Cluster (IPC) Control Module	EXE
GX63-14C088-CK.vbf	Jaguar XF (X260)	IPC - Instrument Panel Cluster (IPC) Control Module	EXE
GX63-14C088-CL.vbf	Jaguar XF (X260)	IPC - Instrument Panel Cluster (IPC) Control Module	EXE
GX63-14C088-JE.vbf	Jaguar XF (X260)	IPC - Instrument Panel Cluster (IPC) Control Module	DATA
GX63-14C088-JF.vbf	Jaguar XF (X260)	IPC - Instrument Panel Cluster (IPC) Control Module	DATA
GX63-14C088-JG.vbf	Jaguar XF (X260)	IPC - Instrument Panel Cluster (IPC) Control Module	DATA
GX63-14C088-LA.vbf	Jaguar XF (X260)	IPC - Instrument Panel Cluster (IPC) Control Module	DATA
GX63-14C090-DB.vbf	Jaguar XF (X260)	PAM - Parking Assist Control Module	EXE
GX63-14C090-DE.vbf	Jaguar XF (X260)	PAM - Parking Assist Control Module	EXE
GX63-14C090-DF.vbf	Jaguar XF (X260)	PAM - Parking Assist Control Module	EXE
GX63-14C090-DG.vbf	Jaguar XF (X260)	PAM - Parking Assist Control Module	EXE
GX63-14C090-DH.vbf	Jaguar XF (X260)	PAM - Parking Assist Control Module	EXE
GX63-14C090-DJ.vbf	Jaguar XF (X260)	PAM - Parking Assist Control Module	EXE
GX63-14C090-DK.vbf	Jaguar XF (X260)	PAM - Parking Assist Control Module	EXE
GX63-14C090-DL.vbf	Jaguar XF (X260)	PAM - Parking Assist Control Module	EXE
GX63-14C090-DM.vbf	Jaguar XF (X260)	PAM - Parking Assist Control Module	EXE
GX63-14C090-DN.vbf	Jaguar XF (X260)	PAM - Parking Assist Control Module	EXE

File name	Vehicle line (indicative)	Module (ECU)	Type
GX63-14C090-DP.vbf	Jaguar XF (X260)	PAM - Parking Assist Control Module	EXE
GX63-14C091-AC.vbf	Jaguar XF (X260)	PAM - Parking Assist Control Module	DATA
GX63-14C091-AD.vbf	Jaguar XF (X260)	PAM - Parking Assist Control Module	DATA
GX63-14C091-AE.vbf	Jaguar XF (X260)	PAM - Parking Assist Control Module	DATA
GX63-14C091-AF.vbf	Jaguar XF (X260)	PAM - Parking Assist Control Module	DATA
GX63-14C091-AH.vbf	Jaguar XF (X260)	PAM - Parking Assist Control Module	DATA
GX63-14C091-AJ.vbf	Jaguar XF (X260)	PAM - Parking Assist Control Module	DATA
GX63-14C091-AK.vbf	Jaguar XF (X260)	PAM - Parking Assist Control Module	DATA
GX63-14C091-AL.vbf	Jaguar XF (X260)	PAM - Parking Assist Control Module	DATA
GX63-14C098-AA.vbf	Jaguar XF (X260)	RCM - Restraints Control Module	DATA
GX63-14C098-AB.vbf	Jaguar XF (X260)	RCM - Restraints Control Module	DATA
GX63-14C098-AC.vbf	Jaguar XF (X260)	RCM - Restraints Control Module	DATA
GX63-14C098-AE.vbf	Jaguar XF (X260)	RCM - Restraints Control Module	DATA
GX63-14C098-BB.vbf	Jaguar XF (X260)	RCM - Restraints Control Module	DATA
GX63-14C098-BC.vbf	Jaguar XF (X260)	RCM - Restraints Control Module	DATA
GX63-14C098-BD.vbf	Jaguar XF (X260)	RCM - Restraints Control Module	DATA
GX63-14C098-BE.vbf	Jaguar XF (X260)	RCM - Restraints Control Module	DATA
GX63-14C098-BF.vbf	Jaguar XF (X260)	RCM - Restraints Control Module	DATA
GX63-14C098-BG.VBF	Jaguar XF (X260)	RCM - Restraints Control Module	DATA
GX63-14C098-CA.vbf	Jaguar XF (X260)	RCM - Restraints Control Module	DATA
GX63-14C098-CB.vbf	Jaguar XF (X260)	RCM - Restraints Control Module	DATA
GX63-14C098-CC.vbf	Jaguar XF (X260)	RCM - Restraints Control Module	DATA
GX63-14C098-CD.vbf	Jaguar XF (X260)	RCM - Restraints Control Module	DATA
GX63-14C098-CE.vbf	Jaguar XF (X260)	RCM - Restraints Control Module	DATA
GX63-14C098-CF.vbf	Jaguar XF (X260)	RCM - Restraints Control Module	DATA
GX63-14C098-CG.vbf	Jaguar XF (X260)	RCM - Restraints Control Module	DATA
GX63-14C098-DA.vbf	Jaguar XF (X260)	RCM - Restraints Control Module	DATA
GX63-14C098-EA.vbf	Jaguar XF (X260)	RCM - Restraints Control Module	DATA
GX63-14C098-EB.vbf	Jaguar XF (X260)	RCM - Restraints Control Module	DATA
GX63-14C105-AC.vbf	Jaguar XF (X260)	TMC Traffic Message Channel Module	DATA
GX63-14C105-AD.vbf	Jaguar XF (X260)	TMC Traffic Message Channel Module	DATA
GX63-14C105-AE.VBF	Jaguar XF (X260)	TMC Traffic Message Channel Module	DATA
GX63-14C105-AJ.vbf	Jaguar XF (X260)	TMC Traffic Message Channel Module	DATA
GX63-14C109-AB.vbf	Jaguar XF (X260)	PDM - Passenger Front Door Module	DATA
GX63-14C109-AC.vbf	Jaguar XF (X260)	PDM - Passenger Front Door Module	DATA
GX63-14C109-BA.vbf	Jaguar XF (X260)	PDM - Passenger Front Door Module	DATA
GX63-14C109-BB.vbf	Jaguar XF (X260)	PDM - Passenger Front Door Module	DATA
GX63-14C109-BC.vbf	Jaguar XF (X260)	PDM - Passenger Front Door Module	DATA
GX63-14C109-BD.vbf	Jaguar XF (X260)	PDM - Passenger Front Door Module	DATA
GX63-14C109-BE.vbf	Jaguar XF (X260)	PDM - Passenger Front Door Module	DATA
GX63-14C109-BF.vbf	Jaguar XF (X260)	PDM - Passenger Front Door Module	DATA
GX63-14C113-AB.vbf	Jaguar XF (X260)	PRDM - Passenger Rear Door Module	DATA
GX63-14C113-AC.vbf	Jaguar XF (X260)	PRDM - Passenger Rear Door Module	DATA
GX63-14C113-BA.vbf	Jaguar XF (X260)	PRDM - Passenger Rear Door Module	DATA
GX63-14C113-BB.vbf	Jaguar XF (X260)	PRDM - Passenger Rear Door Module	DATA
GX63-14C113-BC.vbf	Jaguar XF (X260)	PRDM - Passenger Rear Door Module	DATA
GX63-14C113-BD.vbf	Jaguar XF (X260)	PRDM - Passenger Rear Door Module	DATA
GX63-14C113-BE.vbf	Jaguar XF (X260)	PRDM - Passenger Rear Door Module	DATA
GX63-14C113-BF.vbf	Jaguar XF (X260)	PRDM - Passenger Rear Door Module	DATA
GX63-14C121-AA.vbf	Jaguar XF (X260)	RGTM - Rear Gate / Trunk Module	EXE
GX63-14C121-AB.vbf	Jaguar XF (X260)	RGTM - Rear Gate / Trunk Module	EXE
GX63-14C122-AA.vbf	Jaguar XF (X260)	RGTM - Rear Gate / Trunk Module	DATA
GX63-14C122-AB.vbf	Jaguar XF (X260)	RGTM - Rear Gate / Trunk Module	DATA
GX63-14C124-AA.vbf	Jaguar XF (X260)	RGTM - Rear Gate / Trunk Module	SBL
GX63-14C151-AA.vbf	Jaguar XF (X260)	TPM - Tire Pressure Monitor Module	EXE
GX63-14C151-AB.vbf	Jaguar XF (X260)	TPM - Tire Pressure Monitor Module	EXE
GX63-14C151-AC.vbf	Jaguar XF (X260)	TPM - Tire Pressure Monitor Module	EXE
GX63-14C151-AD.vbf	Jaguar XF (X260)	TPM - Tire Pressure Monitor Module	EXE
GX63-14C152-AA.vbf	Jaguar XF (X260)	TPM - Tire Pressure Monitor Module	DATA
GX63-14C185-AF.vbf	Jaguar XF (X260)	BCM - Body Control Module	DATA
GX63-14C185-AG.vbf	Jaguar XF (X260)	BCM - Body Control Module	DATA
GX63-14C185-AH.vbf	Jaguar XF (X260)	BCM - Body Control Module	DATA
GX63-14C185-AJ.vbf	Jaguar XF (X260)	BCM - Body Control Module	DATA
GX63-14C185-AK.vbf	Jaguar XF (X260)	BCM - Body Control Module	DATA
GX63-14C185-AL.vbf	Jaguar XF (X260)	BCM - Body Control Module	DATA
GX63-14C185-AM.vbf	Jaguar XF (X260)	BCM - Body Control Module	DATA
GX63-14C185-AN.vbf	Jaguar XF (X260)	BCM - Body Control Module	DATA
GX63-14C204-CAA.vbf	Jaguar XF (X260)	PCM - Powertrain Control Module	EXE
GX63-14C204-CAB.vbf	Jaguar XF (X260)	PCM - Powertrain Control Module	EXE
GX63-14C204-CAC.vbf	Jaguar XF (X260)	PCM - Powertrain Control Module	EXE
GX63-14C204-CAD.vbf	Jaguar XF (X260)	PCM - Powertrain Control Module	EXE
GX63-14C204-CAE.vbf	Jaguar XF (X260)	PCM - Powertrain Control Module	EXE
GX63-14C204-CAF.vbf	Jaguar XF (X260)	PCM - Powertrain Control Module	EXE
GX63-14C204-CCA.vbf	Jaguar XF (X260)	PCM - Powertrain Control Module	EXE
GX63-14C204-CCB.vbf	Jaguar XF (X260)	PCM - Powertrain Control Module	EXE
GX63-14C204-CCC.vbf	Jaguar XF (X260)	PCM - Powertrain Control Module	EXE

File name	Vehicle line (indicative)	Module (ECU)	Type
GX63-14C204-CCD.vbf	Jaguar XF (X260)	PCM - Powertrain Control Module	EXE
GX63-14C204-CTA.vbf	Jaguar XF (X260)	PCM - Powertrain Control Module	EXE
GX63-14C204-CTB.vbf	Jaguar XF (X260)	PCM - Powertrain Control Module	EXE
GX63-14C204-CTC.vbf	Jaguar XF (X260)	PCM - Powertrain Control Module	EXE
GX63-14C204-CTD.vbf	Jaguar XF (X260)	PCM - Powertrain Control Module	EXE
GX63-14C204-CTE.vbf	Jaguar XF (X260)	PCM - Powertrain Control Module	EXE
GX63-14C204-JAA.vbf	Jaguar XF (X260)	PCM - Powertrain Control Module	EXE
GX63-14C204-JAB.vbf	Jaguar XF (X260)	PCM - Powertrain Control Module	EXE
GX63-14C204-JAC.vbf	Jaguar XF (X260)	PCM - Powertrain Control Module	EXE
GX63-14C204-JAD.vbf	Jaguar XF (X260)	PCM - Powertrain Control Module	EXE
GX63-14C204-JAE.vbf	Jaguar XF (X260)	PCM - Powertrain Control Module	EXE
GX63-14C204-JAF.vbf	Jaguar XF (X260)	PCM - Powertrain Control Module	EXE
GX63-14C204-JCA.vbf	Jaguar XF (X260)	PCM - Powertrain Control Module	EXE
GX63-14C204-JCB.vbf	Jaguar XF (X260)	PCM - Powertrain Control Module	EXE
GX63-14C204-JCC.vbf	Jaguar XF (X260)	PCM - Powertrain Control Module	EXE
GX63-14C204-JCD.vbf	Jaguar XF (X260)	PCM - Powertrain Control Module	EXE
GX63-14C204-JTA.vbf	Jaguar XF (X260)	PCM - Powertrain Control Module	EXE
GX63-14C204-JTB.vbf	Jaguar XF (X260)	PCM - Powertrain Control Module	EXE
GX63-14C204-JTC.vbf	Jaguar XF (X260)	PCM - Powertrain Control Module	EXE
GX63-14C204-JTD.vbf	Jaguar XF (X260)	PCM - Powertrain Control Module	EXE
GX63-14C204-MCC.vbf	Jaguar XF (X260)	PCM - Powertrain Control Module	EXE
GX63-14C204-MCD.vbf	Jaguar XF (X260)	PCM - Powertrain Control Module	EXE
GX63-14C204-MCE.vbf	Jaguar XF (X260)	PCM - Powertrain Control Module	EXE
GX63-14C204-MCF.vbf	Jaguar XF (X260)	PCM - Powertrain Control Module	EXE
GX63-14C204-MEC.vbf	Jaguar XF (X260)	PCM - Powertrain Control Module	EXE
GX63-14C204-MED.vbf	Jaguar XF (X260)	PCM - Powertrain Control Module	EXE
GX63-14C204-MEE.vbf	Jaguar XF (X260)	PCM - Powertrain Control Module	EXE
GX63-14C204-MEF.vbf	Jaguar XF (X260)	PCM - Powertrain Control Module	EXE
GX63-14C204-MHC.vbf	Jaguar XF (X260)	PCM - Powertrain Control Module	EXE
GX63-14C204-MHD.vbf	Jaguar XF (X260)	PCM - Powertrain Control Module	EXE
GX63-14C204-MHE.vbf	Jaguar XF (X260)	PCM - Powertrain Control Module	EXE
GX63-14C204-MHF.vbf	Jaguar XF (X260)	PCM - Powertrain Control Module	EXE
GX63-14C204-TAB.vbf	Jaguar XF (X260)	PCM - Powertrain Control Module	EXE
GX63-14C204-TAC.vbf	Jaguar XF (X260)	PCM - Powertrain Control Module	EXE
GX63-14C204-TAD.vbf	Jaguar XF (X260)	PCM - Powertrain Control Module	EXE
GX63-14C204-TAE.vbf	Jaguar XF (X260)	PCM - Powertrain Control Module	EXE
GX63-14C204-TAF.vbf	Jaguar XF (X260)	PCM - Powertrain Control Module	EXE
GX63-14C204-TCA.vbf	Jaguar XF (X260)	PCM - Powertrain Control Module	EXE
GX63-14C204-TCB.vbf	Jaguar XF (X260)	PCM - Powertrain Control Module	EXE
GX63-14C204-TCC.vbf	Jaguar XF (X260)	PCM - Powertrain Control Module	EXE
GX63-14C204-TCD.vbf	Jaguar XF (X260)	PCM - Powertrain Control Module	EXE
GX63-14C204-TEA.vbf	Jaguar XF (X260)	PCM - Powertrain Control Module	EXE
GX63-14C204-TEB.vbf	Jaguar XF (X260)	PCM - Powertrain Control Module	EXE
GX63-14C204-TEC.vbf	Jaguar XF (X260)	PCM - Powertrain Control Module	EXE
GX63-14C204-TTB.vbf	Jaguar XF (X260)	PCM - Powertrain Control Module	EXE
GX63-14C204-TTC.vbf	Jaguar XF (X260)	PCM - Powertrain Control Module	EXE
GX63-14C204-TTD.vbf	Jaguar XF (X260)	PCM - Powertrain Control Module	EXE
GX63-14C204-TTE.vbf	Jaguar XF (X260)	PCM - Powertrain Control Module	EXE
GX63-14C204-UAB.vbf	Jaguar XF (X260)	PCM - Powertrain Control Module	EXE
GX63-14C204-UAC.vbf	Jaguar XF (X260)	PCM - Powertrain Control Module	EXE
GX63-14C204-UAD.vbf	Jaguar XF (X260)	PCM - Powertrain Control Module	EXE
GX63-14C204-UAE.vbf	Jaguar XF (X260)	PCM - Powertrain Control Module	EXE
GX63-14C204-UAF.vbf	Jaguar XF (X260)	PCM - Powertrain Control Module	EXE
GX63-14C204-UCB.vbf	Jaguar XF (X260)	PCM - Powertrain Control Module	EXE
GX63-14C204-UCC.vbf	Jaguar XF (X260)	PCM - Powertrain Control Module	EXE
GX63-14C204-UCD.vbf	Jaguar XF (X260)	PCM - Powertrain Control Module	EXE
GX63-14C204-UCE.vbf	Jaguar XF (X260)	PCM - Powertrain Control Module	EXE
GX63-14C204-UEA.vbf	Jaguar XF (X260)	PCM - Powertrain Control Module	EXE
GX63-14C204-UEB.vbf	Jaguar XF (X260)	PCM - Powertrain Control Module	EXE
GX63-14C204-UEC.vbf	Jaguar XF (X260)	PCM - Powertrain Control Module	EXE
GX63-14C204-UED.vbf	Jaguar XF (X260)	PCM - Powertrain Control Module	EXE
GX63-14C204-UTB.vbf	Jaguar XF (X260)	PCM - Powertrain Control Module	EXE
GX63-14C204-UTC.vbf	Jaguar XF (X260)	PCM - Powertrain Control Module	EXE
GX63-14C204-UTD.vbf	Jaguar XF (X260)	PCM - Powertrain Control Module	EXE
GX63-14C204-UTE.vbf	Jaguar XF (X260)	PCM - Powertrain Control Module	EXE
GX63-14C217-AA.vbf	Jaguar XF (X260)	PSCM - Power Steering Control Module	EXE
GX63-14C217-AB.vbf	Jaguar XF (X260)	PSCM - Power Steering Control Module	EXE
GX63-14C217-AC.vbf	Jaguar XF (X260)	PSCM - Power Steering Control Module	EXE
GX63-14C217-AD.vbf	Jaguar XF (X260)	PSCM - Power Steering Control Module	EXE
GX63-14C218-AA.vbf	Jaguar XF (X260)	PSCM - Power Steering Control Module	DATA
GX63-14C218-AB.vbf	Jaguar XF (X260)	PSCM - Power Steering Control Module	DATA
GX63-14C218-AC.vbf	Jaguar XF (X260)	PSCM - Power Steering Control Module	DATA
GX63-14C218-EA.vbf	Jaguar XF (X260)	PSCM - Power Steering Control Module	DATA
GX63-14C218-FA.vbf	Jaguar XF (X260)	PSCM - Power Steering Control Module	DATA
GX63-14C218-GA.vbf	Jaguar XF (X260)	PSCM - Power Steering Control Module	DATA
GX63-14C305-AC.vbf	Jaguar XF (X260)	ACM - Audio Front Control Module	SBL

File name	Vehicle line (indicative)	Module (ECU)	Type
GX63-14C305-AD.vbf	Jaguar XF (X260)	ACM - Audio Front Control Module	SBL
GX63-14C305-AE.vbf	Jaguar XF (X260)	ACM - Audio Front Control Module	SBL
GX63-14C366-AA.vbf	Jaguar XF (X260)	TCCM - Transfer Case Control Module	EXE
GX63-14C366-AB.vbf	Jaguar XF (X260)	TCCM - Transfer Case Control Module	EXE
GX63-14C366-AC.vbf	Jaguar XF (X260)	TCCM - Transfer Case Control Module	EXE
GX63-14C366-AD.vbf	Jaguar XF (X260)	TCCM - Transfer Case Control Module	EXE
GX63-14C367-AA.vbf	Jaguar XF (X260)	TCCM - Transfer Case Control Module	DATA
GX63-14C367-AB.vbf	Jaguar XF (X260)	TCCM - Transfer Case Control Module	DATA
GX63-14C367-AC.vbf	Jaguar XF (X260)	TCCM - Transfer Case Control Module	DATA
GX63-14C367-AD.vbf	Jaguar XF (X260)	TCCM - Transfer Case Control Module	DATA
GX63-14C367-BB.vbf	Jaguar XF (X260)	TCCM - Transfer Case Control Module	DATA
GX63-14C367-BC.vbf	Jaguar XF (X260)	TCCM - Transfer Case Control Module	DATA
GX63-14C367-BD.vbf	Jaguar XF (X260)	TCCM - Transfer Case Control Module	DATA
GX63-14C367-BE.vbf	Jaguar XF (X260)	TCCM - Transfer Case Control Module	DATA
GX63-14C367-BF.vbf	Jaguar XF (X260)	TCCM - Transfer Case Control Module	DATA
GX63-14C368-AA.vbf	Jaguar XF (X260)	TCCM - Transfer Case Control Module	SBL
GX63-14C368-AB.vbf	Jaguar XF (X260)	TCCM - Transfer Case Control Module	SBL
GX63-14C377-AB.vbf	Jaguar XF (X260)	PAM - Parking Assist Control Module	SIGCFG
GX63-14C377-AC.vbf	Jaguar XF (X260)	PAM - Parking Assist Control Module	SIGCFG
GX63-14C390-AA.vbf	Jaguar XF (X260)	TCCM - Transfer Case Control Module	DATA
GX63-14C390-AB.vbf	Jaguar XF (X260)	TCCM - Transfer Case Control Module	DATA
GX63-14C434-AA.vbf	Jaguar XF (X260)	TPM - Tire Pressure Monitor Module	SIGCFG
GX63-14C434-AB.vbf	Jaguar XF (X260)	TPM - Tire Pressure Monitor Module	SIGCFG
GX63-14C527-BB.vbf	Jaguar XF (X260)	AAM - Audio Amplifier Module	DATA
GX63-14C527-BC.vbf	Jaguar XF (X260)	AAM - Audio Amplifier Module	DATA
GX63-14C527-BD.vbf	Jaguar XF (X260)	AAM - Audio Amplifier Module	DATA
GX63-14C527-BF.vbf	Jaguar XF (X260)	AAM - Audio Amplifier Module	DATA
GX63-14C527-CA.vbf	Jaguar XF (X260)	AAM - Audio Amplifier Module	DATA
GX63-14C527-CB.vbf	Jaguar XF (X260)	AAM - Audio Amplifier Module	DATA
GX63-14C527-CC.vbf	Jaguar XF (X260)	AAM - Audio Amplifier Module	DATA
GX63-14C527-CD.vbf	Jaguar XF (X260)	AAM - Audio Amplifier Module	DATA
GX63-14C527-CF.vbf	Jaguar XF (X260)	AAM - Audio Amplifier Module	DATA
GX63-14C534-AC.vbf	Jaguar XF (X260)	FCIM - Front Controls Interface Module	SIGCFG
GX63-14C534-AD.vbf	Jaguar XF (X260)	FCIM - Front Controls Interface Module	SIGCFG
GX63-14C535-AB.vbf	Jaguar XF (X260)	FCIM - Front Controls Interface Module	EXE
GX63-14C535-AC.vbf	Jaguar XF (X260)	FCIM - Front Controls Interface Module	EXE
GX63-14C535-AD.vbf	Jaguar XF (X260)	FCIM - Front Controls Interface Module	EXE
GX63-14C535-AE.vbf	Jaguar XF (X260)	FCIM - Front Controls Interface Module	EXE
GX63-14C536-AB.vbf	Jaguar XF (X260)	FCIM - Front Controls Interface Module	DATA
GX63-14C536-AC.vbf	Jaguar XF (X260)	FCIM - Front Controls Interface Module	DATA
GX63-14C536-AD.vbf	Jaguar XF (X260)	FCIM - Front Controls Interface Module	DATA
GX63-14C536-AE.vbf	Jaguar XF (X260)	FCIM - Front Controls Interface Module	DATA
GX63-14C536-BAA.vbf	Jaguar XF (X260)	FCIM - Front Controls Interface Module	DATA
GX63-14C536-BBA.vbf	Jaguar XF (X260)	FCIM - Front Controls Interface Module	DATA
GX63-14C536-BCA.vbf	Jaguar XF (X260)	FCIM - Front Controls Interface Module	DATA
GX63-14C536-BDA.vbf	Jaguar XF (X260)	FCIM - Front Controls Interface Module	DATA
GX63-14C536-BEA.vbf	Jaguar XF (X260)	FCIM - Front Controls Interface Module	DATA
GX63-14C536-BFA.vbf	Jaguar XF (X260)	FCIM - Front Controls Interface Module	DATA
GX63-14C536-BGA.vbf	Jaguar XF (X260)	FCIM - Front Controls Interface Module	DATA
GX63-14C536-BHA.vbf	Jaguar XF (X260)	FCIM - Front Controls Interface Module	DATA
GX63-14C536-BJA.vbf	Jaguar XF (X260)	FCIM - Front Controls Interface Module	DATA
GX63-14C536-BKA.vbf	Jaguar XF (X260)	FCIM - Front Controls Interface Module	DATA
GX63-14C536-BLA.vbf	Jaguar XF (X260)	FCIM - Front Controls Interface Module	DATA
GX63-14C536-BMA.vbf	Jaguar XF (X260)	FCIM - Front Controls Interface Module	DATA
GX63-14C536-BNA.vbf	Jaguar XF (X260)	FCIM - Front Controls Interface Module	DATA
GX63-14C536-BPA.vbf	Jaguar XF (X260)	FCIM - Front Controls Interface Module	DATA
GX63-14C536-BRA.vbf	Jaguar XF (X260)	FCIM - Front Controls Interface Module	DATA
GX63-14C536-BSA.vbf	Jaguar XF (X260)	FCIM - Front Controls Interface Module	DATA
GX63-14C536-BTA.vbf	Jaguar XF (X260)	FCIM - Front Controls Interface Module	DATA
GX63-14C536-BUA.vbf	Jaguar XF (X260)	FCIM - Front Controls Interface Module	DATA
GX63-14C536-BVA.vbf	Jaguar XF (X260)	FCIM - Front Controls Interface Module	DATA
GX63-14C536-BXA.vbf	Jaguar XF (X260)	FCIM - Front Controls Interface Module	DATA
GX63-14C536-BYA.vbf	Jaguar XF (X260)	FCIM - Front Controls Interface Module	DATA
GX63-14C536-BZA.vbf	Jaguar XF (X260)	FCIM - Front Controls Interface Module	DATA
GX63-14C536-CAA.vbf	Jaguar XF (X260)	FCIM - Front Controls Interface Module	DATA
GX63-14C536-CBA.vbf	Jaguar XF (X260)	FCIM - Front Controls Interface Module	DATA
GX63-14C536-CCA.vbf	Jaguar XF (X260)	FCIM - Front Controls Interface Module	DATA
GX63-14C536-CDA.vbf	Jaguar XF (X260)	FCIM - Front Controls Interface Module	DATA
GX63-14C536-CEA.vbf	Jaguar XF (X260)	FCIM - Front Controls Interface Module	DATA
GX63-14C536-CFA.vbf	Jaguar XF (X260)	FCIM - Front Controls Interface Module	DATA
GX63-14C536-CGA.vbf	Jaguar XF (X260)	FCIM - Front Controls Interface Module	DATA
GX63-14C536-CHA.vbf	Jaguar XF (X260)	FCIM - Front Controls Interface Module	DATA
GX63-14C536-CJA.vbf	Jaguar XF (X260)	FCIM - Front Controls Interface Module	DATA
GX63-14C536-CKA.vbf	Jaguar XF (X260)	FCIM - Front Controls Interface Module	DATA
GX63-14C536-CLA.vbf	Jaguar XF (X260)	FCIM - Front Controls Interface Module	DATA
GX63-14C536-CMA.vbf	Jaguar XF (X260)	FCIM - Front Controls Interface Module	DATA

File name	Vehicle line (indicative)	Module (ECU)	Type
GX63-14C536-CNA.vbf	Jaguar XF (X260)	FCIM - Front Controls Interface Module	DATA
GX63-14C536-CPA.vbf	Jaguar XF (X260)	FCIM - Front Controls Interface Module	DATA
GX63-14C536-CRA.vbf	Jaguar XF (X260)	FCIM - Front Controls Interface Module	DATA
GX63-14C536-CSA.vbf	Jaguar XF (X260)	FCIM - Front Controls Interface Module	DATA
GX63-14C536-CTA.vbf	Jaguar XF (X260)	FCIM - Front Controls Interface Module	DATA
GX63-14C536-CUA.vbf	Jaguar XF (X260)	FCIM - Front Controls Interface Module	DATA
GX63-14C548-BB.vbf	Jaguar XE (X760)	PSM - Passenger Front Seat Module	EXE
GX63-14C549-CA.vbf	Range Rover Sport (L494)	PSM - Passenger Front Seat Module	DATA
GX63-14C609-AA.vbf	Jaguar XF (X260)	PSCM - Power Steering Control Module	DATA
GX63-14C609-AB.vbf	Jaguar XF (X260)	PSCM - Power Steering Control Module	DATA
GX63-14C609-AC.vbf	Jaguar XF (X260)	PSCM - Power Steering Control Module	DATA
GX63-14C609-AD.vbf	Jaguar XF (X260)	PSCM - Power Steering Control Module	DATA
GX63-14C609-AE.vbf	Jaguar XF (X260)	PSCM - Power Steering Control Module	DATA
GX63-14C653-AC.vbf	Jaguar XF (X260)	ACM - Audio Front Control Module	DATA
GX63-14C653-AD.vbf	Jaguar XF (X260)	ACM - Audio Front Control Module	DATA
GX63-14C653-AE.vbf	Jaguar XF (X260)	ACM - Audio Front Control Module	DATA
GX63-14C653-AF.vbf	Jaguar XF (X260)	ACM - Audio Front Control Module	DATA
GX63-14D183-BB.vbf	Jaguar XF (X260)	OCS - Restraints Occupant Classification System Module	DATA
GX63-14D183-BC.vbf	Jaguar XF (X260)	OCS - Restraints Occupant Classification System Module	DATA
GX63-14D183-BD.vbf	Jaguar XF (X260)	OCS - Restraints Occupant Classification System Module	DATA
GX63-14D480-BA.vbf	Jaguar XF (X260)	IPMB - Image Processing Module B	EXE
GX63-14D480-BC.vbf	Jaguar XF (X260)	IPMB - Image Processing Module B	EXE
GX63-14D480-BD.vbf	Jaguar XF (X260)	IPMB - Image Processing Module B	EXE
GX63-14D480-BF.vbf	Jaguar XF (X260)	IPMB - Image Processing Module B	EXE
GX63-14D480-BH.vbf	Jaguar XF (X260)	IPMB - Image Processing Module B	EXE
GX63-14D480-BJ.vbf	Jaguar XF (X260)	IPMB - Image Processing Module B	EXE
GX63-14D480-CA.vbf	Jaguar XF (X260)	IPMB - Image Processing Module B	EXE
GX63-14D485-BA.vbf	Jaguar XF (X260)	IPMB - Image Processing Module B	DATA
GX63-14D485-BC.vbf	Jaguar XF (X260)	IPMB - Image Processing Module B	DATA
GX63-14D485-CA.vbf	Jaguar XF (X260)	IPMB - Image Processing Module B	DATA
GX63-14D519-AC.vbf	Jaguar XF (X260)	HVAC - HVAC Control Module	EXE
GX63-14D519-AD.vbf	Jaguar XF (X260)	HVAC - HVAC Control Module	EXE
GX63-14D519-AE.vbf	Jaguar XF (X260)	HVAC - HVAC Control Module	EXE
GX63-14D520-AC.vbf	Jaguar XF (X260)	HVAC - HVAC Control Module	DATA
GX63-14D520-AD.vbf	Jaguar XF (X260)	HVAC - HVAC Control Module	DATA
GX63-14D520-AE.vbf	Jaguar XF (X260)	HVAC - HVAC Control Module	DATA
GX63-14D520-AF.vbf	Jaguar XF (X260)	HVAC - HVAC Control Module	DATA
GX63-14D520-AG.vbf	Jaguar XF (X260)	HVAC - HVAC Control Module	DATA
GX63-14D520-AH.vbf	Jaguar XF (X260)	HVAC - HVAC Control Module	DATA
GX63-14D520-BC.vbf	Jaguar XF (X260)	HVAC - HVAC Control Module	DATA
GX63-14D520-BD.vbf	Jaguar XF (X260)	HVAC - HVAC Control Module	DATA
GX63-14D520-BE.vbf	Jaguar XF (X260)	HVAC - HVAC Control Module	DATA
GX63-14D520-CC.vbf	Jaguar XF (X260)	HVAC - HVAC Control Module	DATA
GX63-14D520-CD.vbf	Jaguar XF (X260)	HVAC - HVAC Control Module	DATA
GX63-14D520-CE.vbf	Jaguar XF (X260)	HVAC - HVAC Control Module	DATA
GX63-14D520-CF.vbf	Jaguar XF (X260)	HVAC - HVAC Control Module	DATA
GX63-14D520-CG.vbf	Jaguar XF (X260)	HVAC - HVAC Control Module	DATA
GX63-14D520-DC.vbf	Jaguar XF (X260)	HVAC - HVAC Control Module	DATA
GX63-14D520-DD.vbf	Jaguar XF (X260)	HVAC - HVAC Control Module	DATA
GX63-14D520-DE.vbf	Jaguar XF (X260)	HVAC - HVAC Control Module	DATA
GX63-14D564-AA.vbf	Jaguar XF (X260)	SODL - Side Obstacle Detection Control Module - Left	DATA
GX63-14D564-BA.vbf	Jaguar XF (X260)	SODR - Side Obstacle Detection Control Module - Right	DATA
GX63-14E093-BA.vbf	Jaguar XF (X260)	CHCM - Chassis Control Module	EXE
GX63-14E093-BB.vbf	Jaguar XF (X260)	CHCM - Chassis Control Module	EXE
GX63-14E093-BC.vbf	Jaguar XF (X260)	CHCM - Chassis Control Module	EXE
GX63-14E093-DB.vbf	Jaguar XF (X260)	CHCM - Chassis Control Module	EXE
GX63-14E093-DC.vbf	Jaguar XF (X260)	CHCM - Chassis Control Module	EXE
GX63-14E093-DD.vbf	Jaguar XF (X260)	CHCM - Chassis Control Module	EXE
GX63-14E093-DE.vbf	Jaguar XF (X260)	CHCM - Chassis Control Module	EXE
GX63-14E093-DF.vbf	Jaguar XF (X260)	CHCM - Chassis Control Module	EXE
GX63-14E093-DG.vbf	Jaguar XF (X260)	CHCM - Chassis Control Module	EXE
GX63-14E094-DAD.vbf	Jaguar XF (X260)	CHCM - Chassis Control Module	EXE
GX63-14E094-DAE.vbf	Jaguar XF (X260)	CHCM - Chassis Control Module	EXE
GX63-14E094-DBD.vbf	Jaguar XF (X260)	CHCM - Chassis Control Module	EXE
GX63-14E094-DBE.vbf	Jaguar XF (X260)	CHCM - Chassis Control Module	EXE
GX63-14E094-DCD.vbf	Jaguar XF (X260)	CHCM - Chassis Control Module	EXE
GX63-14E094-DCE.vbf	Jaguar XF (X260)	CHCM - Chassis Control Module	EXE
GX63-14E094-DDD.vbf	Jaguar XF (X260)	CHCM - Chassis Control Module	EXE
GX63-14E094-DDE.vbf	Jaguar XF (X260)	CHCM - Chassis Control Module	EXE
GX63-14E094-DED.vbf	Jaguar XF (X260)	CHCM - Chassis Control Module	EXE
GX63-14E094-DEF.vbf	Jaguar XF (X260)	CHCM - Chassis Control Module	EXE
GX63-14F017-AA.vbf	Jaguar XF (X260)	IPMB - Image Processing Module B	EXE
GX63-14F017-AB.vbf	Jaguar XF (X260)	IPMB - Image Processing Module B	EXE
GX63-14F017-AC.vbf	Jaguar XF (X260)	IPMB - Image Processing Module B	EXE
GX63-14F017-BB.vbf	Jaguar XF (X260)	IPMB - Image Processing Module B	EXE
GX63-14F017-BC.vbf	Jaguar XF (X260)	IPMB - Image Processing Module B	EXE

File name	Vehicle line (indicative)	Module (ECU)	Type
GX63-14F017-BD.vbf	Jaguar XF (X260)	IPMB - Image Processing Module B	EXE
GX63-14F022-AA.vbf	Jaguar XF (X260)	IPMB - Image Processing Module B	DATA
GX63-14F022-BA.vbf	Jaguar XF (X260)	IPMB - Image Processing Module B	DATA
GX63-14F022-BB.vbf	Jaguar XF (X260)	IPMB - Image Processing Module B	DATA
GX63-14F022-BC.vbf	Jaguar XF (X260)	IPMB - Image Processing Module B	DATA
GX63-14F022-FA.vbf	Jaguar XF (X260)	IPMB - Image Processing Module B	DATA
GX63-14F022-FB.vbf	Jaguar XF (X260)	IPMB - Image Processing Module B	DATA
GX63-14F022-FC.vbf	Jaguar XF (X260)	IPMB - Image Processing Module B	DATA
GX63-14F216-AA.vbf	Jaguar XF (X260)	RHVAC - Rear HVAC Control Module	SIGCFG
GX63-14F217-AA.vbf	Jaguar XF (X260)	RHVAC - Rear HVAC Control Module	EXE
GX63-14F217-AB.vbf	Jaguar XF (X260)	RHVAC - Rear HVAC Control Module	EXE
GX63-14F218-AA.vbf	Jaguar XF (X260)	RHVAC - Rear HVAC Control Module	CUSTOM
GX63-14F219-AA.vbf	Jaguar XF (X260)	RHVAC - Rear HVAC Control Module	SBL
GX63-14F229-AC.vbf	Jaguar XF (X260)	HUD - Head Up Display	SIGCFG
GX63-14F230-AB.vbf	Jaguar XF (X260)	HUD - Head Up Display	EXE
GX63-14F230-AC.VBF	Jaguar XF (X260)	HUD - Head Up Display	EXE
GX63-14F230-AD.vbf	Jaguar XF (X260)	HUD - Head Up Display	EXE
GX63-14F231-AB.vbf	Jaguar XF (X260)	HUD - Head Up Display	CUSTOM
GX63-14F231-AC.vbf	Jaguar XF (X260)	HUD - Head Up Display	CUSTOM
GX63-14F232-AA.vbf	Jaguar XF (X260)	HUD - Head Up Display	SBL
GX63-14F397-AC.vbf	Jaguar XF (X260)	IPMA - Image Processing Module A	EXE
GX63-14F397-AE.vbf	Jaguar XF (X260)	IPMA - Image Processing Module A	EXE
GX63-14F397-AF.vbf	Jaguar XF (X260)	IPMA - Image Processing Module A	EXE
GX63-14F397-AG.vbf	Jaguar XF (X260)	IPMA - Image Processing Module A	EXE
GX63-14F397-BC.vbf	Jaguar XF (X260)	IPMA - Image Processing Module A	EXE
GX63-14F397-BE.vbf	Jaguar XF (X260)	IPMA - Image Processing Module A	EXE
GX63-14F397-BF.vbf	Jaguar XF (X260)	IPMA - Image Processing Module A	EXE
GX63-14F397-BG.vbf	Jaguar XF (X260)	IPMA - Image Processing Module A	EXE
GX63-14F397-CB.vbf	Jaguar XF (X260)	IPMA - Image Processing Module A	EXE
GX63-14F397-CC.vbf	Jaguar XF (X260)	IPMA - Image Processing Module A	EXE
GX63-14F397-CD.vbf	Jaguar XF (X260)	IPMA - Image Processing Module A	EXE
GX63-14F397-CE.vbf	Jaguar XF (X260)	IPMA - Image Processing Module A	EXE
GX63-14F397-CF.vbf	Jaguar XF (X260)	IPMA - Image Processing Module A	EXE
GX63-14F397-DB.vbf	Jaguar XF (X260)	IPMA - Image Processing Module A	EXE
GX63-14F397-DC.vbf	Jaguar XF (X260)	IPMA - Image Processing Module A	EXE
GX63-14F397-DD.vbf	Jaguar XF (X260)	IPMA - Image Processing Module A	EXE
GX63-14F397-DE.vbf	Jaguar XF (X260)	IPMA - Image Processing Module A	EXE
GX63-14F397-DF.vbf	Jaguar XF (X260)	IPMA - Image Processing Module A	EXE
GX63-14F398-AC.vbf	Jaguar XF (X260)	IPMA - Image Processing Module A	EXE
GX63-14F398-AE.vbf	Jaguar XF (X260)	IPMA - Image Processing Module A	EXE
GX63-14F398-AF.vbf	Jaguar XF (X260)	IPMA - Image Processing Module A	EXE
GX63-14F398-AG.vbf	Jaguar XF (X260)	IPMA - Image Processing Module A	EXE
GX63-14F398-AH.vbf	Jaguar XF (X260)	IPMA - Image Processing Module A	EXE
GX63-14F398-AJ.vbf	Jaguar XF (X260)	IPMA - Image Processing Module A	EXE
GX63-14F398-AK.vbf	Jaguar XF (X260)	IPMA - Image Processing Module A	EXE
GX63-14F398-BB.vbf	Jaguar XF (X260)	IPMA - Image Processing Module A	EXE
GX63-14F398-BC.vbf	Jaguar XF (X260)	IPMA - Image Processing Module A	EXE
GX63-14F398-BD.vbf	Jaguar XF (X260)	IPMA - Image Processing Module A	EXE
GX63-14F398-BE.vbf	Jaguar XF (X260)	IPMA - Image Processing Module A	EXE
GX63-14F398-BF.vbf	Jaguar XF (X260)	IPMA - Image Processing Module A	EXE
GX63-14F398-BG.vbf	Jaguar XF (X260)	IPMA - Image Processing Module A	EXE
GX63-14F398-BH.vbf	Jaguar XF (X260)	IPMA - Image Processing Module A	EXE
GX63-14F398-BJ.vbf	Jaguar XF (X260)	IPMA - Image Processing Module A	EXE
GX63-14F530-AD.vbf	Jaguar XF (X260)	GWM - Gateway Module A	EXE
GX63-14F530-AF.vbf	Jaguar XF (X260)	GWM - Gateway Module A	EXE
GX63-14F530-AG.vbf	Jaguar XF (X260)	GWM - Gateway Module A	EXE
GX63-14F530-AH.vbf	Jaguar XF (X260)	GWM - Gateway Module A	EXE
GX63-14F530-AK.vbf	Jaguar XF (X260)	GWM - Gateway Module A	EXE
GX63-14F530-AL.vbf	Jaguar XF (X260)	GWM - Gateway Module A	EXE
GX63-14F530-AM.vbf	Jaguar XF (X260)	GWM - Gateway Module A	EXE
GX63-14F531-AC.vbf	Jaguar XF (X260)	GWM - Gateway Module A	DATA
GX63-14F531-AD.vbf	Jaguar XF (X260)	GWM - Gateway Module A	DATA
GX63-14F531-AE.vbf	Jaguar XF (X260)	GWM - Gateway Module A	DATA
GX63-14F531-AF.vbf	Jaguar XF (X260)	GWM - Gateway Module A	DATA
GX63-14F531-AG.vbf	Jaguar XF (X260)	GWM - Gateway Module A	DATA
GX63-14F531-AH.vbf	Jaguar XF (X260)	GWM - Gateway Module A	DATA
GX63-19C204-AA.vbf	Jaguar XF (X260)	IMC - Infotainment Master Controller	EXE
GX63-19C204-AC.vbf	Jaguar XF (X260)	IMC - Infotainment Master Controller	EXE
GX63-19C293-AE.vbf	Jaguar XF (X260)	ACM - Audio Front Control Module	EXE
GX63-19C293-CE.vbf	Jaguar XF (X260)	ACM - Audio Front Control Module	DATA
GX63-19C295-AE.vbf	Jaguar XF (X260)	ACM - Audio Front Control Module	SBL
GX63-19H527-AB.vbf	Jaguar XF (X260)	ACCM - Air Conditioning Control Module	EXE
GX63-19H529-AA.vbf	Jaguar XF (X260)	AUCM - Auxilliary Control Module	SBL
GX63-70713-BH.vbf	Jaguar XF (X260)	TCU - Telematic Control Unit Module	DATA
GX63-70713-BK.vbf	Jaguar XF (X260)	TCU - Telematic Control Unit Module	DATA
GX63-70713-BL.vbf	Jaguar XF (X260)	TCU - Telematic Control Unit Module	DATA

File name	Vehicle line (indicative)	Module (ECU)	Type
GX63-70713-BM.vbf	Jaguar XF (X260)	TCU - Telematic Control Unit Module	DATA
GX63-70713-BN.vbf	Jaguar XF (X260)	TCU - Telematic Control Unit Module	DATA
GX63-70713-BP.vbf	Jaguar XF (X260)	TCU - Telematic Control Unit Module	DATA
GX63-70713-BR.vbf	Jaguar XF (X260)	TCU - Telematic Control Unit Module	DATA
GX63-70713-BS.vbf	Jaguar XF (X260)	TCU - Telematic Control Unit Module	DATA
GX63-70713-BT.vbf	Jaguar XF (X260)	TCU - Telematic Control Unit Module	DATA
GX63-70713-CH.vbf	Jaguar XF (X260)	TCU - Telematic Control Unit Module	DATA
GX63-70713-CK.vbf	Jaguar XF (X260)	TCU - Telematic Control Unit Module	DATA
GX63-70713-CL.vbf	Jaguar XF (X260)	TCU - Telematic Control Unit Module	DATA
GX63-70713-CM.vbf	Jaguar XF (X260)	TCU - Telematic Control Unit Module	DATA
GX63-70713-CN.vbf	Jaguar XF (X260)	TCU - Telematic Control Unit Module	DATA
GX63-70713-CP.vbf	Jaguar XF (X260)	TCU - Telematic Control Unit Module	DATA
GX63-70713-CR.vbf	Jaguar XF (X260)	TCU - Telematic Control Unit Module	DATA
GX63-70713-CS.vbf	Jaguar XF (X260)	TCU - Telematic Control Unit Module	DATA
GX63-70713-CT.vbf	Jaguar XF (X260)	TCU - Telematic Control Unit Module	DATA
GX63-70713-DC.vbf	Jaguar XF (X260)	TCU - Telematic Control Unit Module	DATA
GX63-70713-DE.vbf	Jaguar XF (X260)	TCU - Telematic Control Unit Module	DATA
GX63-70713-DF.vbf	Jaguar XF (X260)	TCU - Telematic Control Unit Module	DATA
GX63-70713-DG.vbf	Jaguar XF (X260)	TCU - Telematic Control Unit Module	DATA
GX63-70713-DH.vbf	Jaguar XF (X260)	TCU - Telematic Control Unit Module	DATA
GX63-70713-DJ.vbf	Jaguar XF (X260)	TCU - Telematic Control Unit Module	DATA
GX63-70713-DL.vbf	Jaguar XF (X260)	TCU - Telematic Control Unit Module	DATA
GX63-70713-DM.vbf	Jaguar XF (X260)	TCU - Telematic Control Unit Module	DATA
GX63-70713-DN.vbf	Jaguar XF (X260)	TCU - Telematic Control Unit Module	DATA
GX63-70713-EC.vbf	Jaguar XF (X260)	TCU - Telematic Control Unit Module	DATA
GX63-70713-EE.vbf	Jaguar XF (X260)	TCU - Telematic Control Unit Module	DATA
GX63-70713-EF.vbf	Jaguar XF (X260)	TCU - Telematic Control Unit Module	DATA
GX63-70713-EG.vbf	Jaguar XF (X260)	TCU - Telematic Control Unit Module	DATA
GX63-70713-EH.vbf	Jaguar XF (X260)	TCU - Telematic Control Unit Module	DATA
GX63-70713-EJ.vbf	Jaguar XF (X260)	TCU - Telematic Control Unit Module	DATA
GX63-70713-EK.vbf	Jaguar XF (X260)	TCU - Telematic Control Unit Module	DATA
GX63-70713-EL.vbf	Jaguar XF (X260)	TCU - Telematic Control Unit Module	DATA
GX63-70713-EM.vbf	Jaguar XF (X260)	TCU - Telematic Control Unit Module	DATA
GX63-70713-JC.vbf	Jaguar XF (X260)	TCU - Telematic Control Unit Module	DATA
GX63-70713-JE.vbf	Jaguar XF (X260)	TCU - Telematic Control Unit Module	DATA
GX63-70713-JF.vbf	Jaguar XF (X260)	TCU - Telematic Control Unit Module	DATA
GX63-70713-JG.vbf	Jaguar XF (X260)	TCU - Telematic Control Unit Module	DATA
GX63-70713-JH.vbf	Jaguar XF (X260)	TCU - Telematic Control Unit Module	DATA
GX63-70713-JJ.vbf	Jaguar XF (X260)	TCU - Telematic Control Unit Module	DATA
GX63-70713-JL.vbf	Jaguar XF (X260)	TCU - Telematic Control Unit Module	DATA
GX63-70713-JM.vbf	Jaguar XF (X260)	TCU - Telematic Control Unit Module	DATA
GX63-70713-KC.vbf	Jaguar XF (X260)	TCU - Telematic Control Unit Module	DATA
GX63-70713-KE.vbf	Jaguar XF (X260)	TCU - Telematic Control Unit Module	DATA
GX63-70713-KF.vbf	Jaguar XF (X260)	TCU - Telematic Control Unit Module	DATA
GX63-70713-KG.vbf	Jaguar XF (X260)	TCU - Telematic Control Unit Module	DATA
GX63-70713-KH.vbf	Jaguar XF (X260)	TCU - Telematic Control Unit Module	DATA
GX63-70713-KJ.vbf	Jaguar XF (X260)	TCU - Telematic Control Unit Module	DATA
GX63-70713-KL.vbf	Jaguar XF (X260)	TCU - Telematic Control Unit Module	DATA
GX63-70713-KM.vbf	Jaguar XF (X260)	TCU - Telematic Control Unit Module	DATA
GX63-70713-KN.vbf	Jaguar XF (X260)	TCU - Telematic Control Unit Module	DATA
GX63-70713-MAA.vbf	Jaguar XF (X260)	TCU - Telematic Control Unit Module	DATA
GX63-70713-MN.vbf	Jaguar XF (X260)	TCU - Telematic Control Unit Module	DATA
GX63-70713-MR.vbf	Jaguar XF (X260)	TCU - Telematic Control Unit Module	DATA
GX63-70713-MS.vbf	Jaguar XF (X260)	TCU - Telematic Control Unit Module	DATA
GX63-70713-MT.vbf	Jaguar XF (X260)	TCU - Telematic Control Unit Module	DATA
GX63-70713-MV.vbf	Jaguar XF (X260)	TCU - Telematic Control Unit Module	DATA
GX63-70713-MX.vbf	Jaguar XF (X260)	TCU - Telematic Control Unit Module	DATA
GX63-70713-MZ.vbf	Jaguar XF (X260)	TCU - Telematic Control Unit Module	DATA
GX63-70713-NAA.vbf	Jaguar XF (X260)	TCU - Telematic Control Unit Module	DATA
GX63-70713-NN.vbf	Jaguar XF (X260)	TCU - Telematic Control Unit Module	DATA
GX63-70713-NR.vbf	Jaguar XF (X260)	TCU - Telematic Control Unit Module	DATA
GX63-70713-NS.vbf	Jaguar XF (X260)	TCU - Telematic Control Unit Module	DATA
GX63-70713-NT.vbf	Jaguar XF (X260)	TCU - Telematic Control Unit Module	DATA
GX63-70713-NV.vbf	Jaguar XF (X260)	TCU - Telematic Control Unit Module	DATA
GX63-70713-NX.vbf	Jaguar XF (X260)	TCU - Telematic Control Unit Module	DATA
GX63-70713-NY.vbf	Jaguar XF (X260)	TCU - Telematic Control Unit Module	DATA
GX63-70713-NZ.vbf	Jaguar XF (X260)	TCU - Telematic Control Unit Module	DATA
GX63-70713-RJ.vbf	Jaguar XF (X260)	TCU - Telematic Control Unit Module	DATA
GX63-70713-RK.vbf	Jaguar XF (X260)	TCU - Telematic Control Unit Module	DATA
GX63-70713-RL.vbf	Jaguar XF (X260)	TCU - Telematic Control Unit Module	DATA
GX63-70713-RM.vbf	Jaguar XF (X260)	TCU - Telematic Control Unit Module	DATA
GX63-70713-RN.vbf	Jaguar XF (X260)	TCU - Telematic Control Unit Module	DATA
GX63-70713-RP.vbf	Jaguar XF (X260)	TCU - Telematic Control Unit Module	DATA
GX63-70713-RR.vbf	Jaguar XF (X260)	TCU - Telematic Control Unit Module	DATA
GX63-70713-RS.vbf	Jaguar XF (X260)	TCU - Telematic Control Unit Module	DATA
GX63-70713-RT.vbf	Jaguar XF (X260)	TCU - Telematic Control Unit Module	DATA

File name	Vehicle line (indicative)	Module (ECU)	Type
GX63-70713-RV.vbf	Jaguar XF (X260)	TCU - Telematic Control Unit Module	DATA
GX63-70713-SJ.vbf	Jaguar XF (X260)	TCU - Telematic Control Unit Module	DATA
GX63-70713-SK.vbf	Jaguar XF (X260)	TCU - Telematic Control Unit Module	DATA
GX63-70713-SL.vbf	Jaguar XF (X260)	TCU - Telematic Control Unit Module	DATA
GX63-70713-SM.vbf	Jaguar XF (X260)	TCU - Telematic Control Unit Module	DATA
GX63-70713-SN.vbf	Jaguar XF (X260)	TCU - Telematic Control Unit Module	DATA
GX63-70713-SP.vbf	Jaguar XF (X260)	TCU - Telematic Control Unit Module	DATA
GX63-70713-SR.vbf	Jaguar XF (X260)	TCU - Telematic Control Unit Module	DATA
GX63-70713-SS.vbf	Jaguar XF (X260)	TCU - Telematic Control Unit Module	DATA
GX63-70713-ST.vbf	Jaguar XF (X260)	TCU - Telematic Control Unit Module	DATA
GX63-70713-SV.vbf	Jaguar XF (X260)	TCU - Telematic Control Unit Module	DATA
GX63-70713-TB.vbf	Jaguar XF (X260)	TCU - Telematic Control Unit Module	DATA
GX63-70713-TD.vbf	Jaguar XF (X260)	TCU - Telematic Control Unit Module	DATA
GX63-70713-TE.vbf	Jaguar XF (X260)	TCU - Telematic Control Unit Module	DATA
GX63-70713-TF.vbf	Jaguar XF (X260)	TCU - Telematic Control Unit Module	DATA
GX63-70713-TG.vbf	Jaguar XF (X260)	TCU - Telematic Control Unit Module	DATA
GX63-70713-TH.vbf	Jaguar XF (X260)	TCU - Telematic Control Unit Module	DATA
GX63-70713-TK.vbf	Jaguar XF (X260)	TCU - Telematic Control Unit Module	DATA
GX63-70713-TL.vbf	Jaguar XF (X260)	TCU - Telematic Control Unit Module	DATA
GX63-70713-TM.vbf	Jaguar XF (X260)	TCU - Telematic Control Unit Module	DATA
GX63-70713-VB.vbf	Jaguar XF (X260)	TCU - Telematic Control Unit Module	DATA
GX63-70713-VD.vbf	Jaguar XF (X260)	TCU - Telematic Control Unit Module	DATA
GX63-70713-VE.vbf	Jaguar XF (X260)	TCU - Telematic Control Unit Module	DATA
GX63-70713-VF.vbf	Jaguar XF (X260)	TCU - Telematic Control Unit Module	DATA
GX63-70713-VG.vbf	Jaguar XF (X260)	TCU - Telematic Control Unit Module	DATA
GX63-70713-VH.vbf	Jaguar XF (X260)	TCU - Telematic Control Unit Module	DATA
GX63-70713-VJ.vbf	Jaguar XF (X260)	TCU - Telematic Control Unit Module	DATA
GX63-70713-VK.vbf	Jaguar XF (X260)	TCU - Telematic Control Unit Module	DATA
GX63-70713-VL.vbf	Jaguar XF (X260)	TCU - Telematic Control Unit Module	DATA
GX63-7J104-BCB.vbf	Jaguar XF (X260)	TCM - Transmission Control Module	EXE
GX63-7J104-BCC.vbf	Jaguar XF (X260)	TCM - Transmission Control Module	EXE
GX63-7J104-BCD.vbf	Jaguar XF (X260)	TCM - Transmission Control Module	EXE
GX63-7J104-BCE.vbf	Jaguar XF (X260)	TCM - Transmission Control Module	EXE
GX63-7J104-BDB.vbf	Jaguar XF (X260)	TCM - Transmission Control Module	EXE
GX63-7J104-BDC.vbf	Jaguar XF (X260)	TCM - Transmission Control Module	EXE
GX63-7J104-BDD.vbf	Jaguar XF (X260)	TCM - Transmission Control Module	EXE
GX63-7J104-BDE.vbf	Jaguar XF (X260)	TCM - Transmission Control Module	EXE
GX63-7J104-BFB.vbf	Jaguar XF (X260)	TCM - Transmission Control Module	EXE
GX63-7J104-BFC.vbf	Jaguar XF (X260)	TCM - Transmission Control Module	EXE
GX63-7J104-BFD.vbf	Jaguar XF (X260)	TCM - Transmission Control Module	EXE
GX63-7J104-BFF.vbf	Jaguar XF (X260)	TCM - Transmission Control Module	EXE
GX63-7J104-BGB.vbf	Jaguar XF (X260)	TCM - Transmission Control Module	EXE
GX63-7J104-BGC.vbf	Jaguar XF (X260)	TCM - Transmission Control Module	EXE
GX63-7J104-BGD.vbf	Jaguar XF (X260)	TCM - Transmission Control Module	EXE
GX63-7J104-BGE.vbf	Jaguar XF (X260)	TCM - Transmission Control Module	EXE
GX63-7J104-BHB.vbf	Jaguar XF (X260)	TCM - Transmission Control Module	EXE
GX63-7J104-BHC.vbf	Jaguar XF (X260)	TCM - Transmission Control Module	EXE
GX63-7J104-BHD.vbf	Jaguar XF (X260)	TCM - Transmission Control Module	EXE
GX63-7J104-BHE.vbf	Jaguar XF (X260)	TCM - Transmission Control Module	EXE
GX63-7J104-BHF.vbf	Jaguar XF (X260)	TCM - Transmission Control Module	EXE
GX63-7J104-BLA.vbf	Jaguar XF (X260)	TCM - Transmission Control Module	EXE
GX63-7J104-BLB.vbf	Jaguar XF (X260)	TCM - Transmission Control Module	EXE
GX63-7J104-BLC.vbf	Jaguar XF (X260)	TCM - Transmission Control Module	EXE
GX63-7J104-BLD.vbf	Jaguar XF (X260)	TCM - Transmission Control Module	EXE
GX63-7J104-BLE.vbf	Jaguar XF (X260)	TCM - Transmission Control Module	EXE
GX63-7J104-BMA.vbf	Jaguar XF (X260)	TCM - Transmission Control Module	EXE
GX63-7J104-BMB.vbf	Jaguar XF (X260)	TCM - Transmission Control Module	EXE
GX63-7J104-BMC.vbf	Jaguar XF (X260)	TCM - Transmission Control Module	EXE
GX63-7J104-BPB.vbf	Jaguar XF (X260)	TCM - Transmission Control Module	EXE
GX63-7J104-BPC.vbf	Jaguar XF (X260)	TCM - Transmission Control Module	EXE
GX63-7J104-BPD.vbf	Jaguar XF (X260)	TCM - Transmission Control Module	EXE
GX63-7J104-BPE.vbf	Jaguar XF (X260)	TCM - Transmission Control Module	EXE
GX6M-14C152-AA.vbf	Not specified	TPM - Tire Pressure Monitor Module	DATA
GX73-12K532-FAB.vbf	Jaguar XE (X760)	PCM - Powertrain Control Module	DATA
GX73-12K532-FAC.vbf	Jaguar XE (X760)	PCM - Powertrain Control Module	DATA
GX73-12K532-FAD.vbf	Jaguar XE (X760)	PCM - Powertrain Control Module	DATA
GX73-12K532-FAE.vbf	Jaguar XE (X760)	PCM - Powertrain Control Module	DATA
GX73-12K532-FAF.vbf	Jaguar XE (X760)	PCM - Powertrain Control Module	DATA
GX73-12K532-FAG.vbf	Jaguar XE (X760)	PCM - Powertrain Control Module	DATA
GX73-12K532-FAH.vbf	Jaguar XE (X760)	PCM - Powertrain Control Module	DATA
GX73-12K532-FAJ.vbf	Jaguar XE (X760)	PCM - Powertrain Control Module	DATA
GX73-12K532-FBB.vbf	Jaguar XE (X760)	PCM - Powertrain Control Module	DATA
GX73-12K532-FBC.vbf	Jaguar XE (X760)	PCM - Powertrain Control Module	DATA
GX73-12K532-FBD.vbf	Jaguar XE (X760)	PCM - Powertrain Control Module	DATA
GX73-12K532-FBE.vbf	Jaguar XE (X760)	PCM - Powertrain Control Module	DATA
GX73-12K532-FBF.vbf	Jaguar XE (X760)	PCM - Powertrain Control Module	DATA

File name	Vehicle line (indicative)	Module (ECU)	Type
GX73-12K532-FBG.vbf	Jaguar XE (X760)	PCM - Powertrain Control Module	DATA
GX73-12K532-FBH.vbf	Jaguar XE (X760)	PCM - Powertrain Control Module	DATA
GX73-12K532-FCA.vbf	Jaguar XE (X760)	PCM - Powertrain Control Module	DATA
GX73-12K532-FCB.vbf	Jaguar XE (X760)	PCM - Powertrain Control Module	DATA
GX73-12K532-FCC.vbf	Jaguar XE (X760)	PCM - Powertrain Control Module	DATA
GX73-12K532-FCD.vbf	Jaguar XE (X760)	PCM - Powertrain Control Module	DATA
GX73-12K532-FCE.vbf	Jaguar XE (X760)	PCM - Powertrain Control Module	DATA
GX73-12K532-FDB.vbf	Jaguar XE (X760)	PCM - Powertrain Control Module	DATA
GX73-12K532-FDC.vbf	Jaguar XE (X760)	PCM - Powertrain Control Module	DATA
GX73-12K532-FDD.vbf	Jaguar XE (X760)	PCM - Powertrain Control Module	DATA
GX73-12K532-FGA.vbf	Jaguar XE (X760)	PCM - Powertrain Control Module	DATA
GX73-12K532-FGB.vbf	Jaguar XE (X760)	PCM - Powertrain Control Module	DATA
GX73-12K532-FGC.vbf	Jaguar XE (X760)	PCM - Powertrain Control Module	DATA
GX73-12K532-FGD.vbf	Jaguar XE (X760)	PCM - Powertrain Control Module	DATA
GX73-12K532-FGE.vbf	Jaguar XE (X760)	PCM - Powertrain Control Module	DATA
GX73-12K532-FGF.vbf	Jaguar XE (X760)	PCM - Powertrain Control Module	DATA
GX73-12K532-FHA.vbf	Jaguar XE (X760)	PCM - Powertrain Control Module	DATA
GX73-12K532-FHB.vbf	Jaguar XE (X760)	PCM - Powertrain Control Module	DATA
GX73-12K532-FHC.vbf	Jaguar XE (X760)	PCM - Powertrain Control Module	DATA
GX73-12K532-FHD.vbf	Jaguar XE (X760)	PCM - Powertrain Control Module	DATA
GX73-12K532-FHE.vbf	Jaguar XE (X760)	PCM - Powertrain Control Module	DATA
GX73-12K532-FHF.vbf	Jaguar XE (X760)	PCM - Powertrain Control Module	DATA
GX73-12K532-FJA.vbf	Jaguar XE (X760)	PCM - Powertrain Control Module	DATA
GX73-12K532-FJB.vbf	Jaguar XE (X760)	PCM - Powertrain Control Module	DATA
GX73-12K532-FJC.vbf	Jaguar XE (X760)	PCM - Powertrain Control Module	DATA
GX73-12K532-FJD.vbf	Jaguar XE (X760)	PCM - Powertrain Control Module	DATA
GX73-12K532-FJE.vbf	Jaguar XE (X760)	PCM - Powertrain Control Module	DATA
GX73-12K532-FJF.vbf	Jaguar XE (X760)	PCM - Powertrain Control Module	DATA
GX73-12K532-FKA.vbf	Jaguar XE (X760)	PCM - Powertrain Control Module	DATA
GX73-12K532-FKB.vbf	Jaguar XE (X760)	PCM - Powertrain Control Module	DATA
GX73-12K532-FKC.vbf	Jaguar XE (X760)	PCM - Powertrain Control Module	DATA
GX73-12K532-FKD.vbf	Jaguar XE (X760)	PCM - Powertrain Control Module	DATA
GX73-12K532-FKE.vbf	Jaguar XE (X760)	PCM - Powertrain Control Module	DATA
GX73-12K532-FKF.vbf	Jaguar XE (X760)	PCM - Powertrain Control Module	DATA
GX73-12K532-FLA.vbf	Jaguar XE (X760)	PCM - Powertrain Control Module	DATA
GX73-12K532-FLB.vbf	Jaguar XE (X760)	PCM - Powertrain Control Module	DATA
GX73-12K532-FLC.vbf	Jaguar XE (X760)	PCM - Powertrain Control Module	DATA
GX73-12K532-FLD.vbf	Jaguar XE (X760)	PCM - Powertrain Control Module	DATA
GX73-12K532-FLE.vbf	Jaguar XE (X760)	PCM - Powertrain Control Module	DATA
GX73-12K532-FLF.vbf	Jaguar XE (X760)	PCM - Powertrain Control Module	DATA
GX73-12K532-FLG.vbf	Jaguar XE (X760)	PCM - Powertrain Control Module	DATA
GX73-12K532-FLH.vbf	Jaguar XE (X760)	PCM - Powertrain Control Module	DATA
GX73-12K532-FTA.vbf	Jaguar XE (X760)	PCM - Powertrain Control Module	DATA
GX73-12K532-FVA.vbf	Jaguar XE (X760)	PCM - Powertrain Control Module	DATA
GX73-12K532-FXA.vbf	Jaguar XE (X760)	PCM - Powertrain Control Module	DATA
GX73-12K532-FYA.vbf	Jaguar XE (X760)	PCM - Powertrain Control Module	DATA
GX73-12K532-FZA.vbf	Jaguar XE (X760)	PCM - Powertrain Control Module	DATA
GX73-12K532-SAA.vbf	Jaguar XE (X760)	PCM - Powertrain Control Module	DATA
GX73-12K532-SAB.vbf	Jaguar XE (X760)	PCM - Powertrain Control Module	DATA
GX73-12K532-SAC.vbf	Jaguar XE (X760)	PCM - Powertrain Control Module	DATA
GX73-12K532-SAD.vbf	Jaguar XE (X760)	PCM - Powertrain Control Module	DATA
GX73-12K532-SAE.vbf	Jaguar XE (X760)	PCM - Powertrain Control Module	DATA
GX73-12K532-SAF.vbf	Jaguar XE (X760)	PCM - Powertrain Control Module	DATA
GX73-12K532-SAG.vbf	Jaguar XE (X760)	PCM - Powertrain Control Module	DATA
GX73-12K532-SBB.vbf	Jaguar XE (X760)	PCM - Powertrain Control Module	DATA
GX73-12K532-SBC.vbf	Jaguar XE (X760)	PCM - Powertrain Control Module	DATA
GX73-12K532-SBD.vbf	Jaguar XE (X760)	PCM - Powertrain Control Module	DATA
GX73-12K532-SBE.vbf	Jaguar XE (X760)	PCM - Powertrain Control Module	DATA
GX73-12K532-SBF.vbf	Jaguar XE (X760)	PCM - Powertrain Control Module	DATA
GX73-12K532-SBG.vbf	Jaguar XE (X760)	PCM - Powertrain Control Module	DATA
GX73-12K532-SBH.vbf	Jaguar XE (X760)	PCM - Powertrain Control Module	DATA
GX73-14B793-AE.vbf	Jaguar XE (X760)	ATCM - All Terrain Control Module	EXE
GX73-14B793-AF.vbf	Jaguar XE (X760)	ATCM - All Terrain Control Module	EXE
GX73-14C026-AA.vbf	Jaguar XE (X760)	IPC - Instrument Panel Cluster (IPC) Control Module	EXE
GX73-14C026-AB.vbf	Jaguar XE (X760)	IPC - Instrument Panel Cluster (IPC) Control Module	EXE
GX73-14C026-AC.vbf	Jaguar XE (X760)	IPC - Instrument Panel Cluster (IPC) Control Module	EXE
GX73-14C026-AD.vbf	Jaguar XE (X760)	IPC - Instrument Panel Cluster (IPC) Control Module	EXE
GX73-14C026-AE.vbf	Jaguar XE (X760)	IPC - Instrument Panel Cluster (IPC) Control Module	EXE
GX73-14C026-AF.vbf	Jaguar XE (X760)	IPC - Instrument Panel Cluster (IPC) Control Module	EXE
GX73-14C030-BB.vbf	Jaguar XE (X760)	DSM - Driver Front Seat Module	EXE
GX73-14C034-AA.vbf	Range Rover Sport (L494)	DSM - Driver Front Seat Module	DATA
GX73-14C034-BB.vbf	Jaguar XE (X760)	DSM - Driver Front Seat Module	DATA
GX73-14C036-AE.vbf	Jaguar XE (X760)	SPCM - Secondary Powertrain Control Module	EXE
GX73-14C036-AF.vbf	Jaguar XE (X760)	SPCM - Secondary Powertrain Control Module	EXE
GX73-14C036-AG.vbf	Jaguar XE (X760)	SPCM - Secondary Powertrain Control Module	EXE
GX73-14C036-AH.vbf	Jaguar XE (X760)	SPCM - Secondary Powertrain Control Module	EXE

File name	Vehicle line (indicative)	Module (ECU)	Type
GX73-14C036-AJ.vbf	Jaguar XE (X760)	SPCM - Secondary Powertrain Control Module	EXE
GX73-14C036-BE.vbf	Jaguar XE (X760)	SPCM - Secondary Powertrain Control Module	EXE
GX73-14C036-BF.vbf	Jaguar XE (X760)	SPCM - Secondary Powertrain Control Module	EXE
GX73-14C036-BG.vbf	Jaguar XE (X760)	SPCM - Secondary Powertrain Control Module	EXE
GX73-14C036-BH.vbf	Jaguar XE (X760)	SPCM - Secondary Powertrain Control Module	EXE
GX73-14C036-BJ.vbf	Jaguar XE (X760)	SPCM - Secondary Powertrain Control Module	EXE
GX73-14C037-AJE.vbf	Jaguar XE (X760)	SPCM - Secondary Powertrain Control Module	EXE
GX73-14C037-AJF.vbf	Jaguar XE (X760)	SPCM - Secondary Powertrain Control Module	EXE
GX73-14C037-AJG.vbf	Jaguar XE (X760)	SPCM - Secondary Powertrain Control Module	EXE
GX73-14C037-AJH.vbf	Jaguar XE (X760)	SPCM - Secondary Powertrain Control Module	EXE
GX73-14C037-AJJ.vbf	Jaguar XE (X760)	SPCM - Secondary Powertrain Control Module	DATA
GX73-14C037-ALE.vbf	Jaguar XE (X760)	SPCM - Secondary Powertrain Control Module	EXE
GX73-14C037-ALF.vbf	Jaguar XE (X760)	SPCM - Secondary Powertrain Control Module	EXE
GX73-14C037-ALG.vbf	Jaguar XE (X760)	SPCM - Secondary Powertrain Control Module	EXE
GX73-14C037-ALH.vbf	Jaguar XE (X760)	SPCM - Secondary Powertrain Control Module	EXE
GX73-14C037-ALJ.vbf	Jaguar XE (X760)	SPCM - Secondary Powertrain Control Module	DATA
GX73-14C037-ANE.vbf	Jaguar XE (X760)	SPCM - Secondary Powertrain Control Module	EXE
GX73-14C037-ANF.vbf	Jaguar XE (X760)	SPCM - Secondary Powertrain Control Module	EXE
GX73-14C037-ANG.vbf	Jaguar XE (X760)	SPCM - Secondary Powertrain Control Module	EXE
GX73-14C037-ANH.vbf	Jaguar XE (X760)	SPCM - Secondary Powertrain Control Module	EXE
GX73-14C037-ANJ.vbf	Jaguar XE (X760)	SPCM - Secondary Powertrain Control Module	DATA
GX73-14C037-ATE.vbf	Jaguar XE (X760)	SPCM - Secondary Powertrain Control Module	EXE
GX73-14C037-ATF.vbf	Jaguar XE (X760)	SPCM - Secondary Powertrain Control Module	EXE
GX73-14C037-ATG.vbf	Jaguar XE (X760)	SPCM - Secondary Powertrain Control Module	EXE
GX73-14C037-ATH.vbf	Jaguar XE (X760)	SPCM - Secondary Powertrain Control Module	EXE
GX73-14C037-ATJ.vbf	Jaguar XE (X760)	SPCM - Secondary Powertrain Control Module	DATA
GX73-14C037-BLE.vbf	Jaguar XE (X760)	SPCM - Secondary Powertrain Control Module	EXE
GX73-14C037-BLF.vbf	Jaguar XE (X760)	SPCM - Secondary Powertrain Control Module	EXE
GX73-14C037-BLG.vbf	Jaguar XE (X760)	SPCM - Secondary Powertrain Control Module	EXE
GX73-14C037-BLH.vbf	Jaguar XE (X760)	SPCM - Secondary Powertrain Control Module	EXE
GX73-14C037-BLJ.vbf	Jaguar XE (X760)	SPCM - Secondary Powertrain Control Module	DATA
GX73-14C037-BNE.vbf	Jaguar XE (X760)	SPCM - Secondary Powertrain Control Module	EXE
GX73-14C037-BNF.vbf	Jaguar XE (X760)	SPCM - Secondary Powertrain Control Module	EXE
GX73-14C037-BNG.vbf	Jaguar XE (X760)	SPCM - Secondary Powertrain Control Module	EXE
GX73-14C037-BNH.vbf	Jaguar XE (X760)	SPCM - Secondary Powertrain Control Module	EXE
GX73-14C037-BNJ.vbf	Jaguar XE (X760)	SPCM - Secondary Powertrain Control Module	DATA
GX73-14C037-BRE.vbf	Jaguar XE (X760)	SPCM - Secondary Powertrain Control Module	EXE
GX73-14C037-BYE.vbf	Jaguar XE (X760)	SPCM - Secondary Powertrain Control Module	EXE
GX73-14C037-BYF.vbf	Jaguar XE (X760)	SPCM - Secondary Powertrain Control Module	EXE
GX73-14C037-BYG.vbf	Jaguar XE (X760)	SPCM - Secondary Powertrain Control Module	EXE
GX73-14C037-BYH.vbf	Jaguar XE (X760)	SPCM - Secondary Powertrain Control Module	EXE
GX73-14C037-BYJ.vbf	Jaguar XE (X760)	SPCM - Secondary Powertrain Control Module	DATA
GX73-14C037-CBE.vbf	Jaguar XE (X760)	SPCM - Secondary Powertrain Control Module	EXE
GX73-14C037-CBF.vbf	Jaguar XE (X760)	SPCM - Secondary Powertrain Control Module	EXE
GX73-14C037-CBG.vbf	Jaguar XE (X760)	SPCM - Secondary Powertrain Control Module	EXE
GX73-14C037-CBH.vbf	Jaguar XE (X760)	SPCM - Secondary Powertrain Control Module	EXE
GX73-14C037-CBJ.vbf	Jaguar XE (X760)	SPCM - Secondary Powertrain Control Module	DATA
GX73-14C037-CJE.vbf	Jaguar XE (X760)	SPCM - Secondary Powertrain Control Module	EXE
GX73-14C037-CJF.vbf	Jaguar XE (X760)	SPCM - Secondary Powertrain Control Module	EXE
GX73-14C037-CJG.vbf	Jaguar XE (X760)	SPCM - Secondary Powertrain Control Module	EXE
GX73-14C037-CJH.vbf	Jaguar XE (X760)	SPCM - Secondary Powertrain Control Module	EXE
GX73-14C037-CJJ.vbf	Jaguar XE (X760)	SPCM - Secondary Powertrain Control Module	DATA
GX73-14C037-CKE.vbf	Jaguar XE (X760)	SPCM - Secondary Powertrain Control Module	EXE
GX73-14C037-CKF.vbf	Jaguar XE (X760)	SPCM - Secondary Powertrain Control Module	EXE
GX73-14C037-CKG.vbf	Jaguar XE (X760)	SPCM - Secondary Powertrain Control Module	EXE
GX73-14C037-CKH.vbf	Jaguar XE (X760)	SPCM - Secondary Powertrain Control Module	EXE
GX73-14C037-CKJ.vbf	Jaguar XE (X760)	SPCM - Secondary Powertrain Control Module	DATA
GX73-14C037-CNE.vbf	Jaguar XE (X760)	SPCM - Secondary Powertrain Control Module	EXE
GX73-14C037-CNF.vbf	Jaguar XE (X760)	SPCM - Secondary Powertrain Control Module	EXE
GX73-14C037-CNG.vbf	Jaguar XE (X760)	SPCM - Secondary Powertrain Control Module	EXE
GX73-14C037-CNH.vbf	Jaguar XE (X760)	SPCM - Secondary Powertrain Control Module	EXE
GX73-14C037-CNJ.vbf	Jaguar XE (X760)	SPCM - Secondary Powertrain Control Module	DATA
GX73-14C037-CPE.vbf	Jaguar XE (X760)	SPCM - Secondary Powertrain Control Module	EXE
GX73-14C037-CPF.vbf	Jaguar XE (X760)	SPCM - Secondary Powertrain Control Module	EXE
GX73-14C037-CPG.vbf	Jaguar XE (X760)	SPCM - Secondary Powertrain Control Module	EXE
GX73-14C037-CPH.vbf	Jaguar XE (X760)	SPCM - Secondary Powertrain Control Module	EXE
GX73-14C037-CPJ.vbf	Jaguar XE (X760)	SPCM - Secondary Powertrain Control Module	DATA
GX73-14C037-CSE.vbf	Jaguar XE (X760)	SPCM - Secondary Powertrain Control Module	EXE
GX73-14C037-CSF.vbf	Jaguar XE (X760)	SPCM - Secondary Powertrain Control Module	EXE
GX73-14C037-CSG.vbf	Jaguar XE (X760)	SPCM - Secondary Powertrain Control Module	EXE
GX73-14C037-CSH.vbf	Jaguar XE (X760)	SPCM - Secondary Powertrain Control Module	EXE
GX73-14C037-CSJ.vbf	Jaguar XE (X760)	SPCM - Secondary Powertrain Control Module	DATA
GX73-14C037-CXE.vbf	Jaguar XE (X760)	SPCM - Secondary Powertrain Control Module	EXE
GX73-14C037-CXF.vbf	Jaguar XE (X760)	SPCM - Secondary Powertrain Control Module	EXE
GX73-14C037-CXG.vbf	Jaguar XE (X760)	SPCM - Secondary Powertrain Control Module	EXE
GX73-14C037-CXH.vbf	Jaguar XE (X760)	SPCM - Secondary Powertrain Control Module	EXE

File name	Vehicle line (indicative)	Module (ECU)	Type
GX73-14C037-CXJ.vbf	Jaguar XE (X760)	SPCM - Secondary Powertrain Control Module	DATA
GX73-14C037-CYG.vbf	Jaguar XE (X760)	SPCM - Secondary Powertrain Control Module	EXE
GX73-14C037-CYH.vbf	Jaguar XE (X760)	SPCM - Secondary Powertrain Control Module	EXE
GX73-14C037-CYJ.vbf	Jaguar XE (X760)	SPCM - Secondary Powertrain Control Module	DATA
GX73-14C037-MJE.vbf	Jaguar XE (X760)	SPCM - Secondary Powertrain Control Module	EXE
GX73-14C037-MJF.vbf	Jaguar XE (X760)	SPCM - Secondary Powertrain Control Module	EXE
GX73-14C037-MJG.vbf	Jaguar XE (X760)	SPCM - Secondary Powertrain Control Module	EXE
GX73-14C037-MJH.vbf	Jaguar XE (X760)	SPCM - Secondary Powertrain Control Module	EXE
GX73-14C037-MJJ.vbf	Jaguar XE (X760)	SPCM - Secondary Powertrain Control Module	DATA
GX73-14C037-MLE.vbf	Jaguar XE (X760)	SPCM - Secondary Powertrain Control Module	EXE
GX73-14C037-MLF.vbf	Jaguar XE (X760)	SPCM - Secondary Powertrain Control Module	EXE
GX73-14C037-MLG.vbf	Jaguar XE (X760)	SPCM - Secondary Powertrain Control Module	EXE
GX73-14C037-MLH.vbf	Jaguar XE (X760)	SPCM - Secondary Powertrain Control Module	EXE
GX73-14C037-MLJ.vbf	Jaguar XE (X760)	SPCM - Secondary Powertrain Control Module	DATA
GX73-14C037-MNE.vbf	Jaguar XE (X760)	SPCM - Secondary Powertrain Control Module	EXE
GX73-14C037-MNF.vbf	Jaguar XE (X760)	SPCM - Secondary Powertrain Control Module	EXE
GX73-14C037-MNG.vbf	Jaguar XE (X760)	SPCM - Secondary Powertrain Control Module	EXE
GX73-14C037-MNH.vbf	Jaguar XE (X760)	SPCM - Secondary Powertrain Control Module	EXE
GX73-14C037-MNJ.vbf	Jaguar XE (X760)	SPCM - Secondary Powertrain Control Module	DATA
GX73-14C037-MTE.vbf	Jaguar XE (X760)	SPCM - Secondary Powertrain Control Module	EXE
GX73-14C037-MTF.vbf	Jaguar XE (X760)	SPCM - Secondary Powertrain Control Module	EXE
GX73-14C037-MTG.vbf	Jaguar XE (X760)	SPCM - Secondary Powertrain Control Module	EXE
GX73-14C037-MTH.vbf	Jaguar XE (X760)	SPCM - Secondary Powertrain Control Module	EXE
GX73-14C037-MTJ.vbf	Jaguar XE (X760)	SPCM - Secondary Powertrain Control Module	DATA
GX73-14C037-NLE.vbf	Jaguar XE (X760)	SPCM - Secondary Powertrain Control Module	EXE
GX73-14C037-NLF.vbf	Jaguar XE (X760)	SPCM - Secondary Powertrain Control Module	EXE
GX73-14C037-NLG.vbf	Jaguar XE (X760)	SPCM - Secondary Powertrain Control Module	EXE
GX73-14C037-NLH.vbf	Jaguar XE (X760)	SPCM - Secondary Powertrain Control Module	EXE
GX73-14C037-NLJ.vbf	Jaguar XE (X760)	SPCM - Secondary Powertrain Control Module	DATA
GX73-14C037-NNE.vbf	Jaguar XE (X760)	SPCM - Secondary Powertrain Control Module	EXE
GX73-14C037-NNF.vbf	Jaguar XE (X760)	SPCM - Secondary Powertrain Control Module	EXE
GX73-14C037-NNG.vbf	Jaguar XE (X760)	SPCM - Secondary Powertrain Control Module	EXE
GX73-14C037-NNH.vbf	Jaguar XE (X760)	SPCM - Secondary Powertrain Control Module	EXE
GX73-14C037-NNJ.vbf	Jaguar XE (X760)	SPCM - Secondary Powertrain Control Module	DATA
GX73-14C037-NRE.vbf	Jaguar XE (X760)	SPCM - Secondary Powertrain Control Module	EXE
GX73-14C037-NYE.vbf	Jaguar XE (X760)	SPCM - Secondary Powertrain Control Module	EXE
GX73-14C037-NYF.vbf	Jaguar XE (X760)	SPCM - Secondary Powertrain Control Module	EXE
GX73-14C037-NYG.vbf	Jaguar XE (X760)	SPCM - Secondary Powertrain Control Module	EXE
GX73-14C037-NYH.vbf	Jaguar XE (X760)	SPCM - Secondary Powertrain Control Module	EXE
GX73-14C037-PBE.vbf	Jaguar XE (X760)	SPCM - Secondary Powertrain Control Module	EXE
GX73-14C037-PBF.vbf	Jaguar XE (X760)	SPCM - Secondary Powertrain Control Module	EXE
GX73-14C037-PBG.vbf	Jaguar XE (X760)	SPCM - Secondary Powertrain Control Module	EXE
GX73-14C037-PBH.vbf	Jaguar XE (X760)	SPCM - Secondary Powertrain Control Module	EXE
GX73-14C037-PBJ.vbf	Jaguar XE (X760)	SPCM - Secondary Powertrain Control Module	DATA
GX73-14C037-PPE.vbf	Jaguar XE (X760)	SPCM - Secondary Powertrain Control Module	EXE
GX73-14C037-PPF.vbf	Jaguar XE (X760)	SPCM - Secondary Powertrain Control Module	EXE
GX73-14C037-PPG.vbf	Jaguar XE (X760)	SPCM - Secondary Powertrain Control Module	EXE
GX73-14C037-PPH.vbf	Jaguar XE (X760)	SPCM - Secondary Powertrain Control Module	EXE
GX73-14C037-PPJ.vbf	Jaguar XE (X760)	SPCM - Secondary Powertrain Control Module	DATA
GX73-14C037-PSE.vbf	Jaguar XE (X760)	SPCM - Secondary Powertrain Control Module	EXE
GX73-14C037-PSF.vbf	Jaguar XE (X760)	SPCM - Secondary Powertrain Control Module	EXE
GX73-14C037-PSG.vbf	Jaguar XE (X760)	SPCM - Secondary Powertrain Control Module	EXE
GX73-14C037-PSH.vbf	Jaguar XE (X760)	SPCM - Secondary Powertrain Control Module	EXE
GX73-14C037-PSJ.vbf	Jaguar XE (X760)	SPCM - Secondary Powertrain Control Module	DATA
GX73-14C039-AB.vbf	Jaguar XE (X760)	SPCM - Secondary Powertrain Control Module	SBL
GX73-14C045-BJ.vbf	Jaguar XE (X760)	ICM - Infotainment Control Module	DATA
GX73-14C045-BK.vbf	Jaguar XE (X760)	ICM - Infotainment Control Module	DATA
GX73-14C045-BL.vbf	Jaguar XE (X760)	ICM - Infotainment Control Module	DATA
GX73-14C045-BM.vbf	Jaguar XE (X760)	ICM - Infotainment Control Module	DATA
GX73-14C045-BN.vbf	Jaguar XE (X760)	ICM - Infotainment Control Module	DATA
GX73-14C045-BP.vbf	Jaguar XE (X760)	ICM - Infotainment Control Module	DATA
GX73-14C060-AE.vbf	Jaguar XE (X760)	FCDIM - Front Control/Display Interface Module	EXE
GX73-14C060-AF.vbf	Jaguar XE (X760)	FCDIM - Front Control/Display Interface Module	EXE
GX73-14C060-AG.vbf	Jaguar XE (X760)	FCDIM - Front Control/Display Interface Module	EXE
GX73-14C060-AH.vbf	Jaguar XE (X760)	FCDIM - Front Control/Display Interface Module	EXE
GX73-14C060-AJ.vbf	Jaguar XE (X760)	FCDIM - Front Control/Display Interface Module	EXE
GX73-14C060-AK.vbf	Jaguar XE (X760)	FCDIM - Front Control/Display Interface Module	EXE
GX73-14C060-BE.vbf	Jaguar XE (X760)	FCDIM - Front Control/Display Interface Module	EXE
GX73-14C060-BF.vbf	Jaguar XE (X760)	FCDIM - Front Control/Display Interface Module	EXE
GX73-14C060-BG.vbf	Jaguar XE (X760)	FCDIM - Front Control/Display Interface Module	EXE
GX73-14C060-BH.vbf	Jaguar XE (X760)	FCDIM - Front Control/Display Interface Module	EXE
GX73-14C060-BJ.vbf	Jaguar XE (X760)	FCDIM - Front Control/Display Interface Module	EXE
GX73-14C060-BK.vbf	Jaguar XE (X760)	FCDIM - Front Control/Display Interface Module	EXE
GX73-14C061-AE.vbf	Jaguar XE (X760)	FCDIM - Front Control/Display Interface Module	DATA
GX73-14C061-AF.vbf	Jaguar XE (X760)	FCDIM - Front Control/Display Interface Module	DATA
GX73-14C061-AG.vbf	Jaguar XE (X760)	FCDIM - Front Control/Display Interface Module	DATA

File name	Vehicle line (indicative)	Module (ECU)	Type
GX73-14C061-AH.vbf	Jaguar XE (X760)	FCDIM - Front Control/Display Interface Module	DATA
GX73-14C061-AJ.vbf	Jaguar XE (X760)	FCDIM - Front Control/Display Interface Module	DATA
GX73-14C061-AK.vbf	Jaguar XE (X760)	FCDIM - Front Control/Display Interface Module	DATA
GX73-14C061-AL.vbf	Jaguar XE (X760)	FCDIM - Front Control/Display Interface Module	DATA
GX73-14C063-AB.vbf	Jaguar XE (X760)	FCDIM - Front Control/Display Interface Module	SBL
GX73-14C064-CB.vbf	Jaguar XE (X760)	DDM - Driver Front Door Module	EXE
GX73-14C064-CC.vbf	Jaguar XE (X760)	DDM - Driver Front Door Module	EXE
GX73-14C064-CD.vbf	Jaguar XE (X760)	DDM - Driver Front Door Module	EXE
GX73-14C064-CE.vbf	Jaguar XE (X760)	DDM - Driver Front Door Module	EXE
GX73-14C064-CF.vbf	Jaguar XE (X760)	DDM - Driver Front Door Module	EXE
GX73-14C065-BE.vbf	Jaguar XE (X760)	DDM - Driver Front Door Module	DATA
GX73-14C065-BF.vbf	Jaguar XE (X760)	DDM - Driver Front Door Module	DATA
GX73-14C065-BG.vbf	Jaguar XE (X760)	DDM - Driver Front Door Module	DATA
GX73-14C065-BH.vbf	Jaguar XE (X760)	DDM - Driver Front Door Module	DATA
GX73-14C065-BJ.vbf	Jaguar XE (X760)	DDM - Driver Front Door Module	DATA
GX73-14C067-AB.vbf	Jaguar XE (X760)	DDM - Driver Front Door Module	SBL
GX73-14C067-AC.vbf	Jaguar XE (X760)	DDM - Driver Front Door Module	SBL
GX73-14C067-BA.vbf	Jaguar XE (X760)	DDM - Driver Front Door Module	SBL
GX73-14C067-BB.vbf	Jaguar XE (X760)	DDM - Driver Front Door Module	SBL
GX73-14C068-CB.vbf	Jaguar XE (X760)	DRDM - Driver Rear Door Module	EXE
GX73-14C068-CC.vbf	Jaguar XE (X760)	DRDM - Driver Rear Door Module	EXE
GX73-14C068-CD.vbf	Jaguar XE (X760)	DRDM - Driver Rear Door Module	EXE
GX73-14C068-CE.vbf	Jaguar XE (X760)	DRDM - Driver Rear Door Module	EXE
GX73-14C068-CF.vbf	Jaguar XE (X760)	DRDM - Driver Rear Door Module	EXE
GX73-14C069-BE.vbf	Jaguar XE (X760)	DRDM - Driver Rear Door Module	DATA
GX73-14C069-BF.vbf	Jaguar XE (X760)	DRDM - Driver Rear Door Module	DATA
GX73-14C069-BG.vbf	Jaguar XE (X760)	DRDM - Driver Rear Door Module	DATA
GX73-14C069-BH.vbf	Jaguar XE (X760)	DRDM - Driver Rear Door Module	DATA
GX73-14C069-BJ.vbf	Jaguar XE (X760)	DRDM - Driver Rear Door Module	DATA
GX73-14C071-AB.vbf	Jaguar XE (X760)	DRDM - Driver Rear Door Module	SBL
GX73-14C071-AC.vbf	Jaguar XE (X760)	DRDM - Driver Rear Door Module	SBL
GX73-14C071-BA.vbf	Jaguar XE (X760)	DRDM - Driver Rear Door Module	SBL
GX73-14C071-BB.vbf	Jaguar XE (X760)	DRDM - Driver Rear Door Module	SBL
GX73-14C084-AB.vbf	Jaguar XE (X760)	HCM - Headlamp Control Module #1	EXE
GX73-14C087-AA.vbf	Jaguar XE (X760)	HCM - Headlamp Control Module #1	SBL
GX73-14C088-BB.vbf	Jaguar XE (X760)	IPC - Instrument Panel Cluster (IPC) Control Module	DATA
GX73-14C088-BC.vbf	Jaguar XE (X760)	IPC - Instrument Panel Cluster (IPC) Control Module	DATA
GX73-14C088-CB.vbf	Jaguar XE (X760)	IPC - Instrument Panel Cluster (IPC) Control Module	EXE
GX73-14C088-CC.vbf	Jaguar XE (X760)	IPC - Instrument Panel Cluster (IPC) Control Module	EXE
GX73-14C088-CD.vbf	Jaguar XE (X760)	IPC - Instrument Panel Cluster (IPC) Control Module	EXE
GX73-14C088-CE.vbf	Jaguar XE (X760)	IPC - Instrument Panel Cluster (IPC) Control Module	EXE
GX73-14C088-CF.vbf	Jaguar XE (X760)	IPC - Instrument Panel Cluster (IPC) Control Module	EXE
GX73-14C088-CG.vbf	Jaguar XE (X760)	IPC - Instrument Panel Cluster (IPC) Control Module	EXE
GX73-14C091-AH.vbf	Jaguar XE (X760)	PAM - Parking Assist Control Module	DATA
GX73-14C091-AJ.vbf	Jaguar XE (X760)	PAM - Parking Assist Control Module	DATA
GX73-14C091-AK.vbf	Jaguar XE (X760)	PAM - Parking Assist Control Module	DATA
GX73-14C091-AL.vbf	Jaguar XE (X760)	PAM - Parking Assist Control Module	DATA
GX73-14C091-AM.vbf	Jaguar XE (X760)	PAM - Parking Assist Control Module	DATA
GX73-14C091-AP.vbf	Jaguar XE (X760)	PAM - Parking Assist Control Module	DATA
GX73-14C091-AS.vbf	Jaguar XE (X760)	PAM - Parking Assist Control Module	DATA
GX73-14C091-AT.vbf	Jaguar XE (X760)	PAM - Parking Assist Control Module	DATA
GX73-14C098-AB.vbf	Jaguar XE (X760)	RCM - Restraints Control Module	DATA
GX73-14C098-AC.vbf	Jaguar XE (X760)	RCM - Restraints Control Module	DATA
GX73-14C098-AD.vbf	Jaguar XE (X760)	RCM - Restraints Control Module	DATA
GX73-14C098-AE.vbf	Jaguar XE (X760)	RCM - Restraints Control Module	DATA
GX73-14C098-BD.vbf	Jaguar XE (X760)	RCM - Restraints Control Module	DATA
GX73-14C098-BE.vbf	Jaguar XE (X760)	RCM - Restraints Control Module	DATA
GX73-14C098-BG.vbf	Jaguar XE (X760)	RCM - Restraints Control Module	DATA
GX73-14C098-BH.vbf	Jaguar XE (X760)	RCM - Restraints Control Module	DATA
GX73-14C098-BJ.VBF	Jaguar XE (X760)	RCM - Restraints Control Module	DATA
GX73-14C098-CB.vbf	Jaguar XE (X760)	RCM - Restraints Control Module	DATA
GX73-14C105-AB.vbf	Jaguar XE (X760)	TMC Traffic Message Channel Module	DATA
GX73-14C105-AC.vbf	Jaguar XE (X760)	TMC Traffic Message Channel Module	DATA
GX73-14C105-AD.vbf	Jaguar XE (X760)	TMC Traffic Message Channel Module	DATA
GX73-14C105-AE.vbf	Jaguar XE (X760)	TMC Traffic Message Channel Module	DATA
GX73-14C105-AJ.vbf	Jaguar XE (X760)	TMC Traffic Message Channel Module	DATA
GX73-14C108-CB.vbf	Jaguar XE (X760)	PDM - Passenger Front Door Module	EXE
GX73-14C108-CC.vbf	Jaguar XE (X760)	PDM - Passenger Front Door Module	EXE
GX73-14C108-CD.vbf	Jaguar XE (X760)	PDM - Passenger Front Door Module	EXE
GX73-14C108-CE.vbf	Jaguar XE (X760)	PDM - Passenger Front Door Module	EXE
GX73-14C108-CF.vbf	Jaguar XE (X760)	PDM - Passenger Front Door Module	EXE
GX73-14C109-BE.vbf	Jaguar XE (X760)	PDM - Passenger Front Door Module	DATA
GX73-14C109-BF.vbf	Jaguar XE (X760)	PDM - Passenger Front Door Module	DATA
GX73-14C109-BG.vbf	Jaguar XE (X760)	PDM - Passenger Front Door Module	DATA
GX73-14C109-BH.vbf	Jaguar XE (X760)	PDM - Passenger Front Door Module	DATA
GX73-14C109-BJ.vbf	Jaguar XE (X760)	PDM - Passenger Front Door Module	DATA

File name	Vehicle line (indicative)	Module (ECU)	Type
GX73-14C111-AB.vbf	Jaguar XE (X760)	PDM - Passenger Front Door Module	SBL
GX73-14C111-AC.vbf	Jaguar XE (X760)	PDM - Passenger Front Door Module	SBL
GX73-14C111-BA.vbf	Jaguar XE (X760)	PDM - Passenger Front Door Module	SBL
GX73-14C111-BB.vbf	Jaguar XE (X760)	PDM - Passenger Front Door Module	SBL
GX73-14C112-CB.vbf	Jaguar XE (X760)	PRDM - Passenger Rear Door Module	EXE
GX73-14C112-CC.vbf	Jaguar XE (X760)	PRDM - Passenger Rear Door Module	EXE
GX73-14C112-CD.vbf	Jaguar XE (X760)	PRDM - Passenger Rear Door Module	EXE
GX73-14C112-CE.vbf	Jaguar XE (X760)	PRDM - Passenger Rear Door Module	EXE
GX73-14C112-CF.vbf	Jaguar XE (X760)	PRDM - Passenger Rear Door Module	EXE
GX73-14C113-BE.vbf	Jaguar XE (X760)	PRDM - Passenger Rear Door Module	DATA
GX73-14C113-BF.vbf	Jaguar XE (X760)	PRDM - Passenger Rear Door Module	DATA
GX73-14C113-BG.vbf	Jaguar XE (X760)	PRDM - Passenger Rear Door Module	DATA
GX73-14C113-BH.vbf	Jaguar XE (X760)	PRDM - Passenger Rear Door Module	DATA
GX73-14C113-BJ.vbf	Jaguar XE (X760)	PRDM - Passenger Rear Door Module	DATA
GX73-14C115-AB.vbf	Jaguar XE (X760)	PRDM - Passenger Rear Door Module	SBL
GX73-14C115-AC.vbf	Jaguar XE (X760)	PRDM - Passenger Rear Door Module	SBL
GX73-14C115-BA.vbf	Jaguar XE (X760)	PRDM - Passenger Rear Door Module	SBL
GX73-14C115-BB.vbf	Jaguar XE (X760)	PRDM - Passenger Rear Door Module	SBL
GX73-14C121-AA.vbf	Jaguar XE (X760)	RGTM - Rear Gate / Trunk Module	EXE
GX73-14C121-AB.vbf	Jaguar XE (X760)	RGTM - Rear Gate / Trunk Module	EXE
GX73-14C121-AC.vbf	Jaguar XE (X760)	RGTM - Rear Gate / Trunk Module	EXE
GX73-14C122-AA.vbf	Jaguar XE (X760)	RGTM - Rear Gate / Trunk Module	DATA
GX73-14C122-AB.vbf	Jaguar XE (X760)	RGTM - Rear Gate / Trunk Module	DATA
GX73-14C122-AC.vbf	Jaguar XE (X760)	RGTM - Rear Gate / Trunk Module	DATA
GX73-14C124-AA.vbf	Jaguar XE (X760)	RGTM - Rear Gate / Trunk Module	SBL
GX73-14C152-AC.vbf	Jaguar XE (X760)	TPM - Tire Pressure Monitor Module	DATA
GX73-14C184-AAA.vbf	Jaguar XE (X760)	BCM - Body Control Module	EXE
GX73-14C184-AAC.vbf	Jaguar XE (X760)	BCM - Body Control Module	EXE
GX73-14C184-AD.vbf	Jaguar XE (X760)	BCM - Body Control Module	EXE
GX73-14C184-AE.vbf	Jaguar XE (X760)	BCM - Body Control Module	EXE
GX73-14C184-AF.vbf	Jaguar XE (X760)	BCM - Body Control Module	EXE
GX73-14C184-AG.vbf	Jaguar XE (X760)	BCM - Body Control Module	EXE
GX73-14C184-AH.vbf	Jaguar XE (X760)	BCM - Body Control Module	EXE
GX73-14C184-AJ.vbf	Jaguar XE (X760)	BCM - Body Control Module	EXE
GX73-14C184-AK.vbf	Jaguar XE (X760)	BCM - Body Control Module	EXE
GX73-14C184-AL.vbf	Jaguar XE (X760)	BCM - Body Control Module	EXE
GX73-14C184-AM.vbf	Jaguar XE (X760)	BCM - Body Control Module	EXE
GX73-14C184-AN.vbf	Jaguar XE (X760)	BCM - Body Control Module	EXE
GX73-14C184-AP.vbf	Jaguar XE (X760)	BCM - Body Control Module	EXE
GX73-14C184-AR.vbf	Jaguar XE (X760)	BCM - Body Control Module	EXE
GX73-14C184-AS.vbf	Jaguar XE (X760)	BCM - Body Control Module	EXE
GX73-14C184-AT.vbf	Jaguar XE (X760)	BCM - Body Control Module	EXE
GX73-14C184-AU.vbf	Jaguar XE (X760)	BCM - Body Control Module	EXE
GX73-14C185-AE.vbf	Jaguar XE (X760)	BCM - Body Control Module	DATA
GX73-14C185-AF.vbf	Jaguar XE (X760)	BCM - Body Control Module	DATA
GX73-14C185-AG.vbf	Jaguar XE (X760)	BCM - Body Control Module	DATA
GX73-14C185-AH.vbf	Jaguar XE (X760)	BCM - Body Control Module	DATA
GX73-14C185-AJ.vbf	Jaguar XE (X760)	BCM - Body Control Module	DATA
GX73-14C185-AK.vbf	Jaguar XE (X760)	BCM - Body Control Module	DATA
GX73-14C185-AL.vbf	Jaguar XE (X760)	BCM - Body Control Module	DATA
GX73-14C185-AP.vbf	Jaguar XE (X760)	BCM - Body Control Module	DATA
GX73-14C187-AB.vbf	Jaguar XE (X760)	BCM - Body Control Module	SBL
GX73-14C204-FAB.vbf	Jaguar XE (X760)	PCM - Powertrain Control Module	EXE
GX73-14C204-FAC.vbf	Jaguar XE (X760)	PCM - Powertrain Control Module	EXE
GX73-14C204-FAD.vbf	Jaguar XE (X760)	PCM - Powertrain Control Module	EXE
GX73-14C204-FAE.vbf	Jaguar XE (X760)	PCM - Powertrain Control Module	EXE
GX73-14C204-FAF.vbf	Jaguar XE (X760)	PCM - Powertrain Control Module	EXE
GX73-14C204-FAH.vbf	Jaguar XE (X760)	PCM - Powertrain Control Module	EXE
GX73-14C204-FBB.vbf	Jaguar XE (X760)	PCM - Powertrain Control Module	EXE
GX73-14C204-FBC.vbf	Jaguar XE (X760)	PCM - Powertrain Control Module	EXE
GX73-14C204-FBE.vbf	Jaguar XE (X760)	PCM - Powertrain Control Module	EXE
GX73-14C204-FBG.vbf	Jaguar XE (X760)	PCM - Powertrain Control Module	EXE
GX73-14C204-MCC.vbf	Jaguar XE (X760)	PCM - Powertrain Control Module	EXE
GX73-14C204-MCD.vbf	Jaguar XE (X760)	PCM - Powertrain Control Module	EXE
GX73-14C204-MCE.vbf	Jaguar XE (X760)	PCM - Powertrain Control Module	EXE
GX73-14C204-MCF.vbf	Jaguar XE (X760)	PCM - Powertrain Control Module	EXE
GX73-14C204-MCG.vbf	Jaguar XE (X760)	PCM - Powertrain Control Module	EXE
GX73-14C204-MEC.vbf	Jaguar XE (X760)	PCM - Powertrain Control Module	EXE
GX73-14C204-MED.vbf	Jaguar XE (X760)	PCM - Powertrain Control Module	EXE
GX73-14C204-MEE.vbf	Jaguar XE (X760)	PCM - Powertrain Control Module	EXE
GX73-14C204-MEF.vbf	Jaguar XE (X760)	PCM - Powertrain Control Module	EXE
GX73-14C204-MEG.vbf	Jaguar XE (X760)	PCM - Powertrain Control Module	EXE
GX73-14C204-MHB.vbf	Jaguar XE (X760)	PCM - Powertrain Control Module	EXE
GX73-14C204-MHC.vbf	Jaguar XE (X760)	PCM - Powertrain Control Module	EXE
GX73-14C204-MHD.vbf	Jaguar XE (X760)	PCM - Powertrain Control Module	EXE
GX73-14C204-MHE.vbf	Jaguar XE (X760)	PCM - Powertrain Control Module	EXE

File name	Vehicle line (indicative)	Module (ECU)	Type
GX73-14C204-MHF.vbf	Jaguar XE (X760)	PCM - Powertrain Control Module	EXE
GX73-14C204-MHG.vbf	Jaguar XE (X760)	PCM - Powertrain Control Module	EXE
GX73-14C204-MTC.vbf	Jaguar XE (X760)	PCM - Powertrain Control Module	EXE
GX73-14C204-MTD.vbf	Jaguar XE (X760)	PCM - Powertrain Control Module	EXE
GX73-14C204-MTE.vbf	Jaguar XE (X760)	PCM - Powertrain Control Module	EXE
GX73-14C204-MTF.vbf	Jaguar XE (X760)	PCM - Powertrain Control Module	EXE
GX73-14C204-MTG.vbf	Jaguar XE (X760)	PCM - Powertrain Control Module	EXE
GX73-14C204-MUD.vbf	Jaguar XE (X760)	PCM - Powertrain Control Module	EXE
GX73-14C204-MUE.vbf	Jaguar XE (X760)	PCM - Powertrain Control Module	EXE
GX73-14C204-MUF.vbf	Jaguar XE (X760)	PCM - Powertrain Control Module	EXE
GX73-14C204-MUG.vbf	Jaguar XE (X760)	PCM - Powertrain Control Module	EXE
GX73-14C204-MVB.vbf	Jaguar XE (X760)	PCM - Powertrain Control Module	EXE
GX73-14C204-MVC.vbf	Jaguar XE (X760)	PCM - Powertrain Control Module	EXE
GX73-14C204-MVD.vbf	Jaguar XE (X760)	PCM - Powertrain Control Module	EXE
GX73-14C204-MVE.vbf	Jaguar XE (X760)	PCM - Powertrain Control Module	EXE
GX73-14C204-MVF.vbf	Jaguar XE (X760)	PCM - Powertrain Control Module	EXE
GX73-14C204-MVG.vbf	Jaguar XE (X760)	PCM - Powertrain Control Module	EXE
GX73-14C204-TCA.vbf	Jaguar XE (X760)	PCM - Powertrain Control Module	EXE
GX73-14C204-TCB.vbf	Jaguar XE (X760)	PCM - Powertrain Control Module	EXE
GX73-14C204-TCC.vbf	Jaguar XE (X760)	PCM - Powertrain Control Module	EXE
GX73-14C204-TCD.vbf	Jaguar XE (X760)	PCM - Powertrain Control Module	EXE
GX73-14C204-TCE.vbf	Jaguar XE (X760)	PCM - Powertrain Control Module	EXE
GX73-14C204-TEA.vbf	Jaguar XE (X760)	PCM - Powertrain Control Module	EXE
GX73-14C204-TEB.vbf	Jaguar XE (X760)	PCM - Powertrain Control Module	EXE
GX73-14C204-TEC.vbf	Jaguar XE (X760)	PCM - Powertrain Control Module	EXE
GX73-14C204-TED.vbf	Jaguar XE (X760)	PCM - Powertrain Control Module	EXE
GX73-14C204-TEE.vbf	Jaguar XE (X760)	PCM - Powertrain Control Module	EXE
GX73-14C204-TEF.vbf	Jaguar XE (X760)	PCM - Powertrain Control Module	EXE
GX73-14C204-TTA.vbf	Jaguar XE (X760)	PCM - Powertrain Control Module	EXE
GX73-14C204-TTB.vbf	Jaguar XE (X760)	PCM - Powertrain Control Module	EXE
GX73-14C204-TTC.vbf	Jaguar XE (X760)	PCM - Powertrain Control Module	EXE
GX73-14C204-TTD.vbf	Jaguar XE (X760)	PCM - Powertrain Control Module	EXE
GX73-14C204-TTE.vbf	Jaguar XE (X760)	PCM - Powertrain Control Module	EXE
GX73-14C204-TTF.vbf	Jaguar XE (X760)	PCM - Powertrain Control Module	EXE
GX73-14C217-AB.vbf	Jaguar XE (X760)	PSCM - Power Steering Control Module	EXE
GX73-14C217-AC.vbf	Jaguar XE (X760)	PSCM - Power Steering Control Module	EXE
GX73-14C217-AD.vbf	Jaguar XE (X760)	PSCM - Power Steering Control Module	EXE
GX73-14C217-BA.vbf	Jaguar XE (X760)	PSCM - Power Steering Control Module	EXE
GX73-14C218-AC.vbf	Jaguar XE (X760)	PSCM - Power Steering Control Module	DATA
GX73-14C218-AD.vbf	Jaguar XE (X760)	PSCM - Power Steering Control Module	DATA
GX73-14C218-AE.vbf	Jaguar XE (X760)	PSCM - Power Steering Control Module	DATA
GX73-14C218-BA.vbf	Jaguar XE (X760)	PSCM - Power Steering Control Module	DATA
GX73-14C218-BB.vbf	Jaguar XE (X760)	PSCM - Power Steering Control Module	DATA
GX73-14C218-CA.vbf	Jaguar XE (X760)	PSCM - Power Steering Control Module	DATA
GX73-14C218-CB.vbf	Jaguar XE (X760)	PSCM - Power Steering Control Module	DATA
GX73-14C218-DA.vbf	Jaguar XE (X760)	PSCM - Power Steering Control Module	DATA
GX73-14C218-EA.vbf	Jaguar XE (X760)	PSCM - Power Steering Control Module	DATA
GX73-14C218-FA.vbf	Jaguar XE (X760)	PSCM - Power Steering Control Module	DATA
GX73-14C218-GA.vbf	Jaguar XE (X760)	PSCM - Power Steering Control Module	DATA
GX73-14C220-AB.vbf	Jaguar XE (X760)	PSCM - Power Steering Control Module	SBL
GX73-14C273-FB.vbf	Jaguar XE (X760)	PCM - Powertrain Control Module	SBL
GX73-14C320-AB.vbf	Jaguar XE (X760)	PDM - Passenger Front Door Module	SIGCFG
GX73-14C320-AC.vbf	Jaguar XE (X760)	PDM - Passenger Front Door Module	SIGCFG
GX73-14C320-CA.vbf	Jaguar XE (X760)	PDM - Passenger Front Door Module	SIGCFG
GX73-14C320-CB.vbf	Jaguar XE (X760)	PDM - Passenger Front Door Module	SIGCFG
GX73-14C320-CC.vbf	Jaguar XE (X760)	PDM - Passenger Front Door Module	SIGCFG
GX73-14C320-CD.vbf	Jaguar XE (X760)	PDM - Passenger Front Door Module	SIGCFG
GX73-14C320-CE.vbf	Jaguar XE (X760)	PDM - Passenger Front Door Module	SIGCFG
GX73-14C320-CF.vbf	Jaguar XE (X760)	PDM - Passenger Front Door Module	SIGCFG
GX73-14C321-AC.vbf	Jaguar XE (X760)	DDM - Driver Front Door Module	SIGCFG
GX73-14C321-CA.vbf	Jaguar XE (X760)	DDM - Driver Front Door Module	SIGCFG
GX73-14C321-CB.vbf	Jaguar XE (X760)	DDM - Driver Front Door Module	SIGCFG
GX73-14C321-CC.vbf	Jaguar XE (X760)	DDM - Driver Front Door Module	SIGCFG
GX73-14C321-CD.vbf	Jaguar XE (X760)	DDM - Driver Front Door Module	SIGCFG
GX73-14C321-CE.vbf	Jaguar XE (X760)	DDM - Driver Front Door Module	SIGCFG
GX73-14C321-CF.vbf	Jaguar XE (X760)	DDM - Driver Front Door Module	SIGCFG
GX73-14C386-AF.vbf	Jaguar XE (X760)	PSCM - Power Steering Control Module	SIGCFG
GX73-14C408-AE.vbf	Jaguar XE (X760)	BCM - Body Control Module	SIGCFG
GX73-14C408-AG.vbf	Jaguar XE (X760)	BCM - Body Control Module	SIGCFG
GX73-14C408-AJ.vbf	Jaguar XE (X760)	BCM - Body Control Module	SIGCFG
GX73-14C408-AK.vbf	Jaguar XE (X760)	BCM - Body Control Module	SIGCFG
GX73-14C408-AM.vbf	Jaguar XE (X760)	BCM - Body Control Module	SIGCFG
GX73-14C408-AR.vbf	Jaguar XE (X760)	BCM - Body Control Module	SIGCFG
GX73-14C410-AC.vbf	Jaguar XE (X760)	PRDM - Passenger Rear Door Module	SIGCFG
GX73-14C410-CA.vbf	Jaguar XE (X760)	PRDM - Passenger Rear Door Module	SIGCFG
GX73-14C410-CB.vbf	Jaguar XE (X760)	PRDM - Passenger Rear Door Module	SIGCFG

File name	Vehicle line (indicative)	Module (ECU)	Type
GX73-14C410-CC.vbf	Jaguar XE (X760)	PRDM - Passenger Rear Door Module	SIGCFG
GX73-14C410-CD.vbf	Jaguar XE (X760)	PRDM - Passenger Rear Door Module	SIGCFG
GX73-14C410-CE.vbf	Jaguar XE (X760)	PRDM - Passenger Rear Door Module	SIGCFG
GX73-14C410-CF.vbf	Jaguar XE (X760)	PRDM - Passenger Rear Door Module	SIGCFG
GX73-14C435-AC.vbf	Jaguar XE (X760)	DRDM - Driver Rear Door Module	SIGCFG
GX73-14C435-CA.vbf	Jaguar XE (X760)	DRDM - Driver Rear Door Module	SIGCFG
GX73-14C435-CB.vbf	Jaguar XE (X760)	DRDM - Driver Rear Door Module	SIGCFG
GX73-14C435-CC.vbf	Jaguar XE (X760)	DRDM - Driver Rear Door Module	SIGCFG
GX73-14C435-CD.vbf	Jaguar XE (X760)	DRDM - Driver Rear Door Module	SIGCFG
GX73-14C435-CE.vbf	Jaguar XE (X760)	DRDM - Driver Rear Door Module	SIGCFG
GX73-14C435-CF.vbf	Jaguar XE (X760)	DRDM - Driver Rear Door Module	SIGCFG
GX73-14C527-BA.vbf	Jaguar XE (X760)	Not specified	DATA
GX73-14C527-BB.vbf	Jaguar XE (X760)	Not specified	DATA
GX73-14C527-DA.vbf	Jaguar XE (X760)	Not specified	DATA
GX73-14C527-DB.vbf	Jaguar XE (X760)	Not specified	DATA
GX73-14C527-DC.vbf	Jaguar XE (X760)	Not specified	DATA
GX73-14C535-AC.vbf	Jaguar XE (X760)	FCIM - Front Controls Interface Module	EXE
GX73-14C535-AF.vbf	Jaguar XE (X760)	FCIM - Front Controls Interface Module	EXE
GX73-14C536-AAA.vbf	Jaguar XE (X760)	FCIM - Front Controls Interface Module	DATA
GX73-14C536-ABA.vbf	Jaguar XE (X760)	FCIM - Front Controls Interface Module	DATA
GX73-14C536-AC.vbf	Jaguar XE (X760)	FCIM - Front Controls Interface Module	DATA
GX73-14C536-ACA.vbf	Jaguar XE (X760)	FCIM - Front Controls Interface Module	DATA
GX73-14C536-ADA.vbf	Jaguar XE (X760)	FCIM - Front Controls Interface Module	DATA
GX73-14C536-AEA.vbf	Jaguar XE (X760)	FCIM - Front Controls Interface Module	DATA
GX73-14C536-AF.vbf	Jaguar XE (X760)	FCIM - Front Controls Interface Module	DATA
GX73-14C536-AFA.vbf	Jaguar XE (X760)	FCIM - Front Controls Interface Module	DATA
GX73-14C536-AGA.vbf	Jaguar XE (X760)	FCIM - Front Controls Interface Module	DATA
GX73-14C536-AHA.vbf	Jaguar XE (X760)	FCIM - Front Controls Interface Module	DATA
GX73-14C536-AJA.vbf	Jaguar XE (X760)	FCIM - Front Controls Interface Module	DATA
GX73-14C536-AKA.vbf	Jaguar XE (X760)	FCIM - Front Controls Interface Module	DATA
GX73-14C536-ALA.vbf	Jaguar XE (X760)	FCIM - Front Controls Interface Module	DATA
GX73-14C536-AMA.vbf	Jaguar XE (X760)	FCIM - Front Controls Interface Module	DATA
GX73-14C536-ANA.vbf	Jaguar XE (X760)	FCIM - Front Controls Interface Module	DATA
GX73-14C536-APA.vbf	Jaguar XE (X760)	FCIM - Front Controls Interface Module	DATA
GX73-14C536-ARA.vbf	Jaguar XE (X760)	FCIM - Front Controls Interface Module	DATA
GX73-14C536-ASA.vbf	Jaguar XE (X760)	FCIM - Front Controls Interface Module	DATA
GX73-14C536-ATA.vbf	Jaguar XE (X760)	FCIM - Front Controls Interface Module	DATA
GX73-14C536-AUA.vbf	Jaguar XE (X760)	FCIM - Front Controls Interface Module	DATA
GX73-14C536-AVA.vbf	Jaguar XE (X760)	FCIM - Front Controls Interface Module	DATA
GX73-14C536-AXA.vbf	Jaguar XE (X760)	FCIM - Front Controls Interface Module	DATA
GX73-14C537-AB.vbf	Jaguar XE (X760)	FCIM - Front Controls Interface Module	SBL
GX73-14C560-AA.vbf	Jaguar XE (X760)	GSM - Gear Shift Module	SIGCFG
GX73-14C560-BB.vbf	Jaguar XE (X760)	GSM - Gear Shift Module	SIGCFG
GX73-14C560-BC.vbf	Jaguar XE (X760)	GSM - Gear Shift Module	SIGCFG
GX73-14C561-AC.vbf	Jaguar XE (X760)	GSM - Gear Shift Module	EXE
GX73-14C561-AD.vbf	Jaguar XE (X760)	GSM - Gear Shift Module	EXE
GX73-14C563-AA.vbf	Jaguar XE (X760)	GSM - Gear Shift Module	SBL
GX73-14C609-AB.vbf	Jaguar XE (X760)	PSCM - Power Steering Control Module	DATA
GX73-14C609-AD.vbf	Jaguar XE (X760)	PSCM - Power Steering Control Module	DATA
GX73-14C609-BA.vbf	Jaguar XE (X760)	PSCM - Power Steering Control Module	DATA
GX73-14C621-AF.vbf	Jaguar XE (X760)	FCDIM - Front Control/Display Interface Module	EXE
GX73-14C653-AE.vbf	Jaguar XE (X760)	ACM - Audio Front Control Module	DATA
GX73-14C653-AG.vbf	Jaguar XE (X760)	ACM - Audio Front Control Module	DATA
GX73-14C653-AH.vbf	Jaguar XE (X760)	ACM - Audio Front Control Module	DATA
GX73-14C653-AJ.vbf	Jaguar XE (X760)	ACM - Audio Front Control Module	DATA
GX73-14C653-AK.vbf	Jaguar XE (X760)	ACM - Audio Front Control Module	DATA
GX73-14C653-AL.vbf	Jaguar XE (X760)	ACM - Audio Front Control Module	DATA
GX73-14C653-AM.vbf	Jaguar XE (X760)	ACM - Audio Front Control Module	DATA
GX73-14D049-AB.vbf	Jaguar XE (X760)	CCM - Cruise Control Module	EXE
GX73-14D049-AD.vbf	Jaguar XE (X760)	CCM - Cruise Control Module	EXE
GX73-14D183-BB.vbf	Jaguar XE (X760)	OCS - Restraints Occupant Classification System Module	DATA
GX73-14D485-AA.vbf	Jaguar XE (X760)	IPMB - Image Processing Module B	DATA
GX73-14D485-AB.vbf	Jaguar XE (X760)	IPMB - Image Processing Module B	DATA
GX73-14D485-AC.vbf	Jaguar XE (X760)	IPMB - Image Processing Module B	DATA
GX73-14D519-AB.vbf	Jaguar XE (X760)	HVAC - HVAC Control Module	EXE
GX73-14D519-AC.vbf	Jaguar XE (X760)	HVAC - HVAC Control Module	EXE
GX73-14D519-AD.vbf	Jaguar XE (X760)	HVAC - HVAC Control Module	EXE
GX73-14D520-AB.vbf	Jaguar XE (X760)	HVAC - HVAC Control Module	DATA
GX73-14D520-AC.vbf	Jaguar XE (X760)	HVAC - HVAC Control Module	DATA
GX73-14D520-AD.vbf	Jaguar XE (X760)	HVAC - HVAC Control Module	DATA
GX73-14D520-AE.vbf	Jaguar XE (X760)	HVAC - HVAC Control Module	DATA
GX73-14D520-AF.vbf	Jaguar XE (X760)	HVAC - HVAC Control Module	DATA
GX73-14D520-BB.vbf	Jaguar XE (X760)	HVAC - HVAC Control Module	DATA
GX73-14D520-BC.vbf	Jaguar XE (X760)	HVAC - HVAC Control Module	DATA
GX73-14D520-BD.vbf	Jaguar XE (X760)	HVAC - HVAC Control Module	DATA
GX73-14D564-AA.vbf	Jaguar XE (X760)	SODL - Side Obstacle Detection Control Module - Left	DATA

File name	Vehicle line (indicative)	Module (ECU)	Type
GX73-14D564-BA.vbf	Jaguar XE (X760)	SODR - Side Obstacle Detection Control Module - Right	DATA
GX73-14E094-DAD.vbf	Jaguar XE (X760)	CHCM - Chassis Control Module	EXE
GX73-14E094-DAE.vbf	Jaguar XE (X760)	CHCM - Chassis Control Module	EXE
GX73-14E094-DBD.vbf	Jaguar XE (X760)	CHCM - Chassis Control Module	EXE
GX73-14E094-DBE.vbf	Jaguar XE (X760)	CHCM - Chassis Control Module	EXE
GX73-14E094-DCD.vbf	Jaguar XE (X760)	CHCM - Chassis Control Module	EXE
GX73-14E094-DCE.vbf	Jaguar XE (X760)	CHCM - Chassis Control Module	EXE
GX73-14F022-AD.vbf	Jaguar XE (X760)	IPMB - Image Processing Module B	DATA
GX73-14F022-AE.vbf	Jaguar XE (X760)	IPMB - Image Processing Module B	DATA
GX73-14F022-AF.vbf	Jaguar XE (X760)	IPMB - Image Processing Module B	DATA
GX73-14F022-AG.vbf	Jaguar XE (X760)	IPMB - Image Processing Module B	DATA
GX73-14F022-AJ.vbf	Jaguar XE (X760)	IPMB - Image Processing Module B	DATA
GX73-14F022-BD.vbf	Jaguar XE (X760)	IPMB - Image Processing Module B	DATA
GX73-14F022-BE.vbf	Jaguar XE (X760)	IPMB - Image Processing Module B	DATA
GX73-14F022-BF.vbf	Jaguar XE (X760)	IPMB - Image Processing Module B	DATA
GX73-14F231-AC.vbf	Jaguar XE (X760)	HUD - Head Up Display	CUSTOM
GX73-14F231-AD.vbf	Jaguar XE (X760)	HUD - Head Up Display	CUSTOM
GX73-14F231-BB.vbf	Jaguar XE (X760)	HUD - Head Up Display	CUSTOM
GX73-14F397-AC.vbf	Jaguar XE (X760)	IPMA - Image Processing Module A	EXE
GX73-14F397-AD.vbf	Jaguar XE (X760)	IPMA - Image Processing Module A	EXE
GX73-14F397-AE.vbf	Jaguar XE (X760)	IPMA - Image Processing Module A	EXE
GX73-14F397-AF.vbf	Jaguar XE (X760)	IPMA - Image Processing Module A	EXE
GX73-14F397-AG.vbf	Jaguar XE (X760)	IPMA - Image Processing Module A	EXE
GX73-14F397-BC.vbf	Jaguar XE (X760)	IPMA - Image Processing Module A	EXE
GX73-14F397-BD.vbf	Jaguar XE (X760)	IPMA - Image Processing Module A	EXE
GX73-14F397-BE.vbf	Jaguar XE (X760)	IPMA - Image Processing Module A	EXE
GX73-14F397-BF.vbf	Jaguar XE (X760)	IPMA - Image Processing Module A	EXE
GX73-14F397-BG.vbf	Jaguar XE (X760)	IPMA - Image Processing Module A	EXE
GX73-14F397-CB.vbf	Jaguar XE (X760)	IPMA - Image Processing Module A	EXE
GX73-14F397-CC.vbf	Jaguar XE (X760)	IPMA - Image Processing Module A	EXE
GX73-14F397-CD.vbf	Jaguar XE (X760)	IPMA - Image Processing Module A	EXE
GX73-14F397-CE.vbf	Jaguar XE (X760)	IPMA - Image Processing Module A	EXE
GX73-14F397-CF.vbf	Jaguar XE (X760)	IPMA - Image Processing Module A	EXE
GX73-14F397-DB.vbf	Jaguar XE (X760)	IPMA - Image Processing Module A	EXE
GX73-14F397-DC.vbf	Jaguar XE (X760)	IPMA - Image Processing Module A	EXE
GX73-14F397-DD.vbf	Jaguar XE (X760)	IPMA - Image Processing Module A	EXE
GX73-14F397-DE.vbf	Jaguar XE (X760)	IPMA - Image Processing Module A	EXE
GX73-14F397-DF.vbf	Jaguar XE (X760)	IPMA - Image Processing Module A	EXE
GX73-14F398-AB.vbf	Jaguar XE (X760)	IPMA - Image Processing Module A	EXE
GX73-14F398-AC.vbf	Jaguar XE (X760)	IPMA - Image Processing Module A	EXE
GX73-14F398-AD.vbf	Jaguar XE (X760)	IPMA - Image Processing Module A	EXE
GX73-14F398-AE.vbf	Jaguar XE (X760)	IPMA - Image Processing Module A	EXE
GX73-14F398-AF.vbf	Jaguar XE (X760)	IPMA - Image Processing Module A	EXE
GX73-14F398-BB.vbf	Jaguar XE (X760)	IPMA - Image Processing Module A	EXE
GX73-14F398-BC.vbf	Jaguar XE (X760)	IPMA - Image Processing Module A	EXE
GX73-14F398-BD.vbf	Jaguar XE (X760)	IPMA - Image Processing Module A	EXE
GX73-14F398-BE.vbf	Jaguar XE (X760)	IPMA - Image Processing Module A	EXE
GX73-14F398-BF.vbf	Jaguar XE (X760)	IPMA - Image Processing Module A	EXE
GX73-14F530-AE.vbf	Jaguar XE (X760)	GWM - Gateway Module A	EXE
GX73-14F530-AG.vbf	Jaguar XE (X760)	GWM - Gateway Module A	EXE
GX73-14F530-AH.vbf	Jaguar XE (X760)	GWM - Gateway Module A	EXE
GX73-14F530-AJ.vbf	Jaguar XE (X760)	GWM - Gateway Module A	EXE
GX73-14F530-AK.vbf	Jaguar XE (X760)	GWM - Gateway Module A	EXE
GX73-14F531-AD.vbf	Jaguar XE (X760)	GWM - Gateway Module A	DATA
GX73-14F531-AE.vbf	Jaguar XE (X760)	GWM - Gateway Module A	DATA
GX73-14F531-AF.vbf	Jaguar XE (X760)	GWM - Gateway Module A	DATA
GX73-14F531-AG.vbf	Jaguar XE (X760)	GWM - Gateway Module A	DATA
GX73-14F532-AD.vbf	Jaguar XE (X760)	GWM - Gateway Module A	SBL
GX73-19H527-AA.vbf	Jaguar XE (X760)	AUCM - Auxiliary Control Module	EXE
GX73-70713-AL.vbf	Jaguar XE (X760)	TCU - Telematic Control Unit Module	DATA
GX73-70713-AM.vbf	Jaguar XE (X760)	TCU - Telematic Control Unit Module	DATA
GX73-70713-AN.vbf	Jaguar XE (X760)	TCU - Telematic Control Unit Module	DATA
GX73-70713-BAA.vbf	Jaguar XE (X760)	TCU - Telematic Control Unit Module	DATA
GX73-70713-BAB.vbf	Jaguar XE (X760)	TCU - Telematic Control Unit Module	DATA
GX73-70713-BL.vbf	Jaguar XE (X760)	TCU - Telematic Control Unit Module	DATA
GX73-70713-BN.vbf	Jaguar XE (X760)	TCU - Telematic Control Unit Module	DATA
GX73-70713-BP.vbf	Jaguar XE (X760)	TCU - Telematic Control Unit Module	DATA
GX73-70713-BS.vbf	Jaguar XE (X760)	TCU - Telematic Control Unit Module	DATA
GX73-70713-BT.vbf	Jaguar XE (X760)	TCU - Telematic Control Unit Module	DATA
GX73-70713-BV.vbf	Jaguar XE (X760)	TCU - Telematic Control Unit Module	DATA
GX73-70713-BX.vbf	Jaguar XE (X760)	TCU - Telematic Control Unit Module	DATA
GX73-70713-BY.vbf	Jaguar XE (X760)	TCU - Telematic Control Unit Module	DATA
GX73-70713-BZ.vbf	Jaguar XE (X760)	TCU - Telematic Control Unit Module	DATA
GX73-70713-CAA.vbf	Jaguar XE (X760)	TCU - Telematic Control Unit Module	DATA
GX73-70713-CAB.vbf	Jaguar XE (X760)	TCU - Telematic Control Unit Module	DATA
GX73-70713-CL.vbf	Jaguar XE (X760)	TCU - Telematic Control Unit Module	DATA

File name	Vehicle line (indicative)	Module (ECU)	Type
GX73-70713-CM.vbf	Jaguar XE (X760)	TCU - Telematic Control Unit Module	DATA
GX73-70713-CN.vbf	Jaguar XE (X760)	TCU - Telematic Control Unit Module	DATA
GX73-70713-CP.vbf	Jaguar XE (X760)	TCU - Telematic Control Unit Module	DATA
GX73-70713-CS.vbf	Jaguar XE (X760)	TCU - Telematic Control Unit Module	DATA
GX73-70713-CT.vbf	Jaguar XE (X760)	TCU - Telematic Control Unit Module	DATA
GX73-70713-CV.vbf	Jaguar XE (X760)	TCU - Telematic Control Unit Module	DATA
GX73-70713-CX.vbf	Jaguar XE (X760)	TCU - Telematic Control Unit Module	DATA
GX73-70713-CY.vbf	Jaguar XE (X760)	TCU - Telematic Control Unit Module	DATA
GX73-70713-CZ.vbf	Jaguar XE (X760)	TCU - Telematic Control Unit Module	DATA
GX73-70713-DC.vbf	Jaguar XE (X760)	TCU - Telematic Control Unit Module	DATA
GX73-70713-DD.vbf	Jaguar XE (X760)	TCU - Telematic Control Unit Module	DATA
GX73-70713-KC.vbf	Jaguar XE (X760)	TCU - Telematic Control Unit Module	DATA
GX73-70713-KD.vbf	Jaguar XE (X760)	TCU - Telematic Control Unit Module	DATA
GX73-70713-LL.vbf	Jaguar XE (X760)	TCU - Telematic Control Unit Module	DATA
GX73-70713-LN.vbf	Jaguar XE (X760)	TCU - Telematic Control Unit Module	DATA
GX73-70713-MAA.vbf	Jaguar XE (X760)	TCU - Telematic Control Unit Module	DATA
GX73-70713-MAB.vbf	Jaguar XE (X760)	TCU - Telematic Control Unit Module	DATA
GX73-70713-ML.vbf	Jaguar XE (X760)	TCU - Telematic Control Unit Module	DATA
GX73-70713-MN.vbf	Jaguar XE (X760)	TCU - Telematic Control Unit Module	DATA
GX73-70713-MP.vbf	Jaguar XE (X760)	TCU - Telematic Control Unit Module	DATA
GX73-70713-MS.vbf	Jaguar XE (X760)	TCU - Telematic Control Unit Module	DATA
GX73-70713-MT.vbf	Jaguar XE (X760)	TCU - Telematic Control Unit Module	DATA
GX73-70713-MV.vbf	Jaguar XE (X760)	TCU - Telematic Control Unit Module	DATA
GX73-70713-MX.vbf	Jaguar XE (X760)	TCU - Telematic Control Unit Module	DATA
GX73-70713-MY.vbf	Jaguar XE (X760)	TCU - Telematic Control Unit Module	DATA
GX73-70713-MZ.vbf	Jaguar XE (X760)	TCU - Telematic Control Unit Module	DATA
GX73-70713-NAA.vbf	Jaguar XE (X760)	TCU - Telematic Control Unit Module	DATA
GX73-70713-NAB.vbf	Jaguar XE (X760)	TCU - Telematic Control Unit Module	DATA
GX73-70713-NL.vbf	Jaguar XE (X760)	TCU - Telematic Control Unit Module	DATA
GX73-70713-NM.vbf	Jaguar XE (X760)	TCU - Telematic Control Unit Module	DATA
GX73-70713-NN.vbf	Jaguar XE (X760)	TCU - Telematic Control Unit Module	DATA
GX73-70713-NP.vbf	Jaguar XE (X760)	TCU - Telematic Control Unit Module	DATA
GX73-70713-NS.vbf	Jaguar XE (X760)	TCU - Telematic Control Unit Module	DATA
GX73-70713-NT.vbf	Jaguar XE (X760)	TCU - Telematic Control Unit Module	DATA
GX73-70713-NV.vbf	Jaguar XE (X760)	TCU - Telematic Control Unit Module	DATA
GX73-70713-NX.vbf	Jaguar XE (X760)	TCU - Telematic Control Unit Module	DATA
GX73-70713-NY.vbf	Jaguar XE (X760)	TCU - Telematic Control Unit Module	DATA
GX73-70713-NZ.vbf	Jaguar XE (X760)	TCU - Telematic Control Unit Module	DATA
GX73-7J104-BCB.vbf	Jaguar XE (X760)	TCM - Transmission Control Module	EXE
GX73-7J104-BCC.vbf	Jaguar XE (X760)	TCM - Transmission Control Module	EXE
GX73-7J104-BCD.vbf	Jaguar XE (X760)	TCM - Transmission Control Module	EXE
GX73-7J104-BCE.vbf	Jaguar XE (X760)	TCM - Transmission Control Module	EXE
GX73-7J104-BCF.vbf	Jaguar XE (X760)	TCM - Transmission Control Module	EXE
GX73-7J104-BCG.vbf	Jaguar XE (X760)	TCM - Transmission Control Module	EXE
GX73-7J104-BCH.vbf	Jaguar XE (X760)	TCM - Transmission Control Module	EXE
GX73-7J104-BDB.vbf	Jaguar XE (X760)	TCM - Transmission Control Module	EXE
GX73-7J104-BDC.vbf	Jaguar XE (X760)	TCM - Transmission Control Module	EXE
GX73-7J104-BDD.vbf	Jaguar XE (X760)	TCM - Transmission Control Module	EXE
GX73-7J104-BDE.vbf	Jaguar XE (X760)	TCM - Transmission Control Module	EXE
GX73-7J104-BDF.vbf	Jaguar XE (X760)	TCM - Transmission Control Module	EXE
GX73-7J104-BDG.vbf	Jaguar XE (X760)	TCM - Transmission Control Module	EXE
GX73-7J104-BFA.vbf	Jaguar XE (X760)	TCM - Transmission Control Module	EXE
GX73-7J104-BFB.vbf	Jaguar XE (X760)	TCM - Transmission Control Module	EXE
GX73-7J104-BFC.vbf	Jaguar XE (X760)	TCM - Transmission Control Module	EXE
GX73-7J104-BFD.vbf	Jaguar XE (X760)	TCM - Transmission Control Module	EXE
GX73-7J104-BFE.vbf	Jaguar XE (X760)	TCM - Transmission Control Module	EXE
GX73-7J104-BGA.vbf	Jaguar XE (X760)	TCM - Transmission Control Module	EXE
GX73-7J104-BGB.vbf	Jaguar XE (X760)	TCM - Transmission Control Module	EXE
GX73-7J104-BGC.vbf	Jaguar XE (X760)	TCM - Transmission Control Module	EXE
GX73-7J104-BGD.vbf	Jaguar XE (X760)	TCM - Transmission Control Module	EXE
GX73-7J104-BGE.vbf	Jaguar XE (X760)	TCM - Transmission Control Module	EXE
GX73-7J104-BGF.vbf	Jaguar XE (X760)	TCM - Transmission Control Module	EXE
GX73-7J104-BJB.vbf	Jaguar XE (X760)	TCM - Transmission Control Module	EXE
GX73-7J104-BJC.vbf	Jaguar XE (X760)	TCM - Transmission Control Module	EXE
GX73-7J104-BJD.vbf	Jaguar XE (X760)	TCM - Transmission Control Module	EXE
GX73-7J104-BJE.vbf	Jaguar XE (X760)	TCM - Transmission Control Module	EXE
GX73-7J104-BJF.vbf	Jaguar XE (X760)	TCM - Transmission Control Module	EXE
GX7M-19H535-AB.vbf	Not specified	TBM - Trailer Brake Control Module	SIGCFG
GX7M-19H536-AE.vbf	Not specified	TBM - Trailer Brake Control Module	EXE
GX7M-19H536-AF.vbf	Not specified	TBM - Trailer Brake Control Module	EXE
GX7M-19H536-AG.vbf	Not specified	TBM - Trailer Brake Control Module	EXE
GX7M-19H536-AH.vbf	Not specified	TBM - Trailer Brake Control Module	EXE
GX7M-19H536-AJ.vbf	Not specified	TBM - Trailer Brake Control Module	EXE
GX7M-19H538-AD.vbf	Not specified	TBM - Trailer Brake Control Module	SBL
H2C2-14D564-AA.vbf	Discovery Sport (L550)	SODL - Side Obstacle Detection Control Module - Left	DATA
H2C2-14D564-BA.vbf	Discovery Sport (L550)	SODR - Side Obstacle Detection Control Module - Right	DATA

File name	Vehicle line (indicative)	Module (ECU)	Type
H7A3-14C030-AA.vbf	Jaguar XE (X760)	DSM - Driver Front Seat Module	EXE
H7A3-14C030-BA.vbf	Jaguar XE (X760)	DSM - Driver Front Seat Module	EXE
H7A3-14C030-BB.vbf	Jaguar XE (X760)	DSM - Driver Front Seat Module	EXE
H7A3-14C030-BC.vbf	Jaguar XE (X760)	DSM - Driver Front Seat Module	EXE
H7A3-14C034-AA.vbf	Jaguar XE (X760)	DSM - Driver Front Seat Module	EXE
H7A3-14C034-BA.vbf	Jaguar XE (X760)	DSM - Driver Front Seat Module	EXE
H7A3-14C034-CB.vbf	Jaguar XE (X760)	DSM - Driver Front Seat Module	EXE
H7A3-14C034-DA.vbf	Jaguar XE (X760)	DSM - Driver Front Seat Module	EXE
H7A3-14C034-DB.vbf	Jaguar XE (X760)	DSM - Driver Front Seat Module	EXE
H7A3-14C204-FCB.vbf	Jaguar XE (X760)	PCM - Powertrain Control Module	EXE
H7A3-14C204-FCC.vbf	Jaguar XE (X760)	PCM - Powertrain Control Module	EXE
H7A3-14C204-FCD.vbf	Jaguar XE (X760)	PCM - Powertrain Control Module	EXE
H7A3-14C204-FDB.vbf	Jaguar XE (X760)	PCM - Powertrain Control Module	EXE
H7A3-14C204-FDC.vbf	Jaguar XE (X760)	PCM - Powertrain Control Module	EXE
H7A3-14C204-FDD.vbf	Jaguar XE (X760)	PCM - Powertrain Control Module	EXE
H7A3-14C204-FEA.vbf	Jaguar XE (X760)	PCM - Powertrain Control Module	EXE
H7A3-14C204-FEB.vbf	Jaguar XE (X760)	PCM - Powertrain Control Module	EXE
H7A3-14C204-FEC.vbf	Jaguar XE (X760)	PCM - Powertrain Control Module	EXE
H7A3-14C273-FA.vbf	Jaguar XE (X760)	PCM - Powertrain Control Module	SBL
H7A3-14C548-AA.vbf	Jaguar XE (X760)	PSM - Passenger Front Seat Module	EXE
H7A3-14C548-BA.vbf	Jaguar XE (X760)	PSM - Passenger Front Seat Module	EXE
H7A3-14C548-BB.vbf	Jaguar XE (X760)	PSM - Passenger Front Seat Module	EXE
H7A3-14C548-BC.vbf	Jaguar XE (X760)	PSM - Passenger Front Seat Module	EXE
H7A3-14C549-AA.vbf	Jaguar XE (X760)	PSM - Passenger Front Seat Module	EXE
H7A3-14C549-BA.vbf	Jaguar XE (X760)	PSM - Passenger Front Seat Module	EXE
H7A3-14C549-CA.vbf	Jaguar XE (X760)	PSM - Passenger Front Seat Module	EXE
H7A3-14C549-DA.vbf	Jaguar XE (X760)	PSM - Passenger Front Seat Module	EXE
H7A3-14C549-DB.vbf	Jaguar XE (X760)	PSM - Passenger Front Seat Module	EXE
H9A3-14C037-EMH.vbf	Not specified	SPCM - Secondary Powertrain Control Module	DATA
H9A3-14C037-EMJ.vbf	Not specified	SPCM - Secondary Powertrain Control Module	DATA
H9A3-14C037-EML.vbf	Not specified	SPCM - Secondary Powertrain Control Module	DATA
H9A3-14C037-ENH.vbf	Not specified	SPCM - Secondary Powertrain Control Module	DATA
H9A3-14C037-ENJ.vbf	Not specified	SPCM - Secondary Powertrain Control Module	DATA
H9A3-14C037-ENL.vbf	Not specified	SPCM - Secondary Powertrain Control Module	DATA
H9A3-14C037-ERH.vbf	Not specified	SPCM - Secondary Powertrain Control Module	DATA
H9A3-14C037-ERJ.vbf	Not specified	SPCM - Secondary Powertrain Control Module	DATA
H9A3-14C037-ERL.vbf	Not specified	SPCM - Secondary Powertrain Control Module	DATA
H9A3-14C037-GAE.vbf	Not specified	ABS - Anti-Lock Brake System Control Module	DATA
H9A3-14C037-GAF.vbf	Not specified	ABS - Anti-Lock Brake System Control Module	DATA
H9A3-14C037-GAG.vbf	Not specified	ABS - Anti-Lock Brake System Control Module	DATA
H9A3-14C037-GAH.vbf	Not specified	ABS - Anti-Lock Brake System Control Module	DATA
H9A3-14C037-GAJ.vbf	Not specified	ABS - Anti-Lock Brake System Control Module	DATA
H9A3-14C037-GBE.vbf	Not specified	ABS - Anti-Lock Brake System Control Module	DATA
H9A3-14C037-GBF.vbf	Not specified	ABS - Anti-Lock Brake System Control Module	DATA
H9A3-14C037-GBG.vbf	Not specified	ABS - Anti-Lock Brake System Control Module	DATA
H9A3-14C037-GBH.vbf	Not specified	ABS - Anti-Lock Brake System Control Module	DATA
H9A3-14C037-GBJ.vbf	Not specified	ABS - Anti-Lock Brake System Control Module	DATA
H9A3-14C037-GDE.vbf	Not specified	ABS - Anti-Lock Brake System Control Module	DATA
H9A3-14C037-GDF.vbf	Not specified	ABS - Anti-Lock Brake System Control Module	DATA
H9A3-14C037-GDG.vbf	Not specified	ABS - Anti-Lock Brake System Control Module	DATA
H9A3-14C037-GDH.vbf	Not specified	ABS - Anti-Lock Brake System Control Module	DATA
H9A3-14C037-GDJ.vbf	Not specified	ABS - Anti-Lock Brake System Control Module	DATA
H9A3-14C037-GEE.vbf	Not specified	ABS - Anti-Lock Brake System Control Module	DATA
H9A3-14C037-GEF.vbf	Not specified	ABS - Anti-Lock Brake System Control Module	DATA
H9A3-14C037-GEG.vbf	Not specified	ABS - Anti-Lock Brake System Control Module	DATA
H9A3-14C037-GEH.vbf	Not specified	ABS - Anti-Lock Brake System Control Module	DATA
H9A3-14C037-GEJ.vbf	Not specified	ABS - Anti-Lock Brake System Control Module	DATA
H9A3-14C037-GFE.vbf	Not specified	ABS - Anti-Lock Brake System Control Module	DATA
H9A3-14C037-GFF.vbf	Not specified	ABS - Anti-Lock Brake System Control Module	DATA
H9A3-14C037-GFG.vbf	Not specified	ABS - Anti-Lock Brake System Control Module	DATA
H9A3-14C037-GFH.vbf	Not specified	ABS - Anti-Lock Brake System Control Module	DATA
H9A3-14C037-GFJ.vbf	Not specified	ABS - Anti-Lock Brake System Control Module	DATA
H9A3-14C037-GGE.vbf	Not specified	ABS - Anti-Lock Brake System Control Module	DATA
H9A3-14C037-GGF.vbf	Not specified	ABS - Anti-Lock Brake System Control Module	DATA
H9A3-14C037-GGG.vbf	Not specified	ABS - Anti-Lock Brake System Control Module	DATA
H9A3-14C037-GGH.vbf	Not specified	ABS - Anti-Lock Brake System Control Module	DATA
H9A3-14C037-GGJ.vbf	Not specified	ABS - Anti-Lock Brake System Control Module	DATA
H9A3-14C037-SMH.vbf	Not specified	SPCM - Secondary Powertrain Control Module	DATA
H9A3-14C037-SMJ.vbf	Not specified	SPCM - Secondary Powertrain Control Module	DATA
H9A3-14C037-SML.vbf	Not specified	SPCM - Secondary Powertrain Control Module	DATA
H9A3-14C037-SNH.vbf	Not specified	SPCM - Secondary Powertrain Control Module	DATA
H9A3-14C037-SNJ.vbf	Not specified	SPCM - Secondary Powertrain Control Module	DATA
H9A3-14C037-SNL.vbf	Not specified	SPCM - Secondary Powertrain Control Module	DATA
H9A3-14C037-SRH.vbf	Not specified	SPCM - Secondary Powertrain Control Module	DATA
H9A3-14C037-SRJ.vbf	Not specified	SPCM - Secondary Powertrain Control Module	DATA
H9A3-14C037-SRL.vbf	Not specified	SPCM - Secondary Powertrain Control Module	DATA

File name	Vehicle line (indicative)	Module (ECU)	Type
H9A3-14C037-UAE.vbf	Not specified	ABS - Anti-Lock Brake System Control Module	DATA
H9A3-14C037-UAF.vbf	Not specified	ABS - Anti-Lock Brake System Control Module	DATA
H9A3-14C037-UAG.vbf	Not specified	ABS - Anti-Lock Brake System Control Module	DATA
H9A3-14C037-UAH.vbf	Not specified	ABS - Anti-Lock Brake System Control Module	DATA
H9A3-14C037-UAJ.vbf	Not specified	ABS - Anti-Lock Brake System Control Module	DATA
H9A3-14C037-UBE.vbf	Not specified	ABS - Anti-Lock Brake System Control Module	DATA
H9A3-14C037-UBF.vbf	Not specified	ABS - Anti-Lock Brake System Control Module	DATA
H9A3-14C037-UBG.vbf	Not specified	ABS - Anti-Lock Brake System Control Module	DATA
H9A3-14C037-UBH.vbf	Not specified	ABS - Anti-Lock Brake System Control Module	DATA
H9A3-14C037-UBJ.vbf	Not specified	ABS - Anti-Lock Brake System Control Module	DATA
H9A3-14C037-UDE.vbf	Not specified	ABS - Anti-Lock Brake System Control Module	DATA
H9A3-14C037-UDF.vbf	Not specified	ABS - Anti-Lock Brake System Control Module	DATA
H9A3-14C037-UDG.vbf	Not specified	ABS - Anti-Lock Brake System Control Module	DATA
H9A3-14C037-UDH.vbf	Not specified	ABS - Anti-Lock Brake System Control Module	DATA
H9A3-14C037-UDJ.vbf	Not specified	ABS - Anti-Lock Brake System Control Module	DATA
H9A3-14C037-UEE.vbf	Not specified	ABS - Anti-Lock Brake System Control Module	DATA
H9A3-14C037-UEF.vbf	Not specified	ABS - Anti-Lock Brake System Control Module	DATA
H9A3-14C037-UEG.vbf	Not specified	ABS - Anti-Lock Brake System Control Module	DATA
H9A3-14C037-UEH.vbf	Not specified	ABS - Anti-Lock Brake System Control Module	DATA
H9A3-14C037-UEJ.vbf	Not specified	ABS - Anti-Lock Brake System Control Module	DATA
H9A3-14C037-UFE.vbf	Not specified	ABS - Anti-Lock Brake System Control Module	DATA
H9A3-14C037-UFF.vbf	Not specified	ABS - Anti-Lock Brake System Control Module	DATA
H9A3-14C037-UFG.vbf	Not specified	ABS - Anti-Lock Brake System Control Module	DATA
H9A3-14C037-UFH.vbf	Not specified	ABS - Anti-Lock Brake System Control Module	DATA
H9A3-14C037-UFJ.vbf	Not specified	ABS - Anti-Lock Brake System Control Module	DATA
H9A3-14C037-UGE.vbf	Not specified	ABS - Anti-Lock Brake System Control Module	DATA
H9A3-14C037-UGF.vbf	Not specified	ABS - Anti-Lock Brake System Control Module	DATA
H9A3-14C037-UGG.vbf	Not specified	ABS - Anti-Lock Brake System Control Module	DATA
H9A3-14C037-UGH.vbf	Not specified	ABS - Anti-Lock Brake System Control Module	DATA
H9A3-14C037-UGJ.vbf	Not specified	ABS - Anti-Lock Brake System Control Module	DATA
H9A3-14C065-AD.vbf	Check in SDD (unconfirmed)	DDM - Driver Front Door Module	DATA
H9A3-14C065-AE.vbf	Check in SDD (unconfirmed)	DDM - Driver Front Door Module	DATA
H9A3-14C065-AF.vbf	Check in SDD (unconfirmed)	DDM - Driver Front Door Module	DATA
H9A3-14C065-AG.vbf	Check in SDD (unconfirmed)	DDM - Driver Front Door Module	DATA
H9A3-14C069-AD.vbf	Check in SDD (unconfirmed)	DRDM - Driver Rear Door Module	DATA
H9A3-14C069-AE.vbf	Check in SDD (unconfirmed)	DRDM - Driver Rear Door Module	DATA
H9A3-14C069-AF.vbf	Check in SDD (unconfirmed)	DRDM - Driver Rear Door Module	DATA
H9A3-14C069-AG.vbf	Check in SDD (unconfirmed)	DRDM - Driver Rear Door Module	DATA
H9A3-14C091-AB.vbf	Jaguar XF (X260)	PAM - Parking Assist Control Module	DATA
H9A3-14C091-AE.vbf	Jaguar XF (X260)	PAM - Parking Assist Control Module	DATA
H9A3-14C091-AF.vbf	Jaguar XF (X260)	PAM - Parking Assist Control Module	DATA
H9A3-14C091-AG.vbf	Jaguar XF (X260)	PAM - Parking Assist Control Module	DATA
H9A3-14C091-BB.vbf	Jaguar XF (X260)	PAM - Parking Assist Control Module	DATA
H9A3-14C091-BD.vbf	Jaguar XF (X260)	PAM - Parking Assist Control Module	DATA
H9A3-14C091-BE.vbf	Jaguar XF (X260)	PAM - Parking Assist Control Module	DATA
H9A3-14C105-AA.vbf	Jaguar XF (X260)	TMC Traffic Message Channel Module	DATA
H9A3-14C105-AD.vbf	Jaguar XF (X260)	TMC Traffic Message Channel Module	DATA
H9A3-14C105-BC.vbf	Jaguar XF (X260)	TMC Traffic Message Channel Module	DATA
H9A3-14C109-AD.vbf	Check in SDD (unconfirmed)	PDM - Passenger Front Door Module	DATA
H9A3-14C109-AE.vbf	Check in SDD (unconfirmed)	PDM - Passenger Front Door Module	DATA
H9A3-14C109-AF.vbf	Check in SDD (unconfirmed)	PDM - Passenger Front Door Module	DATA
H9A3-14C109-AG.vbf	Check in SDD (unconfirmed)	PDM - Passenger Front Door Module	DATA
H9A3-14C113-AD.vbf	Check in SDD (unconfirmed)	PRDM - Passenger Rear Door Module	DATA
H9A3-14C113-AE.vbf	Check in SDD (unconfirmed)	PRDM - Passenger Rear Door Module	DATA
H9A3-14C113-AF.vbf	Check in SDD (unconfirmed)	PRDM - Passenger Rear Door Module	DATA
H9A3-14C113-AG.vbf	Check in SDD (unconfirmed)	PRDM - Passenger Rear Door Module	DATA
H9A3-14C204-MVA.vbf	Jaguar XF (X260)	PCM - Powertrain Control Module	EXE
H9A3-14C527-CC.vbf	Not specified	AAM - Audio Amplifier Module	DATA
H9A3-14C535-AA.vbf	Not specified	FCIM - Front Controls Interface Module	EXE
H9A3-14C536-AA.vbf	Not specified	FCIM - Front Controls Interface Module	DATA
H9A3-14D367-AB.vbf	Not specified	SODL - Side Obstacle Detection Control Module - Left	SIGCFG
H9A3-14D367-AC.vbf	Not specified	SODL - Side Obstacle Detection Control Module - Left	SIGCFG
H9A3-14D367-BB.vbf	Not specified	SODR - Side Obstacle Detection Control Module - Right	SIGCFG
H9A3-14D367-BC.vbf	Not specified	SODR - Side Obstacle Detection Control Module - Right	SIGCFG
H9A3-14D368-AB.vbf	Not specified	SODL - Side Obstacle Detection Control Module - Left	EXE
H9A3-14D368-AD.vbf	Not specified	SODL - Side Obstacle Detection Control Module - Left	EXE
H9A3-14D368-AE.vbf	Not specified	SODL - Side Obstacle Detection Control Module - Left	EXE
H9A3-14D368-AF.vbf	Not specified	SODL - Side Obstacle Detection Control Module - Left	EXE
H9A3-14D368-AG.vbf	Not specified	SODL - Side Obstacle Detection Control Module - Left	EXE
H9A3-14D368-AH.vbf	Not specified	SODL - Side Obstacle Detection Control Module - Left	EXE
H9A3-14D368-BA.vbf	Not specified	SODL - Side Obstacle Detection Control Module - Left	EXE
H9A3-14D368-BC.vbf	Not specified	SODL - Side Obstacle Detection Control Module - Left	EXE
H9A3-14D368-BD.vbf	Not specified	SODL - Side Obstacle Detection Control Module - Left	EXE
H9A3-14D368-BE.vbf	Not specified	SODL - Side Obstacle Detection Control Module - Left	EXE
H9A3-14D368-BF.vbf	Not specified	SODL - Side Obstacle Detection Control Module - Left	EXE
H9A3-14D368-BG.vbf	Not specified	SODL - Side Obstacle Detection Control Module - Left	EXE

File name	Vehicle line (indicative)	Module (ECU)	Type
H9A3-14D370-AA.vbf	Not specified	SODL - Side Obstacle Detection Control Module - Left	SBL
H9A3-14D370-AC.vbf	Not specified	SODL - Side Obstacle Detection Control Module - Left	SBL
H9A3-14D370-AD.vbf	Not specified	SODL - Side Obstacle Detection Control Module - Left	SBL
H9A3-14D370-AE.vbf	Not specified	SODL - Side Obstacle Detection Control Module - Left	SBL
H9A3-14D370-AF.vbf	Not specified	SODL - Side Obstacle Detection Control Module - Left	SBL
H9A3-14D481-BB.vbf	Not specified	IPMB - Image Processing Module B	DATA
H9A3-14D481-BC.vbf	Not specified	IPMB - Image Processing Module B	DATA
H9A3-14D485-CD.vbf	Not specified	IPMB - Image Processing Module B	DATA
H9A3-14D485-CE.vbf	Not specified	IPMB - Image Processing Module B	DATA
H9A3-14D520-BA.vbf	Not specified	HVAC - HVAC Control Module	DATA
H9A3-14D520-BB.vbf	Not specified	HVAC - HVAC Control Module	DATA
H9A3-14D520-BC.vbf	Not specified	HVAC - HVAC Control Module	DATA
H9A3-14D520-DA.vbf	Not specified	HVAC - HVAC Control Module	DATA
H9A3-14D520-DB.vbf	Not specified	HVAC - HVAC Control Module	DATA
H9A3-14D520-DC.vbf	Not specified	HVAC - HVAC Control Module	DATA
H9A3-14D564-AB.vbf	Not specified	SODL - Side Obstacle Detection Control Module - Left	DATA
H9A3-14D564-AD.vbf	Not specified	SODL - Side Obstacle Detection Control Module - Left	DATA
H9A3-14D564-AE.vbf	Not specified	SODL - Side Obstacle Detection Control Module - Left	DATA
H9A3-14D564-AF.vbf	Not specified	SODL - Side Obstacle Detection Control Module - Left	DATA
H9A3-14D564-AG.vbf	Not specified	SODL - Side Obstacle Detection Control Module - Left	DATA
H9A3-14D564-BB.vbf	Not specified	SODR - Side Obstacle Detection Control Module - Right	DATA
H9A3-14D564-BD.vbf	Not specified	SODR - Side Obstacle Detection Control Module - Right	DATA
H9A3-14D564-BE.vbf	Not specified	SODR - Side Obstacle Detection Control Module - Right	DATA
H9A3-14D564-BF.vbf	Not specified	SODR - Side Obstacle Detection Control Module - Right	DATA
H9A3-14D564-BG.vbf	Not specified	SODR - Side Obstacle Detection Control Module - Right	DATA
H9A3-14F022-BG.vbf	Not specified	IPMB - Image Processing Module B	DATA
H9A3-14F022-BH.vbf	Not specified	IPMB - Image Processing Module B	DATA
H9A3-14F022-GF.vbf	Not specified	IPMB - Image Processing Module B	DATA
H9A3-14F022-GG.vbf	Not specified	IPMB - Image Processing Module B	DATA
H9A3-14F022-GH.vbf	Not specified	IPMB - Image Processing Module B	DATA
H9A3-14F216-AA.vbf	Not specified	RHVAC - Rear HVAC Control Module	SIGCFG
H9A3-14F217-AC.vbf	Not specified	RHVAC - Rear HVAC Control Module	EXE
H9A3-14F218-AC.vbf	Not specified	RHVAC - Rear HVAC Control Module	DATA
H9A3-14F219-AC.vbf	Not specified	RHVAC - Rear HVAC Control Module	SBL
H9A3-14F530-AA.vbf	Not specified	GWM - Gateway Module A	EXE
H9A3-14F530-AC.vbf	Not specified	GWM - Gateway Module A	EXE
H9A3-14F530-AD.vbf	Not specified	GWM - Gateway Module A	EXE
H9A3-14F530-AE.vbf	Not specified	GWM - Gateway Module A	EXE
H9A3-19C204-AC.vbf	Not specified	IMC - Infotainment Master Controller	EXE
H9A3-19C204-AD.vbf	Not specified	IMC - Infotainment Master Controller	EXE
H9A3-19C204-AE.vbf	Not specified	IMC - Infotainment Master Controller	EXE
HJ32-12K532-FBB.vbf	Range Rover Evoque (L538)	PCM - Powertrain Control Module	DATA
HJ32-12K532-FBC.vbf	Range Rover Evoque (L538)	PCM - Powertrain Control Module	DATA
HJ32-12K532-FBD.vbf	Range Rover Evoque (L538)	PCM - Powertrain Control Module	DATA
HJ32-12K532-FBE.vbf	Range Rover Evoque (L538)	PCM - Powertrain Control Module	DATA
HJ32-12K532-FBF.vbf	Range Rover Evoque (L538)	PCM - Powertrain Control Module	DATA
HJ32-12K532-FTA.vbf	Range Rover Evoque (L538)	PCM - Powertrain Control Module	DATA
HJ32-12K532-FTB.vbf	Range Rover Evoque (L538)	PCM - Powertrain Control Module	DATA
HJ32-12K532-FTC.vbf	Range Rover Evoque (L538)	PCM - Powertrain Control Module	DATA
HJ32-12K532-FTD.vbf	Range Rover Evoque (L538)	PCM - Powertrain Control Module	DATA
HJ32-12K532-FTE.vbf	Range Rover Evoque (L538)	PCM - Powertrain Control Module	DATA
HJ32-12K532-FXA.vbf	Range Rover Evoque (L538)	PCM - Powertrain Control Module	DATA
HJ32-12K532-FXB.vbf	Range Rover Evoque (L538)	PCM - Powertrain Control Module	DATA
HJ32-12K532-FXC.vbf	Range Rover Evoque (L538)	PCM - Powertrain Control Module	DATA
HJ32-12K532-FXD.vbf	Range Rover Evoque (L538)	PCM - Powertrain Control Module	DATA
HJ32-12K532-FXE.vbf	Range Rover Evoque (L538)	PCM - Powertrain Control Module	DATA
HJ32-12K532-FZA.vbf	Range Rover Evoque (L538)	PCM - Powertrain Control Module	DATA
HJ32-12K532-FZB.vbf	Range Rover Evoque (L538)	PCM - Powertrain Control Module	DATA
HJ32-12K532-FZC.vbf	Range Rover Evoque (L538)	PCM - Powertrain Control Module	DATA
HJ32-12K532-FZD.vbf	Range Rover Evoque (L538)	PCM - Powertrain Control Module	DATA
HJ32-12K532-FZE.vbf	Range Rover Evoque (L538)	PCM - Powertrain Control Module	DATA
HJ32-12K532-GAA.vbf	Range Rover Evoque (L538)	PCM - Powertrain Control Module	DATA
HJ32-12K532-GAB.vbf	Range Rover Evoque (L538)	PCM - Powertrain Control Module	DATA
HJ32-12K532-GAC.vbf	Range Rover Evoque (L538)	PCM - Powertrain Control Module	DATA
HJ32-12K532-GAD.vbf	Range Rover Evoque (L538)	PCM - Powertrain Control Module	DATA
HJ32-12K532-GAE.vbf	Range Rover Evoque (L538)	PCM - Powertrain Control Module	DATA
HJ32-12K532-GAF.vbf	Range Rover Evoque (L538)	PCM - Powertrain Control Module	DATA
HJ32-12K532-GAG.vbf	Range Rover Evoque (L538)	PCM - Powertrain Control Module	DATA
HJ32-12K532-GBA.vbf	Range Rover Evoque (L538)	PCM - Powertrain Control Module	DATA
HJ32-12K532-GBB.vbf	Range Rover Evoque (L538)	PCM - Powertrain Control Module	DATA
HJ32-12K532-GBC.vbf	Range Rover Evoque (L538)	PCM - Powertrain Control Module	DATA
HJ32-12K532-GBD.vbf	Range Rover Evoque (L538)	PCM - Powertrain Control Module	DATA
HJ32-12K532-GBE.vbf	Range Rover Evoque (L538)	PCM - Powertrain Control Module	DATA
HJ32-12K532-GBF.vbf	Range Rover Evoque (L538)	PCM - Powertrain Control Module	DATA
HJ32-12K532-GBG.vbf	Range Rover Evoque (L538)	PCM - Powertrain Control Module	DATA
HJ32-12K532-GCA.vbf	Range Rover Evoque (L538)	PCM - Powertrain Control Module	DATA

File name	Vehicle line (indicative)	Module (ECU)	Type
HJ32-12K532-GCB.vbf	Range Rover Evoque (L538)	PCM - Powertrain Control Module	DATA
HJ32-12K532-GCC.vbf	Range Rover Evoque (L538)	PCM - Powertrain Control Module	DATA
HJ32-12K532-GCD.vbf	Range Rover Evoque (L538)	PCM - Powertrain Control Module	DATA
HJ32-12K532-GCE.vbf	Range Rover Evoque (L538)	PCM - Powertrain Control Module	DATA
HJ32-12K532-GCF.vbf	Range Rover Evoque (L538)	PCM - Powertrain Control Module	DATA
HJ32-12K532-GCG.vbf	Range Rover Evoque (L538)	PCM - Powertrain Control Module	DATA
HJ32-12K532-GDB.vbf	Range Rover Evoque (L538)	PCM - Powertrain Control Module	DATA
HJ32-12K532-GDC.vbf	Range Rover Evoque (L538)	PCM - Powertrain Control Module	DATA
HJ32-12K532-GDD.vbf	Range Rover Evoque (L538)	PCM - Powertrain Control Module	DATA
HJ32-12K532-GDE.vbf	Range Rover Evoque (L538)	PCM - Powertrain Control Module	DATA
HJ32-12K532-GDF.vbf	Range Rover Evoque (L538)	PCM - Powertrain Control Module	DATA
HJ32-12K532-GDG.vbf	Range Rover Evoque (L538)	PCM - Powertrain Control Module	DATA
HJ32-12K532-GEB.vbf	Range Rover Evoque (L538)	PCM - Powertrain Control Module	DATA
HJ32-12K532-GFB.vbf	Range Rover Evoque (L538)	PCM - Powertrain Control Module	DATA
HJ32-12K532-GGA.vbf	Range Rover Evoque (L538)	PCM - Powertrain Control Module	DATA
HJ32-12K532-GGB.vbf	Range Rover Evoque (L538)	PCM - Powertrain Control Module	DATA
HJ32-12K532-GGC.vbf	Range Rover Evoque (L538)	PCM - Powertrain Control Module	DATA
HJ32-12K532-GGD.vbf	Range Rover Evoque (L538)	PCM - Powertrain Control Module	DATA
HJ32-12K532-GHB.vbf	Range Rover Evoque (L538)	PCM - Powertrain Control Module	DATA
HJ32-12K532-GHC.vbf	Range Rover Evoque (L538)	PCM - Powertrain Control Module	DATA
HJ32-12K532-GJB.vbf	Range Rover Evoque (L538)	PCM - Powertrain Control Module	DATA
HJ32-12K532-GJC.vbf	Range Rover Evoque (L538)	PCM - Powertrain Control Module	DATA
HJ32-12K532-GKB.vbf	Range Rover Evoque (L538)	PCM - Powertrain Control Module	DATA
HJ32-12K532-GKC.vbf	Range Rover Evoque (L538)	PCM - Powertrain Control Module	DATA
HJ32-12K532-GLB.vbf	Range Rover Evoque (L538)	PCM - Powertrain Control Module	DATA
HJ32-12K532-GLC.vbf	Range Rover Evoque (L538)	PCM - Powertrain Control Module	DATA
HJ32-12K532-GLD.vbf	Range Rover Evoque (L538)	PCM - Powertrain Control Module	DATA
HJ32-12K532-GLE.vbf	Range Rover Evoque (L538)	PCM - Powertrain Control Module	DATA
HJ32-12K532-GLF.vbf	Range Rover Evoque (L538)	PCM - Powertrain Control Module	DATA
HJ32-12K532-GLG.vbf	Range Rover Evoque (L538)	PCM - Powertrain Control Module	DATA
HJ32-12K532-GMB.vbf	Range Rover Evoque (L538)	PCM - Powertrain Control Module	DATA
HJ32-12K532-GMC.vbf	Range Rover Evoque (L538)	PCM - Powertrain Control Module	DATA
HJ32-12K532-GPA.vbf	Range Rover Evoque (L538)	PCM - Powertrain Control Module	DATA
HJ32-12K532-GPB.vbf	Range Rover Evoque (L538)	PCM - Powertrain Control Module	DATA
HJ32-12K532-GRA.vbf	Range Rover Evoque (L538)	PCM - Powertrain Control Module	DATA
HJ32-12K532-GRB.vbf	Range Rover Evoque (L538)	PCM - Powertrain Control Module	DATA
HJ32-12K532-GSA.vbf	Range Rover Evoque (L538)	PCM - Powertrain Control Module	DATA
HJ32-12K532-GSB.vbf	Range Rover Evoque (L538)	PCM - Powertrain Control Module	DATA
HJ32-12K532-GTB.vbf	Range Rover Evoque (L538)	PCM - Powertrain Control Module	DATA
HJ32-12K532-GTC.vbf	Range Rover Evoque (L538)	PCM - Powertrain Control Module	DATA
HJ32-12K532-GTD.vbf	Range Rover Evoque (L538)	PCM - Powertrain Control Module	DATA
HJ32-12K532-GTE.vbf	Range Rover Evoque (L538)	PCM - Powertrain Control Module	DATA
HJ32-12K532-GTF.vbf	Range Rover Evoque (L538)	PCM - Powertrain Control Module	DATA
HJ32-12K532-GTG.vbf	Range Rover Evoque (L538)	PCM - Powertrain Control Module	DATA
HJ32-12K532-GUB.vbf	Range Rover Evoque (L538)	PCM - Powertrain Control Module	DATA
HJ32-12K532-GUC.vbf	Range Rover Evoque (L538)	PCM - Powertrain Control Module	DATA
HJ32-12K532-GUD.vbf	Range Rover Evoque (L538)	PCM - Powertrain Control Module	DATA
HJ32-12K532-KAC.vbf	Range Rover Evoque (L538)	PCM - Powertrain Control Module	DATA
HJ32-12K532-KAE.vbf	Range Rover Evoque (L538)	PCM - Powertrain Control Module	DATA
HJ32-12K532-KAF.vbf	Range Rover Evoque (L538)	PCM - Powertrain Control Module	DATA
HJ32-12K532-KAG.vbf	Range Rover Evoque (L538)	PCM - Powertrain Control Module	DATA
HJ32-12K532-KAJ.vbf	Range Rover Evoque (L538)	PCM - Powertrain Control Module	DATA
HJ32-12K532-KAK.vbf	Range Rover Evoque (L538)	PCM - Powertrain Control Module	DATA
HJ32-12K532-KBC.vbf	Range Rover Evoque (L538)	PCM - Powertrain Control Module	DATA
HJ32-12K532-KBE.vbf	Range Rover Evoque (L538)	PCM - Powertrain Control Module	DATA
HJ32-12K532-KBF.vbf	Range Rover Evoque (L538)	PCM - Powertrain Control Module	DATA
HJ32-12K532-KBG.vbf	Range Rover Evoque (L538)	PCM - Powertrain Control Module	DATA
HJ32-12K532-KCA.vbf	Range Rover Evoque (L538)	PCM - Powertrain Control Module	DATA
HJ32-12K532-KCB.vbf	Range Rover Evoque (L538)	PCM - Powertrain Control Module	DATA
HJ32-12K532-KCC.vbf	Range Rover Evoque (L538)	PCM - Powertrain Control Module	DATA
HJ32-12K532-KDB.vbf	Range Rover Evoque (L538)	PCM - Powertrain Control Module	DATA
HJ32-12K532-KDC.vbf	Range Rover Evoque (L538)	PCM - Powertrain Control Module	DATA
HJ32-12K532-KEA.vbf	Range Rover Evoque (L538)	PCM - Powertrain Control Module	DATA
HJ32-12K532-KFC.vbf	Range Rover Evoque (L538)	PCM - Powertrain Control Module	DATA
HJ32-12K532-KFE.vbf	Range Rover Evoque (L538)	PCM - Powertrain Control Module	DATA
HJ32-12K532-KFF.vbf	Range Rover Evoque (L538)	PCM - Powertrain Control Module	DATA
HJ32-12K532-KGB.vbf	Range Rover Evoque (L538)	PCM - Powertrain Control Module	DATA
HJ32-12K532-KGD.vbf	Range Rover Evoque (L538)	PCM - Powertrain Control Module	DATA
HJ32-12K532-KHD.vbf	Range Rover Evoque (L538)	PCM - Powertrain Control Module	DATA
HJ32-12K532-KKA.vbf	Range Rover Evoque (L538)	PCM - Powertrain Control Module	DATA
HJ32-12K532-KKB.vbf	Range Rover Evoque (L538)	PCM - Powertrain Control Module	DATA
HJ32-12K532-KLA.vbf	Range Rover Evoque (L538)	PCM - Powertrain Control Module	DATA
HJ32-12K532-KLB.vbf	Range Rover Evoque (L538)	PCM - Powertrain Control Module	DATA
HJ32-14C025-AA.vbf	Range Rover Evoque (L538)	IPC - Instrument Panel Cluster (IPC) Control Module	SBL
HJ32-14C025-AB.vbf	Range Rover Evoque (L538)	IPC - Instrument Panel Cluster (IPC) Control Module	SBL
HJ32-14C026-AA.vbf	Range Rover Evoque (L538)	IPC - Instrument Panel Cluster (IPC) Control Module	EXE

File name	Vehicle line (indicative)	Module (ECU)	Type
HJ32-14C026-AB.vbf	Range Rover Evoque (L538)	IPC - Instrument Panel Cluster (IPC) Control Module	EXE
HJ32-14C026-AC.vbf	Range Rover Evoque (L538)	IPC - Instrument Panel Cluster (IPC) Control Module	EXE
HJ32-14C026-AD.vbf	Range Rover Evoque (L538)	IPC - Instrument Panel Cluster (IPC) Control Module	EXE
HJ32-14C026-AE.vbf	Range Rover Evoque (L538)	IPC - Instrument Panel Cluster (IPC) Control Module	EXE
HJ32-14C036-AB.vbf	Range Rover Evoque (L538)	ABS - Anit-Lock Brake System (ABS) Control Module	EXE
HJ32-14C036-AC.vbf	Range Rover Evoque (L538)	ABS - Anit-Lock Brake System (ABS) Control Module	EXE
HJ32-14C036-AD.vbf	Range Rover Evoque (L538)	ABS - Anit-Lock Brake System (ABS) Control Module	EXE
HJ32-14C036-AE.vbf	Range Rover Evoque (L538)	ABS - Anit-Lock Brake System (ABS) Control Module	EXE
HJ32-14C036-AF.vbf	Range Rover Evoque (L538)	ABS - Anit-Lock Brake System (ABS) Control Module	EXE
HJ32-14C036-AG.vbf	Range Rover Evoque (L538)	ABS - Anit-Lock Brake System (ABS) Control Module	EXE
HJ32-14C088-BB.vbf	Range Rover Evoque (L538)	IPC - Instrument Panel Cluster (IPC) Control Module	DATA
HJ32-14C088-CA.vbf	Range Rover Evoque (L538)	IPC - Instrument Panel Cluster (IPC) Control Module	EXE
HJ32-14C088-CB.vbf	Range Rover Evoque (L538)	IPC - Instrument Panel Cluster (IPC) Control Module	EXE
HJ32-14C088-CC.vbf	Range Rover Evoque (L538)	IPC - Instrument Panel Cluster (IPC) Control Module	EXE
HJ32-14C088-CD.vbf	Range Rover Evoque (L538)	IPC - Instrument Panel Cluster (IPC) Control Module	EXE
HJ32-14C088-DA.vbf	Range Rover Evoque (L538)	IPC - Instrument Panel Cluster (IPC) Control Module	DATA
HJ32-14C152-AA.vbf	Range Rover Evoque (L538)	TPM - Tire Pressure Monitor Module	DATA
HJ32-14C152-AB.vbf	Range Rover Evoque (L538)	TPM - Tire Pressure Monitor Module	DATA
HJ32-14C337-CAA.vbf	Range Rover Evoque (L538)	TCM - Transmission Control Module	EXE
HJ32-14C337-CAC.vbf	Range Rover Evoque (L538)	TCM - Transmission Control Module	EXE
HJ32-14C337-CAD.vbf	Range Rover Evoque (L538)	TCM - Transmission Control Module	EXE
HJ32-14C337-CAE.vbf	Range Rover Evoque (L538)	TCM - Transmission Control Module	EXE
HJ32-14C337-CAF.vbf	Range Rover Evoque (L538)	TCM - Transmission Control Module	EXE
HJ32-14C337-CAG.vbf	Range Rover Evoque (L538)	TCM - Transmission Control Module	EXE
HJ32-14C337-CBA.vbf	Range Rover Evoque (L538)	TCM - Transmission Control Module	EXE
HJ32-14C337-CCA.vbf	Range Rover Evoque (L538)	TCM - Transmission Control Module	EXE
HJ32-14C337-CCB.vbf	Range Rover Evoque (L538)	TCM - Transmission Control Module	EXE
HJ32-14C337-CCC.vbf	Range Rover Evoque (L538)	TCM - Transmission Control Module	EXE
HJ32-14C337-CCD.vbf	Range Rover Evoque (L538)	TCM - Transmission Control Module	EXE
HJ32-14C337-CCE.vbf	Range Rover Evoque (L538)	TCM - Transmission Control Module	EXE
HJ32-14C337-CDA.vbf	Range Rover Evoque (L538)	TCM - Transmission Control Module	EXE
HJ32-14C337-CDB.vbf	Range Rover Evoque (L538)	TCM - Transmission Control Module	EXE
HJ32-14C337-CDD.vbf	Range Rover Evoque (L538)	TCM - Transmission Control Module	EXE
HJ32-14C527-BAB.vbf	Range Rover Evoque (L538)	AAM - Audio Amplifier Module	DATA
HJ32-14C527-BB.vbf	Range Rover Evoque (L538)	AAM - Audio Amplifier Module	DATA
HJ32-14C527-BBB.vbf	Range Rover Evoque (L538)	AAM - Audio Amplifier Module	DATA
HJ32-14C527-BC.vbf	Range Rover Evoque (L538)	AAM - Audio Amplifier Module	DATA
HJ32-14C527-BDB.vbf	Range Rover Evoque (L538)	AAM - Audio Amplifier Module	DATA
HJ32-14C527-BEB.vbf	Range Rover Evoque (L538)	AAM - Audio Amplifier Module	DATA
HJ32-14C527-CAB.vbf	Range Rover Evoque (L538)	AAM - Audio Amplifier Module	DATA
HJ32-14C527-CB.vbf	Range Rover Evoque (L538)	AAM - Audio Amplifier Module	DATA
HJ32-14C527-CBB.vbf	Range Rover Evoque (L538)	AAM - Audio Amplifier Module	DATA
HJ32-14C527-CDB.vbf	Range Rover Evoque (L538)	AAM - Audio Amplifier Module	DATA
HJ32-14C527-CEB.vbf	Range Rover Evoque (L538)	AAM - Audio Amplifier Module	DATA
HJ32-14C527-FAB.vbf	Range Rover Evoque (L538)	AAM - Audio Amplifier Module	DATA
HJ32-14C527-FB.vbf	Range Rover Evoque (L538)	AAM - Audio Amplifier Module	DATA
HJ32-14C527-FBB.vbf	Range Rover Evoque (L538)	AAM - Audio Amplifier Module	DATA
HJ32-14C527-FC.vbf	Range Rover Evoque (L538)	AAM - Audio Amplifier Module	DATA
HJ32-14C527-FDB.vbf	Range Rover Evoque (L538)	AAM - Audio Amplifier Module	DATA
HJ32-14C527-FEB.vbf	Range Rover Evoque (L538)	AAM - Audio Amplifier Module	DATA
HJ32-14C527-GAB.vbf	Range Rover Evoque (L538)	AAM - Audio Amplifier Module	DATA
HJ32-14C527-GB.vbf	Range Rover Evoque (L538)	AAM - Audio Amplifier Module	DATA
HJ32-14C527-GBB.vbf	Range Rover Evoque (L538)	AAM - Audio Amplifier Module	DATA
HJ32-14C527-GDB.vbf	Range Rover Evoque (L538)	AAM - Audio Amplifier Module	DATA
HJ32-14C527-GEB.vbf	Range Rover Evoque (L538)	AAM - Audio Amplifier Module	DATA
HJ32-14C570-BAC.vbf	Range Rover Evoque (L538)	PCM - Powertrain Control Module	EXE
HJ32-14C570-BAD.vbf	Range Rover Evoque (L538)	PCM - Powertrain Control Module	EXE
HJ32-14C570-BAE.vbf	Range Rover Evoque (L538)	PCM - Powertrain Control Module	EXE
HJ32-14C570-BAG.vbf	Range Rover Evoque (L538)	PCM - Powertrain Control Module	EXE
HJ32-14C570-BAH.vbf	Range Rover Evoque (L538)	PCM - Powertrain Control Module	EXE
HJ32-14C570-BAK.vbf	Range Rover Evoque (L538)	PCM - Powertrain Control Module	EXE
HJ32-14C570-BCD.vbf	Range Rover Evoque (L538)	PCM - Powertrain Control Module	EXE
HJ32-14C570-BCE.vbf	Range Rover Evoque (L538)	PCM - Powertrain Control Module	EXE
HJ32-14C570-BCG.vbf	Range Rover Evoque (L538)	PCM - Powertrain Control Module	EXE
HJ32-14C570-BED.vbf	Range Rover Evoque (L538)	PCM - Powertrain Control Module	EXE
HJ32-14C570-BEE.vbf	Range Rover Evoque (L538)	PCM - Powertrain Control Module	EXE
HJ32-14C570-BEG.vbf	Range Rover Evoque (L538)	PCM - Powertrain Control Module	EXE
HJ32-14C570-BTC.vbf	Range Rover Evoque (L538)	PCM - Powertrain Control Module	EXE
HJ32-14C570-BTD.vbf	Range Rover Evoque (L538)	PCM - Powertrain Control Module	EXE
HJ32-14C570-BTE.vbf	Range Rover Evoque (L538)	PCM - Powertrain Control Module	EXE
HJ32-14C570-BTF.vbf	Range Rover Evoque (L538)	PCM - Powertrain Control Module	EXE
HJ32-14C570-BTH.vbf	Range Rover Evoque (L538)	PCM - Powertrain Control Module	EXE
HJ32-14C570-BTL.vbf	Range Rover Evoque (L538)	PCM - Powertrain Control Module	EXE
HJ32-14C572-AC.VBF	Range Rover Evoque (L538)	PCM - Powertrain Control Module	SBL
HJ32-14C653-AG.vbf	Range Rover Evoque (L538)	ACM - Audio Front Control Module	DATA
HJ32-14C653-AH.vbf	Range Rover Evoque (L538)	ACM - Audio Front Control Module	DATA

File name	Vehicle line (indicative)	Module (ECU)	Type
HJ32-14D049-AB.vbf	Check in SDD (unconfirmed)	CCM - Cruise Control Module	EXE
HJ32-14D049-AC.vbf	Check in SDD (unconfirmed)	CCM - Cruise Control Module	EXE
HJ32-14D049-AD.vbf	Check in SDD (unconfirmed)	CCM - Cruise Control Module	EXE
HJ32-14D049-AE.vbf	Check in SDD (unconfirmed)	CCM - Cruise Control Module	EXE
HJ32-14D049-AF.vbf	Check in SDD (unconfirmed)	CCM - Cruise Control Module	EXE
HJ32-14D049-AG.vbf	Check in SDD (unconfirmed)	CCM - Cruise Control Module	EXE
HJ32-14D049-AH.vbf	Check in SDD (unconfirmed)	CCM - Cruise Control Module	EXE
HJ32-14D049-BA.vbf	Check in SDD (unconfirmed)	CCM - Cruise Control Module	EXE
HJ32-14D049-BB.vbf	Check in SDD (unconfirmed)	CCM - Cruise Control Module	EXE
HJ32-14D049-BC.vbf	Check in SDD (unconfirmed)	CCM - Cruise Control Module	EXE
HJ32-14D049-BD.vbf	Check in SDD (unconfirmed)	CCM - Cruise Control Module	EXE
HJ32-14D051-AA.vbf	Range Rover Evoque (L538)	CCM - Cruise Control Module	SBL
HJ32-14D480-CA.vbf	Range Rover Evoque (L538)	IPMB - Image Processing Module B	EXE
HJ32-14D480-CB.vbf	Range Rover Evoque (L538)	IPMB - Image Processing Module B	EXE
HJ32-14D481-BB.vbf	Range Rover Evoque (L538)	IPMB - Image Processing Module B	DATA
HJ32-14D481-BC.vbf	Range Rover Evoque (L538)	IPMB - Image Processing Module B	DATA
HJ32-14D485-BD.vbf	Range Rover Evoque (L538)	IPMB - Image Processing Module B	DATA
HJ32-14D485-BE.vbf	Range Rover Evoque (L538)	IPMB - Image Processing Module B	DATA
HJ32-14F022-GD.vbf	Range Rover Evoque (L538)	IPMB - Image Processing Module B	DATA
HJ32-14F022-GE.vbf	Range Rover Evoque (L538)	IPMB - Image Processing Module B	DATA
HJ32-14F022-GF.vbf	Range Rover Evoque (L538)	IPMB - Image Processing Module B	DATA
HJ32-14F022-GG.vbf	Range Rover Evoque (L538)	IPMB - Image Processing Module B	DATA
HJ32-14F022-HD.vbf	Range Rover Evoque (L538)	IPMB - Image Processing Module B	DATA
HJ32-14F022-HE.vbf	Range Rover Evoque (L538)	IPMB - Image Processing Module B	DATA
HJ32-14F022-HF.vbf	Range Rover Evoque (L538)	IPMB - Image Processing Module B	DATA
HJ32-14F022-HG.vbf	Range Rover Evoque (L538)	IPMB - Image Processing Module B	DATA
HJ32-14F022-JA.vbf	Range Rover Evoque (L538)	IPMB - Image Processing Module B	DATA
HJ32-14F022-JB.vbf	Range Rover Evoque (L538)	IPMB - Image Processing Module B	DATA
HJ32-14F022-JC.vbf	Range Rover Evoque (L538)	IPMB - Image Processing Module B	DATA
HJ32-14F531-AA.vbf	Range Rover Evoque (L538)	GWM - Gateway Module A	DATA
HJ32-14F531-AB.vbf	Range Rover Evoque (L538)	GWM - Gateway Module A	DATA
HJ32-14F531-AC.vbf	Range Rover Evoque (L538)	GWM - Gateway Module A	DATA
HJ32-14F531-AD.vbf	Range Rover Evoque (L538)	GWM - Gateway Module A	DATA
HJ32-14F531-AE.vbf	Range Rover Evoque (L538)	GWM - Gateway Module A	DATA
HJ32-14F531-AF.vbf	Range Rover Evoque (L538)	GWM - Gateway Module A	DATA
HJ32-18D619-AB.vbf	Range Rover Evoque (L538)	HVAC - HVAC Control Module	EXE
HJ32-18D619-AC.vbf	Range Rover Evoque (L538)	HVAC - HVAC Control Module	EXE
HJ32-18D619-AD.vbf	Range Rover Evoque (L538)	HVAC - HVAC Control Module	EXE
HJ32-18D619-BA.vbf	Range Rover Evoque (L538)	HVAC - HVAC Control Module	EXE
HJ32-18D619-BB.vbf	Range Rover Evoque (L538)	HVAC - HVAC Control Module	EXE
HJ32-18D619-BC.vbf	Range Rover Evoque (L538)	HVAC - HVAC Control Module	EXE
HJ32-18D619-BD.vbf	Range Rover Evoque (L538)	HVAC - HVAC Control Module	EXE
HJ32-18D619-BE.vbf	Range Rover Evoque (L538)	HVAC - HVAC Control Module	EXE
HJ32-18D620-AB.vbf	Range Rover Evoque (L538)	HVAC - HVAC Control Module	DATA
HJ32-18D620-AC.vbf	Range Rover Evoque (L538)	HVAC - HVAC Control Module	DATA
HJ32-18D620-AD.vbf	Range Rover Evoque (L538)	HVAC - HVAC Control Module	DATA
HJ32-18D620-AE.vbf	Range Rover Evoque (L538)	HVAC - HVAC Control Module	DATA
HJ32-18D620-AF.vbf	Range Rover Evoque (L538)	HVAC - HVAC Control Module	DATA
HJ32-18D620-AG.vbf	Range Rover Evoque (L538)	HVAC - HVAC Control Module	DATA
HJ32-18D620-AH.vbf	Range Rover Evoque (L538)	HVAC - HVAC Control Module	DATA
HJ32-18D620-AJ.vbf	Range Rover Evoque (L538)	HVAC - HVAC Control Module	DATA
HJ32-18D620-AK.vbf	Range Rover Evoque (L538)	HVAC - HVAC Control Module	DATA
HJ32-18D620-AL.vbf	Range Rover Evoque (L538)	HVAC - HVAC Control Module	DATA
HJ32-18D620-CB.vbf	Range Rover Evoque (L538)	HVAC - HVAC Control Module	DATA
HJ32-18D620-CC.vbf	Range Rover Evoque (L538)	HVAC - HVAC Control Module	DATA
HJ32-18D620-CD.vbf	Range Rover Evoque (L538)	HVAC - HVAC Control Module	DATA
HJ32-18D620-CE.vbf	Range Rover Evoque (L538)	HVAC - HVAC Control Module	DATA
HJ32-18D620-CF.vbf	Range Rover Evoque (L538)	HVAC - HVAC Control Module	DATA
HJ32-18D620-CG.vbf	Range Rover Evoque (L538)	HVAC - HVAC Control Module	DATA
HJ32-18D620-CH.vbf	Range Rover Evoque (L538)	HVAC - HVAC Control Module	DATA
HJ32-18D620-CJ.vbf	Range Rover Evoque (L538)	HVAC - HVAC Control Module	DATA
HJ32-18D620-CK.vbf	Range Rover Evoque (L538)	HVAC - HVAC Control Module	DATA
HJ32-18D620-CL.vbf	Range Rover Evoque (L538)	HVAC - HVAC Control Module	DATA
HJ32-70713-DB.vbf	Range Rover Evoque (L538)	TCU - Telematic Control Unit Module	DATA
HJ32-70713-DC.vbf	Range Rover Evoque (L538)	TCU - Telematic Control Unit Module	DATA
HJ32-70713-DD.vbf	Range Rover Evoque (L538)	TCU - Telematic Control Unit Module	DATA
HJ32-70713-DE.vbf	Range Rover Evoque (L538)	TCU - Telematic Control Unit Module	DATA
HJ32-70713-DF.vbf	Range Rover Evoque (L538)	TCU - Telematic Control Unit Module	DATA
HJ32-70713-DH.vbf	Range Rover Evoque (L538)	TCU - Telematic Control Unit Module	DATA
HJ32-70713-DJ.vbf	Range Rover Evoque (L538)	TCU - Telematic Control Unit Module	DATA
HJ32-70713-DK.vbf	Range Rover Evoque (L538)	TCU - Telematic Control Unit Module	DATA
HJ32-70713-EB.vbf	Range Rover Evoque (L538)	TCU - Telematic Control Unit Module	DATA
HJ32-70713-EC.vbf	Range Rover Evoque (L538)	TCU - Telematic Control Unit Module	DATA
HJ32-70713-ED.vbf	Range Rover Evoque (L538)	TCU - Telematic Control Unit Module	DATA
HJ32-70713-EE.vbf	Range Rover Evoque (L538)	TCU - Telematic Control Unit Module	DATA
HJ32-70713-EF.vbf	Range Rover Evoque (L538)	TCU - Telematic Control Unit Module	DATA

File name	Vehicle line (indicative)	Module (ECU)	Type
HJ32-70713-EG.vbf	Range Rover Evoque (L538)	TCU - Telematic Control Unit Module	DATA
HJ32-70713-EH.vbf	Range Rover Evoque (L538)	TCU - Telematic Control Unit Module	DATA
HJ32-70713-EJ.vbf	Range Rover Evoque (L538)	TCU - Telematic Control Unit Module	DATA
HJ32-70713-JB.vbf	Range Rover Evoque (L538)	TCU - Telematic Control Unit Module	DATA
HJ32-70713-JC.vbf	Range Rover Evoque (L538)	TCU - Telematic Control Unit Module	DATA
HJ32-70713-JD.vbf	Range Rover Evoque (L538)	TCU - Telematic Control Unit Module	DATA
HJ32-70713-JE.vbf	Range Rover Evoque (L538)	TCU - Telematic Control Unit Module	DATA
HJ32-70713-JF.vbf	Range Rover Evoque (L538)	TCU - Telematic Control Unit Module	DATA
HJ32-70713-JG.vbf	Range Rover Evoque (L538)	TCU - Telematic Control Unit Module	DATA
HJ32-70713-JH.vbf	Range Rover Evoque (L538)	TCU - Telematic Control Unit Module	DATA
HJ32-70713-JJ.vbf	Range Rover Evoque (L538)	TCU - Telematic Control Unit Module	DATA
HJ32-70713-KB.vbf	Range Rover Evoque (L538)	TCU - Telematic Control Unit Module	DATA
HJ32-70713-KC.vbf	Range Rover Evoque (L538)	TCU - Telematic Control Unit Module	DATA
HJ32-70713-KD.vbf	Range Rover Evoque (L538)	TCU - Telematic Control Unit Module	DATA
HJ32-70713-KE.vbf	Range Rover Evoque (L538)	TCU - Telematic Control Unit Module	DATA
HJ32-70713-KF.vbf	Range Rover Evoque (L538)	TCU - Telematic Control Unit Module	DATA
HJ32-70713-KH.vbf	Range Rover Evoque (L538)	TCU - Telematic Control Unit Module	DATA
HJ32-70713-KJ.vbf	Range Rover Evoque (L538)	TCU - Telematic Control Unit Module	DATA
HJ32-70713-KK.vbf	Range Rover Evoque (L538)	TCU - Telematic Control Unit Module	DATA
HK52-14C034-AAA.vbf	Range Rover (L405)	DSM - Driver Front Seat Module	EXE
HK52-14C034-ABA.vbf	Range Rover (L405)	DSM - Driver Front Seat Module	EXE
HK52-14C034-BAA.vbf	Range Rover (L405)	DSM - Driver Front Seat Module	EXE
HK52-14C034-BBA.vbf	Range Rover (L405)	DSM - Driver Front Seat Module	EXE
HK52-14C034-BCA.vbf	Range Rover (L405)	DSM - Driver Front Seat Module	EXE
HK52-14C034-BDA.vbf	Range Rover (L405)	DSM - Driver Front Seat Module	EXE
HK52-14C034-BEB.vbf	Range Rover (L405)	DSM - Driver Front Seat Module	EXE
HK52-14C034-CAA.vbf	Range Rover (L405)	DSM - Driver Front Seat Module	EXE
HK52-14C034-CBA.vbf	Range Rover (L405)	DSM - Driver Front Seat Module	EXE
HK52-14C034-CCA.vbf	Range Rover (L405)	DSM - Driver Front Seat Module	EXE
HK52-14C034-CDA.vbf	Range Rover (L405)	DSM - Driver Front Seat Module	EXE
HK52-14C034-CEB.vbf	Range Rover (L405)	DSM - Driver Front Seat Module	EXE
HK52-14C034-DAA.vbf	Range Rover (L405)	DSM - Driver Front Seat Module	EXE
HK52-14C034-DBA.vbf	Range Rover (L405)	DSM - Driver Front Seat Module	EXE
HK52-14C034-DCA.vbf	Range Rover (L405)	DSM - Driver Front Seat Module	EXE
HK52-14C034-DDA.vbf	Range Rover (L405)	DSM - Driver Front Seat Module	EXE
HK52-14C034-DEA.vbf	Range Rover (L405)	DSM - Driver Front Seat Module	EXE
HK52-14C034-EAA.vbf	Range Rover (L405)	DSM - Driver Front Seat Module	EXE
HK52-14C034-EBA.vbf	Range Rover (L405)	DSM - Driver Front Seat Module	EXE
HK52-14C034-ECA.vbf	Range Rover (L405)	DSM - Driver Front Seat Module	EXE
HK52-14C034-EDA.vbf	Range Rover (L405)	DSM - Driver Front Seat Module	EXE
HK52-14C034-EEA.vbf	Range Rover (L405)	DSM - Driver Front Seat Module	EXE
HK52-14C034-FAA.vbf	Range Rover (L405)	DSM - Driver Front Seat Module	EXE
HK52-14C034-FBA.vbf	Range Rover (L405)	DSM - Driver Front Seat Module	EXE
HK52-14C034-FCA.vbf	Range Rover (L405)	DSM - Driver Front Seat Module	EXE
HK52-14C034-FDA.vbf	Range Rover (L405)	DSM - Driver Front Seat Module	EXE
HK52-14C034-FEA.vbf	Range Rover (L405)	DSM - Driver Front Seat Module	EXE
HK52-14C034-FFA.vbf	Range Rover (L405)	DSM - Driver Front Seat Module	EXE
HK52-14C034-FGA.vbf	Range Rover (L405)	DSM - Driver Front Seat Module	EXE
HK52-14C034-FHA.vbf	Range Rover (L405)	DSM - Driver Front Seat Module	EXE
HK52-14C034-FJA.vbf	Range Rover (L405)	DSM - Driver Front Seat Module	EXE
HK52-14C034-FKA.vbf	Range Rover (L405)	DSM - Driver Front Seat Module	EXE
HK52-14C037-ABC.vbf	Range Rover (L405)	ABS - Anti-Lock Brake System Control Module	DATA
HK52-14C037-ABE.vbf	Range Rover (L405)	ABS - Anti-Lock Brake System Control Module	DATA
HK52-14C037-ABF.vbf	Range Rover (L405)	ABS - Anti-Lock Brake System Control Module	DATA
HK52-14C037-ABG.vbf	Range Rover (L405)	ABS - Anti-Lock Brake System Control Module	DATA
HK52-14C037-ABH.vbf	Range Rover (L405)	ABS - Anti-Lock Brake System Control Module	DATA
HK52-14C037-ABJ.vbf	Range Rover (L405)	ABS - Anti-Lock Brake System Control Module	DATA
HK52-14C037-ACC.vbf	Range Rover (L405)	ABS - Anti-Lock Brake System Control Module	DATA
HK52-14C037-ACE.vbf	Range Rover (L405)	ABS - Anti-Lock Brake System Control Module	DATA
HK52-14C037-ACF.vbf	Range Rover (L405)	ABS - Anti-Lock Brake System Control Module	DATA
HK52-14C037-ACG.vbf	Range Rover (L405)	ABS - Anti-Lock Brake System Control Module	DATA
HK52-14C037-ACH.vbf	Range Rover (L405)	ABS - Anti-Lock Brake System Control Module	DATA
HK52-14C037-ACJ.vbf	Range Rover (L405)	ABS - Anti-Lock Brake System Control Module	DATA
HK52-14C037-ADC.vbf	Range Rover (L405)	ABS - Anti-Lock Brake System Control Module	DATA
HK52-14C037-ADE.vbf	Range Rover (L405)	ABS - Anti-Lock Brake System Control Module	DATA
HK52-14C037-ADF.vbf	Range Rover (L405)	ABS - Anti-Lock Brake System Control Module	DATA
HK52-14C037-ADG.vbf	Range Rover (L405)	ABS - Anti-Lock Brake System Control Module	DATA
HK52-14C037-ADH.vbf	Range Rover (L405)	ABS - Anti-Lock Brake System Control Module	DATA
HK52-14C037-ADJ.vbf	Range Rover (L405)	ABS - Anti-Lock Brake System Control Module	DATA
HK52-14C037-AEC.vbf	Range Rover (L405)	ABS - Anti-Lock Brake System Control Module	DATA
HK52-14C037-AEE.vbf	Range Rover (L405)	ABS - Anti-Lock Brake System Control Module	DATA
HK52-14C037-AEF.vbf	Range Rover (L405)	ABS - Anti-Lock Brake System Control Module	DATA
HK52-14C037-AEG.vbf	Range Rover (L405)	ABS - Anti-Lock Brake System Control Module	DATA
HK52-14C037-AEH.vbf	Range Rover (L405)	ABS - Anti-Lock Brake System Control Module	DATA
HK52-14C037-AEJ.vbf	Range Rover (L405)	ABS - Anti-Lock Brake System Control Module	DATA
HK52-14C037-AFC.vbf	Range Rover (L405)	ABS - Anti-Lock Brake System Control Module	DATA

File name	Vehicle line (indicative)	Module (ECU)	Type
HK52-14C037-AFE.vbf	Range Rover (L405)	ABS - Anti-Lock Brake System Control Module	DATA
HK52-14C037-AFF.vbf	Range Rover (L405)	ABS - Anti-Lock Brake System Control Module	DATA
HK52-14C037-AFG.vbf	Range Rover (L405)	ABS - Anti-Lock Brake System Control Module	DATA
HK52-14C037-AFH.vbf	Range Rover (L405)	ABS - Anti-Lock Brake System Control Module	DATA
HK52-14C037-AFJ.vbf	Range Rover (L405)	ABS - Anti-Lock Brake System Control Module	DATA
HK52-14C037-AMC.vbf	Range Rover (L405)	ABS - Anti-Lock Brake System Control Module	DATA
HK52-14C037-AME.vbf	Range Rover (L405)	ABS - Anti-Lock Brake System Control Module	DATA
HK52-14C037-AMF.vbf	Range Rover (L405)	ABS - Anti-Lock Brake System Control Module	DATA
HK52-14C037-AMG.vbf	Range Rover (L405)	ABS - Anti-Lock Brake System Control Module	DATA
HK52-14C037-AMH.vbf	Range Rover (L405)	ABS - Anti-Lock Brake System Control Module	DATA
HK52-14C037-AMJ.vbf	Range Rover (L405)	ABS - Anti-Lock Brake System Control Module	DATA
HK52-14C037-ANC.vbf	Range Rover (L405)	ABS - Anti-Lock Brake System Control Module	DATA
HK52-14C037-ANE.vbf	Range Rover (L405)	ABS - Anti-Lock Brake System Control Module	DATA
HK52-14C037-ANG.vbf	Range Rover (L405)	ABS - Anti-Lock Brake System Control Module	DATA
HK52-14C037-ANH.vbf	Range Rover (L405)	ABS - Anti-Lock Brake System Control Module	DATA
HK52-14C037-ANJ.vbf	Range Rover (L405)	ABS - Anti-Lock Brake System Control Module	DATA
HK52-14C037-APC.vbf	Range Rover (L405)	ABS - Anti-Lock Brake System Control Module	DATA
HK52-14C037-APE.vbf	Range Rover (L405)	ABS - Anti-Lock Brake System Control Module	DATA
HK52-14C037-APG.vbf	Range Rover (L405)	ABS - Anti-Lock Brake System Control Module	DATA
HK52-14C037-APH.vbf	Range Rover (L405)	ABS - Anti-Lock Brake System Control Module	DATA
HK52-14C037-APJ.vbf	Range Rover (L405)	ABS - Anti-Lock Brake System Control Module	DATA
HK52-14C037-ARC.vbf	Range Rover (L405)	ABS - Anti-Lock Brake System Control Module	DATA
HK52-14C037-ARE.vbf	Range Rover (L405)	ABS - Anti-Lock Brake System Control Module	DATA
HK52-14C037-ARG.vbf	Range Rover (L405)	ABS - Anti-Lock Brake System Control Module	DATA
HK52-14C037-ARH.vbf	Range Rover (L405)	ABS - Anti-Lock Brake System Control Module	DATA
HK52-14C037-ARJ.vbf	Range Rover (L405)	ABS - Anti-Lock Brake System Control Module	DATA
HK52-14C037-ATC.vbf	Range Rover (L405)	ABS - Anti-Lock Brake System Control Module	DATA
HK52-14C037-ATE.vbf	Range Rover (L405)	ABS - Anti-Lock Brake System Control Module	DATA
HK52-14C037-ATG.vbf	Range Rover (L405)	ABS - Anti-Lock Brake System Control Module	DATA
HK52-14C037-ATH.vbf	Range Rover (L405)	ABS - Anti-Lock Brake System Control Module	DATA
HK52-14C037-ATJ.vbf	Range Rover (L405)	ABS - Anti-Lock Brake System Control Module	DATA
HK52-14C037-AVC.vbf	Range Rover (L405)	ABS - Anti-Lock Brake System Control Module	DATA
HK52-14C037-AVE.vbf	Range Rover (L405)	ABS - Anti-Lock Brake System Control Module	DATA
HK52-14C037-AVG.vbf	Range Rover (L405)	ABS - Anti-Lock Brake System Control Module	DATA
HK52-14C037-AVH.vbf	Range Rover (L405)	ABS - Anti-Lock Brake System Control Module	DATA
HK52-14C037-AVJ.vbf	Range Rover (L405)	ABS - Anti-Lock Brake System Control Module	DATA
HK52-14C037-BAF.vbf	Range Rover (L405)	ABS - Anti-Lock Brake System Control Module	DATA
HK52-14C037-BAH.vbf	Range Rover (L405)	ABS - Anti-Lock Brake System Control Module	DATA
HK52-14C037-BAJ.vbf	Range Rover (L405)	ABS - Anti-Lock Brake System Control Module	DATA
HK52-14C037-BAK.vbf	Range Rover (L405)	ABS - Anti-Lock Brake System Control Module	DATA
HK52-14C037-BBF.vbf	Range Rover (L405)	ABS - Anti-Lock Brake System Control Module	DATA
HK52-14C037-BBH.vbf	Range Rover (L405)	ABS - Anti-Lock Brake System Control Module	DATA
HK52-14C037-BBJ.vbf	Range Rover (L405)	ABS - Anti-Lock Brake System Control Module	DATA
HK52-14C037-BBK.vbf	Range Rover (L405)	ABS - Anti-Lock Brake System Control Module	DATA
HK52-14C037-DKC.vbf	Range Rover (L405)	ABS - Anti-Lock Brake System Control Module	DATA
HK52-14C037-DKE.vbf	Range Rover (L405)	ABS - Anti-Lock Brake System Control Module	DATA
HK52-14C037-DKG.vbf	Range Rover (L405)	ABS - Anti-Lock Brake System Control Module	DATA
HK52-14C037-DKH.vbf	Range Rover (L405)	ABS - Anti-Lock Brake System Control Module	DATA
HK52-14C037-DKJ.vbf	Range Rover (L405)	ABS - Anti-Lock Brake System Control Module	DATA
HK52-14C037-DLC.vbf	Range Rover (L405)	ABS - Anti-Lock Brake System Control Module	DATA
HK52-14C037-DLE.vbf	Range Rover (L405)	ABS - Anti-Lock Brake System Control Module	DATA
HK52-14C037-DLF.vbf	Range Rover (L405)	ABS - Anti-Lock Brake System Control Module	DATA
HK52-14C037-DLG.vbf	Range Rover (L405)	ABS - Anti-Lock Brake System Control Module	DATA
HK52-14C037-DLH.vbf	Range Rover (L405)	ABS - Anti-Lock Brake System Control Module	DATA
HK52-14C037-DLJ.vbf	Range Rover (L405)	ABS - Anti-Lock Brake System Control Module	DATA
HK52-14C037-DMC.vbf	Range Rover (L405)	ABS - Anti-Lock Brake System Control Module	DATA
HK52-14C037-DME.vbf	Range Rover (L405)	ABS - Anti-Lock Brake System Control Module	DATA
HK52-14C037-DMG.vbf	Range Rover (L405)	ABS - Anti-Lock Brake System Control Module	DATA
HK52-14C037-DMH.vbf	Range Rover (L405)	ABS - Anti-Lock Brake System Control Module	DATA
HK52-14C037-DMJ.vbf	Range Rover (L405)	ABS - Anti-Lock Brake System Control Module	DATA
HK52-14C037-DUE.vbf	Range Rover (L405)	ABS - Anti-Lock Brake System Control Module	DATA
HK52-14C037-DUH.vbf	Range Rover (L405)	ABS - Anti-Lock Brake System Control Module	DATA
HK52-14C037-DUJ.vbf	Range Rover (L405)	ABS - Anti-Lock Brake System Control Module	DATA
HK52-14C037-FAA.vbf	Range Rover (L405)	ABS - Anti-Lock Brake System Control Module	DATA
HK52-14C037-FAC.vbf	Range Rover (L405)	ABS - Anti-Lock Brake System Control Module	DATA
HK52-14C037-FAD.vbf	Range Rover (L405)	ABS - Anti-Lock Brake System Control Module	DATA
HK52-14C037-FAE.vbf	Range Rover (L405)	ABS - Anti-Lock Brake System Control Module	DATA
HK52-14C037-FBA.vbf	Range Rover (L405)	ABS - Anti-Lock Brake System Control Module	DATA
HK52-14C037-FBC.vbf	Range Rover (L405)	ABS - Anti-Lock Brake System Control Module	DATA
HK52-14C037-FBD.vbf	Range Rover (L405)	ABS - Anti-Lock Brake System Control Module	DATA
HK52-14C037-FBE.vbf	Range Rover (L405)	ABS - Anti-Lock Brake System Control Module	DATA
HK52-14C065-AC.vbf	Range Rover (L405)	DDM - Driver Front Door Module	DATA
HK52-14C065-AD.vbf	Range Rover (L405)	DDM - Driver Front Door Module	DATA
HK52-14C065-AE.vbf	Range Rover (L405)	DDM - Driver Front Door Module	DATA
HK52-14C065-AF.vbf	Range Rover (L405)	DDM - Driver Front Door Module	DATA
HK52-14C065-BB.vbf	Range Rover (L405)	DDM - Driver Front Door Module	DATA

File name	Vehicle line (indicative)	Module (ECU)	Type
HK52-14C065-BC.vbf	Range Rover (L405)	DDM - Driver Front Door Module	DATA
HK52-14C065-BD.vbf	Range Rover (L405)	DDM - Driver Front Door Module	DATA
HK52-14C065-BE.vbf	Range Rover (L405)	DDM - Driver Front Door Module	DATA
HK52-14C069-AC.vbf	Range Rover (L405)	DRDM - Driver Rear Door Module	DATA
HK52-14C069-AD.vbf	Range Rover (L405)	DRDM - Driver Rear Door Module	DATA
HK52-14C069-AE.vbf	Range Rover (L405)	DRDM - Driver Rear Door Module	DATA
HK52-14C069-AF.vbf	Range Rover (L405)	DRDM - Driver Rear Door Module	DATA
HK52-14C069-BB.vbf	Range Rover (L405)	DRDM - Driver Rear Door Module	DATA
HK52-14C069-BC.vbf	Range Rover (L405)	DRDM - Driver Rear Door Module	DATA
HK52-14C069-BD.vbf	Range Rover (L405)	DRDM - Driver Rear Door Module	DATA
HK52-14C069-BE.vbf	Range Rover (L405)	DRDM - Driver Rear Door Module	DATA
HK52-14C090-AB.vbf	Range Rover (L405)	PAM - Parking Assist Control Module	EXE
HK52-14C090-AC.vbf	Range Rover (L405)	PAM - Parking Assist Control Module	EXE
HK52-14C090-AD.vbf	Range Rover (L405)	PAM - Parking Assist Control Module	EXE
HK52-14C090-AE.vbf	Range Rover (L405)	PAM - Parking Assist Control Module	EXE
HK52-14C090-AF.vbf	Range Rover (L405)	PAM - Parking Assist Control Module	EXE
HK52-14C091-AB.vbf	Range Rover (L405)	PAM - Parking Assist Control Module	DATA
HK52-14C091-AC.vbf	Range Rover (L405)	PAM - Parking Assist Control Module	DATA
HK52-14C091-AD.vbf	Range Rover (L405)	PAM - Parking Assist Control Module	DATA
HK52-14C091-AE.vbf	Range Rover (L405)	PAM - Parking Assist Control Module	DATA
HK52-14C091-AF.vbf	Range Rover (L405)	PAM - Parking Assist Control Module	DATA
HK52-14C091-AG.vbf	Range Rover (L405)	PAM - Parking Assist Control Module	DATA
HK52-14C098-AB.vbf	Range Rover (L405)	RCM - Restraints Control Module	DATA
HK52-14C098-AC.vbf	Range Rover (L405)	RCM - Restraints Control Module	DATA
HK52-14C098-AD.vbf	Range Rover (L405)	SRS - Airbag	DATA
HK52-14C098-BB.vbf	Range Rover (L405)	RCM - Restraints Control Module	DATA
HK52-14C098-BC.vbf	Range Rover (L405)	RCM - Restraints Control Module	DATA
HK52-14C098-BD.vbf	Range Rover (L405)	SRS - Airbag	DATA
HK52-14C098-CB.vbf	Range Rover (L405)	RCM - Restraints Control Module	DATA
HK52-14C098-CC.vbf	Range Rover (L405)	RCM - Restraints Control Module	DATA
HK52-14C098-CD.vbf	Range Rover (L405)	SRS - Airbag	DATA
HK52-14C098-DC.vbf	Range Rover (L405)	RCM - Restraints Control Module	DATA
HK52-14C098-DD.vbf	Range Rover (L405)	SRS - Airbag	DATA
HK52-14C098-EC.vbf	Range Rover (L405)	RCM - Restraints Control Module	DATA
HK52-14C098-ED.vbf	Range Rover (L405)	SRS - Airbag	DATA
HK52-14C105-AA.vbf	Range Rover (L405)	TMC Traffic Message Channel Module	DATA
HK52-14C105-AC.vbf	Range Rover (L405)	TMC Traffic Message Channel Module	DATA
HK52-14C105-BA.vbf	Range Rover (L405)	TMC Traffic Message Channel Module	DATA
HK52-14C105-BC.vbf	Range Rover (L405)	TMC Traffic Message Channel Module	DATA
HK52-14C109-AC.vbf	Range Rover (L405)	PDM - Passenger Front Door Module	DATA
HK52-14C109-AD.vbf	Range Rover (L405)	PDM - Passenger Front Door Module	DATA
HK52-14C109-AE.vbf	Range Rover (L405)	PDM - Passenger Front Door Module	DATA
HK52-14C109-AF.vbf	Range Rover (L405)	PDM - Passenger Front Door Module	DATA
HK52-14C109-BB.vbf	Range Rover (L405)	PDM - Passenger Front Door Module	DATA
HK52-14C109-BC.vbf	Range Rover (L405)	PDM - Passenger Front Door Module	DATA
HK52-14C109-BD.vbf	Range Rover (L405)	PDM - Passenger Front Door Module	DATA
HK52-14C109-BE.vbf	Range Rover (L405)	PDM - Passenger Front Door Module	DATA
HK52-14C113-AC.vbf	Range Rover (L405)	PRDM - Passenger Rear Door Module	DATA
HK52-14C113-AD.vbf	Range Rover (L405)	PRDM - Passenger Rear Door Module	DATA
HK52-14C113-AE.vbf	Range Rover (L405)	PRDM - Passenger Rear Door Module	DATA
HK52-14C113-AF.vbf	Range Rover (L405)	PRDM - Passenger Rear Door Module	DATA
HK52-14C113-BB.vbf	Range Rover (L405)	PRDM - Passenger Rear Door Module	DATA
HK52-14C113-BC.vbf	Range Rover (L405)	PRDM - Passenger Rear Door Module	DATA
HK52-14C113-BD.vbf	Range Rover (L405)	PRDM - Passenger Rear Door Module	DATA
HK52-14C113-BE.vbf	Range Rover (L405)	PRDM - Passenger Rear Door Module	DATA
HK52-14C121-AB.vbf	Range Rover (L405)	RGTM - Rear Gate / Trunk Module	EXE
HK52-14C121-AC.vbf	Range Rover (L405)	RGTM - Rear Gate / Trunk Module	EXE
HK52-14C121-AD.vbf	Range Rover (L405)	RGTM - Rear Gate / Trunk Module	EXE
HK52-14C121-BA.vbf	Range Rover (L405)	RGTM - Rear Gate / Trunk Module	EXE
HK52-14C122-AB.vbf	Range Rover (L405)	RGTM - Rear Gate / Trunk Module	DATA
HK52-14C122-AC.vbf	Range Rover (L405)	RGTM - Rear Gate / Trunk Module	DATA
HK52-14C122-AD.vbf	Range Rover (L405)	RGTM - Rear Gate / Trunk Module	DATA
HK52-14C124-AA.vbf	Range Rover (L405)	RGTM - Rear Gate / Trunk Module	SBL
HK52-14C152-AA.vbf	Range Rover (L405)	TPM - Tire Pressure Monitor Module	DATA
HK52-14C152-AB.vbf	Range Rover (L405)	TPM - Tire Pressure Monitor Module	DATA
HK52-14C184-AA.vbf	Range Rover (L405)	BCM - Body Control Module	CUSTOM
HK52-14C184-AB.vbf	Range Rover (L405)	BCM - Body Control Module	CUSTOM
HK52-14C184-AC.vbf	Range Rover (L405)	BCM - Body Control Module	CUSTOM
HK52-14C184-AD.vbf	Range Rover (L405)	BCM - Body Control Module	CUSTOM
HK52-14C185-AA.vbf	Range Rover (L405)	BCM - Body Control Module	DATA
HK52-14C185-AB.vbf	Range Rover (L405)	BCM - Body Control Module	DATA
HK52-14C185-AC.vbf	Range Rover (L405)	BCM - Body Control Module	DATA
HK52-14C185-AD.vbf	Range Rover (L405)	BCM - Body Control Module	DATA
HK52-14C218-AA.vbf	Range Rover (L405)	PSCM - Power Steering Control Module	EXE
HK52-14C218-AB.vbf	Range Rover (L405)	PSCM - Power Steering Control Module	EXE
HK52-14C218-BB.vbf	Range Rover (L405)	PSCM - Power Steering Control Module	EXE

File name	Vehicle line (indicative)	Module (ECU)	Type
HK52-14C218-CB.vbf	Range Rover (L405)	PSCM - Power Steering Control Module	EXE
HK52-14C408-AA.vbf	Range Rover (L405)	BCM - Body Control Module	SIGCFG
HK52-14C408-AB.vbf	Range Rover (L405)	BCM - Body Control Module	SIGCFG
HK52-14C527-BAB.vbf	Range Rover (L405)	AAM - Audio Amplifier Module	DATA
HK52-14C527-BAC.vbf	Range Rover (L405)	AAM - Audio Amplifier Module	DATA
HK52-14C527-BAD.vbf	Range Rover (L405)	AAM - Audio Amplifier Module	DATA
HK52-14C527-BAE.vbf	Range Rover (L405)	AAM - Audio Amplifier Module	DATA
HK52-14C527-BB.vbf	Range Rover (L405)	AAM - Audio Amplifier Module	DATA
HK52-14C527-BC.vbf	Range Rover (L405)	AAM - Audio Amplifier Module	DATA
HK52-14C527-BD.vbf	Range Rover (L405)	AAM - Audio Amplifier Module	DATA
HK52-14C527-BE.vbf	Range Rover (L405)	AAM - Audio Amplifier Module	DATA
HK52-14C527-CAB.vbf	Range Rover (L405)	AAM - Audio Amplifier Module	DATA
HK52-14C527-CAC.vbf	Range Rover (L405)	AAM - Audio Amplifier Module	DATA
HK52-14C527-CAD.vbf	Range Rover (L405)	AAM - Audio Amplifier Module	DATA
HK52-14C527-CAE.vbf	Range Rover (L405)	AAM - Audio Amplifier Module	DATA
HK52-14C527-CB.vbf	Range Rover (L405)	AAM - Audio Amplifier Module	DATA
HK52-14C527-CC.vbf	Range Rover (L405)	AAM - Audio Amplifier Module	DATA
HK52-14C527-CD.vbf	Range Rover (L405)	AAM - Audio Amplifier Module	DATA
HK52-14C527-DAB.vbf	Range Rover (L405)	AAM - Audio Amplifier Module	DATA
HK52-14C527-DAC.vbf	Range Rover (L405)	AAM - Audio Amplifier Module	DATA
HK52-14C527-DAD.vbf	Range Rover (L405)	AAM - Audio Amplifier Module	DATA
HK52-14C527-DAE.vbf	Range Rover (L405)	AAM - Audio Amplifier Module	DATA
HK52-14C527-DB.vbf	Range Rover (L405)	AAM - Audio Amplifier Module	DATA
HK52-14C527-DC.vbf	Range Rover (L405)	AAM - Audio Amplifier Module	DATA
HK52-14C527-DD.vbf	Range Rover (L405)	AAM - Audio Amplifier Module	DATA
HK52-14C527-DE.vbf	Range Rover (L405)	AAM - Audio Amplifier Module	DATA
HK52-14C527-FC.vbf	Range Rover (L405)	AAM - Audio Amplifier Module	DATA
HK52-14C527-FD.vbf	Range Rover (L405)	AAM - Audio Amplifier Module	DATA
HK52-14C527-FE.vbf	Range Rover (L405)	AAM - Audio Amplifier Module	DATA
HK52-14C527-GC.vbf	Range Rover (L405)	AAM - Audio Amplifier Module	DATA
HK52-14C527-GD.vbf	Range Rover (L405)	AAM - Audio Amplifier Module	DATA
HK52-14C527-HC.vbf	Range Rover (L405)	AAM - Audio Amplifier Module	DATA
HK52-14C527-HD.vbf	Range Rover (L405)	AAM - Audio Amplifier Module	DATA
HK52-14C549-AAA.vbf	Range Rover (L405)	PSM - Passenger Front Seat Module	EXE
HK52-14C549-ABA.vbf	Range Rover (L405)	PSM - Passenger Front Seat Module	EXE
HK52-14C549-BAA.vbf	Range Rover (L405)	PSM - Passenger Front Seat Module	EXE
HK52-14C549-BBA.vbf	Range Rover (L405)	PSM - Passenger Front Seat Module	EXE
HK52-14C549-BCA.vbf	Range Rover (L405)	PSM - Passenger Front Seat Module	EXE
HK52-14C549-BDA.vbf	Range Rover (L405)	PSM - Passenger Front Seat Module	EXE
HK52-14C549-BEA.vbf	Range Rover (L405)	PSM - Passenger Front Seat Module	EXE
HK52-14C549-CAA.vbf	Range Rover (L405)	PSM - Passenger Front Seat Module	EXE
HK52-14C549-CBA.vbf	Range Rover (L405)	PSM - Passenger Front Seat Module	EXE
HK52-14C549-CCA.vbf	Range Rover (L405)	PSM - Passenger Front Seat Module	EXE
HK52-14C549-CDA.vbf	Range Rover (L405)	PSM - Passenger Front Seat Module	EXE
HK52-14C549-CEA.vbf	Range Rover (L405)	PSM - Passenger Front Seat Module	EXE
HK52-14C549-DAA.vbf	Range Rover (L405)	PSM - Passenger Front Seat Module	EXE
HK52-14C549-DBA.vbf	Range Rover (L405)	PSM - Passenger Front Seat Module	EXE
HK52-14C549-DCA.vbf	Range Rover (L405)	PSM - Passenger Front Seat Module	EXE
HK52-14C549-DDA.vbf	Range Rover (L405)	PSM - Passenger Front Seat Module	EXE
HK52-14C549-DEA.vbf	Range Rover (L405)	PSM - Passenger Front Seat Module	EXE
HK52-14C549-EAA.vbf	Range Rover (L405)	PSM - Passenger Front Seat Module	EXE
HK52-14C549-EBA.vbf	Range Rover (L405)	PSM - Passenger Front Seat Module	EXE
HK52-14C549-ECA.vbf	Range Rover (L405)	PSM - Passenger Front Seat Module	EXE
HK52-14C549-EDA.vbf	Range Rover (L405)	PSM - Passenger Front Seat Module	EXE
HK52-14C549-EEA.vbf	Range Rover (L405)	PSM - Passenger Front Seat Module	EXE
HK52-14C549-FAA.vbf	Range Rover (L405)	PSM - Passenger Front Seat Module	EXE
HK52-14C549-FBA.vbf	Range Rover (L405)	PSM - Passenger Front Seat Module	EXE
HK52-14C549-FCA.vbf	Range Rover (L405)	PSM - Passenger Front Seat Module	EXE
HK52-14C549-FDA.vbf	Range Rover (L405)	PSM - Passenger Front Seat Module	EXE
HK52-14C549-FEA.vbf	Range Rover (L405)	PSM - Passenger Front Seat Module	EXE
HK52-14C549-FFA.vbf	Range Rover (L405)	PSM - Passenger Front Seat Module	EXE
HK52-14C549-FGA.vbf	Range Rover (L405)	PSM - Passenger Front Seat Module	EXE
HK52-14C549-FHA.vbf	Range Rover (L405)	PSM - Passenger Front Seat Module	EXE
HK52-14C549-FJA.vbf	Range Rover (L405)	PSM - Passenger Front Seat Module	EXE
HK52-14C549-FKA.vbf	Range Rover (L405)	PSM - Passenger Front Seat Module	EXE
HK52-14C609-AA.vbf	Range Rover (L405)	PSCM - Power Steering Control Module	EXE
HK52-14C609-AB.vbf	Range Rover (L405)	PSCM - Power Steering Control Module	EXE
HK52-14C609-AC.vbf	Range Rover (L405)	PSCM - Power Steering Control Module	EXE
HK52-14C609-AD.vbf	Range Rover (L405)	PSCM - Power Steering Control Module	EXE
HK52-14C609-AE.vbf	Range Rover (L405)	PSCM - Power Steering Control Module	EXE
HK52-14D181-AA.vbf	Range Rover (L405)	OCS - Restraints Occupant Classification System Module	SIGCFG
HK52-14D183-AB.vbf	Range Rover (L405)	OCS - Restraints Occupant Classification System Module	DATA
HK52-14D485-AC.vbf	Range Rover (L405)	IPMB - Image Processing Module B	EXE
HK52-14D485-AD.vbf	Range Rover (L405)	IPMB - Image Processing Module B	EXE
HK52-14D485-AE.vbf	Range Rover (L405)	IPMB - Image Processing Module B	EXE
HK52-14D485-AF.vbf	Range Rover (L405)	IPMB - Image Processing Module B	EXE

File name	Vehicle line (indicative)	Module (ECU)	Type
HK52-14D485-AG.vbf	Range Rover (L405)	IPMB - Image Processing Module B	EXE
HK52-14D485-AH.vbf	Range Rover (L405)	IPMB - Image Processing Module B	EXE
HK52-14D485-AJ.vbf	Range Rover (L405)	IPMB - Image Processing Module B	EXE
HK52-14D485-EC.vbf	Range Rover (L405)	IPMB - Image Processing Module B	EXE
HK52-14D485-ED.vbf	Range Rover (L405)	IPMB - Image Processing Module B	EXE
HK52-14D485-EE.vbf	Range Rover (L405)	IPMB - Image Processing Module B	EXE
HK52-14D485-EF.vbf	Range Rover (L405)	IPMB - Image Processing Module B	EXE
HK52-14D485-EG.vbf	Range Rover (L405)	IPMB - Image Processing Module B	EXE
HK52-14D485-EH.vbf	Range Rover (L405)	IPMB - Image Processing Module B	EXE
HK52-14D485-EJ.vbf	Range Rover (L405)	IPMB - Image Processing Module B	EXE
HK52-14D564-AB.vbf	Range Rover (L405)	SODL - Side Obstacle Detection Control Module - Left	DATA
HK52-14D564-AC.vbf	Range Rover (L405)	SODL - Side Obstacle Detection Control Module - Left	DATA
HK52-14D564-AE.vbf	Range Rover (L405)	SODL - Side Obstacle Detection Control Module - Left	DATA
HK52-14D564-AF.vbf	Range Rover (L405)	SODL - Side Obstacle Detection Control Module - Left	DATA
HK52-14D564-BB.vbf	Range Rover (L405)	SODR - Side Obstacle Detection Control Module - Right	DATA
HK52-14D564-BC.vbf	Range Rover (L405)	SODR - Side Obstacle Detection Control Module - Right	DATA
HK52-14D564-BE.vbf	Range Rover (L405)	SODR - Side Obstacle Detection Control Module - Right	DATA
HK52-14D564-BF.vbf	Range Rover (L405)	SODR - Side Obstacle Detection Control Module - Right	DATA
HK52-14E094-JAA.vbf	Range Rover (L405)	CHCM - Chassis Control Module	EXE
HK52-14E094-JAB.vbf	Range Rover (L405)	CHCM - Chassis Control Module	EXE
HK52-14E094-JAC.vbf	Range Rover (L405)	CHCM - Chassis Control Module	EXE
HK52-14E094-JAD.vbf	Range Rover (L405)	CHCM - Chassis Control Module	EXE
HK52-14E094-JAE.vbf	Range Rover (L405)	CHCM - Chassis Control Module	EXE
HK52-14E094-JAF.vbf	Range Rover (L405)	CHCM - Chassis Control Module	EXE
HK52-14E094-JAG.vbf	Range Rover (L405)	CHCM - Chassis Control Module	EXE
HK52-14E094-JBA.vbf	Range Rover (L405)	CHCM - Chassis Control Module	EXE
HK52-14E094-JBB.vbf	Range Rover (L405)	CHCM - Chassis Control Module	EXE
HK52-14E094-JBC.vbf	Range Rover (L405)	CHCM - Chassis Control Module	EXE
HK52-14E094-JBD.vbf	Range Rover (L405)	CHCM - Chassis Control Module	EXE
HK52-14E094-JBE.vbf	Range Rover (L405)	CHCM - Chassis Control Module	EXE
HK52-14E094-JBF.vbf	Range Rover (L405)	CHCM - Chassis Control Module	EXE
HK52-14E094-JBG.vbf	Range Rover (L405)	CHCM - Chassis Control Module	EXE
HK52-14E094-JBH.vbf	Range Rover (L405)	CHCM - Chassis Control Module	EXE
HK52-14E094-JCA.vbf	Range Rover (L405)	CHCM - Chassis Control Module	EXE
HK52-14E094-JCB.vbf	Range Rover (L405)	CHCM - Chassis Control Module	EXE
HK52-14E094-JCC.vbf	Range Rover (L405)	CHCM - Chassis Control Module	EXE
HK52-14E094-JCD.vbf	Range Rover (L405)	CHCM - Chassis Control Module	EXE
HK52-14E094-JCE.vbf	Range Rover (L405)	CHCM - Chassis Control Module	EXE
HK52-14E094-JCF.vbf	Range Rover (L405)	CHCM - Chassis Control Module	EXE
HK52-14E094-JCG.vbf	Range Rover (L405)	CHCM - Chassis Control Module	EXE
HK52-14E094-JEA.vbf	Range Rover (L405)	CHCM - Chassis Control Module	EXE
HK52-14E094-JEB.vbf	Range Rover (L405)	CHCM - Chassis Control Module	EXE
HK52-14E094-JEC.vbf	Range Rover (L405)	CHCM - Chassis Control Module	EXE
HK52-14E094-JED.vbf	Range Rover (L405)	CHCM - Chassis Control Module	EXE
HK52-14E094-JEE.vbf	Range Rover (L405)	CHCM - Chassis Control Module	EXE
HK52-14E094-JEF.vbf	Range Rover (L405)	CHCM - Chassis Control Module	EXE
HK52-14E094-JEG.vbf	Range Rover (L405)	CHCM - Chassis Control Module	EXE
HK52-14E094-JFA.vbf	Range Rover (L405)	CHCM - Chassis Control Module	EXE
HK52-14E094-JFB.vbf	Range Rover (L405)	CHCM - Chassis Control Module	EXE
HK52-14E094-JFC.vbf	Range Rover (L405)	CHCM - Chassis Control Module	EXE
HK52-14E094-JFD.vbf	Range Rover (L405)	CHCM - Chassis Control Module	EXE
HK52-14E094-JFE.vbf	Range Rover (L405)	CHCM - Chassis Control Module	EXE
HK52-14E094-JFF.vbf	Range Rover (L405)	CHCM - Chassis Control Module	EXE
HK52-14E094-JFG.vbf	Range Rover (L405)	CHCM - Chassis Control Module	EXE
HK52-14E094-JGA.vbf	Range Rover (L405)	CHCM - Chassis Control Module	EXE
HK52-14E094-JGB.vbf	Range Rover (L405)	CHCM - Chassis Control Module	EXE
HK52-14E094-JGC.vbf	Range Rover (L405)	CHCM - Chassis Control Module	EXE
HK52-14E094-JGD.vbf	Range Rover (L405)	CHCM - Chassis Control Module	EXE
HK52-14E094-JGE.vbf	Range Rover (L405)	CHCM - Chassis Control Module	EXE
HK52-14E094-JGF.vbf	Range Rover (L405)	CHCM - Chassis Control Module	EXE
HK52-14E094-JGG.vbf	Range Rover (L405)	CHCM - Chassis Control Module	EXE
HK52-14E094-JHA.vbf	Range Rover (L405)	CHCM - Chassis Control Module	EXE
HK52-14E094-JHB.vbf	Range Rover (L405)	CHCM - Chassis Control Module	EXE
HK52-14E094-JHC.vbf	Range Rover (L405)	CHCM - Chassis Control Module	EXE
HK52-14E094-JHD.vbf	Range Rover (L405)	CHCM - Chassis Control Module	EXE
HK52-14E094-JHE.vbf	Range Rover (L405)	CHCM - Chassis Control Module	EXE
HK52-14E094-JHF.vbf	Range Rover (L405)	CHCM - Chassis Control Module	EXE
HK52-14E094-JHG.vbf	Range Rover (L405)	CHCM - Chassis Control Module	EXE
HK52-14E094-JJA.vbf	Range Rover (L405)	CHCM - Chassis Control Module	EXE
HK52-14E094-JJB.vbf	Range Rover (L405)	CHCM - Chassis Control Module	EXE
HK52-14E094-JJC.vbf	Range Rover (L405)	CHCM - Chassis Control Module	EXE
HK52-14E094-JJD.vbf	Range Rover (L405)	CHCM - Chassis Control Module	EXE
HK52-14E094-JJE.vbf	Range Rover (L405)	CHCM - Chassis Control Module	EXE
HK52-14E094-JJF.vbf	Range Rover (L405)	CHCM - Chassis Control Module	EXE
HK52-14E094-JJG.vbf	Range Rover (L405)	CHCM - Chassis Control Module	EXE
HK52-14E094-JKA.vbf	Range Rover (L405)	CHCM - Chassis Control Module	EXE

File name	Vehicle line (indicative)	Module (ECU)	Type
HK52-14E094-JKB.vbf	Range Rover (L405)	CHCM - Chassis Control Module	EXE
HK52-14E094-JKC.vbf	Range Rover (L405)	CHCM - Chassis Control Module	EXE
HK52-14E094-JKD.vbf	Range Rover (L405)	CHCM - Chassis Control Module	EXE
HK52-14E094-JKE.vbf	Range Rover (L405)	CHCM - Chassis Control Module	EXE
HK52-14E094-JKF.vbf	Range Rover (L405)	CHCM - Chassis Control Module	EXE
HK52-14E094-JKG.vbf	Range Rover (L405)	CHCM - Chassis Control Module	EXE
HK52-14E094-JLA.vbf	Range Rover (L405)	CHCM - Chassis Control Module	EXE
HK52-14E094-JLB.vbf	Range Rover (L405)	CHCM - Chassis Control Module	EXE
HK52-14E094-JLC.vbf	Range Rover (L405)	CHCM - Chassis Control Module	EXE
HK52-14E094-JLD.vbf	Range Rover (L405)	CHCM - Chassis Control Module	EXE
HK52-14E094-JLE.vbf	Range Rover (L405)	CHCM - Chassis Control Module	EXE
HK52-14E094-JLF.vbf	Range Rover (L405)	CHCM - Chassis Control Module	EXE
HK52-14E094-JLG.vbf	Range Rover (L405)	CHCM - Chassis Control Module	EXE
HK52-14E094-JRA.vbf	Range Rover (L405)	CHCM - Chassis Control Module	EXE
HK52-14E094-JRB.vbf	Range Rover (L405)	CHCM - Chassis Control Module	EXE
HK52-14E094-JRC.vbf	Range Rover (L405)	CHCM - Chassis Control Module	EXE
HK52-14E094-JRD.vbf	Range Rover (L405)	CHCM - Chassis Control Module	EXE
HK52-14E094-JRE.vbf	Range Rover (L405)	CHCM - Chassis Control Module	EXE
HK52-14E094-JRF.vbf	Range Rover (L405)	CHCM - Chassis Control Module	EXE
HK52-14E094-JRG.vbf	Range Rover (L405)	CHCM - Chassis Control Module	EXE
HK52-14E094-JSA.vbf	Range Rover (L405)	CHCM - Chassis Control Module	EXE
HK52-14E094-JSB.vbf	Range Rover (L405)	CHCM - Chassis Control Module	EXE
HK52-14E094-JSC.vbf	Range Rover (L405)	CHCM - Chassis Control Module	EXE
HK52-14E094-JSD.vbf	Range Rover (L405)	CHCM - Chassis Control Module	EXE
HK52-14E094-JSE.vbf	Range Rover (L405)	CHCM - Chassis Control Module	EXE
HK52-14E094-JSF.vbf	Range Rover (L405)	CHCM - Chassis Control Module	EXE
HK52-14E094-JSG.vbf	Range Rover (L405)	CHCM - Chassis Control Module	EXE
HK52-14F022-AB.vbf	Range Rover (L405)	IPMB - Image Processing Module B	DATA
HK52-14F022-AC.vbf	Range Rover (L405)	IPMB - Image Processing Module B	DATA
HK52-14F022-AD.vbf	Range Rover (L405)	IPMB - Image Processing Module B	DATA
HK52-14F022-AE.vbf	Range Rover (L405)	IPMB - Image Processing Module B	DATA
HK52-14F022-AF.vbf	Range Rover (L405)	IPMB - Image Processing Module B	DATA
HK52-14F022-AG.vbf	Range Rover (L405)	IPMB - Image Processing Module B	DATA
HK52-14F022-AH.vbf	Range Rover (L405)	IPMB - Image Processing Module B	DATA
HK52-14F022-AJ.vbf	Range Rover (L405)	IPMB - Image Processing Module B	DATA
HK52-14F022-CC.vbf	Range Rover (L405)	IPMB - Image Processing Module B	DATA
HK52-14F022-CD.vbf	Range Rover (L405)	IPMB - Image Processing Module B	DATA
HK52-14F022-CE.vbf	Range Rover (L405)	IPMB - Image Processing Module B	DATA
HK52-14F022-CF.vbf	Range Rover (L405)	IPMB - Image Processing Module B	DATA
HK52-14F022-CG.vbf	Range Rover (L405)	IPMB - Image Processing Module B	DATA
HK52-14F022-CH.vbf	Range Rover (L405)	IPMB - Image Processing Module B	DATA
HK52-14F022-CJ.vbf	Range Rover (L405)	IPMB - Image Processing Module B	DATA
HK52-14F230-AA.vbf	Range Rover (L405)	HUD - Head Up Display	EXE
HK52-14F435-NAB.vbf	Range Rover (L405)	CHCMB - Chassis Control Module B	EXE
HK52-14F435-NAC.vbf	Range Rover (L405)	CHCMB - Chassis Control Module B	EXE
HK52-14F435-NAD.vbf	Range Rover (L405)	CHCMB - Chassis Control Module B	EXE
HK52-14F435-NAE.vbf	Range Rover (L405)	CHCMB - Chassis Control Module B	EXE
HK52-14F435-NAF.vbf	Range Rover (L405)	CHCMB - Chassis Control Module B	EXE
HK52-14F435-NBB.vbf	Range Rover (L405)	CHCMB - Chassis Control Module B	EXE
HK52-14F435-NBC.vbf	Range Rover (L405)	CHCMB - Chassis Control Module B	EXE
HK52-14F435-NBD.vbf	Range Rover (L405)	CHCMB - Chassis Control Module B	EXE
HK52-14F435-NBE.vbf	Range Rover (L405)	CHCMB - Chassis Control Module B	EXE
HK52-14F435-NBF.vbf	Range Rover (L405)	CHCMB - Chassis Control Module B	EXE
HK52-14F435-NBG.vbf	Range Rover (L405)	CHCMB - Chassis Control Module B	EXE
HK52-14F435-NCB.vbf	Range Rover (L405)	CHCMB - Chassis Control Module B	EXE
HK52-14F435-NCC.vbf	Range Rover (L405)	CHCMB - Chassis Control Module B	EXE
HK52-14F435-NCD.vbf	Range Rover (L405)	CHCMB - Chassis Control Module B	EXE
HK52-14F435-NCE.vbf	Range Rover (L405)	CHCMB - Chassis Control Module B	EXE
HK52-14F435-NCF.vbf	Range Rover (L405)	CHCMB - Chassis Control Module B	EXE
HK52-14F435-NDB.vbf	Range Rover (L405)	CHCMB - Chassis Control Module B	EXE
HK52-14F435-NDC.vbf	Range Rover (L405)	CHCMB - Chassis Control Module B	EXE
HK52-14F435-NDD.vbf	Range Rover (L405)	CHCMB - Chassis Control Module B	EXE
HK52-14F435-NDE.vbf	Range Rover (L405)	CHCMB - Chassis Control Module B	EXE
HK52-14F435-NDF.vbf	Range Rover (L405)	CHCMB - Chassis Control Module B	EXE
HK52-14F529-BC.vbf	Range Rover (L405)	GWM - Gateway Module A	EXE
HK52-14F529-BD.vbf	Range Rover (L405)	GWM - Gateway Module A	EXE
HK52-14F529-BE.vbf	Range Rover (L405)	GWM - Gateway Module A	EXE
HK52-14F530-BD.vbf	Range Rover (L405)	GWM - Gateway Module A	EXE
HK52-14F530-BE.vbf	Range Rover (L405)	GWM - Gateway Module A	EXE
HK52-14F530-BG.vbf	Range Rover (L405)	GWM - Gateway Module A	EXE
HK52-14F531-BC.vbf	Range Rover (L405)	GWM - Gateway Module A	DATA
HK52-14F531-BD.vbf	Range Rover (L405)	GWM - Gateway Module A	DATA
HK52-14F531-BE.vbf	Range Rover (L405)	GWM - Gateway Module A	DATA
HK52-14F671-AB.vbf	Range Rover (L405)	RGTMB - Rear Gate / Trunk Module	EXE
HK52-14F671-AC.vbf	Range Rover (L405)	RGTMB - Rear Gate / Trunk Module	EXE
HK52-14F671-AD.vbf	Range Rover (L405)	RGTMB - Rear Gate / Trunk Module	EXE

File name	Vehicle line (indicative)	Module (ECU)	Type
HK52-14F671-BA.vbf	Range Rover (L405)	RGTMB - Rear Gate / Trunk Module	EXE
HK52-14F672-AB.vbf	Range Rover (L405)	RGTMB - Rear Gate / Trunk Module	DATA
HK52-14F672-AC.vbf	Range Rover (L405)	RGTMB - Rear Gate / Trunk Module	DATA
HK52-14F672-AD.vbf	Range Rover (L405)	RGTMB - Rear Gate / Trunk Module	DATA
HK52-14F673-AA.vbf	Range Rover (L405)	RGTMB - Rear Gate / Trunk Module	SBL
HK52-19H527-AA.vbf	Range Rover (L405)	ACCM - Air Conditioning Control Module	EXE
HK52-19H527-AB.vbf	Range Rover (L405)	ACCM - Air Conditioning Control Module	EXE
HK52-7J104-FBB.vbf	Range Rover (L405)	TCM - Transmission Control Module	EXE
HK52-7J104-FBC.vbf	Range Rover (L405)	TCM - Transmission Control Module	EXE
HK52-7J104-FBD.vbf	Range Rover (L405)	TCM - Transmission Control Module	EXE
HK52-7J104-FBE.vbf	Range Rover (L405)	TCM - Transmission Control Module	EXE
HK52-7J104-FBF.vbf	Range Rover (L405)	TCM - Transmission Control Module	EXE
HK52-7J104-FBG.vbf	Range Rover (L405)	TCM - Transmission Control Module	EXE
HK52-7J104-FBH.vbf	Range Rover (L405)	TCM - Transmission Control Module	EXE
HK52-7J104-FBJ.vbf	Range Rover (L405)	TCM - Transmission Control Module	EXE
HK52-7J104-FCB.vbf	Range Rover (L405)	TCM - Transmission Control Module	EXE
HK52-7J104-FCC.vbf	Range Rover (L405)	TCM - Transmission Control Module	EXE
HK52-7J104-FCD.vbf	Range Rover (L405)	TCM - Transmission Control Module	EXE
HK52-7J104-FCE.vbf	Range Rover (L405)	TCM - Transmission Control Module	EXE
HK52-7J104-FCF.vbf	Range Rover (L405)	TCM - Transmission Control Module	EXE
HK52-7J104-FCG.vbf	Range Rover (L405)	TCM - Transmission Control Module	EXE
HK52-7J104-FCH.vbf	Range Rover (L405)	TCM - Transmission Control Module	EXE
HK52-7J104-FDB.vbf	Range Rover (L405)	TCM - Transmission Control Module	EXE
HK52-7J104-FDC.vbf	Range Rover (L405)	TCM - Transmission Control Module	EXE
HK52-7J104-FDD.vbf	Range Rover (L405)	TCM - Transmission Control Module	EXE
HK52-7J104-FDE.vbf	Range Rover (L405)	TCM - Transmission Control Module	EXE
HK52-7J104-FDF.vbf	Range Rover (L405)	TCM - Transmission Control Module	EXE
HK52-7J104-FDG.vbf	Range Rover (L405)	TCM - Transmission Control Module	EXE
HK52-7J104-FDH.vbf	Range Rover (L405)	TCM - Transmission Control Module	EXE
HK52-7J104-FDJ.vbf	Range Rover (L405)	TCM - Transmission Control Module	EXE
HK52-7J104-FHB.vbf	Range Rover (L405)	TCM - Transmission Control Module	EXE
HK52-7J104-FHC.vbf	Range Rover (L405)	TCM - Transmission Control Module	EXE
HK52-7J104-FHD.vbf	Range Rover (L405)	TCM - Transmission Control Module	EXE
HK52-7J104-FHE.vbf	Range Rover (L405)	TCM - Transmission Control Module	EXE
HK52-7J104-FHF.vbf	Range Rover (L405)	TCM - Transmission Control Module	EXE
HK52-7J104-FHG.vbf	Range Rover (L405)	TCM - Transmission Control Module	EXE
HK52-7J104-FHH.vbf	Range Rover (L405)	TCM - Transmission Control Module	EXE
HK52-7J104-FKA.vbf	Range Rover (L405)	TCM - Transmission Control Module	EXE
HK52-7J104-FKB.vbf	Range Rover (L405)	TCM - Transmission Control Module	EXE
HK52-7J104-FKC.vbf	Range Rover (L405)	TCM - Transmission Control Module	EXE
HK52-7J104-FKD.vbf	Range Rover (L405)	TCM - Transmission Control Module	EXE
HK52-7J104-FKE.vbf	Range Rover (L405)	TCM - Transmission Control Module	EXE
HK52-7J104-FKF.vbf	Range Rover (L405)	TCM - Transmission Control Module	EXE
HK52-7J104-FKG.vbf	Range Rover (L405)	TCM - Transmission Control Module	EXE
HK52-7J104-FKH.vbf	Range Rover (L405)	TCM - Transmission Control Module	EXE
HK52-7J104-FYB.vbf	Range Rover (L405)	TCM - Transmission Control Module	EXE
HK52-7J104-FYC.vbf	Range Rover (L405)	TCM - Transmission Control Module	EXE
HK52-7J104-FYD.vbf	Range Rover (L405)	TCM - Transmission Control Module	EXE
HK52-7J104-FYE.vbf	Range Rover (L405)	TCM - Transmission Control Module	EXE
HK52-7J104-FYF.vbf	Range Rover (L405)	TCM - Transmission Control Module	EXE
HK52-7J104-FYG.vbf	Range Rover (L405)	TCM - Transmission Control Module	EXE
HK52-7J104-FYH.vbf	Range Rover (L405)	TCM - Transmission Control Module	EXE
HK52-9J404-AA.vbf	Range Rover (L405)	GPSM - Global Positioning System Module	EXE
HK52-9J404-AB.vbf	Range Rover (L405)	GPSM - Global Positioning System Module	EXE
HK52-9J404-AC.vbf	Range Rover (L405)	GPSM - Global Positioning System Module	EXE
HK52-9J405-AA.vbf	Range Rover (L405)	GPSM - Global Positioning System Module	DATA
HK52-9J405-AB.vbf	Range Rover (L405)	GPSM - Global Positioning System Module	DATA
HK52-9J406-AA.vbf	Range Rover (L405)	GPSM - Global Positioning System Module	SBL
HK5M-14C218-AB.vbf	Not specified	PSCM - Power Steering Control Module	EXE
HK5M-14E094-JPA.vbf	Not specified	CHCM - Chassis Control Module	EXE
HK5M-14E094-JPB.vbf	Not specified	CHCM - Chassis Control Module	EXE
HK5M-14E094-JPC.vbf	Not specified	CHCM - Chassis Control Module	EXE
HK5M-14E094-JPD.vbf	Not specified	CHCM - Chassis Control Module	EXE
HK5M-14E094-JPE.vbf	Not specified	CHCM - Chassis Control Module	EXE
HK5M-14E094-JPF.vbf	Not specified	CHCM - Chassis Control Module	EXE
HK5M-14E094-JPG.vbf	Not specified	CHCM - Chassis Control Module	EXE
HK5M-14E094-JRA.vbf	Not specified	CHCM - Chassis Control Module	EXE
HK5M-14E094-JRB.vbf	Not specified	CHCM - Chassis Control Module	EXE
HK5M-14E094-JRC.vbf	Not specified	CHCM - Chassis Control Module	EXE
HK5M-14E094-JRD.vbf	Not specified	CHCM - Chassis Control Module	EXE
HK5M-14E094-JRE.vbf	Not specified	CHCM - Chassis Control Module	EXE
HK5M-14E094-JRF.vbf	Not specified	CHCM - Chassis Control Module	EXE
HK5M-14E094-JRG.vbf	Not specified	CHCM - Chassis Control Module	EXE
HK5M-14E094-JTA.vbf	Not specified	CHCM - Chassis Control Module	EXE
HK5M-14E094-JTB.vbf	Not specified	CHCM - Chassis Control Module	EXE
HK5M-14E094-JTC.vbf	Not specified	CHCM - Chassis Control Module	EXE

File name	Vehicle line (indicative)	Module (ECU)	Type
HK5M-14F435-NEB.vbf	Not specified	CHCMB - Chassis Control Module B	EXE
HK5M-14F435-NEC.vbf	Not specified	CHCMB - Chassis Control Module B	EXE
HK5M-14F435-NED.vbf	Not specified	CHCMB - Chassis Control Module B	EXE
HK5M-14F435-NEE.vbf	Not specified	CHCMB - Chassis Control Module B	EXE
HK5M-14F435-NEF.vbf	Not specified	CHCMB - Chassis Control Module B	EXE
HK5M-606K42-AA.vbf	Not specified	YRM - Yaw Rate Sensor Module	EXE
HK5M-606K43-AA.vbf	Not specified	YRM - Yaw Rate Sensor Module	EXE
HK5M-606K43-AB.vbf	Not specified	YRM - Yaw Rate Sensor Module	EXE
HK5M-606K44-AA.vbf	Not specified	YRM - Yaw Rate Sensor Module	EXE
HK5M-606K44-BA.vbf	Not specified	YRM - Yaw Rate Sensor Module	EXE
HK5M-606K44-CA.vbf	Not specified	YRM - Yaw Rate Sensor Module	EXE
HK5M-606K45-AA.vbf	Not specified	CRM - Calf Rest Module	SBL
HK5M-606K45-AB.vbf	Not specified	CRM - Calf Rest Module	SBL
HK62-12K532-FBA.vbf	Range Rover Sport (L494)	PCM - Powertrain Control Module	DATA
HK62-12K532-FBC.vbf	Range Rover Sport (L494)	PCM - Powertrain Control Module	DATA
HK62-12K532-FBD.vbf	Range Rover Sport (L494)	PCM - Powertrain Control Module	DATA
HK62-12K532-FBE.vbf	Range Rover Sport (L494)	PCM - Powertrain Control Module	DATA
HK62-12K532-FBF.vbf	Range Rover Sport (L494)	PCM - Powertrain Control Module	DATA
HK62-12K532-FBG.vbf	Range Rover Sport (L494)	PCM - Powertrain Control Module	DATA
HK62-12K532-FBH.vbf	Range Rover Sport (L494)	PCM - Powertrain Control Module	DATA
HK62-12K532-FBJ.vbf	Range Rover Sport (L494)	PCM - Powertrain Control Module	DATA
HK62-12K532-NLC.vbf	Range Rover Sport (L494)	PCM - Powertrain Control Module	DATA
HK62-12K532-NLD.vbf	Range Rover Sport (L494)	PCM - Powertrain Control Module	DATA
HK62-12K532-NLE.vbf	Range Rover Sport (L494)	PCM - Powertrain Control Module	DATA
HK62-12K532-NMC.vbf	Range Rover Sport (L494)	PCM - Powertrain Control Module	DATA
HK62-12K532-NMD.vbf	Range Rover Sport (L494)	PCM - Powertrain Control Module	DATA
HK62-12K532-NME.vbf	Range Rover Sport (L494)	PCM - Powertrain Control Module	DATA
HK62-12K532-NMF.vbf	Range Rover Sport (L494)	PCM - Powertrain Control Module	DATA
HK62-12K532-NNA.vbf	Range Rover Sport (L494)	PCM - Powertrain Control Module	DATA
HK62-12K532-NNB.vbf	Range Rover Sport (L494)	PCM - Powertrain Control Module	DATA
HK62-12K532-NNC.vbf	Range Rover Sport (L494)	PCM - Powertrain Control Module	DATA
HK62-12K532-NND.vbf	Range Rover Sport (L494)	PCM - Powertrain Control Module	DATA
HK62-12K532-NNE.vbf	Range Rover Sport (L494)	PCM - Powertrain Control Module	DATA
HK62-12K532-NNF.vbf	Range Rover Sport (L494)	PCM - Powertrain Control Module	DATA
HK62-12K532-NNG.vbf	Range Rover Sport (L494)	PCM - Powertrain Control Module	DATA
HK62-12K532-NNH.vbf	Range Rover Sport (L494)	PCM - Powertrain Control Module	DATA
HK62-12K532-NNJ.vbf	Range Rover Sport (L494)	PCM - Powertrain Control Module	DATA
HK62-12K532-NNK.vbf	Range Rover Sport (L494)	PCM - Powertrain Control Module	DATA
HK62-12K532-NNL.vbf	Range Rover Sport (L494)	PCM - Powertrain Control Module	EXE
HK62-12K532-NRC.vbf	Range Rover Sport (L494)	PCM - Powertrain Control Module	DATA
HK62-12K532-NRD.vbf	Range Rover Sport (L494)	PCM - Powertrain Control Module	DATA
HK62-12K532-NRE.vbf	Range Rover Sport (L494)	PCM - Powertrain Control Module	DATA
HK62-12K532-NRG.vbf	Range Rover Sport (L494)	PCM - Powertrain Control Module	DATA
HK62-12K532-PCD.vbf	Range Rover Sport (L494)	PCM - Powertrain Control Module	DATA
HK62-12K532-PCE.vbf	Range Rover Sport (L494)	PCM - Powertrain Control Module	DATA
HK62-12K532-PDD.vbf	Range Rover Sport (L494)	PCM - Powertrain Control Module	DATA
HK62-12K532-PDE.vbf	Range Rover Sport (L494)	PCM - Powertrain Control Module	DATA
HK62-12K532-PDF.vbf	Range Rover Sport (L494)	PCM - Powertrain Control Module	DATA
HK62-12K532-PEB.vbf	Range Rover Sport (L494)	PCM - Powertrain Control Module	DATA
HK62-12K532-PED.vbf	Range Rover Sport (L494)	PCM - Powertrain Control Module	DATA
HK62-12K532-PEE.vbf	Range Rover Sport (L494)	PCM - Powertrain Control Module	DATA
HK62-12K532-PEF.vbf	Range Rover Sport (L494)	PCM - Powertrain Control Module	DATA
HK62-12K532-PFD.vbf	Range Rover Sport (L494)	PCM - Powertrain Control Module	DATA
HK62-12K532-PFE.vbf	Range Rover Sport (L494)	PCM - Powertrain Control Module	DATA
HK62-12K532-PFF.vbf	Range Rover Sport (L494)	PCM - Powertrain Control Module	DATA
HK62-12K532-PGD.vbf	Range Rover Sport (L494)	PCM - Powertrain Control Module	DATA
HK62-12K532-PGE.vbf	Range Rover Sport (L494)	PCM - Powertrain Control Module	DATA
HK62-12K532-PGF.vbf	Range Rover Sport (L494)	PCM - Powertrain Control Module	DATA
HK62-12K532-PGG.vbf	Range Rover Sport (L494)	PCM - Powertrain Control Module	DATA
HK62-12K532-PGH.vbf	Range Rover Sport (L494)	PCM - Powertrain Control Module	DATA
HK62-12K532-PGJ.vbf	Range Rover Sport (L494)	PCM - Powertrain Control Module	EXE
HK62-12K532-PHD.vbf	Range Rover Sport (L494)	PCM - Powertrain Control Module	DATA
HK62-12K532-PHE.vbf	Range Rover Sport (L494)	PCM - Powertrain Control Module	DATA
HK62-12K532-PHF.vbf	Range Rover Sport (L494)	PCM - Powertrain Control Module	DATA
HK62-12K532-PHG.vbf	Range Rover Sport (L494)	PCM - Powertrain Control Module	DATA
HK62-12K532-PHH.vbf	Range Rover Sport (L494)	PCM - Powertrain Control Module	DATA
HK62-12K532-PHJ.vbf	Range Rover Sport (L494)	PCM - Powertrain Control Module	EXE
HK62-12K532-PJA.vbf	Range Rover Sport (L494)	PCM - Powertrain Control Module	DATA
HK62-12K532-PJB.vbf	Range Rover Sport (L494)	PCM - Powertrain Control Module	DATA
HK62-12K532-PJD.vbf	Range Rover Sport (L494)	PCM - Powertrain Control Module	DATA
HK62-12K532-PJE.vbf	Range Rover Sport (L494)	PCM - Powertrain Control Module	DATA
HK62-12K532-PJF.vbf	Range Rover Sport (L494)	PCM - Powertrain Control Module	DATA
HK62-12K532-PJG.vbf	Range Rover Sport (L494)	PCM - Powertrain Control Module	DATA
HK62-12K532-PJH.vbf	Range Rover Sport (L494)	PCM - Powertrain Control Module	DATA
HK62-12K532-PJJ.vbf	Range Rover Sport (L494)	PCM - Powertrain Control Module	EXE
HK62-12K532-PKA.vbf	Range Rover Sport (L494)	PCM - Powertrain Control Module	DATA

File name	Vehicle line (indicative)	Module (ECU)	Type
HK62-12K532-PKB.vbf	Range Rover Sport (L494)	PCM - Powertrain Control Module	DATA
HK62-12K532-PKD.vbf	Range Rover Sport (L494)	PCM - Powertrain Control Module	DATA
HK62-12K532-PKE.vbf	Range Rover Sport (L494)	PCM - Powertrain Control Module	DATA
HK62-12K532-PKF.vbf	Range Rover Sport (L494)	PCM - Powertrain Control Module	DATA
HK62-12K532-PKG.vbf	Range Rover Sport (L494)	PCM - Powertrain Control Module	DATA
HK62-12K532-PKH.vbf	Range Rover Sport (L494)	PCM - Powertrain Control Module	DATA
HK62-12K532-PKJ.vbf	Range Rover Sport (L494)	PCM - Powertrain Control Module	DATA
HK62-12K532-PKK.vbf	Range Rover Sport (L494)	PCM - Powertrain Control Module	DATA
HK62-12K532-PKL.vbf	Range Rover Sport (L494)	PCM - Powertrain Control Module	DATA
HK62-12K532-PMC.vbf	Range Rover Sport (L494)	PCM - Powertrain Control Module	DATA
HK62-12K532-PMD.vbf	Range Rover Sport (L494)	PCM - Powertrain Control Module	DATA
HK62-12K532-PNA.vbf	Range Rover Sport (L494)	PCM - Powertrain Control Module	DATA
HK62-12K532-PNB.vbf	Range Rover Sport (L494)	PCM - Powertrain Control Module	DATA
HK62-12K532-PNC.vbf	Range Rover Sport (L494)	PCM - Powertrain Control Module	DATA
HK62-12K532-PND.vbf	Range Rover Sport (L494)	PCM - Powertrain Control Module	DATA
HK62-12K532-PNE.vbf	Range Rover Sport (L494)	PCM - Powertrain Control Module	DATA
HK62-12K532-PNF.vbf	Range Rover Sport (L494)	PCM - Powertrain Control Module	DATA
HK62-12K532-PNG.vbf	Range Rover Sport (L494)	PCM - Powertrain Control Module	DATA
HK62-12K532-PNH.vbf	Range Rover Sport (L494)	PCM - Powertrain Control Module	EXE
HK62-12K532-PRC.vbf	Range Rover Sport (L494)	PCM - Powertrain Control Module	DATA
HK62-12K532-PRD.vbf	Range Rover Sport (L494)	PCM - Powertrain Control Module	DATA
HK62-12K532-PSB.vbf	Range Rover Sport (L494)	PCM - Powertrain Control Module	DATA
HK62-12K532-PSD.vbf	Range Rover Sport (L494)	PCM - Powertrain Control Module	DATA
HK62-12K532-PSE.vbf	Range Rover Sport (L494)	PCM - Powertrain Control Module	DATA
HK62-12K532-PSF.vbf	Range Rover Sport (L494)	PCM - Powertrain Control Module	DATA
HK62-12K532-PSG.vbf	Range Rover Sport (L494)	PCM - Powertrain Control Module	DATA
HK62-14C034-AAA.vbf	Range Rover Sport (L494)	DSM - Driver Front Seat Module	EXE
HK62-14C034-ABA.vbf	Range Rover Sport (L494)	DSM - Driver Front Seat Module	EXE
HK62-14C034-ACA.vbf	Range Rover Sport (L494)	DSM - Driver Front Seat Module	EXE
HK62-14C034-ADA.vbf	Range Rover Sport (L494)	DSM - Driver Front Seat Module	EXE
HK62-14C034-ADB.vbf	Range Rover Sport (L494)	PSM - Passenger Front Seat Module	EXE
HK62-14C034-AEA.vbf	Range Rover Sport (L494)	DSM - Driver Front Seat Module	EXE
HK62-14C034-BAA.vbf	Range Rover Sport (L494)	DSM - Driver Front Seat Module	EXE
HK62-14C034-BAB.vbf	Range Rover Sport (L494)	PSM - Passenger Front Seat Module	EXE
HK62-14C034-BBA.vbf	Range Rover Sport (L494)	DSM - Driver Front Seat Module	EXE
HK62-14C034-BBB.vbf	Range Rover Sport (L494)	PSM - Passenger Front Seat Module	EXE
HK62-14C034-BCA.vbf	Range Rover Sport (L494)	DSM - Driver Front Seat Module	EXE
HK62-14C034-BCB.vbf	Range Rover Sport (L494)	PSM - Passenger Front Seat Module	EXE
HK62-14C034-BDA.vbf	Range Rover Sport (L494)	DSM - Driver Front Seat Module	EXE
HK62-14C034-BDB.vbf	Range Rover Sport (L494)	PSM - Passenger Front Seat Module	EXE
HK62-14C034-BEA.vbf	Range Rover Sport (L494)	DSM - Driver Front Seat Module	EXE
HK62-14C034-BEB.vbf	Range Rover Sport (L494)	PSM - Passenger Front Seat Module	EXE
HK62-14C037-AAC.vbf	Range Rover Sport (L494)	ABS - Anti-Lock Brake System Control Module	DATA
HK62-14C037-AAE.vbf	Range Rover Sport (L494)	ABS - Anti-Lock Brake System Control Module	DATA
HK62-14C037-AAG.vbf	Range Rover Sport (L494)	ABS - Anti-Lock Brake System Control Module	DATA
HK62-14C037-AAH.vbf	Range Rover Sport (L494)	ABS - Anti-Lock Brake System Control Module	DATA
HK62-14C037-AAJ.vbf	Range Rover Sport (L494)	ABS - Anti-Lock Brake System Control Module	DATA
HK62-14C037-ABC.vbf	Range Rover Sport (L494)	ABS - Anti-Lock Brake System Control Module	DATA
HK62-14C037-ABG.vbf	Range Rover Sport (L494)	ABS - Anti-Lock Brake System Control Module	DATA
HK62-14C037-ABH.vbf	Range Rover Sport (L494)	ABS - Anti-Lock Brake System Control Module	DATA
HK62-14C037-ABJ.vbf	Range Rover Sport (L494)	ABS - Anti-Lock Brake System Control Module	DATA
HK62-14C037-ACC.vbf	Range Rover Sport (L494)	ABS - Anti-Lock Brake System Control Module	DATA
HK62-14C037-ACE.vbf	Range Rover Sport (L494)	ABS - Anti-Lock Brake System Control Module	DATA
HK62-14C037-ACG.vbf	Range Rover Sport (L494)	ABS - Anti-Lock Brake System Control Module	DATA
HK62-14C037-ACH.vbf	Range Rover Sport (L494)	ABS - Anti-Lock Brake System Control Module	DATA
HK62-14C037-ACJ.vbf	Range Rover Sport (L494)	ABS - Anti-Lock Brake System Control Module	DATA
HK62-14C037-ADC.vbf	Range Rover Sport (L494)	ABS - Anti-Lock Brake System Control Module	DATA
HK62-14C037-ADE.vbf	Range Rover Sport (L494)	ABS - Anti-Lock Brake System Control Module	DATA
HK62-14C037-ADG.vbf	Range Rover Sport (L494)	ABS - Anti-Lock Brake System Control Module	DATA
HK62-14C037-ADH.vbf	Range Rover Sport (L494)	ABS - Anti-Lock Brake System Control Module	DATA
HK62-14C037-ADJ.vbf	Range Rover Sport (L494)	ABS - Anti-Lock Brake System Control Module	DATA
HK62-14C037-AEC.vbf	Range Rover Sport (L494)	ABS - Anti-Lock Brake System Control Module	DATA
HK62-14C037-AEE.vbf	Range Rover Sport (L494)	ABS - Anti-Lock Brake System Control Module	DATA
HK62-14C037-AEG.vbf	Range Rover Sport (L494)	ABS - Anti-Lock Brake System Control Module	DATA
HK62-14C037-AEH.vbf	Range Rover Sport (L494)	ABS - Anti-Lock Brake System Control Module	DATA
HK62-14C037-AEJ.vbf	Range Rover Sport (L494)	ABS - Anti-Lock Brake System Control Module	DATA
HK62-14C037-AFC.vbf	Range Rover Sport (L494)	ABS - Anti-Lock Brake System Control Module	DATA
HK62-14C037-AFE.vbf	Range Rover Sport (L494)	ABS - Anti-Lock Brake System Control Module	DATA
HK62-14C037-AFG.vbf	Range Rover Sport (L494)	ABS - Anti-Lock Brake System Control Module	DATA
HK62-14C037-AFH.vbf	Range Rover Sport (L494)	ABS - Anti-Lock Brake System Control Module	DATA
HK62-14C037-AFJ.vbf	Range Rover Sport (L494)	ABS - Anti-Lock Brake System Control Module	DATA
HK62-14C037-AGC.vbf	Range Rover Sport (L494)	ABS - Anti-Lock Brake System Control Module	DATA
HK62-14C037-AGE.vbf	Range Rover Sport (L494)	ABS - Anti-Lock Brake System Control Module	DATA
HK62-14C037-AGG.vbf	Range Rover Sport (L494)	ABS - Anti-Lock Brake System Control Module	DATA
HK62-14C037-AGH.vbf	Range Rover Sport (L494)	ABS - Anti-Lock Brake System Control Module	DATA
HK62-14C037-AGJ.vbf	Range Rover Sport (L494)	ABS - Anti-Lock Brake System Control Module	DATA

File name	Vehicle line (indicative)	Module (ECU)	Type
HK62-14C037-AHC.vbf	Range Rover Sport (L494)	ABS - Anti-Lock Brake System Control Module	DATA
HK62-14C037-AHE.vbf	Range Rover Sport (L494)	ABS - Anti-Lock Brake System Control Module	DATA
HK62-14C037-AHG.vbf	Range Rover Sport (L494)	ABS - Anti-Lock Brake System Control Module	DATA
HK62-14C037-AHH.vbf	Range Rover Sport (L494)	ABS - Anti-Lock Brake System Control Module	DATA
HK62-14C037-AHJ.vbf	Range Rover Sport (L494)	ABS - Anti-Lock Brake System Control Module	DATA
HK62-14C037-AKC.vbf	Range Rover Sport (L494)	ABS - Anti-Lock Brake System Control Module	DATA
HK62-14C037-AKE.vbf	Range Rover Sport (L494)	ABS - Anti-Lock Brake System Control Module	DATA
HK62-14C037-AKG.vbf	Range Rover Sport (L494)	ABS - Anti-Lock Brake System Control Module	DATA
HK62-14C037-AKH.vbf	Range Rover Sport (L494)	ABS - Anti-Lock Brake System Control Module	DATA
HK62-14C037-AKJ.vbf	Range Rover Sport (L494)	ABS - Anti-Lock Brake System Control Module	DATA
HK62-14C037-AVC.vbf	Range Rover Sport (L494)	ABS - Anti-Lock Brake System Control Module	DATA
HK62-14C037-AVE.vbf	Range Rover Sport (L494)	ABS - Anti-Lock Brake System Control Module	DATA
HK62-14C037-AVG.vbf	Range Rover Sport (L494)	ABS - Anti-Lock Brake System Control Module	DATA
HK62-14C037-AVH.vbf	Range Rover Sport (L494)	ABS - Anti-Lock Brake System Control Module	DATA
HK62-14C037-AVJ.vbf	Range Rover Sport (L494)	ABS - Anti-Lock Brake System Control Module	DATA
HK62-14C037-BAF.vbf	Range Rover Sport (L494)	ABS - Anti-Lock Brake System Control Module	DATA
HK62-14C037-BAH.vbf	Range Rover Sport (L494)	ABS - Anti-Lock Brake System Control Module	DATA
HK62-14C037-BAJ.vbf	Range Rover Sport (L494)	ABS - Anti-Lock Brake System Control Module	DATA
HK62-14C037-BAK.vbf	Range Rover Sport (L494)	ABS - Anti-Lock Brake System Control Module	DATA
HK62-14C037-DJC.vbf	Range Rover Sport (L494)	ABS - Anti-Lock Brake System Control Module	DATA
HK62-14C037-DJE.vbf	Range Rover Sport (L494)	ABS - Anti-Lock Brake System Control Module	DATA
HK62-14C037-DJG.vbf	Range Rover Sport (L494)	ABS - Anti-Lock Brake System Control Module	DATA
HK62-14C037-DJH.vbf	Range Rover Sport (L494)	ABS - Anti-Lock Brake System Control Module	DATA
HK62-14C037-DJJ.vbf	Range Rover Sport (L494)	ABS - Anti-Lock Brake System Control Module	DATA
HK62-14C037-DKC.vbf	Range Rover Sport (L494)	ABS - Anti-Lock Brake System Control Module	DATA
HK62-14C037-DKE.vbf	Range Rover Sport (L494)	ABS - Anti-Lock Brake System Control Module	DATA
HK62-14C037-DKG.vbf	Range Rover Sport (L494)	ABS - Anti-Lock Brake System Control Module	DATA
HK62-14C037-DKH.vbf	Range Rover Sport (L494)	ABS - Anti-Lock Brake System Control Module	DATA
HK62-14C037-DKJ.vbf	Range Rover Sport (L494)	ABS - Anti-Lock Brake System Control Module	DATA
HK62-14C037-DLC.vbf	Range Rover Sport (L494)	ABS - Anti-Lock Brake System Control Module	DATA
HK62-14C037-DLE.vbf	Range Rover Sport (L494)	ABS - Anti-Lock Brake System Control Module	DATA
HK62-14C037-DLG.vbf	Range Rover Sport (L494)	ABS - Anti-Lock Brake System Control Module	DATA
HK62-14C037-DLH.vbf	Range Rover Sport (L494)	ABS - Anti-Lock Brake System Control Module	DATA
HK62-14C037-DLJ.vbf	Range Rover Sport (L494)	ABS - Anti-Lock Brake System Control Module	DATA
HK62-14C037-DMC.vbf	Range Rover Sport (L494)	ABS - Anti-Lock Brake System Control Module	DATA
HK62-14C037-DME.vbf	Range Rover Sport (L494)	ABS - Anti-Lock Brake System Control Module	DATA
HK62-14C037-DMG.vbf	Range Rover Sport (L494)	ABS - Anti-Lock Brake System Control Module	DATA
HK62-14C037-DMH.vbf	Range Rover Sport (L494)	ABS - Anti-Lock Brake System Control Module	DATA
HK62-14C037-DMJ.vbf	Range Rover Sport (L494)	ABS - Anti-Lock Brake System Control Module	DATA
HK62-14C037-DNC.vbf	Range Rover Sport (L494)	ABS - Anti-Lock Brake System Control Module	DATA
HK62-14C037-DNE.vbf	Range Rover Sport (L494)	ABS - Anti-Lock Brake System Control Module	DATA
HK62-14C037-DNG.vbf	Range Rover Sport (L494)	ABS - Anti-Lock Brake System Control Module	DATA
HK62-14C037-DNH.vbf	Range Rover Sport (L494)	ABS - Anti-Lock Brake System Control Module	DATA
HK62-14C037-DNJ.vbf	Range Rover Sport (L494)	ABS - Anti-Lock Brake System Control Module	DATA
HK62-14C037-FAA.vbf	Range Rover Sport (L494)	ABS - Anti-Lock Brake System Control Module	DATA
HK62-14C037-FAC.vbf	Range Rover Sport (L494)	ABS - Anti-Lock Brake System Control Module	DATA
HK62-14C037-FAD.vbf	Range Rover Sport (L494)	ABS - Anti-Lock Brake System Control Module	DATA
HK62-14C037-FAE.vbf	Range Rover Sport (L494)	ABS - Anti-Lock Brake System Control Module	DATA
HK62-14C037-FBA.vbf	Range Rover Sport (L494)	ABS - Anti-Lock Brake System Control Module	DATA
HK62-14C037-FBC.vbf	Range Rover Sport (L494)	ABS - Anti-Lock Brake System Control Module	DATA
HK62-14C037-FBD.vbf	Range Rover Sport (L494)	ABS - Anti-Lock Brake System Control Module	DATA
HK62-14C037-FBE.vbf	Range Rover Sport (L494)	ABS - Anti-Lock Brake System Control Module	DATA
HK62-14C065-AB.vbf	Range Rover Sport (L494)	DDM - Driver Front Door Module	DATA
HK62-14C065-AC.vbf	Range Rover Sport (L494)	DDM - Driver Front Door Module	DATA
HK62-14C065-AD.vbf	Range Rover Sport (L494)	DDM - Driver Front Door Module	DATA
HK62-14C065-AE.vbf	Range Rover Sport (L494)	DDM - Driver Front Door Module	DATA
HK62-14C069-AB.vbf	Range Rover Sport (L494)	DRDM - Driver Rear Door Module	DATA
HK62-14C069-AC.vbf	Range Rover Sport (L494)	DRDM - Driver Rear Door Module	DATA
HK62-14C069-AD.vbf	Range Rover Sport (L494)	DRDM - Driver Rear Door Module	DATA
HK62-14C069-AE.vbf	Range Rover Sport (L494)	DRDM - Driver Rear Door Module	DATA
HK62-14C091-AB.vbf	Range Rover Sport (L494)	PAM - Parking Assist Control Module	DATA
HK62-14C091-AC.vbf	Range Rover Sport (L494)	PAM - Parking Assist Control Module	DATA
HK62-14C091-AD.vbf	Range Rover Sport (L494)	PAM - Parking Assist Control Module	DATA
HK62-14C091-AE.vbf	Range Rover Sport (L494)	PAM - Parking Assist Control Module	DATA
HK62-14C091-AF.vbf	Range Rover Sport (L494)	PAM - Parking Assist Control Module	DATA
HK62-14C098-AB.vbf	Range Rover Sport (L494)	RCM - Restraints Control Module	DATA
HK62-14C098-AC.vbf	Range Rover Sport (L494)	RCM - Restraints Control Module	DATA
HK62-14C098-AD.vbf	Range Rover Sport (L494)	SRS - Airbag	DATA
HK62-14C098-BB.vbf	Range Rover Sport (L494)	RCM - Restraints Control Module	DATA
HK62-14C098-BC.vbf	Range Rover Sport (L494)	RCM - Restraints Control Module	DATA
HK62-14C098-BD.vbf	Range Rover Sport (L494)	SRS - Airbag	DATA
HK62-14C098-CB.vbf	Range Rover Sport (L494)	RCM - Restraints Control Module	DATA
HK62-14C098-CC.vbf	Range Rover Sport (L494)	RCM - Restraints Control Module	DATA
HK62-14C098-CD.vbf	Range Rover Sport (L494)	SRS - Airbag	DATA
HK62-14C105-AA.vbf	Range Rover Sport (L494)	TMC Traffic Message Channel Module	DATA
HK62-14C105-AC.vbf	Range Rover Sport (L494)	TMC Traffic Message Channel Module	DATA

File name	Vehicle line (indicative)	Module (ECU)	Type
HK62-14C105-BA.vbf	Range Rover Sport (L494)	TMC Traffic Message Channel Module	DATA
HK62-14C105-BC.vbf	Range Rover Sport (L494)	TMC Traffic Message Channel Module	DATA
HK62-14C109-AB.vbf	Range Rover Sport (L494)	PDM - Passenger Front Door Module	DATA
HK62-14C109-AC.vbf	Range Rover Sport (L494)	PDM - Passenger Front Door Module	DATA
HK62-14C109-AD.vbf	Range Rover Sport (L494)	PDM - Passenger Front Door Module	DATA
HK62-14C109-AE.vbf	Range Rover Sport (L494)	PDM - Passenger Front Door Module	DATA
HK62-14C113-AB.vbf	Range Rover Sport (L494)	PRDM - Passenger Rear Door Module	DATA
HK62-14C113-AC.vbf	Range Rover Sport (L494)	PRDM - Passenger Rear Door Module	DATA
HK62-14C113-AD.vbf	Range Rover Sport (L494)	PRDM - Passenger Rear Door Module	DATA
HK62-14C113-AE.vbf	Range Rover Sport (L494)	PRDM - Passenger Rear Door Module	DATA
HK62-14C121-AB.vbf	Range Rover Sport (L494)	RGTM - Rear Gate / Trunk Module	EXE
HK62-14C121-AC.vbf	Range Rover Sport (L494)	RGTM - Rear Gate / Trunk Module	EXE
HK62-14C121-BA.vbf	Range Rover Sport (L494)	RGTM - Rear Gate / Trunk Module	EXE
HK62-14C122-AB.vbf	Range Rover Sport (L494)	RGTM - Rear Gate / Trunk Module	DATA
HK62-14C124-AA.vbf	Range Rover Sport (L494)	RGTM - Rear Gate / Trunk Module	SBL
HK62-14C152-AA.vbf	Range Rover Sport (L494)	TPM - Tire Pressure Monitor Module	DATA
HK62-14C152-AB.vbf	Range Rover Sport (L494)	TPM - Tire Pressure Monitor Module	DATA
HK62-14C152-AC.vbf	Range Rover Sport (L494)	TPM - Tire Pressure Monitor Module	DATA
HK62-14C185-AA.vbf	Range Rover Sport (L494)	BCM - Body Control Module	DATA
HK62-14C185-AB.vbf	Range Rover Sport (L494)	BCM - Body Control Module	DATA
HK62-14C185-AC.vbf	Range Rover Sport (L494)	BCM - Body Control Module	DATA
HK62-14C185-AD.vbf	Range Rover Sport (L494)	BCM - Body Control Module	DATA
HK62-14C218-AA.vbf	Range Rover Sport (L494)	PSCM - Power Steering Control Module	EXE
HK62-14C218-AB.vbf	Range Rover Sport (L494)	PSCM - Power Steering Control Module	EXE
HK62-14C218-BB.vbf	Range Rover Sport (L494)	PSCM - Power Steering Control Module	EXE
HK62-14C273-FA.vbf	Range Rover Sport (L494)	PCM - Powertrain Control Module	SBL
HK62-14C526-AB.vbf	Range Rover Sport (L494)	AAM - Audio Amplifier Module	EXE
HK62-14C526-AC.vbf	Range Rover Sport (L494)	AAM - Audio Amplifier Module	EXE
HK62-14C526-AD.vbf	Range Rover Sport (L494)	AAM - Audio Amplifier Module	EXE
HK62-14C526-DB.vbf	Range Rover Sport (L494)	AAM - Audio Amplifier Module	EXE
HK62-14C526-DC.vbf	Range Rover Sport (L494)	AAM - Audio Amplifier Module	EXE
HK62-14C526-DD.vbf	Range Rover Sport (L494)	AAM - Audio Amplifier Module	EXE
HK62-14C527-AAB.vbf	Range Rover Sport (L494)	AAM - Audio Amplifier Module	DATA
HK62-14C527-AAC.vbf	Range Rover Sport (L494)	AAM - Audio Amplifier Module	DATA
HK62-14C527-AAD.vbf	Range Rover Sport (L494)	AAM - Audio Amplifier Module	DATA
HK62-14C527-AAE.vbf	Range Rover Sport (L494)	AAM - Audio Amplifier Module	DATA
HK62-14C527-AB.vbf	Range Rover Sport (L494)	AAM - Audio Amplifier Module	DATA
HK62-14C527-AC.vbf	Range Rover Sport (L494)	AAM - Audio Amplifier Module	DATA
HK62-14C527-ACB.vbf	Range Rover Sport (L494)	AAM - Audio Amplifier Module	DATA
HK62-14C527-ACC.vbf	Range Rover Sport (L494)	AAM - Audio Amplifier Module	DATA
HK62-14C527-ACD.vbf	Range Rover Sport (L494)	AAM - Audio Amplifier Module	DATA
HK62-14C527-ACE.vbf	Range Rover Sport (L494)	AAM - Audio Amplifier Module	DATA
HK62-14C527-AD.vbf	Range Rover Sport (L494)	AAM - Audio Amplifier Module	DATA
HK62-14C527-ADB.vbf	Range Rover Sport (L494)	AAM - Audio Amplifier Module	DATA
HK62-14C527-ADC.vbf	Range Rover Sport (L494)	AAM - Audio Amplifier Module	DATA
HK62-14C527-ADD.vbf	Range Rover Sport (L494)	AAM - Audio Amplifier Module	DATA
HK62-14C527-ADE.vbf	Range Rover Sport (L494)	AAM - Audio Amplifier Module	DATA
HK62-14C527-AEB.vbf	Range Rover Sport (L494)	AAM - Audio Amplifier Module	DATA
HK62-14C527-AEC.vbf	Range Rover Sport (L494)	AAM - Audio Amplifier Module	DATA
HK62-14C527-AED.vbf	Range Rover Sport (L494)	AAM - Audio Amplifier Module	DATA
HK62-14C527-AEE.vbf	Range Rover Sport (L494)	AAM - Audio Amplifier Module	DATA
HK62-14C527-AFB.vbf	Range Rover Sport (L494)	AAM - Audio Amplifier Module	DATA
HK62-14C527-AFC.vbf	Range Rover Sport (L494)	AAM - Audio Amplifier Module	DATA
HK62-14C527-AFD.vbf	Range Rover Sport (L494)	AAM - Audio Amplifier Module	DATA
HK62-14C527-AFE.vbf	Range Rover Sport (L494)	AAM - Audio Amplifier Module	DATA
HK62-14C527-AGB.vbf	Range Rover Sport (L494)	AAM - Audio Amplifier Module	DATA
HK62-14C527-AGC.vbf	Range Rover Sport (L494)	AAM - Audio Amplifier Module	DATA
HK62-14C527-AGD.vbf	Range Rover Sport (L494)	AAM - Audio Amplifier Module	DATA
HK62-14C527-AGE.vbf	Range Rover Sport (L494)	AAM - Audio Amplifier Module	DATA
HK62-14C527-AHB.vbf	Range Rover Sport (L494)	AAM - Audio Amplifier Module	DATA
HK62-14C527-AHC.vbf	Range Rover Sport (L494)	AAM - Audio Amplifier Module	DATA
HK62-14C527-AHD.vbf	Range Rover Sport (L494)	AAM - Audio Amplifier Module	DATA
HK62-14C527-AHE.vbf	Range Rover Sport (L494)	AAM - Audio Amplifier Module	DATA
HK62-14C527-CAB.vbf	Range Rover Sport (L494)	AAM - Audio Amplifier Module	DATA
HK62-14C527-CAC.vbf	Range Rover Sport (L494)	AAM - Audio Amplifier Module	DATA
HK62-14C527-CAD.vbf	Range Rover Sport (L494)	AAM - Audio Amplifier Module	DATA
HK62-14C527-CAE.vbf	Range Rover Sport (L494)	AAM - Audio Amplifier Module	DATA
HK62-14C527-CB.vbf	Range Rover Sport (L494)	AAM - Audio Amplifier Module	DATA
HK62-14C527-CC.vbf	Range Rover Sport (L494)	AAM - Audio Amplifier Module	DATA
HK62-14C527-CCB.vbf	Range Rover Sport (L494)	AAM - Audio Amplifier Module	DATA
HK62-14C527-CCC.vbf	Range Rover Sport (L494)	AAM - Audio Amplifier Module	DATA
HK62-14C527-CCD.vbf	Range Rover Sport (L494)	AAM - Audio Amplifier Module	DATA
HK62-14C527-CCE.vbf	Range Rover Sport (L494)	AAM - Audio Amplifier Module	DATA
HK62-14C527-CD.vbf	Range Rover Sport (L494)	AAM - Audio Amplifier Module	DATA
HK62-14C527-CDB.vbf	Range Rover Sport (L494)	AAM - Audio Amplifier Module	DATA
HK62-14C527-CDC.vbf	Range Rover Sport (L494)	AAM - Audio Amplifier Module	DATA

File name	Vehicle line (indicative)	Module (ECU)	Type
HK62-14C527-CDD.vbf	Range Rover Sport (L494)	AAM - Audio Amplifier Module	DATA
HK62-14C527-CDE.vbf	Range Rover Sport (L494)	AAM - Audio Amplifier Module	DATA
HK62-14C527-CE.vbf	Range Rover Sport (L494)	AAM - Audio Amplifier Module	DATA
HK62-14C527-CEB.vbf	Range Rover Sport (L494)	AAM - Audio Amplifier Module	DATA
HK62-14C527-CEC.vbf	Range Rover Sport (L494)	AAM - Audio Amplifier Module	DATA
HK62-14C527-CED.vbf	Range Rover Sport (L494)	AAM - Audio Amplifier Module	DATA
HK62-14C527-CEE.vbf	Range Rover Sport (L494)	AAM - Audio Amplifier Module	DATA
HK62-14C527-CFB.vbf	Range Rover Sport (L494)	AAM - Audio Amplifier Module	DATA
HK62-14C527-CFC.vbf	Range Rover Sport (L494)	AAM - Audio Amplifier Module	DATA
HK62-14C527-CFD.vbf	Range Rover Sport (L494)	AAM - Audio Amplifier Module	DATA
HK62-14C527-CFE.vbf	Range Rover Sport (L494)	AAM - Audio Amplifier Module	DATA
HK62-14C527-CGB.vbf	Range Rover Sport (L494)	AAM - Audio Amplifier Module	DATA
HK62-14C527-CGC.vbf	Range Rover Sport (L494)	AAM - Audio Amplifier Module	DATA
HK62-14C527-CGD.vbf	Range Rover Sport (L494)	AAM - Audio Amplifier Module	DATA
HK62-14C527-CGE.vbf	Range Rover Sport (L494)	AAM - Audio Amplifier Module	DATA
HK62-14C527-CHB.vbf	Range Rover Sport (L494)	AAM - Audio Amplifier Module	DATA
HK62-14C527-CHC.vbf	Range Rover Sport (L494)	AAM - Audio Amplifier Module	DATA
HK62-14C527-CHD.vbf	Range Rover Sport (L494)	AAM - Audio Amplifier Module	DATA
HK62-14C527-CHE.vbf	Range Rover Sport (L494)	AAM - Audio Amplifier Module	DATA
HK62-14C527-DAB.vbf	Range Rover Sport (L494)	AAM - Audio Amplifier Module	DATA
HK62-14C527-DAC.vbf	Range Rover Sport (L494)	AAM - Audio Amplifier Module	DATA
HK62-14C527-DAD.vbf	Range Rover Sport (L494)	AAM - Audio Amplifier Module	DATA
HK62-14C527-DAE.vbf	Range Rover Sport (L494)	AAM - Audio Amplifier Module	DATA
HK62-14C527-DB.vbf	Range Rover Sport (L494)	AAM - Audio Amplifier Module	DATA
HK62-14C527-DC.vbf	Range Rover Sport (L494)	AAM - Audio Amplifier Module	DATA
HK62-14C527-DCB.vbf	Range Rover Sport (L494)	AAM - Audio Amplifier Module	DATA
HK62-14C527-DCC.vbf	Range Rover Sport (L494)	AAM - Audio Amplifier Module	DATA
HK62-14C527-DCD.vbf	Range Rover Sport (L494)	AAM - Audio Amplifier Module	DATA
HK62-14C527-DCE.vbf	Range Rover Sport (L494)	AAM - Audio Amplifier Module	DATA
HK62-14C527-DD.vbf	Range Rover Sport (L494)	AAM - Audio Amplifier Module	DATA
HK62-14C527-DDB.vbf	Range Rover Sport (L494)	AAM - Audio Amplifier Module	DATA
HK62-14C527-DDC.vbf	Range Rover Sport (L494)	AAM - Audio Amplifier Module	DATA
HK62-14C527-DDD.vbf	Range Rover Sport (L494)	AAM - Audio Amplifier Module	DATA
HK62-14C527-DDE.vbf	Range Rover Sport (L494)	AAM - Audio Amplifier Module	DATA
HK62-14C527-DEB.vbf	Range Rover Sport (L494)	AAM - Audio Amplifier Module	DATA
HK62-14C527-DEC.vbf	Range Rover Sport (L494)	AAM - Audio Amplifier Module	DATA
HK62-14C527-DED.vbf	Range Rover Sport (L494)	AAM - Audio Amplifier Module	DATA
HK62-14C527-DEE.vbf	Range Rover Sport (L494)	AAM - Audio Amplifier Module	DATA
HK62-14C527-DFB.vbf	Range Rover Sport (L494)	AAM - Audio Amplifier Module	DATA
HK62-14C527-DFC.vbf	Range Rover Sport (L494)	AAM - Audio Amplifier Module	DATA
HK62-14C527-DFD.vbf	Range Rover Sport (L494)	AAM - Audio Amplifier Module	DATA
HK62-14C527-DFE.vbf	Range Rover Sport (L494)	AAM - Audio Amplifier Module	DATA
HK62-14C527-DGB.vbf	Range Rover Sport (L494)	AAM - Audio Amplifier Module	DATA
HK62-14C527-DGC.vbf	Range Rover Sport (L494)	AAM - Audio Amplifier Module	DATA
HK62-14C527-DGD.vbf	Range Rover Sport (L494)	AAM - Audio Amplifier Module	DATA
HK62-14C527-DGE.vbf	Range Rover Sport (L494)	AAM - Audio Amplifier Module	DATA
HK62-14C527-DHB.vbf	Range Rover Sport (L494)	AAM - Audio Amplifier Module	DATA
HK62-14C527-DHC.vbf	Range Rover Sport (L494)	AAM - Audio Amplifier Module	DATA
HK62-14C527-DHD.vbf	Range Rover Sport (L494)	AAM - Audio Amplifier Module	DATA
HK62-14C527-DHE.vbf	Range Rover Sport (L494)	AAM - Audio Amplifier Module	DATA
HK62-14C549-AAA.vbf	Range Rover Sport (L494)	PSM - Passenger Front Seat Module	EXE
HK62-14C549-ABA.vbf	Range Rover Sport (L494)	PSM - Passenger Front Seat Module	EXE
HK62-14C549-ACA.vbf	Range Rover Sport (L494)	PSM - Passenger Front Seat Module	EXE
HK62-14C549-ADA.vbf	Range Rover Sport (L494)	PSM - Passenger Front Seat Module	EXE
HK62-14C549-ADB.vbf	Range Rover Sport (L494)	PSM - Passenger Front Seat Module	EXE
HK62-14C549-AEA.vbf	Range Rover Sport (L494)	PSM - Passenger Front Seat Module	EXE
HK62-14C549-BAA.vbf	Range Rover Sport (L494)	PSM - Passenger Front Seat Module	EXE
HK62-14C549-BAB.vbf	Range Rover Sport (L494)	PSM - Passenger Front Seat Module	EXE
HK62-14C549-BBA.vbf	Range Rover Sport (L494)	PSM - Passenger Front Seat Module	EXE
HK62-14C549-BBB.vbf	Range Rover Sport (L494)	PSM - Passenger Front Seat Module	EXE
HK62-14C549-BCA.vbf	Range Rover Sport (L494)	PSM - Passenger Front Seat Module	EXE
HK62-14C549-BCB.vbf	Range Rover Sport (L494)	PSM - Passenger Front Seat Module	EXE
HK62-14C549-BDA.vbf	Range Rover Sport (L494)	PSM - Passenger Front Seat Module	EXE
HK62-14C549-BDB.vbf	Range Rover Sport (L494)	PSM - Passenger Front Seat Module	EXE
HK62-14C549-BEA.vbf	Range Rover Sport (L494)	PSM - Passenger Front Seat Module	EXE
HK62-14C549-BEB.vbf	Range Rover Sport (L494)	PSM - Passenger Front Seat Module	EXE
HK62-14C560-AB.vbf	Range Rover Sport (L494)	GSM - Gear Shift Module	SIGCFG
HK62-14C561-AA.vbf	Range Rover Sport (L494)	GSM - Gear Shift Module	EXE
HK62-14C561-AC.vbf	Range Rover Sport (L494)	GSM - Gear Shift Module	EXE
HK62-14C609-AA.vbf	Range Rover Sport (L494)	PSCM - Power Steering Control Module	EXE
HK62-14C609-AB.vbf	Range Rover Sport (L494)	PSCM - Power Steering Control Module	EXE
HK62-14C609-AC.vbf	Range Rover Sport (L494)	PSCM - Power Steering Control Module	EXE
HK62-14C609-AD.vbf	Range Rover Sport (L494)	PSCM - Power Steering Control Module	EXE
HK62-14C609-AE.vbf	Range Rover Sport (L494)	PSCM - Power Steering Control Module	EXE
HK62-14D183-AB.vbf	Range Rover Sport (L494)	OCS - Restraints Occupant Classification System Module	DATA
HK62-14D485-AC.vbf	Range Rover Sport (L494)	IPMB - Image Processing Module B	EXE

File name	Vehicle line (indicative)	Module (ECU)	Type
HK62-14D485-AD.vbf	Range Rover Sport (L494)	IPMB - Image Processing Module B	EXE
HK62-14D485-AE.vbf	Range Rover Sport (L494)	IPMB - Image Processing Module B	EXE
HK62-14D485-AF.vbf	Range Rover Sport (L494)	IPMB - Image Processing Module B	EXE
HK62-14D485-AG.vbf	Range Rover Sport (L494)	IPMB - Image Processing Module B	EXE
HK62-14D485-AH.vbf	Range Rover Sport (L494)	IPMB - Image Processing Module B	EXE
HK62-14D485-AJ.vbf	Range Rover Sport (L494)	IPMB - Image Processing Module B	EXE
HK62-14D564-AB.vbf	Range Rover Sport (L494)	SODL - Side Obstacle Detection Control Module - Left	DATA
HK62-14D564-AC.vbf	Range Rover Sport (L494)	SODL - Side Obstacle Detection Control Module - Left	DATA
HK62-14D564-AD.vbf	Range Rover Sport (L494)	SODL - Side Obstacle Detection Control Module - Left	DATA
HK62-14D564-AE.vbf	Range Rover Sport (L494)	SODL - Side Obstacle Detection Control Module - Left	DATA
HK62-14D564-BB.vbf	Range Rover Sport (L494)	SODR - Side Obstacle Detection Control Module - Right	DATA
HK62-14D564-BC.vbf	Range Rover Sport (L494)	SODR - Side Obstacle Detection Control Module - Right	DATA
HK62-14D564-BD.vbf	Range Rover Sport (L494)	SODR - Side Obstacle Detection Control Module - Right	DATA
HK62-14D564-BE.vbf	Range Rover Sport (L494)	SODR - Side Obstacle Detection Control Module - Right	DATA
HK62-14E094-HAA.vbf	Range Rover Sport (L494)	CHCM - Chassis Control Module	EXE
HK62-14E094-HAB.vbf	Range Rover Sport (L494)	CHCM - Chassis Control Module	EXE
HK62-14E094-HAC.vbf	Range Rover Sport (L494)	CHCM - Chassis Control Module	EXE
HK62-14E094-HAD.vbf	Range Rover Sport (L494)	CHCM - Chassis Control Module	EXE
HK62-14E094-HAE.vbf	Range Rover Sport (L494)	CHCM - Chassis Control Module	EXE
HK62-14E094-HAF.vbf	Range Rover Sport (L494)	CHCM - Chassis Control Module	EXE
HK62-14E094-HAG.vbf	Range Rover Sport (L494)	CHCM - Chassis Control Module	EXE
HK62-14E094-HBA.vbf	Range Rover Sport (L494)	CHCM - Chassis Control Module	EXE
HK62-14E094-HBB.vbf	Range Rover Sport (L494)	CHCM - Chassis Control Module	EXE
HK62-14E094-HBC.vbf	Range Rover Sport (L494)	CHCM - Chassis Control Module	EXE
HK62-14E094-HBD.vbf	Range Rover Sport (L494)	CHCM - Chassis Control Module	EXE
HK62-14E094-HBE.vbf	Range Rover Sport (L494)	CHCM - Chassis Control Module	EXE
HK62-14E094-HBF.vbf	Range Rover Sport (L494)	CHCM - Chassis Control Module	EXE
HK62-14E094-HBG.vbf	Range Rover Sport (L494)	CHCM - Chassis Control Module	EXE
HK62-14E094-JAA.vbf	Range Rover Sport (L494)	CHCM - Chassis Control Module	EXE
HK62-14E094-JAB.vbf	Range Rover Sport (L494)	CHCM - Chassis Control Module	EXE
HK62-14E094-JAC.vbf	Range Rover Sport (L494)	CHCM - Chassis Control Module	EXE
HK62-14E094-JAD.vbf	Range Rover Sport (L494)	CHCM - Chassis Control Module	EXE
HK62-14E094-JAE.vbf	Range Rover Sport (L494)	CHCM - Chassis Control Module	EXE
HK62-14E094-JAF.vbf	Range Rover Sport (L494)	CHCM - Chassis Control Module	EXE
HK62-14E094-JAG.vbf	Range Rover Sport (L494)	CHCM - Chassis Control Module	EXE
HK62-14E094-JBA.vbf	Range Rover Sport (L494)	CHCM - Chassis Control Module	EXE
HK62-14E094-JBB.vbf	Range Rover Sport (L494)	CHCM - Chassis Control Module	EXE
HK62-14E094-JBC.vbf	Range Rover Sport (L494)	CHCM - Chassis Control Module	EXE
HK62-14E094-JBD.vbf	Range Rover Sport (L494)	CHCM - Chassis Control Module	EXE
HK62-14E094-JBE.vbf	Range Rover Sport (L494)	CHCM - Chassis Control Module	EXE
HK62-14E094-JBF.vbf	Range Rover Sport (L494)	CHCM - Chassis Control Module	EXE
HK62-14E094-JBG.vbf	Range Rover Sport (L494)	CHCM - Chassis Control Module	EXE
HK62-14E094-JCA.vbf	Range Rover Sport (L494)	CHCM - Chassis Control Module	EXE
HK62-14E094-JCB.vbf	Range Rover Sport (L494)	CHCM - Chassis Control Module	EXE
HK62-14E094-JCC.vbf	Range Rover Sport (L494)	CHCM - Chassis Control Module	EXE
HK62-14E094-JCD.vbf	Range Rover Sport (L494)	CHCM - Chassis Control Module	EXE
HK62-14E094-JCE.vbf	Range Rover Sport (L494)	CHCM - Chassis Control Module	EXE
HK62-14E094-JCF.vbf	Range Rover Sport (L494)	CHCM - Chassis Control Module	EXE
HK62-14E094-JCG.vbf	Range Rover Sport (L494)	CHCM - Chassis Control Module	EXE
HK62-14E094-JDA.vbf	Range Rover Sport (L494)	CHCM - Chassis Control Module	EXE
HK62-14E094-JDB.vbf	Range Rover Sport (L494)	CHCM - Chassis Control Module	EXE
HK62-14E094-JDC.vbf	Range Rover Sport (L494)	CHCM - Chassis Control Module	EXE
HK62-14E094-JDD.vbf	Range Rover Sport (L494)	CHCM - Chassis Control Module	EXE
HK62-14E094-JDE.vbf	Range Rover Sport (L494)	CHCM - Chassis Control Module	EXE
HK62-14E094-JDF.vbf	Range Rover Sport (L494)	CHCM - Chassis Control Module	EXE
HK62-14E094-JDG.vbf	Range Rover Sport (L494)	CHCM - Chassis Control Module	EXE
HK62-14E094-JEA.vbf	Range Rover Sport (L494)	CHCM - Chassis Control Module	EXE
HK62-14E094-JEB.vbf	Range Rover Sport (L494)	CHCM - Chassis Control Module	EXE
HK62-14E094-JEC.vbf	Range Rover Sport (L494)	CHCM - Chassis Control Module	EXE
HK62-14E094-JED.vbf	Range Rover Sport (L494)	CHCM - Chassis Control Module	EXE
HK62-14E094-JEE.vbf	Range Rover Sport (L494)	CHCM - Chassis Control Module	EXE
HK62-14E094-JEF.vbf	Range Rover Sport (L494)	CHCM - Chassis Control Module	EXE
HK62-14E094-JEG.vbf	Range Rover Sport (L494)	CHCM - Chassis Control Module	EXE
HK62-14E094-JFA.vbf	Range Rover Sport (L494)	CHCM - Chassis Control Module	EXE
HK62-14E094-JFB.vbf	Range Rover Sport (L494)	CHCM - Chassis Control Module	EXE
HK62-14E094-JFC.vbf	Range Rover Sport (L494)	CHCM - Chassis Control Module	EXE
HK62-14E094-JFD.vbf	Range Rover Sport (L494)	CHCM - Chassis Control Module	EXE
HK62-14E094-JFE.vbf	Range Rover Sport (L494)	CHCM - Chassis Control Module	EXE
HK62-14E094-JFF.vbf	Range Rover Sport (L494)	CHCM - Chassis Control Module	EXE
HK62-14E094-JFG.vbf	Range Rover Sport (L494)	CHCM - Chassis Control Module	EXE
HK62-14E094-JGA.vbf	Range Rover Sport (L494)	CHCM - Chassis Control Module	EXE
HK62-14E094-JGB.vbf	Range Rover Sport (L494)	CHCM - Chassis Control Module	EXE
HK62-14E094-JGC.vbf	Range Rover Sport (L494)	CHCM - Chassis Control Module	EXE
HK62-14E094-JGD.vbf	Range Rover Sport (L494)	CHCM - Chassis Control Module	EXE
HK62-14E094-JGE.vbf	Range Rover Sport (L494)	CHCM - Chassis Control Module	EXE
HK62-14E094-JGF.vbf	Range Rover Sport (L494)	CHCM - Chassis Control Module	EXE

File name	Vehicle line (indicative)	Module (ECU)	Type
HK62-14E094-JGG.vbf	Range Rover Sport (L494)	CHCM - Chassis Control Module	EXE
HK62-14E094-JJA.vbf	Range Rover Sport (L494)	CHCM - Chassis Control Module	EXE
HK62-14E094-JJB.vbf	Range Rover Sport (L494)	CHCM - Chassis Control Module	EXE
HK62-14E094-JJC.vbf	Range Rover Sport (L494)	CHCM - Chassis Control Module	EXE
HK62-14E094-JJD.vbf	Range Rover Sport (L494)	CHCM - Chassis Control Module	EXE
HK62-14E094-JJE.vbf	Range Rover Sport (L494)	CHCM - Chassis Control Module	EXE
HK62-14E094-JJF.vbf	Range Rover Sport (L494)	CHCM - Chassis Control Module	EXE
HK62-14E094-JJG.vbf	Range Rover Sport (L494)	CHCM - Chassis Control Module	EXE
HK62-14E094-JKB.vbf	Range Rover Sport (L494)	CHCM - Chassis Control Module	EXE
HK62-14E094-JKC.vbf	Range Rover Sport (L494)	CHCM - Chassis Control Module	EXE
HK62-14E094-JKD.vbf	Range Rover Sport (L494)	CHCM - Chassis Control Module	EXE
HK62-14E094-JKE.vbf	Range Rover Sport (L494)	CHCM - Chassis Control Module	EXE
HK62-14E094-JKF.vbf	Range Rover Sport (L494)	CHCM - Chassis Control Module	EXE
HK62-14E094-JKG.vbf	Range Rover Sport (L494)	CHCM - Chassis Control Module	EXE
HK62-14E094-JKH.vbf	Range Rover Sport (L494)	CHCM - Chassis Control Module	EXE
HK62-14F022-AB.vbf	Range Rover Sport (L494)	IPMB - Image Processing Module B	DATA
HK62-14F022-AC.vbf	Range Rover Sport (L494)	IPMB - Image Processing Module B	DATA
HK62-14F022-AD.vbf	Range Rover Sport (L494)	IPMB - Image Processing Module B	DATA
HK62-14F022-AE.vbf	Range Rover Sport (L494)	IPMB - Image Processing Module B	DATA
HK62-14F022-AF.vbf	Range Rover Sport (L494)	IPMB - Image Processing Module B	DATA
HK62-14F022-AG.vbf	Range Rover Sport (L494)	IPMB - Image Processing Module B	DATA
HK62-14F022-AH.vbf	Range Rover Sport (L494)	IPMB - Image Processing Module B	DATA
HK62-14F022-AJ.vbf	Range Rover Sport (L494)	IPMB - Image Processing Module B	DATA
HK62-14F229-AB.vbf	Range Rover Sport (L494)	HUD - Head Up Display	SIGCFG
HK62-14F231-AB.vbf	Range Rover Sport (L494)	HUD - Head Up Display	CUSTOM
HK62-14F231-AC.vbf	Range Rover Sport (L494)	HUD - Head Up Display	CUSTOM
HK62-14F435-NAB.vbf	Range Rover Sport (L494)	CHCMB - Chassis Control Module B	EXE
HK62-14F435-NAC.vbf	Range Rover Sport (L494)	CHCMB - Chassis Control Module B	EXE
HK62-14F435-NAD.vbf	Range Rover Sport (L494)	CHCMB - Chassis Control Module B	EXE
HK62-14F435-NAE.vbf	Range Rover Sport (L494)	CHCMB - Chassis Control Module B	EXE
HK62-14F435-NAF.vbf	Range Rover Sport (L494)	CHCMB - Chassis Control Module B	EXE
HK62-14F435-NBB.vbf	Range Rover Sport (L494)	CHCMB - Chassis Control Module B	EXE
HK62-14F435-NBC.vbf	Range Rover Sport (L494)	CHCMB - Chassis Control Module B	EXE
HK62-14F435-NBD.vbf	Range Rover Sport (L494)	CHCMB - Chassis Control Module B	EXE
HK62-14F435-NBE.vbf	Range Rover Sport (L494)	CHCMB - Chassis Control Module B	EXE
HK62-14F435-NBF.vbf	Range Rover Sport (L494)	CHCMB - Chassis Control Module B	EXE
HK62-14F435-NCB.vbf	Range Rover Sport (L494)	CHCMB - Chassis Control Module B	EXE
HK62-14F435-NCC.vbf	Range Rover Sport (L494)	CHCMB - Chassis Control Module B	EXE
HK62-14F435-NCD.vbf	Range Rover Sport (L494)	CHCMB - Chassis Control Module B	EXE
HK62-14F435-NCE.vbf	Range Rover Sport (L494)	CHCMB - Chassis Control Module B	EXE
HK62-14F435-NCF.vbf	Range Rover Sport (L494)	CHCMB - Chassis Control Module B	EXE
HK62-14F529-BA.vbf	Range Rover Sport (L494)	GWM - Gateway Module A	EXE
HK62-14F529-BB.vbf	Range Rover Sport (L494)	GWM - Gateway Module A	EXE
HK62-14F529-BC.vbf	Range Rover Sport (L494)	GWM - Gateway Module A	DATA
HK62-14F529-BD.vbf	Range Rover Sport (L494)	GWM - Gateway Module A	EXE
HK62-14F529-BE.vbf	Range Rover Sport (L494)	GWM - Gateway Module A	EXE
HK62-14F529-BF.vbf	Range Rover Sport (L494)	GWM - Gateway Module A	EXE
HK62-14F529-BG.vbf	Range Rover Sport (L494)	GWM - Gateway Module A	EXE
HK62-14F529-BH.vbf	Range Rover Sport (L494)	GWM - Gateway Module A	EXE
HK62-14F529-BJ.vbf	Range Rover Sport (L494)	GWM - Gateway Module A	EXE
HK62-14F529-BK.vbf	Range Rover Sport (L494)	GWM - Gateway Module A	EXE
HK62-14F529-BL.vbf	Range Rover Sport (L494)	GWM - Gateway Module A	EXE
HK62-14F529-CA.vbf	Range Rover Sport (L494)	GWM - Gateway Module A	EXE
HK62-14F530-BB.vbf	Range Rover Sport (L494)	GWM - Gateway Module A	EXE
HK62-14F530-BC.vbf	Range Rover Sport (L494)	GWM - Gateway Module A	EXE
HK62-14F530-BD.vbf	Range Rover Sport (L494)	GWM - Gateway Module A	DATA
HK62-14F530-BF.vbf	Range Rover Sport (L494)	GWM - Gateway Module A	EXE
HK62-14F530-BH.vbf	Range Rover Sport (L494)	GWM - Gateway Module A	EXE
HK62-14F530-BJ.vbf	Range Rover Sport (L494)	GWM - Gateway Module A	EXE
HK62-14F530-BK.vbf	Range Rover Sport (L494)	GWM - Gateway Module A	EXE
HK62-14F530-BL.vbf	Range Rover Sport (L494)	GWM - Gateway Module A	EXE
HK62-14F530-BM.vbf	Range Rover Sport (L494)	GWM - Gateway Module A	EXE
HK62-14F530-BN.vbf	Range Rover Sport (L494)	GWM - Gateway Module A	EXE
HK62-14F530-CA.vbf	Range Rover Sport (L494)	GWM - Gateway Module A	EXE
HK62-14F531-BB.vbf	Range Rover Sport (L494)	GWM - Gateway Module A	DATA
HK62-14F531-BC.vbf	Range Rover Sport (L494)	GWM - Gateway Module A	DATA
HK62-14F531-BD.vbf	Range Rover Sport (L494)	GWM - Gateway Module A	DATA
HK62-14F531-BE.vbf	Range Rover Sport (L494)	GWM - Gateway Module A	DATA
HK62-14F531-BG.vbf	Range Rover Sport (L494)	GWM - Gateway Module A	DATA
HK62-14F531-BH.vbf	Range Rover Sport (L494)	GWM - Gateway Module A	DATA
HK62-14F531-BJ.vbf	Range Rover Sport (L494)	GWM - Gateway Module A	DATA
HK62-14F531-CA.vbf	Range Rover Sport (L494)	GWM - Gateway Module A	DATA
HK62-7J104-FBB.vbf	Range Rover Sport (L494)	TCM - Transmission Control Module	EXE
HK62-7J104-FBC.vbf	Range Rover Sport (L494)	TCM - Transmission Control Module	EXE
HK62-7J104-FBD.vbf	Range Rover Sport (L494)	TCM - Transmission Control Module	EXE
HK62-7J104-FBE.vbf	Range Rover Sport (L494)	TCM - Transmission Control Module	EXE

File name	Vehicle line (indicative)	Module (ECU)	Type
HK62-7J104-FBF.vbf	Range Rover Sport (L494)	TCM - Transmission Control Module	EXE
HK62-7J104-FBG.vbf	Range Rover Sport (L494)	TCM - Transmission Control Module	EXE
HK62-7J104-FBH.vbf	Range Rover Sport (L494)	TCM - Transmission Control Module	EXE
HK62-7J104-FBJ.vbf	Range Rover Sport (L494)	TCM - Transmission Control Module	EXE
HK62-7J104-FCB.vbf	Range Rover Sport (L494)	TCM - Transmission Control Module	EXE
HK62-7J104-FCC.vbf	Range Rover Sport (L494)	TCM - Transmission Control Module	EXE
HK62-7J104-FCD.vbf	Range Rover Sport (L494)	TCM - Transmission Control Module	EXE
HK62-7J104-FCE.vbf	Range Rover Sport (L494)	TCM - Transmission Control Module	EXE
HK62-7J104-FCF.vbf	Range Rover Sport (L494)	TCM - Transmission Control Module	EXE
HK62-7J104-FCG.vbf	Range Rover Sport (L494)	TCM - Transmission Control Module	EXE
HK62-7J104-FCH.vbf	Range Rover Sport (L494)	TCM - Transmission Control Module	EXE
HK62-7J104-FDB.vbf	Range Rover Sport (L494)	TCM - Transmission Control Module	EXE
HK62-7J104-FDC.vbf	Range Rover Sport (L494)	TCM - Transmission Control Module	EXE
HK62-7J104-FDD.vbf	Range Rover Sport (L494)	TCM - Transmission Control Module	EXE
HK62-7J104-FDE.vbf	Range Rover Sport (L494)	TCM - Transmission Control Module	EXE
HK62-7J104-FDF.vbf	Range Rover Sport (L494)	TCM - Transmission Control Module	EXE
HK62-7J104-FDG.vbf	Range Rover Sport (L494)	TCM - Transmission Control Module	EXE
HK62-7J104-FDH.vbf	Range Rover Sport (L494)	TCM - Transmission Control Module	EXE
HK62-7J104-FDJ.vbf	Range Rover Sport (L494)	TCM - Transmission Control Module	EXE
HK62-7J104-FHB.vbf	Range Rover Sport (L494)	TCM - Transmission Control Module	EXE
HK62-7J104-FHC.vbf	Range Rover Sport (L494)	TCM - Transmission Control Module	EXE
HK62-7J104-FHD.vbf	Range Rover Sport (L494)	TCM - Transmission Control Module	EXE
HK62-7J104-FHE.vbf	Range Rover Sport (L494)	TCM - Transmission Control Module	EXE
HK62-7J104-FHF.vbf	Range Rover Sport (L494)	TCM - Transmission Control Module	EXE
HK62-7J104-FHG.vbf	Range Rover Sport (L494)	TCM - Transmission Control Module	EXE
HK62-7J104-FHH.vbf	Range Rover Sport (L494)	TCM - Transmission Control Module	EXE
HK62-7J104-FKB.vbf	Range Rover Sport (L494)	TCM - Transmission Control Module	EXE
HK62-7J104-FKC.vbf	Range Rover Sport (L494)	TCM - Transmission Control Module	EXE
HK62-7J104-FKD.vbf	Range Rover Sport (L494)	TCM - Transmission Control Module	EXE
HK62-7J104-FKE.vbf	Range Rover Sport (L494)	TCM - Transmission Control Module	EXE
HK62-7J104-FKF.vbf	Range Rover Sport (L494)	TCM - Transmission Control Module	EXE
HK62-7J104-FKG.vbf	Range Rover Sport (L494)	TCM - Transmission Control Module	EXE
HK62-7J104-FKH.vbf	Range Rover Sport (L494)	TCM - Transmission Control Module	EXE
HK62-7J104-FKJ.vbf	Range Rover Sport (L494)	TCM - Transmission Control Module	EXE
HK62-7J104-FLB.vbf	Range Rover Sport (L494)	TCM - Transmission Control Module	EXE
HK62-7J104-FLC.vbf	Range Rover Sport (L494)	TCM - Transmission Control Module	EXE
HK62-7J104-FLD.vbf	Range Rover Sport (L494)	TCM - Transmission Control Module	EXE
HK62-7J104-FLE.vbf	Range Rover Sport (L494)	TCM - Transmission Control Module	EXE
HK62-7J104-FLF.vbf	Range Rover Sport (L494)	TCM - Transmission Control Module	EXE
HK62-7J104-FLG.vbf	Range Rover Sport (L494)	TCM - Transmission Control Module	EXE
HK62-7J104-FLH.vbf	Range Rover Sport (L494)	TCM - Transmission Control Module	EXE
HK62-7J104-FPA.vbf	Range Rover Sport (L494)	TCM - Transmission Control Module	EXE
HK62-7J104-FPB.vbf	Range Rover Sport (L494)	TCM - Transmission Control Module	EXE
HK62-7J104-FPC.vbf	Range Rover Sport (L494)	TCM - Transmission Control Module	EXE
HK62-7J104-FPD.vbf	Range Rover Sport (L494)	TCM - Transmission Control Module	EXE
HK62-7J104-FPE.vbf	Range Rover Sport (L494)	TCM - Transmission Control Module	EXE
HK62-7J104-FPF.vbf	Range Rover Sport (L494)	TCM - Transmission Control Module	EXE
HK62-7J104-FPG.vbf	Range Rover Sport (L494)	TCM - Transmission Control Module	EXE
HK62-7J104-FPH.vbf	Range Rover Sport (L494)	TCM - Transmission Control Module	EXE
HK62-7J104-FYB.vbf	Range Rover Sport (L494)	TCM - Transmission Control Module	EXE
HK62-7J104-FYC.vbf	Range Rover Sport (L494)	TCM - Transmission Control Module	EXE
HK62-7J104-FYD.vbf	Range Rover Sport (L494)	TCM - Transmission Control Module	EXE
HK62-7J104-FYE.vbf	Range Rover Sport (L494)	TCM - Transmission Control Module	EXE
HK62-7J104-FYF.vbf	Range Rover Sport (L494)	TCM - Transmission Control Module	EXE
HK62-7J104-FYG.vbf	Range Rover Sport (L494)	TCM - Transmission Control Module	EXE
HK62-7J104-FYH.vbf	Range Rover Sport (L494)	TCM - Transmission Control Module	EXE
HK6M-14C034-AAA.vbf	Range Rover Sport (L494)	DSM - Driver Front Seat Module	EXE
HK6M-14C218-AB.vbf	Range Rover Sport (L494)	PSCM - Power Steering Control Module	EXE
HK6M-14C549-AAA.vbf	Range Rover Sport (L494)	PSM - Passenger Front Seat Module	EXE
HK6M-14C570-SAA.vbf	Range Rover Sport (L494)	PCM - Powertrain Control Module	EXE
HK6M-14C570-SAB.vbf	Range Rover Sport (L494)	PCM - Powertrain Control Module	EXE
HK6M-14C570-SAC.vbf	Range Rover Sport (L494)	PCM - Powertrain Control Module	EXE
HK6M-14C570-SAD.vbf	Range Rover Sport (L494)	PCM - Powertrain Control Module	EXE
HK6M-14C570-SAE.vbf	Range Rover Sport (L494)	PCM - Powertrain Control Module	EXE
HK6M-14C570-SBA.vbf	Range Rover Sport (L494)	PCM - Powertrain Control Module	EXE
HK6M-14C570-SBB.vbf	Range Rover Sport (L494)	PCM - Powertrain Control Module	EXE
HK6M-14C570-SBC.vbf	Range Rover Sport (L494)	PCM - Powertrain Control Module	EXE
HK6M-14C570-SCA.vbf	Range Rover Sport (L494)	PCM - Powertrain Control Module	EXE
HK6M-14C570-SCC.vbf	Range Rover Sport (L494)	PCM - Powertrain Control Module	EXE
HK6M-14C570-SCD.vbf	Range Rover Sport (L494)	PCM - Powertrain Control Module	EXE
HK6M-14C570-SCE.vbf	Range Rover Sport (L494)	PCM - Powertrain Control Module	EXE
HK6M-14C570-SDA.vbf	Range Rover Sport (L494)	PCM - Powertrain Control Module	EXE
HK6M-14C570-SDC.vbf	Range Rover Sport (L494)	PCM - Powertrain Control Module	EXE
HK6M-14C570-SDD.vbf	Range Rover Sport (L494)	PCM - Powertrain Control Module	EXE
HK6M-14C570-SEA.vbf	Range Rover Sport (L494)	PCM - Powertrain Control Module	EXE
HK6M-14C570-SEB.vbf	Range Rover Sport (L494)	PCM - Powertrain Control Module	EXE

File name	Vehicle line (indicative)	Module (ECU)	Type
HK6M-14C570-SEC.vbf	Range Rover Sport (L494)	PCM - Powertrain Control Module	EXE
HK6M-14C570-SED.vbf	Range Rover Sport (L494)	PCM - Powertrain Control Module	EXE
HK6M-14C570-STA.vbf	Range Rover Sport (L494)	PCM - Powertrain Control Module	EXE
HK6M-14C570-STB.vbf	Range Rover Sport (L494)	PCM - Powertrain Control Module	EXE
HK6M-14C570-STC.vbf	Range Rover Sport (L494)	PCM - Powertrain Control Module	EXE
HK6M-14C570-STE.vbf	Range Rover Sport (L494)	PCM - Powertrain Control Module	EXE
HK6M-14C570-STF.vbf	Range Rover Sport (L494)	PCM - Powertrain Control Module	EXE
HK6M-14E094-JHA.vbf	Range Rover Sport (L494)	CHCM - Chassis Control Module	EXE
HK6M-14E094-JHB.vbf	Range Rover Sport (L494)	CHCM - Chassis Control Module	EXE
HK6M-14E094-JHC.vbf	Range Rover Sport (L494)	CHCM - Chassis Control Module	EXE
HK6M-14E094-JHD.vbf	Range Rover Sport (L494)	CHCM - Chassis Control Module	EXE
HK6M-14E094-JHE.vbf	Range Rover Sport (L494)	CHCM - Chassis Control Module	EXE
HK6M-14E094-JHF.vbf	Range Rover Sport (L494)	CHCM - Chassis Control Module	EXE
HK6M-14E094-JHG.vbf	Range Rover Sport (L494)	CHCM - Chassis Control Module	EXE
HK6M-14F435-NEB.vbf	Range Rover Sport (L494)	CHCMB - Chassis Control Module B	EXE
HK6M-14F435-NEC.vbf	Range Rover Sport (L494)	CHCMB - Chassis Control Module B	EXE
HK6M-14F435-NED.vbf	Range Rover Sport (L494)	CHCMB - Chassis Control Module B	EXE
HK6M-14F435-NEE.vbf	Range Rover Sport (L494)	CHCMB - Chassis Control Module B	EXE
HK6M-14F435-NEF.vbf	Range Rover Sport (L494)	CHCMB - Chassis Control Module B	EXE
HK72-12K532-FBB.vbf	Discovery Sport (L550)	PCM - Powertrain Control Module	DATA
HK72-12K532-FBC.vbf	Discovery Sport (L550)	PCM - Powertrain Control Module	DATA
HK72-12K532-FBD.vbf	Discovery Sport (L550)	PCM - Powertrain Control Module	DATA
HK72-12K532-FBE.vbf	Discovery Sport (L550)	PCM - Powertrain Control Module	DATA
HK72-12K532-FBF.vbf	Discovery Sport (L550)	PCM - Powertrain Control Module	DATA
HK72-12K532-FBG.vbf	Discovery Sport (L550)	PCM - Powertrain Control Module	DATA
HK72-12K532-FTA.vbf	Discovery Sport (L550)	PCM - Powertrain Control Module	DATA
HK72-12K532-FTB.vbf	Discovery Sport (L550)	PCM - Powertrain Control Module	DATA
HK72-12K532-FTC.vbf	Discovery Sport (L550)	PCM - Powertrain Control Module	DATA
HK72-12K532-FTD.vbf	Discovery Sport (L550)	PCM - Powertrain Control Module	DATA
HK72-12K532-FTE.vbf	Discovery Sport (L550)	PCM - Powertrain Control Module	DATA
HK72-12K532-FXA.vbf	Discovery Sport (L550)	PCM - Powertrain Control Module	DATA
HK72-12K532-FXB.vbf	Discovery Sport (L550)	PCM - Powertrain Control Module	DATA
HK72-12K532-FXC.vbf	Discovery Sport (L550)	PCM - Powertrain Control Module	DATA
HK72-12K532-FXD.vbf	Discovery Sport (L550)	PCM - Powertrain Control Module	DATA
HK72-12K532-FXE.vbf	Discovery Sport (L550)	PCM - Powertrain Control Module	DATA
HK72-12K532-FZA.vbf	Discovery Sport (L550)	PCM - Powertrain Control Module	DATA
HK72-12K532-FZB.vbf	Discovery Sport (L550)	PCM - Powertrain Control Module	DATA
HK72-12K532-FZC.vbf	Discovery Sport (L550)	PCM - Powertrain Control Module	DATA
HK72-12K532-FZD.vbf	Discovery Sport (L550)	PCM - Powertrain Control Module	DATA
HK72-12K532-FZE.vbf	Discovery Sport (L550)	PCM - Powertrain Control Module	DATA
HK72-12K532-GAA.vbf	Discovery Sport (L550)	PCM - Powertrain Control Module	DATA
HK72-12K532-GAB.vbf	Discovery Sport (L550)	PCM - Powertrain Control Module	DATA
HK72-12K532-GAC.vbf	Discovery Sport (L550)	PCM - Powertrain Control Module	DATA
HK72-12K532-GAD.vbf	Discovery Sport (L550)	PCM - Powertrain Control Module	DATA
HK72-12K532-GAE.vbf	Discovery Sport (L550)	PCM - Powertrain Control Module	DATA
HK72-12K532-GAF.vbf	Discovery Sport (L550)	PCM - Powertrain Control Module	DATA
HK72-12K532-GAG.vbf	Discovery Sport (L550)	PCM - Powertrain Control Module	DATA
HK72-12K532-GBB.vbf	Discovery Sport (L550)	PCM - Powertrain Control Module	DATA
HK72-12K532-GBC.vbf	Discovery Sport (L550)	PCM - Powertrain Control Module	DATA
HK72-12K532-GBD.vbf	Discovery Sport (L550)	PCM - Powertrain Control Module	DATA
HK72-12K532-GBE.vbf	Discovery Sport (L550)	PCM - Powertrain Control Module	DATA
HK72-12K532-GBF.vbf	Discovery Sport (L550)	PCM - Powertrain Control Module	DATA
HK72-12K532-GBG.vbf	Discovery Sport (L550)	PCM - Powertrain Control Module	DATA
HK72-12K532-GCB.vbf	Discovery Sport (L550)	PCM - Powertrain Control Module	DATA
HK72-12K532-GCC.vbf	Discovery Sport (L550)	PCM - Powertrain Control Module	DATA
HK72-12K532-GCD.vbf	Discovery Sport (L550)	PCM - Powertrain Control Module	DATA
HK72-12K532-GCE.vbf	Discovery Sport (L550)	PCM - Powertrain Control Module	DATA
HK72-12K532-GCF.vbf	Discovery Sport (L550)	PCM - Powertrain Control Module	DATA
HK72-12K532-GCG.vbf	Discovery Sport (L550)	PCM - Powertrain Control Module	DATA
HK72-12K532-GDB.vbf	Discovery Sport (L550)	PCM - Powertrain Control Module	DATA
HK72-12K532-GDC.vbf	Discovery Sport (L550)	PCM - Powertrain Control Module	DATA
HK72-12K532-GDD.vbf	Discovery Sport (L550)	PCM - Powertrain Control Module	DATA
HK72-12K532-GDE.vbf	Discovery Sport (L550)	PCM - Powertrain Control Module	DATA
HK72-12K532-GDF.vbf	Discovery Sport (L550)	PCM - Powertrain Control Module	DATA
HK72-12K532-GDG.vbf	Discovery Sport (L550)	PCM - Powertrain Control Module	DATA
HK72-12K532-GEB.vbf	Discovery Sport (L550)	PCM - Powertrain Control Module	DATA
HK72-12K532-GEC.vbf	Discovery Sport (L550)	PCM - Powertrain Control Module	DATA
HK72-12K532-GGA.vbf	Discovery Sport (L550)	PCM - Powertrain Control Module	DATA
HK72-12K532-GGB.vbf	Discovery Sport (L550)	PCM - Powertrain Control Module	DATA
HK72-12K532-GGC.vbf	Discovery Sport (L550)	PCM - Powertrain Control Module	DATA
HK72-12K532-GGD.vbf	Discovery Sport (L550)	PCM - Powertrain Control Module	DATA
HK72-12K532-GHB.vbf	Discovery Sport (L550)	PCM - Powertrain Control Module	DATA
HK72-12K532-GHC.vbf	Discovery Sport (L550)	PCM - Powertrain Control Module	DATA
HK72-12K532-GJA.vbf	Discovery Sport (L550)	PCM - Powertrain Control Module	DATA
HK72-12K532-GJB.vbf	Discovery Sport (L550)	PCM - Powertrain Control Module	DATA
HK72-12K532-GJC.vbf	Discovery Sport (L550)	PCM - Powertrain Control Module	DATA

File name	Vehicle line (indicative)	Module (ECU)	Type
HK72-12K532-GKB.vbf	Discovery Sport (L550)	PCM - Powertrain Control Module	DATA
HK72-12K532-GKC.vbf	Discovery Sport (L550)	PCM - Powertrain Control Module	DATA
HK72-12K532-GLA.vbf	Discovery Sport (L550)	PCM - Powertrain Control Module	DATA
HK72-12K532-GLB.vbf	Discovery Sport (L550)	PCM - Powertrain Control Module	DATA
HK72-12K532-GLC.vbf	Discovery Sport (L550)	PCM - Powertrain Control Module	DATA
HK72-12K532-GLD.vbf	Discovery Sport (L550)	PCM - Powertrain Control Module	DATA
HK72-12K532-GLE.vbf	Discovery Sport (L550)	PCM - Powertrain Control Module	DATA
HK72-12K532-GLF.vbf	Discovery Sport (L550)	PCM - Powertrain Control Module	DATA
HK72-12K532-GLG.vbf	Discovery Sport (L550)	PCM - Powertrain Control Module	DATA
HK72-12K532-GMB.vbf	Discovery Sport (L550)	PCM - Powertrain Control Module	DATA
HK72-12K532-GMC.vbf	Discovery Sport (L550)	PCM - Powertrain Control Module	DATA
HK72-12K532-GNB.vbf	Discovery Sport (L550)	PCM - Powertrain Control Module	DATA
HK72-12K532-GNC.vbf	Discovery Sport (L550)	PCM - Powertrain Control Module	DATA
HK72-12K532-GND.vbf	Discovery Sport (L550)	PCM - Powertrain Control Module	DATA
HK72-12K532-GNE.vbf	Discovery Sport (L550)	PCM - Powertrain Control Module	DATA
HK72-12K532-GNF.vbf	Discovery Sport (L550)	PCM - Powertrain Control Module	DATA
HK72-12K532-GNG.vbf	Discovery Sport (L550)	PCM - Powertrain Control Module	DATA
HK72-12K532-GRA.vbf	Discovery Sport (L550)	PCM - Powertrain Control Module	DATA
HK72-12K532-GRB.vbf	Discovery Sport (L550)	PCM - Powertrain Control Module	DATA
HK72-12K532-GSA.vbf	Discovery Sport (L550)	PCM - Powertrain Control Module	DATA
HK72-12K532-GSB.vbf	Discovery Sport (L550)	PCM - Powertrain Control Module	DATA
HK72-12K532-GTA.vbf	Discovery Sport (L550)	PCM - Powertrain Control Module	DATA
HK72-12K532-GTB.vbf	Discovery Sport (L550)	PCM - Powertrain Control Module	DATA
HK72-12K532-GTC.vbf	Discovery Sport (L550)	PCM - Powertrain Control Module	DATA
HK72-12K532-GTD.vbf	Discovery Sport (L550)	PCM - Powertrain Control Module	DATA
HK72-12K532-GTE.vbf	Discovery Sport (L550)	PCM - Powertrain Control Module	DATA
HK72-12K532-GTF.vbf	Discovery Sport (L550)	PCM - Powertrain Control Module	DATA
HK72-12K532-GTG.vbf	Discovery Sport (L550)	PCM - Powertrain Control Module	DATA
HK72-12K532-GUB.vbf	Discovery Sport (L550)	PCM - Powertrain Control Module	DATA
HK72-12K532-GUC.vbf	Discovery Sport (L550)	PCM - Powertrain Control Module	DATA
HK72-12K532-GUD.vbf	Discovery Sport (L550)	PCM - Powertrain Control Module	DATA
HK72-12K532-GVA.vbf	Discovery Sport (L550)	PCM - Powertrain Control Module	DATA
HK72-12K532-GVB.vbf	Discovery Sport (L550)	PCM - Powertrain Control Module	DATA
HK72-12K532-KAC.vbf	Discovery Sport (L550)	PCM - Powertrain Control Module	DATA
HK72-12K532-KAE.vbf	Discovery Sport (L550)	PCM - Powertrain Control Module	DATA
HK72-12K532-KAF.vbf	Discovery Sport (L550)	PCM - Powertrain Control Module	DATA
HK72-12K532-KAG.vbf	Discovery Sport (L550)	PCM - Powertrain Control Module	DATA
HK72-12K532-KAJ.vbf	Discovery Sport (L550)	PCM - Powertrain Control Module	DATA
HK72-12K532-KAK.vbf	Discovery Sport (L550)	PCM - Powertrain Control Module	DATA
HK72-12K532-KBC.vbf	Discovery Sport (L550)	PCM - Powertrain Control Module	DATA
HK72-12K532-KBE.vbf	Discovery Sport (L550)	PCM - Powertrain Control Module	DATA
HK72-12K532-KBF.vbf	Discovery Sport (L550)	PCM - Powertrain Control Module	DATA
HK72-12K532-KBG.vbf	Discovery Sport (L550)	PCM - Powertrain Control Module	DATA
HK72-12K532-KCA.vbf	Discovery Sport (L550)	PCM - Powertrain Control Module	DATA
HK72-12K532-KCB.vbf	Discovery Sport (L550)	PCM - Powertrain Control Module	DATA
HK72-12K532-KCC.vbf	Discovery Sport (L550)	PCM - Powertrain Control Module	DATA
HK72-12K532-KDB.vbf	Discovery Sport (L550)	PCM - Powertrain Control Module	DATA
HK72-12K532-KDC.vbf	Discovery Sport (L550)	PCM - Powertrain Control Module	DATA
HK72-12K532-KEA.vbf	Discovery Sport (L550)	PCM - Powertrain Control Module	DATA
HK72-12K532-KFC.vbf	Discovery Sport (L550)	PCM - Powertrain Control Module	DATA
HK72-12K532-KFE.vbf	Discovery Sport (L550)	PCM - Powertrain Control Module	DATA
HK72-12K532-KFF.vbf	Discovery Sport (L550)	PCM - Powertrain Control Module	DATA
HK72-12K532-KGD.vbf	Discovery Sport (L550)	PCM - Powertrain Control Module	DATA
HK72-12K532-KHB.vbf	Discovery Sport (L550)	PCM - Powertrain Control Module	DATA
HK72-12K532-KHD.vbf	Discovery Sport (L550)	PCM - Powertrain Control Module	DATA
HK72-14C025-AA.vbf	Discovery Sport (L550)	IPC - Instrument Panel Cluster (IPC) Control Module	SBL
HK72-14C025-AB.vbf	Discovery Sport (L550)	IPC - Instrument Panel Cluster (IPC) Control Module	SBL
HK72-14C026-AA.vbf	Discovery Sport (L550)	IPC - Instrument Panel Cluster (IPC) Control Module	EXE
HK72-14C026-AB.vbf	Discovery Sport (L550)	IPC - Instrument Panel Cluster (IPC) Control Module	EXE
HK72-14C026-AC.vbf	Discovery Sport (L550)	IPC - Instrument Panel Cluster (IPC) Control Module	EXE
HK72-14C026-AD.vbf	Discovery Sport (L550)	IPC - Instrument Panel Cluster (IPC) Control Module	EXE
HK72-14C026-AE.vbf	Discovery Sport (L550)	IPC - Instrument Panel Cluster (IPC) Control Module	EXE
HK72-14C088-BB.vbf	Discovery Sport (L550)	IPC - Instrument Panel Cluster (IPC) Control Module	DATA
HK72-14C088-CA.vbf	Discovery Sport (L550)	IPC - Instrument Panel Cluster (IPC) Control Module	EXE
HK72-14C088-CB.vbf	Discovery Sport (L550)	IPC - Instrument Panel Cluster (IPC) Control Module	EXE
HK72-14C088-CC.vbf	Discovery Sport (L550)	IPC - Instrument Panel Cluster (IPC) Control Module	EXE
HK72-14C088-CD.vbf	Discovery Sport (L550)	IPC - Instrument Panel Cluster (IPC) Control Module	EXE
HK72-14C088-DA.vbf	Discovery Sport (L550)	IPC - Instrument Panel Cluster (IPC) Control Module	DATA
HK72-14C152-AA.vbf	Discovery Sport (L550)	TPM - Tire Pressure Monitor Module	DATA
HK72-14C152-AB.vbf	Discovery Sport (L550)	TPM - Tire Pressure Monitor Module	DATA
HK72-14C217-AA.vbf	Discovery Sport (L550)	PSCM - Power Steering Control Module	EXE
HK72-14C218-AA.vbf	Discovery Sport (L550)	PSCM - Power Steering Control Module	EXE
HK72-14C337-CAA.vbf	Discovery Sport (L550)	TCM - Transmission Control Module	EXE
HK72-14C337-CAC.vbf	Discovery Sport (L550)	TCM - Transmission Control Module	EXE
HK72-14C337-CAD.vbf	Discovery Sport (L550)	TCM - Transmission Control Module	EXE
HK72-14C337-CAE.vbf	Discovery Sport (L550)	TCM - Transmission Control Module	EXE

File name	Vehicle line (indicative)	Module (ECU)	Type
HK72-14C337-CAF.vbf	Discovery Sport (L550)	TCM - Transmission Control Module	EXE
HK72-14C337-CBA.vbf	Discovery Sport (L550)	TCM - Transmission Control Module	EXE
HK72-14C337-CCA.vbf	Discovery Sport (L550)	TCM - Transmission Control Module	EXE
HK72-14C337-CCB.vbf	Discovery Sport (L550)	TCM - Transmission Control Module	EXE
HK72-14C337-CCC.vbf	Discovery Sport (L550)	TCM - Transmission Control Module	EXE
HK72-14C337-CCD.vbf	Discovery Sport (L550)	TCM - Transmission Control Module	EXE
HK72-14C337-CCE.vbf	Discovery Sport (L550)	TCM - Transmission Control Module	EXE
HK72-14C337-CDA.vbf	Discovery Sport (L550)	TCM - Transmission Control Module	EXE
HK72-14C337-CDB.vbf	Discovery Sport (L550)	TCM - Transmission Control Module	EXE
HK72-14C527-BAB.vbf	Discovery Sport (L550)	AAM - Audio Amplifier Module	DATA
HK72-14C527-BD.vbf	Discovery Sport (L550)	AAM - Audio Amplifier Module	DATA
HK72-14C527-BE.vbf	Discovery Sport (L550)	AAM - Audio Amplifier Module	DATA
HK72-14C527-CAB.vbf	Discovery Sport (L550)	AAM - Audio Amplifier Module	DATA
HK72-14C527-CD.vbf	Discovery Sport (L550)	AAM - Audio Amplifier Module	DATA
HK72-14C527-FB.vbf	Discovery Sport (L550)	AAM - Audio Amplifier Module	DATA
HK72-14C527-FC.vbf	Discovery Sport (L550)	AAM - Audio Amplifier Module	DATA
HK72-14C527-GB.vbf	Discovery Sport (L550)	AAM - Audio Amplifier Module	DATA
HK72-14C535-AB.vbf	Discovery Sport (L550)	HVAC - HVAC Control Module	EXE
HK72-14C535-AC.vbf	Discovery Sport (L550)	HVAC - HVAC Control Module	EXE
HK72-14C535-AD.vbf	Discovery Sport (L550)	HVAC - HVAC Control Module	EXE
HK72-14C535-BA.vbf	Discovery Sport (L550)	HVAC - HVAC Control Module	EXE
HK72-14C535-BB.vbf	Discovery Sport (L550)	HVAC - HVAC Control Module	EXE
HK72-14C535-BC.vbf	Discovery Sport (L550)	HVAC - HVAC Control Module	EXE
HK72-14C535-BD.vbf	Discovery Sport (L550)	HVAC - HVAC Control Module	EXE
HK72-14C535-BE.vbf	Discovery Sport (L550)	HVAC - HVAC Control Module	EXE
HK72-14C536-AB.vbf	Discovery Sport (L550)	HVAC - HVAC Control Module	DATA
HK72-14C536-AC.vbf	Discovery Sport (L550)	HVAC - HVAC Control Module	DATA
HK72-14C536-AD.vbf	Discovery Sport (L550)	HVAC - HVAC Control Module	DATA
HK72-14C536-AE.vbf	Discovery Sport (L550)	HVAC - HVAC Control Module	DATA
HK72-14C536-AF.vbf	Discovery Sport (L550)	HVAC - HVAC Control Module	DATA
HK72-14C536-AG.vbf	Discovery Sport (L550)	HVAC - HVAC Control Module	DATA
HK72-14C536-AH.vbf	Discovery Sport (L550)	HVAC - HVAC Control Module	DATA
HK72-14C536-AJ.vbf	Discovery Sport (L550)	HVAC - HVAC Control Module	DATA
HK72-14C536-AK.vbf	Discovery Sport (L550)	HVAC - HVAC Control Module	DATA
HK72-14C536-AL.vbf	Discovery Sport (L550)	HVAC - HVAC Control Module	DATA
HK72-14C536-BB.vbf	Discovery Sport (L550)	HVAC - HVAC Control Module	DATA
HK72-14C536-BC.vbf	Discovery Sport (L550)	HVAC - HVAC Control Module	DATA
HK72-14C536-BD.vbf	Discovery Sport (L550)	HVAC - HVAC Control Module	DATA
HK72-14C536-BE.vbf	Discovery Sport (L550)	HVAC - HVAC Control Module	DATA
HK72-14C536-BF.vbf	Discovery Sport (L550)	HVAC - HVAC Control Module	DATA
HK72-14C536-BG.vbf	Discovery Sport (L550)	HVAC - HVAC Control Module	DATA
HK72-14C536-BH.vbf	Discovery Sport (L550)	HVAC - HVAC Control Module	DATA
HK72-14C536-BJ.vbf	Discovery Sport (L550)	HVAC - HVAC Control Module	DATA
HK72-14C536-BK.vbf	Discovery Sport (L550)	HVAC - HVAC Control Module	DATA
HK72-14C536-BL.vbf	Discovery Sport (L550)	HVAC - HVAC Control Module	DATA
HK72-14C609-AA.vbf	Discovery Sport (L550)	PSCM - Power Steering Control Module	EXE
HK72-14C653-AG.vbf	Discovery Sport (L550)	ACM - Audio Front Control Module	DATA
HK72-14C653-AH.vbf	Discovery Sport (L550)	ACM - Audio Front Control Module	DATA
HK72-14D481-BB.vbf	Discovery Sport (L550)	IPMB - Image Processing Module B	DATA
HK72-14D481-BD.vbf	Discovery Sport (L550)	IPMB - Image Processing Module B	DATA
HK72-14D485-BD.vbf	Discovery Sport (L550)	IPMB - Image Processing Module B	DATA
HK72-14D485-BF.vbf	Discovery Sport (L550)	IPMB - Image Processing Module B	DATA
HK72-14F022-BE.vbf	Discovery Sport (L550)	IPMB - Image Processing Module B	DATA
HK72-14F022-BG.vbf	Discovery Sport (L550)	IPMB - Image Processing Module B	DATA
HK72-14F022-GE.vbf	Discovery Sport (L550)	IPMB - Image Processing Module B	DATA
HK72-14F022-GF.vbf	Discovery Sport (L550)	IPMB - Image Processing Module B	DATA
HK72-14F022-GG.vbf	Discovery Sport (L550)	IPMB - Image Processing Module B	DATA
HK72-14F231-AA.vbf	Discovery Sport (L550)	HUD - Head Up Display	CUSTOM
HK72-14F231-AB.vbf	Discovery Sport (L550)	HUD - Head Up Display	CUSTOM
HK72-14F396-AA.vbf	Discovery Sport (L550)	IPMA - Image Processing Module A	EXE
HK72-14F397-AA.vbf	Discovery Sport (L550)	IPMA - Image Processing Module A	EXE
HK72-14F397-AB.vbf	Discovery Sport (L550)	IPMA - Image Processing Module A	EXE
HK72-14F397-AC.vbf	Discovery Sport (L550)	IPMA - Image Processing Module A	EXE
HK72-14F397-AD.vbf	Discovery Sport (L550)	IPMA - Image Processing Module A	EXE
HK72-14F397-BA.vbf	Discovery Sport (L550)	IPMA - Image Processing Module A	EXE
HK72-14F397-BB.vbf	Discovery Sport (L550)	IPMA - Image Processing Module A	EXE
HK72-14F397-BC.vbf	Discovery Sport (L550)	IPMA - Image Processing Module A	EXE
HK72-14F397-BD.vbf	Discovery Sport (L550)	IPMA - Image Processing Module A	EXE
HK72-14F397-CA.vbf	Discovery Sport (L550)	IPMA - Image Processing Module A	EXE
HK72-14F397-CB.vbf	Discovery Sport (L550)	IPMA - Image Processing Module A	EXE
HK72-14F397-CC.vbf	Discovery Sport (L550)	IPMA - Image Processing Module A	EXE
HK72-14F397-CD.vbf	Discovery Sport (L550)	IPMA - Image Processing Module A	EXE
HK72-14F397-DA.vbf	Discovery Sport (L550)	IPMA - Image Processing Module A	EXE
HK72-14F397-DB.vbf	Discovery Sport (L550)	IPMA - Image Processing Module A	EXE
HK72-14F397-DC.vbf	Discovery Sport (L550)	IPMA - Image Processing Module A	EXE
HK72-14F397-DD.vbf	Discovery Sport (L550)	IPMA - Image Processing Module A	EXE

File name	Vehicle line (indicative)	Module (ECU)	Type
HK72-14F397-EA.vbf	Discovery Sport (L550)	IPMA - Image Processing Module A	EXE
HK72-14F397-FA.vbf	Discovery Sport (L550)	IPMA - Image Processing Module A	EXE
HK72-14F397-GA.vbf	Discovery Sport (L550)	IPMA - Image Processing Module A	EXE
HK72-14F397-HA.vbf	Discovery Sport (L550)	IPMA - Image Processing Module A	EXE
HK72-14F398-AA.vbf	Discovery Sport (L550)	IPMA - Image Processing Module A	EXE
HK72-14F398-AB.vbf	Discovery Sport (L550)	IPMA - Image Processing Module A	EXE
HK72-14F398-AC.vbf	Discovery Sport (L550)	IPMA - Image Processing Module A	EXE
HK72-14F398-AD.vbf	Discovery Sport (L550)	IPMA - Image Processing Module A	EXE
HK72-14F398-BA.vbf	Discovery Sport (L550)	IPMA - Image Processing Module A	EXE
HK72-14F398-BB.vbf	Discovery Sport (L550)	IPMA - Image Processing Module A	EXE
HK72-14F398-BC.vbf	Discovery Sport (L550)	IPMA - Image Processing Module A	EXE
HK72-14F398-BD.vbf	Discovery Sport (L550)	IPMA - Image Processing Module A	EXE
HK72-14F398-CA.vbf	Discovery Sport (L550)	IPMA - Image Processing Module A	EXE
HK72-14F398-DA.vbf	Discovery Sport (L550)	IPMA - Image Processing Module A	EXE
HK72-14F530-AA.vbf	Discovery Sport (L550)	GWM - Gateway Module A	EXE
HK72-14F530-AB.vbf	Discovery Sport (L550)	GWM - Gateway Module A	EXE
HK72-14F530-AC.vbf	Discovery Sport (L550)	GWM - Gateway Module A	EXE
HK72-14F530-AD.vbf	Discovery Sport (L550)	GWM - Gateway Module A	EXE
HK72-14F530-AE.vbf	Discovery Sport (L550)	GWM - Gateway Module A	EXE
HK72-14F530-AF.vbf	Discovery Sport (L550)	GWM - Gateway Module A	EXE
HK72-14F530-AG.vbf	Discovery Sport (L550)	GWM - Gateway Module A	EXE
HK72-14F531-AA.vbf	Discovery Sport (L550)	GWM - Gateway Module A	DATA
HK72-14F531-AB.vbf	Discovery Sport (L550)	GWM - Gateway Module A	DATA
HK72-14F531-AC.vbf	Discovery Sport (L550)	GWM - Gateway Module A	DATA
HK72-14F531-AD.vbf	Discovery Sport (L550)	GWM - Gateway Module A	DATA
HK72-14F531-AE.vbf	Discovery Sport (L550)	GWM - Gateway Module A	DATA
HK72-14F531-AF.vbf	Discovery Sport (L550)	GWM - Gateway Module A	DATA
HK72-14F532-AA.vbf	Discovery Sport (L550)	GWM - Gateway Module A	SBL
HK72-70713-DB.vbf	Discovery Sport (L550)	TCU - Telematic Control Unit Module	DATA
HK72-70713-DC.vbf	Discovery Sport (L550)	TCU - Telematic Control Unit Module	DATA
HK72-70713-DD.vbf	Discovery Sport (L550)	TCU - Telematic Control Unit Module	DATA
HK72-70713-EB.vbf	Discovery Sport (L550)	TCU - Telematic Control Unit Module	DATA
HK72-70713-EC.vbf	Discovery Sport (L550)	TCU - Telematic Control Unit Module	DATA
HK72-70713-ED.vbf	Discovery Sport (L550)	TCU - Telematic Control Unit Module	DATA
HK72-70713-JC.vbf	Discovery Sport (L550)	TCU - Telematic Control Unit Module	DATA
HK72-70713-JD.vbf	Discovery Sport (L550)	TCU - Telematic Control Unit Module	DATA
HK72-70713-KC.vbf	Discovery Sport (L550)	TCU - Telematic Control Unit Module	DATA
HK72-70713-KD.vbf	Discovery Sport (L550)	TCU - Telematic Control Unit Module	DATA
HK72-70713-RK.vbf	Discovery Sport (L550)	TCU - Telematic Control Unit Module	DATA
HK72-70713-RL.vbf	Discovery Sport (L550)	TCU - Telematic Control Unit Module	DATA
HK72-70713-RM.vbf	Discovery Sport (L550)	TCU - Telematic Control Unit Module	DATA
HK72-70713-RN.vbf	Discovery Sport (L550)	TCU - Telematic Control Unit Module	DATA
HK72-70713-RP.vbf	Discovery Sport (L550)	TCU - Telematic Control Unit Module	DATA
HK72-70713-RR.vbf	Discovery Sport (L550)	TCU - Telematic Control Unit Module	DATA
HK72-70713-RS.vbf	Discovery Sport (L550)	TCU - Telematic Control Unit Module	DATA
HK72-70713-SK.vbf	Discovery Sport (L550)	TCU - Telematic Control Unit Module	DATA
HK72-70713-TC.vbf	Discovery Sport (L550)	TCU - Telematic Control Unit Module	DATA
HK72-70713-TD.vbf	Discovery Sport (L550)	TCU - Telematic Control Unit Module	DATA
HK72-70713-TE.vbf	Discovery Sport (L550)	TCU - Telematic Control Unit Module	DATA
HK72-70713-TF.vbf	Discovery Sport (L550)	TCU - Telematic Control Unit Module	DATA
HK72-70713-TH.vbf	Discovery Sport (L550)	TCU - Telematic Control Unit Module	DATA
HK72-70713-TJ.vbf	Discovery Sport (L550)	TCU - Telematic Control Unit Module	DATA
HK72-70713-TK.vbf	Discovery Sport (L550)	TCU - Telematic Control Unit Module	DATA
HK72-70713-VC.vbf	Discovery Sport (L550)	TCU - Telematic Control Unit Module	DATA
HK72-70713-VD.vbf	Discovery Sport (L550)	TCU - Telematic Control Unit Module	DATA
HK72-70713-VE.vbf	Discovery Sport (L550)	TCU - Telematic Control Unit Module	DATA
HK72-70713-VF.vbf	Discovery Sport (L550)	TCU - Telematic Control Unit Module	DATA
HK72-70713-VG.vbf	Discovery Sport (L550)	TCU - Telematic Control Unit Module	DATA
HK72-70713-VH.vbf	Discovery Sport (L550)	TCU - Telematic Control Unit Module	DATA
HK72-70713-VJ.vbf	Discovery Sport (L550)	TCU - Telematic Control Unit Module	DATA
HK72-70713-XB.vbf	Discovery Sport (L550)	TCU - Telematic Control Unit Module	DATA
HK72-70713-XC.vbf	Discovery Sport (L550)	TCU - Telematic Control Unit Module	DATA
HK72-70713-XD.vbf	Discovery Sport (L550)	TCU - Telematic Control Unit Module	DATA
HK72-70713-XE.vbf	Discovery Sport (L550)	TCU - Telematic Control Unit Module	DATA
HK72-70713-XF.vbf	Discovery Sport (L550)	TCU - Telematic Control Unit Module	DATA
HK72-70713-XG.vbf	Discovery Sport (L550)	TCU - Telematic Control Unit Module	DATA
HK83-12K532-KCA.vbf	Jaguar F-Pace (X761)	PCM - Powertrain Control Module	DATA
HK83-12K532-KCB.vbf	Jaguar F-Pace (X761)	PCM - Powertrain Control Module	DATA
HK83-12K532-KCC.vbf	Jaguar F-Pace (X761)	PCM - Powertrain Control Module	DATA
HK83-12K532-KCD.vbf	Jaguar F-Pace (X761)	PCM - Powertrain Control Module	DATA
HK83-12K532-KCE.vbf	Jaguar F-Pace (X761)	PCM - Powertrain Control Module	DATA
HK83-12K532-KCF.vbf	Jaguar F-Pace (X761)	PCM - Powertrain Control Module	DATA
HK83-12K532-KFB.vbf	Jaguar F-Pace (X761)	PCM - Powertrain Control Module	DATA
HK83-12K532-KFC.vbf	Jaguar F-Pace (X761)	PCM - Powertrain Control Module	DATA
HK83-12K532-KFD.vbf	Jaguar F-Pace (X761)	PCM - Powertrain Control Module	DATA
HK83-12K532-KFE.vbf	Jaguar F-Pace (X761)	PCM - Powertrain Control Module	DATA

File name	Vehicle line (indicative)	Module (ECU)	Type
HK83-12K532-KFF.vbf	Jaguar F-Pace (X761)	PCM - Powertrain Control Module	DATA
HK83-12K532-KHF.vbf	Jaguar F-Pace (X761)	PCM - Powertrain Control Module	DATA
HK83-12K532-KJA.vbf	Jaguar F-Pace (X761)	PCM - Powertrain Control Module	DATA
HK83-12K532-KJC.vbf	Jaguar F-Pace (X761)	PCM - Powertrain Control Module	DATA
HK83-12K532-KJD.vbf	Jaguar F-Pace (X761)	PCM - Powertrain Control Module	DATA
HK83-12K532-KJE.vbf	Jaguar F-Pace (X761)	PCM - Powertrain Control Module	DATA
HK83-12K532-KJF.vbf	Jaguar F-Pace (X761)	PCM - Powertrain Control Module	DATA
HK83-12K532-KJG.vbf	Jaguar F-Pace (X761)	PCM - Powertrain Control Module	DATA
HK83-12K532-KJH.vbf	Jaguar F-Pace (X761)	PCM - Powertrain Control Module	DATA
HK83-12K532-KJJ.vbf	Jaguar F-Pace (X761)	PCM - Powertrain Control Module	DATA
HK83-12K532-KJK.vbf	Jaguar F-Pace (X761)	PCM - Powertrain Control Module	DATA
HK83-12K532-KJL.vbf	Jaguar F-Pace (X761)	PCM - Powertrain Control Module	DATA
HK83-12K532-KJN.vbf	Jaguar F-Pace (X761)	PCM - Powertrain Control Module	DATA
HK83-12K532-KJP.vbf	Jaguar F-Pace (X761)	PCM - Powertrain Control Module	DATA
HK83-12K532-KJR.vbf	Jaguar F-Pace (X761)	PCM - Powertrain Control Module	DATA
HK83-12K532-KJS.vbf	Jaguar F-Pace (X761)	PCM - Powertrain Control Module	DATA
HK83-12K532-KLA.vbf	Jaguar F-Pace (X761)	PCM - Powertrain Control Module	DATA
HK83-12K532-KLC.vbf	Jaguar F-Pace (X761)	PCM - Powertrain Control Module	DATA
HK83-12K532-KLD.vbf	Jaguar F-Pace (X761)	PCM - Powertrain Control Module	DATA
HK83-12K532-KLE.vbf	Jaguar F-Pace (X761)	PCM - Powertrain Control Module	DATA
HK83-12K532-KMB.vbf	Jaguar F-Pace (X761)	PCM - Powertrain Control Module	DATA
HK83-12K532-KMC.vbf	Jaguar F-Pace (X761)	PCM - Powertrain Control Module	DATA
HK83-12K532-KNA.vbf	Jaguar F-Pace (X761)	PCM - Powertrain Control Module	DATA
HK83-12K532-KNB.vbf	Jaguar F-Pace (X761)	PCM - Powertrain Control Module	DATA
HK83-12K532-KNC.vbf	Jaguar F-Pace (X761)	PCM - Powertrain Control Module	DATA
HK83-12K532-KND.vbf	Jaguar F-Pace (X761)	PCM - Powertrain Control Module	DATA
HK83-12K532-KNE.vbf	Jaguar F-Pace (X761)	PCM - Powertrain Control Module	DATA
HK83-12K532-KPB.vbf	Jaguar F-Pace (X761)	PCM - Powertrain Control Module	DATA
HK83-12K532-KPC.vbf	Jaguar F-Pace (X761)	PCM - Powertrain Control Module	DATA
HK83-12K532-KPD.vbf	Jaguar F-Pace (X761)	PCM - Powertrain Control Module	DATA
HK83-12K532-KPE.vbf	Jaguar F-Pace (X761)	PCM - Powertrain Control Module	DATA
HK83-12K532-KPF.vbf	Jaguar F-Pace (X761)	PCM - Powertrain Control Module	DATA
HK83-12K532-KRB.vbf	Jaguar F-Pace (X761)	PCM - Powertrain Control Module	DATA
HK83-12K532-KRC.vbf	Jaguar F-Pace (X761)	PCM - Powertrain Control Module	DATA
HK83-12K532-KRD.vbf	Jaguar F-Pace (X761)	PCM - Powertrain Control Module	DATA
HK83-12K532-KRE.vbf	Jaguar F-Pace (X761)	PCM - Powertrain Control Module	DATA
HK83-12K532-KRF.vbf	Jaguar F-Pace (X761)	PCM - Powertrain Control Module	DATA
HK83-12K532-LAA.vbf	Jaguar F-Pace (X761)	PCM - Powertrain Control Module	DATA
HK83-12K532-LAB.vbf	Jaguar F-Pace (X761)	PCM - Powertrain Control Module	DATA
HK83-12K532-LAC.vbf	Jaguar F-Pace (X761)	PCM - Powertrain Control Module	DATA
HK83-12K532-LAD.vbf	Jaguar F-Pace (X761)	PCM - Powertrain Control Module	DATA
HK83-12K532-LAE.vbf	Jaguar F-Pace (X761)	PCM - Powertrain Control Module	DATA
HK83-12K532-LAF.vbf	Jaguar F-Pace (X761)	PCM - Powertrain Control Module	DATA
HK83-12K532-LAG.vbf	Jaguar F-Pace (X761)	PCM - Powertrain Control Module	DATA
HK83-12K532-LBA.vbf	Jaguar F-Pace (X761)	PCM - Powertrain Control Module	DATA
HK83-12K532-LBB.vbf	Jaguar F-Pace (X761)	PCM - Powertrain Control Module	DATA
HK83-12K532-LBC.vbf	Jaguar F-Pace (X761)	PCM - Powertrain Control Module	DATA
HK83-12K532-LBD.vbf	Jaguar F-Pace (X761)	PCM - Powertrain Control Module	DATA
HK83-12K532-LBE.vbf	Jaguar F-Pace (X761)	PCM - Powertrain Control Module	DATA
HK83-12K532-LBF.vbf	Jaguar F-Pace (X761)	PCM - Powertrain Control Module	DATA
HK83-12K532-LBG.vbf	Jaguar F-Pace (X761)	PCM - Powertrain Control Module	DATA
HK83-12K532-LGA.vbf	Jaguar F-Pace (X761)	PCM - Powertrain Control Module	DATA
HK83-12K532-LGB.vbf	Jaguar F-Pace (X761)	PCM - Powertrain Control Module	DATA
HK83-12K532-LGC.vbf	Jaguar F-Pace (X761)	PCM - Powertrain Control Module	DATA
HK83-12K532-LGD.vbf	Jaguar F-Pace (X761)	PCM - Powertrain Control Module	DATA
HK83-12K532-LGE.vbf	Jaguar F-Pace (X761)	PCM - Powertrain Control Module	DATA
HK83-12K532-LHA.vbf	Jaguar F-Pace (X761)	PCM - Powertrain Control Module	DATA
HK83-12K532-LHB.vbf	Jaguar F-Pace (X761)	PCM - Powertrain Control Module	DATA
HK83-12K532-LHC.vbf	Jaguar F-Pace (X761)	PCM - Powertrain Control Module	DATA
HK83-12K532-LHD.vbf	Jaguar F-Pace (X761)	PCM - Powertrain Control Module	DATA
HK83-12K532-LHE.vbf	Jaguar F-Pace (X761)	PCM - Powertrain Control Module	DATA
HK83-12K532-PCC.vbf	Jaguar F-Pace (X761)	PCM - Powertrain Control Module	DATA
HK83-12K532-PCD.vbf	Jaguar F-Pace (X761)	PCM - Powertrain Control Module	DATA
HK83-12K532-PCE.vbf	Jaguar F-Pace (X761)	PCM - Powertrain Control Module	DATA
HK83-12K532-PCF.vbf	Jaguar F-Pace (X761)	PCM - Powertrain Control Module	DATA
HK83-12K532-PCG.vbf	Jaguar F-Pace (X761)	PCM - Powertrain Control Module	DATA
HK83-12K532-PCH.vbf	Jaguar F-Pace (X761)	PCM - Powertrain Control Module	DATA
HK83-12K532-PCJ.vbf	Jaguar F-Pace (X761)	PCM - Powertrain Control Module	DATA
HK83-12K532-PHC.vbf	Jaguar F-Pace (X761)	PCM - Powertrain Control Module	DATA
HK83-12K532-PHD.vbf	Jaguar F-Pace (X761)	PCM - Powertrain Control Module	DATA
HK83-12K532-PHE.vbf	Jaguar F-Pace (X761)	PCM - Powertrain Control Module	DATA
HK83-12K532-PHF.vbf	Jaguar F-Pace (X761)	PCM - Powertrain Control Module	DATA
HK83-12K532-PHG.vbf	Jaguar F-Pace (X761)	PCM - Powertrain Control Module	DATA
HK83-12K532-PHH.vbf	Jaguar F-Pace (X761)	PCM - Powertrain Control Module	DATA
HK83-14C025-AA.vbf	Jaguar F-Pace (X761)	IPC - Instrument Panel Cluster (IPC) Control Module	SBL
HK83-14C025-AB.vbf	Jaguar F-Pace (X761)	IPC - Instrument Panel Cluster (IPC) Control Module	SBL

File name	Vehicle line (indicative)	Module (ECU)	Type
HK83-14C026-AB.vbf	Jaguar F-Pace (X761)	IPC - Instrument Panel Cluster (IPC) Control Module	EXE
HK83-14C026-AC.vbf	Jaguar F-Pace (X761)	IPC - Instrument Panel Cluster (IPC) Control Module	EXE
HK83-14C026-AD.vbf	Jaguar F-Pace (X761)	IPC - Instrument Panel Cluster (IPC) Control Module	EXE
HK83-14C026-AE.vbf	Jaguar F-Pace (X761)	IPC - Instrument Panel Cluster (IPC) Control Module	EXE
HK83-14C026-AF.vbf	Jaguar F-Pace (X761)	IPC - Instrument Panel Cluster (IPC) Control Module	EXE
HK83-14C026-AG.vbf	Jaguar F-Pace (X761)	IPC - Instrument Panel Cluster (IPC) Control Module	EXE
HK83-14C026-CC.vbf	Jaguar F-Pace (X761)	IPC - Instrument Panel Cluster (IPC) Control Module	EXE
HK83-14C026-CD.vbf	Jaguar F-Pace (X761)	IPC - Instrument Panel Cluster (IPC) Control Module	EXE
HK83-14C026-CE.vbf	Jaguar F-Pace (X761)	IPC - Instrument Panel Cluster (IPC) Control Module	EXE
HK83-14C026-JA.vbf	Jaguar F-Pace (X761)	IPC - Instrument Panel Cluster (IPC) Control Module	EXE
HK83-14C026-JB.vbf	Jaguar F-Pace (X761)	IPC - Instrument Panel Cluster (IPC) Control Module	EXE
HK83-14C026-JC.vbf	Jaguar F-Pace (X761)	IPC - Instrument Panel Cluster (IPC) Control Module	EXE
HK83-14C026-JD.vbf	Jaguar F-Pace (X761)	IPC - Instrument Panel Cluster (IPC) Control Module	EXE
HK83-14C026-JDX.vbf	Jaguar F-Pace (X761)	IPC - Instrument Panel Cluster (IPC) Control Module	EXE
HK83-14C026-KA.vbf	Jaguar F-Pace (X761)	IPC - Instrument Panel Cluster (IPC) Control Module	EXE
HK83-14C026-KB.vbf	Jaguar F-Pace (X761)	IPC - Instrument Panel Cluster (IPC) Control Module	EXE
HK83-14C026-KC.vbf	Jaguar F-Pace (X761)	IPC - Instrument Panel Cluster (IPC) Control Module	EXE
HK83-14C026-LA.vbf	Jaguar F-Pace (X761)	IPC - Instrument Panel Cluster (IPC) Control Module	EXE
HK83-14C026-MA.vbf	Jaguar F-Pace (X761)	IPC - Instrument Panel Cluster (IPC) Control Module	DATA
HK83-14C026-MB.vbf	Jaguar F-Pace (X761)	IPC - Instrument Panel Cluster (IPC) Control Module	DATA
HK83-14C026-MC.vbf	Jaguar F-Pace (X761)	IPC - Instrument Panel Cluster (IPC) Control Module	DATA
HK83-14C026-MD.vbf	Jaguar F-Pace (X761)	IPC - Instrument Panel Cluster (IPC) Control Module	EXE
HK83-14C026-NA.vbf	Jaguar F-Pace (X761)	IPC - Instrument Panel Cluster (IPC) Control Module	DATA
HK83-14C026-NC.vbf	Jaguar F-Pace (X761)	IPC - Instrument Panel Cluster (IPC) Control Module	DATA
HK83-14C034-AA.vbf	Jaguar F-Pace (X761)	DSM - Driver Front Seat Module	EXE
HK83-14C036-CE.vbf	Jaguar F-Pace (X761)	ABS - Anti-Lock Brake System Control Module	EXE
HK83-14C036-CF.vbf	Jaguar F-Pace (X761)	ABS - Anti-Lock Brake System Control Module	EXE
HK83-14C036-CG.vbf	Jaguar F-Pace (X761)	ABS - Anti-Lock Brake System Control Module	EXE
HK83-14C036-DE.vbf	Jaguar F-Pace (X761)	ABS - Anti-Lock Brake System Control Module	EXE
HK83-14C036-DF.vbf	Jaguar F-Pace (X761)	ABS - Anti-Lock Brake System Control Module	EXE
HK83-14C036-DG.vbf	Jaguar F-Pace (X761)	ABS - Anti-Lock Brake System Control Module	EXE
HK83-14C037-AAD.vbf	Jaguar F-Pace (X761)	SPCM - Secondary Powertrain Control Module	EXE
HK83-14C037-AAF.vbf	Jaguar F-Pace (X761)	SPCM - Secondary Powertrain Control Module	EXE
HK83-14C037-AAG.vbf	Jaguar F-Pace (X761)	SPCM - Secondary Powertrain Control Module	DATA
HK83-14C037-AAJ.vbf	Jaguar F-Pace (X761)	SPCM - Secondary Powertrain Control Module	DATA
HK83-14C037-ABD.vbf	Jaguar F-Pace (X761)	SPCM - Secondary Powertrain Control Module	EXE
HK83-14C037-ABF.vbf	Jaguar F-Pace (X761)	SPCM - Secondary Powertrain Control Module	EXE
HK83-14C037-ABG.vbf	Jaguar F-Pace (X761)	SPCM - Secondary Powertrain Control Module	DATA
HK83-14C037-ABJ.vbf	Jaguar F-Pace (X761)	SPCM - Secondary Powertrain Control Module	DATA
HK83-14C037-ACD.vbf	Jaguar F-Pace (X761)	SPCM - Secondary Powertrain Control Module	EXE
HK83-14C037-ACF.vbf	Jaguar F-Pace (X761)	SPCM - Secondary Powertrain Control Module	EXE
HK83-14C037-ACG.vbf	Jaguar F-Pace (X761)	SPCM - Secondary Powertrain Control Module	DATA
HK83-14C037-ACJ.vbf	Jaguar F-Pace (X761)	SPCM - Secondary Powertrain Control Module	DATA
HK83-14C037-ADD.vbf	Jaguar F-Pace (X761)	SPCM - Secondary Powertrain Control Module	EXE
HK83-14C037-ADF.vbf	Jaguar F-Pace (X761)	SPCM - Secondary Powertrain Control Module	EXE
HK83-14C037-ADG.vbf	Jaguar F-Pace (X761)	SPCM - Secondary Powertrain Control Module	DATA
HK83-14C037-ADJ.vbf	Jaguar F-Pace (X761)	SPCM - Secondary Powertrain Control Module	DATA
HK83-14C037-AED.vbf	Jaguar F-Pace (X761)	SPCM - Secondary Powertrain Control Module	EXE
HK83-14C037-AEF.vbf	Jaguar F-Pace (X761)	SPCM - Secondary Powertrain Control Module	EXE
HK83-14C037-AEG.vbf	Jaguar F-Pace (X761)	SPCM - Secondary Powertrain Control Module	DATA
HK83-14C037-AEJ.vbf	Jaguar F-Pace (X761)	SPCM - Secondary Powertrain Control Module	DATA
HK83-14C037-AHD.vbf	Jaguar F-Pace (X761)	SPCM - Secondary Powertrain Control Module	EXE
HK83-14C037-AHF.vbf	Jaguar F-Pace (X761)	SPCM - Secondary Powertrain Control Module	EXE
HK83-14C037-AHG.vbf	Jaguar F-Pace (X761)	SPCM - Secondary Powertrain Control Module	DATA
HK83-14C037-AHJ.vbf	Jaguar F-Pace (X761)	SPCM - Secondary Powertrain Control Module	DATA
HK83-14C037-AKD.vbf	Jaguar F-Pace (X761)	SPCM - Secondary Powertrain Control Module	EXE
HK83-14C037-AKF.vbf	Jaguar F-Pace (X761)	SPCM - Secondary Powertrain Control Module	EXE
HK83-14C037-AKG.vbf	Jaguar F-Pace (X761)	SPCM - Secondary Powertrain Control Module	DATA
HK83-14C037-AKJ.vbf	Jaguar F-Pace (X761)	SPCM - Secondary Powertrain Control Module	DATA
HK83-14C037-AMD.vbf	Jaguar F-Pace (X761)	SPCM - Secondary Powertrain Control Module	EXE
HK83-14C037-AMF.vbf	Jaguar F-Pace (X761)	SPCM - Secondary Powertrain Control Module	EXE
HK83-14C037-AMG.vbf	Jaguar F-Pace (X761)	SPCM - Secondary Powertrain Control Module	DATA
HK83-14C037-AMJ.vbf	Jaguar F-Pace (X761)	SPCM - Secondary Powertrain Control Module	DATA
HK83-14C037-ARD.vbf	Jaguar F-Pace (X761)	SPCM - Secondary Powertrain Control Module	EXE
HK83-14C037-ARF.vbf	Jaguar F-Pace (X761)	SPCM - Secondary Powertrain Control Module	EXE
HK83-14C037-ARG.vbf	Jaguar F-Pace (X761)	SPCM - Secondary Powertrain Control Module	DATA
HK83-14C037-ARJ.vbf	Jaguar F-Pace (X761)	SPCM - Secondary Powertrain Control Module	DATA
HK83-14C037-ATD.vbf	Jaguar F-Pace (X761)	SPCM - Secondary Powertrain Control Module	EXE
HK83-14C037-ATF.vbf	Jaguar F-Pace (X761)	SPCM - Secondary Powertrain Control Module	EXE
HK83-14C037-ATG.vbf	Jaguar F-Pace (X761)	SPCM - Secondary Powertrain Control Module	DATA
HK83-14C037-ATJ.vbf	Jaguar F-Pace (X761)	SPCM - Secondary Powertrain Control Module	DATA
HK83-14C037-AUD.vbf	Jaguar F-Pace (X761)	SPCM - Secondary Powertrain Control Module	EXE
HK83-14C037-AUF.vbf	Jaguar F-Pace (X761)	SPCM - Secondary Powertrain Control Module	EXE
HK83-14C037-AUG.vbf	Jaguar F-Pace (X761)	SPCM - Secondary Powertrain Control Module	DATA
HK83-14C037-AUJ.vbf	Jaguar F-Pace (X761)	SPCM - Secondary Powertrain Control Module	DATA
HK83-14C037-AXD.vbf	Jaguar F-Pace (X761)	SPCM - Secondary Powertrain Control Module	EXE

File name	Vehicle line (indicative)	Module (ECU)	Type
HK83-14C037-AXF.vbf	Jaguar F-Pace (X761)	SPCM - Secondary Powertrain Control Module	EXE
HK83-14C037-AXG.vbf	Jaguar F-Pace (X761)	SPCM - Secondary Powertrain Control Module	DATA
HK83-14C037-AXJ.vbf	Jaguar F-Pace (X761)	SPCM - Secondary Powertrain Control Module	DATA
HK83-14C037-AZD.vbf	Jaguar F-Pace (X761)	SPCM - Secondary Powertrain Control Module	EXE
HK83-14C037-AZF.vbf	Jaguar F-Pace (X761)	SPCM - Secondary Powertrain Control Module	EXE
HK83-14C037-AZG.vbf	Jaguar F-Pace (X761)	SPCM - Secondary Powertrain Control Module	DATA
HK83-14C037-AZJ.vbf	Jaguar F-Pace (X761)	SPCM - Secondary Powertrain Control Module	DATA
HK83-14C037-BAD.vbf	Jaguar F-Pace (X761)	SPCM - Secondary Powertrain Control Module	EXE
HK83-14C037-BAF.vbf	Jaguar F-Pace (X761)	SPCM - Secondary Powertrain Control Module	EXE
HK83-14C037-BAG.vbf	Jaguar F-Pace (X761)	SPCM - Secondary Powertrain Control Module	DATA
HK83-14C037-BAJ.vbf	Jaguar F-Pace (X761)	SPCM - Secondary Powertrain Control Module	DATA
HK83-14C037-BHE.vbf	Jaguar F-Pace (X761)	ABS - Anti-Lock Brake System Control Module	DATA
HK83-14C037-BHF.vbf	Jaguar F-Pace (X761)	ABS - Anti-Lock Brake System Control Module	DATA
HK83-14C037-BHG.vbf	Jaguar F-Pace (X761)	ABS - Anti-Lock Brake System Control Module	DATA
HK83-14C037-BHH.vbf	Jaguar F-Pace (X761)	ABS - Anti-Lock Brake System Control Module	DATA
HK83-14C037-BHJ.vbf	Jaguar F-Pace (X761)	ABS - Anti-Lock Brake System Control Module	DATA
HK83-14C037-BKE.vbf	Jaguar F-Pace (X761)	ABS - Anti-Lock Brake System Control Module	DATA
HK83-14C037-BKF.vbf	Jaguar F-Pace (X761)	ABS - Anti-Lock Brake System Control Module	DATA
HK83-14C037-BKG.vbf	Jaguar F-Pace (X761)	ABS - Anti-Lock Brake System Control Module	DATA
HK83-14C037-BKH.vbf	Jaguar F-Pace (X761)	ABS - Anti-Lock Brake System Control Module	DATA
HK83-14C037-BKJ.vbf	Jaguar F-Pace (X761)	ABS - Anti-Lock Brake System Control Module	DATA
HK83-14C037-BLE.vbf	Jaguar F-Pace (X761)	ABS - Anti-Lock Brake System Control Module	DATA
HK83-14C037-BLF.vbf	Jaguar F-Pace (X761)	ABS - Anti-Lock Brake System Control Module	DATA
HK83-14C037-BLG.vbf	Jaguar F-Pace (X761)	ABS - Anti-Lock Brake System Control Module	DATA
HK83-14C037-BLH.vbf	Jaguar F-Pace (X761)	ABS - Anti-Lock Brake System Control Module	DATA
HK83-14C037-BLJ.vbf	Jaguar F-Pace (X761)	ABS - Anti-Lock Brake System Control Module	DATA
HK83-14C037-BLK.vbf	Jaguar F-Pace (X761)	ABS - Anti-Lock Brake System Control Module	DATA
HK83-14C037-BME.vbf	Jaguar F-Pace (X761)	ABS - Anti-Lock Brake System Control Module	DATA
HK83-14C037-BMF.vbf	Jaguar F-Pace (X761)	ABS - Anti-Lock Brake System Control Module	DATA
HK83-14C037-BMG.vbf	Jaguar F-Pace (X761)	ABS - Anti-Lock Brake System Control Module	DATA
HK83-14C037-BMH.vbf	Jaguar F-Pace (X761)	ABS - Anti-Lock Brake System Control Module	DATA
HK83-14C037-BMJ.vbf	Jaguar F-Pace (X761)	ABS - Anti-Lock Brake System Control Module	DATA
HK83-14C037-BMK.vbf	Jaguar F-Pace (X761)	ABS - Anti-Lock Brake System Control Module	DATA
HK83-14C037-BXE.vbf	Jaguar F-Pace (X761)	ABS - Anti-Lock Brake System Control Module	DATA
HK83-14C037-BXF.vbf	Jaguar F-Pace (X761)	ABS - Anti-Lock Brake System Control Module	DATA
HK83-14C037-BXG.vbf	Jaguar F-Pace (X761)	ABS - Anti-Lock Brake System Control Module	DATA
HK83-14C037-BXH.vbf	Jaguar F-Pace (X761)	ABS - Anti-Lock Brake System Control Module	DATA
HK83-14C037-BXJ.vbf	Jaguar F-Pace (X761)	ABS - Anti-Lock Brake System Control Module	DATA
HK83-14C037-BXK.vbf	Jaguar F-Pace (X761)	ABS - Anti-Lock Brake System Control Module	DATA
HK83-14C037-BXL.vbf	Jaguar F-Pace (X761)	ABS - Anti-Lock Brake System Control Module	DATA
HK83-14C037-BYE.vbf	Jaguar F-Pace (X761)	ABS - Anti-Lock Brake System Control Module	DATA
HK83-14C037-BYF.vbf	Jaguar F-Pace (X761)	ABS - Anti-Lock Brake System Control Module	DATA
HK83-14C037-BYG.vbf	Jaguar F-Pace (X761)	ABS - Anti-Lock Brake System Control Module	DATA
HK83-14C037-BYH.vbf	Jaguar F-Pace (X761)	ABS - Anti-Lock Brake System Control Module	DATA
HK83-14C037-BYJ.vbf	Jaguar F-Pace (X761)	ABS - Anti-Lock Brake System Control Module	DATA
HK83-14C037-BYK.vbf	Jaguar F-Pace (X761)	ABS - Anti-Lock Brake System Control Module	DATA
HK83-14C037-BYL.vbf	Jaguar F-Pace (X761)	ABS - Anti-Lock Brake System Control Module	DATA
HK83-14C037-CAE.vbf	Jaguar F-Pace (X761)	ABS - Anti-Lock Brake System Control Module	DATA
HK83-14C037-CAF.vbf	Jaguar F-Pace (X761)	ABS - Anti-Lock Brake System Control Module	DATA
HK83-14C037-CAG.vbf	Jaguar F-Pace (X761)	ABS - Anti-Lock Brake System Control Module	DATA
HK83-14C037-CAH.vbf	Jaguar F-Pace (X761)	ABS - Anti-Lock Brake System Control Module	DATA
HK83-14C037-CAJ.vbf	Jaguar F-Pace (X761)	ABS - Anti-Lock Brake System Control Module	DATA
HK83-14C037-CBE.vbf	Jaguar F-Pace (X761)	ABS - Anti-Lock Brake System Control Module	DATA
HK83-14C037-CBF.vbf	Jaguar F-Pace (X761)	ABS - Anti-Lock Brake System Control Module	DATA
HK83-14C037-CBG.vbf	Jaguar F-Pace (X761)	ABS - Anti-Lock Brake System Control Module	DATA
HK83-14C037-CBH.vbf	Jaguar F-Pace (X761)	ABS - Anti-Lock Brake System Control Module	DATA
HK83-14C037-CBJ.vbf	Jaguar F-Pace (X761)	ABS - Anti-Lock Brake System Control Module	DATA
HK83-14C037-CBK.vbf	Jaguar F-Pace (X761)	ABS - Anti-Lock Brake System Control Module	DATA
HK83-14C037-CCE.vbf	Jaguar F-Pace (X761)	ABS - Anti-Lock Brake System Control Module	DATA
HK83-14C037-CCF.vbf	Jaguar F-Pace (X761)	ABS - Anti-Lock Brake System Control Module	DATA
HK83-14C037-CCG.vbf	Jaguar F-Pace (X761)	ABS - Anti-Lock Brake System Control Module	DATA
HK83-14C037-CCH.vbf	Jaguar F-Pace (X761)	ABS - Anti-Lock Brake System Control Module	DATA
HK83-14C037-CCJ.vbf	Jaguar F-Pace (X761)	ABS - Anti-Lock Brake System Control Module	DATA
HK83-14C037-CDE.vbf	Jaguar F-Pace (X761)	ABS - Anti-Lock Brake System Control Module	DATA
HK83-14C037-CDF.vbf	Jaguar F-Pace (X761)	ABS - Anti-Lock Brake System Control Module	DATA
HK83-14C037-CDG.vbf	Jaguar F-Pace (X761)	ABS - Anti-Lock Brake System Control Module	DATA
HK83-14C037-CDH.vbf	Jaguar F-Pace (X761)	ABS - Anti-Lock Brake System Control Module	DATA
HK83-14C037-CDJ.vbf	Jaguar F-Pace (X761)	ABS - Anti-Lock Brake System Control Module	DATA
HK83-14C037-CDK.vbf	Jaguar F-Pace (X761)	ABS - Anti-Lock Brake System Control Module	DATA
HK83-14C037-CEE.vbf	Jaguar F-Pace (X761)	ABS - Anti-Lock Brake System Control Module	DATA
HK83-14C037-CEF.vbf	Jaguar F-Pace (X761)	ABS - Anti-Lock Brake System Control Module	DATA
HK83-14C037-CEG.vbf	Jaguar F-Pace (X761)	ABS - Anti-Lock Brake System Control Module	DATA
HK83-14C037-CEH.vbf	Jaguar F-Pace (X761)	ABS - Anti-Lock Brake System Control Module	DATA
HK83-14C037-CEJ.vbf	Jaguar F-Pace (X761)	ABS - Anti-Lock Brake System Control Module	DATA
HK83-14C037-CHE.vbf	Jaguar F-Pace (X761)	ABS - Anti-Lock Brake System Control Module	DATA
HK83-14C037-CHF.vbf	Jaguar F-Pace (X761)	ABS - Anti-Lock Brake System Control Module	DATA

File name	Vehicle line (indicative)	Module (ECU)	Type
HK83-14C037-CHG.vbf	Jaguar F-Pace (X761)	ABS - Anti-Lock Brake System Control Module	DATA
HK83-14C037-CHH.vbf	Jaguar F-Pace (X761)	ABS - Anti-Lock Brake System Control Module	DATA
HK83-14C037-CHJ.vbf	Jaguar F-Pace (X761)	ABS - Anti-Lock Brake System Control Module	DATA
HK83-14C037-CKE.vbf	Jaguar F-Pace (X761)	ABS - Anti-Lock Brake System Control Module	DATA
HK83-14C037-CKF.vbf	Jaguar F-Pace (X761)	ABS - Anti-Lock Brake System Control Module	DATA
HK83-14C037-CKG.vbf	Jaguar F-Pace (X761)	ABS - Anti-Lock Brake System Control Module	DATA
HK83-14C037-CKH.vbf	Jaguar F-Pace (X761)	ABS - Anti-Lock Brake System Control Module	DATA
HK83-14C037-CKJ.vbf	Jaguar F-Pace (X761)	ABS - Anti-Lock Brake System Control Module	DATA
HK83-14C037-CKK.vbf	Jaguar F-Pace (X761)	ABS - Anti-Lock Brake System Control Module	DATA
HK83-14C037-CME.vbf	Jaguar F-Pace (X761)	ABS - Anti-Lock Brake System Control Module	DATA
HK83-14C037-CMF.vbf	Jaguar F-Pace (X761)	ABS - Anti-Lock Brake System Control Module	DATA
HK83-14C037-CMG.vbf	Jaguar F-Pace (X761)	ABS - Anti-Lock Brake System Control Module	DATA
HK83-14C037-CMH.vbf	Jaguar F-Pace (X761)	ABS - Anti-Lock Brake System Control Module	DATA
HK83-14C037-CMJ.vbf	Jaguar F-Pace (X761)	ABS - Anti-Lock Brake System Control Module	DATA
HK83-14C037-CMK.vbf	Jaguar F-Pace (X761)	ABS - Anti-Lock Brake System Control Module	DATA
HK83-14C037-CTE.vbf	Jaguar F-Pace (X761)	ABS - Anti-Lock Brake System Control Module	DATA
HK83-14C037-CTF.vbf	Jaguar F-Pace (X761)	ABS - Anti-Lock Brake System Control Module	DATA
HK83-14C037-CTG.vbf	Jaguar F-Pace (X761)	ABS - Anti-Lock Brake System Control Module	DATA
HK83-14C037-CTH.vbf	Jaguar F-Pace (X761)	ABS - Anti-Lock Brake System Control Module	DATA
HK83-14C037-CTJ.vbf	Jaguar F-Pace (X761)	ABS - Anti-Lock Brake System Control Module	DATA
HK83-14C037-CTK.vbf	Jaguar F-Pace (X761)	ABS - Anti-Lock Brake System Control Module	DATA
HK83-14C037-CUE.vbf	Jaguar F-Pace (X761)	ABS - Anti-Lock Brake System Control Module	DATA
HK83-14C037-CUF.vbf	Jaguar F-Pace (X761)	ABS - Anti-Lock Brake System Control Module	DATA
HK83-14C037-CUG.vbf	Jaguar F-Pace (X761)	ABS - Anti-Lock Brake System Control Module	DATA
HK83-14C037-CUH.vbf	Jaguar F-Pace (X761)	ABS - Anti-Lock Brake System Control Module	DATA
HK83-14C037-CUJ.vbf	Jaguar F-Pace (X761)	ABS - Anti-Lock Brake System Control Module	DATA
HK83-14C037-CUK.vbf	Jaguar F-Pace (X761)	ABS - Anti-Lock Brake System Control Module	DATA
HK83-14C037-CXE.vbf	Jaguar F-Pace (X761)	ABS - Anti-Lock Brake System Control Module	DATA
HK83-14C037-CXF.vbf	Jaguar F-Pace (X761)	ABS - Anti-Lock Brake System Control Module	DATA
HK83-14C037-CXG.vbf	Jaguar F-Pace (X761)	ABS - Anti-Lock Brake System Control Module	DATA
HK83-14C037-CXH.vbf	Jaguar F-Pace (X761)	ABS - Anti-Lock Brake System Control Module	DATA
HK83-14C037-CXJ.vbf	Jaguar F-Pace (X761)	ABS - Anti-Lock Brake System Control Module	DATA
HK83-14C037-CXK.vbf	Jaguar F-Pace (X761)	ABS - Anti-Lock Brake System Control Module	DATA
HK83-14C037-CZE.vbf	Jaguar F-Pace (X761)	ABS - Anti-Lock Brake System Control Module	DATA
HK83-14C037-CZF.vbf	Jaguar F-Pace (X761)	ABS - Anti-Lock Brake System Control Module	DATA
HK83-14C037-CZG.vbf	Jaguar F-Pace (X761)	ABS - Anti-Lock Brake System Control Module	DATA
HK83-14C037-CZH.vbf	Jaguar F-Pace (X761)	ABS - Anti-Lock Brake System Control Module	DATA
HK83-14C037-CZJ.vbf	Jaguar F-Pace (X761)	ABS - Anti-Lock Brake System Control Module	DATA
HK83-14C037-CZK.vbf	Jaguar F-Pace (X761)	ABS - Anti-Lock Brake System Control Module	DATA
HK83-14C037-DAE.vbf	Jaguar F-Pace (X761)	ABS - Anti-Lock Brake System Control Module	DATA
HK83-14C037-DAF.vbf	Jaguar F-Pace (X761)	ABS - Anti-Lock Brake System Control Module	DATA
HK83-14C037-DAG.vbf	Jaguar F-Pace (X761)	ABS - Anti-Lock Brake System Control Module	DATA
HK83-14C037-DAH.vbf	Jaguar F-Pace (X761)	ABS - Anti-Lock Brake System Control Module	DATA
HK83-14C037-DAJ.vbf	Jaguar F-Pace (X761)	ABS - Anti-Lock Brake System Control Module	DATA
HK83-14C037-DBE.vbf	Jaguar F-Pace (X761)	ABS - Anti-Lock Brake System Control Module	DATA
HK83-14C037-DBF.vbf	Jaguar F-Pace (X761)	ABS - Anti-Lock Brake System Control Module	DATA
HK83-14C037-DBG.vbf	Jaguar F-Pace (X761)	ABS - Anti-Lock Brake System Control Module	DATA
HK83-14C037-DBH.vbf	Jaguar F-Pace (X761)	ABS - Anti-Lock Brake System Control Module	DATA
HK83-14C037-DBJ.vbf	Jaguar F-Pace (X761)	ABS - Anti-Lock Brake System Control Module	DATA
HK83-14C037-DBK.vbf	Jaguar F-Pace (X761)	ABS - Anti-Lock Brake System Control Module	DATA
HK83-14C037-DCE.vbf	Jaguar F-Pace (X761)	ABS - Anti-Lock Brake System Control Module	DATA
HK83-14C037-DCF.vbf	Jaguar F-Pace (X761)	ABS - Anti-Lock Brake System Control Module	DATA
HK83-14C037-DCG.vbf	Jaguar F-Pace (X761)	ABS - Anti-Lock Brake System Control Module	DATA
HK83-14C037-DCH.vbf	Jaguar F-Pace (X761)	ABS - Anti-Lock Brake System Control Module	DATA
HK83-14C037-DCJ.vbf	Jaguar F-Pace (X761)	ABS - Anti-Lock Brake System Control Module	DATA
HK83-14C037-DCK.vbf	Jaguar F-Pace (X761)	ABS - Anti-Lock Brake System Control Module	DATA
HK83-14C037-MED.vbf	Jaguar F-Pace (X761)	SPCM - Secondary Powertrain Control Module	EXE
HK83-14C037-MEF.vbf	Jaguar F-Pace (X761)	SPCM - Secondary Powertrain Control Module	EXE
HK83-14C037-MEG.vbf	Jaguar F-Pace (X761)	SPCM - Secondary Powertrain Control Module	DATA
HK83-14C037-MEJ.vbf	Jaguar F-Pace (X761)	SPCM - Secondary Powertrain Control Module	DATA
HK83-14C037-MHD.vbf	Jaguar F-Pace (X761)	SPCM - Secondary Powertrain Control Module	EXE
HK83-14C037-MHF.vbf	Jaguar F-Pace (X761)	SPCM - Secondary Powertrain Control Module	EXE
HK83-14C037-MHG.vbf	Jaguar F-Pace (X761)	SPCM - Secondary Powertrain Control Module	DATA
HK83-14C037-MHJ.vbf	Jaguar F-Pace (X761)	SPCM - Secondary Powertrain Control Module	DATA
HK83-14C037-MKD.vbf	Jaguar F-Pace (X761)	SPCM - Secondary Powertrain Control Module	EXE
HK83-14C037-MKF.vbf	Jaguar F-Pace (X761)	SPCM - Secondary Powertrain Control Module	EXE
HK83-14C037-MKG.vbf	Jaguar F-Pace (X761)	SPCM - Secondary Powertrain Control Module	DATA
HK83-14C037-MKJ.vbf	Jaguar F-Pace (X761)	SPCM - Secondary Powertrain Control Module	DATA
HK83-14C037-MMD.vbf	Jaguar F-Pace (X761)	SPCM - Secondary Powertrain Control Module	EXE
HK83-14C037-MMF.vbf	Jaguar F-Pace (X761)	SPCM - Secondary Powertrain Control Module	EXE
HK83-14C037-MMG.vbf	Jaguar F-Pace (X761)	SPCM - Secondary Powertrain Control Module	DATA
HK83-14C037-MMJ.vbf	Jaguar F-Pace (X761)	SPCM - Secondary Powertrain Control Module	DATA
HK83-14C037-MRD.vbf	Jaguar F-Pace (X761)	SPCM - Secondary Powertrain Control Module	EXE
HK83-14C037-MRF.vbf	Jaguar F-Pace (X761)	SPCM - Secondary Powertrain Control Module	EXE
HK83-14C037-MRG.vbf	Jaguar F-Pace (X761)	SPCM - Secondary Powertrain Control Module	DATA
HK83-14C037-MRJ.vbf	Jaguar F-Pace (X761)	SPCM - Secondary Powertrain Control Module	DATA

File name	Vehicle line (indicative)	Module (ECU)	Type
HK83-14C037-MTD.vbf	Jaguar F-Pace (X761)	SPCM - Secondary Powertrain Control Module	EXE
HK83-14C037-MTF.vbf	Jaguar F-Pace (X761)	SPCM - Secondary Powertrain Control Module	EXE
HK83-14C037-MTG.vbf	Jaguar F-Pace (X761)	SPCM - Secondary Powertrain Control Module	DATA
HK83-14C037-MTJ.vbf	Jaguar F-Pace (X761)	SPCM - Secondary Powertrain Control Module	DATA
HK83-14C037-MUD.vbf	Jaguar F-Pace (X761)	SPCM - Secondary Powertrain Control Module	EXE
HK83-14C037-MUF.vbf	Jaguar F-Pace (X761)	SPCM - Secondary Powertrain Control Module	EXE
HK83-14C037-MUG.vbf	Jaguar F-Pace (X761)	SPCM - Secondary Powertrain Control Module	DATA
HK83-14C037-MUJ.vbf	Jaguar F-Pace (X761)	SPCM - Secondary Powertrain Control Module	DATA
HK83-14C037-MXD.vbf	Jaguar F-Pace (X761)	SPCM - Secondary Powertrain Control Module	EXE
HK83-14C037-MXF.vbf	Jaguar F-Pace (X761)	SPCM - Secondary Powertrain Control Module	EXE
HK83-14C037-MXG.vbf	Jaguar F-Pace (X761)	SPCM - Secondary Powertrain Control Module	DATA
HK83-14C037-MXJ.vbf	Jaguar F-Pace (X761)	SPCM - Secondary Powertrain Control Module	DATA
HK83-14C037-MZD.vbf	Jaguar F-Pace (X761)	SPCM - Secondary Powertrain Control Module	EXE
HK83-14C037-MZF.vbf	Jaguar F-Pace (X761)	SPCM - Secondary Powertrain Control Module	EXE
HK83-14C037-MZG.vbf	Jaguar F-Pace (X761)	SPCM - Secondary Powertrain Control Module	DATA
HK83-14C037-MZJ.vbf	Jaguar F-Pace (X761)	SPCM - Secondary Powertrain Control Module	DATA
HK83-14C037-NHE.vbf	Jaguar F-Pace (X761)	ABS - Anti-Lock Brake System Control Module	DATA
HK83-14C037-NHF.vbf	Jaguar F-Pace (X761)	ABS - Anti-Lock Brake System Control Module	DATA
HK83-14C037-NHG.vbf	Jaguar F-Pace (X761)	ABS - Anti-Lock Brake System Control Module	DATA
HK83-14C037-NHH.vbf	Jaguar F-Pace (X761)	ABS - Anti-Lock Brake System Control Module	DATA
HK83-14C037-NHJ.vbf	Jaguar F-Pace (X761)	ABS - Anti-Lock Brake System Control Module	DATA
HK83-14C037-NKE.vbf	Jaguar F-Pace (X761)	ABS - Anti-Lock Brake System Control Module	DATA
HK83-14C037-NKF.vbf	Jaguar F-Pace (X761)	ABS - Anti-Lock Brake System Control Module	DATA
HK83-14C037-NKG.vbf	Jaguar F-Pace (X761)	ABS - Anti-Lock Brake System Control Module	DATA
HK83-14C037-NKH.vbf	Jaguar F-Pace (X761)	ABS - Anti-Lock Brake System Control Module	DATA
HK83-14C037-NKJ.vbf	Jaguar F-Pace (X761)	ABS - Anti-Lock Brake System Control Module	DATA
HK83-14C037-NLE.vbf	Jaguar F-Pace (X761)	ABS - Anti-Lock Brake System Control Module	DATA
HK83-14C037-NLF.vbf	Jaguar F-Pace (X761)	ABS - Anti-Lock Brake System Control Module	DATA
HK83-14C037-NLG.vbf	Jaguar F-Pace (X761)	ABS - Anti-Lock Brake System Control Module	DATA
HK83-14C037-NLH.vbf	Jaguar F-Pace (X761)	ABS - Anti-Lock Brake System Control Module	DATA
HK83-14C037-NLJ.vbf	Jaguar F-Pace (X761)	ABS - Anti-Lock Brake System Control Module	DATA
HK83-14C037-NLK.vbf	Jaguar F-Pace (X761)	ABS - Anti-Lock Brake System Control Module	DATA
HK83-14C037-NME.vbf	Jaguar F-Pace (X761)	ABS - Anti-Lock Brake System Control Module	DATA
HK83-14C037-NMF.vbf	Jaguar F-Pace (X761)	ABS - Anti-Lock Brake System Control Module	DATA
HK83-14C037-NMG.vbf	Jaguar F-Pace (X761)	ABS - Anti-Lock Brake System Control Module	DATA
HK83-14C037-NMH.vbf	Jaguar F-Pace (X761)	ABS - Anti-Lock Brake System Control Module	DATA
HK83-14C037-NMJ.vbf	Jaguar F-Pace (X761)	ABS - Anti-Lock Brake System Control Module	DATA
HK83-14C037-NMK.vbf	Jaguar F-Pace (X761)	ABS - Anti-Lock Brake System Control Module	DATA
HK83-14C037-NXE.vbf	Jaguar F-Pace (X761)	ABS - Anti-Lock Brake System Control Module	DATA
HK83-14C037-NXF.vbf	Jaguar F-Pace (X761)	ABS - Anti-Lock Brake System Control Module	DATA
HK83-14C037-NXG.vbf	Jaguar F-Pace (X761)	ABS - Anti-Lock Brake System Control Module	DATA
HK83-14C037-NXH.vbf	Jaguar F-Pace (X761)	ABS - Anti-Lock Brake System Control Module	DATA
HK83-14C037-NXJ.vbf	Jaguar F-Pace (X761)	ABS - Anti-Lock Brake System Control Module	DATA
HK83-14C037-NXK.vbf	Jaguar F-Pace (X761)	ABS - Anti-Lock Brake System Control Module	DATA
HK83-14C037-NXL.vbf	Jaguar F-Pace (X761)	ABS - Anti-Lock Brake System Control Module	DATA
HK83-14C037-NYE.vbf	Jaguar F-Pace (X761)	ABS - Anti-Lock Brake System Control Module	DATA
HK83-14C037-NYF.vbf	Jaguar F-Pace (X761)	ABS - Anti-Lock Brake System Control Module	DATA
HK83-14C037-NYG.vbf	Jaguar F-Pace (X761)	ABS - Anti-Lock Brake System Control Module	DATA
HK83-14C037-NYH.vbf	Jaguar F-Pace (X761)	ABS - Anti-Lock Brake System Control Module	DATA
HK83-14C037-NYJ.vbf	Jaguar F-Pace (X761)	ABS - Anti-Lock Brake System Control Module	DATA
HK83-14C037-NYK.vbf	Jaguar F-Pace (X761)	ABS - Anti-Lock Brake System Control Module	DATA
HK83-14C037-PEE.vbf	Jaguar F-Pace (X761)	ABS - Anti-Lock Brake System Control Module	DATA
HK83-14C037-PEF.vbf	Jaguar F-Pace (X761)	ABS - Anti-Lock Brake System Control Module	DATA
HK83-14C037-PEG.vbf	Jaguar F-Pace (X761)	ABS - Anti-Lock Brake System Control Module	DATA
HK83-14C037-PEH.vbf	Jaguar F-Pace (X761)	ABS - Anti-Lock Brake System Control Module	DATA
HK83-14C037-PEJ.vbf	Jaguar F-Pace (X761)	ABS - Anti-Lock Brake System Control Module	DATA
HK83-14C037-PHE.vbf	Jaguar F-Pace (X761)	ABS - Anti-Lock Brake System Control Module	DATA
HK83-14C037-PHF.vbf	Jaguar F-Pace (X761)	ABS - Anti-Lock Brake System Control Module	DATA
HK83-14C037-PHG.vbf	Jaguar F-Pace (X761)	ABS - Anti-Lock Brake System Control Module	DATA
HK83-14C037-PHH.vbf	Jaguar F-Pace (X761)	ABS - Anti-Lock Brake System Control Module	DATA
HK83-14C037-PHJ.vbf	Jaguar F-Pace (X761)	ABS - Anti-Lock Brake System Control Module	DATA
HK83-14C037-PKE.vbf	Jaguar F-Pace (X761)	ABS - Anti-Lock Brake System Control Module	DATA
HK83-14C037-PKF.vbf	Jaguar F-Pace (X761)	ABS - Anti-Lock Brake System Control Module	DATA
HK83-14C037-PKG.vbf	Jaguar F-Pace (X761)	ABS - Anti-Lock Brake System Control Module	DATA
HK83-14C037-PKH.vbf	Jaguar F-Pace (X761)	ABS - Anti-Lock Brake System Control Module	DATA
HK83-14C037-PKJ.vbf	Jaguar F-Pace (X761)	ABS - Anti-Lock Brake System Control Module	DATA
HK83-14C037-PKK.vbf	Jaguar F-Pace (X761)	ABS - Anti-Lock Brake System Control Module	DATA
HK83-14C037-PME.vbf	Jaguar F-Pace (X761)	ABS - Anti-Lock Brake System Control Module	DATA
HK83-14C037-PMF.vbf	Jaguar F-Pace (X761)	ABS - Anti-Lock Brake System Control Module	DATA
HK83-14C037-PMG.vbf	Jaguar F-Pace (X761)	ABS - Anti-Lock Brake System Control Module	DATA
HK83-14C037-PMH.vbf	Jaguar F-Pace (X761)	ABS - Anti-Lock Brake System Control Module	DATA
HK83-14C037-PMJ.vbf	Jaguar F-Pace (X761)	ABS - Anti-Lock Brake System Control Module	DATA
HK83-14C037-PMK.vbf	Jaguar F-Pace (X761)	ABS - Anti-Lock Brake System Control Module	DATA
HK83-14C037-PTE.vbf	Jaguar F-Pace (X761)	ABS - Anti-Lock Brake System Control Module	DATA
HK83-14C037-PTF.vbf	Jaguar F-Pace (X761)	ABS - Anti-Lock Brake System Control Module	DATA
HK83-14C037-PTG.vbf	Jaguar F-Pace (X761)	ABS - Anti-Lock Brake System Control Module	DATA

File name	Vehicle line (indicative)	Module (ECU)	Type
HK83-14C037-PTH.vbf	Jaguar F-Pace (X761)	ABS - Anti-Lock Brake System Control Module	DATA
HK83-14C037-PTJ.vbf	Jaguar F-Pace (X761)	ABS - Anti-Lock Brake System Control Module	DATA
HK83-14C037-PUE.vbf	Jaguar F-Pace (X761)	ABS - Anti-Lock Brake System Control Module	DATA
HK83-14C037-PUF.vbf	Jaguar F-Pace (X761)	ABS - Anti-Lock Brake System Control Module	DATA
HK83-14C037-PUG.vbf	Jaguar F-Pace (X761)	ABS - Anti-Lock Brake System Control Module	DATA
HK83-14C037-PUH.vbf	Jaguar F-Pace (X761)	ABS - Anti-Lock Brake System Control Module	DATA
HK83-14C037-PUJ.vbf	Jaguar F-Pace (X761)	ABS - Anti-Lock Brake System Control Module	DATA
HK83-14C037-PUK.vbf	Jaguar F-Pace (X761)	ABS - Anti-Lock Brake System Control Module	DATA
HK83-14C037-PXE.vbf	Jaguar F-Pace (X761)	ABS - Anti-Lock Brake System Control Module	DATA
HK83-14C037-PXF.vbf	Jaguar F-Pace (X761)	ABS - Anti-Lock Brake System Control Module	DATA
HK83-14C037-PXG.vbf	Jaguar F-Pace (X761)	ABS - Anti-Lock Brake System Control Module	DATA
HK83-14C037-PXH.vbf	Jaguar F-Pace (X761)	ABS - Anti-Lock Brake System Control Module	DATA
HK83-14C037-PXJ.vbf	Jaguar F-Pace (X761)	ABS - Anti-Lock Brake System Control Module	DATA
HK83-14C037-PXK.vbf	Jaguar F-Pace (X761)	ABS - Anti-Lock Brake System Control Module	DATA
HK83-14C037-PZE.vbf	Jaguar F-Pace (X761)	ABS - Anti-Lock Brake System Control Module	DATA
HK83-14C037-PZF.vbf	Jaguar F-Pace (X761)	ABS - Anti-Lock Brake System Control Module	DATA
HK83-14C037-PZG.vbf	Jaguar F-Pace (X761)	ABS - Anti-Lock Brake System Control Module	DATA
HK83-14C037-PZH.vbf	Jaguar F-Pace (X761)	ABS - Anti-Lock Brake System Control Module	DATA
HK83-14C037-PZJ.vbf	Jaguar F-Pace (X761)	ABS - Anti-Lock Brake System Control Module	DATA
HK83-14C037-PZK.vbf	Jaguar F-Pace (X761)	ABS - Anti-Lock Brake System Control Module	DATA
HK83-14C037-RBE.vbf	Jaguar F-Pace (X761)	ABS - Anti-Lock Brake System Control Module	DATA
HK83-14C037-RBF.vbf	Jaguar F-Pace (X761)	ABS - Anti-Lock Brake System Control Module	DATA
HK83-14C037-RBG.vbf	Jaguar F-Pace (X761)	ABS - Anti-Lock Brake System Control Module	DATA
HK83-14C037-RBH.vbf	Jaguar F-Pace (X761)	ABS - Anti-Lock Brake System Control Module	DATA
HK83-14C037-RBJ.vbf	Jaguar F-Pace (X761)	ABS - Anti-Lock Brake System Control Module	DATA
HK83-14C037-RBK.vbf	Jaguar F-Pace (X761)	ABS - Anti-Lock Brake System Control Module	DATA
HK83-14C037-RCE.vbf	Jaguar F-Pace (X761)	ABS - Anti-Lock Brake System Control Module	DATA
HK83-14C037-RCF.vbf	Jaguar F-Pace (X761)	ABS - Anti-Lock Brake System Control Module	DATA
HK83-14C037-RCG.vbf	Jaguar F-Pace (X761)	ABS - Anti-Lock Brake System Control Module	DATA
HK83-14C037-RCH.vbf	Jaguar F-Pace (X761)	ABS - Anti-Lock Brake System Control Module	DATA
HK83-14C037-RCJ.vbf	Jaguar F-Pace (X761)	ABS - Anti-Lock Brake System Control Module	DATA
HK83-14C037-RCK.vbf	Jaguar F-Pace (X761)	ABS - Anti-Lock Brake System Control Module	DATA
HK83-14C039-AB.vbf	Jaguar F-Pace (X761)	ABS - Anti-Lock Brake System Control Module	SBL
HK83-14C064-AA.vbf	Jaguar F-Pace (X761)	DDM - Driver Front Door Module	EXE
HK83-14C064-AB.vbf	Jaguar F-Pace (X761)	DDM - Driver Front Door Module	EXE
HK83-14C064-AC.vbf	Jaguar F-Pace (X761)	DDM - Driver Front Door Module	EXE
HK83-14C064-BA.vbf	Jaguar F-Pace (X761)	DDM - Driver Front Door Module	EXE
HK83-14C064-BB.vbf	Jaguar F-Pace (X761)	DDM - Driver Front Door Module	EXE
HK83-14C064-BC.vbf	Jaguar F-Pace (X761)	DDM - Driver Front Door Module	EXE
HK83-14C064-CA.vbf	Jaguar F-Pace (X761)	DDM - Driver Front Door Module	EXE
HK83-14C064-CB.vbf	Jaguar F-Pace (X761)	DDM - Driver Front Door Module	EXE
HK83-14C065-AE.vbf	Jaguar F-Pace (X761)	DDM - Driver Front Door Module	DATA
HK83-14C065-AF.vbf	Jaguar F-Pace (X761)	DDM - Driver Front Door Module	DATA
HK83-14C065-AG.vbf	Jaguar F-Pace (X761)	DDM - Driver Front Door Module	DATA
HK83-14C065-AH.vbf	Jaguar F-Pace (X761)	DDM - Driver Front Door Module	DATA
HK83-14C068-AA.vbf	Jaguar F-Pace (X761)	DRDM - Driver Rear Door Module	EXE
HK83-14C068-AB.vbf	Jaguar F-Pace (X761)	DRDM - Driver Rear Door Module	EXE
HK83-14C068-AC.vbf	Jaguar F-Pace (X761)	DRDM - Driver Rear Door Module	EXE
HK83-14C068-BA.vbf	Jaguar F-Pace (X761)	DRDM - Driver Rear Door Module	EXE
HK83-14C068-BB.vbf	Jaguar F-Pace (X761)	DRDM - Driver Rear Door Module	EXE
HK83-14C068-BC.vbf	Jaguar F-Pace (X761)	DRDM - Driver Rear Door Module	EXE
HK83-14C068-CA.vbf	Jaguar F-Pace (X761)	DRDM - Driver Rear Door Module	EXE
HK83-14C068-CB.vbf	Jaguar F-Pace (X761)	DRDM - Driver Rear Door Module	EXE
HK83-14C069-AD.vbf	Jaguar F-Pace (X761)	DRDM - Driver Rear Door Module	DATA
HK83-14C069-AE.vbf	Jaguar F-Pace (X761)	DRDM - Driver Rear Door Module	DATA
HK83-14C069-AF.vbf	Jaguar F-Pace (X761)	DRDM - Driver Rear Door Module	DATA
HK83-14C069-AG.vbf	Jaguar F-Pace (X761)	DRDM - Driver Rear Door Module	DATA
HK83-14C088-BE.vbf	Jaguar F-Pace (X761)	IPC - Instrument Panel Cluster (IPC) Control Module	DATA
HK83-14C088-CB.vbf	Jaguar F-Pace (X761)	IPC - Instrument Panel Cluster (IPC) Control Module	EXE
HK83-14C088-CC.vbf	Jaguar F-Pace (X761)	IPC - Instrument Panel Cluster (IPC) Control Module	EXE
HK83-14C088-CD.vbf	Jaguar F-Pace (X761)	IPC - Instrument Panel Cluster (IPC) Control Module	EXE
HK83-14C088-CE.vbf	Jaguar F-Pace (X761)	IPC - Instrument Panel Cluster (IPC) Control Module	EXE
HK83-14C088-CF.vbf	Jaguar F-Pace (X761)	IPC - Instrument Panel Cluster (IPC) Control Module	EXE
HK83-14C088-DA.vbf	Jaguar F-Pace (X761)	IPC - Instrument Panel Cluster (IPC) Control Module	DATA
HK83-14C088-JA.vbf	Jaguar F-Pace (X761)	IPC - Instrument Panel Cluster (IPC) Control Module	DATA
HK83-14C088-JB.vbf	Jaguar F-Pace (X761)	IPC - Instrument Panel Cluster (IPC) Control Module	DATA
HK83-14C088-JC.vbf	Jaguar F-Pace (X761)	IPC - Instrument Panel Cluster (IPC) Control Module	DATA
HK83-14C088-JD.vbf	Jaguar F-Pace (X761)	IPC - Instrument Panel Cluster (IPC) Control Module	DATA
HK83-14C088-KA.vbf	Jaguar F-Pace (X761)	IPC - Instrument Panel Cluster (IPC) Control Module	DATA
HK83-14C088-LA.vbf	Jaguar F-Pace (X761)	IPC - Instrument Panel Cluster (IPC) Control Module	DATA
HK83-14C088-LB.vbf	Jaguar F-Pace (X761)	IPC - Instrument Panel Cluster (IPC) Control Module	DATA
HK83-14C088-LC.vbf	Jaguar F-Pace (X761)	IPC - Instrument Panel Cluster (IPC) Control Module	DATA
HK83-14C088-LD.vbf	Jaguar F-Pace (X761)	IPC - Instrument Panel Cluster (IPC) Control Module	DATA
HK83-14C090-AB.vbf	Jaguar F-Pace (X761)	PAM - Parking Assist Control Module	EXE
HK83-14C090-AD.vbf	Jaguar F-Pace (X761)	PAM - Parking Assist Control Module	EXE
HK83-14C090-AE.vbf	Jaguar F-Pace (X761)	PAM - Parking Assist Control Module	EXE

File name	Vehicle line (indicative)	Module (ECU)	Type
HK83-14C090-AG.vbf	Jaguar F-Pace (X761)	PAM - Parking Assist Control Module	EXE
HK83-14C090-AH.vbf	Jaguar F-Pace (X761)	PAM - Parking Assist Control Module	EXE
HK83-14C090-AK.vbf	Jaguar F-Pace (X761)	PAM - Parking Assist Control Module	EXE
HK83-14C090-AL.vbf	Jaguar F-Pace (X761)	PAM - Parking Assist Control Module	EXE
HK83-14C091-AE.vbf	Jaguar F-Pace (X761)	PAM - Parking Assist Control Module	DATA
HK83-14C091-AF.vbf	Jaguar F-Pace (X761)	PAM - Parking Assist Control Module	DATA
HK83-14C091-AH.vbf	Jaguar F-Pace (X761)	PAM - Parking Assist Control Module	DATA
HK83-14C091-AJ.vbf	Jaguar F-Pace (X761)	PAM - Parking Assist Control Module	DATA
HK83-14C091-AK.vbf	Jaguar F-Pace (X761)	PAM - Parking Assist Control Module	DATA
HK83-14C091-AL.vbf	Jaguar F-Pace (X761)	PAM - Parking Assist Control Module	DATA
HK83-14C091-AM.vbf	Jaguar F-Pace (X761)	PAM - Parking Assist Control Module	DATA
HK83-14C091-BB.vbf	Jaguar F-Pace (X761)	PAM - Parking Assist Control Module	DATA
HK83-14C091-BD.vbf	Jaguar F-Pace (X761)	PAM - Parking Assist Control Module	DATA
HK83-14C091-BE.vbf	Jaguar F-Pace (X761)	PAM - Parking Assist Control Module	DATA
HK83-14C091-BG.vbf	Jaguar F-Pace (X761)	PAM - Parking Assist Control Module	DATA
HK83-14C091-BH.vbf	Jaguar F-Pace (X761)	PAM - Parking Assist Control Module	DATA
HK83-14C091-BL.vbf	Jaguar F-Pace (X761)	PAM - Parking Assist Control Module	DATA
HK83-14C093-AB.vbf	Jaguar F-Pace (X761)	PAM - Parking Assist Control Module	SBL
HK83-14C098-AB.vbf	Jaguar F-Pace (X761)	RCM - Restraints Control Module	DATA
HK83-14C098-AC.vbf	Jaguar F-Pace (X761)	RCM - Restraints Control Module	DATA
HK83-14C098-AD.VBF	Jaguar F-Pace (X761)	RCM - Restraints Control Module	DATA
HK83-14C098-BC.vbf	Jaguar F-Pace (X761)	RCM - Restraints Control Module	DATA
HK83-14C098-BD.vbf	Jaguar F-Pace (X761)	RCM - Restraints Control Module	DATA
HK83-14C098-CA.vbf	Jaguar F-Pace (X761)	RCM - Restraints Control Module	DATA
HK83-14C098-CB.vbf	Jaguar F-Pace (X761)	RCM - Restraints Control Module	DATA
HK83-14C098-CC.vbf	Jaguar F-Pace (X761)	RCM - Restraints Control Module	DATA
HK83-14C098-CD.VBF	Jaguar F-Pace (X761)	RCM - Restraints Control Module	DATA
HK83-14C098-CE.VBF	Jaguar F-Pace (X761)	RCM - Restraints Control Module	DATA
HK83-14C098-DB.vbf	Jaguar F-Pace (X761)	RCM - Restraints Control Module	DATA
HK83-14C098-DD.VBF	Jaguar F-Pace (X761)	RCM - Restraints Control Module	DATA
HK83-14C105-AB.vbf	Jaguar F-Pace (X761)	TMC Traffic Message Channel Module	DATA
HK83-14C105-AC.vbf	Jaguar F-Pace (X761)	TMC Traffic Message Channel Module	DATA
HK83-14C105-AG.vbf	Jaguar F-Pace (X761)	TMC Traffic Message Channel Module	DATA
HK83-14C108-AA.vbf	Jaguar F-Pace (X761)	PDM - Passenger Front Door Module	EXE
HK83-14C108-AB.vbf	Jaguar F-Pace (X761)	PDM - Passenger Front Door Module	EXE
HK83-14C108-AC.vbf	Jaguar F-Pace (X761)	PDM - Passenger Front Door Module	EXE
HK83-14C108-BA.vbf	Jaguar F-Pace (X761)	PDM - Passenger Front Door Module	EXE
HK83-14C108-BB.vbf	Jaguar F-Pace (X761)	PDM - Passenger Front Door Module	EXE
HK83-14C108-BC.vbf	Jaguar F-Pace (X761)	PDM - Passenger Front Door Module	EXE
HK83-14C108-CA.vbf	Jaguar F-Pace (X761)	PDM - Passenger Front Door Module	EXE
HK83-14C108-CB.vbf	Jaguar F-Pace (X761)	PDM - Passenger Front Door Module	EXE
HK83-14C109-AD.vbf	Jaguar F-Pace (X761)	PDM - Passenger Front Door Module	DATA
HK83-14C109-AE.vbf	Jaguar F-Pace (X761)	PDM - Passenger Front Door Module	DATA
HK83-14C109-AF.vbf	Jaguar F-Pace (X761)	PDM - Passenger Front Door Module	DATA
HK83-14C109-AG.vbf	Jaguar F-Pace (X761)	PDM - Passenger Front Door Module	DATA
HK83-14C112-AA.vbf	Jaguar F-Pace (X761)	PRDM - Passenger Rear Door Module	EXE
HK83-14C112-AB.vbf	Jaguar F-Pace (X761)	PRDM - Passenger Rear Door Module	EXE
HK83-14C112-AC.vbf	Jaguar F-Pace (X761)	PRDM - Passenger Rear Door Module	EXE
HK83-14C112-BA.vbf	Jaguar F-Pace (X761)	PRDM - Passenger Rear Door Module	EXE
HK83-14C112-BB.vbf	Jaguar F-Pace (X761)	PRDM - Passenger Rear Door Module	EXE
HK83-14C112-BC.vbf	Jaguar F-Pace (X761)	PRDM - Passenger Rear Door Module	EXE
HK83-14C112-CA.vbf	Jaguar F-Pace (X761)	PRDM - Passenger Rear Door Module	EXE
HK83-14C112-CB.vbf	Jaguar F-Pace (X761)	PRDM - Passenger Rear Door Module	EXE
HK83-14C113-AD.vbf	Jaguar F-Pace (X761)	PRDM - Passenger Rear Door Module	DATA
HK83-14C113-AE.vbf	Jaguar F-Pace (X761)	PRDM - Passenger Rear Door Module	DATA
HK83-14C113-AF.vbf	Jaguar F-Pace (X761)	PRDM - Passenger Rear Door Module	DATA
HK83-14C113-AG.vbf	Jaguar F-Pace (X761)	PRDM - Passenger Rear Door Module	DATA
HK83-14C121-AB.vbf	Jaguar F-Pace (X761)	RGTM - Rear Gate / Trunk Module	EXE
HK83-14C121-AC.vbf	Jaguar F-Pace (X761)	RGTM - Rear Gate / Trunk Module	EXE
HK83-14C122-AB.vbf	Jaguar F-Pace (X761)	RGTM - Rear Gate / Trunk Module	DATA
HK83-14C122-AC.vbf	Jaguar F-Pace (X761)	RGTM - Rear Gate / Trunk Module	DATA
HK83-14C124-AA.vbf	Jaguar F-Pace (X761)	RGTM - Rear Gate / Trunk Module	SBL
HK83-14C152-AA.vbf	Jaguar F-Pace (X761)	TPM - Tire Pressure Monitor Module	DATA
HK83-14C152-BA.vbf	Jaguar F-Pace (X761)	TPM - Tire Pressure Monitor Module	DATA
HK83-14C152-BB.vbf	Jaguar F-Pace (X761)	TPM - Tire Pressure Monitor Module	DATA
HK83-14C185-AB.vbf	Jaguar F-Pace (X761)	BCM - Body Control Module	DATA
HK83-14C185-AC.vbf	Jaguar F-Pace (X761)	BCM - Body Control Module	DATA
HK83-14C185-AD.vbf	Jaguar F-Pace (X761)	BCM - Body Control Module	DATA
HK83-14C185-AE.vbf	Jaguar F-Pace (X761)	BCM - Body Control Module	DATA
HK83-14C185-AF.vbf	Jaguar F-Pace (X761)	BCM - Body Control Module	DATA
HK83-14C204-CAA.vbf	Jaguar F-Pace (X761)	PCM - Powertrain Control Module	EXE
HK83-14C204-CAB.vbf	Jaguar F-Pace (X761)	PCM - Powertrain Control Module	EXE
HK83-14C204-CAC.vbf	Jaguar F-Pace (X761)	PCM - Powertrain Control Module	EXE
HK83-14C204-CAD.vbf	Jaguar F-Pace (X761)	PCM - Powertrain Control Module	EXE
HK83-14C204-CCA.vbf	Jaguar F-Pace (X761)	PCM - Powertrain Control Module	EXE
HK83-14C204-CCB.vbf	Jaguar F-Pace (X761)	PCM - Powertrain Control Module	EXE

File name	Vehicle line (indicative)	Module (ECU)	Type
HK83-14C204-CCC.vbf	Jaguar F-Pace (X761)	PCM - Powertrain Control Module	EXE
HK83-14C204-CCD.vbf	Jaguar F-Pace (X761)	PCM - Powertrain Control Module	EXE
HK83-14C204-CEA.vbf	Jaguar F-Pace (X761)	PCM - Powertrain Control Module	EXE
HK83-14C204-CEB.vbf	Jaguar F-Pace (X761)	PCM - Powertrain Control Module	EXE
HK83-14C204-CEC.vbf	Jaguar F-Pace (X761)	PCM - Powertrain Control Module	EXE
HK83-14C204-CTA.vbf	Jaguar F-Pace (X761)	PCM - Powertrain Control Module	EXE
HK83-14C204-CTB.vbf	Jaguar F-Pace (X761)	PCM - Powertrain Control Module	EXE
HK83-14C204-CTC.vbf	Jaguar F-Pace (X761)	PCM - Powertrain Control Module	EXE
HK83-14C204-CTD.vbf	Jaguar F-Pace (X761)	PCM - Powertrain Control Module	EXE
HK83-14C204-MBC.vbf	Jaguar F-Pace (X761)	PCM - Powertrain Control Module	EXE
HK83-14C204-MBD.vbf	Jaguar F-Pace (X761)	PCM - Powertrain Control Module	EXE
HK83-14C217-AA.vbf	Jaguar F-Pace (X761)	PSCM - Power Steering Control Module	EXE
HK83-14C217-AC.vbf	Jaguar F-Pace (X761)	PSCM - Power Steering Control Module	EXE
HK83-14C217-AD.vbf	Jaguar F-Pace (X761)	PSCM - Power Steering Control Module	EXE
HK83-14C218-AA.vbf	Jaguar F-Pace (X761)	PSCM - Power Steering Control Module	DATA
HK83-14C218-AC.vbf	Jaguar F-Pace (X761)	PSCM - Power Steering Control Module	DATA
HK83-14C218-AD.vbf	Jaguar F-Pace (X761)	PSCM - Power Steering Control Module	DATA
HK83-14C218-BA.vbf	Jaguar F-Pace (X761)	PSCM - Power Steering Control Module	DATA
HK83-14C218-BB.vbf	Jaguar F-Pace (X761)	PSCM - Power Steering Control Module	DATA
HK83-14C218-CA.vbf	Jaguar F-Pace (X761)	PSCM - Power Steering Control Module	DATA
HK83-14C218-CB.vbf	Jaguar F-Pace (X761)	PSCM - Power Steering Control Module	DATA
HK83-14C218-DA.vbf	Jaguar F-Pace (X761)	PSCM - Power Steering Control Module	DATA
HK83-14C218-DB.vbf	Jaguar F-Pace (X761)	PSCM - Power Steering Control Module	DATA
HK83-14C366-AE.vbf	Jaguar F-Pace (X761)	TCCM - Transfer Case Control Module	EXE
HK83-14C367-BA.vbf	Jaguar F-Pace (X761)	TCCM - Transfer Case Control Module	DATA
HK83-14C367-BB.vbf	Jaguar F-Pace (X761)	TCCM - Transfer Case Control Module	DATA
HK83-14C367-BC.vbf	Jaguar F-Pace (X761)	TCCM - Transfer Case Control Module	DATA
HK83-14C367-CA.vbf	Jaguar F-Pace (X761)	TCCM - Transfer Case Control Module	DATA
HK83-14C367-CB.vbf	Jaguar F-Pace (X761)	TCCM - Transfer Case Control Module	DATA
HK83-14C367-CC.vbf	Jaguar F-Pace (X761)	TCCM - Transfer Case Control Module	DATA
HK83-14C367-CD.vbf	Jaguar F-Pace (X761)	TCCM - Transfer Case Control Module	DATA
HK83-14C367-DA.vbf	Jaguar F-Pace (X761)	TCCM - Transfer Case Control Module	DATA
HK83-14C367-DB.vbf	Jaguar F-Pace (X761)	TCCM - Transfer Case Control Module	DATA
HK83-14C367-DC.vbf	Jaguar F-Pace (X761)	TCCM - Transfer Case Control Module	DATA
HK83-14C367-EA.vbf	Jaguar F-Pace (X761)	TCCM - Transfer Case Control Module	DATA
HK83-14C367-EB.vbf	Jaguar F-Pace (X761)	TCCM - Transfer Case Control Module	DATA
HK83-14C367-EC.vbf	Jaguar F-Pace (X761)	TCCM - Transfer Case Control Module	DATA
HK83-14C367-FA.vbf	Jaguar F-Pace (X761)	TCCM - Transfer Case Control Module	DATA
HK83-14C367-GA.vbf	Jaguar F-Pace (X761)	TCCM - Transfer Case Control Module	DATA
HK83-14C367-GB.vbf	Jaguar F-Pace (X761)	TCCM - Transfer Case Control Module	DATA
HK83-14C367-HA.vbf	Jaguar F-Pace (X761)	TCCM - Transfer Case Control Module	DATA
HK83-14C367-JA.vbf	Jaguar F-Pace (X761)	TCCM - Transfer Case Control Module	DATA
HK83-14C386-AA.vbf	Jaguar F-Pace (X761)	PSCM - Power Steering Control Module	SIGCFG
HK83-14C390-AA.vbf	Jaguar F-Pace (X761)	TCCM - Transfer Case Control Module	DATA
HK83-14C413-AA.vbf	Jaguar F-Pace (X761)	DSM - Driver Front Seat Module	EXE
HK83-14C413-AB.vbf	Jaguar F-Pace (X761)	DSM - Driver Front Seat Module	EXE
HK83-14C413-AC.vbf	Jaguar F-Pace (X761)	DSM - Driver Front Seat Module	EXE
HK83-14C527-BA.vbf	Jaguar F-Pace (X761)	AAM - Audio Amplifier Module	DATA
HK83-14C527-BB.vbf	Jaguar F-Pace (X761)	AAM - Audio Amplifier Module	DATA
HK83-14C527-BC.vbf	Jaguar F-Pace (X761)	AAM - Audio Amplifier Module	DATA
HK83-14C527-BD.vbf	Jaguar F-Pace (X761)	AAM - Audio Amplifier Module	DATA
HK83-14C527-BE.vbf	Jaguar F-Pace (X761)	AAM - Audio Amplifier Module	DATA
HK83-14C527-CA.vbf	Jaguar F-Pace (X761)	AAM - Audio Amplifier Module	DATA
HK83-14C527-CB.vbf	Jaguar F-Pace (X761)	AAM - Audio Amplifier Module	DATA
HK83-14C527-CC.vbf	Jaguar F-Pace (X761)	AAM - Audio Amplifier Module	DATA
HK83-14C527-CD.vbf	Jaguar F-Pace (X761)	AAM - Audio Amplifier Module	DATA
HK83-14C527-CE.vbf	Jaguar F-Pace (X761)	AAM - Audio Amplifier Module	DATA
HK83-14C536-BAA.vbf	Jaguar F-Pace (X761)	FCIM - Front Controls Interface Module	DATA
HK83-14C536-BBA.vbf	Jaguar F-Pace (X761)	FCIM - Front Controls Interface Module	DATA
HK83-14C536-BEA.vbf	Jaguar F-Pace (X761)	FCIM - Front Controls Interface Module	DATA
HK83-14C536-BFA.vbf	Jaguar F-Pace (X761)	FCIM - Front Controls Interface Module	DATA
HK83-14C536-BJA.vbf	Jaguar F-Pace (X761)	FCIM - Front Controls Interface Module	DATA
HK83-14C536-BKA.vbf	Jaguar F-Pace (X761)	FCIM - Front Controls Interface Module	DATA
HK83-14C536-BNA.vbf	Jaguar F-Pace (X761)	FCIM - Front Controls Interface Module	DATA
HK83-14C536-BPA.vbf	Jaguar F-Pace (X761)	FCIM - Front Controls Interface Module	DATA
HK83-14C536-BTA.vbf	Jaguar F-Pace (X761)	FCIM - Front Controls Interface Module	DATA
HK83-14C536-BUA.vbf	Jaguar F-Pace (X761)	FCIM - Front Controls Interface Module	DATA
HK83-14C536-BXA.vbf	Jaguar F-Pace (X761)	FCIM - Front Controls Interface Module	DATA
HK83-14C536-BYA.vbf	Jaguar F-Pace (X761)	FCIM - Front Controls Interface Module	DATA
HK83-14C536-CBA.vbf	Jaguar F-Pace (X761)	FCIM - Front Controls Interface Module	DATA
HK83-14C536-CCA.vbf	Jaguar F-Pace (X761)	FCIM - Front Controls Interface Module	DATA
HK83-14C536-CFA.vbf	Jaguar F-Pace (X761)	FCIM - Front Controls Interface Module	DATA
HK83-14C536-CGA.vbf	Jaguar F-Pace (X761)	FCIM - Front Controls Interface Module	DATA
HK83-14C547-AA.vbf	Jaguar F-Pace (X761)	PSM - Passenger Front Seat Module	EXE
HK83-14C547-AB.vbf	Jaguar F-Pace (X761)	PSM - Passenger Front Seat Module	EXE
HK83-14C547-AC.vbf	Jaguar F-Pace (X761)	PSM - Passenger Front Seat Module	EXE

File name	Vehicle line (indicative)	Module (ECU)	Type
HK83-14C549-AB.vbf	Jaguar F-Pace (X761)	PSM - Passenger Front Seat Module	EXE
HK83-14C549-AC.vbf	Jaguar F-Pace (X761)	PSM - Passenger Front Seat Module	EXE
HK83-14C549-BA.vbf	Jaguar F-Pace (X761)	PSM - Passenger Front Seat Module	EXE
HK83-14C609-AA.vbf	Jaguar F-Pace (X761)	PSCM - Power Steering Control Module	DATA
HK83-14C609-AC.vbf	Jaguar F-Pace (X761)	PSCM - Power Steering Control Module	DATA
HK83-14C609-AD.vbf	Jaguar F-Pace (X761)	PSCM - Power Steering Control Module	DATA
HK83-14C609-AE.vbf	Jaguar F-Pace (X761)	PSCM - Power Steering Control Module	DATA
HK83-14C653-AE.vbf	Jaguar F-Pace (X761)	ACM - Audio Front Control Module	DATA
HK83-14C653-AF.vbf	Jaguar F-Pace (X761)	ACM - Audio Front Control Module	DATA
HK83-14C653-AG.vbf	Jaguar F-Pace (X761)	ACM - Audio Front Control Module	DATA
HK83-14C653-AH.vbf	Jaguar F-Pace (X761)	ACM - Audio Front Control Module	DATA
HK83-14D183-BB.vbf	Jaguar F-Pace (X761)	OCS - Restraints Occupant Classification System Module	DATA
HK83-14D183-BC.vbf	Jaguar F-Pace (X761)	OCS - Restraints Occupant Classification System Module	DATA
HK83-14D481-BA.vbf	Jaguar F-Pace (X761)	IPMB - Image Processing Module B	DATA
HK83-14D481-BB.vbf	Jaguar F-Pace (X761)	IPMB - Image Processing Module B	DATA
HK83-14D481-BC.vbf	Jaguar F-Pace (X761)	IPMB - Image Processing Module B	DATA
HK83-14D481-BE.vbf	Jaguar F-Pace (X761)	IPMB - Image Processing Module B	DATA
HK83-14D485-BD.vbf	Jaguar F-Pace (X761)	IPMB - Image Processing Module B	DATA
HK83-14D485-BE.vbf	Jaguar F-Pace (X761)	IPMB - Image Processing Module B	DATA
HK83-14D485-BF.vbf	Jaguar F-Pace (X761)	IPMB - Image Processing Module B	DATA
HK83-14D520-AA.vbf	Jaguar F-Pace (X761)	HVAC - HVAC Control Module	DATA
HK83-14D520-AB.vbf	Jaguar F-Pace (X761)	HVAC - HVAC Control Module	DATA
HK83-14D520-AC.vbf	Jaguar F-Pace (X761)	HVAC - HVAC Control Module	DATA
HK83-14D520-AD.vbf	Jaguar F-Pace (X761)	HVAC - HVAC Control Module	DATA
HK83-14D520-BA.vbf	Jaguar F-Pace (X761)	HVAC - HVAC Control Module	DATA
HK83-14D520-BB.vbf	Jaguar F-Pace (X761)	HVAC - HVAC Control Module	DATA
HK83-14D520-CA.vbf	Jaguar F-Pace (X761)	HVAC - HVAC Control Module	DATA
HK83-14D520-CB.vbf	Jaguar F-Pace (X761)	HVAC - HVAC Control Module	DATA
HK83-14D520-CC.vbf	Jaguar F-Pace (X761)	HVAC - HVAC Control Module	DATA
HK83-14D520-DA.vbf	Jaguar F-Pace (X761)	HVAC - HVAC Control Module	DATA
HK83-14D520-DB.vbf	Jaguar F-Pace (X761)	HVAC - HVAC Control Module	DATA
HK83-14D564-AB.vbf	Jaguar F-Pace (X761)	SODL - Side Obstacle Detection Control Module - Left	DATA
HK83-14D564-BB.vbf	Jaguar F-Pace (X761)	SODR - Side Obstacle Detection Control Module - Right	DATA
HK83-14E093-DA.vbf	Jaguar F-Pace (X761)	CHCM - Chassis Control Module	EXE
HK83-14E093-DC.vbf	Jaguar F-Pace (X761)	CHCM - Chassis Control Module	EXE
HK83-14E093-DD.vbf	Jaguar F-Pace (X761)	CHCM - Chassis Control Module	EXE
HK83-14E093-DE.vbf	Jaguar F-Pace (X761)	CHCM - Chassis Control Module	EXE
HK83-14E094-DAC.vbf	Jaguar F-Pace (X761)	CHCM - Chassis Control Module	EXE
HK83-14E094-DAD.vbf	Jaguar F-Pace (X761)	CHCM - Chassis Control Module	EXE
HK83-14E094-DAE.vbf	Jaguar F-Pace (X761)	CHCM - Chassis Control Module	EXE
HK83-14E094-DBC.vbf	Jaguar F-Pace (X761)	CHCM - Chassis Control Module	EXE
HK83-14E094-DBD.vbf	Jaguar F-Pace (X761)	CHCM - Chassis Control Module	EXE
HK83-14E094-DBE.vbf	Jaguar F-Pace (X761)	CHCM - Chassis Control Module	EXE
HK83-14E094-DCC.vbf	Jaguar F-Pace (X761)	CHCM - Chassis Control Module	EXE
HK83-14E094-DCD.vbf	Jaguar F-Pace (X761)	CHCM - Chassis Control Module	EXE
HK83-14E094-DCE.vbf	Jaguar F-Pace (X761)	CHCM - Chassis Control Module	EXE
HK83-14E094-DDC.vbf	Jaguar F-Pace (X761)	CHCM - Chassis Control Module	EXE
HK83-14E094-DDD.vbf	Jaguar F-Pace (X761)	CHCM - Chassis Control Module	EXE
HK83-14E094-DDE.vbf	Jaguar F-Pace (X761)	CHCM - Chassis Control Module	EXE
HK83-14E094-DEC.vbf	Jaguar F-Pace (X761)	CHCM - Chassis Control Module	EXE
HK83-14E094-DED.vbf	Jaguar F-Pace (X761)	CHCM - Chassis Control Module	EXE
HK83-14E094-DEE.vbf	Jaguar F-Pace (X761)	CHCM - Chassis Control Module	EXE
HK83-14F017-AB.vbf	Jaguar F-Pace (X761)	IPMB - Image Processing Module B	EXE
HK83-14F017-AE.vbf	Jaguar F-Pace (X761)	IPMB - Image Processing Module B	EXE
HK83-14F017-AF.vbf	Jaguar F-Pace (X761)	IPMB - Image Processing Module B	EXE
HK83-14F017-AG.vbf	Jaguar F-Pace (X761)	IPMB - Image Processing Module B	EXE
HK83-14F017-AH.vbf	Jaguar F-Pace (X761)	IPMB - Image Processing Module B	EXE
HK83-14F017-BB.vbf	Jaguar F-Pace (X761)	IPMB - Image Processing Module B	EXE
HK83-14F017-BE.vbf	Jaguar F-Pace (X761)	IPMB - Image Processing Module B	EXE
HK83-14F017-BG.vbf	Jaguar F-Pace (X761)	IPMB - Image Processing Module B	EXE
HK83-14F022-BC.vbf	Jaguar F-Pace (X761)	IPMB - Image Processing Module B	DATA
HK83-14F022-BF.vbf	Jaguar F-Pace (X761)	IPMB - Image Processing Module B	DATA
HK83-14F022-BH.vbf	Jaguar F-Pace (X761)	IPMB - Image Processing Module B	DATA
HK83-14F022-GB.vbf	Jaguar F-Pace (X761)	IPMB - Image Processing Module B	DATA
HK83-14F022-GE.vbf	Jaguar F-Pace (X761)	IPMB - Image Processing Module B	DATA
HK83-14F022-GF.vbf	Jaguar F-Pace (X761)	IPMB - Image Processing Module B	DATA
HK83-14F022-GH.vbf	Jaguar F-Pace (X761)	IPMB - Image Processing Module B	DATA
HK83-14F231-AB.vbf	Jaguar F-Pace (X761)	HUD - Head Up Display	CUSTOM
HK83-14F231-AC.vbf	Jaguar F-Pace (X761)	HUD - Head Up Display	CUSTOM
HK83-14F396-AC.vbf	Jaguar F-Pace (X761)	IPMA - Image Processing Module A	EXE
HK83-14F396-AD.vbf	Jaguar F-Pace (X761)	IPMA - Image Processing Module A	EXE
HK83-14F397-AC.vbf	Jaguar F-Pace (X761)	IPMA - Image Processing Module A	EXE
HK83-14F397-AE.vbf	Jaguar F-Pace (X761)	IPMA - Image Processing Module A	EXE
HK83-14F397-AF.vbf	Jaguar F-Pace (X761)	IPMA - Image Processing Module A	EXE
HK83-14F397-AG.vbf	Jaguar F-Pace (X761)	IPMA - Image Processing Module A	EXE
HK83-14F397-BC.vbf	Jaguar F-Pace (X761)	IPMA - Image Processing Module A	EXE

File name	Vehicle line (indicative)	Module (ECU)	Type
HK83-14F397-BE.vbf	Jaguar F-Pace (X761)	IPMA - Image Processing Module A	EXE
HK83-14F397-BF.vbf	Jaguar F-Pace (X761)	IPMA - Image Processing Module A	EXE
HK83-14F397-BG.vbf	Jaguar F-Pace (X761)	IPMA - Image Processing Module A	EXE
HK83-14F397-CB.vbf	Jaguar F-Pace (X761)	IPMA - Image Processing Module A	EXE
HK83-14F397-CD.vbf	Jaguar F-Pace (X761)	IPMA - Image Processing Module A	EXE
HK83-14F397-CE.vbf	Jaguar F-Pace (X761)	IPMA - Image Processing Module A	EXE
HK83-14F397-CF.vbf	Jaguar F-Pace (X761)	IPMA - Image Processing Module A	EXE
HK83-14F397-DB.vbf	Jaguar F-Pace (X761)	IPMA - Image Processing Module A	EXE
HK83-14F397-DD.vbf	Jaguar F-Pace (X761)	IPMA - Image Processing Module A	EXE
HK83-14F397-DE.vbf	Jaguar F-Pace (X761)	IPMA - Image Processing Module A	EXE
HK83-14F397-DF.vbf	Jaguar F-Pace (X761)	IPMA - Image Processing Module A	EXE
HK83-14F398-AC.vbf	Jaguar F-Pace (X761)	IPMA - Image Processing Module A	EXE
HK83-14F398-AE.vbf	Jaguar F-Pace (X761)	IPMA - Image Processing Module A	EXE
HK83-14F398-AF.vbf	Jaguar F-Pace (X761)	IPMA - Image Processing Module A	EXE
HK83-14F398-AG.vbf	Jaguar F-Pace (X761)	IPMA - Image Processing Module A	EXE
HK83-14F398-BC.vbf	Jaguar F-Pace (X761)	IPMA - Image Processing Module A	EXE
HK83-14F398-BE.vbf	Jaguar F-Pace (X761)	IPMA - Image Processing Module A	EXE
HK83-14F398-BF.vbf	Jaguar F-Pace (X761)	IPMA - Image Processing Module A	EXE
HK83-14F398-BG.vbf	Jaguar F-Pace (X761)	IPMA - Image Processing Module A	EXE
HK83-14F530-AA.vbf	Jaguar F-Pace (X761)	GWM - Gateway Module A	EXE
HK83-14F530-AB.vbf	Jaguar F-Pace (X761)	GWM - Gateway Module A	EXE
HK83-14F530-AC.vbf	Jaguar F-Pace (X761)	GWM - Gateway Module A	EXE
HK83-14F530-AD.vbf	Jaguar F-Pace (X761)	GWM - Gateway Module A	EXE
HK83-14F530-AE.vbf	Jaguar F-Pace (X761)	GWM - Gateway Module A	EXE
HK83-14F530-AF.vbf	Jaguar F-Pace (X761)	GWM - Gateway Module A	EXE
HK83-14F530-AG.vbf	Jaguar F-Pace (X761)	GWM - Gateway Module A	EXE
HK83-14F531-AB.vbf	Jaguar F-Pace (X761)	GWM - Gateway Module A	DATA
HK83-14F531-AC.vbf	Jaguar F-Pace (X761)	GWM - Gateway Module A	DATA
HK83-14F531-AD.vbf	Jaguar F-Pace (X761)	GWM - Gateway Module A	DATA
HK83-14F531-AE.vbf	Jaguar F-Pace (X761)	GWM - Gateway Module A	DATA
HK83-14F531-AF.vbf	Jaguar F-Pace (X761)	GWM - Gateway Module A	DATA
HK83-70713-BJ.vbf	Jaguar F-Pace (X761)	TCU - Telematic Control Unit Module	DATA
HK83-70713-BK.vbf	Jaguar F-Pace (X761)	TCU - Telematic Control Unit Module	DATA
HK83-70713-BL.vbf	Jaguar F-Pace (X761)	TCU - Telematic Control Unit Module	DATA
HK83-70713-BM.vbf	Jaguar F-Pace (X761)	TCU - Telematic Control Unit Module	DATA
HK83-70713-BN.vbf	Jaguar F-Pace (X761)	TCU - Telematic Control Unit Module	DATA
HK83-70713-BP.vbf	Jaguar F-Pace (X761)	TCU - Telematic Control Unit Module	DATA
HK83-70713-BR.vbf	Jaguar F-Pace (X761)	TCU - Telematic Control Unit Module	DATA
HK83-70713-BS.vbf	Jaguar F-Pace (X761)	TCU - Telematic Control Unit Module	DATA
HK83-70713-CJ.vbf	Jaguar F-Pace (X761)	TCU - Telematic Control Unit Module	DATA
HK83-70713-CK.vbf	Jaguar F-Pace (X761)	TCU - Telematic Control Unit Module	DATA
HK83-70713-CL.vbf	Jaguar F-Pace (X761)	TCU - Telematic Control Unit Module	DATA
HK83-70713-CM.vbf	Jaguar F-Pace (X761)	TCU - Telematic Control Unit Module	DATA
HK83-70713-CN.vbf	Jaguar F-Pace (X761)	TCU - Telematic Control Unit Module	DATA
HK83-70713-CP.vbf	Jaguar F-Pace (X761)	TCU - Telematic Control Unit Module	DATA
HK83-70713-CR.vbf	Jaguar F-Pace (X761)	TCU - Telematic Control Unit Module	DATA
HK83-70713-CS.vbf	Jaguar F-Pace (X761)	TCU - Telematic Control Unit Module	DATA
HK83-70713-DC.vbf	Jaguar F-Pace (X761)	TCU - Telematic Control Unit Module	DATA
HK83-70713-DD.vbf	Jaguar F-Pace (X761)	TCU - Telematic Control Unit Module	DATA
HK83-70713-DE.vbf	Jaguar F-Pace (X761)	TCU - Telematic Control Unit Module	DATA
HK83-70713-DF.vbf	Jaguar F-Pace (X761)	TCU - Telematic Control Unit Module	DATA
HK83-70713-DG.vbf	Jaguar F-Pace (X761)	TCU - Telematic Control Unit Module	DATA
HK83-70713-DJ.vbf	Jaguar F-Pace (X761)	TCU - Telematic Control Unit Module	DATA
HK83-70713-DK.vbf	Jaguar F-Pace (X761)	TCU - Telematic Control Unit Module	DATA
HK83-70713-DL.vbf	Jaguar F-Pace (X761)	TCU - Telematic Control Unit Module	DATA
HK83-70713-EB.vbf	Jaguar F-Pace (X761)	TCU - Telematic Control Unit Module	DATA
HK83-70713-EC.vbf	Jaguar F-Pace (X761)	TCU - Telematic Control Unit Module	DATA
HK83-70713-ED.vbf	Jaguar F-Pace (X761)	TCU - Telematic Control Unit Module	DATA
HK83-70713-EE.vbf	Jaguar F-Pace (X761)	TCU - Telematic Control Unit Module	DATA
HK83-70713-EF.vbf	Jaguar F-Pace (X761)	TCU - Telematic Control Unit Module	DATA
HK83-70713-EG.vbf	Jaguar F-Pace (X761)	TCU - Telematic Control Unit Module	DATA
HK83-70713-EH.vbf	Jaguar F-Pace (X761)	TCU - Telematic Control Unit Module	DATA
HK83-70713-EJ.vbf	Jaguar F-Pace (X761)	TCU - Telematic Control Unit Module	DATA
HK83-70713-JA.vbf	Jaguar F-Pace (X761)	TCU - Telematic Control Unit Module	DATA
HK83-70713-JB.vbf	Jaguar F-Pace (X761)	TCU - Telematic Control Unit Module	DATA
HK83-70713-JC.vbf	Jaguar F-Pace (X761)	TCU - Telematic Control Unit Module	DATA
HK83-70713-JD.vbf	Jaguar F-Pace (X761)	TCU - Telematic Control Unit Module	DATA
HK83-70713-JE.vbf	Jaguar F-Pace (X761)	TCU - Telematic Control Unit Module	DATA
HK83-70713-JF.vbf	Jaguar F-Pace (X761)	TCU - Telematic Control Unit Module	DATA
HK83-70713-JG.vbf	Jaguar F-Pace (X761)	TCU - Telematic Control Unit Module	DATA
HK83-70713-JH.vbf	Jaguar F-Pace (X761)	TCU - Telematic Control Unit Module	DATA
HK83-70713-JJ.vbf	Jaguar F-Pace (X761)	TCU - Telematic Control Unit Module	DATA
HK83-70713-KC.vbf	Jaguar F-Pace (X761)	TCU - Telematic Control Unit Module	DATA
HK83-70713-KD.vbf	Jaguar F-Pace (X761)	TCU - Telematic Control Unit Module	DATA
HK83-70713-KE.vbf	Jaguar F-Pace (X761)	TCU - Telematic Control Unit Module	DATA
HK83-70713-KF.vbf	Jaguar F-Pace (X761)	TCU - Telematic Control Unit Module	DATA

File name	Vehicle line (indicative)	Module (ECU)	Type
HK83-70713-KG.vbf	Jaguar F-Pace (X761)	TCU - Telematic Control Unit Module	DATA
HK83-70713-KJ.vbf	Jaguar F-Pace (X761)	TCU - Telematic Control Unit Module	DATA
HK83-70713-KK.vbf	Jaguar F-Pace (X761)	TCU - Telematic Control Unit Module	DATA
HK83-70713-KL.vbf	Jaguar F-Pace (X761)	TCU - Telematic Control Unit Module	DATA
HK83-70713-MAA.vbf	Jaguar F-Pace (X761)	TCU - Telematic Control Unit Module	DATA
HK83-70713-MR.vbf	Jaguar F-Pace (X761)	TCU - Telematic Control Unit Module	DATA
HK83-70713-MS.vbf	Jaguar F-Pace (X761)	TCU - Telematic Control Unit Module	DATA
HK83-70713-MT.vbf	Jaguar F-Pace (X761)	TCU - Telematic Control Unit Module	DATA
HK83-70713-MV.vbf	Jaguar F-Pace (X761)	TCU - Telematic Control Unit Module	DATA
HK83-70713-MX.vbf	Jaguar F-Pace (X761)	TCU - Telematic Control Unit Module	DATA
HK83-70713-MY.vbf	Jaguar F-Pace (X761)	TCU - Telematic Control Unit Module	DATA
HK83-70713-MZ.vbf	Jaguar F-Pace (X761)	TCU - Telematic Control Unit Module	DATA
HK83-70713-NAA.vbf	Jaguar F-Pace (X761)	TCU - Telematic Control Unit Module	DATA
HK83-70713-NR.vbf	Jaguar F-Pace (X761)	TCU - Telematic Control Unit Module	DATA
HK83-70713-NS.vbf	Jaguar F-Pace (X761)	TCU - Telematic Control Unit Module	DATA
HK83-70713-NT.vbf	Jaguar F-Pace (X761)	TCU - Telematic Control Unit Module	DATA
HK83-70713-NV.vbf	Jaguar F-Pace (X761)	TCU - Telematic Control Unit Module	DATA
HK83-70713-NX.vbf	Jaguar F-Pace (X761)	TCU - Telematic Control Unit Module	DATA
HK83-70713-NZ.vbf	Jaguar F-Pace (X761)	TCU - Telematic Control Unit Module	DATA
HK83-70713-RJ.vbf	Jaguar F-Pace (X761)	TCU - Telematic Control Unit Module	DATA
HK83-70713-RK.vbf	Jaguar F-Pace (X761)	TCU - Telematic Control Unit Module	DATA
HK83-70713-RL.vbf	Jaguar F-Pace (X761)	TCU - Telematic Control Unit Module	DATA
HK83-70713-RM.vbf	Jaguar F-Pace (X761)	TCU - Telematic Control Unit Module	DATA
HK83-70713-RN.vbf	Jaguar F-Pace (X761)	TCU - Telematic Control Unit Module	DATA
HK83-70713-RR.vbf	Jaguar F-Pace (X761)	TCU - Telematic Control Unit Module	DATA
HK83-70713-RT.vbf	Jaguar F-Pace (X761)	TCU - Telematic Control Unit Module	DATA
HK83-70713-SJ.vbf	Jaguar F-Pace (X761)	TCU - Telematic Control Unit Module	DATA
HK83-70713-SK.vbf	Jaguar F-Pace (X761)	TCU - Telematic Control Unit Module	DATA
HK83-70713-SL.vbf	Jaguar F-Pace (X761)	TCU - Telematic Control Unit Module	DATA
HK83-70713-SM.vbf	Jaguar F-Pace (X761)	TCU - Telematic Control Unit Module	DATA
HK83-70713-SN.vbf	Jaguar F-Pace (X761)	TCU - Telematic Control Unit Module	DATA
HK83-70713-SR.vbf	Jaguar F-Pace (X761)	TCU - Telematic Control Unit Module	DATA
HK83-70713-ST.vbf	Jaguar F-Pace (X761)	TCU - Telematic Control Unit Module	DATA
HK83-70713-TB.vbf	Jaguar F-Pace (X761)	TCU - Telematic Control Unit Module	DATA
HK83-70713-TC.vbf	Jaguar F-Pace (X761)	TCU - Telematic Control Unit Module	DATA
HK83-70713-TD.vbf	Jaguar F-Pace (X761)	TCU - Telematic Control Unit Module	DATA
HK83-70713-TE.vbf	Jaguar F-Pace (X761)	TCU - Telematic Control Unit Module	DATA
HK83-70713-TF.vbf	Jaguar F-Pace (X761)	TCU - Telematic Control Unit Module	DATA
HK83-70713-TG.vbf	Jaguar F-Pace (X761)	TCU - Telematic Control Unit Module	DATA
HK83-70713-TJ.vbf	Jaguar F-Pace (X761)	TCU - Telematic Control Unit Module	DATA
HK83-70713-TL.vbf	Jaguar F-Pace (X761)	TCU - Telematic Control Unit Module	DATA
HK83-70713-VA.vbf	Jaguar F-Pace (X761)	TCU - Telematic Control Unit Module	DATA
HK83-70713-VB.vbf	Jaguar F-Pace (X761)	TCU - Telematic Control Unit Module	DATA
HK83-70713-VC.vbf	Jaguar F-Pace (X761)	TCU - Telematic Control Unit Module	DATA
HK83-70713-VD.vbf	Jaguar F-Pace (X761)	TCU - Telematic Control Unit Module	DATA
HK83-70713-VE.vbf	Jaguar F-Pace (X761)	TCU - Telematic Control Unit Module	DATA
HK83-70713-VF.vbf	Jaguar F-Pace (X761)	TCU - Telematic Control Unit Module	DATA
HK83-70713-VG.vbf	Jaguar F-Pace (X761)	TCU - Telematic Control Unit Module	DATA
HK83-70713-VJ.vbf	Jaguar F-Pace (X761)	TCU - Telematic Control Unit Module	DATA
HK83-7J104-BCB.vbf	Jaguar F-Pace (X761)	TCM - Transmission Control Module	EXE
HK83-7J104-BCC.vbf	Jaguar F-Pace (X761)	TCM - Transmission Control Module	EXE
HK83-7J104-BCD.vbf	Jaguar F-Pace (X761)	TCM - Transmission Control Module	EXE
HK83-7J104-BCE.vbf	Jaguar F-Pace (X761)	TCM - Transmission Control Module	EXE
HK83-7J104-BFB.vbf	Jaguar F-Pace (X761)	TCM - Transmission Control Module	EXE
HK83-7J104-BFC.vbf	Jaguar F-Pace (X761)	TCM - Transmission Control Module	EXE
HK83-7J104-BFD.vbf	Jaguar F-Pace (X761)	TCM - Transmission Control Module	EXE
HK83-7J104-BHC.vbf	Jaguar F-Pace (X761)	TCM - Transmission Control Module	EXE
HK83-7J104-BHD.vbf	Jaguar F-Pace (X761)	TCM - Transmission Control Module	EXE
HK83-7J104-BHE.vbf	Jaguar F-Pace (X761)	TCM - Transmission Control Module	EXE
HK83-7J104-BHF.vbf	Jaguar F-Pace (X761)	TCM - Transmission Control Module	EXE
HK83-7J104-BKA.vbf	Jaguar F-Pace (X761)	TCM - Transmission Control Module	EXE
HK83-7J104-BLA.vbf	Jaguar F-Pace (X761)	TCM - Transmission Control Module	EXE
HK83-7J104-BLB.vbf	Jaguar F-Pace (X761)	TCM - Transmission Control Module	EXE
HK83-7J104-BLC.vbf	Jaguar F-Pace (X761)	TCM - Transmission Control Module	EXE
HK83-7J104-BLD.vbf	Jaguar F-Pace (X761)	TCM - Transmission Control Module	EXE
HK83-7J104-BMA.vbf	Jaguar F-Pace (X761)	TCM - Transmission Control Module	EXE
HK83-7J104-BMB.vbf	Jaguar F-Pace (X761)	TCM - Transmission Control Module	EXE
HK83-7J104-BXA.vbf	Jaguar F-Pace (X761)	TCM - Transmission Control Module	EXE
HK83-7J104-BXB.vbf	Jaguar F-Pace (X761)	TCM - Transmission Control Module	EXE
HK83-7J104-BXC.vbf	Jaguar F-Pace (X761)	TCM - Transmission Control Module	EXE
HK83-7J104-BXD.vbf	Jaguar F-Pace (X761)	TCM - Transmission Control Module	EXE
HK8M-12K532-PTA.vbf	Not specified	PCM - Powertrain Control Module	DATA
HK8M-12K532-PTB.vbf	Not specified	PCM - Powertrain Control Module	DATA
HK8M-12K532-PTC.vbf	Not specified	PCM - Powertrain Control Module	DATA
HPLA-12K532-HMC.vbf	Multiple models (shared module)	PCM - Powertrain Control Module	DATA
HPLA-12K532-HNA.vbf	Multiple models (shared module)	PCM - Powertrain Control Module	DATA

File name	Vehicle line (indicative)	Module (ECU)	Type
HPLA-12K532-HNB.vbf	Multiple models (shared module)	PCM - Powertrain Control Module	DATA
HPLA-12K532-HNC.vbf	Multiple models (shared module)	PCM - Powertrain Control Module	DATA
HPLA-12K532-PCD.vbf	Multiple models (shared module)	PCM - Powertrain Control Module	DATA
HPLA-12K532-PCE.vbf	Multiple models (shared module)	PCM - Powertrain Control Module	DATA
HPLA-12K532-PDD.vbf	Multiple models (shared module)	PCM - Powertrain Control Module	DATA
HPLA-12K532-PDE.vbf	Multiple models (shared module)	PCM - Powertrain Control Module	DATA
HPLA-12K532-PDF.vbf	Multiple models (shared module)	PCM - Powertrain Control Module	DATA
HPLA-12K532-PEB.vbf	Multiple models (shared module)	PCM - Powertrain Control Module	DATA
HPLA-12K532-PED.vbf	Multiple models (shared module)	PCM - Powertrain Control Module	DATA
HPLA-12K532-PEE.vbf	Multiple models (shared module)	PCM - Powertrain Control Module	DATA
HPLA-12K532-PEF.vbf	Multiple models (shared module)	PCM - Powertrain Control Module	DATA
HPLA-12K532-PFD.vbf	Multiple models (shared module)	PCM - Powertrain Control Module	DATA
HPLA-12K532-PFE.vbf	Multiple models (shared module)	PCM - Powertrain Control Module	DATA
HPLA-12K532-PFF.vbf	Multiple models (shared module)	PCM - Powertrain Control Module	DATA
HPLA-12K532-PGD.vbf	Multiple models (shared module)	PCM - Powertrain Control Module	DATA
HPLA-12K532-PGE.vbf	Multiple models (shared module)	PCM - Powertrain Control Module	DATA
HPLA-12K532-PGF.vbf	Multiple models (shared module)	PCM - Powertrain Control Module	DATA
HPLA-12K532-PGG.vbf	Multiple models (shared module)	PCM - Powertrain Control Module	DATA
HPLA-12K532-PGH.vbf	Multiple models (shared module)	PCM - Powertrain Control Module	DATA
HPLA-12K532-PGJ.vbf	Multiple models (shared module)	PCM - Powertrain Control Module	EXE
HPLA-12K532-PHD.vbf	Multiple models (shared module)	PCM - Powertrain Control Module	DATA
HPLA-12K532-PHE.vbf	Multiple models (shared module)	PCM - Powertrain Control Module	DATA
HPLA-12K532-PHF.vbf	Multiple models (shared module)	PCM - Powertrain Control Module	DATA
HPLA-12K532-PHG.vbf	Multiple models (shared module)	PCM - Powertrain Control Module	DATA
HPLA-12K532-PHH.vbf	Multiple models (shared module)	PCM - Powertrain Control Module	DATA
HPLA-12K532-PHJ.vbf	Multiple models (shared module)	PCM - Powertrain Control Module	EXE
HPLA-12K532-PJA.vbf	Multiple models (shared module)	PCM - Powertrain Control Module	DATA
HPLA-12K532-PJB.vbf	Multiple models (shared module)	PCM - Powertrain Control Module	DATA
HPLA-12K532-PJC.vbf	Multiple models (shared module)	PCM - Powertrain Control Module	DATA
HPLA-12K532-PJD.vbf	Multiple models (shared module)	PCM - Powertrain Control Module	DATA
HPLA-12K532-PJE.vbf	Multiple models (shared module)	PCM - Powertrain Control Module	DATA
HPLA-12K532-PJF.vbf	Multiple models (shared module)	PCM - Powertrain Control Module	DATA
HPLA-12K532-PJG.vbf	Multiple models (shared module)	PCM - Powertrain Control Module	DATA
HPLA-12K532-PJH.vbf	Multiple models (shared module)	PCM - Powertrain Control Module	DATA
HPLA-12K532-PJJ.vbf	Multiple models (shared module)	PCM - Powertrain Control Module	EXE
HPLA-12K532-PKA.vbf	Multiple models (shared module)	PCM - Powertrain Control Module	DATA
HPLA-12K532-PKD.vbf	Multiple models (shared module)	PCM - Powertrain Control Module	DATA
HPLA-12K532-PKE.vbf	Multiple models (shared module)	PCM - Powertrain Control Module	DATA
HPLA-12K532-PKF.vbf	Multiple models (shared module)	PCM - Powertrain Control Module	DATA
HPLA-12K532-PKG.vbf	Multiple models (shared module)	PCM - Powertrain Control Module	DATA
HPLA-12K532-PKH.vbf	Multiple models (shared module)	PCM - Powertrain Control Module	DATA
HPLA-12K532-PKJ.vbf	Multiple models (shared module)	PCM - Powertrain Control Module	DATA
HPLA-12K532-PKK.vbf	Multiple models (shared module)	PCM - Powertrain Control Module	DATA
HPLA-12K532-PKL.vbf	Multiple models (shared module)	PCM - Powertrain Control Module	DATA
HPLA-12K532-PPD.vbf	Multiple models (shared module)	PCM - Powertrain Control Module	DATA
HPLA-12K532-PPE.vbf	Multiple models (shared module)	PCM - Powertrain Control Module	DATA
HPLA-12K532-PPF.vbf	Multiple models (shared module)	PCM - Powertrain Control Module	DATA
HPLA-12K532-PSB.vbf	Multiple models (shared module)	PCM - Powertrain Control Module	DATA
HPLA-12K532-PSD.vbf	Multiple models (shared module)	PCM - Powertrain Control Module	DATA
HPLA-12K532-PSE.vbf	Multiple models (shared module)	PCM - Powertrain Control Module	DATA
HPLA-12K532-PSF.vbf	Multiple models (shared module)	PCM - Powertrain Control Module	DATA
HPLA-12K532-PSG.vbf	Multiple models (shared module)	PCM - Powertrain Control Module	DATA
HPLA-14C025-AA.vbf	Multiple models (shared module)	IPC - Instrument Panel Cluster (IPC) Control Module	SBL
HPLA-14C025-BA.vbf	Multiple models (shared module)	IPC - Instrument Panel Cluster (IPC) Control Module	SBL
HPLA-14C025-BB.vbf	Multiple models (shared module)	IPC - Instrument Panel Cluster (IPC) Control Module	SBL
HPLA-14C025-CA.vbf	Multiple models (shared module)	IPC - Instrument Panel Cluster (IPC) Control Module	SBL
HPLA-14C026-AA.vbf	Multiple models (shared module)	IPC - Instrument Panel Cluster (IPC) Control Module	EXE
HPLA-14C026-AB.vbf	Multiple models (shared module)	IPC - Instrument Panel Cluster (IPC) Control Module	EXE
HPLA-14C026-AC.vbf	Multiple models (shared module)	IPC - Instrument Panel Cluster (IPC) Control Module	EXE
HPLA-14C026-AD.vbf	Multiple models (shared module)	IPC - Instrument Panel Cluster (IPC) Control Module	EXE
HPLA-14C026-AE.vbf	Multiple models (shared module)	IPC - Instrument Panel Cluster (IPC) Control Module	EXE
HPLA-14C026-JB.vbf	Multiple models (shared module)	IPC - Instrument Panel Cluster (IPC) Control Module	EXE
HPLA-14C026-JC.vbf	Multiple models (shared module)	IPC - Instrument Panel Cluster (IPC) Control Module	EXE
HPLA-14C026-JD.vbf	Multiple models (shared module)	IPC - Instrument Panel Cluster (IPC) Control Module	EXE
HPLA-14C026-JE.vbf	Multiple models (shared module)	IPC - Instrument Panel Cluster (IPC) Control Module	EXE
HPLA-14C026-JEX.vbf	Multiple models (shared module)	IPC - Instrument Panel Cluster (IPC) Control Module	EXE
HPLA-14C026-JEY.vbf	Multiple models (shared module)	IPC - Instrument Panel Cluster (IPC) Control Module	EXE
HPLA-14C026-JF.vbf	Multiple models (shared module)	IPC - Instrument Panel Cluster (IPC) Control Module	EXE
HPLA-14C026-KB.vbf	Multiple models (shared module)	IPC - Instrument Panel Cluster (IPC) Control Module	EXE
HPLA-14C026-KC.vbf	Multiple models (shared module)	IPC - Instrument Panel Cluster (IPC) Control Module	DATA
HPLA-14C026-KD.vbf	Multiple models (shared module)	IPC - Instrument Panel Cluster (IPC) Control Module	DATA
HPLA-14C026-KE.vbf	Multiple models (shared module)	IPC - Instrument Panel Cluster (IPC) Control Module	EXE
HPLA-14C026-LB.vbf	Multiple models (shared module)	IPC - Instrument Panel Cluster (IPC) Control Module	DATA
HPLA-14C026-LC.vbf	Multiple models (shared module)	IPC - Instrument Panel Cluster (IPC) Control Module	DATA
HPLA-14C026-LD.vbf	Multiple models (shared module)	IPC - Instrument Panel Cluster (IPC) Control Module	EXE
HPLA-14C026-MA.vbf	Multiple models (shared module)	IPC - Instrument Panel Cluster (IPC) Control Module	EXE

File name	Vehicle line (indicative)	Module (ECU)	Type
HPLA-14C027-AA.vbf	Multiple models (shared module)	RCM - Restraints Control Module	SBL
HPLA-14C028-AB.vbf	Multiple models (shared module)	SRS - Airbag	EXE
HPLA-14C030-AA.vbf	Multiple models (shared module)	DSM - Driver Front Seat Module	EXE
HPLA-14C036-AC.vbf	Multiple models (shared module)	ABS - Anti-Lock Brake System Control Module	DATA
HPLA-14C036-AD.vbf	Multiple models (shared module)	ABS - Anti-Lock Brake System Control Module	EXE
HPLA-14C036-AE.vbf	Multiple models (shared module)	ABS - Anti-Lock Brake System Control Module	EXE
HPLA-14C036-AF.vbf	Multiple models (shared module)	ABS - Anti-Lock Brake System Control Module	EXE
HPLA-14C036-AG.vbf	Multiple models (shared module)	ABS - Anti-Lock Brake System Control Module	EXE
HPLA-14C036-BF.vbf	Multiple models (shared module)	ABS - Anti-Lock Brake System Control Module	EXE
HPLA-14C036-BG.vbf	Multiple models (shared module)	ABS - Anti-Lock Brake System Control Module	EXE
HPLA-14C036-BH.vbf	Multiple models (shared module)	ABS - Anti-Lock Brake System Control Module	EXE
HPLA-14C036-BJ.vbf	Multiple models (shared module)	ABS - Anti-Lock Brake System Control Module	EXE
HPLA-14C039-AA.vbf	Multiple models (shared module)	ABS - Anti-Lock Brake System Control Module	SBL
HPLA-14C039-AB.vbf	Multiple models (shared module)	ABS - Anti-Lock Brake System Control Module	SBL
HPLA-14C039-BA.vbf	Multiple models (shared module)	ABS - Anti-Lock Brake System Control Module	SBL
HPLA-14C064-AB.vbf	Multiple models (shared module)	DDM - Driver Front Door Module	EXE
HPLA-14C064-AC.vbf	Multiple models (shared module)	DDM - Driver Front Door Module	EXE
HPLA-14C064-AD.vbf	Multiple models (shared module)	DDM - Driver Front Door Module	EXE
HPLA-14C064-AE.vbf	Multiple models (shared module)	DDM - Driver Front Door Module	EXE
HPLA-14C064-AF.vbf	Multiple models (shared module)	DDM - Driver Front Door Module	EXE
HPLA-14C064-BB.vbf	Multiple models (shared module)	DDM - Driver Front Door Module	EXE
HPLA-14C064-BC.vbf	Multiple models (shared module)	DDM - Driver Front Door Module	EXE
HPLA-14C064-BD.vbf	Multiple models (shared module)	DDM - Driver Front Door Module	EXE
HPLA-14C064-BE.vbf	Multiple models (shared module)	DDM - Driver Front Door Module	EXE
HPLA-14C064-BF.vbf	Multiple models (shared module)	DDM - Driver Front Door Module	EXE
HPLA-14C064-CC.vbf	Multiple models (shared module)	DDM - Driver Front Door Module	EXE
HPLA-14C064-CD.vbf	Multiple models (shared module)	DDM - Driver Front Door Module	EXE
HPLA-14C064-CE.vbf	Multiple models (shared module)	DDM - Driver Front Door Module	EXE
HPLA-14C067-AC.vbf	Multiple models (shared module)	DDM - Driver Front Door Module	SBL
HPLA-14C068-AB.vbf	Multiple models (shared module)	DRDM - Driver Rear Door Module	EXE
HPLA-14C068-AC.vbf	Multiple models (shared module)	DRDM - Driver Rear Door Module	EXE
HPLA-14C068-AD.vbf	Multiple models (shared module)	DRDM - Driver Rear Door Module	EXE
HPLA-14C068-AE.vbf	Multiple models (shared module)	DRDM - Driver Rear Door Module	EXE
HPLA-14C068-AF.vbf	Multiple models (shared module)	DRDM - Driver Rear Door Module	EXE
HPLA-14C068-BB.vbf	Multiple models (shared module)	DRDM - Driver Rear Door Module	EXE
HPLA-14C068-BC.vbf	Multiple models (shared module)	DRDM - Driver Rear Door Module	EXE
HPLA-14C068-BD.vbf	Multiple models (shared module)	DRDM - Driver Rear Door Module	EXE
HPLA-14C068-BE.vbf	Multiple models (shared module)	DRDM - Driver Rear Door Module	EXE
HPLA-14C068-BF.vbf	Multiple models (shared module)	DRDM - Driver Rear Door Module	EXE
HPLA-14C068-CC.vbf	Multiple models (shared module)	DRDM - Driver Rear Door Module	EXE
HPLA-14C068-CD.vbf	Multiple models (shared module)	DRDM - Driver Rear Door Module	EXE
HPLA-14C068-CE.vbf	Multiple models (shared module)	DRDM - Driver Rear Door Module	EXE
HPLA-14C071-AC.vbf	Multiple models (shared module)	DRDM - Driver Rear Door Module	SBL
HPLA-14C088-BB.vbf	Multiple models (shared module)	IPC - Instrument Panel Cluster (IPC) Control Module	DATA
HPLA-14C088-CA.vbf	Multiple models (shared module)	IPC - Instrument Panel Cluster (IPC) Control Module	EXE
HPLA-14C088-CB.vbf	Multiple models (shared module)	IPC - Instrument Panel Cluster (IPC) Control Module	EXE
HPLA-14C088-CC.vbf	Multiple models (shared module)	IPC - Instrument Panel Cluster (IPC) Control Module	EXE
HPLA-14C088-CD.vbf	Multiple models (shared module)	IPC - Instrument Panel Cluster (IPC) Control Module	EXE
HPLA-14C088-DA.vbf	Multiple models (shared module)	IPC - Instrument Panel Cluster (IPC) Control Module	DATA
HPLA-14C088-JB.vbf	Multiple models (shared module)	IPC - Instrument Panel Cluster (IPC) Control Module	DATA
HPLA-14C088-JC.vbf	Multiple models (shared module)	IPC - Instrument Panel Cluster (IPC) Control Module	DATA
HPLA-14C088-JD.vbf	Multiple models (shared module)	IPC - Instrument Panel Cluster (IPC) Control Module	DATA
HPLA-14C088-JE.vbf	Multiple models (shared module)	IPC - Instrument Panel Cluster (IPC) Control Module	DATA
HPLA-14C088-JF.vbf	Multiple models (shared module)	IPC - Instrument Panel Cluster (IPC) Control Module	DATA
HPLA-14C104-AC.vbf	Multiple models (shared module)	TMC Traffic Message Channel Module	EXE
HPLA-14C104-AG.vbf	Multiple models (shared module)	TMC Traffic Message Channel Module	EXE
HPLA-14C104-AH.vbf	Multiple models (shared module)	TMC Traffic Message Channel Module	EXE
HPLA-14C104-AJ.vbf	Multiple models (shared module)	TMC Traffic Message Channel Module	EXE
HPLA-14C104-KC.vbf	Multiple models (shared module)	TMC Traffic Message Channel Module	EXE
HPLA-14C104-KG.vbf	Multiple models (shared module)	TMC Traffic Message Channel Module	EXE
HPLA-14C104-KH.vbf	Multiple models (shared module)	TMC Traffic Message Channel Module	EXE
HPLA-14C104-KJ.vbf	Multiple models (shared module)	TMC Traffic Message Channel Module	EXE
HPLA-14C107-AA.vbf	Multiple models (shared module)	TMC Traffic Message Channel Module	SBL
HPLA-14C107-AB.vbf	Multiple models (shared module)	TMC Traffic Message Channel Module	SBL
HPLA-14C108-AB.vbf	Multiple models (shared module)	PDM - Passenger Front Door Module	EXE
HPLA-14C108-AC.vbf	Multiple models (shared module)	PDM - Passenger Front Door Module	EXE
HPLA-14C108-AD.vbf	Multiple models (shared module)	PDM - Passenger Front Door Module	EXE
HPLA-14C108-AE.vbf	Multiple models (shared module)	PDM - Passenger Front Door Module	EXE
HPLA-14C108-AF.vbf	Multiple models (shared module)	PDM - Passenger Front Door Module	EXE
HPLA-14C108-BB.vbf	Multiple models (shared module)	PDM - Passenger Front Door Module	EXE
HPLA-14C108-BC.vbf	Multiple models (shared module)	PDM - Passenger Front Door Module	EXE
HPLA-14C108-BD.vbf	Multiple models (shared module)	PDM - Passenger Front Door Module	EXE
HPLA-14C108-BE.vbf	Multiple models (shared module)	PDM - Passenger Front Door Module	EXE
HPLA-14C108-BF.vbf	Multiple models (shared module)	PDM - Passenger Front Door Module	EXE
HPLA-14C108-CC.vbf	Multiple models (shared module)	PDM - Passenger Front Door Module	EXE
HPLA-14C108-CD.vbf	Multiple models (shared module)	PDM - Passenger Front Door Module	EXE

File name	Vehicle line (indicative)	Module (ECU)	Type
HPLA-14C108-CE.vbf	Multiple models (shared module)	PDM - Passenger Front Door Module	EXE
HPLA-14C111-AC.vbf	Multiple models (shared module)	PDM - Passenger Front Door Module	SBL
HPLA-14C112-AB.vbf	Multiple models (shared module)	PRDM - Passenger Rear Door Module	EXE
HPLA-14C112-AC.vbf	Multiple models (shared module)	PRDM - Passenger Rear Door Module	EXE
HPLA-14C112-AD.vbf	Multiple models (shared module)	PRDM - Passenger Rear Door Module	EXE
HPLA-14C112-AE.vbf	Multiple models (shared module)	PRDM - Passenger Rear Door Module	EXE
HPLA-14C112-AF.vbf	Multiple models (shared module)	PRDM - Passenger Rear Door Module	EXE
HPLA-14C112-BB.vbf	Multiple models (shared module)	PRDM - Passenger Rear Door Module	EXE
HPLA-14C112-BC.vbf	Multiple models (shared module)	PRDM - Passenger Rear Door Module	EXE
HPLA-14C112-BD.vbf	Multiple models (shared module)	PRDM - Passenger Rear Door Module	EXE
HPLA-14C112-BE.vbf	Multiple models (shared module)	PRDM - Passenger Rear Door Module	EXE
HPLA-14C112-BF.vbf	Multiple models (shared module)	PRDM - Passenger Rear Door Module	EXE
HPLA-14C112-CC.vbf	Multiple models (shared module)	PRDM - Passenger Rear Door Module	EXE
HPLA-14C112-CD.vbf	Multiple models (shared module)	PRDM - Passenger Rear Door Module	EXE
HPLA-14C112-CE.vbf	Multiple models (shared module)	PRDM - Passenger Rear Door Module	EXE
HPLA-14C115-AC.vbf	Multiple models (shared module)	PRDM - Passenger Rear Door Module	SBL
HPLA-14C184-BA.vbf	Multiple models (shared module)	BCM - Body Control Module	CUSTOM
HPLA-14C184-BB.vbf	Multiple models (shared module)	BCM - Body Control Module	CUSTOM
HPLA-14C184-BC.vbf	Multiple models (shared module)	BCM - Body Control Module	CUSTOM
HPLA-14C184-BD.vbf	Multiple models (shared module)	BCM - Body Control Module	CUSTOM
HPLA-14C184-BE.vbf	Multiple models (shared module)	BCM - Body Control Module	CUSTOM
HPLA-14C184-BG.vbf	Multiple models (shared module)	BCM - Body Control Module	CUSTOM
HPLA-14C184-BH.vbf	Multiple models (shared module)	BCM - Body Control Module	CUSTOM
HPLA-14C184-BJ.vbf	Multiple models (shared module)	BCM - Body Control Module	CUSTOM
HPLA-14C184-BK.vbf	Multiple models (shared module)	BCM - Body Control Module	CUSTOM
HPLA-14C184-BL.vbf	Multiple models (shared module)	BCM - Body Control Module	CUSTOM
HPLA-14C187-BA.vbf	Multiple models (shared module)	BCM - Body Control Module	SBL
HPLA-14C187-BB.vbf	Multiple models (shared module)	BCM - Body Control Module	SBL
HPLA-14C187-BC.vbf	Multiple models (shared module)	BCM - Body Control Module	SBL
HPLA-14C187-BD.vbf	Multiple models (shared module)	BCM - Body Control Module	SBL
HPLA-14C197-AA.VBF	Multiple models (shared module)	BECM - Battery Energy Control Module	EXE
HPLA-14C198-AB.VBF	Multiple models (shared module)	BECM - Battery Energy Control Module	EXE
HPLA-14C204-PHA.vbf	Multiple models (shared module)	PCM - Powertrain Control Module	EXE
HPLA-14C204-PHB.vbf	Multiple models (shared module)	PCM - Powertrain Control Module	EXE
HPLA-14C217-AA.vbf	Multiple models (shared module)	PSCM - Power Steering Control Module	EXE
HPLA-14C217-AB.vbf	Multiple models (shared module)	PSCM - Power Steering Control Module	EXE
HPLA-14C217-AC.vbf	Multiple models (shared module)	PSCM - Power Steering Control Module	EXE
HPLA-14C217-AD.vbf	Multiple models (shared module)	PSCM - Power Steering Control Module	EXE
HPLA-14C217-AE.vbf	Multiple models (shared module)	PSCM - Power Steering Control Module	EXE
HPLA-14C273-HAA.VBF	Multiple models (shared module)	PCM - Powertrain Control Module	SBL
HPLA-14C273-PAA.VBF	Multiple models (shared module)	PCM - Powertrain Control Module	SBL
HPLA-14C320-AC.vbf	Multiple models (shared module)	PDM - Passenger Front Door Module	SIGCFG
HPLA-14C320-AD.vbf	Multiple models (shared module)	PDM - Passenger Front Door Module	SIGCFG
HPLA-14C320-AE.vbf	Multiple models (shared module)	PDM - Passenger Front Door Module	SIGCFG
HPLA-14C320-AF.vbf	Multiple models (shared module)	PDM - Passenger Front Door Module	SIGCFG
HPLA-14C321-AC.vbf	Multiple models (shared module)	DDM - Driver Front Door Module	SIGCFG
HPLA-14C321-AD.vbf	Multiple models (shared module)	DDM - Driver Front Door Module	SIGCFG
HPLA-14C321-AE.vbf	Multiple models (shared module)	DDM - Driver Front Door Module	SIGCFG
HPLA-14C321-AF.vbf	Multiple models (shared module)	DDM - Driver Front Door Module	SIGCFG
HPLA-14C366-AA.vbf	Multiple models (shared module)	TCCM - Transfer Case Control Module	EXE
HPLA-14C366-AB.vbf	Multiple models (shared module)	TCCM - Transfer Case Control Module	EXE
HPLA-14C366-AC.vbf	Multiple models (shared module)	TCCM - Transfer Case Control Module	EXE
HPLA-14C366-AD.vbf	Multiple models (shared module)	TCCM - Transfer Case Control Module	EXE
HPLA-14C366-AE.vbf	Multiple models (shared module)	TCCM - Transfer Case Control Module	EXE
HPLA-14C366-AF.vbf	Multiple models (shared module)	TCCM - Transfer Case Control Module	EXE
HPLA-14C366-AG.vbf	Multiple models (shared module)	TCCM - Transfer Case Control Module	EXE
HPLA-14C366-AH.vbf	Multiple models (shared module)	TCCM - Transfer Case Control Module	EXE
HPLA-14C366-AJ.vbf	Multiple models (shared module)	TCCM - Transfer Case Control Module	EXE
HPLA-14C368-AA.vbf	Multiple models (shared module)	TCCM - Transfer Case Control Module	SBL
HPLA-14C368-AB.vbf	Multiple models (shared module)	TCCM - Transfer Case Control Module	SBL
HPLA-14C368-AC.vbf	Multiple models (shared module)	TCCM - Transfer Case Control Module	SBL
HPLA-14C377-AA.vbf	Multiple models (shared module)	PAM - Parking Assist Control Module	SIGCFG
HPLA-14C377-AB.vbf	Multiple models (shared module)	PAM - Parking Assist Control Module	SIGCFG
HPLA-14C377-AC.vbf	Multiple models (shared module)	PAM - Parking Assist Control Module	SIGCFG
HPLA-14C386-AA.vbf	Multiple models (shared module)	PSCM - Power Steering Control Module	EXE
HPLA-14C387-AA.VBF	Multiple models (shared module)	SASM - Steering Angle Sensor Module	SIGCFG
HPLA-14C407-AB.vbf	Multiple models (shared module)	RCM - Restraints Control Module	SIGCFG
HPLA-14C408-AA.vbf	Multiple models (shared module)	BCM - Body Control Module	SIGCFG
HPLA-14C408-AB.vbf	Multiple models (shared module)	BCM - Body Control Module	SIGCFG
HPLA-14C408-AC.vbf	Multiple models (shared module)	BCM - Body Control Module	SIGCFG
HPLA-14C408-AD.vbf	Multiple models (shared module)	BCM - Body Control Module	SIGCFG
HPLA-14C408-AE.vbf	Multiple models (shared module)	BCM - Body Control Module	SIGCFG
HPLA-14C410-AC.vbf	Multiple models (shared module)	PRDM - Passenger Rear Door Module	SIGCFG
HPLA-14C410-AD.vbf	Multiple models (shared module)	PRDM - Passenger Rear Door Module	SIGCFG
HPLA-14C410-AE.vbf	Multiple models (shared module)	PRDM - Passenger Rear Door Module	SIGCFG
HPLA-14C410-AF.vbf	Multiple models (shared module)	PRDM - Passenger Rear Door Module	SIGCFG

File name	Vehicle line (indicative)	Module (ECU)	Type
HPLA-14C410-AG.vbf	Multiple models (shared module)	PRDM - Passenger Rear Door Module	SIGCFG
HPLA-14C430-AA.vbf	Multiple models (shared module)	TMC Traffic Message Channel Module	DATA
HPLA-14C430-AF.vbf	Multiple models (shared module)	TMC Traffic Message Channel Module	DATA
HPLA-14C433-AA.vbf	Multiple models (shared module)	RGTM - Rear Gate / Trunk Module	SIGCFG
HPLA-14C434-AA.vbf	Multiple models (shared module)	TPM - Tire Pressure Monitor Module	SIGCFG
HPLA-14C434-AC.vbf	Multiple models (shared module)	TPM - Tire Pressure Monitor Module	SIGCFG
HPLA-14C435-AC.vbf	Multiple models (shared module)	DRDM - Driver Rear Door Module	SIGCFG
HPLA-14C435-AD.vbf	Multiple models (shared module)	DRDM - Driver Rear Door Module	SIGCFG
HPLA-14C435-AE.vbf	Multiple models (shared module)	DRDM - Driver Rear Door Module	SIGCFG
HPLA-14C435-AF.vbf	Multiple models (shared module)	DRDM - Driver Rear Door Module	SIGCFG
HPLA-14C435-AG.vbf	Multiple models (shared module)	DRDM - Driver Rear Door Module	SIGCFG
HPLA-14C548-AA.vbf	Multiple models (shared module)	PSM - Passenger Front Seat Module	EXE
HPLA-14C560-BA.vbf	Multiple models (shared module)	GSM - Gear Shift Module	SIGCFG
HPLA-14C560-CA.vbf	Multiple models (shared module)	GSM - Gear Shift Module	SIGCFG
HPLA-14C561-AC.vbf	Multiple models (shared module)	GSM - Gear Shift Module	EXE
HPLA-14C561-BA.vbf	Multiple models (shared module)	GSM - Gear Shift Module	EXE
HPLA-14C561-BB.vbf	Multiple models (shared module)	GSM - Gear Shift Module	EXE
HPLA-14C561-BC.vbf	Multiple models (shared module)	GSM - Gear Shift Module	EXE
HPLA-14C561-CA.vbf	Multiple models (shared module)	GSM - Gear Shift Module	EXE
HPLA-14C570-SAA.vbf	Multiple models (shared module)	PCM - Powertrain Control Module	EXE
HPLA-14C570-SAB.vbf	Multiple models (shared module)	PCM - Powertrain Control Module	EXE
HPLA-14C570-SAC.vbf	Multiple models (shared module)	PCM - Powertrain Control Module	EXE
HPLA-14C570-SAD.vbf	Multiple models (shared module)	PCM - Powertrain Control Module	EXE
HPLA-14C570-SAE.vbf	Multiple models (shared module)	PCM - Powertrain Control Module	EXE
HPLA-14C570-SAF.vbf	Multiple models (shared module)	PCM - Powertrain Control Module	EXE
HPLA-14C570-SCA.vbf	Multiple models (shared module)	PCM - Powertrain Control Module	EXE
HPLA-14C570-SCC.vbf	Multiple models (shared module)	PCM - Powertrain Control Module	EXE
HPLA-14C570-SCD.vbf	Multiple models (shared module)	PCM - Powertrain Control Module	EXE
HPLA-14C570-SCE.vbf	Multiple models (shared module)	PCM - Powertrain Control Module	EXE
HPLA-14C570-SEA.vbf	Multiple models (shared module)	PCM - Powertrain Control Module	EXE
HPLA-14C570-SEB.vbf	Multiple models (shared module)	PCM - Powertrain Control Module	EXE
HPLA-14C570-SEC.vbf	Multiple models (shared module)	PCM - Powertrain Control Module	EXE
HPLA-14C570-SED.vbf	Multiple models (shared module)	PCM - Powertrain Control Module	EXE
HPLA-14C570-STA.vbf	Multiple models (shared module)	PCM - Powertrain Control Module	EXE
HPLA-14C570-STB.vbf	Multiple models (shared module)	PCM - Powertrain Control Module	EXE
HPLA-14C570-STC.vbf	Multiple models (shared module)	PCM - Powertrain Control Module	EXE
HPLA-14C570-STE.vbf	Multiple models (shared module)	PCM - Powertrain Control Module	EXE
HPLA-14C570-STF.vbf	Multiple models (shared module)	PCM - Powertrain Control Module	EXE
HPLA-14C570-UAA.vbf	Multiple models (shared module)	PCM - Powertrain Control Module	EXE
HPLA-14C570-UAB.vbf	Multiple models (shared module)	PCM - Powertrain Control Module	EXE
HPLA-14C570-UAC.vbf	Multiple models (shared module)	PCM - Powertrain Control Module	EXE
HPLA-14C570-UAD.vbf	Multiple models (shared module)	PCM - Powertrain Control Module	EXE
HPLA-14C570-UAE.vbf	Multiple models (shared module)	PCM - Powertrain Control Module	EXE
HPLA-14C570-UAF.vbf	Multiple models (shared module)	PCM - Powertrain Control Module	EXE
HPLA-14C570-UCA.vbf	Multiple models (shared module)	PCM - Powertrain Control Module	EXE
HPLA-14C570-UCC.vbf	Multiple models (shared module)	PCM - Powertrain Control Module	EXE
HPLA-14C570-UCD.vbf	Multiple models (shared module)	PCM - Powertrain Control Module	EXE
HPLA-14C570-UCE.vbf	Multiple models (shared module)	PCM - Powertrain Control Module	EXE
HPLA-14C570-UEA.vbf	Multiple models (shared module)	PCM - Powertrain Control Module	EXE
HPLA-14C570-UEB.vbf	Multiple models (shared module)	PCM - Powertrain Control Module	EXE
HPLA-14C570-UEC.vbf	Multiple models (shared module)	PCM - Powertrain Control Module	EXE
HPLA-14C570-UED.vbf	Multiple models (shared module)	PCM - Powertrain Control Module	EXE
HPLA-14C570-UTA.vbf	Multiple models (shared module)	PCM - Powertrain Control Module	EXE
HPLA-14C570-UTB.vbf	Multiple models (shared module)	PCM - Powertrain Control Module	EXE
HPLA-14C570-UTC.vbf	Multiple models (shared module)	PCM - Powertrain Control Module	EXE
HPLA-14C570-UTE.vbf	Multiple models (shared module)	PCM - Powertrain Control Module	EXE
HPLA-14C570-UTF.vbf	Multiple models (shared module)	PCM - Powertrain Control Module	EXE
HPLA-14C570-UTG.vbf	Multiple models (shared module)	PCM - Powertrain Control Module	EXE
HPLA-14C572-TA.VBF	Multiple models (shared module)	PCM - Powertrain Control Module	SBL
HPLA-14C572-TB.vbf	Multiple models (shared module)	PCM - Powertrain Control Module	SBL
HPLA-14C572-TC.vbf	Multiple models (shared module)	PCM - Powertrain Control Module	SBL
HPLA-14C578-AB.vbf	Multiple models (shared module)	VIM - Vehicle Immobilizer Control Module	SIGCFG
HPLA-14C579-AA.vbf	Multiple models (shared module)	VIM - Vehicle Immobilizer Control Module	EXE
HPLA-14C581-AA.vbf	Multiple models (shared module)	VIM - Vehicle Immobilizer Control Module	SBL
HPLA-14D016-AA.vbf	Multiple models (shared module)	FCIM - Front Controls Interface Module	SIGCFG
HPLA-14D017-AB.vbf	Multiple models (shared module)	FCIM - Front Controls Interface Module	EXE
HPLA-14D018-AB.vbf	Multiple models (shared module)	FCIM - Front Controls Interface Module	CUSTOM
HPLA-14D019-AA.vbf	Multiple models (shared module)	FCIM - Front Controls Interface Module	SBL
HPLA-14D023-AC.vbf	Multiple models (shared module)	ATCM - All Terrain Control Module	SIGCFG
HPLA-14D023-BA.vbf	Range Rover Sport (L494)	ATCM - All Terrain Control Module	SIGCFG
HPLA-14D024-AB.vbf	Multiple models (shared module)	ATCM - All Terrain Control Module	EXE
HPLA-14D024-AC.vbf	Multiple models (shared module)	ATCM - All Terrain Control Module	EXE
HPLA-14D024-AD.vbf	Multiple models (shared module)	ATCM - All Terrain Control Module	EXE
HPLA-14D024-BA.vbf	Range Rover Sport (L494)	ATCM - All Terrain Control Module	EXE
HPLA-14D024-CA.vbf	Range Rover Sport (L494)	ATCM - All Terrain Control Module	EXE
HPLA-14D026-AB.vbf	Multiple models (shared module)	ATCM - All Terrain Control Module	SBL

File name	Vehicle line (indicative)	Module (ECU)	Type
HPLA-14D026-AC.vbf	Multiple models (shared module)	ATCM - All Terrain Control Module	SBL
HPLA-14D026-AD.vbf	Multiple models (shared module)	ATCM - All Terrain Control Module	SBL
HPLA-14D026-BA.vbf	Multiple models (shared module)	ATCM - All Terrain Control Module	SBL
HPLA-14D048-AC.vbf	Multiple models (shared module)	CCM - Cruise Control Module	SIGCFG
HPLA-14D048-AD.vbf	Multiple models (shared module)	CCM - Cruise Control Module	SIGCFG
HPLA-14D049-AB.vbf	Multiple models (shared module)	CCM - Cruise Control Module	EXE
HPLA-14D049-AC.vbf	Multiple models (shared module)	CCM - Cruise Control Module	EXE
HPLA-14D049-AD.vbf	Multiple models (shared module)	CCM - Cruise Control Module	EXE
HPLA-14D049-AE.vbf	Multiple models (shared module)	CCM - Cruise Control Module	EXE
HPLA-14D181-AB.vbf	Multiple models (shared module)	OCS - Restraints Occupant Classification System Module	SIGCFG
HPLA-14D367-AA.vbf	Multiple models (shared module)	SODL - Side Obstacle Detection Control Module - Left	SIGCFG
HPLA-14D367-BA.vbf	Multiple models (shared module)	SODR - Side Obstacle Detection Control Module - Right	SIGCFG
HPLA-14D368-AC.vbf	Multiple models (shared module)	SODL - Side Obstacle Detection Control Module - Left	EXE
HPLA-14D368-AD.vbf	Multiple models (shared module)	SODL - Side Obstacle Detection Control Module - Left	EXE
HPLA-14D368-AE.vbf	Multiple models (shared module)	SODL - Side Obstacle Detection Control Module - Left	EXE
HPLA-14D368-AF.vbf	Multiple models (shared module)	SODL - Side Obstacle Detection Control Module - Left	EXE
HPLA-14D368-AG.vbf	Multiple models (shared module)	SODR - Side Obstacle Detection Control Module - Right	EXE
HPLA-14D368-BC.vbf	Multiple models (shared module)	SODL - Side Obstacle Detection Control Module - Left	EXE
HPLA-14D368-BD.vbf	Multiple models (shared module)	SODL - Side Obstacle Detection Control Module - Left	EXE
HPLA-14D368-BE.vbf	Multiple models (shared module)	SODL - Side Obstacle Detection Control Module - Left	EXE
HPLA-14D368-BF.vbf	Multiple models (shared module)	SODL - Side Obstacle Detection Control Module - Left	EXE
HPLA-14D368-BG.vbf	Multiple models (shared module)	SODR - Side Obstacle Detection Control Module - Right	EXE
HPLA-14D370-AC.vbf	Multiple models (shared module)	SODL - Side Obstacle Detection Control Module - Left	SBL
HPLA-14D370-AD.vbf	Multiple models (shared module)	SODL - Side Obstacle Detection Control Module - Left	SBL
HPLA-14D370-AE.vbf	Multiple models (shared module)	SODL - Side Obstacle Detection Control Module - Left	SBL
HPLA-14D480-AC.vbf	Multiple models (shared module)	IPMB - Image Processing Module B	EXE
HPLA-14D480-AD.vbf	Multiple models (shared module)	IPMB - Image Processing Module B	EXE
HPLA-14D480-AE.vbf	Multiple models (shared module)	IPMB - Image Processing Module B	EXE
HPLA-14D480-AF.vbf	Multiple models (shared module)	IPMB - Image Processing Module B	EXE
HPLA-14D480-AG.vbf	Multiple models (shared module)	IPMB - Image Processing Module B	EXE
HPLA-14D480-AH.vbf	Multiple models (shared module)	IPMB - Image Processing Module B	EXE
HPLA-14D480-AJ.vbf	Multiple models (shared module)	IPMB - Image Processing Module B	EXE
HPLA-14D519-AA.vbf	Multiple models (shared module)	HVAC - HVAC Control Module	EXE
HPLA-14D519-AB.vbf	Multiple models (shared module)	HVAC - HVAC Control Module	EXE
HPLA-14D519-AC.vbf	Multiple models (shared module)	HVAC - HVAC Control Module	EXE
HPLA-14D519-AD.vbf	Multiple models (shared module)	HVAC - HVAC Control Module	EXE
HPLA-14D520-AA.vbf	Multiple models (shared module)	HVAC - HVAC Control Module	DATA
HPLA-14D520-AB.vbf	Multiple models (shared module)	HVAC - HVAC Control Module	DATA
HPLA-14D520-AC.vbf	Multiple models (shared module)	HVAC - HVAC Control Module	DATA
HPLA-14D520-AD.vbf	Multiple models (shared module)	HVAC - HVAC Control Module	DATA
HPLA-14D520-AE.vbf	Multiple models (shared module)	HVAC - HVAC Control Module	DATA
HPLA-14D520-AF.vbf	Multiple models (shared module)	HVAC - HVAC Control Module	DATA
HPLA-14D520-BA.vbf	Multiple models (shared module)	HVAC - HVAC Control Module	DATA
HPLA-14D520-BB.vbf	Multiple models (shared module)	HVAC - HVAC Control Module	DATA
HPLA-14D520-BC.vbf	Multiple models (shared module)	HVAC - HVAC Control Module	DATA
HPLA-14D520-BD.vbf	Multiple models (shared module)	HVAC - HVAC Control Module	DATA
HPLA-14D520-CA.vbf	Multiple models (shared module)	HVAC - HVAC Control Module	DATA
HPLA-14D520-CB.vbf	Multiple models (shared module)	HVAC - HVAC Control Module	DATA
HPLA-14D520-CC.vbf	Multiple models (shared module)	HVAC - HVAC Control Module	DATA
HPLA-14D520-CD.vbf	Multiple models (shared module)	HVAC - HVAC Control Module	DATA
HPLA-14D520-CE.vbf	Multiple models (shared module)	HVAC - HVAC Control Module	DATA
HPLA-14D520-CF.vbf	Multiple models (shared module)	HVAC - HVAC Control Module	DATA
HPLA-14D520-DA.vbf	Multiple models (shared module)	HVAC - HVAC Control Module	DATA
HPLA-14D520-DB.vbf	Multiple models (shared module)	HVAC - HVAC Control Module	DATA
HPLA-14D520-DC.vbf	Multiple models (shared module)	HVAC - HVAC Control Module	DATA
HPLA-14D520-DD.vbf	Multiple models (shared module)	HVAC - HVAC Control Module	DATA
HPLA-14D520-EA.vbf	Multiple models (shared module)	HVAC - HVAC Control Module	DATA
HPLA-14D520-EB.vbf	Multiple models (shared module)	HVAC - HVAC Control Module	DATA
HPLA-14D520-EC.vbf	Multiple models (shared module)	HVAC - HVAC Control Module	DATA
HPLA-14D520-ED.vbf	Multiple models (shared module)	HVAC - HVAC Control Module	DATA
HPLA-14E093-JB.vbf	Multiple models (shared module)	CHCM - Chassis Control Module	EXE
HPLA-14E093-JC.vbf	Multiple models (shared module)	CHCM - Chassis Control Module	EXE
HPLA-14E093-JD.vbf	Multiple models (shared module)	CHCM - Chassis Control Module	EXE
HPLA-14E093-JE.vbf	Multiple models (shared module)	CHCM - Chassis Control Module	EXE
HPLA-14E093-JF.vbf	Multiple models (shared module)	CHCM - Chassis Control Module	EXE
HPLA-14E093-JG.vbf	Multiple models (shared module)	CHCM - Chassis Control Module	EXE
HPLA-14E093-JH.vbf	Multiple models (shared module)	CHCM - Chassis Control Module	EXE
HPLA-14E093-JJ.vbf	Multiple models (shared module)	CHCM - Chassis Control Module	EXE
HPLA-14E093-JK.vbf	Multiple models (shared module)	CHCM - Chassis Control Module	EXE
HPLA-14E093-JL.vbf	Multiple models (shared module)	CHCM - Chassis Control Module	EXE
HPLA-14E093-JM.vbf	Multiple models (shared module)	CHCM - Chassis Control Module	EXE
HPLA-14F216-AA.vbf	Multiple models (shared module)	RHVAC - Rear HVAC Control Module	SIGCFG
HPLA-14F217-AB.vbf	Multiple models (shared module)	RHVAC - Rear HVAC Control Module	EXE
HPLA-14F219-AA.vbf	Multiple models (shared module)	RHVAC - Rear HVAC Control Module	SBL
HPLA-14F352-AC.vbf	Multiple models (shared module)	SPMA - Seatbelt Pretensioner Control Module A	EXE
HPLA-14F357-AC.vbf	Multiple models (shared module)	SPMA - Seatbelt Pretensioner Control Module A	DATA

File name	Vehicle line (indicative)	Module (ECU)	Type
HPLA-14F370-AC.vbf	Multiple models (shared module)	SPMB - Seatbelt Pretensioner Control Module B	DATA
HPLA-14F396-AB.vbf	Multiple models (shared module)	IPMA - Image Processing Module A	EXE
HPLA-14F397-AC.vbf	Multiple models (shared module)	IPMA - Image Processing Module A	EXE
HPLA-14F397-AD.vbf	Multiple models (shared module)	IPMA - Image Processing Module A	EXE
HPLA-14F397-AF.vbf	Multiple models (shared module)	IPMA - Image Processing Module A	EXE
HPLA-14F397-AG.vbf	Multiple models (shared module)	IPMA - Image Processing Module A	EXE
HPLA-14F397-AH.vbf	Multiple models (shared module)	IPMA - Image Processing Module A	EXE
HPLA-14F397-AJ.vbf	Multiple models (shared module)	IPMA - Image Processing Module A	EXE
HPLA-14F397-BC.vbf	Multiple models (shared module)	IPMA - Image Processing Module A	EXE
HPLA-14F397-BD.vbf	Multiple models (shared module)	IPMA - Image Processing Module A	EXE
HPLA-14F397-BF.vbf	Multiple models (shared module)	IPMA - Image Processing Module A	EXE
HPLA-14F397-BG.vbf	Multiple models (shared module)	IPMA - Image Processing Module A	EXE
HPLA-14F397-BH.vbf	Multiple models (shared module)	IPMA - Image Processing Module A	EXE
HPLA-14F397-BJ.vbf	Multiple models (shared module)	IPMA - Image Processing Module A	EXE
HPLA-14F397-CC.vbf	Multiple models (shared module)	IPMA - Image Processing Module A	EXE
HPLA-14F397-CD.vbf	Multiple models (shared module)	IPMA - Image Processing Module A	EXE
HPLA-14F397-CF.vbf	Multiple models (shared module)	IPMA - Image Processing Module A	EXE
HPLA-14F397-CG.vbf	Multiple models (shared module)	IPMA - Image Processing Module A	EXE
HPLA-14F397-CH.vbf	Multiple models (shared module)	IPMA - Image Processing Module A	EXE
HPLA-14F397-CJ.vbf	Multiple models (shared module)	IPMA - Image Processing Module A	EXE
HPLA-14F397-DC.vbf	Multiple models (shared module)	IPMA - Image Processing Module A	EXE
HPLA-14F397-DD.vbf	Multiple models (shared module)	IPMA - Image Processing Module A	EXE
HPLA-14F397-DF.vbf	Multiple models (shared module)	IPMA - Image Processing Module A	EXE
HPLA-14F397-DG.vbf	Multiple models (shared module)	IPMA - Image Processing Module A	EXE
HPLA-14F397-DH.vbf	Multiple models (shared module)	IPMA - Image Processing Module A	EXE
HPLA-14F397-DJ.vbf	Multiple models (shared module)	IPMA - Image Processing Module A	EXE
HPLA-14F398-AC.vbf	Multiple models (shared module)	IPMA - Image Processing Module A	EXE
HPLA-14F398-AD.vbf	Multiple models (shared module)	IPMA - Image Processing Module A	EXE
HPLA-14F398-AF.vbf	Multiple models (shared module)	IPMA - Image Processing Module A	EXE
HPLA-14F398-AG.vbf	Multiple models (shared module)	IPMA - Image Processing Module A	EXE
HPLA-14F398-AH.vbf	Multiple models (shared module)	IPMA - Image Processing Module A	EXE
HPLA-14F398-AJ.vbf	Multiple models (shared module)	IPMA - Image Processing Module A	EXE
HPLA-14F398-BC.vbf	Multiple models (shared module)	IPMA - Image Processing Module A	EXE
HPLA-14F398-BD.vbf	Multiple models (shared module)	IPMA - Image Processing Module A	EXE
HPLA-14F398-BF.vbf	Multiple models (shared module)	IPMA - Image Processing Module A	EXE
HPLA-14F398-BG.vbf	Multiple models (shared module)	IPMA - Image Processing Module A	EXE
HPLA-14F398-BH.vbf	Multiple models (shared module)	IPMA - Image Processing Module A	EXE
HPLA-14F398-BJ.vbf	Multiple models (shared module)	IPMA - Image Processing Module A	EXE
HPLA-14F434-NB.vbf	Multiple models (shared module)	CHCMB - Chassis Control Module B	EXE
HPLA-14F434-NC.vbf	Multiple models (shared module)	CHCMB - Chassis Control Module B	EXE
HPLA-14F434-ND.vbf	Multiple models (shared module)	CHCMB - Chassis Control Module B	EXE
HPLA-14F434-NE.vbf	Multiple models (shared module)	CHCMB - Chassis Control Module B	EXE
HPLA-14F434-NF.vbf	Multiple models (shared module)	CHCMB - Chassis Control Module B	EXE
HPLA-14F434-NG.vbf	Multiple models (shared module)	CHCMB - Chassis Control Module B	EXE
HPLA-14F520-AA.vbf	Multiple models (shared module)	SOBDMB - Secondary OBD Control Module B	EXE
HPLA-14F529-BC.vbf	Multiple models (shared module)	GWM - Gateway Module A	EXE
HPLA-14F529-BD.vbf	Multiple models (shared module)	GWM - Gateway Module A	EXE
HPLA-14F529-BF.vbf	Multiple models (shared module)	GWM - Gateway Module A	EXE
HPLA-14F529-BG.vbf	Multiple models (shared module)	GWM - Gateway Module A	EXE
HPLA-14F529-BH.vbf	Multiple models (shared module)	GWM - Gateway Module A	EXE
HPLA-14F529-BJ.vbf	Multiple models (shared module)	GWM - Gateway Module A	EXE
HPLA-14F529-BK.vbf	Multiple models (shared module)	GWM - Gateway Module A	EXE
HPLA-14F529-BL.vbf	Multiple models (shared module)	GWM - Gateway Module A	EXE
HPLA-14F529-BM.vbf	Multiple models (shared module)	GWM - Gateway Module A	EXE
HPLA-14F529-BN.vbf	Multiple models (shared module)	GWM - Gateway Module A	EXE
HPLA-14F530-BC.vbf	Multiple models (shared module)	GWM - Gateway Module A	EXE
HPLA-14F530-BD.vbf	Multiple models (shared module)	GWM - Gateway Module A	EXE
HPLA-14F530-BG.vbf	Multiple models (shared module)	GWM - Gateway Module A	EXE
HPLA-14F530-BJ.vbf	Multiple models (shared module)	GWM - Gateway Module A	EXE
HPLA-14F530-BK.vbf	Multiple models (shared module)	GWM - Gateway Module A	EXE
HPLA-14F530-BL.vbf	Multiple models (shared module)	GWM - Gateway Module A	EXE
HPLA-14F530-BM.vbf	Multiple models (shared module)	GWM - Gateway Module A	EXE
HPLA-14F530-BN.vbf	Multiple models (shared module)	GWM - Gateway Module A	EXE
HPLA-14F531-BC.vbf	Multiple models (shared module)	GWM - Gateway Module A	DATA
HPLA-14F531-BD.vbf	Multiple models (shared module)	GWM - Gateway Module A	DATA
HPLA-14F531-BF.vbf	Multiple models (shared module)	GWM - Gateway Module A	DATA
HPLA-14F531-BH.vbf	Multiple models (shared module)	GWM - Gateway Module A	DATA
HPLA-14F531-BJ.vbf	Multiple models (shared module)	GWM - Gateway Module A	DATA
HPLA-14F531-BK.vbf	Multiple models (shared module)	GWM - Gateway Module A	DATA
HPLA-14F532-BB.vbf	Multiple models (shared module)	GWM - Gateway Module A	SBL
HPLA-14F532-BC.vbf	Multiple models (shared module)	GWM - Gateway Module A	SBL
HPLA-14F532-BD.vbf	Multiple models (shared module)	GWM - Gateway Module A	SBL
HPLA-14F532-BE.vbf	Multiple models (shared module)	GWM - Gateway Module A	SBL
HPLA-14F670-AA.vbf	Multiple models (shared module)	RGTMB - Rear Gate / Trunk Module B	SIGCFG
HPLA-19C204-AA.vbf	Multiple models (shared module)	IMC - Infotainment Master Controller	EXE
HPLA-19C204-AC.vbf	Multiple models (shared module)	IMC - Infotainment Master Controller	EXE

File name	Vehicle line (indicative)	Module (ECU)	Type
HPLA-19C204-AD.vbf	Multiple models (shared module)	IMC - Infotainment Master Controller	EXE
HPLA-19C204-AE.vbf	Multiple models (shared module)	IMC - Infotainment Master Controller	EXE
HPLA-70711-AB.vbf	Multiple models (shared module)	TCU - Telematic Control Unit Module	SIGCFG
HPLA-70711-AC.vbf	Multiple models (shared module)	TCU - Telematic Control Unit Module	SIGCFG
HPLA-70711-AD.vbf	Multiple models (shared module)	TCU - Telematic Control Unit Module	SIGCFG
HPLA-70712-AC.vbf	Multiple models (shared module)	TCU - Telematic Control Unit Module	EXE
HPLA-70712-AD.vbf	Multiple models (shared module)	TCU - Telematic Control Unit Module	EXE
HPLA-70712-AE.vbf	Multiple models (shared module)	TCU - Telematic Control Unit Module	EXE
HPLA-70712-AF.vbf	Multiple models (shared module)	TCU - Telematic Control Unit Module	EXE
HPLA-70712-AG.vbf	Multiple models (shared module)	TCU - Telematic Control Unit Module	EXE
HPLA-70712-AH.vbf	Multiple models (shared module)	TCU - Telematic Control Unit Module	EXE
HPLA-70713-BB.vbf	Multiple models (shared module)	TCU - Telematic Control Unit Module	DATA
HPLA-70713-CB.vbf	Multiple models (shared module)	TCU - Telematic Control Unit Module	DATA
HPLA-70713-DB.vbf	Multiple models (shared module)	TCU - Telematic Control Unit Module	DATA
HPLA-70713-EB.vbf	Multiple models (shared module)	TCU - Telematic Control Unit Module	DATA
HPLA-70713-JB.vbf	Multiple models (shared module)	TCU - Telematic Control Unit Module	DATA
HPLA-70713-JC.vbf	Multiple models (shared module)	TCU - Telematic Control Unit Module	DATA
HPLA-70713-JD.vbf	Multiple models (shared module)	TCU - Telematic Control Unit Module	DATA
HPLA-70713-JE.vbf	Multiple models (shared module)	TCU - Telematic Control Unit Module	DATA
HPLA-70713-JF.vbf	Multiple models (shared module)	TCU - Telematic Control Unit Module	DATA
HPLA-70713-JG.vbf	Multiple models (shared module)	TCU - Telematic Control Unit Module	DATA
HPLA-70713-JH.vbf	Multiple models (shared module)	TCU - Telematic Control Unit Module	DATA
HPLA-70713-KB.vbf	Multiple models (shared module)	TCU - Telematic Control Unit Module	DATA
HPLA-70713-KC.vbf	Multiple models (shared module)	TCU - Telematic Control Unit Module	DATA
HPLA-70713-KD.vbf	Multiple models (shared module)	TCU - Telematic Control Unit Module	DATA
HPLA-70713-KE.vbf	Multiple models (shared module)	TCU - Telematic Control Unit Module	DATA
HPLA-70713-KG.vbf	Multiple models (shared module)	TCU - Telematic Control Unit Module	DATA
HPLA-70713-KH.vbf	Multiple models (shared module)	TCU - Telematic Control Unit Module	DATA
HPLA-70713-KJ.vbf	Multiple models (shared module)	TCU - Telematic Control Unit Module	DATA
HPLA-70713-MB.vbf	Multiple models (shared module)	TCU - Telematic Control Unit Module	DATA
HPLA-70713-MC.vbf	Multiple models (shared module)	TCU - Telematic Control Unit Module	DATA
HPLA-70713-MD.vbf	Multiple models (shared module)	TCU - Telematic Control Unit Module	DATA
HPLA-70713-ME.vbf	Multiple models (shared module)	TCU - Telematic Control Unit Module	DATA
HPLA-70713-MF.vbf	Multiple models (shared module)	TCU - Telematic Control Unit Module	DATA
HPLA-70713-MG.vbf	Multiple models (shared module)	TCU - Telematic Control Unit Module	DATA
HPLA-70713-MH.vbf	Multiple models (shared module)	TCU - Telematic Control Unit Module	DATA
HPLA-70713-NB.vbf	Multiple models (shared module)	TCU - Telematic Control Unit Module	DATA
HPLA-70713-NC.vbf	Multiple models (shared module)	TCU - Telematic Control Unit Module	DATA
HPLA-70713-ND.vbf	Multiple models (shared module)	TCU - Telematic Control Unit Module	DATA
HPLA-70713-NE.vbf	Multiple models (shared module)	TCU - Telematic Control Unit Module	DATA
HPLA-70713-NF.vbf	Multiple models (shared module)	TCU - Telematic Control Unit Module	DATA
HPLA-70713-NG.vbf	Multiple models (shared module)	TCU - Telematic Control Unit Module	DATA
HPLA-70713-NH.vbf	Multiple models (shared module)	TCU - Telematic Control Unit Module	DATA
HPLA-70713-RC.vbf	Multiple models (shared module)	TCU - Telematic Control Unit Module	DATA
HPLA-70713-RD.vbf	Multiple models (shared module)	TCU - Telematic Control Unit Module	DATA
HPLA-70713-RE.vbf	Multiple models (shared module)	TCU - Telematic Control Unit Module	DATA
HPLA-70713-RF.vbf	Multiple models (shared module)	TCU - Telematic Control Unit Module	DATA
HPLA-70713-RG.vbf	Multiple models (shared module)	TCU - Telematic Control Unit Module	DATA
HPLA-70713-RH.vbf	Multiple models (shared module)	TCU - Telematic Control Unit Module	DATA
HPLA-70713-RJ.vbf	Multiple models (shared module)	TCU - Telematic Control Unit Module	DATA
HPLA-70713-SC.vbf	Multiple models (shared module)	TCU - Telematic Control Unit Module	DATA
HPLA-70713-SD.vbf	Multiple models (shared module)	TCU - Telematic Control Unit Module	DATA
HPLA-70713-SE.vbf	Multiple models (shared module)	TCU - Telematic Control Unit Module	DATA
HPLA-70713-SF.vbf	Multiple models (shared module)	TCU - Telematic Control Unit Module	DATA
HPLA-70713-SG.vbf	Multiple models (shared module)	TCU - Telematic Control Unit Module	DATA
HPLA-70713-SH.vbf	Multiple models (shared module)	TCU - Telematic Control Unit Module	DATA
HPLA-70713-SJ.vbf	Multiple models (shared module)	TCU - Telematic Control Unit Module	DATA
HPLA-70713-TC.vbf	Multiple models (shared module)	TCU - Telematic Control Unit Module	DATA
HPLA-70713-TD.vbf	Multiple models (shared module)	TCU - Telematic Control Unit Module	DATA
HPLA-70713-TE.vbf	Multiple models (shared module)	TCU - Telematic Control Unit Module	DATA
HPLA-70713-TF.vbf	Multiple models (shared module)	TCU - Telematic Control Unit Module	DATA
HPLA-70713-TH.vbf	Multiple models (shared module)	TCU - Telematic Control Unit Module	DATA
HPLA-70713-TJ.vbf	Multiple models (shared module)	TCU - Telematic Control Unit Module	DATA
HPLA-70713-TK.vbf	Multiple models (shared module)	TCU - Telematic Control Unit Module	DATA
HPLA-70713-VC.vbf	Multiple models (shared module)	TCU - Telematic Control Unit Module	DATA
HPLA-70713-VD.vbf	Multiple models (shared module)	TCU - Telematic Control Unit Module	DATA
HPLA-70713-VE.vbf	Multiple models (shared module)	TCU - Telematic Control Unit Module	DATA
HPLA-70713-VF.vbf	Multiple models (shared module)	TCU - Telematic Control Unit Module	DATA
HPLA-70713-VG.vbf	Multiple models (shared module)	TCU - Telematic Control Unit Module	DATA
HPLA-70713-VH.vbf	Multiple models (shared module)	TCU - Telematic Control Unit Module	DATA
HPLA-70713-VJ.vbf	Multiple models (shared module)	TCU - Telematic Control Unit Module	DATA
HPLA-7J104-CCA.vbf	Multiple models (shared module)	TCM - Transmission Control Module	EXE
HPLA-7J104-CCB.vbf	Multiple models (shared module)	TCM - Transmission Control Module	EXE
HPLA-7J104-CCC.vbf	Multiple models (shared module)	TCM - Transmission Control Module	EXE
HPLA-7J244-BA.vbf	Multiple models (shared module)	TCM - Transmission Control Module	SBL
HPLA-9J403-AA.vbf	Multiple models (shared module)	GPSM - Global Positioning System Module	SIGCFG

File name	Vehicle line (indicative)	Module (ECU)	Type
HW93-14C155-AA.vbf	Jaguar XJ (X351)	VDM - Vehicle Dynamics Control Module	EXE
HW93-14C156-AA.vbf	Jaguar XJ (X351)	RCM - Restraints Control Module	DATA
HW93-14C156-AB.VBF	Jaguar XJ (X351)	VDM	DATA
HW93-14C158-AA.vbf	Jaguar XJ (X351)	VDM - Vehicle Dynamics Control Module	SBL
HW93-14C185-AA.vbf	Jaguar XJ (X351)	BCM - Body Control Module	DATA
HW93-14C384-AA.vbf	Jaguar XJ (X351)	VDM - Vehicle Dynamics Control Module	SIGCFG
HW93-70713-JA.vbf	Jaguar XJ (X351)	TCU - Telematic Control Unit Module	DATA
HW93-70713-JB.vbf	Jaguar XJ (X351)	TCU - Telematic Control Unit Module	DATA
HW93-70713-JC.vbf	Jaguar XJ (X351)	TCU - Telematic Control Unit Module	DATA
HW93-70713-JD.vbf	Jaguar XJ (X351)	TCU - Telematic Control Unit Module	DATA
HW93-70713-JE.vbf	Jaguar XJ (X351)	TCU - Telematic Control Unit Module	DATA
HW93-70713-JF.vbf	Jaguar XJ (X351)	TCU - Telematic Control Unit Module	DATA
HX53-14C026-AA.vbf	Jaguar F-Type (X152)	IPC - Instrument Panel Cluster (IPC) Control Module	EXE
HX53-14C026-AB.vbf	Jaguar F-Type (X152)	IPC - Instrument Panel Cluster (IPC) Control Module	EXE
HX53-14C026-AD.vbf	Jaguar F-Type (X152)	IPC - Instrument Panel Cluster (IPC) Control Module	EXE
HX53-14C060-AB.vbf	Jaguar F-Type (X152)	FCDIM - Front Control/Display Interface Module	EXE
HX53-14C060-AC.vbf	Jaguar F-Type (X152)	FCDIM - Front Control/Display Interface Module	EXE
HX53-14C060-AD.vbf	Jaguar F-Type (X152)	FCDIM - Front Control/Display Interface Module	EXE
HX53-14C060-AE.vbf	Jaguar F-Type (X152)	FCDIM - Front Control/Display Interface Module	EXE
HX53-14C060-AF.vbf	Jaguar F-Type (X152)	FCDIM - Front Control/Display Interface Module	EXE
HX53-14C061-AB.vbf	Jaguar F-Type (X152)	FCDIM - Front Control/Display Interface Module	DATA
HX53-14C061-AC.vbf	Jaguar F-Type (X152)	FCDIM - Front Control/Display Interface Module	DATA
HX53-14C061-AD.vbf	Jaguar F-Type (X152)	FCDIM - Front Control/Display Interface Module	DATA
HX53-14C061-AE.vbf	Jaguar F-Type (X152)	FCDIM - Front Control/Display Interface Module	DATA
HX53-14C061-AF.vbf	Jaguar F-Type (X152)	FCDIM - Front Control/Display Interface Module	DATA
HX53-14C063-AA.vbf	Jaguar F-Type (X152)	FCDIM - Front Control/Display Interface Module	SBL
HX53-14C091-AA.vbf	Jaguar F-Type (X152)	PAM - Parking Assist Control Module	DATA
HX53-14C091-AC.vbf	Jaguar F-Type (X152)	PAM - Parking Assist Control Module	DATA
HX53-14C091-AD.vbf	Jaguar F-Type (X152)	PAM - Parking Assist Control Module	DATA
HX53-14C091-AE.vbf	Jaguar F-Type (X152)	PAM - Parking Assist Control Module	DATA
HX53-14C621-AA.vbf	Jaguar F-Type (X152)	FCDIM - Front Control/Display Interface Module	EXE
HX53-14E093-DA.vbf	Jaguar F-Type (X152)	CHCM - Chassis Control Module	EXE
HX53-14E093-DB.vbf	Jaguar F-Type (X152)	CHCM - Chassis Control Module	EXE
HX53-14E093-DC.vbf	Jaguar F-Type (X152)	CHCM - Chassis Control Module	EXE
HX53-14E093-DD.vbf	Jaguar F-Type (X152)	CHCM - Chassis Control Module	EXE
HX53-14E093-DE.vbf	Jaguar F-Type (X152)	CHCM - Chassis Control Module	EXE
HX53-4C045-AA.vbf	Jaguar F-Type (X152)	ECM - Engine Control Module	EXE
HX53-7J104-BNA.vbf	Jaguar F-Type (X152)	TCM - Transmission Control Module	EXE
HX53-7J104-BNB.vbf	Jaguar F-Type (X152)	TCM - Transmission Control Module	EXE
HX53-7J104-BNC.vbf	Jaguar F-Type (X152)	TCM - Transmission Control Module	EXE
HX53-7J104-BNF.vbf	Jaguar F-Type (X152)	TCM - Transmission Control Module	EXE
HX5M-14C152-AA.vbf	Not specified	TPM - Tire Pressure Monitor Module	DATA
HX5M-14C152-AB.vbf	Not specified	TPM - Tire Pressure Monitor Module	DATA
HX5M-14C152-AC.vbf	Not specified	TPM - Tire Pressure Monitor Module	DATA
HX5M-14C204-ZAA.vbf	Not specified	PCM - Powertrain Control Module	EXE
HX5M-14C204-ZAB.vbf	Not specified	PCM - Powertrain Control Module	EXE
HX5M-14C204-ZAC.vbf	Not specified	PCM - Powertrain Control Module	EXE
HX5M-14C204-ZAD.vbf	Not specified	PCM - Powertrain Control Module	EXE
HX5M-14C204-ZCA.vbf	Not specified	PCM - Powertrain Control Module	EXE
HX5M-14C204-ZCB.vbf	Not specified	PCM - Powertrain Control Module	EXE
HX5M-14C204-ZCC.vbf	Not specified	PCM - Powertrain Control Module	EXE
HX5M-14C204-ZEA.vbf	Not specified	PCM - Powertrain Control Module	EXE
HX5M-14C204-ZEB.vbf	Not specified	PCM - Powertrain Control Module	EXE
HX5M-14C204-ZEC.vbf	Not specified	PCM - Powertrain Control Module	EXE
HX5M-14C204-ZTA.vbf	Not specified	PCM - Powertrain Control Module	EXE
HX5M-14C204-ZTB.vbf	Not specified	PCM - Powertrain Control Module	EXE
HX5M-14C204-ZTC.vbf	Not specified	PCM - Powertrain Control Module	EXE
HX5M-14C204-ZTD.vbf	Not specified	PCM - Powertrain Control Module	EXE
HX5M-14C218-AA.vbf	Not specified	PSCM - Power Steering Control Module	DATA
HX5M-14C218-AB.vbf	Not specified	PSCM - Power Steering Control Module	DATA
HX5M-14C218-AC.vbf	Not specified	PSCM - Power Steering Control Module	DATA
HX5M-14E094-DAA.vbf	Not specified	CHCM - Chassis Control Module	EXE
HX5M-14E094-DAB.vbf	Not specified	CHCM - Chassis Control Module	EXE
HX5M-14E094-DAC.vbf	Not specified	CHCM - Chassis Control Module	EXE
HX5M-14E094-DBA.vbf	Not specified	CHCM - Chassis Control Module	EXE
HX5M-14E094-DBB.vbf	Not specified	CHCM - Chassis Control Module	EXE
HX5M-14E094-DBC.vbf	Not specified	CHCM - Chassis Control Module	EXE
HX5M-14E094-DCA.vbf	Not specified	CHCM - Chassis Control Module	EXE
HX5M-14E094-DCB.vbf	Not specified	CHCM - Chassis Control Module	EXE
HX5M-14E094-DDA.vbf	Not specified	CHCM - Chassis Control Module	EXE
HX5M-14E094-DDB.vbf	Not specified	CHCM - Chassis Control Module	EXE
HX63-12K532-KBA.vbf	Jaguar XF (X260)	PCM - Powertrain Control Module	DATA
HX63-12K532-KBB.vbf	Jaguar XF (X260)	PCM - Powertrain Control Module	DATA
HX63-12K532-KBC.vbf	Jaguar XF (X260)	PCM - Powertrain Control Module	DATA
HX63-12K532-KBD.vbf	Jaguar XF (X260)	PCM - Powertrain Control Module	DATA
HX63-12K532-KBE.vbf	Jaguar XF (X260)	PCM - Powertrain Control Module	DATA

File name	Vehicle line (indicative)	Module (ECU)	Type
HX63-12K532-KBF.vbf	Jaguar XF (X260)	PCM - Powertrain Control Module	DATA
HX63-12K532-KDA.vbf	Jaguar XF (X260)	PCM - Powertrain Control Module	DATA
HX63-12K532-KDC.vbf	Jaguar XF (X260)	PCM - Powertrain Control Module	DATA
HX63-12K532-KDD.vbf	Jaguar XF (X260)	PCM - Powertrain Control Module	DATA
HX63-12K532-KDE.vbf	Jaguar XF (X260)	PCM - Powertrain Control Module	DATA
HX63-12K532-KDF.vbf	Jaguar XF (X260)	PCM - Powertrain Control Module	DATA
HX63-12K532-KEA.vbf	Jaguar XF (X260)	PCM - Powertrain Control Module	DATA
HX63-12K532-KEB.vbf	Jaguar XF (X260)	PCM - Powertrain Control Module	DATA
HX63-12K532-KED.vbf	Jaguar XF (X260)	PCM - Powertrain Control Module	DATA
HX63-12K532-KEE.vbf	Jaguar XF (X260)	PCM - Powertrain Control Module	DATA
HX63-12K532-KEF.vbf	Jaguar XF (X260)	PCM - Powertrain Control Module	DATA
HX63-12K532-KEG.vbf	Jaguar XF (X260)	PCM - Powertrain Control Module	DATA
HX63-12K532-KEH.vbf	Jaguar XF (X260)	PCM - Powertrain Control Module	DATA
HX63-12K532-KEJ.vbf	Jaguar XF (X260)	PCM - Powertrain Control Module	DATA
HX63-12K532-KEK.vbf	Jaguar XF (X260)	PCM - Powertrain Control Module	DATA
HX63-12K532-KEL.vbf	Jaguar XF (X260)	PCM - Powertrain Control Module	DATA
HX63-12K532-KEM.vbf	Jaguar XF (X260)	PCM - Powertrain Control Module	DATA
HX63-12K532-KEN.vbf	Jaguar XF (X260)	PCM - Powertrain Control Module	DATA
HX63-12K532-KFA.vbf	Jaguar XF (X260)	PCM - Powertrain Control Module	DATA
HX63-12K532-KFB.vbf	Jaguar XF (X260)	PCM - Powertrain Control Module	DATA
HX63-12K532-KFD.vbf	Jaguar XF (X260)	PCM - Powertrain Control Module	DATA
HX63-12K532-KFE.vbf	Jaguar XF (X260)	PCM - Powertrain Control Module	DATA
HX63-12K532-KFF.vbf	Jaguar XF (X260)	PCM - Powertrain Control Module	DATA
HX63-12K532-KFG.vbf	Jaguar XF (X260)	PCM - Powertrain Control Module	DATA
HX63-12K532-KFH.vbf	Jaguar XF (X260)	PCM - Powertrain Control Module	DATA
HX63-12K532-KFJ.vbf	Jaguar XF (X260)	PCM - Powertrain Control Module	DATA
HX63-12K532-KFK.vbf	Jaguar XF (X260)	PCM - Powertrain Control Module	DATA
HX63-12K532-KFL.vbf	Jaguar XF (X260)	PCM - Powertrain Control Module	DATA
HX63-12K532-KFM.vbf	Jaguar XF (X260)	PCM - Powertrain Control Module	DATA
HX63-12K532-KFN.vbf	Jaguar XF (X260)	PCM - Powertrain Control Module	DATA
HX63-12K532-KGA.vbf	Jaguar XF (X260)	PCM - Powertrain Control Module	DATA
HX63-12K532-KGB.vbf	Jaguar XF (X260)	PCM - Powertrain Control Module	DATA
HX63-12K532-KGC.vbf	Jaguar XF (X260)	PCM - Powertrain Control Module	DATA
HX63-12K532-KGD.vbf	Jaguar XF (X260)	PCM - Powertrain Control Module	DATA
HX63-12K532-KGE.vbf	Jaguar XF (X260)	PCM - Powertrain Control Module	DATA
HX63-12K532-KHA.vbf	Jaguar XF (X260)	PCM - Powertrain Control Module	DATA
HX63-12K532-KHB.vbf	Jaguar XF (X260)	PCM - Powertrain Control Module	DATA
HX63-12K532-KHC.vbf	Jaguar XF (X260)	PCM - Powertrain Control Module	DATA
HX63-12K532-KHD.vbf	Jaguar XF (X260)	PCM - Powertrain Control Module	DATA
HX63-12K532-KHE.vbf	Jaguar XF (X260)	PCM - Powertrain Control Module	DATA
HX63-14C025-AA.vbf	Jaguar XF (X260)	IPC - Instrument Panel Cluster (IPC) Control Module	SBL
HX63-14C025-AB.vbf	Jaguar XF (X260)	IPC - Instrument Panel Cluster (IPC) Control Module	SBL
HX63-14C026-AA.vbf	Jaguar XF (X260)	IPC - Instrument Panel Cluster (IPC) Control Module	EXE
HX63-14C026-AB.vbf	Jaguar XF (X260)	IPC - Instrument Panel Cluster (IPC) Control Module	EXE
HX63-14C026-AC.vbf	Jaguar XF (X260)	IPC - Instrument Panel Cluster (IPC) Control Module	EXE
HX63-14C026-AD.vbf	Jaguar XF (X260)	IPC - Instrument Panel Cluster (IPC) Control Module	EXE
HX63-14C026-AE.vbf	Jaguar XF (X260)	IPC - Instrument Panel Cluster (IPC) Control Module	EXE
HX63-14C026-JA.vbf	Jaguar XF (X260)	IPC - Instrument Panel Cluster (IPC) Control Module	EXE
HX63-14C026-JB.vbf	Jaguar XF (X260)	IPC - Instrument Panel Cluster (IPC) Control Module	EXE
HX63-14C026-JC.vbf	Jaguar XF (X260)	IPC - Instrument Panel Cluster (IPC) Control Module	EXE
HX63-14C026-JCX.vbf	Jaguar XF (X260)	IPC - Instrument Panel Cluster (IPC) Control Module	EXE
HX63-14C026-JD.vbf	Jaguar XF (X260)	IPC - Instrument Panel Cluster (IPC) Control Module	EXE
HX63-14C026-JE.vbf	Jaguar XF (X260)	IPC - Instrument Panel Cluster (IPC) Control Module	EXE
HX63-14C026-JF.vbf	Jaguar XF (X260)	IPC - Instrument Panel Cluster (IPC) Control Module	EXE
HX63-14C034-BB.vbf	Jaguar XF (X260)	DSM - Driver Front Seat Module	EXE
HX63-14C037-AAD.vbf	Jaguar XF (X260)	SPCM - Secondary Powertrain Control Module	EXE
HX63-14C037-AAE.vbf	Jaguar XF (X260)	SPCM - Secondary Powertrain Control Module	EXE
HX63-14C037-AAF.vbf	Jaguar XF (X260)	SPCM - Secondary Powertrain Control Module	EXE
HX63-14C037-AAG.vbf	Jaguar XF (X260)	SPCM - Secondary Powertrain Control Module	DATA
HX63-14C037-AAJ.vbf	Jaguar XF (X260)	SPCM - Secondary Powertrain Control Module	DATA
HX63-14C037-AED.vbf	Jaguar XF (X260)	SPCM - Secondary Powertrain Control Module	EXE
HX63-14C037-AEE.vbf	Jaguar XF (X260)	SPCM - Secondary Powertrain Control Module	EXE
HX63-14C037-AEF.vbf	Jaguar XF (X260)	SPCM - Secondary Powertrain Control Module	EXE
HX63-14C037-AEG.vbf	Jaguar XF (X260)	SPCM - Secondary Powertrain Control Module	DATA
HX63-14C037-AEJ.vbf	Jaguar XF (X260)	SPCM - Secondary Powertrain Control Module	DATA
HX63-14C037-AGD.vbf	Jaguar XF (X260)	SPCM - Secondary Powertrain Control Module	EXE
HX63-14C037-AGE.vbf	Jaguar XF (X260)	SPCM - Secondary Powertrain Control Module	EXE
HX63-14C037-AGF.vbf	Jaguar XF (X260)	SPCM - Secondary Powertrain Control Module	EXE
HX63-14C037-AGG.vbf	Jaguar XF (X260)	SPCM - Secondary Powertrain Control Module	DATA
HX63-14C037-AGJ.vbf	Jaguar XF (X260)	SPCM - Secondary Powertrain Control Module	DATA
HX63-14C037-ALD.vbf	Jaguar XF (X260)	SPCM - Secondary Powertrain Control Module	EXE
HX63-14C037-ALE.vbf	Jaguar XF (X260)	SPCM - Secondary Powertrain Control Module	EXE
HX63-14C037-ALF.vbf	Jaguar XF (X260)	SPCM - Secondary Powertrain Control Module	EXE
HX63-14C037-ALG.vbf	Jaguar XF (X260)	SPCM - Secondary Powertrain Control Module	DATA
HX63-14C037-ALJ.vbf	Jaguar XF (X260)	SPCM - Secondary Powertrain Control Module	DATA
HX63-14C037-AND.vbf	Jaguar XF (X260)	SPCM - Secondary Powertrain Control Module	EXE

File name	Vehicle line (indicative)	Module (ECU)	Type
HX63-14C037-ANE.vbf	Jaguar XF (X260)	SPCM - Secondary Powertrain Control Module	EXE
HX63-14C037-ANF.vbf	Jaguar XF (X260)	SPCM - Secondary Powertrain Control Module	EXE
HX63-14C037-ANG.vbf	Jaguar XF (X260)	SPCM - Secondary Powertrain Control Module	DATA
HX63-14C037-ANJ.vbf	Jaguar XF (X260)	SPCM - Secondary Powertrain Control Module	DATA
HX63-14C037-ATD.vbf	Jaguar XF (X260)	SPCM - Secondary Powertrain Control Module	EXE
HX63-14C037-ATE.vbf	Jaguar XF (X260)	SPCM - Secondary Powertrain Control Module	EXE
HX63-14C037-ATF.vbf	Jaguar XF (X260)	SPCM - Secondary Powertrain Control Module	EXE
HX63-14C037-ATG.vbf	Jaguar XF (X260)	SPCM - Secondary Powertrain Control Module	DATA
HX63-14C037-ATJ.vbf	Jaguar XF (X260)	SPCM - Secondary Powertrain Control Module	DATA
HX63-14C037-AVD.vbf	Jaguar XF (X260)	SPCM - Secondary Powertrain Control Module	EXE
HX63-14C037-AVE.vbf	Jaguar XF (X260)	SPCM - Secondary Powertrain Control Module	EXE
HX63-14C037-AVF.vbf	Jaguar XF (X260)	SPCM - Secondary Powertrain Control Module	EXE
HX63-14C037-AVG.vbf	Jaguar XF (X260)	SPCM - Secondary Powertrain Control Module	DATA
HX63-14C037-AVJ.vbf	Jaguar XF (X260)	SPCM - Secondary Powertrain Control Module	DATA
HX63-14C037-BAD.vbf	Jaguar XF (X260)	SPCM - Secondary Powertrain Control Module	EXE
HX63-14C037-BAE.vbf	Jaguar XF (X260)	SPCM - Secondary Powertrain Control Module	EXE
HX63-14C037-BAF.vbf	Jaguar XF (X260)	SPCM - Secondary Powertrain Control Module	EXE
HX63-14C037-BAG.vbf	Jaguar XF (X260)	SPCM - Secondary Powertrain Control Module	DATA
HX63-14C037-BAJ.vbf	Jaguar XF (X260)	SPCM - Secondary Powertrain Control Module	DATA
HX63-14C037-BCD.vbf	Jaguar XF (X260)	SPCM - Secondary Powertrain Control Module	EXE
HX63-14C037-BCE.vbf	Jaguar XF (X260)	SPCM - Secondary Powertrain Control Module	EXE
HX63-14C037-BCF.vbf	Jaguar XF (X260)	SPCM - Secondary Powertrain Control Module	EXE
HX63-14C037-BCG.vbf	Jaguar XF (X260)	SPCM - Secondary Powertrain Control Module	DATA
HX63-14C037-BCJ.vbf	Jaguar XF (X260)	SPCM - Secondary Powertrain Control Module	DATA
HX63-14C037-BJD.vbf	Jaguar XF (X260)	SPCM - Secondary Powertrain Control Module	EXE
HX63-14C037-BJE.vbf	Jaguar XF (X260)	SPCM - Secondary Powertrain Control Module	EXE
HX63-14C037-BJF.vbf	Jaguar XF (X260)	SPCM - Secondary Powertrain Control Module	EXE
HX63-14C037-BJG.vbf	Jaguar XF (X260)	SPCM - Secondary Powertrain Control Module	DATA
HX63-14C037-BJJ.vbf	Jaguar XF (X260)	SPCM - Secondary Powertrain Control Module	DATA
HX63-14C037-BLD.vbf	Jaguar XF (X260)	SPCM - Secondary Powertrain Control Module	EXE
HX63-14C037-BLE.vbf	Jaguar XF (X260)	SPCM - Secondary Powertrain Control Module	EXE
HX63-14C037-BLF.vbf	Jaguar XF (X260)	SPCM - Secondary Powertrain Control Module	EXE
HX63-14C037-BLG.vbf	Jaguar XF (X260)	SPCM - Secondary Powertrain Control Module	DATA
HX63-14C037-BLJ.vbf	Jaguar XF (X260)	SPCM - Secondary Powertrain Control Module	DATA
HX63-14C037-BVD.vbf	Jaguar XF (X260)	SPCM - Secondary Powertrain Control Module	EXE
HX63-14C037-BVE.vbf	Jaguar XF (X260)	SPCM - Secondary Powertrain Control Module	EXE
HX63-14C037-BVF.vbf	Jaguar XF (X260)	SPCM - Secondary Powertrain Control Module	EXE
HX63-14C037-BVG.vbf	Jaguar XF (X260)	SPCM - Secondary Powertrain Control Module	DATA
HX63-14C037-BVJ.vbf	Jaguar XF (X260)	SPCM - Secondary Powertrain Control Module	DATA
HX63-14C037-BXD.vbf	Jaguar XF (X260)	SPCM - Secondary Powertrain Control Module	EXE
HX63-14C037-BXE.vbf	Jaguar XF (X260)	SPCM - Secondary Powertrain Control Module	EXE
HX63-14C037-BXF.vbf	Jaguar XF (X260)	SPCM - Secondary Powertrain Control Module	EXE
HX63-14C037-BXG.vbf	Jaguar XF (X260)	SPCM - Secondary Powertrain Control Module	DATA
HX63-14C037-BXJ.vbf	Jaguar XF (X260)	SPCM - Secondary Powertrain Control Module	DATA
HX63-14C037-CAD.vbf	Jaguar XF (X260)	SPCM - Secondary Powertrain Control Module	EXE
HX63-14C037-CAE.vbf	Jaguar XF (X260)	SPCM - Secondary Powertrain Control Module	EXE
HX63-14C037-CAF.vbf	Jaguar XF (X260)	SPCM - Secondary Powertrain Control Module	EXE
HX63-14C037-CAG.vbf	Jaguar XF (X260)	SPCM - Secondary Powertrain Control Module	DATA
HX63-14C037-CAJ.vbf	Jaguar XF (X260)	SPCM - Secondary Powertrain Control Module	DATA
HX63-14C037-CBD.vbf	Jaguar XF (X260)	SPCM - Secondary Powertrain Control Module	EXE
HX63-14C037-CBE.vbf	Jaguar XF (X260)	SPCM - Secondary Powertrain Control Module	EXE
HX63-14C037-CBF.vbf	Jaguar XF (X260)	SPCM - Secondary Powertrain Control Module	EXE
HX63-14C037-CBG.vbf	Jaguar XF (X260)	SPCM - Secondary Powertrain Control Module	DATA
HX63-14C037-CBJ.vbf	Jaguar XF (X260)	SPCM - Secondary Powertrain Control Module	DATA
HX63-14C037-CFD.vbf	Jaguar XF (X260)	SPCM - Secondary Powertrain Control Module	EXE
HX63-14C037-CFE.vbf	Jaguar XF (X260)	SPCM - Secondary Powertrain Control Module	EXE
HX63-14C037-CFF.vbf	Jaguar XF (X260)	SPCM - Secondary Powertrain Control Module	EXE
HX63-14C037-CFG.vbf	Jaguar XF (X260)	SPCM - Secondary Powertrain Control Module	DATA
HX63-14C037-CFJ.vbf	Jaguar XF (X260)	SPCM - Secondary Powertrain Control Module	DATA
HX63-14C037-CXD.vbf	Jaguar XF (X260)	SPCM - Secondary Powertrain Control Module	EXE
HX63-14C037-CXE.vbf	Jaguar XF (X260)	SPCM - Secondary Powertrain Control Module	EXE
HX63-14C037-CXF.vbf	Jaguar XF (X260)	SPCM - Secondary Powertrain Control Module	EXE
HX63-14C037-CXG.vbf	Jaguar XF (X260)	SPCM - Secondary Powertrain Control Module	DATA
HX63-14C037-CXJ.vbf	Jaguar XF (X260)	SPCM - Secondary Powertrain Control Module	DATA
HX63-14C037-DPD.vbf	Jaguar XF (X260)	SPCM - Secondary Powertrain Control Module	EXE
HX63-14C037-DPE.vbf	Jaguar XF (X260)	SPCM - Secondary Powertrain Control Module	EXE
HX63-14C037-DPF.vbf	Jaguar XF (X260)	SPCM - Secondary Powertrain Control Module	EXE
HX63-14C037-DPJ.vbf	Jaguar XF (X260)	SPCM - Secondary Powertrain Control Module	DATA
HX63-14C037-DRD.vbf	Jaguar XF (X260)	SPCM - Secondary Powertrain Control Module	EXE
HX63-14C037-DRE.vbf	Jaguar XF (X260)	SPCM - Secondary Powertrain Control Module	EXE
HX63-14C037-DRF.vbf	Jaguar XF (X260)	SPCM - Secondary Powertrain Control Module	EXE
HX63-14C037-DRJ.vbf	Jaguar XF (X260)	SPCM - Secondary Powertrain Control Module	DATA
HX63-14C037-DSD.vbf	Jaguar XF (X260)	SPCM - Secondary Powertrain Control Module	EXE
HX63-14C037-DSE.vbf	Jaguar XF (X260)	SPCM - Secondary Powertrain Control Module	EXE
HX63-14C037-DSG.vbf	Jaguar XF (X260)	SPCM - Secondary Powertrain Control Module	EXE
HX63-14C037-DSH.vbf	Jaguar XF (X260)	SPCM - Secondary Powertrain Control Module	DATA

File name	Vehicle line (indicative)	Module (ECU)	Type
HX63-14C037-DSJ.vbf	Jaguar XF (X260)	SPCM - Secondary Powertrain Control Module	DATA
HX63-14C037-DSL.vbf	Jaguar XF (X260)	SPCM - Secondary Powertrain Control Module	DATA
HX63-14C037-DUD.vbf	Jaguar XF (X260)	SPCM - Secondary Powertrain Control Module	EXE
HX63-14C037-DUE.vbf	Jaguar XF (X260)	SPCM - Secondary Powertrain Control Module	EXE
HX63-14C037-DUG.vbf	Jaguar XF (X260)	SPCM - Secondary Powertrain Control Module	EXE
HX63-14C037-DUH.vbf	Jaguar XF (X260)	SPCM - Secondary Powertrain Control Module	DATA
HX63-14C037-DUJ.vbf	Jaguar XF (X260)	SPCM - Secondary Powertrain Control Module	DATA
HX63-14C037-DUL.vbf	Jaguar XF (X260)	SPCM - Secondary Powertrain Control Module	DATA
HX63-14C037-EBE.vbf	Jaguar XF (X260)	ABS - Anti-Lock Brake System Control Module	DATA
HX63-14C037-EBF.vbf	Jaguar XF (X260)	ABS - Anti-Lock Brake System Control Module	DATA
HX63-14C037-EBG.vbf	Jaguar XF (X260)	ABS - Anti-Lock Brake System Control Module	DATA
HX63-14C037-EBH.vbf	Jaguar XF (X260)	ABS - Anti-Lock Brake System Control Module	DATA
HX63-14C037-ECF.vbf	Jaguar XF (X260)	ABS - Anti-Lock Brake System Control Module	DATA
HX63-14C037-ECG.vbf	Jaguar XF (X260)	ABS - Anti-Lock Brake System Control Module	DATA
HX63-14C037-ECH.vbf	Jaguar XF (X260)	ABS - Anti-Lock Brake System Control Module	DATA
HX63-14C037-EFE.vbf	Jaguar XF (X260)	ABS - Anti-Lock Brake System Control Module	DATA
HX63-14C037-EFF.vbf	Jaguar XF (X260)	ABS - Anti-Lock Brake System Control Module	DATA
HX63-14C037-EFG.vbf	Jaguar XF (X260)	ABS - Anti-Lock Brake System Control Module	DATA
HX63-14C037-EFH.vbf	Jaguar XF (X260)	ABS - Anti-Lock Brake System Control Module	DATA
HX63-14C037-EGF.vbf	Jaguar XF (X260)	ABS - Anti-Lock Brake System Control Module	DATA
HX63-14C037-EGG.vbf	Jaguar XF (X260)	ABS - Anti-Lock Brake System Control Module	DATA
HX63-14C037-EGH.vbf	Jaguar XF (X260)	ABS - Anti-Lock Brake System Control Module	DATA
HX63-14C037-EHG.vbf	Jaguar XF (X260)	ABS - Anti-Lock Brake System Control Module	DATA
HX63-14C037-EHH.vbf	Jaguar XF (X260)	ABS - Anti-Lock Brake System Control Module	DATA
HX63-14C037-EHJ.vbf	Jaguar XF (X260)	ABS - Anti-Lock Brake System Control Module	DATA
HX63-14C037-EHK.vbf	Jaguar XF (X260)	ABS - Anti-Lock Brake System Control Module	DATA
HX63-14C037-EJF.vbf	Jaguar XF (X260)	ABS - Anti-Lock Brake System Control Module	DATA
HX63-14C037-EJH.vbf	Jaguar XF (X260)	ABS - Anti-Lock Brake System Control Module	DATA
HX63-14C037-EJJ.vbf	Jaguar XF (X260)	ABS - Anti-Lock Brake System Control Module	DATA
HX63-14C037-EJK.vbf	Jaguar XF (X260)	ABS - Anti-Lock Brake System Control Module	DATA
HX63-14C037-EKG.vbf	Jaguar XF (X260)	ABS - Anti-Lock Brake System Control Module	DATA
HX63-14C037-EKH.vbf	Jaguar XF (X260)	ABS - Anti-Lock Brake System Control Module	DATA
HX63-14C037-EKJ.vbf	Jaguar XF (X260)	ABS - Anti-Lock Brake System Control Module	DATA
HX63-14C037-EKK.vbf	Jaguar XF (X260)	ABS - Anti-Lock Brake System Control Module	DATA
HX63-14C037-ELG.vbf	Jaguar XF (X260)	ABS - Anti-Lock Brake System Control Module	DATA
HX63-14C037-ELH.vbf	Jaguar XF (X260)	ABS - Anti-Lock Brake System Control Module	DATA
HX63-14C037-ELJ.vbf	Jaguar XF (X260)	ABS - Anti-Lock Brake System Control Module	DATA
HX63-14C037-ELK.vbf	Jaguar XF (X260)	ABS - Anti-Lock Brake System Control Module	DATA
HX63-14C037-EMF.vbf	Jaguar XF (X260)	ABS - Anti-Lock Brake System Control Module	DATA
HX63-14C037-EMG.vbf	Jaguar XF (X260)	ABS - Anti-Lock Brake System Control Module	DATA
HX63-14C037-EMH.vbf	Jaguar XF (X260)	ABS - Anti-Lock Brake System Control Module	DATA
HX63-14C037-FAF.vbf	Jaguar XF (X260)	ABS - Anti-Lock Brake System Control Module	DATA
HX63-14C037-FAG.vbf	Jaguar XF (X260)	ABS - Anti-Lock Brake System Control Module	DATA
HX63-14C037-FAH.vbf	Jaguar XF (X260)	ABS - Anti-Lock Brake System Control Module	DATA
HX63-14C037-FBF.vbf	Jaguar XF (X260)	ABS - Anti-Lock Brake System Control Module	DATA
HX63-14C037-FBG.vbf	Jaguar XF (X260)	ABS - Anti-Lock Brake System Control Module	DATA
HX63-14C037-FBH.vbf	Jaguar XF (X260)	ABS - Anti-Lock Brake System Control Module	DATA
HX63-14C037-FCF.vbf	Jaguar XF (X260)	ABS - Anti-Lock Brake System Control Module	DATA
HX63-14C037-FCG.vbf	Jaguar XF (X260)	ABS - Anti-Lock Brake System Control Module	DATA
HX63-14C037-FCH.vbf	Jaguar XF (X260)	ABS - Anti-Lock Brake System Control Module	DATA
HX63-14C037-FDE.vbf	Jaguar XF (X260)	ABS - Anti-Lock Brake System Control Module	DATA
HX63-14C037-FDF.vbf	Jaguar XF (X260)	ABS - Anti-Lock Brake System Control Module	DATA
HX63-14C037-FDG.vbf	Jaguar XF (X260)	ABS - Anti-Lock Brake System Control Module	DATA
HX63-14C037-FDH.vbf	Jaguar XF (X260)	ABS - Anti-Lock Brake System Control Module	DATA
HX63-14C037-FGE.vbf	Jaguar XF (X260)	ABS - Anti-Lock Brake System Control Module	DATA
HX63-14C037-FGF.vbf	Jaguar XF (X260)	ABS - Anti-Lock Brake System Control Module	DATA
HX63-14C037-FGG.vbf	Jaguar XF (X260)	ABS - Anti-Lock Brake System Control Module	DATA
HX63-14C037-FGH.vbf	Jaguar XF (X260)	ABS - Anti-Lock Brake System Control Module	DATA
HX63-14C037-FHF.vbf	Jaguar XF (X260)	ABS - Anti-Lock Brake System Control Module	DATA
HX63-14C037-FHG.vbf	Jaguar XF (X260)	ABS - Anti-Lock Brake System Control Module	DATA
HX63-14C037-FHH.vbf	Jaguar XF (X260)	ABS - Anti-Lock Brake System Control Module	DATA
HX63-14C037-FJF.vbf	Jaguar XF (X260)	ABS - Anti-Lock Brake System Control Module	DATA
HX63-14C037-FJG.vbf	Jaguar XF (X260)	ABS - Anti-Lock Brake System Control Module	DATA
HX63-14C037-FJH.vbf	Jaguar XF (X260)	ABS - Anti-Lock Brake System Control Module	DATA
HX63-14C037-FME.vbf	Jaguar XF (X260)	ABS - Anti-Lock Brake System Control Module	DATA
HX63-14C037-FMF.vbf	Jaguar XF (X260)	ABS - Anti-Lock Brake System Control Module	DATA
HX63-14C037-FMG.vbf	Jaguar XF (X260)	ABS - Anti-Lock Brake System Control Module	DATA
HX63-14C037-FMH.vbf	Jaguar XF (X260)	ABS - Anti-Lock Brake System Control Module	DATA
HX63-14C037-FNF.vbf	Jaguar XF (X260)	ABS - Anti-Lock Brake System Control Module	DATA
HX63-14C037-FNG.vbf	Jaguar XF (X260)	ABS - Anti-Lock Brake System Control Module	DATA
HX63-14C037-FNH.vbf	Jaguar XF (X260)	ABS - Anti-Lock Brake System Control Module	DATA
HX63-14C037-FRF.vbf	Jaguar XF (X260)	ABS - Anti-Lock Brake System Control Module	DATA
HX63-14C037-FRG.vbf	Jaguar XF (X260)	ABS - Anti-Lock Brake System Control Module	DATA
HX63-14C037-FRH.vbf	Jaguar XF (X260)	ABS - Anti-Lock Brake System Control Module	DATA
HX63-14C037-FSF.vbf	Jaguar XF (X260)	ABS - Anti-Lock Brake System Control Module	DATA
HX63-14C037-FSG.vbf	Jaguar XF (X260)	ABS - Anti-Lock Brake System Control Module	DATA

File name	Vehicle line (indicative)	Module (ECU)	Type
HX63-14C037-FSH.vbf	Jaguar XF (X260)	ABS - Anti-Lock Brake System Control Module	DATA
HX63-14C037-FTF.vbf	Jaguar XF (X260)	ABS - Anti-Lock Brake System Control Module	DATA
HX63-14C037-FTG.vbf	Jaguar XF (X260)	ABS - Anti-Lock Brake System Control Module	DATA
HX63-14C037-FTH.vbf	Jaguar XF (X260)	ABS - Anti-Lock Brake System Control Module	DATA
HX63-14C037-FUE.vbf	Jaguar XF (X260)	ABS - Anti-Lock Brake System Control Module	DATA
HX63-14C037-FUF.vbf	Jaguar XF (X260)	ABS - Anti-Lock Brake System Control Module	DATA
HX63-14C037-FUG.vbf	Jaguar XF (X260)	ABS - Anti-Lock Brake System Control Module	DATA
HX63-14C037-FUH.vbf	Jaguar XF (X260)	ABS - Anti-Lock Brake System Control Module	DATA
HX63-14C037-FVF.vbf	Jaguar XF (X260)	ABS - Anti-Lock Brake System Control Module	DATA
HX63-14C037-FVG.vbf	Jaguar XF (X260)	ABS - Anti-Lock Brake System Control Module	DATA
HX63-14C037-FVH.vbf	Jaguar XF (X260)	ABS - Anti-Lock Brake System Control Module	DATA
HX63-14C037-FXF.vbf	Jaguar XF (X260)	ABS - Anti-Lock Brake System Control Module	DATA
HX63-14C037-FXG.vbf	Jaguar XF (X260)	ABS - Anti-Lock Brake System Control Module	DATA
HX63-14C037-FXH.vbf	Jaguar XF (X260)	ABS - Anti-Lock Brake System Control Module	DATA
HX63-14C037-FYE.vbf	Jaguar XF (X260)	ABS - Anti-Lock Brake System Control Module	DATA
HX63-14C037-FYF.vbf	Jaguar XF (X260)	ABS - Anti-Lock Brake System Control Module	DATA
HX63-14C037-FYG.vbf	Jaguar XF (X260)	ABS - Anti-Lock Brake System Control Module	DATA
HX63-14C037-FYH.vbf	Jaguar XF (X260)	ABS - Anti-Lock Brake System Control Module	DATA
HX63-14C037-FZE.vbf	Jaguar XF (X260)	ABS - Anti-Lock Brake System Control Module	DATA
HX63-14C037-FZF.vbf	Jaguar XF (X260)	ABS - Anti-Lock Brake System Control Module	DATA
HX63-14C037-FZG.vbf	Jaguar XF (X260)	ABS - Anti-Lock Brake System Control Module	DATA
HX63-14C037-FZH.vbf	Jaguar XF (X260)	ABS - Anti-Lock Brake System Control Module	DATA
HX63-14C037-MAD.vbf	Jaguar XF (X260)	SPCM - Secondary Powertrain Control Module	EXE
HX63-14C037-MAE.vbf	Jaguar XF (X260)	SPCM - Secondary Powertrain Control Module	EXE
HX63-14C037-MAF.vbf	Jaguar XF (X260)	SPCM - Secondary Powertrain Control Module	EXE
HX63-14C037-MAG.vbf	Jaguar XF (X260)	SPCM - Secondary Powertrain Control Module	DATA
HX63-14C037-MAJ.vbf	Jaguar XF (X260)	SPCM - Secondary Powertrain Control Module	DATA
HX63-14C037-MED.vbf	Jaguar XF (X260)	SPCM - Secondary Powertrain Control Module	EXE
HX63-14C037-MEE.vbf	Jaguar XF (X260)	SPCM - Secondary Powertrain Control Module	EXE
HX63-14C037-MEF.vbf	Jaguar XF (X260)	SPCM - Secondary Powertrain Control Module	EXE
HX63-14C037-MEG.vbf	Jaguar XF (X260)	SPCM - Secondary Powertrain Control Module	DATA
HX63-14C037-MEJ.vbf	Jaguar XF (X260)	SPCM - Secondary Powertrain Control Module	DATA
HX63-14C037-MGD.vbf	Jaguar XF (X260)	SPCM - Secondary Powertrain Control Module	EXE
HX63-14C037-MGE.vbf	Jaguar XF (X260)	SPCM - Secondary Powertrain Control Module	EXE
HX63-14C037-MGF.vbf	Jaguar XF (X260)	SPCM - Secondary Powertrain Control Module	EXE
HX63-14C037-MGG.vbf	Jaguar XF (X260)	SPCM - Secondary Powertrain Control Module	DATA
HX63-14C037-MGJ.vbf	Jaguar XF (X260)	SPCM - Secondary Powertrain Control Module	DATA
HX63-14C037-MLD.vbf	Jaguar XF (X260)	SPCM - Secondary Powertrain Control Module	EXE
HX63-14C037-MLE.vbf	Jaguar XF (X260)	SPCM - Secondary Powertrain Control Module	EXE
HX63-14C037-MLF.vbf	Jaguar XF (X260)	SPCM - Secondary Powertrain Control Module	EXE
HX63-14C037-MLG.vbf	Jaguar XF (X260)	SPCM - Secondary Powertrain Control Module	DATA
HX63-14C037-MLJ.vbf	Jaguar XF (X260)	SPCM - Secondary Powertrain Control Module	DATA
HX63-14C037-MND.vbf	Jaguar XF (X260)	SPCM - Secondary Powertrain Control Module	EXE
HX63-14C037-MNE.vbf	Jaguar XF (X260)	SPCM - Secondary Powertrain Control Module	EXE
HX63-14C037-MNF.vbf	Jaguar XF (X260)	SPCM - Secondary Powertrain Control Module	EXE
HX63-14C037-MNG.vbf	Jaguar XF (X260)	SPCM - Secondary Powertrain Control Module	DATA
HX63-14C037-MNJ.vbf	Jaguar XF (X260)	SPCM - Secondary Powertrain Control Module	DATA
HX63-14C037-MTD.vbf	Jaguar XF (X260)	SPCM - Secondary Powertrain Control Module	EXE
HX63-14C037-MTE.vbf	Jaguar XF (X260)	SPCM - Secondary Powertrain Control Module	EXE
HX63-14C037-MTF.vbf	Jaguar XF (X260)	SPCM - Secondary Powertrain Control Module	EXE
HX63-14C037-MTG.vbf	Jaguar XF (X260)	SPCM - Secondary Powertrain Control Module	DATA
HX63-14C037-MTJ.vbf	Jaguar XF (X260)	SPCM - Secondary Powertrain Control Module	DATA
HX63-14C037-MVD.vbf	Jaguar XF (X260)	SPCM - Secondary Powertrain Control Module	EXE
HX63-14C037-MVE.vbf	Jaguar XF (X260)	SPCM - Secondary Powertrain Control Module	EXE
HX63-14C037-MVF.vbf	Jaguar XF (X260)	SPCM - Secondary Powertrain Control Module	EXE
HX63-14C037-MVG.vbf	Jaguar XF (X260)	SPCM - Secondary Powertrain Control Module	DATA
HX63-14C037-MVJ.vbf	Jaguar XF (X260)	SPCM - Secondary Powertrain Control Module	DATA
HX63-14C037-NAD.vbf	Jaguar XF (X260)	SPCM - Secondary Powertrain Control Module	EXE
HX63-14C037-NAE.vbf	Jaguar XF (X260)	SPCM - Secondary Powertrain Control Module	EXE
HX63-14C037-NAF.vbf	Jaguar XF (X260)	SPCM - Secondary Powertrain Control Module	EXE
HX63-14C037-NAG.vbf	Jaguar XF (X260)	SPCM - Secondary Powertrain Control Module	DATA
HX63-14C037-NAJ.vbf	Jaguar XF (X260)	SPCM - Secondary Powertrain Control Module	DATA
HX63-14C037-NCD.vbf	Jaguar XF (X260)	SPCM - Secondary Powertrain Control Module	EXE
HX63-14C037-NCE.vbf	Jaguar XF (X260)	SPCM - Secondary Powertrain Control Module	EXE
HX63-14C037-NCF.vbf	Jaguar XF (X260)	SPCM - Secondary Powertrain Control Module	EXE
HX63-14C037-NCG.vbf	Jaguar XF (X260)	SPCM - Secondary Powertrain Control Module	DATA
HX63-14C037-NCJ.vbf	Jaguar XF (X260)	SPCM - Secondary Powertrain Control Module	DATA
HX63-14C037-NJD.vbf	Jaguar XF (X260)	SPCM - Secondary Powertrain Control Module	EXE
HX63-14C037-NJE.vbf	Jaguar XF (X260)	SPCM - Secondary Powertrain Control Module	EXE
HX63-14C037-NJF.vbf	Jaguar XF (X260)	SPCM - Secondary Powertrain Control Module	EXE
HX63-14C037-NJG.vbf	Jaguar XF (X260)	SPCM - Secondary Powertrain Control Module	DATA
HX63-14C037-NJJ.vbf	Jaguar XF (X260)	SPCM - Secondary Powertrain Control Module	DATA
HX63-14C037-NLD.vbf	Jaguar XF (X260)	SPCM - Secondary Powertrain Control Module	EXE
HX63-14C037-NLE.vbf	Jaguar XF (X260)	SPCM - Secondary Powertrain Control Module	EXE
HX63-14C037-NLF.vbf	Jaguar XF (X260)	SPCM - Secondary Powertrain Control Module	EXE
HX63-14C037-NLG.vbf	Jaguar XF (X260)	SPCM - Secondary Powertrain Control Module	DATA

File name	Vehicle line (indicative)	Module (ECU)	Type
HX63-14C037-NLJ.vbf	Jaguar XF (X260)	SPCM - Secondary Powertrain Control Module	DATA
HX63-14C037-PBD.vbf	Jaguar XF (X260)	SPCM - Secondary Powertrain Control Module	EXE
HX63-14C037-PBE.vbf	Jaguar XF (X260)	SPCM - Secondary Powertrain Control Module	EXE
HX63-14C037-PBF.vbf	Jaguar XF (X260)	SPCM - Secondary Powertrain Control Module	EXE
HX63-14C037-PBG.vbf	Jaguar XF (X260)	SPCM - Secondary Powertrain Control Module	DATA
HX63-14C037-PBJ.vbf	Jaguar XF (X260)	SPCM - Secondary Powertrain Control Module	DATA
HX63-14C037-PFD.vbf	Jaguar XF (X260)	SPCM - Secondary Powertrain Control Module	EXE
HX63-14C037-PFE.vbf	Jaguar XF (X260)	SPCM - Secondary Powertrain Control Module	EXE
HX63-14C037-PFF.vbf	Jaguar XF (X260)	SPCM - Secondary Powertrain Control Module	EXE
HX63-14C037-PFG.vbf	Jaguar XF (X260)	SPCM - Secondary Powertrain Control Module	DATA
HX63-14C037-PFJ.vbf	Jaguar XF (X260)	SPCM - Secondary Powertrain Control Module	DATA
HX63-14C037-RPD.vbf	Jaguar XF (X260)	SPCM - Secondary Powertrain Control Module	EXE
HX63-14C037-RPE.vbf	Jaguar XF (X260)	SPCM - Secondary Powertrain Control Module	EXE
HX63-14C037-RPF.vbf	Jaguar XF (X260)	SPCM - Secondary Powertrain Control Module	EXE
HX63-14C037-RPG.vbf	Jaguar XF (X260)	SPCM - Secondary Powertrain Control Module	DATA
HX63-14C037-RPJ.vbf	Jaguar XF (X260)	SPCM - Secondary Powertrain Control Module	DATA
HX63-14C037-RRD.vbf	Jaguar XF (X260)	SPCM - Secondary Powertrain Control Module	EXE
HX63-14C037-RRE.vbf	Jaguar XF (X260)	SPCM - Secondary Powertrain Control Module	EXE
HX63-14C037-RRF.vbf	Jaguar XF (X260)	SPCM - Secondary Powertrain Control Module	EXE
HX63-14C037-RRG.vbf	Jaguar XF (X260)	SPCM - Secondary Powertrain Control Module	DATA
HX63-14C037-RRJ.vbf	Jaguar XF (X260)	SPCM - Secondary Powertrain Control Module	DATA
HX63-14C037-RSD.vbf	Jaguar XF (X260)	SPCM - Secondary Powertrain Control Module	EXE
HX63-14C037-RSE.vbf	Jaguar XF (X260)	SPCM - Secondary Powertrain Control Module	EXE
HX63-14C037-RSG.vbf	Jaguar XF (X260)	SPCM - Secondary Powertrain Control Module	EXE
HX63-14C037-RSH.vbf	Jaguar XF (X260)	SPCM - Secondary Powertrain Control Module	DATA
HX63-14C037-RSJ.vbf	Jaguar XF (X260)	SPCM - Secondary Powertrain Control Module	DATA
HX63-14C037-RSL.vbf	Jaguar XF (X260)	SPCM - Secondary Powertrain Control Module	DATA
HX63-14C037-RUD.vbf	Jaguar XF (X260)	SPCM - Secondary Powertrain Control Module	EXE
HX63-14C037-RUE.vbf	Jaguar XF (X260)	SPCM - Secondary Powertrain Control Module	EXE
HX63-14C037-RUG.vbf	Jaguar XF (X260)	SPCM - Secondary Powertrain Control Module	EXE
HX63-14C037-RUH.vbf	Jaguar XF (X260)	SPCM - Secondary Powertrain Control Module	DATA
HX63-14C037-RUJ.vbf	Jaguar XF (X260)	SPCM - Secondary Powertrain Control Module	DATA
HX63-14C037-RUL.vbf	Jaguar XF (X260)	SPCM - Secondary Powertrain Control Module	DATA
HX63-14C037-SBE.vbf	Jaguar XF (X260)	ABS - Anti-Lock Brake System Control Module	DATA
HX63-14C037-SBF.vbf	Jaguar XF (X260)	ABS - Anti-Lock Brake System Control Module	DATA
HX63-14C037-SBG.vbf	Jaguar XF (X260)	ABS - Anti-Lock Brake System Control Module	DATA
HX63-14C037-SBH.vbf	Jaguar XF (X260)	ABS - Anti-Lock Brake System Control Module	DATA
HX63-14C037-SCE.vbf	Jaguar XF (X260)	ABS - Anti-Lock Brake System Control Module	DATA
HX63-14C037-SCF.vbf	Jaguar XF (X260)	ABS - Anti-Lock Brake System Control Module	DATA
HX63-14C037-SCG.vbf	Jaguar XF (X260)	ABS - Anti-Lock Brake System Control Module	DATA
HX63-14C037-SCH.vbf	Jaguar XF (X260)	ABS - Anti-Lock Brake System Control Module	DATA
HX63-14C037-SFE.vbf	Jaguar XF (X260)	ABS - Anti-Lock Brake System Control Module	DATA
HX63-14C037-SFF.vbf	Jaguar XF (X260)	ABS - Anti-Lock Brake System Control Module	DATA
HX63-14C037-SFG.vbf	Jaguar XF (X260)	ABS - Anti-Lock Brake System Control Module	DATA
HX63-14C037-SFH.vbf	Jaguar XF (X260)	ABS - Anti-Lock Brake System Control Module	DATA
HX63-14C037-SGE.vbf	Jaguar XF (X260)	ABS - Anti-Lock Brake System Control Module	DATA
HX63-14C037-SGF.vbf	Jaguar XF (X260)	ABS - Anti-Lock Brake System Control Module	DATA
HX63-14C037-SGG.vbf	Jaguar XF (X260)	ABS - Anti-Lock Brake System Control Module	DATA
HX63-14C037-SGH.vbf	Jaguar XF (X260)	ABS - Anti-Lock Brake System Control Module	DATA
HX63-14C037-SHG.vbf	Jaguar XF (X260)	ABS - Anti-Lock Brake System Control Module	DATA
HX63-14C037-SHH.vbf	Jaguar XF (X260)	ABS - Anti-Lock Brake System Control Module	DATA
HX63-14C037-SHJ.vbf	Jaguar XF (X260)	ABS - Anti-Lock Brake System Control Module	DATA
HX63-14C037-SHK.vbf	Jaguar XF (X260)	ABS - Anti-Lock Brake System Control Module	DATA
HX63-14C037-SJG.vbf	Jaguar XF (X260)	ABS - Anti-Lock Brake System Control Module	DATA
HX63-14C037-SJH.vbf	Jaguar XF (X260)	ABS - Anti-Lock Brake System Control Module	DATA
HX63-14C037-SJJ.vbf	Jaguar XF (X260)	ABS - Anti-Lock Brake System Control Module	DATA
HX63-14C037-SJK.vbf	Jaguar XF (X260)	ABS - Anti-Lock Brake System Control Module	DATA
HX63-14C037-SKG.vbf	Jaguar XF (X260)	ABS - Anti-Lock Brake System Control Module	DATA
HX63-14C037-SKH.vbf	Jaguar XF (X260)	ABS - Anti-Lock Brake System Control Module	DATA
HX63-14C037-SKJ.vbf	Jaguar XF (X260)	ABS - Anti-Lock Brake System Control Module	DATA
HX63-14C037-SKK.vbf	Jaguar XF (X260)	ABS - Anti-Lock Brake System Control Module	DATA
HX63-14C037-SLG.vbf	Jaguar XF (X260)	ABS - Anti-Lock Brake System Control Module	DATA
HX63-14C037-SLH.vbf	Jaguar XF (X260)	ABS - Anti-Lock Brake System Control Module	DATA
HX63-14C037-SLJ.vbf	Jaguar XF (X260)	ABS - Anti-Lock Brake System Control Module	DATA
HX63-14C037-SLK.vbf	Jaguar XF (X260)	ABS - Anti-Lock Brake System Control Module	DATA
HX63-14C037-SME.vbf	Jaguar XF (X260)	ABS - Anti-Lock Brake System Control Module	DATA
HX63-14C037-SMF.vbf	Jaguar XF (X260)	ABS - Anti-Lock Brake System Control Module	DATA
HX63-14C037-SMG.vbf	Jaguar XF (X260)	ABS - Anti-Lock Brake System Control Module	DATA
HX63-14C037-SMH.vbf	Jaguar XF (X260)	ABS - Anti-Lock Brake System Control Module	DATA
HX63-14C037-TAF.vbf	Jaguar XF (X260)	ABS - Anti-Lock Brake System Control Module	DATA
HX63-14C037-TAG.vbf	Jaguar XF (X260)	ABS - Anti-Lock Brake System Control Module	DATA
HX63-14C037-TAH.vbf	Jaguar XF (X260)	ABS - Anti-Lock Brake System Control Module	DATA
HX63-14C037-TBE.vbf	Jaguar XF (X260)	ABS - Anti-Lock Brake System Control Module	DATA
HX63-14C037-TBF.vbf	Jaguar XF (X260)	ABS - Anti-Lock Brake System Control Module	DATA
HX63-14C037-TBG.vbf	Jaguar XF (X260)	ABS - Anti-Lock Brake System Control Module	DATA
HX63-14C037-TBH.vbf	Jaguar XF (X260)	ABS - Anti-Lock Brake System Control Module	DATA

File name	Vehicle line (indicative)	Module (ECU)	Type
HX63-14C037-TCE.vbf	Jaguar XF (X260)	ABS - Anti-Lock Brake System Control Module	DATA
HX63-14C037-TCF.vbf	Jaguar XF (X260)	ABS - Anti-Lock Brake System Control Module	DATA
HX63-14C037-TCG.vbf	Jaguar XF (X260)	ABS - Anti-Lock Brake System Control Module	DATA
HX63-14C037-TCH.vbf	Jaguar XF (X260)	ABS - Anti-Lock Brake System Control Module	DATA
HX63-14C037-TDE.vbf	Jaguar XF (X260)	ABS - Anti-Lock Brake System Control Module	DATA
HX63-14C037-TDF.vbf	Jaguar XF (X260)	ABS - Anti-Lock Brake System Control Module	DATA
HX63-14C037-TDG.vbf	Jaguar XF (X260)	ABS - Anti-Lock Brake System Control Module	DATA
HX63-14C037-TDH.vbf	Jaguar XF (X260)	ABS - Anti-Lock Brake System Control Module	DATA
HX63-14C037-TGE.vbf	Jaguar XF (X260)	ABS - Anti-Lock Brake System Control Module	DATA
HX63-14C037-TGF.vbf	Jaguar XF (X260)	ABS - Anti-Lock Brake System Control Module	DATA
HX63-14C037-TGG.vbf	Jaguar XF (X260)	ABS - Anti-Lock Brake System Control Module	DATA
HX63-14C037-TGH.vbf	Jaguar XF (X260)	ABS - Anti-Lock Brake System Control Module	DATA
HX63-14C037-THF.vbf	Jaguar XF (X260)	ABS - Anti-Lock Brake System Control Module	DATA
HX63-14C037-THG.vbf	Jaguar XF (X260)	ABS - Anti-Lock Brake System Control Module	DATA
HX63-14C037-THH.vbf	Jaguar XF (X260)	ABS - Anti-Lock Brake System Control Module	DATA
HX63-14C037-TJE.vbf	Jaguar XF (X260)	ABS - Anti-Lock Brake System Control Module	DATA
HX63-14C037-TJF.vbf	Jaguar XF (X260)	ABS - Anti-Lock Brake System Control Module	DATA
HX63-14C037-TJG.vbf	Jaguar XF (X260)	ABS - Anti-Lock Brake System Control Module	DATA
HX63-14C037-TJH.vbf	Jaguar XF (X260)	ABS - Anti-Lock Brake System Control Module	DATA
HX63-14C037-TRE.vbf	Jaguar XF (X260)	ABS - Anti-Lock Brake System Control Module	DATA
HX63-14C037-TRF.vbf	Jaguar XF (X260)	ABS - Anti-Lock Brake System Control Module	DATA
HX63-14C037-TRG.vbf	Jaguar XF (X260)	ABS - Anti-Lock Brake System Control Module	DATA
HX63-14C037-TRH.vbf	Jaguar XF (X260)	ABS - Anti-Lock Brake System Control Module	DATA
HX63-14C037-TSE.vbf	Jaguar XF (X260)	ABS - Anti-Lock Brake System Control Module	DATA
HX63-14C037-TSF.vbf	Jaguar XF (X260)	ABS - Anti-Lock Brake System Control Module	DATA
HX63-14C037-TSG.vbf	Jaguar XF (X260)	ABS - Anti-Lock Brake System Control Module	DATA
HX63-14C037-TSH.vbf	Jaguar XF (X260)	ABS - Anti-Lock Brake System Control Module	DATA
HX63-14C037-TUE.vbf	Jaguar XF (X260)	ABS - Anti-Lock Brake System Control Module	DATA
HX63-14C037-TUF.vbf	Jaguar XF (X260)	ABS - Anti-Lock Brake System Control Module	DATA
HX63-14C037-TUG.vbf	Jaguar XF (X260)	ABS - Anti-Lock Brake System Control Module	DATA
HX63-14C037-TUH.vbf	Jaguar XF (X260)	ABS - Anti-Lock Brake System Control Module	DATA
HX63-14C037-TVF.vbf	Jaguar XF (X260)	ABS - Anti-Lock Brake System Control Module	DATA
HX63-14C037-TVG.vbf	Jaguar XF (X260)	ABS - Anti-Lock Brake System Control Module	DATA
HX63-14C037-TVH.vbf	Jaguar XF (X260)	ABS - Anti-Lock Brake System Control Module	DATA
HX63-14C037-TXE.vbf	Jaguar XF (X260)	ABS - Anti-Lock Brake System Control Module	DATA
HX63-14C037-TXF.vbf	Jaguar XF (X260)	ABS - Anti-Lock Brake System Control Module	DATA
HX63-14C037-TXG.vbf	Jaguar XF (X260)	ABS - Anti-Lock Brake System Control Module	DATA
HX63-14C037-TXH.vbf	Jaguar XF (X260)	ABS - Anti-Lock Brake System Control Module	DATA
HX63-14C037-TYF.vbf	Jaguar XF (X260)	ABS - Anti-Lock Brake System Control Module	DATA
HX63-14C037-TYG.vbf	Jaguar XF (X260)	ABS - Anti-Lock Brake System Control Module	DATA
HX63-14C037-TYH.vbf	Jaguar XF (X260)	ABS - Anti-Lock Brake System Control Module	DATA
HX63-14C037-TZE.vbf	Jaguar XF (X260)	ABS - Anti-Lock Brake System Control Module	DATA
HX63-14C037-TZF.vbf	Jaguar XF (X260)	ABS - Anti-Lock Brake System Control Module	DATA
HX63-14C037-TZG.vbf	Jaguar XF (X260)	ABS - Anti-Lock Brake System Control Module	DATA
HX63-14C037-TZH.vbf	Jaguar XF (X260)	ABS - Anti-Lock Brake System Control Module	DATA
HX63-14C065-AC.vbf	Jaguar XF (X260)	DDM - Driver Front Door Module	DATA
HX63-14C065-AD.vbf	Jaguar XF (X260)	DDM - Driver Front Door Module	DATA
HX63-14C065-AE.vbf	Jaguar XF (X260)	DDM - Driver Front Door Module	DATA
HX63-14C065-AF.vbf	Jaguar XF (X260)	DDM - Driver Front Door Module	DATA
HX63-14C069-AC.vbf	Jaguar XF (X260)	DRDM - Driver Rear Door Module	DATA
HX63-14C069-AD.vbf	Jaguar XF (X260)	DRDM - Driver Rear Door Module	DATA
HX63-14C069-AE.vbf	Jaguar XF (X260)	DRDM - Driver Rear Door Module	DATA
HX63-14C069-AF.vbf	Jaguar XF (X260)	DRDM - Driver Rear Door Module	DATA
HX63-14C088-BC.vbf	Jaguar XF (X260)	IPC - Instrument Panel Cluster (IPC) Control Module	DATA
HX63-14C088-CA.vbf	Jaguar XF (X260)	IPC - Instrument Panel Cluster (IPC) Control Module	EXE
HX63-14C088-CB.vbf	Jaguar XF (X260)	IPC - Instrument Panel Cluster (IPC) Control Module	EXE
HX63-14C088-CC.vbf	Jaguar XF (X260)	IPC - Instrument Panel Cluster (IPC) Control Module	EXE
HX63-14C088-CD.vbf	Jaguar XF (X260)	IPC - Instrument Panel Cluster (IPC) Control Module	EXE
HX63-14C088-DA.vbf	Jaguar XF (X260)	IPC - Instrument Panel Cluster (IPC) Control Module	DATA
HX63-14C088-JA.vbf	Jaguar XF (X260)	IPC - Instrument Panel Cluster (IPC) Control Module	DATA
HX63-14C088-JB.vbf	Jaguar XF (X260)	IPC - Instrument Panel Cluster (IPC) Control Module	DATA
HX63-14C088-JC.vbf	Jaguar XF (X260)	IPC - Instrument Panel Cluster (IPC) Control Module	DATA
HX63-14C088-JD.vbf	Jaguar XF (X260)	IPC - Instrument Panel Cluster (IPC) Control Module	DATA
HX63-14C088-JE.vbf	Jaguar XF (X260)	IPC - Instrument Panel Cluster (IPC) Control Module	DATA
HX63-14C088-JF.vbf	Jaguar XF (X260)	IPC - Instrument Panel Cluster (IPC) Control Module	DATA
HX63-14C091-AB.vbf	Jaguar XF (X260)	PAM - Parking Assist Control Module	DATA
HX63-14C091-AD.vbf	Jaguar XF (X260)	PAM - Parking Assist Control Module	DATA
HX63-14C091-AE.vbf	Jaguar XF (X260)	PAM - Parking Assist Control Module	DATA
HX63-14C091-BA.vbf	Jaguar XF (X260)	PAM - Parking Assist Control Module	DATA
HX63-14C091-BB.vbf	Jaguar XF (X260)	PAM - Parking Assist Control Module	DATA
HX63-14C091-BC.vbf	Jaguar XF (X260)	PAM - Parking Assist Control Module	DATA
HX63-14C098-DB.vbf	Jaguar XF (X260)	RCM - Restraints Control Module	DATA
HX63-14C098-DC.vbf	Jaguar XF (X260)	RCM - Restraints Control Module	DATA
HX63-14C098-DD.VBF	Jaguar XF (X260)	RCM - Restraints Control Module	DATA
HX63-14C098-DE.VBF	Jaguar XF (X260)	RCM - Restraints Control Module	DATA
HX63-14C109-AC.vbf	Jaguar XF (X260)	PDM - Passenger Front Door Module	DATA

File name	Vehicle line (indicative)	Module (ECU)	Type
HX63-14C109-AD.vbf	Jaguar XF (X260)	PDM - Passenger Front Door Module	DATA
HX63-14C109-AE.vbf	Jaguar XF (X260)	PDM - Passenger Front Door Module	DATA
HX63-14C109-AF.vbf	Jaguar XF (X260)	PDM - Passenger Front Door Module	DATA
HX63-14C113-AC.vbf	Jaguar XF (X260)	PRDM - Passenger Rear Door Module	DATA
HX63-14C113-AD.vbf	Jaguar XF (X260)	PRDM - Passenger Rear Door Module	DATA
HX63-14C113-AE.vbf	Jaguar XF (X260)	PRDM - Passenger Rear Door Module	DATA
HX63-14C113-AF.vbf	Jaguar XF (X260)	PRDM - Passenger Rear Door Module	DATA
HX63-14C121-AB.vbf	X620	RGTM - Rear Gate / Trunk Module	EXE
HX63-14C122-AB.vbf	X620	RGTM - Rear Gate / Trunk Module	DATA
HX63-14C124-AA.vbf	Jaguar XF (X260)	RGTM - Rear Gate / Trunk Module	SBL
HX63-14C152-AA.vbf	Jaguar XF (X260)	TPM - Tire Pressure Monitor Module	DATA
HX63-14C152-BA.vbf	Jaguar XF (X260)	TPM - Tire Pressure Monitor Module	DATA
HX63-14C152-BB.vbf	Jaguar XF (X260)	TPM - Tire Pressure Monitor Module	DATA
HX63-14C152-BC.vbf	Jaguar XF (X260)	TPM - Tire Pressure Monitor Module	DATA
HX63-14C204-CAA.vbf	Jaguar XF (X260)	PCM - Powertrain Control Module	EXE
HX63-14C204-CTA.vbf	Jaguar XF (X260)	PCM - Powertrain Control Module	EXE
HX63-14C218-BA.vbf	Jaguar XF (X260)	PSCM - Power Steering Control Module	DATA
HX63-14C218-CA.vbf	Jaguar XF (X260)	PSCM - Power Steering Control Module	DATA
HX63-14C218-DA.vbf	Jaguar XF (X260)	PSCM - Power Steering Control Module	DATA
HX63-14C218-EA.vbf	Jaguar XF (X260)	PSCM - Power Steering Control Module	DATA
HX63-14C218-FA.vbf	Jaguar XF (X260)	PSCM - Power Steering Control Module	DATA
HX63-14C218-GA.vbf	Jaguar XF (X260)	PSCM - Power Steering Control Module	DATA
HX63-14C302-AH.iso	Jaguar XF (X260)	-	-
HX63-14C302-BJ.iso	Jaguar XF (X260)	-	-
HX63-14C367-DB.vbf	Jaguar XF (X260)	TCCM - Transfer Case Control Module	DATA
HX63-14C367-DC.vbf	Jaguar XF (X260)	TCCM - Transfer Case Control Module	DATA
HX63-14C527-BB.vbf	Jaguar XF (X260)	AAM - Audio Amplifier Module	DATA
HX63-14C527-BC.vbf	Jaguar XF (X260)	AAM - Audio Amplifier Module	DATA
HX63-14C527-CB.vbf	Jaguar XF (X260)	AAM - Audio Amplifier Module	DATA
HX63-14C527-CC.vbf	Jaguar XF (X260)	AAM - Audio Amplifier Module	DATA
HX63-14C548-BB.vbf	Jaguar XF (X260)	PSM - Passenger Front Seat Module	EXE
HX63-14C548-BC.vbf	Jaguar XF (X260)	PSM - Passenger Front Seat Module	EXE
HX63-14C548-BD.vbf	Jaguar XF (X260)	PSM - Passenger Front Seat Module	EXE
HX63-14C548-BE.vbf	Jaguar XF (X260)	PSM - Passenger Front Seat Module	EXE
HX63-14C549-AB.vbf	Jaguar XF (X260)	PSM - Passenger Front Seat Module	EXE
HX63-14C549-AD.vbf	Jaguar XF (X260)	PSM - Passenger Front Seat Module	EXE
HX63-14C609-BA.vbf	Jaguar XF (X260)	PSCM - Power Steering Control Module	DATA
HX63-14C609-BB.vbf	Jaguar XF (X260)	PSCM - Power Steering Control Module	DATA
HX63-14C653-AA.vbf	Jaguar XF (X260)	ACM - Audio Front Control Module	DATA
HX63-14C653-AB.vbf	Jaguar XF (X260)	ACM - Audio Front Control Module	DATA
HX63-14C653-AC.vbf	Jaguar XF (X260)	ACM - Audio Front Control Module	DATA
HX63-14D183-BA.vbf	Jaguar XF (X260)	OCS - Restraints Occupant Classification System Module	DATA
HX63-14D481-BA.vbf	Jaguar XF (X260)	IPMB - Image Processing Module B	DATA
HX63-14D481-BB.vbf	Jaguar XF (X260)	IPMB - Image Processing Module B	DATA
HX63-14D481-BC.vbf	Jaguar XF (X260)	IPMB - Image Processing Module B	DATA
HX63-14D485-BC.vbf	Jaguar XF (X260)	IPMB - Image Processing Module B	DATA
HX63-14D485-BD.vbf	Jaguar XF (X260)	IPMB - Image Processing Module B	DATA
HX63-14D485-BE.vbf	Jaguar XF (X260)	IPMB - Image Processing Module B	DATA
HX63-14E094-DAC.vbf	Jaguar XF (X260)	CHCM - Chassis Control Module	EXE
HX63-14E094-DBC.vbf	Jaguar XF (X260)	CHCM - Chassis Control Module	EXE
HX63-14E094-DCC.vbf	Jaguar XF (X260)	CHCM - Chassis Control Module	EXE
HX63-14E094-DDC.vbf	Jaguar XF (X260)	CHCM - Chassis Control Module	EXE
HX63-14E094-DEC.vbf	Jaguar XF (X260)	CHCM - Chassis Control Module	EXE
HX63-14E094-DFC.vbf	Jaguar XF (X260)	CHCM - Chassis Control Module	EXE
HX63-14E094-DFD.vbf	Jaguar XF (X260)	CHCM - Chassis Control Module	EXE
HX63-14F022-BA.vbf	Jaguar XF (X260)	IPMB - Image Processing Module B	DATA
HX63-14F022-BE.vbf	Jaguar XF (X260)	IPMB - Image Processing Module B	DATA
HX63-14F022-BG.vbf	Jaguar XF (X260)	IPMB - Image Processing Module B	DATA
HX63-14F022-GB.vbf	Jaguar XF (X260)	IPMB - Image Processing Module B	DATA
HX63-14F022-GE.vbf	Jaguar XF (X260)	IPMB - Image Processing Module B	DATA
HX63-14F022-GF.vbf	Jaguar XF (X260)	IPMB - Image Processing Module B	DATA
HX63-14F022-GG.vbf	Jaguar XF (X260)	IPMB - Image Processing Module B	DATA
HX63-19H527-AB.vbf	Jaguar XF (X260)	ACCM - Air Conditioning Control Module	EXE
HX63-7J104-BCA.vbf	Jaguar XF (X260)	TCM - Transmission Control Module	EXE
HX63-7J104-BCB.vbf	Jaguar XF (X260)	TCM - Transmission Control Module	EXE
HX63-7J104-BCC.vbf	Jaguar XF (X260)	TCM - Transmission Control Module	EXE
HX63-7J104-BCD.vbf	Jaguar XF (X260)	TCM - Transmission Control Module	EXE
HX63-7J104-BGA.vbf	Jaguar XF (X260)	TCM - Transmission Control Module	EXE
HX63-7J104-BGB.vbf	Jaguar XF (X260)	TCM - Transmission Control Module	EXE
HX63-7J104-BXA.vbf	Jaguar XF (X260)	TCM - Transmission Control Module	EXE
HX63-7J104-BXB.vbf	Jaguar XF (X260)	TCM - Transmission Control Module	EXE
HX63-7J104-BXC.vbf	Jaguar XF (X260)	TCM - Transmission Control Module	EXE
HX63-7J104-BXD.vbf	Jaguar XF (X260)	TCM - Transmission Control Module	EXE
HX73-12K532-KBA.vbf	Jaguar XE (X760)	PCM - Powertrain Control Module	DATA
HX73-12K532-KBB.vbf	Jaguar XE (X760)	PCM - Powertrain Control Module	DATA
HX73-12K532-KBC.vbf	Jaguar XE (X760)	PCM - Powertrain Control Module	DATA

File name	Vehicle line (indicative)	Module (ECU)	Type
HX73-12K532-KBD.vbf	Jaguar XE (X760)	PCM - Powertrain Control Module	DATA
HX73-12K532-KBE.vbf	Jaguar XE (X760)	PCM - Powertrain Control Module	DATA
HX73-12K532-KBF.vbf	Jaguar XE (X760)	PCM - Powertrain Control Module	DATA
HX73-12K532-KDA.vbf	Jaguar XE (X760)	PCM - Powertrain Control Module	DATA
HX73-12K532-KDC.vbf	Jaguar XE (X760)	PCM - Powertrain Control Module	DATA
HX73-12K532-KDD.vbf	Jaguar XE (X760)	PCM - Powertrain Control Module	DATA
HX73-12K532-KDE.vbf	Jaguar XE (X760)	PCM - Powertrain Control Module	DATA
HX73-12K532-KDF.vbf	Jaguar XE (X760)	PCM - Powertrain Control Module	DATA
HX73-12K532-KEA.vbf	Jaguar XE (X760)	PCM - Powertrain Control Module	DATA
HX73-12K532-KEC.vbf	Jaguar XE (X760)	PCM - Powertrain Control Module	DATA
HX73-12K532-KEE.vbf	Jaguar XE (X760)	PCM - Powertrain Control Module	DATA
HX73-12K532-KEF.vbf	Jaguar XE (X760)	PCM - Powertrain Control Module	DATA
HX73-12K532-KEG.vbf	Jaguar XE (X760)	PCM - Powertrain Control Module	DATA
HX73-12K532-KEH.vbf	Jaguar XE (X760)	PCM - Powertrain Control Module	DATA
HX73-12K532-KEJ.vbf	Jaguar XE (X760)	PCM - Powertrain Control Module	DATA
HX73-12K532-KEK.vbf	Jaguar XE (X760)	PCM - Powertrain Control Module	DATA
HX73-12K532-KEL.vbf	Jaguar XE (X760)	PCM - Powertrain Control Module	DATA
HX73-12K532-KEM.vbf	Jaguar XE (X760)	PCM - Powertrain Control Module	DATA
HX73-12K532-KEN.vbf	Jaguar XE (X760)	PCM - Powertrain Control Module	DATA
HX73-12K532-KEP.vbf	Jaguar XE (X760)	PCM - Powertrain Control Module	DATA
HX73-12K532-KFA.vbf	Jaguar XE (X760)	PCM - Powertrain Control Module	DATA
HX73-12K532-KFC.vbf	Jaguar XE (X760)	PCM - Powertrain Control Module	DATA
HX73-12K532-KFE.vbf	Jaguar XE (X760)	PCM - Powertrain Control Module	DATA
HX73-12K532-KFF.vbf	Jaguar XE (X760)	PCM - Powertrain Control Module	DATA
HX73-12K532-KFG.vbf	Jaguar XE (X760)	PCM - Powertrain Control Module	DATA
HX73-12K532-KFH.vbf	Jaguar XE (X760)	PCM - Powertrain Control Module	DATA
HX73-12K532-KFJ.vbf	Jaguar XE (X760)	PCM - Powertrain Control Module	DATA
HX73-12K532-KFK.vbf	Jaguar XE (X760)	PCM - Powertrain Control Module	DATA
HX73-12K532-KFL.vbf	Jaguar XE (X760)	PCM - Powertrain Control Module	DATA
HX73-12K532-KFM.vbf	Jaguar XE (X760)	PCM - Powertrain Control Module	DATA
HX73-12K532-KFN.vbf	Jaguar XE (X760)	PCM - Powertrain Control Module	DATA
HX73-12K532-KFP.vbf	Jaguar XE (X760)	PCM - Powertrain Control Module	DATA
HX73-12K532-KGA.vbf	Jaguar XE (X760)	PCM - Powertrain Control Module	DATA
HX73-12K532-KGB.vbf	Jaguar XE (X760)	PCM - Powertrain Control Module	DATA
HX73-12K532-KGC.vbf	Jaguar XE (X760)	PCM - Powertrain Control Module	DATA
HX73-12K532-KGD.vbf	Jaguar XE (X760)	PCM - Powertrain Control Module	DATA
HX73-12K532-KGE.vbf	Jaguar XE (X760)	PCM - Powertrain Control Module	DATA
HX73-12K532-KGF.vbf	Jaguar XE (X760)	PCM - Powertrain Control Module	DATA
HX73-12K532-KHA.vbf	Jaguar XE (X760)	PCM - Powertrain Control Module	DATA
HX73-12K532-KHB.vbf	Jaguar XE (X760)	PCM - Powertrain Control Module	DATA
HX73-12K532-KHC.vbf	Jaguar XE (X760)	PCM - Powertrain Control Module	DATA
HX73-12K532-KHD.vbf	Jaguar XE (X760)	PCM - Powertrain Control Module	DATA
HX73-12K532-KHE.vbf	Jaguar XE (X760)	PCM - Powertrain Control Module	DATA
HX73-14C025-AA.vbf	Jaguar XE (X760)	IPC - Instrument Panel Cluster (IPC) Control Module	SBL
HX73-14C025-AB.vbf	Jaguar XE (X760)	IPC - Instrument Panel Cluster (IPC) Control Module	SBL
HX73-14C026-AA.vbf	Jaguar XE (X760)	IPC - Instrument Panel Cluster (IPC) Control Module	EXE
HX73-14C026-AB.vbf	Jaguar XE (X760)	IPC - Instrument Panel Cluster (IPC) Control Module	EXE
HX73-14C026-AC.vbf	Jaguar XE (X760)	IPC - Instrument Panel Cluster (IPC) Control Module	EXE
HX73-14C026-AD.vbf	Jaguar XE (X760)	IPC - Instrument Panel Cluster (IPC) Control Module	EXE
HX73-14C026-AE.vbf	Jaguar XE (X760)	IPC - Instrument Panel Cluster (IPC) Control Module	EXE
HX73-14C026-AF.vbf	Jaguar XE (X760)	IPC - Instrument Panel Cluster (IPC) Control Module	EXE
HX73-14C026-JA.vbf	Jaguar XE (X760)	IPC - Instrument Panel Cluster (IPC) Control Module	EXE
HX73-14C026-KA.vbf	Jaguar XE (X760)	IPC - Instrument Panel Cluster (IPC) Control Module	EXE
HX73-14C026-KB.vbf	Jaguar XE (X760)	IPC - Instrument Panel Cluster (IPC) Control Module	EXE
HX73-14C026-MA.vbf	Jaguar XE (X760)	IPC - Instrument Panel Cluster (IPC) Control Module	EXE
HX73-14C026-MB.vbf	Jaguar XE (X760)	IPC - Instrument Panel Cluster (IPC) Control Module	EXE
HX73-14C026-MC.vbf	Jaguar XE (X760)	IPC - Instrument Panel Cluster (IPC) Control Module	EXE
HX73-14C027-AA.vbf	Jaguar XE (X760)	RCM - Restraints Control Module	SBL
HX73-14C028-AB.vbf	Jaguar XE (X760)	RCM - Restraints Control Module	EXE
HX73-14C028-AC.VBF	Jaguar XE (X760)	RCM - Restraints Control Module	EXE
HX73-14C030-BB.vbf	Jaguar XE (X760)	DSM - Driver Front Seat Module	EXE
HX73-14C030-BC.vbf	Jaguar XE (X760)	DSM - Driver Front Seat Module	EXE
HX73-14C030-BD.vbf	Jaguar XE (X760)	DSM - Driver Front Seat Module	EXE
HX73-14C030-BE.vbf	Jaguar XE (X760)	DSM - Driver Front Seat Module	EXE
HX73-14C034-AB.vbf	Jaguar XE (X760)	DSM - Driver Front Seat Module	EXE
HX73-14C034-AC.vbf	Jaguar XE (X760)	DSM - Driver Front Seat Module	EXE
HX73-14C034-BB.vbf	Jaguar XE (X760)	DSM - Driver Front Seat Module	EXE
HX73-14C034-BC.vbf	Jaguar XE (X760)	DSM - Driver Front Seat Module	EXE
HX73-14C036-AD.vbf	Jaguar XE (X760)	SPCM - Secondary Powertrain Control Module	EXE
HX73-14C036-AE.vbf	Jaguar XE (X760)	SPCM - Secondary Powertrain Control Module	EXE
HX73-14C036-AF.vbf	Jaguar XE (X760)	SPCM - Secondary Powertrain Control Module	EXE
HX73-14C036-AH.vbf	Jaguar XE (X760)	SPCM - Secondary Powertrain Control Module	EXE
HX73-14C036-BD.vbf	Jaguar XE (X760)	SPCM - Secondary Powertrain Control Module	EXE
HX73-14C036-BE.vbf	Jaguar XE (X760)	SPCM - Secondary Powertrain Control Module	EXE
HX73-14C036-BF.vbf	Jaguar XE (X760)	SPCM - Secondary Powertrain Control Module	EXE
HX73-14C036-BH.vbf	Jaguar XE (X760)	SPCM - Secondary Powertrain Control Module	EXE

File name	Vehicle line (indicative)	Module (ECU)	Type
HX73-14C037-AJD.vbf	Jaguar XE (X760)	SPCM - Secondary Powertrain Control Module	EXE
HX73-14C037-AJE.vbf	Jaguar XE (X760)	SPCM - Secondary Powertrain Control Module	EXE
HX73-14C037-AJF.vbf	Jaguar XE (X760)	SPCM - Secondary Powertrain Control Module	EXE
HX73-14C037-AJG.vbf	Jaguar XE (X760)	SPCM - Secondary Powertrain Control Module	DATA
HX73-14C037-AJJ.vbf	Jaguar XE (X760)	SPCM - Secondary Powertrain Control Module	DATA
HX73-14C037-ALD.vbf	Jaguar XE (X760)	SPCM - Secondary Powertrain Control Module	EXE
HX73-14C037-ALE.vbf	Jaguar XE (X760)	SPCM - Secondary Powertrain Control Module	EXE
HX73-14C037-ALF.vbf	Jaguar XE (X760)	SPCM - Secondary Powertrain Control Module	EXE
HX73-14C037-ALG.vbf	Jaguar XE (X760)	SPCM - Secondary Powertrain Control Module	DATA
HX73-14C037-ALJ.vbf	Jaguar XE (X760)	SPCM - Secondary Powertrain Control Module	DATA
HX73-14C037-AND.vbf	Jaguar XE (X760)	SPCM - Secondary Powertrain Control Module	EXE
HX73-14C037-ANE.vbf	Jaguar XE (X760)	SPCM - Secondary Powertrain Control Module	EXE
HX73-14C037-ANF.vbf	Jaguar XE (X760)	SPCM - Secondary Powertrain Control Module	EXE
HX73-14C037-ANG.vbf	Jaguar XE (X760)	SPCM - Secondary Powertrain Control Module	DATA
HX73-14C037-ANJ.vbf	Jaguar XE (X760)	SPCM - Secondary Powertrain Control Module	DATA
HX73-14C037-ATD.vbf	Jaguar XE (X760)	SPCM - Secondary Powertrain Control Module	EXE
HX73-14C037-ATE.vbf	Jaguar XE (X760)	SPCM - Secondary Powertrain Control Module	EXE
HX73-14C037-ATF.vbf	Jaguar XE (X760)	SPCM - Secondary Powertrain Control Module	EXE
HX73-14C037-ATG.vbf	Jaguar XE (X760)	SPCM - Secondary Powertrain Control Module	DATA
HX73-14C037-ATJ.vbf	Jaguar XE (X760)	SPCM - Secondary Powertrain Control Module	DATA
HX73-14C037-BLD.vbf	Jaguar XE (X760)	SPCM - Secondary Powertrain Control Module	EXE
HX73-14C037-BLE.vbf	Jaguar XE (X760)	SPCM - Secondary Powertrain Control Module	EXE
HX73-14C037-BLF.vbf	Jaguar XE (X760)	SPCM - Secondary Powertrain Control Module	EXE
HX73-14C037-BLG.vbf	Jaguar XE (X760)	SPCM - Secondary Powertrain Control Module	DATA
HX73-14C037-BLJ.vbf	Jaguar XE (X760)	SPCM - Secondary Powertrain Control Module	DATA
HX73-14C037-BND.vbf	Jaguar XE (X760)	SPCM - Secondary Powertrain Control Module	EXE
HX73-14C037-BNE.vbf	Jaguar XE (X760)	SPCM - Secondary Powertrain Control Module	EXE
HX73-14C037-BNF.vbf	Jaguar XE (X760)	SPCM - Secondary Powertrain Control Module	EXE
HX73-14C037-BNG.vbf	Jaguar XE (X760)	SPCM - Secondary Powertrain Control Module	DATA
HX73-14C037-BNJ.vbf	Jaguar XE (X760)	SPCM - Secondary Powertrain Control Module	DATA
HX73-14C037-BYD.vbf	Jaguar XE (X760)	SPCM - Secondary Powertrain Control Module	EXE
HX73-14C037-BYE.vbf	Jaguar XE (X760)	SPCM - Secondary Powertrain Control Module	EXE
HX73-14C037-BYF.vbf	Jaguar XE (X760)	SPCM - Secondary Powertrain Control Module	EXE
HX73-14C037-BYG.vbf	Jaguar XE (X760)	SPCM - Secondary Powertrain Control Module	DATA
HX73-14C037-BYJ.vbf	Jaguar XE (X760)	SPCM - Secondary Powertrain Control Module	DATA
HX73-14C037-CBD.vbf	Jaguar XE (X760)	SPCM - Secondary Powertrain Control Module	EXE
HX73-14C037-CBE.vbf	Jaguar XE (X760)	SPCM - Secondary Powertrain Control Module	EXE
HX73-14C037-CBF.vbf	Jaguar XE (X760)	SPCM - Secondary Powertrain Control Module	EXE
HX73-14C037-CBG.vbf	Jaguar XE (X760)	SPCM - Secondary Powertrain Control Module	DATA
HX73-14C037-CBJ.vbf	Jaguar XE (X760)	SPCM - Secondary Powertrain Control Module	DATA
HX73-14C037-CJD.vbf	Jaguar XE (X760)	SPCM - Secondary Powertrain Control Module	EXE
HX73-14C037-CJE.vbf	Jaguar XE (X760)	SPCM - Secondary Powertrain Control Module	EXE
HX73-14C037-CJF.vbf	Jaguar XE (X760)	SPCM - Secondary Powertrain Control Module	EXE
HX73-14C037-CJG.vbf	Jaguar XE (X760)	SPCM - Secondary Powertrain Control Module	DATA
HX73-14C037-CJJ.vbf	Jaguar XE (X760)	SPCM - Secondary Powertrain Control Module	DATA
HX73-14C037-CKD.vbf	Jaguar XE (X760)	SPCM - Secondary Powertrain Control Module	EXE
HX73-14C037-CKE.vbf	Jaguar XE (X760)	SPCM - Secondary Powertrain Control Module	EXE
HX73-14C037-CKF.vbf	Jaguar XE (X760)	SPCM - Secondary Powertrain Control Module	EXE
HX73-14C037-CKG.vbf	Jaguar XE (X760)	SPCM - Secondary Powertrain Control Module	DATA
HX73-14C037-CKJ.vbf	Jaguar XE (X760)	SPCM - Secondary Powertrain Control Module	DATA
HX73-14C037-CND.vbf	Jaguar XE (X760)	SPCM - Secondary Powertrain Control Module	EXE
HX73-14C037-CNE.vbf	Jaguar XE (X760)	SPCM - Secondary Powertrain Control Module	EXE
HX73-14C037-CNF.vbf	Jaguar XE (X760)	SPCM - Secondary Powertrain Control Module	EXE
HX73-14C037-CNG.vbf	Jaguar XE (X760)	SPCM - Secondary Powertrain Control Module	DATA
HX73-14C037-CNJ.vbf	Jaguar XE (X760)	SPCM - Secondary Powertrain Control Module	DATA
HX73-14C037-CPD.vbf	Jaguar XE (X760)	SPCM - Secondary Powertrain Control Module	EXE
HX73-14C037-CPE.vbf	Jaguar XE (X760)	SPCM - Secondary Powertrain Control Module	EXE
HX73-14C037-CPF.vbf	Jaguar XE (X760)	SPCM - Secondary Powertrain Control Module	EXE
HX73-14C037-CPG.vbf	Jaguar XE (X760)	SPCM - Secondary Powertrain Control Module	DATA
HX73-14C037-CPJ.vbf	Jaguar XE (X760)	SPCM - Secondary Powertrain Control Module	DATA
HX73-14C037-CSD.vbf	Jaguar XE (X760)	SPCM - Secondary Powertrain Control Module	EXE
HX73-14C037-CSE.vbf	Jaguar XE (X760)	SPCM - Secondary Powertrain Control Module	EXE
HX73-14C037-CSF.vbf	Jaguar XE (X760)	SPCM - Secondary Powertrain Control Module	EXE
HX73-14C037-CSG.vbf	Jaguar XE (X760)	SPCM - Secondary Powertrain Control Module	DATA
HX73-14C037-CSJ.vbf	Jaguar XE (X760)	SPCM - Secondary Powertrain Control Module	DATA
HX73-14C037-CXD.vbf	Jaguar XE (X760)	SPCM - Secondary Powertrain Control Module	EXE
HX73-14C037-CXE.vbf	Jaguar XE (X760)	SPCM - Secondary Powertrain Control Module	EXE
HX73-14C037-CXF.vbf	Jaguar XE (X760)	SPCM - Secondary Powertrain Control Module	EXE
HX73-14C037-CXG.vbf	Jaguar XE (X760)	SPCM - Secondary Powertrain Control Module	DATA
HX73-14C037-CXJ.vbf	Jaguar XE (X760)	SPCM - Secondary Powertrain Control Module	DATA
HX73-14C037-CYD.vbf	Jaguar XE (X760)	SPCM - Secondary Powertrain Control Module	EXE
HX73-14C037-CYE.vbf	Jaguar XE (X760)	SPCM - Secondary Powertrain Control Module	EXE
HX73-14C037-CYF.vbf	Jaguar XE (X760)	SPCM - Secondary Powertrain Control Module	EXE
HX73-14C037-CYG.vbf	Jaguar XE (X760)	SPCM - Secondary Powertrain Control Module	DATA
HX73-14C037-CYJ.vbf	Jaguar XE (X760)	SPCM - Secondary Powertrain Control Module	DATA
HX73-14C037-DPD.vbf	Jaguar XE (X760)	SPCM - Secondary Powertrain Control Module	EXE

File name	Vehicle line (indicative)	Module (ECU)	Type
HX73-14C037-DPE.vbf	Jaguar XE (X760)	SPCM - Secondary Powertrain Control Module	EXE
HX73-14C037-DPG.vbf	Jaguar XE (X760)	SPCM - Secondary Powertrain Control Module	EXE
HX73-14C037-DPH.vbf	Jaguar XE (X760)	SPCM - Secondary Powertrain Control Module	DATA
HX73-14C037-DPJ.vbf	Jaguar XE (X760)	SPCM - Secondary Powertrain Control Module	DATA
HX73-14C037-DPL.vbf	Jaguar XE (X760)	SPCM - Secondary Powertrain Control Module	DATA
HX73-14C037-DRD.vbf	Jaguar XE (X760)	SPCM - Secondary Powertrain Control Module	EXE
HX73-14C037-DRE.vbf	Jaguar XE (X760)	SPCM - Secondary Powertrain Control Module	EXE
HX73-14C037-DRG.vbf	Jaguar XE (X760)	SPCM - Secondary Powertrain Control Module	EXE
HX73-14C037-DRH.vbf	Jaguar XE (X760)	SPCM - Secondary Powertrain Control Module	DATA
HX73-14C037-DRJ.vbf	Jaguar XE (X760)	SPCM - Secondary Powertrain Control Module	DATA
HX73-14C037-DRL.vbf	Jaguar XE (X760)	SPCM - Secondary Powertrain Control Module	DATA
HX73-14C037-DSD.vbf	Jaguar XE (X760)	SPCM - Secondary Powertrain Control Module	EXE
HX73-14C037-DSE.vbf	Jaguar XE (X760)	SPCM - Secondary Powertrain Control Module	EXE
HX73-14C037-DSF.vbf	Jaguar XE (X760)	SPCM - Secondary Powertrain Control Module	EXE
HX73-14C037-DSG.vbf	Jaguar XE (X760)	SPCM - Secondary Powertrain Control Module	DATA
HX73-14C037-DSJ.vbf	Jaguar XE (X760)	SPCM - Secondary Powertrain Control Module	DATA
HX73-14C037-DUD.vbf	Jaguar XE (X760)	SPCM - Secondary Powertrain Control Module	EXE
HX73-14C037-DUE.vbf	Jaguar XE (X760)	SPCM - Secondary Powertrain Control Module	EXE
HX73-14C037-DUF.vbf	Jaguar XE (X760)	SPCM - Secondary Powertrain Control Module	EXE
HX73-14C037-DUG.vbf	Jaguar XE (X760)	SPCM - Secondary Powertrain Control Module	DATA
HX73-14C037-DUJ.vbf	Jaguar XE (X760)	SPCM - Secondary Powertrain Control Module	DATA
HX73-14C037-DVD.vbf	Jaguar XE (X760)	SPCM - Secondary Powertrain Control Module	EXE
HX73-14C037-DVE.vbf	Jaguar XE (X760)	SPCM - Secondary Powertrain Control Module	EXE
HX73-14C037-DVG.vbf	Jaguar XE (X760)	SPCM - Secondary Powertrain Control Module	EXE
HX73-14C037-DVH.vbf	Jaguar XE (X760)	SPCM - Secondary Powertrain Control Module	DATA
HX73-14C037-DVJ.vbf	Jaguar XE (X760)	SPCM - Secondary Powertrain Control Module	DATA
HX73-14C037-DVL.vbf	Jaguar XE (X760)	SPCM - Secondary Powertrain Control Module	DATA
HX73-14C037-DXD.vbf	Jaguar XE (X760)	SPCM - Secondary Powertrain Control Module	EXE
HX73-14C037-DXE.vbf	Jaguar XE (X760)	SPCM - Secondary Powertrain Control Module	EXE
HX73-14C037-DXG.vbf	Jaguar XE (X760)	SPCM - Secondary Powertrain Control Module	EXE
HX73-14C037-DXH.vbf	Jaguar XE (X760)	SPCM - Secondary Powertrain Control Module	DATA
HX73-14C037-DXJ.vbf	Jaguar XE (X760)	SPCM - Secondary Powertrain Control Module	DATA
HX73-14C037-DXL.vbf	Jaguar XE (X760)	SPCM - Secondary Powertrain Control Module	DATA
HX73-14C037-EAE.vbf	Jaguar XE (X760)	ABS - Anti-Lock Brake System Control Module	DATA
HX73-14C037-EAF.vbf	Jaguar XE (X760)	ABS - Anti-Lock Brake System Control Module	DATA
HX73-14C037-EAG.vbf	Jaguar XE (X760)	ABS - Anti-Lock Brake System Control Module	DATA
HX73-14C037-EAH.vbf	Jaguar XE (X760)	ABS - Anti-Lock Brake System Control Module	DATA
HX73-14C037-EBE.vbf	Jaguar XE (X760)	ABS - Anti-Lock Brake System Control Module	DATA
HX73-14C037-EBF.vbf	Jaguar XE (X760)	ABS - Anti-Lock Brake System Control Module	DATA
HX73-14C037-EBG.vbf	Jaguar XE (X760)	ABS - Anti-Lock Brake System Control Module	DATA
HX73-14C037-EBH.vbf	Jaguar XE (X760)	ABS - Anti-Lock Brake System Control Module	DATA
HX73-14C037-ECE.vbf	Jaguar XE (X760)	ABS - Anti-Lock Brake System Control Module	DATA
HX73-14C037-ECF.vbf	Jaguar XE (X760)	ABS - Anti-Lock Brake System Control Module	DATA
HX73-14C037-ECG.vbf	Jaguar XE (X760)	ABS - Anti-Lock Brake System Control Module	DATA
HX73-14C037-ECH.vbf	Jaguar XE (X760)	ABS - Anti-Lock Brake System Control Module	DATA
HX73-14C037-EDE.vbf	Jaguar XE (X760)	ABS - Anti-Lock Brake System Control Module	DATA
HX73-14C037-EEE.vbf	Jaguar XE (X760)	ABS - Anti-Lock Brake System Control Module	DATA
HX73-14C037-EHE.vbf	Jaguar XE (X760)	ABS - Anti-Lock Brake System Control Module	DATA
HX73-14C037-EHF.vbf	Jaguar XE (X760)	ABS - Anti-Lock Brake System Control Module	DATA
HX73-14C037-EHG.vbf	Jaguar XE (X760)	ABS - Anti-Lock Brake System Control Module	DATA
HX73-14C037-EHH.vbf	Jaguar XE (X760)	ABS - Anti-Lock Brake System Control Module	DATA
HX73-14C037-EHJ.vbf	Jaguar XE (X760)	ABS - Anti-Lock Brake System Control Module	DATA
HX73-14C037-EHK.vbf	Jaguar XE (X760)	ABS - Anti-Lock Brake System Control Module	DATA
HX73-14C037-EJE.vbf	Jaguar XE (X760)	ABS - Anti-Lock Brake System Control Module	DATA
HX73-14C037-EJG.vbf	Jaguar XE (X760)	ABS - Anti-Lock Brake System Control Module	DATA
HX73-14C037-EJH.vbf	Jaguar XE (X760)	ABS - Anti-Lock Brake System Control Module	DATA
HX73-14C037-EJJ.vbf	Jaguar XE (X760)	ABS - Anti-Lock Brake System Control Module	DATA
HX73-14C037-EJK.vbf	Jaguar XE (X760)	ABS - Anti-Lock Brake System Control Module	DATA
HX73-14C037-EKE.vbf	Jaguar XE (X760)	ABS - Anti-Lock Brake System Control Module	DATA
HX73-14C037-EKF.vbf	Jaguar XE (X760)	ABS - Anti-Lock Brake System Control Module	DATA
HX73-14C037-EKG.vbf	Jaguar XE (X760)	ABS - Anti-Lock Brake System Control Module	DATA
HX73-14C037-EKH.vbf	Jaguar XE (X760)	ABS - Anti-Lock Brake System Control Module	DATA
HX73-14C037-ELE.vbf	Jaguar XE (X760)	ABS - Anti-Lock Brake System Control Module	DATA
HX73-14C037-ELH.vbf	Jaguar XE (X760)	ABS - Anti-Lock Brake System Control Module	DATA
HX73-14C037-EME.vbf	Jaguar XE (X760)	ABS - Anti-Lock Brake System Control Module	DATA
HX73-14C037-EMF.vbf	Jaguar XE (X760)	ABS - Anti-Lock Brake System Control Module	DATA
HX73-14C037-EMG.vbf	Jaguar XE (X760)	ABS - Anti-Lock Brake System Control Module	DATA
HX73-14C037-EMH.vbf	Jaguar XE (X760)	ABS - Anti-Lock Brake System Control Module	DATA
HX73-14C037-ENE.vbf	Jaguar XE (X760)	ABS - Anti-Lock Brake System Control Module	DATA
HX73-14C037-ENF.vbf	Jaguar XE (X760)	ABS - Anti-Lock Brake System Control Module	DATA
HX73-14C037-EPE.vbf	Jaguar XE (X760)	ABS - Anti-Lock Brake System Control Module	DATA
HX73-14C037-EPF.vbf	Jaguar XE (X760)	ABS - Anti-Lock Brake System Control Module	DATA
HX73-14C037-EPG.vbf	Jaguar XE (X760)	ABS - Anti-Lock Brake System Control Module	DATA
HX73-14C037-EPH.vbf	Jaguar XE (X760)	ABS - Anti-Lock Brake System Control Module	DATA
HX73-14C037-ERE.vbf	Jaguar XE (X760)	ABS - Anti-Lock Brake System Control Module	DATA
HX73-14C037-ERF.vbf	Jaguar XE (X760)	ABS - Anti-Lock Brake System Control Module	DATA

File name	Vehicle line (indicative)	Module (ECU)	Type
HX73-14C037-ERG.vbf	Jaguar XE (X760)	ABS - Anti-Lock Brake System Control Module	DATA
HX73-14C037-ERH.vbf	Jaguar XE (X760)	ABS - Anti-Lock Brake System Control Module	DATA
HX73-14C037-ESE.vbf	Jaguar XE (X760)	ABS - Anti-Lock Brake System Control Module	DATA
HX73-14C037-ESG.vbf	Jaguar XE (X760)	ABS - Anti-Lock Brake System Control Module	DATA
HX73-14C037-ESH.vbf	Jaguar XE (X760)	ABS - Anti-Lock Brake System Control Module	DATA
HX73-14C037-ESJ.vbf	Jaguar XE (X760)	ABS - Anti-Lock Brake System Control Module	DATA
HX73-14C037-ESK.vbf	Jaguar XE (X760)	ABS - Anti-Lock Brake System Control Module	DATA
HX73-14C037-ETE.vbf	Jaguar XE (X760)	ABS - Anti-Lock Brake System Control Module	DATA
HX73-14C037-ETG.vbf	Jaguar XE (X760)	ABS - Anti-Lock Brake System Control Module	DATA
HX73-14C037-ETH.vbf	Jaguar XE (X760)	ABS - Anti-Lock Brake System Control Module	DATA
HX73-14C037-ETJ.vbf	Jaguar XE (X760)	ABS - Anti-Lock Brake System Control Module	DATA
HX73-14C037-ETK.vbf	Jaguar XE (X760)	ABS - Anti-Lock Brake System Control Module	DATA
HX73-14C037-FAE.vbf	Jaguar XE (X760)	ABS - Anti-Lock Brake System Control Module	DATA
HX73-14C037-FAF.vbf	Jaguar XE (X760)	ABS - Anti-Lock Brake System Control Module	DATA
HX73-14C037-FAG.vbf	Jaguar XE (X760)	ABS - Anti-Lock Brake System Control Module	DATA
HX73-14C037-FAH.vbf	Jaguar XE (X760)	ABS - Anti-Lock Brake System Control Module	DATA
HX73-14C037-FAJ.vbf	Jaguar XE (X760)	ABS - Anti-Lock Brake System Control Module	DATA
HX73-14C037-FBE.vbf	Jaguar XE (X760)	ABS - Anti-Lock Brake System Control Module	DATA
HX73-14C037-FBF.vbf	Jaguar XE (X760)	ABS - Anti-Lock Brake System Control Module	DATA
HX73-14C037-FBG.vbf	Jaguar XE (X760)	ABS - Anti-Lock Brake System Control Module	DATA
HX73-14C037-FBH.vbf	Jaguar XE (X760)	ABS - Anti-Lock Brake System Control Module	DATA
HX73-14C037-FBJ.vbf	Jaguar XE (X760)	ABS - Anti-Lock Brake System Control Module	DATA
HX73-14C037-FEE.vbf	Jaguar XE (X760)	ABS - Anti-Lock Brake System Control Module	DATA
HX73-14C037-FEF.vbf	Jaguar XE (X760)	ABS - Anti-Lock Brake System Control Module	DATA
HX73-14C037-FEG.vbf	Jaguar XE (X760)	ABS - Anti-Lock Brake System Control Module	DATA
HX73-14C037-FEH.vbf	Jaguar XE (X760)	ABS - Anti-Lock Brake System Control Module	DATA
HX73-14C037-FFE.vbf	Jaguar XE (X760)	ABS - Anti-Lock Brake System Control Module	DATA
HX73-14C037-FFF.vbf	Jaguar XE (X760)	ABS - Anti-Lock Brake System Control Module	DATA
HX73-14C037-FFG.vbf	Jaguar XE (X760)	ABS - Anti-Lock Brake System Control Module	DATA
HX73-14C037-FFH.vbf	Jaguar XE (X760)	ABS - Anti-Lock Brake System Control Module	DATA
HX73-14C037-FGE.vbf	Jaguar XE (X760)	ABS - Anti-Lock Brake System Control Module	DATA
HX73-14C037-FGF.vbf	Jaguar XE (X760)	ABS - Anti-Lock Brake System Control Module	DATA
HX73-14C037-FGH.vbf	Jaguar XE (X760)	ABS - Anti-Lock Brake System Control Module	DATA
HX73-14C037-FJE.vbf	Jaguar XE (X760)	ABS - Anti-Lock Brake System Control Module	DATA
HX73-14C037-FJF.vbf	Jaguar XE (X760)	ABS - Anti-Lock Brake System Control Module	DATA
HX73-14C037-FJG.vbf	Jaguar XE (X760)	ABS - Anti-Lock Brake System Control Module	DATA
HX73-14C037-FJH.vbf	Jaguar XE (X760)	ABS - Anti-Lock Brake System Control Module	DATA
HX73-14C037-FKE.vbf	Jaguar XE (X760)	ABS - Anti-Lock Brake System Control Module	DATA
HX73-14C037-FKF.vbf	Jaguar XE (X760)	ABS - Anti-Lock Brake System Control Module	DATA
HX73-14C037-FKG.vbf	Jaguar XE (X760)	ABS - Anti-Lock Brake System Control Module	DATA
HX73-14C037-FKH.vbf	Jaguar XE (X760)	ABS - Anti-Lock Brake System Control Module	DATA
HX73-14C037-FLE.vbf	Jaguar XE (X760)	ABS - Anti-Lock Brake System Control Module	DATA
HX73-14C037-FLF.vbf	Jaguar XE (X760)	ABS - Anti-Lock Brake System Control Module	DATA
HX73-14C037-FLG.vbf	Jaguar XE (X760)	ABS - Anti-Lock Brake System Control Module	DATA
HX73-14C037-FLH.vbf	Jaguar XE (X760)	ABS - Anti-Lock Brake System Control Module	DATA
HX73-14C037-FNE.vbf	Jaguar XE (X760)	ABS - Anti-Lock Brake System Control Module	DATA
HX73-14C037-FNF.vbf	Jaguar XE (X760)	ABS - Anti-Lock Brake System Control Module	DATA
HX73-14C037-FNG.vbf	Jaguar XE (X760)	ABS - Anti-Lock Brake System Control Module	DATA
HX73-14C037-FNH.vbf	Jaguar XE (X760)	ABS - Anti-Lock Brake System Control Module	DATA
HX73-14C037-FPE.vbf	Jaguar XE (X760)	ABS - Anti-Lock Brake System Control Module	DATA
HX73-14C037-FPF.vbf	Jaguar XE (X760)	ABS - Anti-Lock Brake System Control Module	DATA
HX73-14C037-FPG.vbf	Jaguar XE (X760)	ABS - Anti-Lock Brake System Control Module	DATA
HX73-14C037-FPH.vbf	Jaguar XE (X760)	ABS - Anti-Lock Brake System Control Module	DATA
HX73-14C037-FRE.vbf	Jaguar XE (X760)	ABS - Anti-Lock Brake System Control Module	DATA
HX73-14C037-FRF.vbf	Jaguar XE (X760)	ABS - Anti-Lock Brake System Control Module	DATA
HX73-14C037-FRG.vbf	Jaguar XE (X760)	ABS - Anti-Lock Brake System Control Module	DATA
HX73-14C037-FRH.vbf	Jaguar XE (X760)	ABS - Anti-Lock Brake System Control Module	DATA
HX73-14C037-FSE.vbf	Jaguar XE (X760)	ABS - Anti-Lock Brake System Control Module	DATA
HX73-14C037-FSF.vbf	Jaguar XE (X760)	ABS - Anti-Lock Brake System Control Module	DATA
HX73-14C037-FSG.vbf	Jaguar XE (X760)	ABS - Anti-Lock Brake System Control Module	DATA
HX73-14C037-FSH.vbf	Jaguar XE (X760)	ABS - Anti-Lock Brake System Control Module	DATA
HX73-14C037-FTE.vbf	Jaguar XE (X760)	ABS - Anti-Lock Brake System Control Module	DATA
HX73-14C037-FTF.vbf	Jaguar XE (X760)	ABS - Anti-Lock Brake System Control Module	DATA
HX73-14C037-FTG.vbf	Jaguar XE (X760)	ABS - Anti-Lock Brake System Control Module	DATA
HX73-14C037-FTH.vbf	Jaguar XE (X760)	ABS - Anti-Lock Brake System Control Module	DATA
HX73-14C037-FUE.vbf	Jaguar XE (X760)	ABS - Anti-Lock Brake System Control Module	DATA
HX73-14C037-FUF.vbf	Jaguar XE (X760)	ABS - Anti-Lock Brake System Control Module	DATA
HX73-14C037-FUG.vbf	Jaguar XE (X760)	ABS - Anti-Lock Brake System Control Module	DATA
HX73-14C037-FUH.vbf	Jaguar XE (X760)	ABS - Anti-Lock Brake System Control Module	DATA
HX73-14C037-FVE.vbf	Jaguar XE (X760)	ABS - Anti-Lock Brake System Control Module	DATA
HX73-14C037-FVF.vbf	Jaguar XE (X760)	ABS - Anti-Lock Brake System Control Module	DATA
HX73-14C037-FVG.vbf	Jaguar XE (X760)	ABS - Anti-Lock Brake System Control Module	DATA
HX73-14C037-FVH.vbf	Jaguar XE (X760)	ABS - Anti-Lock Brake System Control Module	DATA
HX73-14C037-FXE.vbf	Jaguar XE (X760)	ABS - Anti-Lock Brake System Control Module	DATA
HX73-14C037-FXG.vbf	Jaguar XE (X760)	ABS - Anti-Lock Brake System Control Module	DATA
HX73-14C037-FXH.vbf	Jaguar XE (X760)	ABS - Anti-Lock Brake System Control Module	DATA

File name	Vehicle line (indicative)	Module (ECU)	Type
HX73-14C037-FXJ.vbf	Jaguar XE (X760)	ABS - Anti-Lock Brake System Control Module	DATA
HX73-14C037-FYE.vbf	Jaguar XE (X760)	ABS - Anti-Lock Brake System Control Module	DATA
HX73-14C037-FYF.vbf	Jaguar XE (X760)	ABS - Anti-Lock Brake System Control Module	DATA
HX73-14C037-FYG.vbf	Jaguar XE (X760)	ABS - Anti-Lock Brake System Control Module	DATA
HX73-14C037-FYH.vbf	Jaguar XE (X760)	ABS - Anti-Lock Brake System Control Module	DATA
HX73-14C037-FYJ.vbf	Jaguar XE (X760)	ABS - Anti-Lock Brake System Control Module	DATA
HX73-14C037-FZE.vbf	Jaguar XE (X760)	ABS - Anti-Lock Brake System Control Module	DATA
HX73-14C037-FZF.vbf	Jaguar XE (X760)	ABS - Anti-Lock Brake System Control Module	DATA
HX73-14C037-FZG.vbf	Jaguar XE (X760)	ABS - Anti-Lock Brake System Control Module	DATA
HX73-14C037-FZH.vbf	Jaguar XE (X760)	ABS - Anti-Lock Brake System Control Module	DATA
HX73-14C037-MJD.vbf	Jaguar XE (X760)	SPCM - Secondary Powertrain Control Module	EXE
HX73-14C037-MJE.vbf	Jaguar XE (X760)	SPCM - Secondary Powertrain Control Module	EXE
HX73-14C037-MJF.vbf	Jaguar XE (X760)	SPCM - Secondary Powertrain Control Module	EXE
HX73-14C037-MJG.vbf	Jaguar XE (X760)	SPCM - Secondary Powertrain Control Module	DATA
HX73-14C037-MJJ.vbf	Jaguar XE (X760)	SPCM - Secondary Powertrain Control Module	DATA
HX73-14C037-MLD.vbf	Jaguar XE (X760)	SPCM - Secondary Powertrain Control Module	EXE
HX73-14C037-MLE.vbf	Jaguar XE (X760)	SPCM - Secondary Powertrain Control Module	EXE
HX73-14C037-MLF.vbf	Jaguar XE (X760)	SPCM - Secondary Powertrain Control Module	EXE
HX73-14C037-MLG.vbf	Jaguar XE (X760)	SPCM - Secondary Powertrain Control Module	DATA
HX73-14C037-MLJ.vbf	Jaguar XE (X760)	SPCM - Secondary Powertrain Control Module	DATA
HX73-14C037-MND.vbf	Jaguar XE (X760)	SPCM - Secondary Powertrain Control Module	EXE
HX73-14C037-MNE.vbf	Jaguar XE (X760)	SPCM - Secondary Powertrain Control Module	EXE
HX73-14C037-MNF.vbf	Jaguar XE (X760)	SPCM - Secondary Powertrain Control Module	EXE
HX73-14C037-MNG.vbf	Jaguar XE (X760)	SPCM - Secondary Powertrain Control Module	DATA
HX73-14C037-MNJ.vbf	Jaguar XE (X760)	SPCM - Secondary Powertrain Control Module	DATA
HX73-14C037-MTD.vbf	Jaguar XE (X760)	SPCM - Secondary Powertrain Control Module	EXE
HX73-14C037-MTE.vbf	Jaguar XE (X760)	SPCM - Secondary Powertrain Control Module	EXE
HX73-14C037-MTF.vbf	Jaguar XE (X760)	SPCM - Secondary Powertrain Control Module	EXE
HX73-14C037-MTG.vbf	Jaguar XE (X760)	SPCM - Secondary Powertrain Control Module	DATA
HX73-14C037-MTJ.vbf	Jaguar XE (X760)	SPCM - Secondary Powertrain Control Module	DATA
HX73-14C037-NLD.vbf	Jaguar XE (X760)	SPCM - Secondary Powertrain Control Module	EXE
HX73-14C037-NLE.vbf	Jaguar XE (X760)	SPCM - Secondary Powertrain Control Module	EXE
HX73-14C037-NLF.vbf	Jaguar XE (X760)	SPCM - Secondary Powertrain Control Module	EXE
HX73-14C037-NLG.vbf	Jaguar XE (X760)	SPCM - Secondary Powertrain Control Module	DATA
HX73-14C037-NLJ.vbf	Jaguar XE (X760)	SPCM - Secondary Powertrain Control Module	DATA
HX73-14C037-NND.vbf	Jaguar XE (X760)	SPCM - Secondary Powertrain Control Module	EXE
HX73-14C037-NNE.vbf	Jaguar XE (X760)	SPCM - Secondary Powertrain Control Module	EXE
HX73-14C037-NNF.vbf	Jaguar XE (X760)	SPCM - Secondary Powertrain Control Module	EXE
HX73-14C037-NNG.vbf	Jaguar XE (X760)	SPCM - Secondary Powertrain Control Module	DATA
HX73-14C037-NNJ.vbf	Jaguar XE (X760)	SPCM - Secondary Powertrain Control Module	DATA
HX73-14C037-NYD.vbf	Jaguar XE (X760)	SPCM - Secondary Powertrain Control Module	EXE
HX73-14C037-NYE.vbf	Jaguar XE (X760)	SPCM - Secondary Powertrain Control Module	EXE
HX73-14C037-NYF.vbf	Jaguar XE (X760)	SPCM - Secondary Powertrain Control Module	EXE
HX73-14C037-NYG.vbf	Jaguar XE (X760)	SPCM - Secondary Powertrain Control Module	DATA
HX73-14C037-NYJ.vbf	Jaguar XE (X760)	SPCM - Secondary Powertrain Control Module	DATA
HX73-14C037-PBD.vbf	Jaguar XE (X760)	SPCM - Secondary Powertrain Control Module	EXE
HX73-14C037-PBE.vbf	Jaguar XE (X760)	SPCM - Secondary Powertrain Control Module	EXE
HX73-14C037-PBF.vbf	Jaguar XE (X760)	SPCM - Secondary Powertrain Control Module	EXE
HX73-14C037-PBG.vbf	Jaguar XE (X760)	SPCM - Secondary Powertrain Control Module	DATA
HX73-14C037-PBJ.vbf	Jaguar XE (X760)	SPCM - Secondary Powertrain Control Module	DATA
HX73-14C037-PPD.vbf	Jaguar XE (X760)	SPCM - Secondary Powertrain Control Module	EXE
HX73-14C037-PPE.vbf	Jaguar XE (X760)	SPCM - Secondary Powertrain Control Module	EXE
HX73-14C037-PPF.vbf	Jaguar XE (X760)	SPCM - Secondary Powertrain Control Module	EXE
HX73-14C037-PPG.vbf	Jaguar XE (X760)	SPCM - Secondary Powertrain Control Module	DATA
HX73-14C037-PPJ.vbf	Jaguar XE (X760)	SPCM - Secondary Powertrain Control Module	DATA
HX73-14C037-PSD.vbf	Jaguar XE (X760)	SPCM - Secondary Powertrain Control Module	EXE
HX73-14C037-PSE.vbf	Jaguar XE (X760)	SPCM - Secondary Powertrain Control Module	EXE
HX73-14C037-PSF.vbf	Jaguar XE (X760)	SPCM - Secondary Powertrain Control Module	EXE
HX73-14C037-PSG.vbf	Jaguar XE (X760)	SPCM - Secondary Powertrain Control Module	DATA
HX73-14C037-PSJ.vbf	Jaguar XE (X760)	SPCM - Secondary Powertrain Control Module	DATA
HX73-14C037-RPD.vbf	Jaguar XE (X760)	SPCM - Secondary Powertrain Control Module	EXE
HX73-14C037-RPE.vbf	Jaguar XE (X760)	SPCM - Secondary Powertrain Control Module	EXE
HX73-14C037-RPG.vbf	Jaguar XE (X760)	SPCM - Secondary Powertrain Control Module	EXE
HX73-14C037-RPH.vbf	Jaguar XE (X760)	SPCM - Secondary Powertrain Control Module	DATA
HX73-14C037-RPJ.vbf	Jaguar XE (X760)	SPCM - Secondary Powertrain Control Module	DATA
HX73-14C037-RPL.vbf	Jaguar XE (X760)	SPCM - Secondary Powertrain Control Module	DATA
HX73-14C037-RRD.vbf	Jaguar XE (X760)	SPCM - Secondary Powertrain Control Module	EXE
HX73-14C037-RRE.vbf	Jaguar XE (X760)	SPCM - Secondary Powertrain Control Module	EXE
HX73-14C037-RRG.vbf	Jaguar XE (X760)	SPCM - Secondary Powertrain Control Module	EXE
HX73-14C037-RRH.vbf	Jaguar XE (X760)	SPCM - Secondary Powertrain Control Module	DATA
HX73-14C037-RRJ.vbf	Jaguar XE (X760)	SPCM - Secondary Powertrain Control Module	DATA
HX73-14C037-RRL.vbf	Jaguar XE (X760)	SPCM - Secondary Powertrain Control Module	DATA
HX73-14C037-RSD.vbf	Jaguar XE (X760)	SPCM - Secondary Powertrain Control Module	EXE
HX73-14C037-RSE.vbf	Jaguar XE (X760)	SPCM - Secondary Powertrain Control Module	EXE
HX73-14C037-RSF.vbf	Jaguar XE (X760)	SPCM - Secondary Powertrain Control Module	EXE
HX73-14C037-RSG.vbf	Jaguar XE (X760)	SPCM - Secondary Powertrain Control Module	DATA

File name	Vehicle line (indicative)	Module (ECU)	Type
HX73-14C037-RSJ.vbf	Jaguar XE (X760)	SPCM - Secondary Powertrain Control Module	DATA
HX73-14C037-RUD.vbf	Jaguar XE (X760)	SPCM - Secondary Powertrain Control Module	EXE
HX73-14C037-RUE.vbf	Jaguar XE (X760)	SPCM - Secondary Powertrain Control Module	EXE
HX73-14C037-RUF.vbf	Jaguar XE (X760)	SPCM - Secondary Powertrain Control Module	EXE
HX73-14C037-RUG.vbf	Jaguar XE (X760)	SPCM - Secondary Powertrain Control Module	DATA
HX73-14C037-RUJ.vbf	Jaguar XE (X760)	SPCM - Secondary Powertrain Control Module	DATA
HX73-14C037-RVD.vbf	Jaguar XE (X760)	SPCM - Secondary Powertrain Control Module	EXE
HX73-14C037-RVE.vbf	Jaguar XE (X760)	SPCM - Secondary Powertrain Control Module	EXE
HX73-14C037-RVG.vbf	Jaguar XE (X760)	SPCM - Secondary Powertrain Control Module	EXE
HX73-14C037-RVH.vbf	Jaguar XE (X760)	SPCM - Secondary Powertrain Control Module	DATA
HX73-14C037-RVJ.vbf	Jaguar XE (X760)	SPCM - Secondary Powertrain Control Module	DATA
HX73-14C037-RVL.vbf	Jaguar XE (X760)	SPCM - Secondary Powertrain Control Module	DATA
HX73-14C037-RXD.vbf	Jaguar XE (X760)	SPCM - Secondary Powertrain Control Module	EXE
HX73-14C037-RXE.vbf	Jaguar XE (X760)	SPCM - Secondary Powertrain Control Module	EXE
HX73-14C037-RXG.vbf	Jaguar XE (X760)	SPCM - Secondary Powertrain Control Module	EXE
HX73-14C037-RXH.vbf	Jaguar XE (X760)	SPCM - Secondary Powertrain Control Module	DATA
HX73-14C037-RXJ.vbf	Jaguar XE (X760)	SPCM - Secondary Powertrain Control Module	DATA
HX73-14C037-RXL.vbf	Jaguar XE (X760)	SPCM - Secondary Powertrain Control Module	DATA
HX73-14C037-SAE.vbf	Jaguar XE (X760)	ABS - Anti-Lock Brake System Control Module	DATA
HX73-14C037-SAF.vbf	Jaguar XE (X760)	ABS - Anti-Lock Brake System Control Module	DATA
HX73-14C037-SAG.vbf	Jaguar XE (X760)	ABS - Anti-Lock Brake System Control Module	DATA
HX73-14C037-SAH.vbf	Jaguar XE (X760)	ABS - Anti-Lock Brake System Control Module	DATA
HX73-14C037-SBE.vbf	Jaguar XE (X760)	ABS - Anti-Lock Brake System Control Module	DATA
HX73-14C037-SBF.vbf	Jaguar XE (X760)	ABS - Anti-Lock Brake System Control Module	DATA
HX73-14C037-SBG.vbf	Jaguar XE (X760)	ABS - Anti-Lock Brake System Control Module	DATA
HX73-14C037-SBH.vbf	Jaguar XE (X760)	ABS - Anti-Lock Brake System Control Module	DATA
HX73-14C037-SCE.vbf	Jaguar XE (X760)	ABS - Anti-Lock Brake System Control Module	DATA
HX73-14C037-SCF.vbf	Jaguar XE (X760)	ABS - Anti-Lock Brake System Control Module	DATA
HX73-14C037-SCG.vbf	Jaguar XE (X760)	ABS - Anti-Lock Brake System Control Module	DATA
HX73-14C037-SCH.vbf	Jaguar XE (X760)	ABS - Anti-Lock Brake System Control Module	DATA
HX73-14C037-SHE.vbf	Jaguar XE (X760)	ABS - Anti-Lock Brake System Control Module	DATA
HX73-14C037-SHG.vbf	Jaguar XE (X760)	ABS - Anti-Lock Brake System Control Module	DATA
HX73-14C037-SHH.vbf	Jaguar XE (X760)	ABS - Anti-Lock Brake System Control Module	DATA
HX73-14C037-SHJ.vbf	Jaguar XE (X760)	ABS - Anti-Lock Brake System Control Module	DATA
HX73-14C037-SHK.vbf	Jaguar XE (X760)	ABS - Anti-Lock Brake System Control Module	DATA
HX73-14C037-SJE.vbf	Jaguar XE (X760)	ABS - Anti-Lock Brake System Control Module	DATA
HX73-14C037-SJG.vbf	Jaguar XE (X760)	ABS - Anti-Lock Brake System Control Module	DATA
HX73-14C037-SJH.vbf	Jaguar XE (X760)	ABS - Anti-Lock Brake System Control Module	DATA
HX73-14C037-SJJ.vbf	Jaguar XE (X760)	ABS - Anti-Lock Brake System Control Module	DATA
HX73-14C037-SJK.vbf	Jaguar XE (X760)	ABS - Anti-Lock Brake System Control Module	DATA
HX73-14C037-SKE.vbf	Jaguar XE (X760)	ABS - Anti-Lock Brake System Control Module	DATA
HX73-14C037-SKF.vbf	Jaguar XE (X760)	ABS - Anti-Lock Brake System Control Module	DATA
HX73-14C037-SKG.vbf	Jaguar XE (X760)	ABS - Anti-Lock Brake System Control Module	DATA
HX73-14C037-SKH.vbf	Jaguar XE (X760)	ABS - Anti-Lock Brake System Control Module	DATA
HX73-14C037-SME.vbf	Jaguar XE (X760)	ABS - Anti-Lock Brake System Control Module	DATA
HX73-14C037-SMF.vbf	Jaguar XE (X760)	ABS - Anti-Lock Brake System Control Module	DATA
HX73-14C037-SMG.vbf	Jaguar XE (X760)	ABS - Anti-Lock Brake System Control Module	DATA
HX73-14C037-SMH.vbf	Jaguar XE (X760)	ABS - Anti-Lock Brake System Control Module	DATA
HX73-14C037-SPE.vbf	Jaguar XE (X760)	ABS - Anti-Lock Brake System Control Module	DATA
HX73-14C037-SPF.vbf	Jaguar XE (X760)	ABS - Anti-Lock Brake System Control Module	DATA
HX73-14C037-SPG.vbf	Jaguar XE (X760)	ABS - Anti-Lock Brake System Control Module	DATA
HX73-14C037-SPH.vbf	Jaguar XE (X760)	ABS - Anti-Lock Brake System Control Module	DATA
HX73-14C037-SRE.vbf	Jaguar XE (X760)	ABS - Anti-Lock Brake System Control Module	DATA
HX73-14C037-SRF.vbf	Jaguar XE (X760)	ABS - Anti-Lock Brake System Control Module	DATA
HX73-14C037-SRG.vbf	Jaguar XE (X760)	ABS - Anti-Lock Brake System Control Module	DATA
HX73-14C037-SRH.vbf	Jaguar XE (X760)	ABS - Anti-Lock Brake System Control Module	DATA
HX73-14C037-SSE.vbf	Jaguar XE (X760)	ABS - Anti-Lock Brake System Control Module	DATA
HX73-14C037-SSG.vbf	Jaguar XE (X760)	ABS - Anti-Lock Brake System Control Module	DATA
HX73-14C037-SSH.vbf	Jaguar XE (X760)	ABS - Anti-Lock Brake System Control Module	DATA
HX73-14C037-SSJ.vbf	Jaguar XE (X760)	ABS - Anti-Lock Brake System Control Module	DATA
HX73-14C037-SSK.vbf	Jaguar XE (X760)	ABS - Anti-Lock Brake System Control Module	DATA
HX73-14C037-STE.vbf	Jaguar XE (X760)	ABS - Anti-Lock Brake System Control Module	DATA
HX73-14C037-STG.vbf	Jaguar XE (X760)	ABS - Anti-Lock Brake System Control Module	DATA
HX73-14C037-STH.vbf	Jaguar XE (X760)	ABS - Anti-Lock Brake System Control Module	DATA
HX73-14C037-STJ.vbf	Jaguar XE (X760)	ABS - Anti-Lock Brake System Control Module	DATA
HX73-14C037-STK.vbf	Jaguar XE (X760)	ABS - Anti-Lock Brake System Control Module	DATA
HX73-14C037-TAE.vbf	Jaguar XE (X760)	ABS - Anti-Lock Brake System Control Module	DATA
HX73-14C037-TAG.vbf	Jaguar XE (X760)	ABS - Anti-Lock Brake System Control Module	DATA
HX73-14C037-TAH.vbf	Jaguar XE (X760)	ABS - Anti-Lock Brake System Control Module	DATA
HX73-14C037-TAJ.vbf	Jaguar XE (X760)	ABS - Anti-Lock Brake System Control Module	DATA
HX73-14C037-TBE.vbf	Jaguar XE (X760)	ABS - Anti-Lock Brake System Control Module	DATA
HX73-14C037-TBF.vbf	Jaguar XE (X760)	ABS - Anti-Lock Brake System Control Module	DATA
HX73-14C037-TBG.vbf	Jaguar XE (X760)	ABS - Anti-Lock Brake System Control Module	DATA
HX73-14C037-TBH.vbf	Jaguar XE (X760)	ABS - Anti-Lock Brake System Control Module	DATA
HX73-14C037-TBJ.vbf	Jaguar XE (X760)	ABS - Anti-Lock Brake System Control Module	DATA
HX73-14C037-TEE.vbf	Jaguar XE (X760)	ABS - Anti-Lock Brake System Control Module	DATA

File name	Vehicle line (indicative)	Module (ECU)	Type
HX73-14C037-TEF.vbf	Jaguar XE (X760)	ABS - Anti-Lock Brake System Control Module	DATA
HX73-14C037-TEG.vbf	Jaguar XE (X760)	ABS - Anti-Lock Brake System Control Module	DATA
HX73-14C037-TEH.vbf	Jaguar XE (X760)	ABS - Anti-Lock Brake System Control Module	DATA
HX73-14C037-TFE.vbf	Jaguar XE (X760)	ABS - Anti-Lock Brake System Control Module	DATA
HX73-14C037-TFF.vbf	Jaguar XE (X760)	ABS - Anti-Lock Brake System Control Module	DATA
HX73-14C037-TFG.vbf	Jaguar XE (X760)	ABS - Anti-Lock Brake System Control Module	DATA
HX73-14C037-TFH.vbf	Jaguar XE (X760)	ABS - Anti-Lock Brake System Control Module	DATA
HX73-14C037-TGE.vbf	Jaguar XE (X760)	ABS - Anti-Lock Brake System Control Module	DATA
HX73-14C037-TGF.vbf	Jaguar XE (X760)	ABS - Anti-Lock Brake System Control Module	DATA
HX73-14C037-TGH.vbf	Jaguar XE (X760)	ABS - Anti-Lock Brake System Control Module	DATA
HX73-14C037-TNE.vbf	Jaguar XE (X760)	ABS - Anti-Lock Brake System Control Module	DATA
HX73-14C037-TNF.vbf	Jaguar XE (X760)	ABS - Anti-Lock Brake System Control Module	DATA
HX73-14C037-TNG.vbf	Jaguar XE (X760)	ABS - Anti-Lock Brake System Control Module	DATA
HX73-14C037-TNH.vbf	Jaguar XE (X760)	ABS - Anti-Lock Brake System Control Module	DATA
HX73-14C037-TSE.vbf	Jaguar XE (X760)	ABS - Anti-Lock Brake System Control Module	DATA
HX73-14C037-TSF.vbf	Jaguar XE (X760)	ABS - Anti-Lock Brake System Control Module	DATA
HX73-14C037-TSG.vbf	Jaguar XE (X760)	ABS - Anti-Lock Brake System Control Module	DATA
HX73-14C037-TSH.vbf	Jaguar XE (X760)	ABS - Anti-Lock Brake System Control Module	DATA
HX73-14C037-TTE.vbf	Jaguar XE (X760)	ABS - Anti-Lock Brake System Control Module	DATA
HX73-14C037-TTF.vbf	Jaguar XE (X760)	ABS - Anti-Lock Brake System Control Module	DATA
HX73-14C037-TTG.vbf	Jaguar XE (X760)	ABS - Anti-Lock Brake System Control Module	DATA
HX73-14C037-TTH.vbf	Jaguar XE (X760)	ABS - Anti-Lock Brake System Control Module	DATA
HX73-14C037-TUE.vbf	Jaguar XE (X760)	ABS - Anti-Lock Brake System Control Module	DATA
HX73-14C037-TUF.vbf	Jaguar XE (X760)	ABS - Anti-Lock Brake System Control Module	DATA
HX73-14C037-TUG.vbf	Jaguar XE (X760)	ABS - Anti-Lock Brake System Control Module	DATA
HX73-14C037-TUH.vbf	Jaguar XE (X760)	ABS - Anti-Lock Brake System Control Module	DATA
HX73-14C037-TVE.vbf	Jaguar XE (X760)	ABS - Anti-Lock Brake System Control Module	DATA
HX73-14C037-TVF.vbf	Jaguar XE (X760)	ABS - Anti-Lock Brake System Control Module	DATA
HX73-14C037-TVG.vbf	Jaguar XE (X760)	ABS - Anti-Lock Brake System Control Module	DATA
HX73-14C037-TVH.vbf	Jaguar XE (X760)	ABS - Anti-Lock Brake System Control Module	DATA
HX73-14C037-TXE.vbf	Jaguar XE (X760)	ABS - Anti-Lock Brake System Control Module	DATA
HX73-14C037-TXG.vbf	Jaguar XE (X760)	ABS - Anti-Lock Brake System Control Module	DATA
HX73-14C037-TXH.vbf	Jaguar XE (X760)	ABS - Anti-Lock Brake System Control Module	DATA
HX73-14C037-TXJ.vbf	Jaguar XE (X760)	ABS - Anti-Lock Brake System Control Module	DATA
HX73-14C037-TYE.vbf	Jaguar XE (X760)	ABS - Anti-Lock Brake System Control Module	DATA
HX73-14C037-TYF.vbf	Jaguar XE (X760)	ABS - Anti-Lock Brake System Control Module	DATA
HX73-14C037-TYG.vbf	Jaguar XE (X760)	ABS - Anti-Lock Brake System Control Module	DATA
HX73-14C037-TYH.vbf	Jaguar XE (X760)	ABS - Anti-Lock Brake System Control Module	DATA
HX73-14C037-TYJ.vbf	Jaguar XE (X760)	ABS - Anti-Lock Brake System Control Module	DATA
HX73-14C037-TZE.vbf	Jaguar XE (X760)	ABS - Anti-Lock Brake System Control Module	DATA
HX73-14C037-TZF.vbf	Jaguar XE (X760)	ABS - Anti-Lock Brake System Control Module	DATA
HX73-14C037-TZG.vbf	Jaguar XE (X760)	ABS - Anti-Lock Brake System Control Module	DATA
HX73-14C037-TZH.vbf	Jaguar XE (X760)	ABS - Anti-Lock Brake System Control Module	DATA
HX73-14C039-AA.vbf	Jaguar XE (X760)	Not specified	SBL
HX73-14C065-AC.vbf	Jaguar XE (X760)	DDM - Driver Front Door Module	DATA
HX73-14C065-AD.vbf	Jaguar XE (X760)	DDM - Driver Front Door Module	DATA
HX73-14C065-AE.vbf	Jaguar XE (X760)	DDM - Driver Front Door Module	DATA
HX73-14C069-AC.vbf	Jaguar XE (X760)	DRDM - Driver Rear Door Module	DATA
HX73-14C069-AD.vbf	Jaguar XE (X760)	DRDM - Driver Rear Door Module	DATA
HX73-14C069-AE.vbf	Jaguar XE (X760)	DRDM - Driver Rear Door Module	DATA
HX73-14C088-BD.vbf	Jaguar XE (X760)	IPC - Instrument Panel Cluster (IPC) Control Module	DATA
HX73-14C088-CA.vbf	Jaguar XE (X760)	IPC - Instrument Panel Cluster (IPC) Control Module	EXE
HX73-14C088-CB.vbf	Jaguar XE (X760)	IPC - Instrument Panel Cluster (IPC) Control Module	EXE
HX73-14C088-CC.vbf	Jaguar XE (X760)	IPC - Instrument Panel Cluster (IPC) Control Module	EXE
HX73-14C088-CD.vbf	Jaguar XE (X760)	IPC - Instrument Panel Cluster (IPC) Control Module	EXE
HX73-14C088-CE.vbf	Jaguar XE (X760)	IPC - Instrument Panel Cluster (IPC) Control Module	EXE
HX73-14C088-DA.vbf	Jaguar XE (X760)	IPC - Instrument Panel Cluster (IPC) Control Module	DATA
HX73-14C088-JA.vbf	Jaguar XE (X760)	IPC - Instrument Panel Cluster (IPC) Control Module	DATA
HX73-14C088-JB.vbf	Jaguar XE (X760)	IPC - Instrument Panel Cluster (IPC) Control Module	DATA
HX73-14C088-JC.vbf	Jaguar XE (X760)	IPC - Instrument Panel Cluster (IPC) Control Module	DATA
HX73-14C088-JD.vbf	Jaguar XE (X760)	IPC - Instrument Panel Cluster (IPC) Control Module	DATA
HX73-14C088-JE.vbf	Jaguar XE (X760)	IPC - Instrument Panel Cluster (IPC) Control Module	DATA
HX73-14C088-JF.vbf	Jaguar XE (X760)	IPC - Instrument Panel Cluster (IPC) Control Module	DATA
HX73-14C091-AB.vbf	Jaguar XE (X760)	PAM - Parking Assist Control Module	DATA
HX73-14C091-AD.vbf	Jaguar XE (X760)	PAM - Parking Assist Control Module	DATA
HX73-14C091-AE.vbf	Jaguar XE (X760)	PAM - Parking Assist Control Module	DATA
HX73-14C091-AG.vbf	Jaguar XE (X760)	PAM - Parking Assist Control Module	DATA
HX73-14C098-BB.vbf	Jaguar XE (X760)	RCM - Restraints Control Module	DATA
HX73-14C098-BD.VBF	Jaguar XE (X760)	RCM - Restraints Control Module	DATA
HX73-14C098-CB.vbf	Jaguar XE (X760)	RCM - Restraints Control Module	DATA
HX73-14C098-CC.vbf	Jaguar XE (X760)	RCM - Restraints Control Module	DATA
HX73-14C109-AC.vbf	Jaguar XE (X760)	PDM - Passenger Front Door Module	DATA
HX73-14C109-AD.vbf	Jaguar XE (X760)	PDM - Passenger Front Door Module	DATA
HX73-14C109-AE.vbf	Jaguar XE (X760)	PDM - Passenger Front Door Module	DATA
HX73-14C113-AC.vbf	Jaguar XE (X760)	PRDM - Passenger Rear Door Module	DATA
HX73-14C113-AD.vbf	Jaguar XE (X760)	PRDM - Passenger Rear Door Module	DATA

File name	Vehicle line (indicative)	Module (ECU)	Type
HX73-14C113-AE.vbf	Jaguar XE (X760)	PRDM - Passenger Rear Door Module	DATA
HX73-14C121-AB.vbf	Jaguar XE (X760)	RGTM - Rear Gate / Trunk Module	EXE
HX73-14C122-AB.vbf	Jaguar XE (X760)	RGTM - Rear Gate / Trunk Module	DATA
HX73-14C124-AA.vbf	Jaguar XE (X760)	RGTM - Rear Gate / Trunk Module	SBL
HX73-14C152-AA.vbf	Jaguar XE (X760)	TPM - Tire Pressure Monitor Module	DATA
HX73-14C152-AB.vbf	Jaguar XE (X760)	TPM - Tire Pressure Monitor Module	DATA
HX73-14C152-BA.vbf	Jaguar XE (X760)	TPM - Tire Pressure Monitor Module	DATA
HX73-14C152-BB.vbf	Jaguar XE (X760)	TPM - Tire Pressure Monitor Module	DATA
HX73-14C152-BC.vbf	Jaguar XE (X760)	TPM - Tire Pressure Monitor Module	DATA
HX73-14C152-BE.vbf	Jaguar XE (X760)	TPM - Tire Pressure Monitor Module	DATA
HX73-14C185-AA.vbf	Jaguar XE (X760)	BCM - Body Control Module	DATA
HX73-14C185-AB.vbf	Jaguar XE (X760)	BCM - Body Control Module	DATA
HX73-14C185-AC.vbf	Jaguar XE (X760)	BCM - Body Control Module	DATA
HX73-14C204-FCA.vbf	Jaguar XE (X760)	PCM - Powertrain Control Module	EXE
HX73-14C204-FCB.vbf	Jaguar XE (X760)	PCM - Powertrain Control Module	EXE
HX73-14C204-FCC.vbf	Jaguar XE (X760)	PCM - Powertrain Control Module	EXE
HX73-14C204-FCD.vbf	Jaguar XE (X760)	PCM - Powertrain Control Module	EXE
HX73-14C204-FDC.vbf	Jaguar XE (X760)	PCM - Powertrain Control Module	EXE
HX73-14C204-FDD.vbf	Jaguar XE (X760)	PCM - Powertrain Control Module	EXE
HX73-14C204-FDE.vbf	Jaguar XE (X760)	PCM - Powertrain Control Module	EXE
HX73-14C204-FEA.vbf	Jaguar XE (X760)	PCM - Powertrain Control Module	EXE
HX73-14C204-FEB.vbf	Jaguar XE (X760)	PCM - Powertrain Control Module	EXE
HX73-14C204-FEC.vbf	Jaguar XE (X760)	PCM - Powertrain Control Module	EXE
HX73-14C204-FED.vbf	Jaguar XE (X760)	PCM - Powertrain Control Module	EXE
HX73-14C204-FFA.vbf	Jaguar XE (X760)	PCM - Powertrain Control Module	EXE
HX73-14C204-FFB.vbf	Jaguar XE (X760)	PCM - Powertrain Control Module	EXE
HX73-14C204-FFC.vbf	Jaguar XE (X760)	PCM - Powertrain Control Module	EXE
HX73-14C204-FFD.vbf	Jaguar XE (X760)	PCM - Powertrain Control Module	EXE
HX73-14C204-FFE.vbf	Jaguar XE (X760)	PCM - Powertrain Control Module	EXE
HX73-14C204-FHA.vbf	Jaguar XE (X760)	PCM - Powertrain Control Module	EXE
HX73-14C204-FHB.vbf	Jaguar XE (X760)	PCM - Powertrain Control Module	EXE
HX73-14C204-FHC.vbf	Jaguar XE (X760)	PCM - Powertrain Control Module	EXE
HX73-14C204-FHE.vbf	Jaguar XE (X760)	PCM - Powertrain Control Module	EXE
HX73-14C204-FJA.vbf	Jaguar XE (X760)	PCM - Powertrain Control Module	EXE
HX73-14C204-FJB.vbf	Jaguar XE (X760)	PCM - Powertrain Control Module	EXE
HX73-14C204-FJC.vbf	Jaguar XE (X760)	PCM - Powertrain Control Module	EXE
HX73-14C204-JAA.vbf	Jaguar XE (X760)	PCM - Powertrain Control Module	EXE
HX73-14C204-JAB.vbf	Jaguar XE (X760)	PCM - Powertrain Control Module	EXE
HX73-14C204-JAC.vbf	Jaguar XE (X760)	PCM - Powertrain Control Module	EXE
HX73-14C204-JAD.vbf	Jaguar XE (X760)	PCM - Powertrain Control Module	EXE
HX73-14C204-JAE.vbf	Jaguar XE (X760)	PCM - Powertrain Control Module	EXE
HX73-14C204-MAA.vbf	Jaguar XE (X760)	PCM - Powertrain Control Module	EXE
HX73-14C204-MAB.vbf	Jaguar XE (X760)	PCM - Powertrain Control Module	EXE
HX73-14C204-MAC.vbf	Jaguar XE (X760)	PCM - Powertrain Control Module	EXE
HX73-14C204-TAA.vbf	Jaguar XE (X760)	PCM - Powertrain Control Module	EXE
HX73-14C204-TAB.vbf	Jaguar XE (X760)	PCM - Powertrain Control Module	EXE
HX73-14C204-TAC.vbf	Jaguar XE (X760)	PCM - Powertrain Control Module	EXE
HX73-14C204-TAD.vbf	Jaguar XE (X760)	PCM - Powertrain Control Module	EXE
HX73-14C204-TAE.vbf	Jaguar XE (X760)	PCM - Powertrain Control Module	EXE
HX73-14C204-TCA.vbf	Jaguar XE (X760)	PCM - Powertrain Control Module	EXE
HX73-14C204-TCB.vbf	Jaguar XE (X760)	PCM - Powertrain Control Module	EXE
HX73-14C204-TCC.vbf	Jaguar XE (X760)	PCM - Powertrain Control Module	EXE
HX73-14C204-TEA.vbf	Jaguar XE (X760)	PCM - Powertrain Control Module	EXE
HX73-14C204-TEB.vbf	Jaguar XE (X760)	PCM - Powertrain Control Module	EXE
HX73-14C204-TEC.vbf	Jaguar XE (X760)	PCM - Powertrain Control Module	EXE
HX73-14C204-TED.vbf	Jaguar XE (X760)	PCM - Powertrain Control Module	EXE
HX73-14C204-TTA.vbf	Jaguar XE (X760)	PCM - Powertrain Control Module	EXE
HX73-14C204-TTB.vbf	Jaguar XE (X760)	PCM - Powertrain Control Module	EXE
HX73-14C204-TTC.vbf	Jaguar XE (X760)	PCM - Powertrain Control Module	EXE
HX73-14C204-TTD.vbf	Jaguar XE (X760)	PCM - Powertrain Control Module	EXE
HX73-14C217-BA.vbf	Jaguar XE (X760)	PSCM - Power Steering Control Module	EXE
HX73-14C218-BA.vbf	Jaguar XE (X760)	PSCM - Power Steering Control Module	DATA
HX73-14C218-CA.vbf	Jaguar XE (X760)	PSCM - Power Steering Control Module	DATA
HX73-14C218-DA.vbf	Jaguar XE (X760)	PSCM - Power Steering Control Module	DATA
HX73-14C218-EA.vbf	Jaguar XE (X760)	PSCM - Power Steering Control Module	DATA
HX73-14C218-FA.vbf	Jaguar XE (X760)	PSCM - Power Steering Control Module	DATA
HX73-14C218-GA.vbf	Jaguar XE (X760)	PSCM - Power Steering Control Module	DATA
HX73-14C367-BA.vbf	Jaguar XE (X760)	TCCM - Transfer Case Control Module	DATA
HX73-14C367-BB.vbf	Jaguar XE (X760)	TCCM - Transfer Case Control Module	DATA
HX73-14C367-BC.vbf	Jaguar XE (X760)	TCCM - Transfer Case Control Module	DATA
HX73-14C367-DA.vbf	Jaguar XE (X760)	TCCM - Transfer Case Control Module	DATA
HX73-14C367-DB.vbf	Jaguar XE (X760)	TCCM - Transfer Case Control Module	DATA
HX73-14C367-DC.vbf	Jaguar XE (X760)	TCCM - Transfer Case Control Module	DATA
HX73-14C407-AB.vbf	Jaguar XE (X760)	RCM - Restraints Control Module	SIGCFG
HX73-14C526-BB.vbf	Jaguar XE (X760)	AAM - Audio Amplifier Module	EXE
HX73-14C526-BC.vbf	Jaguar XE (X760)	AAM - Audio Amplifier Module	EXE

File name	Vehicle line (indicative)	Module (ECU)	Type
HX73-14C526-BD.vbf	Jaguar XE (X760)	AAM - Audio Amplifier Module	EXE
HX73-14C526-CB.vbf	Jaguar XE (X760)	AAM - Audio Amplifier Module	EXE
HX73-14C526-CC.vbf	Jaguar XE (X760)	AAM - Audio Amplifier Module	EXE
HX73-14C526-CD.vbf	Jaguar XE (X760)	AAM - Audio Amplifier Module	EXE
HX73-14C527-BA.vbf	Jaguar XE (X760)	AAM - Audio Amplifier Module	DATA
HX73-14C527-BC.vbf	Jaguar XE (X760)	AAM - Audio Amplifier Module	DATA
HX73-14C527-CA.vbf	Jaguar XE (X760)	AAM - Audio Amplifier Module	DATA
HX73-14C527-CC.vbf	Jaguar XE (X760)	AAM - Audio Amplifier Module	DATA
HX73-14C528-AA.vbf	Jaguar XE (X760)	AAM - Audio Amplifier Module	SBL
HX73-14C561-AC.vbf	Jaguar XE (X760)	GSM - Gear Shift Module	EXE
HX73-14C561-AD.vbf	Jaguar XE (X760)	GSM - Gear Shift Module	EXE
HX73-14C561-AE.vbf	Jaguar XE (X760)	GSM - Gear Shift Module	EXE
HX73-14C561-AF.vbf	Jaguar XE (X760)	GSM - Gear Shift Module	EXE
HX73-14C562-AB.vbf	Jaguar XE (X760)	GSM - Gear Shift Module	DATA
HX73-14C563-AA.vbf	Jaguar XE (X760)	GSM - Gear Shift Module	SBL
HX73-14C572-BC.vbf	Jaguar XE (X760)	PCM - Powertrain Control Module	SBL
HX73-14C609-BA.vbf	Jaguar XE (X760)	PSCM - Power Steering Control Module	DATA
HX73-14C609-CA.vbf	Jaguar XE (X760)	PSCM - Power Steering Control Module	DATA
HX73-14C653-AE.vbf	Jaguar XE (X760)	ACM - Audio Front Control Module	DATA
HX73-14C653-AF.vbf	Jaguar XE (X760)	ACM - Audio Front Control Module	DATA
HX73-14C653-AG.vbf	Jaguar XE (X760)	ACM - Audio Front Control Module	DATA
HX73-14C653-AH.vbf	Jaguar XE (X760)	ACM - Audio Front Control Module	DATA
HX73-14D183-BA.vbf	Jaguar XE (X760)	OCS - Restraints Occupant Classification System Module	DATA
HX73-14D481-BA.vbf	Jaguar XE (X760)	IPMB - Image Processing Module B	DATA
HX73-14D481-BB.vbf	Jaguar XE (X760)	IPMB - Image Processing Module B	DATA
HX73-14D481-BC.vbf	Jaguar XE (X760)	IPMB - Image Processing Module B	DATA
HX73-14D481-BE.vbf	Jaguar XE (X760)	IPMB - Image Processing Module B	DATA
HX73-14D485-BC.vbf	Jaguar XE (X760)	IPMB - Image Processing Module B	DATA
HX73-14D485-BD.vbf	Jaguar XE (X760)	IPMB - Image Processing Module B	DATA
HX73-14D485-BE.vbf	Jaguar XE (X760)	IPMB - Image Processing Module B	DATA
HX73-14D564-AA.vbf	Jaguar XE (X760)	SODL - Side Obstacle Detection Control Module - Left	DATA
HX73-14D564-BA.vbf	Jaguar XE (X760)	SODR - Side Obstacle Detection Control Module - Right	DATA
HX73-14E094-DAC.vbf	Jaguar XE (X760)	CHCM - Chassis Control Module	EXE
HX73-14E094-DBC.vbf	Jaguar XE (X760)	CHCM - Chassis Control Module	EXE
HX73-14E094-DCC.vbf	Jaguar XE (X760)	CHCM - Chassis Control Module	EXE
HX73-14E094-DDC.vbf	Jaguar XE (X760)	CHCM - Chassis Control Module	EXE
HX73-14E094-DDD.vbf	Jaguar XE (X760)	CHCM - Chassis Control Module	EXE
HX73-14E094-DEC.vbf	Jaguar XE (X760)	CHCM - Chassis Control Module	EXE
HX73-14E094-DED.vbf	Jaguar XE (X760)	CHCM - Chassis Control Module	EXE
HX73-14F022-BC.vbf	Jaguar XE (X760)	IPMB - Image Processing Module B	DATA
HX73-14F022-BF.vbf	Jaguar XE (X760)	IPMB - Image Processing Module B	DATA
HX73-14F022-BG.vbf	Jaguar XE (X760)	IPMB - Image Processing Module B	DATA
HX73-14F022-BH.vbf	Jaguar XE (X760)	IPMB - Image Processing Module B	DATA
HX73-14F022-GB.vbf	Jaguar XE (X760)	IPMB - Image Processing Module B	DATA
HX73-14F022-GF.vbf	Jaguar XE (X760)	IPMB - Image Processing Module B	DATA
HX73-14F022-GG.vbf	Jaguar XE (X760)	IPMB - Image Processing Module B	DATA
HX73-14F022-GH.vbf	Jaguar XE (X760)	IPMB - Image Processing Module B	DATA
HX73-70713-DA.vbf	Jaguar XE (X760)	TCU - Telematic Control Unit Module	DATA
HX73-70713-DB.vbf	Jaguar XE (X760)	TCU - Telematic Control Unit Module	DATA
HX73-70713-DC.vbf	Jaguar XE (X760)	TCU - Telematic Control Unit Module	DATA
HX73-70713-DD.vbf	Jaguar XE (X760)	TCU - Telematic Control Unit Module	DATA
HX73-70713-DE.vbf	Jaguar XE (X760)	TCU - Telematic Control Unit Module	DATA
HX73-70713-DF.vbf	Jaguar XE (X760)	TCU - Telematic Control Unit Module	DATA
HX73-70713-DH.vbf	Jaguar XE (X760)	TCU - Telematic Control Unit Module	DATA
HX73-70713-DJ.vbf	Jaguar XE (X760)	TCU - Telematic Control Unit Module	DATA
HX73-70713-KA.vbf	Jaguar XE (X760)	TCU - Telematic Control Unit Module	DATA
HX73-70713-KB.vbf	Jaguar XE (X760)	TCU - Telematic Control Unit Module	DATA
HX73-70713-KC.vbf	Jaguar XE (X760)	TCU - Telematic Control Unit Module	DATA
HX73-70713-KD.vbf	Jaguar XE (X760)	TCU - Telematic Control Unit Module	DATA
HX73-70713-KE.vbf	Jaguar XE (X760)	TCU - Telematic Control Unit Module	DATA
HX73-70713-KF.vbf	Jaguar XE (X760)	TCU - Telematic Control Unit Module	DATA
HX73-70713-KH.vbf	Jaguar XE (X760)	TCU - Telematic Control Unit Module	DATA
HX73-70713-KJ.vbf	Jaguar XE (X760)	TCU - Telematic Control Unit Module	DATA
HX73-70713-RH.vbf	Jaguar XE (X760)	TCU - Telematic Control Unit Module	DATA
HX73-70713-RJ.vbf	Jaguar XE (X760)	TCU - Telematic Control Unit Module	DATA
HX73-70713-RK.vbf	Jaguar XE (X760)	TCU - Telematic Control Unit Module	DATA
HX73-70713-RL.vbf	Jaguar XE (X760)	TCU - Telematic Control Unit Module	DATA
HX73-70713-RM.vbf	Jaguar XE (X760)	TCU - Telematic Control Unit Module	DATA
HX73-70713-RN.vbf	Jaguar XE (X760)	TCU - Telematic Control Unit Module	DATA
HX73-70713-RR.vbf	Jaguar XE (X760)	TCU - Telematic Control Unit Module	DATA
HX73-70713-RS.vbf	Jaguar XE (X760)	TCU - Telematic Control Unit Module	DATA
HX73-70713-SH.vbf	Jaguar XE (X760)	TCU - Telematic Control Unit Module	DATA
HX73-70713-SJ.vbf	Jaguar XE (X760)	TCU - Telematic Control Unit Module	DATA
HX73-70713-SK.vbf	Jaguar XE (X760)	TCU - Telematic Control Unit Module	DATA
HX73-70713-SL.vbf	Jaguar XE (X760)	TCU - Telematic Control Unit Module	DATA
HX73-70713-SM.vbf	Jaguar XE (X760)	TCU - Telematic Control Unit Module	DATA

File name	Vehicle line (indicative)	Module (ECU)	Type
HX73-70713-SN.vbf	Jaguar XE (X760)	TCU - Telematic Control Unit Module	DATA
HX73-70713-SR.vbf	Jaguar XE (X760)	TCU - Telematic Control Unit Module	DATA
HX73-70713-SS.vbf	Jaguar XE (X760)	TCU - Telematic Control Unit Module	DATA
HX73-70713-TC.vbf	Jaguar XE (X760)	TCU - Telematic Control Unit Module	DATA
HX73-70713-TD.vbf	Jaguar XE (X760)	TCU - Telematic Control Unit Module	DATA
HX73-70713-TE.vbf	Jaguar XE (X760)	TCU - Telematic Control Unit Module	DATA
HX73-70713-TF.vbf	Jaguar XE (X760)	TCU - Telematic Control Unit Module	DATA
HX73-70713-TG.vbf	Jaguar XE (X760)	TCU - Telematic Control Unit Module	DATA
HX73-70713-TK.vbf	Jaguar XE (X760)	TCU - Telematic Control Unit Module	DATA
HX73-70713-TL.vbf	Jaguar XE (X760)	TCU - Telematic Control Unit Module	DATA
HX73-7J104-BCA.vbf	Jaguar XE (X760)	TCM - Transmission Control Module	EXE
HX73-7J104-BCB.vbf	Jaguar XE (X760)	TCM - Transmission Control Module	EXE
HX73-7J104-BCC.vbf	Jaguar XE (X760)	TCM - Transmission Control Module	EXE
HX73-7J104-BCD.vbf	Jaguar XE (X760)	TCM - Transmission Control Module	EXE
HX73-7J104-BDA.vbf	Jaguar XE (X760)	TCM - Transmission Control Module	EXE
HX73-7J104-BDB.vbf	Jaguar XE (X760)	TCM - Transmission Control Module	EXE
HX73-7J104-BDC.vbf	Jaguar XE (X760)	TCM - Transmission Control Module	EXE
HX73-7J104-BGA.vbf	Jaguar XE (X760)	TCM - Transmission Control Module	EXE
HX73-7J104-BGB.vbf	Jaguar XE (X760)	TCM - Transmission Control Module	EXE
HX73-7J104-BMA.vbf	Jaguar XE (X760)	TCM - Transmission Control Module	EXE
HX73-7J104-BMB.vbf	Jaguar XE (X760)	TCM - Transmission Control Module	EXE
HX73-7J104-BMC.vbf	Jaguar XE (X760)	TCM - Transmission Control Module	EXE
HX73-7J104-BMD.vbf	Jaguar XE (X760)	TCM - Transmission Control Module	EXE
HX73-7J104-BXA.vbf	Jaguar XE (X760)	TCM - Transmission Control Module	EXE
HX73-7J104-BXB.vbf	Jaguar XE (X760)	TCM - Transmission Control Module	EXE
HX73-7J104-BXC.vbf	Jaguar XE (X760)	TCM - Transmission Control Module	EXE
HX73-7J104-BXD.vbf	Jaguar XE (X760)	TCM - Transmission Control Module	EXE
HY32-14C029-AA.vbf	Not specified	DSM - Driver Front Seat Module	SBL
HY32-14C029-AB.vbf	Not specified	DSM - Driver Front Seat Module	SBL
HY32-14C029-AC.vbf	Not specified	DSM - Driver Front Seat Module	SBL
HY32-14C030-AB.vbf	Not specified	DSM - Driver Front Seat Module	EXE
HY32-14C030-AC.vbf	Not specified	DSM - Driver Front Seat Module	EXE
HY32-14C030-AD.vbf	Not specified	DSM - Driver Front Seat Module	EXE
HY32-14C030-AE.vbf	Not specified	DSM - Driver Front Seat Module	EXE
HY32-14C119-AA.vbf	Not specified	RDCM - Rear Differential Control Module	DATA
HY32-14C119-AB.vbf	Not specified	ecu_address = 0x795;	DATA
HY32-14C119-AC.vbf	Not specified	ecu_address = 0x795;	DATA
HY32-14C119-AD.vbf	Not specified	ecu_address = 0x795;	DATA
HY32-14C119-AE.vbf	Not specified	ecu_address = 0x795;	DATA
HY32-14C151-AA.vbf	Not specified	TPM - Tire Pressure Monitor Module	EXE
HY32-14C151-AB.vbf	Not specified	TPM - Tire Pressure Monitor Module	EXE
HY32-14C151-AC.vbf	Not specified	TPM - Tire Pressure Monitor Module	EXE
HY32-14C151-AD.vbf	Not specified	TPM - Tire Pressure Monitor Module	EXE
HY32-14C151-AE.vbf	Not specified	TPM - Tire Pressure Monitor Module	EXE
HY32-14C151-AF.vbf	Not specified	TPM - Tire Pressure Monitor Module	EXE
HY32-14C204-FAA.vbf	Not specified	PCM - Powertrain Control Module	EXE
HY32-14C204-FAB.vbf	Not specified	PCM - Powertrain Control Module	EXE
HY32-14C204-FAC.vbf	Not specified	PCM - Powertrain Control Module	EXE
HY32-14C204-FAD.vbf	Not specified	PCM - Powertrain Control Module	EXE
HY32-14C204-FBB.vbf	Not specified	PCM - Powertrain Control Module	EXE
HY32-14C204-NAB.vbf	Not specified	PCM - Powertrain Control Module	EXE
HY32-14C204-NAC.vbf	Not specified	PCM - Powertrain Control Module	EXE
HY32-14C204-NAD.vbf	Not specified	PCM - Powertrain Control Module	EXE
HY32-14C204-PAA.vbf	Not specified	PCM - Powertrain Control Module ecu_address = 0x17E0; // 16-bit ...	EXE
HY32-14C204-PAB.vbf	Not specified	PCM - Powertrain Control Module	EXE
HY32-14C204-PAC.vbf	Not specified	PCM - Powertrain Control Module	EXE
HY32-14C204-PAD.vbf	Not specified	PCM - Powertrain Control Module	EXE
HY32-14C204-PAE.vbf	Not specified	PCM - Powertrain Control Module	EXE
HY32-14C218-BC.vbf	Not specified	PSCM - Power Steering Control Module	EXE
HY32-14C305-AA.vbf	Not specified	ACM - Audio Front Control Module	SBL
HY32-14C388-AA.vbf	Not specified	RDCM - Rear Differential Control Module	SIGCFG
HY32-14C388-AB.vbf	Not specified	ecu_address = 0x795;	SIGCFG
HY32-14C413-AB.vbf	Not specified	DSM - Driver Front Seat Module	EXE
HY32-14C413-AC.vbf	Not specified	DSM - Driver Front Seat Module	EXE
HY32-14C413-AD.vbf	Not specified	DSM - Driver Front Seat Module	EXE
HY32-14C413-BA.vbf	Not specified	DSM - Driver Front Seat Module	EXE
HY32-14C547-AB.vbf	Not specified	PSM - Passenger Front Seat Module	EXE
HY32-14C547-AC.vbf	Not specified	PSM - Passenger Front Seat Module	EXE
HY32-14C547-AD.vbf	Not specified	PSM - Passenger Front Seat Module	EXE
HY32-14C547-BA.vbf	Not specified	PSM - Passenger Front Seat Module	EXE
HY32-14C548-AB.vbf	Not specified	PSM - Passenger Front Seat Module	EXE
HY32-14C548-AC.vbf	Not specified	PSM - Passenger Front Seat Module	EXE
HY32-14C548-AD.vbf	Not specified	PSM - Passenger Front Seat Module	EXE
HY32-14C548-AE.vbf	Not specified	PSM - Passenger Front Seat Module	EXE
HY32-14C550-AA.vbf	Not specified	PSM - Passenger Front Seat Module	SBL
HY32-14C550-AB.vbf	Not specified	PSM - Passenger Front Seat Module	SBL

File name	Vehicle line (indicative)	Module (ECU)	Type
HY32-14C550-AC.vbf	Not specified	PSM - Passenger Front Seat Module	SBL
HY32-14D479-AC.vbf	Not specified	IPMB - Image Processing Module B	SIGCFG
HY32-14D479-AD.vbf	Not specified	IPMB - Image Processing Module B	SIGCFG
HY32-14D479-BB.vbf	Not specified	IPMB - Image Processing Module B	SIGCFG
HY32-14D480-BD.vbf	Not specified	IPMB - Image Processing Module B	EXE
HY32-14D480-BE.vbf	Not specified	IPMB - Image Processing Module B	EXE
HY32-14F016-AA.vbf	Not specified	IPMB - Image Processing Module B	SIGCFG
HY32-14F016-AB.vbf	Not specified	IPMB - Image Processing Module B	SIGCFG
HY32-14F016-AC.vbf	Not specified	IPMB - Image Processing Module B	SIGCFG
HY32-14F017-AB.vbf	Not specified	IPMB - Image Processing Module B	EXE
HY32-14F017-AC.vbf	Not specified	IPMB - Image Processing Module B	EXE
HY32-14F017-AD.vbf	Not specified	IPMB - Image Processing Module B	EXE
HY32-14F017-AE.vbf	Not specified	IPMB - Image Processing Module B	EXE
HY32-14F017-AF.vbf	Not specified	IPMB - Image Processing Module B	EXE
HY32-14F017-AG.vbf	Not specified	IPMB - Image Processing Module B	EXE
HY32-14F017-AH.vbf	Not specified	IPMB - Image Processing Module B	EXE
HY32-14F017-AJ.vbf	Not specified	IPMB - Image Processing Module B	EXE
HY32-14F017-AK.vbf	Not specified	IPMB - Image Processing Module B	EXE
HY32-14F017-AL.vbf	Not specified	IPMB - Image Processing Module B	EXE
HY32-14F017-AM.vbf	Not specified	IPMB - Image Processing Module B	EXE
HY32-14F017-BF.vbf	Not specified	IPMB - Image Processing Module B	EXE
HY32-14F017-BH.vbf	Not specified	IPMB - Image Processing Module B	EXE
HY32-14F017-BJ.vbf	Not specified	IPMB - Image Processing Module B	EXE
HY32-14F017-BK.vbf	Not specified	IPMB - Image Processing Module B	EXE
HY32-14F017-BL.vbf	Not specified	IPMB - Image Processing Module B	EXE
HY32-14F017-BM.vbf	Not specified	IPMB - Image Processing Module B	EXE
HY32-14F216-AA.vbf	Not specified	RHVAC - Rear HVAC Control Module	SIGCFG
HY32-14F216-AB.vbf	Not specified	RHVAC - Rear HVAC Control Module	SIGCFG
HY32-14F217-AA.vbf	Not specified	RHVAC - Rear HVAC Control Module	EXE
HY32-14F217-AB.vbf	Not specified	RHVAC - Rear HVAC Control Module	EXE
HY32-14F217-AC.vbf	Not specified	RHVAC - Rear HVAC Control Module	EXE
HY32-14F219-AA.vbf	Not specified	RHVAC - Rear HVAC Control Module	SBL
HY32-14F219-AB.vbf	Not specified	RHVAC - Rear HVAC Control Module	SBL
HY32-14F219-AC.vbf	Not specified	RHVAC - Rear HVAC Control Module	SBL
HY32-4C044-AA.vbf	Not specified	ecu_address = 0x795;	SBL
HY32-4C045-AA.vbf	Jaguar X400	RDCM - Rear Differential Control Module	EXE
HY32-4C045-AB.vbf	Jaguar X400	ecu_address = 0x795;	EXE
HY32-4C045-AC.vbf	Jaguar X400	ecu_address = 0x795;	EXE
HY32-4C045-AD.vbf	Jaguar X400	ecu_address = 0x795;	EXE
HY32-4C045-AE.vbf	Jaguar X400	ecu_address = 0x795;	EXE
HY32-70712-AC.vbf	Not specified	TCU - Telematic Control Unit Module	EXE
HY32-70712-AD.vbf	Not specified	TCU - Telematic Control Unit Module	EXE
HY32-70712-AE.vbf	Not specified	TCU - Telematic Control Unit Module	EXE
HY32-70712-AF.vbf	Not specified	TCU - Telematic Control Unit Module	EXE
HY32-70712-AG.vbf	Not specified	TCU - Telematic Control Unit Module	EXE
HY32-70712-AH.vbf	Not specified	TCU - Telematic Control Unit Module	EXE
HY32-9J405-BA.vbf	Not specified	GPSM - Global Positioning System Module	DATA
HY3M-19H535-AB.vbf	Not specified	TBM - Trailer Brake Control Module	SIGCFG
HY3M-19H535-AC.vbf	Not specified	TBM - Trailer Brake Control Module	SIGCFG
HY3M-19H535-AD.vbf	Not specified	TBM - Trailer Brake Control Module	SIGCFG
HY3M-19H535-AE.vbf	Not specified	TBM - Trailer Brake Control Module	SIGCFG
HY3M-19H536-AB.vbf	Not specified	TBM - Trailer Brake Control Module	EXE
HY3M-19H536-AC.vbf	Not specified	TBM - Trailer Brake Control Module	EXE
HY3M-19H536-AD.vbf	Not specified	TBM - Trailer Brake Control Module	EXE
HY3M-19H536-AE.vbf	Not specified	TBM - Trailer Brake Control Module	EXE
HY3M-19H536-AF.vbf	Not specified	TBM - Trailer Brake Control Module	EXE
HY3M-19H536-AG.vbf	Not specified	TBM - Trailer Brake Control Module	EXE
HY3M-19H536-AH.vbf	Not specified	ecu_address = 0x757;	EXE
HY3M-19H536-AJ.vbf	Not specified	ecu_address = 0x757;	EXE
HY3M-19H536-AK.vbf	Not specified	TBM - Trailer Brake Control Module	EXE
HY3M-19H536-AL.vbf	Not specified	TBM - Trailer Brake Control Module	EXE
HY3M-19H536-AM.vbf	Not specified	TBM - Trailer Brake Control Module	EXE
HY3M-19H536-AN.vbf	Not specified	TBM - Trailer Brake Control Module	EXE
HY3M-19H536-AP.vbf	Not specified	TBM - Trailer Brake Control Module	EXE
HY3M-19H538-AB.vbf	Not specified	TBM - Trailer Brake Control Module	SBL
HY3M-19H538-AC.vbf	Not specified	TBM - Trailer Brake Control Module	SBL
HY3M-19H538-AD.vbf	Not specified	TBM - Trailer Brake Control Module	SBL
HY3M-19H538-AE.vbf	Not specified	TBM - Trailer Brake Control Module	SBL
J2C2-14D564-AC.vbf	Discovery Sport (L550)	SODL - Side Obstacle Detection Control Module - Left	DATA
J2C2-14D564-AD.vbf	Discovery Sport (L550)	SODL - Side Obstacle Detection Control Module - Left	DATA
J2C2-14D564-AF.vbf	Discovery Sport (L550)	SODL - Side Obstacle Detection Control Module - Left	DATA
J2C2-14D564-BC.vbf	Discovery Sport (L550)	SODR - Side Obstacle Detection Control Module - Right	DATA
J2C2-14D564-BD.vbf	Discovery Sport (L550)	SODR - Side Obstacle Detection Control Module - Right	DATA
J2C2-14D564-BF.vbf	Discovery Sport (L550)	SODR - Side Obstacle Detection Control Module - Right	DATA
J6P3-6J073-AB.vbf	Not specified	ACM - Audio Front Control Module	EXE
J6P3-6J073-AD.vbf	Not specified	ACM - Audio Front Control Module	EXE

File name	Vehicle line (indicative)	Module (ECU)	Type
J6P3-6J073-BB.vbf	Not specified	ACM - Audio Front Control Module	EXE
J6P3-6J073-BC.vbf	Not specified	ACM - Audio Front Control Module	EXE
J6P3-6J075-AA.vbf	Not specified	ACM - Audio Front Control Module	SBL
J6P3-6J075-AB.vbf	Not specified	ACM - Audio Front Control Module	SBL
J7A3-70713-AAA.vbf	Jaguar XE (X760)	TCU - Telematic Control Unit Module	DATA
J7A3-70713-AD.vbf	Jaguar XE (X760)	TCU - Telematic Control Unit Module	DATA
J7A3-70713-AE.vbf	Jaguar XE (X760)	TCU - Telematic Control Unit Module	DATA
J7A3-70713-AF.vbf	Jaguar XE (X760)	TCU - Telematic Control Unit Module	DATA
J7A3-70713-AG.vbf	Jaguar XE (X760)	TCU - Telematic Control Unit Module	DATA
J7A3-70713-AH.vbf	Jaguar XE (X760)	TCU - Telematic Control Unit Module	DATA
J7A3-70713-AJ.vbf	Jaguar XE (X760)	TCU - Telematic Control Unit Module	DATA
J7A3-70713-AK.vbf	Jaguar XE (X760)	TCU - Telematic Control Unit Module	DATA
J7A3-70713-AL.vbf	Jaguar XE (X760)	TCU - Telematic Control Unit Module	DATA
J7A3-70713-AM.vbf	Jaguar XE (X760)	TCU - Telematic Control Unit Module	DATA
J7A3-70713-AN.vbf	Jaguar XE (X760)	TCU - Telematic Control Unit Module	DATA
J7A3-70713-ANV.vbf	Jaguar XE (X760)	TCU - Telematic Control Unit Module	DATA
J7A3-70713-ANX.vbf	Jaguar XE (X760)	TCU - Telematic Control Unit Module	DATA
J7A3-70713-AP.vbf	Jaguar XE (X760)	TCU - Telematic Control Unit Module	DATA
J7A3-70713-APV.vbf	Jaguar XE (X760)	TCU - Telematic Control Unit Module	DATA
J7A3-70713-AR.vbf	Jaguar XE (X760)	TCU - Telematic Control Unit Module	DATA
J7A3-70713-AS.vbf	Jaguar XE (X760)	TCU - Telematic Control Unit Module	DATA
J7A3-70713-AT.vbf	Jaguar XE (X760)	TCU - Telematic Control Unit Module	DATA
J7A3-70713-AV.vbf	Jaguar XE (X760)	TCU - Telematic Control Unit Module	DATA
J7A3-70713-AX.vbf	Jaguar XE (X760)	TCU - Telematic Control Unit Module	DATA
J7A3-70713-AY.vbf	Jaguar XE (X760)	TCU - Telematic Control Unit Module	DATA
J7A3-70713-AZ.vbf	Jaguar XE (X760)	TCU - Telematic Control Unit Module	DATA
J7A3-70713-BAA.vbf	Jaguar XE (X760)	TCU - Telematic Control Unit Module	DATA
J7A3-70713-BD.vbf	Jaguar XE (X760)	TCU - Telematic Control Unit Module	DATA
J7A3-70713-BE.vbf	Jaguar XE (X760)	TCU - Telematic Control Unit Module	DATA
J7A3-70713-BF.vbf	Jaguar XE (X760)	TCU - Telematic Control Unit Module	DATA
J7A3-70713-BG.vbf	Jaguar XE (X760)	TCU - Telematic Control Unit Module	DATA
J7A3-70713-BH.vbf	Jaguar XE (X760)	TCU - Telematic Control Unit Module	DATA
J7A3-70713-BJ.vbf	Jaguar XE (X760)	TCU - Telematic Control Unit Module	DATA
J7A3-70713-BK.vbf	Jaguar XE (X760)	TCU - Telematic Control Unit Module	DATA
J7A3-70713-BL.vbf	Jaguar XE (X760)	TCU - Telematic Control Unit Module	DATA
J7A3-70713-BM.vbf	Jaguar XE (X760)	TCU - Telematic Control Unit Module	DATA
J7A3-70713-BN.vbf	Jaguar XE (X760)	TCU - Telematic Control Unit Module	DATA
J7A3-70713-BNV.vbf	Jaguar XE (X760)	TCU - Telematic Control Unit Module	DATA
J7A3-70713-BNX.vbf	Jaguar XE (X760)	TCU - Telematic Control Unit Module	DATA
J7A3-70713-BP.vbf	Jaguar XE (X760)	TCU - Telematic Control Unit Module	DATA
J7A3-70713-BPV.vbf	Jaguar XE (X760)	TCU - Telematic Control Unit Module	DATA
J7A3-70713-BR.vbf	Jaguar XE (X760)	TCU - Telematic Control Unit Module	DATA
J7A3-70713-BS.vbf	Jaguar XE (X760)	TCU - Telematic Control Unit Module	DATA
J7A3-70713-BT.vbf	Jaguar XE (X760)	TCU - Telematic Control Unit Module	DATA
J7A3-70713-BV.vbf	Jaguar XE (X760)	TCU - Telematic Control Unit Module	DATA
J7A3-70713-BX.vbf	Jaguar XE (X760)	TCU - Telematic Control Unit Module	DATA
J7A3-70713-BY.vbf	Jaguar XE (X760)	TCU - Telematic Control Unit Module	DATA
J7A3-70713-BZ.vbf	Jaguar XE (X760)	TCU - Telematic Control Unit Module	DATA
J7A3-70713-CAA.vbf	Jaguar XE (X760)	TCU - Telematic Control Unit Module	DATA
J7A3-70713-CD.vbf	Jaguar XE (X760)	TCU - Telematic Control Unit Module	DATA
J7A3-70713-CE.vbf	Jaguar XE (X760)	TCU - Telematic Control Unit Module	DATA
J7A3-70713-CF.vbf	Jaguar XE (X760)	TCU - Telematic Control Unit Module	DATA
J7A3-70713-CG.vbf	Jaguar XE (X760)	TCU - Telematic Control Unit Module	DATA
J7A3-70713-CH.vbf	Jaguar XE (X760)	TCU - Telematic Control Unit Module	DATA
J7A3-70713-CJ.vbf	Jaguar XE (X760)	TCU - Telematic Control Unit Module	DATA
J7A3-70713-CK.vbf	Jaguar XE (X760)	TCU - Telematic Control Unit Module	DATA
J7A3-70713-CL.vbf	Jaguar XE (X760)	TCU - Telematic Control Unit Module	DATA
J7A3-70713-CM.vbf	Jaguar XE (X760)	TCU - Telematic Control Unit Module	DATA
J7A3-70713-CN.vbf	Jaguar XE (X760)	TCU - Telematic Control Unit Module	DATA
J7A3-70713-CNV.vbf	Jaguar XE (X760)	TCU - Telematic Control Unit Module	DATA
J7A3-70713-CNX.vbf	Jaguar XE (X760)	TCU - Telematic Control Unit Module	DATA
J7A3-70713-CP.vbf	Jaguar XE (X760)	TCU - Telematic Control Unit Module	DATA
J7A3-70713-CPV.vbf	Jaguar XE (X760)	TCU - Telematic Control Unit Module	DATA
J7A3-70713-CR.vbf	Jaguar XE (X760)	TCU - Telematic Control Unit Module	DATA
J7A3-70713-CS.vbf	Jaguar XE (X760)	TCU - Telematic Control Unit Module	DATA
J7A3-70713-CT.vbf	Jaguar XE (X760)	TCU - Telematic Control Unit Module	DATA
J7A3-70713-CV.vbf	Jaguar XE (X760)	TCU - Telematic Control Unit Module	DATA
J7A3-70713-CX.vbf	Jaguar XE (X760)	TCU - Telematic Control Unit Module	DATA
J7A3-70713-CY.vbf	Jaguar XE (X760)	TCU - Telematic Control Unit Module	DATA
J7A3-70713-CZ.vbf	Jaguar XE (X760)	TCU - Telematic Control Unit Module	DATA
J7A3-70713-DAA.vbf	Jaguar XE (X760)	TCU - Telematic Control Unit Module	DATA
J7A3-70713-DD.vbf	Jaguar XE (X760)	TCU - Telematic Control Unit Module	DATA
J7A3-70713-DE.vbf	Jaguar XE (X760)	TCU - Telematic Control Unit Module	DATA
J7A3-70713-DF.vbf	Jaguar XE (X760)	TCU - Telematic Control Unit Module	DATA
J7A3-70713-DG.vbf	Jaguar XE (X760)	TCU - Telematic Control Unit Module	DATA
J7A3-70713-DH.vbf	Jaguar XE (X760)	TCU - Telematic Control Unit Module	DATA

File name	Vehicle line (indicative)	Module (ECU)	Type
J7A3-70713-DJ.vbf	Jaguar XE (X760)	TCU - Telematic Control Unit Module	DATA
J7A3-70713-DK.vbf	Jaguar XE (X760)	TCU - Telematic Control Unit Module	DATA
J7A3-70713-DL.vbf	Jaguar XE (X760)	TCU - Telematic Control Unit Module	DATA
J7A3-70713-DM.vbf	Jaguar XE (X760)	TCU - Telematic Control Unit Module	DATA
J7A3-70713-DN.vbf	Jaguar XE (X760)	TCU - Telematic Control Unit Module	DATA
J7A3-70713-DNV.vbf	Jaguar XE (X760)	TCU - Telematic Control Unit Module	DATA
J7A3-70713-DNX.vbf	Jaguar XE (X760)	TCU - Telematic Control Unit Module	DATA
J7A3-70713-DP.vbf	Jaguar XE (X760)	TCU - Telematic Control Unit Module	DATA
J7A3-70713-DPV.vbf	Jaguar XE (X760)	TCU - Telematic Control Unit Module	DATA
J7A3-70713-DR.vbf	Jaguar XE (X760)	TCU - Telematic Control Unit Module	DATA
J7A3-70713-DS.vbf	Jaguar XE (X760)	TCU - Telematic Control Unit Module	DATA
J7A3-70713-DT.vbf	Jaguar XE (X760)	TCU - Telematic Control Unit Module	DATA
J7A3-70713-DV.vbf	Jaguar XE (X760)	TCU - Telematic Control Unit Module	DATA
J7A3-70713-DX.vbf	Jaguar XE (X760)	TCU - Telematic Control Unit Module	DATA
J7A3-70713-DY.vbf	Jaguar XE (X760)	TCU - Telematic Control Unit Module	DATA
J7A3-70713-DZ.vbf	Jaguar XE (X760)	TCU - Telematic Control Unit Module	DATA
J7A3-70713-EAA.vbf	Jaguar XE (X760)	TCU - Telematic Control Unit Module	DATA
J7A3-70713-ED.vbf	Jaguar XE (X760)	TCU - Telematic Control Unit Module	DATA
J7A3-70713-EE.vbf	Jaguar XE (X760)	TCU - Telematic Control Unit Module	DATA
J7A3-70713-EF.vbf	Jaguar XE (X760)	TCU - Telematic Control Unit Module	DATA
J7A3-70713-EG.vbf	Jaguar XE (X760)	TCU - Telematic Control Unit Module	DATA
J7A3-70713-EH.vbf	Jaguar XE (X760)	TCU - Telematic Control Unit Module	DATA
J7A3-70713-EJ.vbf	Jaguar XE (X760)	TCU - Telematic Control Unit Module	DATA
J7A3-70713-EK.vbf	Jaguar XE (X760)	TCU - Telematic Control Unit Module	DATA
J7A3-70713-EL.vbf	Jaguar XE (X760)	TCU - Telematic Control Unit Module	DATA
J7A3-70713-EM.vbf	Jaguar XE (X760)	TCU - Telematic Control Unit Module	DATA
J7A3-70713-EN.vbf	Jaguar XE (X760)	TCU - Telematic Control Unit Module	DATA
J7A3-70713-ENV.vbf	Jaguar XE (X760)	TCU - Telematic Control Unit Module	DATA
J7A3-70713-ENX.vbf	Jaguar XE (X760)	TCU - Telematic Control Unit Module	DATA
J7A3-70713-EP.vbf	Jaguar XE (X760)	TCU - Telematic Control Unit Module	DATA
J7A3-70713-EPV.vbf	Jaguar XE (X760)	TCU - Telematic Control Unit Module	DATA
J7A3-70713-ER.vbf	Jaguar XE (X760)	TCU - Telematic Control Unit Module	DATA
J7A3-70713-ES.vbf	Jaguar XE (X760)	TCU - Telematic Control Unit Module	DATA
J7A3-70713-ET.vbf	Jaguar XE (X760)	TCU - Telematic Control Unit Module	DATA
J7A3-70713-EV.vbf	Jaguar XE (X760)	TCU - Telematic Control Unit Module	DATA
J7A3-70713-EX.vbf	Jaguar XE (X760)	TCU - Telematic Control Unit Module	DATA
J7A3-70713-EY.vbf	Jaguar XE (X760)	TCU - Telematic Control Unit Module	DATA
J7A3-70713-EZ.vbf	Jaguar XE (X760)	TCU - Telematic Control Unit Module	DATA
J7A3-70713-FAA.vbf	Jaguar XE (X760)	TCU - Telematic Control Unit Module	DATA
J7A3-70713-FD.vbf	Jaguar XE (X760)	TCU - Telematic Control Unit Module	DATA
J7A3-70713-FE.vbf	Jaguar XE (X760)	TCU - Telematic Control Unit Module	DATA
J7A3-70713-FF.vbf	Jaguar XE (X760)	TCU - Telematic Control Unit Module	DATA
J7A3-70713-FG.vbf	Jaguar XE (X760)	TCU - Telematic Control Unit Module	DATA
J7A3-70713-FH.vbf	Jaguar XE (X760)	TCU - Telematic Control Unit Module	DATA
J7A3-70713-FJ.vbf	Jaguar XE (X760)	TCU - Telematic Control Unit Module	DATA
J7A3-70713-FK.vbf	Jaguar XE (X760)	TCU - Telematic Control Unit Module	DATA
J7A3-70713-FL.vbf	Jaguar XE (X760)	TCU - Telematic Control Unit Module	CARCFG
J7A3-70713-FM.vbf	Jaguar XE (X760)	TCU - Telematic Control Unit Module	DATA
J7A3-70713-FN.vbf	Jaguar XE (X760)	TCU - Telematic Control Unit Module	DATA
J7A3-70713-FNV.vbf	Jaguar XE (X760)	TCU - Telematic Control Unit Module	DATA
J7A3-70713-FNX.vbf	Jaguar XE (X760)	TCU - Telematic Control Unit Module	DATA
J7A3-70713-FP.vbf	Jaguar XE (X760)	TCU - Telematic Control Unit Module	DATA
J7A3-70713-FPV.vbf	Jaguar XE (X760)	TCU - Telematic Control Unit Module	DATA
J7A3-70713-FR.vbf	Jaguar XE (X760)	TCU - Telematic Control Unit Module	DATA
J7A3-70713-FS.vbf	Jaguar XE (X760)	TCU - Telematic Control Unit Module	DATA
J7A3-70713-FT.vbf	Jaguar XE (X760)	TCU - Telematic Control Unit Module	DATA
J7A3-70713-FV.vbf	Jaguar XE (X760)	TCU - Telematic Control Unit Module	DATA
J7A3-70713-FX.vbf	Jaguar XE (X760)	TCU - Telematic Control Unit Module	DATA
J7A3-70713-FY.vbf	Jaguar XE (X760)	TCU - Telematic Control Unit Module	DATA
J7A3-70713-FZ.vbf	Jaguar XE (X760)	TCU - Telematic Control Unit Module	DATA
J7A3-70713-JAA.vbf	Jaguar XE (X760)	TCU - Telematic Control Unit Module	DATA
J7A3-70713-JE.vbf	Jaguar XE (X760)	TCU - Telematic Control Unit Module	DATA
J7A3-70713-JF.vbf	Jaguar XE (X760)	TCU - Telematic Control Unit Module	DATA
J7A3-70713-JG.vbf	Jaguar XE (X760)	TCU - Telematic Control Unit Module	DATA
J7A3-70713-JK.vbf	Jaguar XE (X760)	TCU - Telematic Control Unit Module	DATA
J7A3-70713-JL.vbf	Jaguar XE (X760)	TCU - Telematic Control Unit Module	CARCFG
J7A3-70713-JM.vbf	Jaguar XE (X760)	TCU - Telematic Control Unit Module	DATA
J7A3-70713-JN.vbf	Jaguar XE (X760)	TCU - Telematic Control Unit Module	DATA
J7A3-70713-JNV.vbf	Jaguar XE (X760)	TCU - Telematic Control Unit Module	DATA
J7A3-70713-JNX.vbf	Jaguar XE (X760)	TCU - Telematic Control Unit Module	DATA
J7A3-70713-JP.vbf	Jaguar XE (X760)	TCU - Telematic Control Unit Module	DATA
J7A3-70713-JPV.vbf	Jaguar XE (X760)	TCU - Telematic Control Unit Module	DATA
J7A3-70713-JR.vbf	Jaguar XE (X760)	TCU - Telematic Control Unit Module	DATA
J7A3-70713-JS.vbf	Jaguar XE (X760)	TCU - Telematic Control Unit Module	DATA
J7A3-70713-JT.vbf	Jaguar XE (X760)	TCU - Telematic Control Unit Module	DATA
J7A3-70713-JV.vbf	Jaguar XE (X760)	TCU - Telematic Control Unit Module	DATA

File name	Vehicle line (indicative)	Module (ECU)	Type
J7A3-70713-JX.vbf	Jaguar XE (X760)	TCU - Telematic Control Unit Module	DATA
J7A3-70713-JY.vbf	Jaguar XE (X760)	TCU - Telematic Control Unit Module	DATA
J7A3-70713-JZ.vbf	Jaguar XE (X760)	TCU - Telematic Control Unit Module	DATA
J7A3-70713-KAA.vbf	Jaguar XE (X760)	TCU - Telematic Control Unit Module	DATA
J7A3-70713-KD.vbf	Jaguar XE (X760)	TCU - Telematic Control Unit Module	DATA
J7A3-70713-KE.vbf	Jaguar XE (X760)	TCU - Telematic Control Unit Module	DATA
J7A3-70713-KF.vbf	Jaguar XE (X760)	TCU - Telematic Control Unit Module	DATA
J7A3-70713-KG.vbf	Jaguar XE (X760)	TCU - Telematic Control Unit Module	DATA
J7A3-70713-KH.vbf	Jaguar XE (X760)	TCU - Telematic Control Unit Module	DATA
J7A3-70713-KJ.vbf	Jaguar XE (X760)	TCU - Telematic Control Unit Module	DATA
J7A3-70713-KK.vbf	Jaguar XE (X760)	TCU - Telematic Control Unit Module	DATA
J7A3-70713-KL.vbf	Jaguar XE (X760)	TCU - Telematic Control Unit Module	CARCFG
J7A3-70713-KM.vbf	Jaguar XE (X760)	TCU - Telematic Control Unit Module	DATA
J7A3-70713-KN.vbf	Jaguar XE (X760)	TCU - Telematic Control Unit Module	DATA
J7A3-70713-KNV.vbf	Jaguar XE (X760)	TCU - Telematic Control Unit Module	DATA
J7A3-70713-KNX.vbf	Jaguar XE (X760)	TCU - Telematic Control Unit Module	DATA
J7A3-70713-KP.vbf	Jaguar XE (X760)	TCU - Telematic Control Unit Module	DATA
J7A3-70713-KPV.vbf	Jaguar XE (X760)	TCU - Telematic Control Unit Module	DATA
J7A3-70713-KR.vbf	Jaguar XE (X760)	TCU - Telematic Control Unit Module	DATA
J7A3-70713-KS.vbf	Jaguar XE (X760)	TCU - Telematic Control Unit Module	DATA
J7A3-70713-KT.vbf	Jaguar XE (X760)	TCU - Telematic Control Unit Module	DATA
J7A3-70713-KV.vbf	Jaguar XE (X760)	TCU - Telematic Control Unit Module	DATA
J7A3-70713-KX.vbf	Jaguar XE (X760)	TCU - Telematic Control Unit Module	DATA
J7A3-70713-KY.vbf	Jaguar XE (X760)	TCU - Telematic Control Unit Module	DATA
J7A3-70713-KZ.vbf	Jaguar XE (X760)	TCU - Telematic Control Unit Module	DATA
J7A3-70713-MAA.vbf	Jaguar XE (X760)	TCU - Telematic Control Unit Module	DATA
J7A3-70713-MD.vbf	Jaguar XE (X760)	TCU - Telematic Control Unit Module	DATA
J7A3-70713-ME.vbf	Jaguar XE (X760)	TCU - Telematic Control Unit Module	DATA
J7A3-70713-MF.vbf	Jaguar XE (X760)	TCU - Telematic Control Unit Module	DATA
J7A3-70713-MH.vbf	Jaguar XE (X760)	TCU - Telematic Control Unit Module	DATA
J7A3-70713-MJ.vbf	Jaguar XE (X760)	TCU - Telematic Control Unit Module	DATA
J7A3-70713-MK.vbf	Jaguar XE (X760)	TCU - Telematic Control Unit Module	DATA
J7A3-70713-ML.vbf	Jaguar XE (X760)	TCU - Telematic Control Unit Module	CARCFG
J7A3-70713-MM.vbf	Jaguar XE (X760)	TCU - Telematic Control Unit Module	DATA
J7A3-70713-MN.vbf	Jaguar XE (X760)	TCU - Telematic Control Unit Module	DATA
J7A3-70713-MNV.vbf	Jaguar XE (X760)	TCU - Telematic Control Unit Module	DATA
J7A3-70713-MNX.vbf	Jaguar XE (X760)	TCU - Telematic Control Unit Module	DATA
J7A3-70713-MP.vbf	Jaguar XE (X760)	TCU - Telematic Control Unit Module	DATA
J7A3-70713-MPV.vbf	Jaguar XE (X760)	TCU - Telematic Control Unit Module	DATA
J7A3-70713-MR.vbf	Jaguar XE (X760)	TCU - Telematic Control Unit Module	DATA
J7A3-70713-MS.vbf	Jaguar XE (X760)	TCU - Telematic Control Unit Module	DATA
J7A3-70713-MT.vbf	Jaguar XE (X760)	TCU - Telematic Control Unit Module	DATA
J7A3-70713-MV.vbf	Jaguar XE (X760)	TCU - Telematic Control Unit Module	DATA
J7A3-70713-MX.vbf	Jaguar XE (X760)	TCU - Telematic Control Unit Module	DATA
J7A3-70713-MY.vbf	Jaguar XE (X760)	TCU - Telematic Control Unit Module	DATA
J7A3-70713-MZ.vbf	Jaguar XE (X760)	TCU - Telematic Control Unit Module	DATA
J7A3-70713-NAA.vbf	Jaguar XE (X760)	TCU - Telematic Control Unit Module	DATA
J7A3-70713-NL.vbf	Jaguar XE (X760)	TCU - Telematic Control Unit Module	CARCFG
J7A3-70713-NM.vbf	Jaguar XE (X760)	TCU - Telematic Control Unit Module	DATA
J7A3-70713-NN.vbf	Jaguar XE (X760)	TCU - Telematic Control Unit Module	DATA
J7A3-70713-NNV.vbf	Jaguar XE (X760)	TCU - Telematic Control Unit Module	DATA
J7A3-70713-NNX.vbf	Jaguar XE (X760)	TCU - Telematic Control Unit Module	DATA
J7A3-70713-NP.vbf	Jaguar XE (X760)	TCU - Telematic Control Unit Module	DATA
J7A3-70713-NPV.vbf	Jaguar XE (X760)	TCU - Telematic Control Unit Module	DATA
J7A3-70713-NR.vbf	Jaguar XE (X760)	TCU - Telematic Control Unit Module	DATA
J7A3-70713-NS.vbf	Jaguar XE (X760)	TCU - Telematic Control Unit Module	DATA
J7A3-70713-NT.vbf	Jaguar XE (X760)	TCU - Telematic Control Unit Module	DATA
J7A3-70713-NV.vbf	Jaguar XE (X760)	TCU - Telematic Control Unit Module	DATA
J7A3-70713-NX.vbf	Jaguar XE (X760)	TCU - Telematic Control Unit Module	DATA
J7A3-70713-NY.vbf	Jaguar XE (X760)	TCU - Telematic Control Unit Module	DATA
J7A3-70713-NZ.vbf	Jaguar XE (X760)	TCU - Telematic Control Unit Module	DATA
J7A3-70713-SB.vbf	Jaguar XE (X760)	TCU - Telematic Control Unit Module	DATA
J7A3-70713-SC.vbf	Jaguar XE (X760)	TCU - Telematic Control Unit Module	DATA
J7A3-70713-SD.vbf	Jaguar XE (X760)	TCU - Telematic Control Unit Module	DATA
J7A3-70713-SE.vbf	Jaguar XE (X760)	TCU - Telematic Control Unit Module	DATA
J7A3-70713-SF.vbf	Jaguar XE (X760)	TCU - Telematic Control Unit Module	DATA
J7A3-70713-SG.vbf	Jaguar XE (X760)	TCU - Telematic Control Unit Module	DATA
J7A3-70713-SH.vbf	Jaguar XE (X760)	TCU - Telematic Control Unit Module	DATA
J7A3-70713-SJ.vbf	Jaguar XE (X760)	TCU - Telematic Control Unit Module	DATA
J7A3-70713-SK.vbf	Jaguar XE (X760)	TCU - Telematic Control Unit Module	DATA
J7A3-70713-SNF.vbf	Jaguar XE (X760)	TCU - Telematic Control Unit Module	DATA
J7A3-70713-SNX.vbf	Jaguar XE (X760)	TCU - Telematic Control Unit Module	DATA
J7A3-70713-SPF.vbf	Jaguar XE (X760)	TCU - Telematic Control Unit Module	DATA
J8A2-14C025-JC.vbf	Not specified	IPC - Instrument Panel Cluster (IPC) Control Module	SBL
J8A2-14C027-AB.vbf	Not specified	ACM - Audio Front Control Module	SBL
J8A2-14C028-AJ.vbf	Not specified	RCM - Restraints Control Module	EXE

File name	Vehicle line (indicative)	Module (ECU)	Type
J8A2-14C028-AK.vbf	Not specified	RCM - Restraints Control Module	EXE
J8A2-14C064-CB.vbf	Not specified	DDM - Driver Front Door Module	EXE
J8A2-14C064-CC.vbf	Not specified	DDM - Driver Front Door Module	EXE
J8A2-14C068-CB.vbf	Not specified	DRDM - Driver Rear Door Module	EXE
J8A2-14C068-CC.vbf	Not specified	DRDM - Driver Rear Door Module	EXE
J8A2-14C084-AB.vbf	Not specified	HCM - Headlamp Control Module #1	EXE
J8A2-14C084-AC.vbf	Not specified	HCM - Headlamp Control Module #1	EXE
J8A2-14C084-BB.vbf	Not specified	Not specified	EXE
J8A2-14C084-BC.vbf	Not specified	Not specified	EXE
J8A2-14C087-AA.vbf	Not specified	HCM - Headlamp Control Module #1	SBL
J8A2-14C087-AB.vbf	Not specified	HCM - Headlamp Control Module #1	SBL
J8A2-14C087-AC.vbf	Not specified	HCM - Headlamp Control Module #1	SBL
J8A2-14C087-BA.vbf	Not specified	Not specified	SBL
J8A2-14C087-BB.vbf	Not specified	Not specified	SBL
J8A2-14C087-BC.vbf	Not specified	Not specified	SBL
J8A2-14C108-CB.vbf	Not specified	PDM - Passenger Front Door Module	EXE
J8A2-14C108-CC.vbf	Not specified	PDM - Passenger Front Door Module	EXE
J8A2-14C112-CB.vbf	Not specified	PRDM - Passenger Rear Door Module	EXE
J8A2-14C112-CC.vbf	Not specified	PRDM - Passenger Rear Door Module	EXE
J8A2-14C399-AB.vbf	Not specified	HCM - Headlamp Control Module #1	SIGCFG
J8A2-14C399-BB.vbf	Not specified	Not specified	SIGCFG
J8A2-14C570-BAB.vbf	Not specified	PCM - Powertrain Control Module	EXE
J8A2-14C570-BAC.vbf	Not specified	PCM - Powertrain Control Module	EXE
J8A2-14C570-BAE.vbf	Not specified	PCM - Powertrain Control Module	EXE
J8A2-14C570-BAF.vbf	Not specified	PCM - Powertrain Control Module	EXE
J8A2-14C570-BAG.vbf	Not specified	PCM - Powertrain Control Module	EXE
J8A2-14C570-BAH.vbf	Not specified	PCM - Powertrain Control Module	EXE
J8A2-14C570-BAJ.vbf	Not specified	PCM - Powertrain Control Module	EXE
J8A2-14C570-BAK.vbf	Not specified	PCM - Powertrain Control Module	EXE
J8A2-14C570-BAL.vbf	Not specified	PCM - Powertrain Control Module	EXE
J8A2-14C570-BCE.vbf	Not specified	PCM - Powertrain Control Module	EXE
J8A2-14C570-BCF.vbf	Not specified	PCM - Powertrain Control Module	EXE
J8A2-14C570-BCH.vbf	Not specified	PCM - Powertrain Control Module	EXE
J8A2-14C570-BCJ.vbf	Not specified	PCM - Powertrain Control Module	EXE
J8A2-14C570-BCK.vbf	Not specified	PCM - Powertrain Control Module	EXE
J8A2-14C570-BEB.vbf	Not specified	PCM - Powertrain Control Module	EXE
J8A2-14C570-BEE.vbf	Not specified	PCM - Powertrain Control Module	EXE
J8A2-14C570-BEF.vbf	Not specified	PCM - Powertrain Control Module	EXE
J8A2-14C570-BEH.vbf	Not specified	PCM - Powertrain Control Module	EXE
J8A2-14C570-BEJ.vbf	Not specified	PCM - Powertrain Control Module	EXE
J8A2-14C570-BGB.vbf	Not specified	PCM - Powertrain Control Module	EXE
J8A2-14C570-BGD.vbf	Not specified	PCM - Powertrain Control Module	EXE
J8A2-14C570-BGE.vbf	Not specified	PCM - Powertrain Control Module	EXE
J8A2-14C570-BGF.vbf	Not specified	PCM - Powertrain Control Module	EXE
J8A2-14C570-BGG.vbf	Not specified	PCM - Powertrain Control Module	EXE
J8A2-14C570-BGH.vbf	Not specified	PCM - Powertrain Control Module	EXE
J8A2-14C570-BLB.vbf	Not specified	PCM - Powertrain Control Module	EXE
J8A2-14C570-BLD.vbf	Not specified	PCM - Powertrain Control Module	EXE
J8A2-14C570-BLE.vbf	Not specified	PCM - Powertrain Control Module	EXE
J8A2-14C570-BLF.vbf	Not specified	PCM - Powertrain Control Module	EXE
J8A2-14C570-BLG.vbf	Not specified	PCM - Powertrain Control Module	EXE
J8A2-14C570-BNB.vbf	Not specified	PCM - Powertrain Control Module	EXE
J8A2-14C570-BND.vbf	Not specified	PCM - Powertrain Control Module	EXE
J8A2-14C570-BNE.vbf	Not specified	PCM - Powertrain Control Module	EXE
J8A2-14C570-BNF.vbf	Not specified	PCM - Powertrain Control Module	EXE
J8A2-14C570-BTB.vbf	Not specified	PCM - Powertrain Control Module	EXE
J8A2-14C570-BTC.vbf	Not specified	PCM - Powertrain Control Module	EXE
J8A2-14C570-BTE.vbf	Not specified	PCM - Powertrain Control Module	EXE
J8A2-14C570-BTF.vbf	Not specified	PCM - Powertrain Control Module	EXE
J8A2-14C570-BTH.vbf	Not specified	PCM - Powertrain Control Module	EXE
J8A2-14C570-BTJ.vbf	Not specified	PCM - Powertrain Control Module	EXE
J8A2-14C570-BTK.vbf	Not specified	PCM - Powertrain Control Module	EXE
J8A2-14C570-BTM.vbf	Range Rover Velar (L560)	PCM - Powertrain Control Module	EXE
J8A2-14C570-BTN.vbf	Not specified	PCM - Powertrain Control Module	EXE
J8A2-14C570-BTP.vbf	Not specified	PCM - Powertrain Control Module	EXE
J8A2-14C570-BUB.vbf	Not specified	PCM - Powertrain Control Module	EXE
J8A2-14C570-BUD.vbf	Not specified	PCM - Powertrain Control Module	EXE
J8A2-14C570-BUE.vbf	Not specified	PCM - Powertrain Control Module	EXE
J8A2-14C570-BUF.vbf	Not specified	PCM - Powertrain Control Module	EXE
J8A2-14C570-BUG.vbf	Range Rover Velar (L560)	PCM - Powertrain Control Module	EXE
J8A2-14C570-BUH.vbf	Not specified	PCM - Powertrain Control Module	EXE
J8A2-14C570-BUJ.vbf	Not specified	PCM - Powertrain Control Module	EXE
J8A2-14D182-AC.vbf	Not specified	OCS - Restraints Occupant Classification System Module	EXE
J8A2-14D182-BA.vbf	Not specified	OCS - Restraints Occupant Classification System Module	EXE
J8A2-14F216-AB.vbf	Not specified	RHVAC - Rear HVAC Control Module	SIGCFG
J8A2-14F217-AC.vbf	Not specified	RHVAC - Rear HVAC Control Module	EXE

File name	Vehicle line (indicative)	Module (ECU)	Type
J8A2-14F217-AD.vbf	Not specified	RHVAC - Rear HVAC Control Module	EXE
J8A2-14F217-AE.vbf	Not specified	RHVAC - Rear HVAC Control Module	EXE
J8A2-14F229-BA.vbf	Not specified	HUD - Head Up Display	SIGCFG
J8A2-14F229-CA.vbf	Not specified	HUD - Head Up Display	SIGCFG
J8A2-14F229-DA.vbf	Not specified	HUD - Head Up Display	SIGCFG
J8A2-14F230-CA.vbf	Not specified	HUD - Head Up Display	DATA
J8A2-14F230-DA.vbf	Not specified	HUD - Head Up Display	DATA
J8A2-14F230-EA.vbf	Not specified	HUD - Head Up Display	DATA
J8A2-14F232-BA.vbf	Not specified	HUD - Head Up Display	SBL
J8A2-14F232-CA.vbf	Not specified	HUD - Head Up Display	SBL
J8A2-14F396-AB.vbf	Not specified	IPMA - Image Processing Module A	EXE
J8A2-19C204-AC.vbf	Not specified	IMC - Infotainment Master Controller	EXE
J8A2-70711-AB.vbf	Not specified	TCU - Telematic Control Unit Module	CARCFG
J8A2-70711-AC.vbf	Not specified	TCU - Telematic Control Unit Module	DATA
J8A2-70711-AD.vbf	Not specified	TCU - Telematic Control Unit Module	DATA
J8A2-70711-AE.vbf	Jaguar XE (X760)	TCU - Telematic Control Unit Module	DATA
J8A2-70711-AF.vbf	Not specified	TCU - Telematic Control Unit Module	DATA
J8A2-70711-AG.vbf	Not specified	TCU - Telematic Control Unit Module	DATA
J8A2-70712-AAA.vbf	Not specified	TCU - Telematic Control Unit Module	DATA
J8A2-70712-AD.vbf	Not specified	TCU - Telematic Control Unit Module	DATA
J8A2-70712-AE.vbf	Not specified	TCU - Telematic Control Unit Module	DATA
J8A2-70712-AF.vbf	Not specified	TCU - Telematic Control Unit Module	DATA
J8A2-70712-AG.vbf	Not specified	TCU - Telematic Control Unit Module	DATA
J8A2-70712-AH.vbf	Not specified	TCU - Telematic Control Unit Module	DATA
J8A2-70712-AJ.vbf	Not specified	TCU - Telematic Control Unit Module	DATA
J8A2-70712-AK.vbf	Not specified	TCU - Telematic Control Unit Module	DATA
J8A2-70712-AL.vbf	Jaguar XE (X760)	TCU - Telematic Control Unit Module	DATA
J8A2-70712-AM.vbf	Not specified	TCU - Telematic Control Unit Module	DATA
J8A2-70712-AN.vbf	Not specified	TCU - Telematic Control Unit Module	DATA
J8A2-70712-ANV.vbf	Not specified	TCU - Telematic Control Unit Module	DATA
J8A2-70712-ANX.vbf	Not specified	TCU - Telematic Control Unit Module	DATA
J8A2-70712-AP.vbf	Not specified	TCU - Telematic Control Unit Module	DATA
J8A2-70712-APV.vbf	Not specified	TCU - Telematic Control Unit Module	DATA
J8A2-70712-AR.vbf	Not specified	TCU - Telematic Control Unit Module	DATA
J8A2-70712-AS.vbf	Not specified	TCU - Telematic Control Unit Module	DATA
J8A2-70712-AT.vbf	Not specified	TCU - Telematic Control Unit Module	DATA
J8A2-70712-AV.vbf	Not specified	TCU - Telematic Control Unit Module	DATA
J8A2-70712-AX.vbf	Not specified	TCU - Telematic Control Unit Module	DATA
J8A2-70712-AY.vbf	Not specified	TCU - Telematic Control Unit Module	DATA
J8A2-70712-AZ.vbf	Not specified	TCU - Telematic Control Unit Module	DATA
J8A2-70712-BAA.vbf	Not specified	TCU - Telematic Control Unit Module	DATA
J8A2-70712-BD.vbf	Not specified	TCU - Telematic Control Unit Module	DATA
J8A2-70712-BE.vbf	Not specified	TCU - Telematic Control Unit Module	DATA
J8A2-70712-BF.vbf	Not specified	TCU - Telematic Control Unit Module	DATA
J8A2-70712-BG.vbf	Not specified	TCU - Telematic Control Unit Module	DATA
J8A2-70712-BH.vbf	Not specified	TCU - Telematic Control Unit Module	DATA
J8A2-70712-BJ.vbf	Not specified	TCU - Telematic Control Unit Module	DATA
J8A2-70712-BK.vbf	Not specified	TCU - Telematic Control Unit Module	DATA
J8A2-70712-BL.vbf	Jaguar XE (X760)	TCU - Telematic Control Unit Module	DATA
J8A2-70712-BM.vbf	Not specified	TCU - Telematic Control Unit Module	DATA
J8A2-70712-BN.vbf	Not specified	TCU - Telematic Control Unit Module	DATA
J8A2-70712-BNV.vbf	Not specified	TCU - Telematic Control Unit Module	DATA
J8A2-70712-BNX.vbf	Not specified	TCU - Telematic Control Unit Module	DATA
J8A2-70712-BP.vbf	Not specified	TCU - Telematic Control Unit Module	DATA
J8A2-70712-BPV.vbf	Not specified	TCU - Telematic Control Unit Module	DATA
J8A2-70712-BR.vbf	Not specified	TCU - Telematic Control Unit Module	DATA
J8A2-70712-BS.vbf	Not specified	TCU - Telematic Control Unit Module	DATA
J8A2-70712-BT.vbf	Not specified	TCU - Telematic Control Unit Module	DATA
J8A2-70712-BV.vbf	Not specified	TCU - Telematic Control Unit Module	DATA
J8A2-70712-BX.vbf	Not specified	TCU - Telematic Control Unit Module	DATA
J8A2-70712-BY.vbf	Not specified	TCU - Telematic Control Unit Module	DATA
J8A2-70712-BZ.vbf	Not specified	TCU - Telematic Control Unit Module	DATA
J8A2-70712-CD.vbf	Not specified	TCU - Telematic Control Unit Module	DATA
J8A2-70712-CE.vbf	Not specified	TCU - Telematic Control Unit Module	DATA
J8A2-70712-CF.vbf	Not specified	TCU - Telematic Control Unit Module	DATA
J8A2-70712-CG.vbf	Not specified	TCU - Telematic Control Unit Module	DATA
J8A2-70712-CH.vbf	Not specified	TCU - Telematic Control Unit Module	DATA
J8A2-70712-CJ.vbf	Not specified	TCU - Telematic Control Unit Module	DATA
J8A2-70712-CK.vbf	Not specified	TCU - Telematic Control Unit Module	DATA
J8A2-70712-CL.vbf	Jaguar XE (X760)	TCU - Telematic Control Unit Module	DATA
J8A2-70712-CM.vbf	Jaguar XE (X760)	TCU - Telematic Control Unit Module	DATA
J8A2-70712-CN.vbf	Not specified	TCU - Telematic Control Unit Module	DATA
J8A2-70712-CNV.vbf	Not specified	TCU - Telematic Control Unit Module	DATA
J8A2-70712-CNX.vbf	Not specified	TCU - Telematic Control Unit Module	DATA
J8A2-70712-CP.vbf	Not specified	TCU - Telematic Control Unit Module	DATA
J8A2-70712-CPV.vbf	Not specified	TCU - Telematic Control Unit Module	DATA

File name	Vehicle line (indicative)	Module (ECU)	Type
J8A2-70712-CR.vbf	Not specified	TCU - Telematic Control Unit Module	DATA
J8A2-70712-CS.vbf	Not specified	TCU - Telematic Control Unit Module	DATA
J8A2-70712-CT.vbf	Not specified	TCU - Telematic Control Unit Module	DATA
J8A2-70712-CV.vbf	Not specified	TCU - Telematic Control Unit Module	DATA
J8A2-70712-CX.vbf	Not specified	TCU - Telematic Control Unit Module	DATA
J8A2-70712-CY.vbf	Not specified	TCU - Telematic Control Unit Module	DATA
J8A2-70712-CZ.vbf	Not specified	TCU - Telematic Control Unit Module	DATA
J8A2-70712-DD.vbf	Not specified	TCU - Telematic Control Unit Module	DATA
J8A2-70712-DE.vbf	Not specified	TCU - Telematic Control Unit Module	DATA
J8A2-70712-DF.vbf	Not specified	TCU - Telematic Control Unit Module	DATA
J8A2-70712-DG.vbf	Not specified	TCU - Telematic Control Unit Module	DATA
J8A2-70712-DH.vbf	Not specified	TCU - Telematic Control Unit Module	DATA
J8A2-70712-DJ.vbf	Not specified	TCU - Telematic Control Unit Module	DATA
J8A2-70712-DK.vbf	Not specified	TCU - Telematic Control Unit Module	DATA
J8A2-70712-DL.vbf	Jaguar XE (X760)	TCU - Telematic Control Unit Module	DATA
J8A2-70712-DM.vbf	Jaguar XE (X760)	TCU - Telematic Control Unit Module	DATA
J8A2-70712-DN.vbf	Not specified	TCU - Telematic Control Unit Module	DATA
J8A2-70712-DNV.vbf	Not specified	TCU - Telematic Control Unit Module	DATA
J8A2-70712-DNX.vbf	Not specified	TCU - Telematic Control Unit Module	DATA
J8A2-70712-DP.vbf	Not specified	TCU - Telematic Control Unit Module	DATA
J8A2-70712-DPV.vbf	Not specified	TCU - Telematic Control Unit Module	DATA
J8A2-70712-DR.vbf	Not specified	TCU - Telematic Control Unit Module	DATA
J8A2-70712-DS.vbf	Not specified	TCU - Telematic Control Unit Module	DATA
J8A2-70712-DT.vbf	Not specified	TCU - Telematic Control Unit Module	DATA
J8A2-70712-DV.vbf	Not specified	TCU - Telematic Control Unit Module	DATA
J8A2-70712-DX.vbf	Not specified	TCU - Telematic Control Unit Module	DATA
J8A2-70712-DY.vbf	Not specified	TCU - Telematic Control Unit Module	DATA
J8A2-70712-DZ.vbf	Not specified	TCU - Telematic Control Unit Module	DATA
J8A2-70712-ED.vbf	Not specified	TCU - Telematic Control Unit Module	DATA
J8A2-70712-EE.vbf	Not specified	TCU - Telematic Control Unit Module	DATA
J8A2-70712-EF.vbf	Not specified	TCU - Telematic Control Unit Module	DATA
J8A2-70712-EG.vbf	Not specified	TCU - Telematic Control Unit Module	DATA
J8A2-70712-EH.vbf	Not specified	TCU - Telematic Control Unit Module	DATA
J8A2-70712-EJ.vbf	Not specified	TCU - Telematic Control Unit Module	DATA
J8A2-70712-EK.vbf	Not specified	TCU - Telematic Control Unit Module	DATA
J8A2-70712-EL.vbf	Jaguar XE (X760)	TCU - Telematic Control Unit Module	DATA
J8A2-70712-EM.vbf	Jaguar XE (X760)	TCU - Telematic Control Unit Module	DATA
J8A2-70712-EN.vbf	Not specified	TCU - Telematic Control Unit Module	DATA
J8A2-70712-ENV.vbf	Not specified	TCU - Telematic Control Unit Module	DATA
J8A2-70712-ENX.vbf	Not specified	TCU - Telematic Control Unit Module	DATA
J8A2-70712-EP.vbf	Not specified	TCU - Telematic Control Unit Module	DATA
J8A2-70712-EPV.vbf	Not specified	TCU - Telematic Control Unit Module	DATA
J8A2-70712-ER.vbf	Not specified	TCU - Telematic Control Unit Module	DATA
J8A2-70712-ES.vbf	Not specified	TCU - Telematic Control Unit Module	DATA
J8A2-70712-ET.vbf	Not specified	TCU - Telematic Control Unit Module	DATA
J8A2-70712-EV.vbf	Not specified	TCU - Telematic Control Unit Module	DATA
J8A2-70712-EX.vbf	Not specified	TCU - Telematic Control Unit Module	DATA
J8A2-70712-EY.vbf	Not specified	TCU - Telematic Control Unit Module	DATA
J8A2-70712-EZ.vbf	Not specified	TCU - Telematic Control Unit Module	DATA
J8A2-70712-FD.vbf	Not specified	TCU - Telematic Control Unit Module	DATA
J8A2-70712-FE.vbf	Not specified	TCU - Telematic Control Unit Module	DATA
J8A2-70712-FF.vbf	Not specified	TCU - Telematic Control Unit Module	DATA
J8A2-70712-FG.vbf	Not specified	TCU - Telematic Control Unit Module	DATA
J8A2-70712-FH.vbf	Not specified	TCU - Telematic Control Unit Module	DATA
J8A2-70712-FJ.vbf	Not specified	TCU - Telematic Control Unit Module	DATA
J8A2-70712-FK.vbf	Not specified	TCU - Telematic Control Unit Module	DATA
J8A2-70712-FL.vbf	Jaguar XE (X760)	TCU - Telematic Control Unit Module	DATA
J8A2-70712-FM.vbf	Not specified	TCU - Telematic Control Unit Module	DATA
J8A2-70712-FN.vbf	Not specified	TCU - Telematic Control Unit Module	DATA
J8A2-70712-FNV.vbf	Not specified	TCU - Telematic Control Unit Module	DATA
J8A2-70712-FNX.vbf	Not specified	TCU - Telematic Control Unit Module	DATA
J8A2-70712-FP.vbf	Not specified	TCU - Telematic Control Unit Module	DATA
J8A2-70712-FPV.vbf	Not specified	TCU - Telematic Control Unit Module	DATA
J8A2-70712-FR.vbf	Not specified	TCU - Telematic Control Unit Module	DATA
J8A2-70712-FS.vbf	Not specified	TCU - Telematic Control Unit Module	DATA
J8A2-70712-FT.vbf	Not specified	TCU - Telematic Control Unit Module	DATA
J8A2-70712-FV.vbf	Not specified	TCU - Telematic Control Unit Module	DATA
J8A2-70712-FX.vbf	Not specified	TCU - Telematic Control Unit Module	DATA
J8A2-70712-FY.vbf	Not specified	TCU - Telematic Control Unit Module	DATA
J8A2-70712-GB.vbf	Not specified	TCU - Telematic Control Unit Module	DATA
J8A2-70712-GC.vbf	Not specified	TCU - Telematic Control Unit Module	DATA
J8A2-70712-GD.vbf	Not specified	TCU - Telematic Control Unit Module	DATA
J8A2-70712-GE.vbf	Not specified	TCU - Telematic Control Unit Module	DATA
J8A2-70712-GF.vbf	Not specified	TCU - Telematic Control Unit Module	DATA
J8A2-70712-GG.vbf	Not specified	TCU - Telematic Control Unit Module	DATA
J8A2-70712-GH.vbf	Not specified	TCU - Telematic Control Unit Module	DATA

File name	Vehicle line (indicative)	Module (ECU)	Type
J8A2-70712-GJ.vbf	Jaguar XE (X760)	TCU - Telematic Control Unit Module	DATA
J8A2-70712-GK.vbf	Jaguar XE (X760)	TCU - Telematic Control Unit Module	DATA
J8A2-70712-GNK.vbf	Jaguar XE (X760)	TCU - Telematic Control Unit Module	DATA
J8A2-70712-GNX.vbf	Jaguar XE (X760)	TCU - Telematic Control Unit Module	DATA
J8A2-70712-GPK.vbf	Jaguar XE (X760)	TCU - Telematic Control Unit Module	DATA
J8A2-70714-AD.vbf	Not specified	TCU - Telematic Control Unit Module	SBL
J9A3-14C065-AC.vbf	Check in SDD (unconfirmed)	DDM - Driver Front Door Module	DATA
J9A3-14C065-AF.vbf	Jaguar XF (X260)	DDM - Driver Front Door Module	DATA
J9A3-14C065-AG.vbf	Jaguar XF (X260)	DDM - Driver Front Door Module	DATA
J9A3-14C065-AH.vbf	Jaguar XF (X260)	DDM - Driver Front Door Module	DATA
J9A3-14C069-AC.vbf	Check in SDD (unconfirmed)	DRDM - Driver Rear Door Module	DATA
J9A3-14C069-AF.vbf	Jaguar XF (X260)	DRDM - Driver Rear Door Module	DATA
J9A3-14C069-AG.vbf	Jaguar XF (X260)	DRDM - Driver Rear Door Module	DATA
J9A3-14C069-AH.vbf	Jaguar XF (X260)	DRDM - Driver Rear Door Module	DATA
J9A3-14C109-AC.vbf	Check in SDD (unconfirmed)	PDM - Passenger Front Door Module	DATA
J9A3-14C109-AF.vbf	Jaguar XF (X260)	PDM - Passenger Front Door Module	DATA
J9A3-14C109-AG.vbf	Jaguar XF (X260)	PDM - Passenger Front Door Module	DATA
J9A3-14C109-AH.vbf	Jaguar XF (X260)	PDM - Passenger Front Door Module	DATA
J9A3-14C113-AC.vbf	Check in SDD (unconfirmed)	PRDM - Passenger Rear Door Module	DATA
J9A3-14C113-AF.vbf	Jaguar XF (X260)	PRDM - Passenger Rear Door Module	DATA
J9A3-14C113-AG.vbf	Jaguar XF (X260)	PRDM - Passenger Rear Door Module	DATA
J9A3-14C113-AH.vbf	Jaguar XF (X260)	PRDM - Passenger Rear Door Module	DATA
J9A3-14C527-CAB.vbf	Not specified	AAM - Audio Amplifier Module	DATA
J9A3-14C527-CB.vbf	Not specified	AAM - Audio Amplifier Module	DATA
J9A3-14C527-CBB.vbf	Not specified	AAM - Audio Amplifier Module	DATA
J9A3-14C527-CBC.vbf	Not specified	AAM - Audio Amplifier Module	DATA
J9A3-14D481-BA.vbf	Not specified	IPMB - Image Processing Module B	DATA
J9A3-14D485-AA.vbf	Not specified	IPMB - Image Processing Module B	EXE
J9A3-14D485-AC.vbf	Not specified	IPMB - Image Processing Module B	EXE
J9A3-14D485-AE.vbf	Not specified	IPMB - Image Processing Module B	EXE
J9A3-14D485-AF.vbf	Not specified	IPMB - Image Processing Module B	EXE
J9A3-14D485-AG.vbf	Not specified	IPMB - Image Processing Module B	EXE
J9A3-14D485-BA.vbf	Not specified	IPMB - Image Processing Module B	DATA
J9A3-14D564-AB.vbf	Not specified	SODL - Side Obstacle Detection Control Module - Left	DATA
J9A3-14D564-AC.vbf	Not specified	SODL - Side Obstacle Detection Control Module - Left	DATA
J9A3-14D564-AD.vbf	Not specified	SODL - Side Obstacle Detection Control Module - Left	DATA
J9A3-14D564-BB.vbf	Not specified	SODR - Side Obstacle Detection Control Module - Right	DATA
J9A3-14D564-BC.vbf	Not specified	SODR - Side Obstacle Detection Control Module - Right	DATA
J9A3-14D564-BD.vbf	Not specified	SODR - Side Obstacle Detection Control Module - Right	DATA
J9A3-14F022-AE.vbf	Not specified	IPMB - Image Processing Module B	DATA
J9A3-14F022-AF.vbf	Not specified	IPMB - Image Processing Module B	DATA
J9A3-14F022-AG.vbf	Not specified	IPMB - Image Processing Module B	DATA
J9A3-14F022-BE.vbf	Not specified	IPMB - Image Processing Module B	DATA
J9A3-14F022-BF.vbf	Not specified	IPMB - Image Processing Module B	DATA
J9A3-14F022-BG.vbf	Not specified	IPMB - Image Processing Module B	DATA
J9A3-14F216-AA.vbf	Not specified	RHVAC - Rear HVAC Control Module	SIGCFG
J9A3-14F217-AA.vbf	Not specified	RHVAC - Rear HVAC Control Module	EXE
J9A3-14F218-AA.vbf	Not specified	RHVAC - Rear HVAC Control Module	DATA
J9C3-14C109-BD.vbf	Jaguar E-Pace (X540)	PDM - Passenger Front Door Module	DATA
J9C3-14C109-BE.vbf	Jaguar E-Pace (X540)	PDM - Passenger Front Door Module	DATA
J9C3-14C109-BF.vbf	Jaguar E-Pace (X540)	PDM - Passenger Front Door Module	DATA
J9C3-14C113-BD.vbf	Jaguar E-Pace (X540)	PRDM - Passenger Rear Door Module	DATA
J9C3-14C113-BE.vbf	Jaguar E-Pace (X540)	PRDM - Passenger Rear Door Module	DATA
J9C3-14C113-BF.vbf	Jaguar E-Pace (X540)	PRDM - Passenger Rear Door Module	DATA
J9C3-14C570-BAD.vbf	Check in SDD (unconfirmed)	PCM - Powertrain Control Module	EXE
J9C3-14C570-BAF.vbf	Check in SDD (unconfirmed)	PCM - Powertrain Control Module	EXE
J9C3-14C570-BAH.vbf	Check in SDD (unconfirmed)	PCM - Powertrain Control Module	EXE
J9C3-14C570-BAJ.vbf	Check in SDD (unconfirmed)	PCM - Powertrain Control Module	EXE
J9C3-14C570-BAK.vbf	Check in SDD (unconfirmed)	PCM - Powertrain Control Module	EXE
J9C3-14C570-BAL.vbf	Check in SDD (unconfirmed)	PCM - Powertrain Control Module	EXE
J9C3-14C570-BAM.vbf	Check in SDD (unconfirmed)	PCM - Powertrain Control Module	EXE
J9C3-14C570-BAN.vbf	Check in SDD (unconfirmed)	PCM - Powertrain Control Module	EXE
J9C3-14C570-BTD.vbf	Check in SDD (unconfirmed)	PCM - Powertrain Control Module	EXE
J9C3-14C570-BTF.vbf	Check in SDD (unconfirmed)	PCM - Powertrain Control Module	EXE
J9C3-14C570-BTH.vbf	Check in SDD (unconfirmed)	PCM - Powertrain Control Module	EXE
J9C3-14C570-BTJ.vbf	Check in SDD (unconfirmed)	PCM - Powertrain Control Module	EXE
J9C3-14C570-BTK.vbf	Check in SDD (unconfirmed)	PCM - Powertrain Control Module	EXE
J9C3-14C570-BTM.vbf	Check in SDD (unconfirmed)	PCM - Powertrain Control Module	EXE
J9C3-14C570-BTR.vbf	Check in SDD (unconfirmed)	PCM - Powertrain Control Module	EXE
J9C3-14D367-AA.vbf	Check in SDD (unconfirmed)	SODL - Side Obstacle Detection Control Module - Left	SIGCFG
J9C3-14D367-BA.vbf	Check in SDD (unconfirmed)	SODR - Side Obstacle Detection Control Module - Right	SIGCFG
J9C3-14D368-AC.vbf	Check in SDD (unconfirmed)	SODL - Side Obstacle Detection Control Module - Left	EXE
J9C3-14D368-AD.vbf	Check in SDD (unconfirmed)	SODL - Side Obstacle Detection Control Module - Left	EXE
J9C3-14D368-AE.vbf	Check in SDD (unconfirmed)	SODL - Side Obstacle Detection Control Module - Left	EXE
J9C3-14D368-AF.vbf	Check in SDD (unconfirmed)	SODL - Side Obstacle Detection Control Module - Left	EXE
J9C3-14D368-AG.vbf	Check in SDD (unconfirmed)	SODL - Side Obstacle Detection Control Module - Left	EXE

File name	Vehicle line (indicative)	Module (ECU)	Type
J9C3-14D368-AH.vbf	Check in SDD (unconfirmed)	SODL - Side Obstacle Detection Control Module - Left	EXE
J9C3-14D368-BC.vbf	Check in SDD (unconfirmed)	SODL - Side Obstacle Detection Control Module - Left	EXE
J9C3-14D368-BD.vbf	Check in SDD (unconfirmed)	SODL - Side Obstacle Detection Control Module - Left	EXE
J9C3-14D368-BE.vbf	Check in SDD (unconfirmed)	SODL - Side Obstacle Detection Control Module - Left	EXE
J9C3-14D368-BF.vbf	Check in SDD (unconfirmed)	SODL - Side Obstacle Detection Control Module - Left	EXE
J9C3-14D368-BG.vbf	Check in SDD (unconfirmed)	SODL - Side Obstacle Detection Control Module - Left	EXE
J9C3-14D368-BH.vbf	Check in SDD (unconfirmed)	SODL - Side Obstacle Detection Control Module - Left	EXE
J9C3-14D370-AB.vbf	Check in SDD (unconfirmed)	SODL - Side Obstacle Detection Control Module - Left	SBL
J9C3-14D370-AC.vbf	Check in SDD (unconfirmed)	SODL - Side Obstacle Detection Control Module - Left	SBL
J9C3-14F396-AB.vbf	Check in SDD (unconfirmed)	IPMA - Image Processing Module A	EXE
J9C3-14F397-AB.vbf	Check in SDD (unconfirmed)	IPMA - Image Processing Module A	EXE
J9C3-14F397-BB.vbf	Check in SDD (unconfirmed)	IPMA - Image Processing Module A	EXE
J9C3-14F397-CB.vbf	Check in SDD (unconfirmed)	IPMA - Image Processing Module A	EXE
J9C3-14F397-DB.vbf	Check in SDD (unconfirmed)	IPMA - Image Processing Module A	EXE
J9C3-19D111-AE.vbf	Check in SDD (unconfirmed)	CTCM - Coolant Temperature Control Module	SIGCFG
J9C3-19D112-AF.vbf	Check in SDD (unconfirmed)	CTCM - Coolant Temperature Control Module	EXE
J9C3-19D112-AG.vbf	Check in SDD (unconfirmed)	CTCM - Coolant Temperature Control Module	EXE
J9C3-19D112-AJ.vbf	Check in SDD (unconfirmed)	CTCM - Coolant Temperature Control Module	EXE
J9C3-19D112-AK.vbf	Check in SDD (unconfirmed)	CTCM - Coolant Temperature Control Module	EXE
J9C3-19D113-AF.vbf	Check in SDD (unconfirmed)	CTCM - Coolant Temperature Control Module	DATA
J9C3-19D113-AG.vbf	Check in SDD (unconfirmed)	CTCM - Coolant Temperature Control Module	DATA
J9C3-19D113-AJ.vbf	Check in SDD (unconfirmed)	CTCM - Coolant Temperature Control Module	DATA
J9C3-19D114-AC.vbf	Check in SDD (unconfirmed)	CTCM - Coolant Temperature Control Module	SBL
J9C3-19D114-AD.vbf	Check in SDD (unconfirmed)	CTCM - Coolant Temperature Control Module	SBL
J9C3-70711-AB.vbf	Check in SDD (unconfirmed)	TCU - Telematic Control Unit Module	DATA
J9C3-70711-AC.vbf	Check in SDD (unconfirmed)	TCU - Telematic Control Unit Module	DATA
J9C3-70711-AD.vbf	Jaguar XE (X760)	TCU - Telematic Control Unit Module	DATA
J9C3-70712-AAA.vbf	Check in SDD (unconfirmed)	TCU - Telematic Control Unit Module	DATA
J9C3-70712-AC.vbf	Check in SDD (unconfirmed)	TCU - Telematic Control Unit Module	DATA
J9C3-70712-AD.vbf	Check in SDD (unconfirmed)	TCU - Telematic Control Unit Module	DATA
J9C3-70712-AE.vbf	Check in SDD (unconfirmed)	TCU - Telematic Control Unit Module	DATA
J9C3-70712-AF.vbf	Check in SDD (unconfirmed)	TCU - Telematic Control Unit Module	DATA
J9C3-70712-AG.vbf	Check in SDD (unconfirmed)	TCU - Telematic Control Unit Module	DATA
J9C3-70712-AH.vbf	Check in SDD (unconfirmed)	TCU - Telematic Control Unit Module	DATA
J9C3-70712-AJ.vbf	Check in SDD (unconfirmed)	TCU - Telematic Control Unit Module	DATA
J9C3-70712-AK.vbf	Jaguar XE (X760)	TCU - Telematic Control Unit Module	DATA
J9C3-70712-AL.vbf	Check in SDD (unconfirmed)	TCU - Telematic Control Unit Module	DATA
J9C3-70712-AN.vbf	Check in SDD (unconfirmed)	TCU - Telematic Control Unit Module	DATA
J9C3-70712-ANV.vbf	Check in SDD (unconfirmed)	TCU - Telematic Control Unit Module	DATA
J9C3-70712-ANX.vbf	Check in SDD (unconfirmed)	TCU - Telematic Control Unit Module	DATA
J9C3-70712-AP.vbf	Check in SDD (unconfirmed)	TCU - Telematic Control Unit Module	DATA
J9C3-70712-APV.vbf	Check in SDD (unconfirmed)	TCU - Telematic Control Unit Module	DATA
J9C3-70712-AR.vbf	Check in SDD (unconfirmed)	TCU - Telematic Control Unit Module	DATA
J9C3-70712-AS.vbf	Check in SDD (unconfirmed)	TCU - Telematic Control Unit Module	DATA
J9C3-70712-AT.vbf	Check in SDD (unconfirmed)	TCU - Telematic Control Unit Module	DATA
J9C3-70712-AV.vbf	Check in SDD (unconfirmed)	TCU - Telematic Control Unit Module	DATA
J9C3-70712-AX.vbf	Check in SDD (unconfirmed)	TCU - Telematic Control Unit Module	DATA
J9C3-70712-AY.vbf	Check in SDD (unconfirmed)	TCU - Telematic Control Unit Module	DATA
J9C3-70712-AZ.vbf	Check in SDD (unconfirmed)	TCU - Telematic Control Unit Module	DATA
J9D3-14C025-JA.vbf	Not specified	IPC - Instrument Panel Cluster (IPC) Control Module	SBL
J9D3-14C093-AC.vbf	Not specified	PAM - Parking Assist Control Module	SBL
J9D3-14C309-AC.vbf	Not specified	SASM - Steering Angle Sensor Module	EXE
J9D3-14C311-AA.vbf	Not specified	SASM - Steering Angle Sensor Module	SBL
J9D3-14F230-BA.vbf	Not specified	HUD - Head Up Display	DATA
J9D3-14F230-CA.vbf	Not specified	HUD - Head Up Display	DATA
J9D3-18D619-BB.vbf	Not specified	HVAC - HVAC Control Module	EXE
J9D3-18D619-DC.vbf	Not specified	HVAC - HVAC Control Module	EXE
J9D3-19C204-AA.vbf	Not specified	IMC - Infotainment Master Controller	EXE
J9D3-19C204-AB.vbf	Not specified	IMC - Infotainment Master Controller	EXE
J9D3-19D111-AC.vbf	Not specified	CTCM - Coolant Temperature Control Module	SIGCFG
J9D3-19D112-AH.vbf	Not specified	CTCM - Coolant Temperature Control Module	EXE
J9D3-19D112-AJ.vbf	Not specified	CTCM - Coolant Temperature Control Module	EXE
J9D3-19D112-AK.vbf	Not specified	CTCM - Coolant Temperature Control Module	EXE
J9D3-19D112-AL.vbf	Not specified	CTCM - Coolant Temperature Control Module	EXE
J9D3-19D112-AM.vbf	Not specified	CTCM - Coolant Temperature Control Module	EXE
J9D3-19D113-AD.vbf	Not specified	CTCM - Coolant Temperature Control Module	DATA
J9W3-14C065-AB.vbf	Jaguar XE (X760)	DDM - Driver Front Door Module	DATA
J9W3-14C065-AD.vbf	Jaguar XE (X760)	DDM - Driver Front Door Module	DATA
J9W3-14C065-AE.vbf	Jaguar XE (X760)	DDM - Driver Front Door Module	DATA
J9W3-14C065-AF.vbf	Jaguar XE (X760)	DDM - Driver Front Door Module	DATA
J9W3-14C065-AG.vbf	Jaguar XE (X760)	DDM - Driver Front Door Module	DATA
J9W3-14C069-AB.vbf	Jaguar XE (X760)	DRDM - Driver Rear Door Module	DATA
J9W3-14C069-AD.vbf	Jaguar XE (X760)	DRDM - Driver Rear Door Module	DATA
J9W3-14C069-AE.vbf	Jaguar XE (X760)	DRDM - Driver Rear Door Module	DATA
J9W3-14C069-AF.vbf	Jaguar XE (X760)	DRDM - Driver Rear Door Module	DATA
J9W3-14C069-AG.vbf	Jaguar XE (X760)	DRDM - Driver Rear Door Module	DATA

File name	Vehicle line (indicative)	Module (ECU)	Type
J9W3-14C109-AB.vbf	Jaguar XE (X760)	PDM - Passenger Front Door Module	DATA
J9W3-14C109-AD.vbf	Jaguar XE (X760)	PDM - Passenger Front Door Module	DATA
J9W3-14C109-AE.vbf	Jaguar XE (X760)	PDM - Passenger Front Door Module	DATA
J9W3-14C109-AF.vbf	Jaguar XE (X760)	PDM - Passenger Front Door Module	DATA
J9W3-14C109-AG.vbf	Jaguar XE (X760)	PDM - Passenger Front Door Module	DATA
J9W3-14C113-AB.vbf	Jaguar XE (X760)	PRDM - Passenger Rear Door Module	DATA
J9W3-14C113-AD.vbf	Jaguar XE (X760)	PRDM - Passenger Rear Door Module	DATA
J9W3-14C113-AE.vbf	Jaguar XE (X760)	PRDM - Passenger Rear Door Module	DATA
J9W3-14C113-AF.vbf	Jaguar XE (X760)	PRDM - Passenger Rear Door Module	DATA
J9W3-14C113-AG.vbf	Jaguar XE (X760)	PRDM - Passenger Rear Door Module	DATA
J9W3-14D564-AA.vbf	Jaguar XE (X760)	SODL - Side Obstacle Detection Control Module - Left	DATA
J9W3-14D564-AB.vbf	Jaguar XE (X760)	SODL - Side Obstacle Detection Control Module - Left	DATA
J9W3-14D564-AC.vbf	Jaguar XE (X760)	SODL - Side Obstacle Detection Control Module - Left	DATA
J9W3-14D564-BA.vbf	Jaguar XE (X760)	SODR - Side Obstacle Detection Control Module - Right	DATA
J9W3-14D564-BB.vbf	Jaguar XE (X760)	SODR - Side Obstacle Detection Control Module - Right	DATA
J9W3-14D564-BC.vbf	Jaguar XE (X760)	SODR - Side Obstacle Detection Control Module - Right	DATA
JCH2-14D564-AA.vbf	Range Rover Evoque (L538)	SODL - Side Obstacle Detection Control Module - Left	DATA
JCH2-14D564-BA.vbf	Range Rover Evoque (L538)	SODR - Side Obstacle Detection Control Module - Right	DATA
JJ32-12K532-FBC.vbf	Range Rover Evoque (L538)	PCM - Powertrain Control Module	DATA
JJ32-12K532-FBE.vbf	Range Rover Evoque (L538)	PCM - Powertrain Control Module	DATA
JJ32-12K532-FBF.vbf	Range Rover Evoque (L538)	PCM - Powertrain Control Module	DATA
JJ32-12K532-FBG.vbf	Range Rover Evoque (L538)	PCM - Powertrain Control Module	DATA
JJ32-12K532-FBH.vbf	Range Rover Evoque (L538)	PCM - Powertrain Control Module	DATA
JJ32-12K532-FBJ.vbf	Range Rover Evoque (L538)	PCM - Powertrain Control Module	DATA
JJ32-12K532-GAC.vbf	Range Rover Evoque (L538)	PCM - Powertrain Control Module	DATA
JJ32-12K532-GAE.vbf	Range Rover Evoque (L538)	PCM - Powertrain Control Module	DATA
JJ32-12K532-GAF.vbf	Range Rover Evoque (L538)	PCM - Powertrain Control Module	DATA
JJ32-12K532-GAG.vbf	Range Rover Evoque (L538)	PCM - Powertrain Control Module	DATA
JJ32-12K532-GBA.vbf	Range Rover Evoque (L538)	PCM - Powertrain Control Module	DATA
JJ32-12K532-GBC.vbf	Range Rover Evoque (L538)	PCM - Powertrain Control Module	DATA
JJ32-12K532-GBE.vbf	Range Rover Evoque (L538)	PCM - Powertrain Control Module	DATA
JJ32-12K532-GBF.vbf	Range Rover Evoque (L538)	PCM - Powertrain Control Module	DATA
JJ32-12K532-GCA.vbf	Range Rover Evoque (L538)	PCM - Powertrain Control Module	DATA
JJ32-12K532-GCC.vbf	Range Rover Evoque (L538)	PCM - Powertrain Control Module	DATA
JJ32-12K532-GCE.vbf	Range Rover Evoque (L538)	PCM - Powertrain Control Module	DATA
JJ32-12K532-GCG.vbf	Range Rover Evoque (L538)	PCM - Powertrain Control Module	DATA
JJ32-12K532-GCH.vbf	Range Rover Evoque (L538)	PCM - Powertrain Control Module	DATA
JJ32-12K532-GDC.vbf	Range Rover Evoque (L538)	PCM - Powertrain Control Module	DATA
JJ32-12K532-GDE.vbf	Range Rover Evoque (L538)	PCM - Powertrain Control Module	DATA
JJ32-12K532-GDF.vbf	Range Rover Evoque (L538)	PCM - Powertrain Control Module	DATA
JJ32-12K532-GEC.vbf	Range Rover Evoque (L538)	PCM - Powertrain Control Module	DATA
JJ32-12K532-GFC.vbf	Range Rover Evoque (L538)	PCM - Powertrain Control Module	DATA
JJ32-12K532-GGA.vbf	Range Rover Evoque (L538)	PCM - Powertrain Control Module	DATA
JJ32-12K532-GGC.vbf	Range Rover Evoque (L538)	PCM - Powertrain Control Module	DATA
JJ32-12K532-GGD.vbf	Range Rover Evoque (L538)	PCM - Powertrain Control Module	DATA
JJ32-12K532-GJC.vbf	Range Rover Evoque (L538)	PCM - Powertrain Control Module	DATA
JJ32-12K532-GJD.vbf	Range Rover Evoque (L538)	PCM - Powertrain Control Module	DATA
JJ32-12K532-GLA.vbf	Range Rover Evoque (L538)	PCM - Powertrain Control Module	DATA
JJ32-12K532-GLC.vbf	Range Rover Evoque (L538)	PCM - Powertrain Control Module	DATA
JJ32-12K532-GLE.vbf	Range Rover Evoque (L538)	PCM - Powertrain Control Module	DATA
JJ32-12K532-GLF.vbf	Range Rover Evoque (L538)	PCM - Powertrain Control Module	DATA
JJ32-12K532-GPC.vbf	Range Rover Evoque (L538)	PCM - Powertrain Control Module	DATA
JJ32-12K532-GPD.vbf	Range Rover Evoque (L538)	PCM - Powertrain Control Module	DATA
JJ32-12K532-GRC.vbf	Range Rover Evoque (L538)	PCM - Powertrain Control Module	DATA
JJ32-12K532-GRD.vbf	Range Rover Evoque (L538)	PCM - Powertrain Control Module	DATA
JJ32-12K532-GSC.vbf	Range Rover Evoque (L538)	PCM - Powertrain Control Module	DATA
JJ32-12K532-GSD.vbf	Range Rover Evoque (L538)	PCM - Powertrain Control Module	DATA
JJ32-12K532-GTC.vbf	Range Rover Evoque (L538)	PCM - Powertrain Control Module	DATA
JJ32-12K532-GTE.vbf	Range Rover Evoque (L538)	PCM - Powertrain Control Module	DATA
JJ32-12K532-GTF.vbf	Range Rover Evoque (L538)	PCM - Powertrain Control Module	DATA
JJ32-12K532-GTG.vbf	Range Rover Evoque (L538)	PCM - Powertrain Control Module	DATA
JJ32-12K532-GUA.vbf	Range Rover Evoque (L538)	PCM - Powertrain Control Module	DATA
JJ32-12K532-GUC.vbf	Range Rover Evoque (L538)	PCM - Powertrain Control Module	DATA
JJ32-12K532-GUD.vbf	Range Rover Evoque (L538)	PCM - Powertrain Control Module	DATA
JJ32-12K532-KCC.vbf	Range Rover Evoque (L538)	PCM - Powertrain Control Module	DATA
JJ32-12K532-KDC.vbf	Range Rover Evoque (L538)	PCM - Powertrain Control Module	DATA
JJ32-12K532-KKC.vbf	Range Rover Evoque (L538)	PCM - Powertrain Control Module	DATA
JJ32-12K532-KLC.vbf	Range Rover Evoque (L538)	PCM - Powertrain Control Module	DATA
JJ32-14C025-AA.vbf	Range Rover Evoque (L538)	IPC - Instrument Panel Cluster (IPC) Control Module	SBL
JJ32-14C025-AB.vbf	Range Rover Evoque (L538)	IPC - Instrument Panel Cluster (IPC) Control Module	SBL
JJ32-14C026-AA.vbf	Range Rover Evoque (L538)	IPC - Instrument Panel Cluster (IPC) Control Module	EXE
JJ32-14C026-AB.vbf	Range Rover Evoque (L538)	IPC - Instrument Panel Cluster (IPC) Control Module	EXE
JJ32-14C026-AC.vbf	Range Rover Evoque (L538)	IPC - Instrument Panel Cluster (IPC) Control Module	EXE
JJ32-14C026-AD.vbf	Range Rover Evoque (L538)	IPC - Instrument Panel Cluster (IPC) Control Module	EXE
JJ32-14C026-AE.vbf	Range Rover Evoque (L538)	IPC - Instrument Panel Cluster (IPC) Control Module	EXE
JJ32-14C026-AF.vbf	Range Rover Evoque (L538)	IPC - Instrument Panel Cluster (IPC) Control Module	EXE

File name	Vehicle line (indicative)	Module (ECU)	Type
JJ32-14C036-AA.vbf	Range Rover Evoque (L538)	ABS - Anit-Lock Brake System (ABS) Control Module	EXE
JJ32-14C036-AB.vbf	Range Rover Evoque (L538)	ABS - Anit-Lock Brake System (ABS) Control Module	EXE
JJ32-14C036-AD.vbf	Range Rover Evoque (L538)	ABS - Anit-Lock Brake System (ABS) Control Module	EXE
JJ32-14C036-AE.vbf	Range Rover Evoque (L538)	ABS - Anit-Lock Brake System (ABS) Control Module	EXE
JJ32-14C036-AF.vbf	Range Rover Evoque (L538)	ABS - Anit-Lock Brake System (ABS) Control Module	EXE
JJ32-14C088-BC.vbf	Range Rover Evoque (L538)	IPC - Instrument Panel Cluster (IPC) Control Module	DATA
JJ32-14C088-CA.vbf	Range Rover Evoque (L538)	IPC - Instrument Panel Cluster (IPC) Control Module	EXE
JJ32-14C088-CB.vbf	Range Rover Evoque (L538)	IPC - Instrument Panel Cluster (IPC) Control Module	EXE
JJ32-14C088-CC.vbf	Range Rover Evoque (L538)	IPC - Instrument Panel Cluster (IPC) Control Module	EXE
JJ32-14C218-AA.vbf	Range Rover Evoque (L538)	PSCM - Power Steering Control Module	EXE
JJ32-14C218-BA.vbf	Range Rover Evoque (L538)	PSCM - Power Steering Control Module	EXE
JJ32-14C218-CA.vbf	Range Rover Evoque (L538)	PSCM - Power Steering Control Module	EXE
JJ32-14C337-CJA.vbf	Range Rover Evoque (L538)	TCM - Transmission Control Module	EXE
JJ32-14C337-CJB.vbf	Range Rover Evoque (L538)	TCM - Transmission Control Module	EXE
JJ32-14C337-CJD.vbf	Range Rover Evoque (L538)	TCM - Transmission Control Module	EXE
JJ32-14C337-CJE.vbf	Range Rover Evoque (L538)	TCM - Transmission Control Module	EXE
JJ32-14C337-CJH.vbf	Range Rover Evoque (L538)	TCM - Transmission Control Module	EXE
JJ32-14C337-CJJ.vbf	Range Rover Evoque (L538)	TCM - Transmission Control Module	EXE
JJ32-14C337-CJK.vbf	Range Rover Evoque (L538)	TCM - Transmission Control Module	EXE
JJ32-14C337-CKA.vbf	Range Rover Evoque (L538)	TCM - Transmission Control Module	EXE
JJ32-14C337-CKB.vbf	Range Rover Evoque (L538)	TCM - Transmission Control Module	EXE
JJ32-14C337-CKE.vbf	Range Rover Evoque (L538)	TCM - Transmission Control Module	EXE
JJ32-14C337-CKF.vbf	Range Rover Evoque (L538)	TCM - Transmission Control Module	EXE
JJ32-14C337-CKG.vbf	Range Rover Evoque (L538)	TCM - Transmission Control Module	EXE
JJ32-14C337-CKH.vbf	Range Rover Evoque (L538)	TCM - Transmission Control Module	EXE
JJ32-14C337-CKJ.vbf	Range Rover Evoque (L538)	TCM - Transmission Control Module	EXE
JJ32-14C337-CKK.vbf	Range Rover Evoque (L538)	TCM - Transmission Control Module	EXE
JJ32-14C337-CMA.vbf	Range Rover Evoque (L538)	TCM - Transmission Control Module	EXE
JJ32-14C337-CMB.vbf	Range Rover Evoque (L538)	TCM - Transmission Control Module	EXE
JJ32-14C337-CMC.vbf	Range Rover Evoque (L538)	TCM - Transmission Control Module	EXE
JJ32-14C337-CMD.vbf	Range Rover Evoque (L538)	TCM - Transmission Control Module	EXE
JJ32-14C337-CME.vbf	Range Rover Evoque (L538)	TCM - Transmission Control Module	EXE
JJ32-14C337-CMF.vbf	Range Rover Evoque (L538)	TCM - Transmission Control Module	EXE
JJ32-14C337-CMG.vbf	Range Rover Evoque (L538)	TCM - Transmission Control Module	EXE
JJ32-14C337-CMH.vbf	Range Rover Evoque (L538)	TCM - Transmission Control Module	EXE
JJ32-14C337-CPA.vbf	Range Rover Evoque (L538)	TCM - Transmission Control Module	EXE
JJ32-14C337-CPB.vbf	Range Rover Evoque (L538)	TCM - Transmission Control Module	EXE
JJ32-14C337-CPC.vbf	Range Rover Evoque (L538)	TCM - Transmission Control Module	EXE
JJ32-14C337-CPD.vbf	Range Rover Evoque (L538)	TCM - Transmission Control Module	EXE
JJ32-14C337-CPE.vbf	Range Rover Evoque (L538)	TCM - Transmission Control Module	EXE
JJ32-14C337-CPF.vbf	Range Rover Evoque (L538)	TCM - Transmission Control Module	EXE
JJ32-14C337-CPG.vbf	Range Rover Evoque (L538)	TCM - Transmission Control Module	EXE
JJ32-14C337-CPH.vbf	Range Rover Evoque (L538)	TCM - Transmission Control Module	EXE
JJ32-14C337-CPJ.vbf	Range Rover Evoque (L538)	TCM - Transmission Control Module	EXE
JJ32-14C337-CRA.vbf	Range Rover Evoque (L538)	TCM - Transmission Control Module	EXE
JJ32-14C337-CRC.vbf	Range Rover Evoque (L538)	TCM - Transmission Control Module	EXE
JJ32-14C337-CRD.vbf	Range Rover Evoque (L538)	TCM - Transmission Control Module	EXE
JJ32-14C337-CRE.vbf	Range Rover Evoque (L538)	TCM - Transmission Control Module	EXE
JJ32-14C337-CRF.vbf	Range Rover Evoque (L538)	TCM - Transmission Control Module	EXE
JJ32-14C337-CRG.vbf	Range Rover Evoque (L538)	TCM - Transmission Control Module	EXE
JJ32-14C337-CRH.vbf	Range Rover Evoque (L538)	TCM - Transmission Control Module	EXE
JJ32-14C337-CUA.vbf	Range Rover Evoque (L538)	TCM - Transmission Control Module	EXE
JJ32-14C337-CUC.vbf	Range Rover Evoque (L538)	TCM - Transmission Control Module	EXE
JJ32-14C337-CUD.vbf	Range Rover Evoque (L538)	TCM - Transmission Control Module	EXE
JJ32-14C337-CUG.vbf	Range Rover Evoque (L538)	TCM - Transmission Control Module	EXE
JJ32-14C337-CUH.vbf	Range Rover Evoque (L538)	TCM - Transmission Control Module	EXE
JJ32-14C337-CUJ.vbf	Range Rover Evoque (L538)	TCM - Transmission Control Module	EXE
JJ32-14C337-CVA.vbf	Range Rover Evoque (L538)	TCM - Transmission Control Module	EXE
JJ32-14C337-DAA.vbf	Range Rover Evoque (L538)	TCM - Transmission Control Module	EXE
JJ32-14C337-DAB.vbf	Range Rover Evoque (L538)	TCM - Transmission Control Module	EXE
JJ32-14C337-DSA.vbf	Range Rover Evoque (L538)	TCM - Transmission Control Module	EXE
JJ32-14C337-DSB.vbf	Range Rover Evoque (L538)	TCM - Transmission Control Module	EXE
JJ32-14C337-DTA.vbf	Range Rover Evoque (L538)	TCM - Transmission Control Module	EXE
JJ32-14C337-DTB.vbf	Range Rover Evoque (L538)	TCM - Transmission Control Module	EXE
JJ32-14C570-BAA.vbf	Range Rover Evoque (L538)	PCM - Powertrain Control Module	EXE
JJ32-14C570-BAC.vbf	Range Rover Evoque (L538)	PCM - Powertrain Control Module	EXE
JJ32-14C570-BAD.vbf	Range Rover Evoque (L538)	PCM - Powertrain Control Module	EXE
JJ32-14C570-BAE.vbf	Range Rover Evoque (L538)	PCM - Powertrain Control Module	EXE
JJ32-14C570-BAG.vbf	Range Rover Evoque (L538)	PCM - Powertrain Control Module	EXE
JJ32-14C570-BAH.vbf	Range Rover Evoque (L538)	PCM - Powertrain Control Module	EXE
JJ32-14C570-BAJ.vbf	Range Rover Evoque (L538)	PCM - Powertrain Control Module	EXE
JJ32-14C570-BAK.vbf	Range Rover Evoque (L538)	PCM - Powertrain Control Module	EXE
JJ32-14C570-BCA.vbf	Range Rover Evoque (L538)	PCM - Powertrain Control Module	EXE
JJ32-14C570-BCD.vbf	Range Rover Evoque (L538)	PCM - Powertrain Control Module	EXE
JJ32-14C570-BCE.vbf	Range Rover Evoque (L538)	PCM - Powertrain Control Module	EXE
JJ32-14C570-BCG.vbf	Range Rover Evoque (L538)	PCM - Powertrain Control Module	EXE

File name	Vehicle line (indicative)	Module (ECU)	Type
JJ32-14C570-BEA.vbf	Range Rover Evoque (L538)	PCM - Powertrain Control Module	EXE
JJ32-14C570-BED.vbf	Range Rover Evoque (L538)	PCM - Powertrain Control Module	EXE
JJ32-14C570-BEE.vbf	Range Rover Evoque (L538)	PCM - Powertrain Control Module	EXE
JJ32-14C570-BEG.vbf	Range Rover Evoque (L538)	PCM - Powertrain Control Module	EXE
JJ32-14C570-BGA.vbf	Range Rover Evoque (L538)	PCM - Powertrain Control Module	EXE
JJ32-14C570-BGC.vbf	Range Rover Evoque (L538)	PCM - Powertrain Control Module	EXE
JJ32-14C570-BGD.vbf	Range Rover Evoque (L538)	PCM - Powertrain Control Module	EXE
JJ32-14C570-BGE.vbf	Range Rover Evoque (L538)	PCM - Powertrain Control Module	EXE
JJ32-14C570-BGF.vbf	Range Rover Evoque (L538)	PCM - Powertrain Control Module	EXE
JJ32-14C570-BGG.vbf	Range Rover Evoque (L538)	PCM - Powertrain Control Module	EXE
JJ32-14C570-BGH.vbf	Range Rover Evoque (L538)	PCM - Powertrain Control Module	EXE
JJ32-14C570-BLD.vbf	Range Rover Evoque (L538)	PCM - Powertrain Control Module	EXE
JJ32-14C570-BLE.vbf	Range Rover Evoque (L538)	PCM - Powertrain Control Module	EXE
JJ32-14C570-BLG.vbf	Range Rover Evoque (L538)	PCM - Powertrain Control Module	EXE
JJ32-14C570-BNA.vbf	Range Rover Evoque (L538)	PCM - Powertrain Control Module	EXE
JJ32-14C570-BND.vbf	Range Rover Evoque (L538)	PCM - Powertrain Control Module	EXE
JJ32-14C570-BNE.vbf	Range Rover Evoque (L538)	PCM - Powertrain Control Module	EXE
JJ32-14C570-BNG.vbf	Range Rover Evoque (L538)	PCM - Powertrain Control Module	EXE
JJ32-14C570-BTA.vbf	Range Rover Evoque (L538)	PCM - Powertrain Control Module	EXE
JJ32-14C570-BTC.vbf	Range Rover Evoque (L538)	PCM - Powertrain Control Module	EXE
JJ32-14C570-BTD.vbf	Range Rover Evoque (L538)	PCM - Powertrain Control Module	EXE
JJ32-14C570-BTE.vbf	Range Rover Evoque (L538)	PCM - Powertrain Control Module	EXE
JJ32-14C570-BTF.vbf	Range Rover Evoque (L538)	PCM - Powertrain Control Module	EXE
JJ32-14C570-BTH.vbf	Range Rover Evoque (L538)	PCM - Powertrain Control Module	EXE
JJ32-14C570-BTL.vbf	Range Rover Evoque (L538)	PCM - Powertrain Control Module	EXE
JJ32-14C570-BUA.vbf	Range Rover Evoque (L538)	PCM - Powertrain Control Module	EXE
JJ32-14C570-BUC.vbf	Range Rover Evoque (L538)	PCM - Powertrain Control Module	EXE
JJ32-14C570-BUD.vbf	Range Rover Evoque (L538)	PCM - Powertrain Control Module	EXE
JJ32-14C570-BUE.vbf	Range Rover Evoque (L538)	PCM - Powertrain Control Module	EXE
JJ32-14C570-BUF.vbf	Range Rover Evoque (L538)	PCM - Powertrain Control Module	EXE
JJ32-14C570-BUG.vbf	Range Rover Evoque (L538)	PCM - Powertrain Control Module	EXE
JJ32-14C570-BUK.vbf	Range Rover Evoque (L538)	PCM - Powertrain Control Module	EXE
JJ32-14C609-AA.vbf	Range Rover Evoque (L538)	PSCM - Power Steering Control Module	EXE
JJ32-14D481-BA.vbf	Range Rover Evoque (L538)	IPMB - Image Processing Module B	DATA
JJ32-14D485-AC.vbf	Range Rover Evoque (L538)	IPMB - Image Processing Module B	EXE
JJ32-14D485-AE.vbf	Range Rover Evoque (L538)	IPMB - Image Processing Module B	EXE
JJ32-14D485-AG.vbf	Range Rover Evoque (L538)	IPMB - Image Processing Module B	EXE
JJ32-14D564-AB.vbf	Range Rover Evoque (L538)	SODL - Side Obstacle Detection Control Module - Left	DATA
JJ32-14D564-AC.vbf	Range Rover Evoque (L538)	SODL - Side Obstacle Detection Control Module - Left	DATA
JJ32-14D564-AD.vbf	Range Rover Evoque (L538)	SODL - Side Obstacle Detection Control Module - Left	DATA
JJ32-14D564-AE.vbf	Range Rover Evoque (L538)	SODL - Side Obstacle Detection Control Module - Left	DATA
JJ32-14D564-BB.vbf	Range Rover Evoque (L538)	SODR - Side Obstacle Detection Control Module - Right	DATA
JJ32-14D564-BC.vbf	Range Rover Evoque (L538)	SODR - Side Obstacle Detection Control Module - Right	DATA
JJ32-14D564-BD.vbf	Range Rover Evoque (L538)	SODR - Side Obstacle Detection Control Module - Right	DATA
JJ32-14D564-BE.vbf	Range Rover Evoque (L538)	SODR - Side Obstacle Detection Control Module - Right	DATA
JJ32-14F016-AA.vbf	Range Rover Evoque (L538)	IPMB - Image Processing Module B	SIGCFG
JJ32-14F017-AA.vbf	Range Rover Evoque (L538)	IPMB - Image Processing Module B	EXE
JJ32-14F017-AB.vbf	Range Rover Evoque (L538)	IPMB - Image Processing Module B	EXE
JJ32-14F017-AC.vbf	Range Rover Evoque (L538)	IPMB - Image Processing Module B	EXE
JJ32-14F017-AD.vbf	Range Rover Evoque (L538)	IPMB - Image Processing Module B	EXE
JJ32-14F017-AE.vbf	Range Rover Evoque (L538)	IPMB - Image Processing Module B	EXE
JJ32-14F017-BA.vbf	Range Rover Evoque (L538)	IPMB - Image Processing Module B	EXE
JJ32-14F017-BB.vbf	Range Rover Evoque (L538)	IPMB - Image Processing Module B	EXE
JJ32-14F017-BC.vbf	Range Rover Evoque (L538)	IPMB - Image Processing Module B	EXE
JJ32-14F017-BD.vbf	Range Rover Evoque (L538)	IPMB - Image Processing Module B	EXE
JJ32-14F022-AB.vbf	Range Rover Evoque (L538)	IPMB - Image Processing Module B	DATA
JJ32-14F022-AC.vbf	Range Rover Evoque (L538)	IPMB - Image Processing Module B	DATA
JJ32-14F022-AD.vbf	Range Rover Evoque (L538)	IPMB - Image Processing Module B	DATA
JJ32-14F022-AE.vbf	Range Rover Evoque (L538)	IPMB - Image Processing Module B	DATA
JJ32-14F022-AF.vbf	Range Rover Evoque (L538)	IPMB - Image Processing Module B	DATA
JJ32-14F022-AG.vbf	Range Rover Evoque (L538)	IPMB - Image Processing Module B	DATA
JJ32-14F022-BB.vbf	Range Rover Evoque (L538)	IPMB - Image Processing Module B	DATA
JJ32-14F022-BC.vbf	Range Rover Evoque (L538)	IPMB - Image Processing Module B	DATA
JJ32-14F022-BD.vbf	Range Rover Evoque (L538)	IPMB - Image Processing Module B	DATA
JJ32-14F022-BE.vbf	Range Rover Evoque (L538)	IPMB - Image Processing Module B	DATA
JJ32-14F022-BF.vbf	Range Rover Evoque (L538)	IPMB - Image Processing Module B	DATA
JJ32-14F022-BG.vbf	Range Rover Evoque (L538)	IPMB - Image Processing Module B	DATA
JJ32-14F022-CA.vbf	Range Rover Evoque (L538)	IPMB - Image Processing Module B	DATA
JJ32-14F022-CB.vbf	Range Rover Evoque (L538)	IPMB - Image Processing Module B	DATA
JJ32-14F022-CC.vbf	Range Rover Evoque (L538)	IPMB - Image Processing Module B	DATA
JJ32-14F022-CD.vbf	Range Rover Evoque (L538)	IPMB - Image Processing Module B	DATA
JJ32-14F022-CE.vbf	Range Rover Evoque (L538)	IPMB - Image Processing Module B	DATA
JJ32-14F022-DA.vbf	Range Rover Evoque (L538)	IPMB - Image Processing Module B	DATA
JJ32-14F022-DB.vbf	Range Rover Evoque (L538)	IPMB - Image Processing Module B	DATA
JJ32-14F022-DC.vbf	Range Rover Evoque (L538)	IPMB - Image Processing Module B	DATA
JJ32-14F022-DD.vbf	Range Rover Evoque (L538)	IPMB - Image Processing Module B	DATA

File name	Vehicle line (indicative)	Module (ECU)	Type
JJ32-14F022-DE.vbf	Range Rover Evoque (L538)	IPMB - Image Processing Module B	DATA
JJ32-14F022-EA.vbf	Range Rover Evoque (L538)	IPMB - Image Processing Module B	DATA
JJ32-14F022-EB.vbf	Range Rover Evoque (L538)	IPMB - Image Processing Module B	DATA
JJ32-14F022-EC.vbf	Range Rover Evoque (L538)	IPMB - Image Processing Module B	DATA
JJ32-14F022-ED.vbf	Range Rover Evoque (L538)	IPMB - Image Processing Module B	DATA
JJ32-14F022-EE.vbf	Range Rover Evoque (L538)	IPMB - Image Processing Module B	DATA
JJ32-14F531-AA.vbf	Range Rover Evoque (L538)	GWM - Gateway Module A	DATA
JJ32-14F531-AB.vbf	Range Rover Evoque (L538)	GWM - Gateway Module A	DATA
JJ32-18D620-BA.vbf	Range Rover Evoque (L538)	HVAC - HVAC Control Module	DATA
JJ32-19C204-AA.vbf	Range Rover Evoque (L538)	IMC - Infotainment Master Controller	EXE
JK52-12K532-PCD.vbf	Range Rover (L405)	PCM - Powertrain Control Module	DATA
JK52-12K532-PFB.vbf	Range Rover (L405)	PCM - Powertrain Control Module	DATA
JK52-12K532-PFC.vbf	Range Rover (L405)	PCM - Powertrain Control Module	DATA
JK52-12K532-PFD.vbf	Range Rover (L405)	PCM - Powertrain Control Module	DATA
JK52-12K532-PFE.vbf	Range Rover (L405)	PCM - Powertrain Control Module	DATA
JK52-12K532-PJB.vbf	Range Rover (L405)	PCM - Powertrain Control Module	DATA
JK52-12K532-PJC.vbf	Range Rover (L405)	PCM - Powertrain Control Module	DATA
JK52-12K532-PJD.vbf	Range Rover (L405)	PCM - Powertrain Control Module	DATA
JK52-12K532-PJE.vbf	Range Rover (L405)	PCM - Powertrain Control Module	DATA
JK52-12K532-PJF.vbf	Range Rover (L405)	PCM - Powertrain Control Module	DATA
JK52-12K532-PJG.vbf	Range Rover (L405)	PCM - Powertrain Control Module	EXE
JK52-12K532-PKB.vbf	Range Rover (L405)	PCM - Powertrain Control Module	DATA
JK52-12K532-PKC.vbf	Range Rover (L405)	PCM - Powertrain Control Module	DATA
JK52-12K532-PKD.vbf	Range Rover (L405)	PCM - Powertrain Control Module	DATA
JK52-12K532-PKE.vbf	Range Rover (L405)	PCM - Powertrain Control Module	DATA
JK52-12K532-PKF.vbf	Range Rover (L405)	PCM - Powertrain Control Module	DATA
JK52-12K532-PKG.vbf	Range Rover (L405)	PCM - Powertrain Control Module	DATA
JK52-12K532-PPD.vbf	Range Rover (L405)	PCM - Powertrain Control Module	DATA
JK52-12K532-PPE.vbf	Range Rover (L405)	PCM - Powertrain Control Module	DATA
JK52-12K532-PSD.vbf	Range Rover (L405)	PCM - Powertrain Control Module	DATA
JK52-12K532-PSE.vbf	Range Rover (L405)	PCM - Powertrain Control Module	DATA
JK52-12K532-PSF.vbf	Range Rover (L405)	PCM - Powertrain Control Module	DATA
JK52-14C030-AA.vbf	Range Rover (L405)	DSM - Driver Front Seat Module	EXE
JK52-14C030-AB.vbf	Range Rover (L405)	DSM - Driver Front Seat Module	EXE
JK52-14C030-AC.vbf	Range Rover (L405)	DSM - Driver Front Seat Module	EXE
JK52-14C030-AD.vbf	Range Rover (L405)	DSM - Driver Front Seat Module	EXE
JK52-14C030-AE.vbf	Range Rover (L405)	DSM - Driver Front Seat Module	EXE
JK52-14C034-ABA.vbf	Range Rover (L405)	DSM - Driver Front Seat Module	EXE
JK52-14C034-ABB.vbf	Range Rover (L405)	DSM - Driver Front Seat Module	EXE
JK52-14C034-ACA.vbf	Range Rover (L405)	DSM - Driver Front Seat Module	EXE
JK52-14C034-ACB.vbf	Range Rover (L405)	DSM - Driver Front Seat Module	EXE
JK52-14C034-BEA.vbf	Range Rover (L405)	PSM - Passenger Front Seat Module	EXE
JK52-14C034-BEB.vbf	Range Rover (L405)	PSM - Passenger Front Seat Module	EXE
JK52-14C034-BEC.vbf	Range Rover (L405)	DSM - Driver Front Seat Module	EXE
JK52-14C034-BED.vbf	Range Rover (L405)	DSM - Driver Front Seat Module	EXE
JK52-14C034-BEE.vbf	Range Rover (L405)	DSM - Driver Front Seat Module	EXE
JK52-14C034-CEA.vbf	Range Rover (L405)	PSM - Passenger Front Seat Module	EXE
JK52-14C034-CEB.vbf	Range Rover (L405)	PSM - Passenger Front Seat Module	EXE
JK52-14C034-CEC.vbf	Range Rover (L405)	DSM - Driver Front Seat Module	EXE
JK52-14C034-CED.vbf	Range Rover (L405)	DSM - Driver Front Seat Module	EXE
JK52-14C034-CEE.vbf	Range Rover (L405)	DSM - Driver Front Seat Module	EXE
JK52-14C034-DEB.vbf	Range Rover (L405)	PSM - Passenger Front Seat Module	EXE
JK52-14C034-DEC.vbf	Range Rover (L405)	DSM - Driver Front Seat Module	EXE
JK52-14C034-DED.vbf	Range Rover (L405)	DSM - Driver Front Seat Module	EXE
JK52-14C034-DEE.vbf	Range Rover (L405)	DSM - Driver Front Seat Module	EXE
JK52-14C034-EEB.vbf	Range Rover (L405)	PSM - Passenger Front Seat Module	EXE
JK52-14C034-EEC.vbf	Range Rover (L405)	DSM - Driver Front Seat Module	EXE
JK52-14C034-EED.vbf	Range Rover (L405)	DSM - Driver Front Seat Module	EXE
JK52-14C034-EEE.vbf	Range Rover (L405)	DSM - Driver Front Seat Module	EXE
JK52-14C034-FEB.vbf	Range Rover (L405)	DSM - Driver Front Seat Module	EXE
JK52-14C034-FEC.vbf	Range Rover (L405)	DSM - Driver Front Seat Module	EXE
JK52-14C034-GEA.vbf	Range Rover (L405)	DSM - Driver Front Seat Module	EXE
JK52-14C034-GEB.vbf	Range Rover (L405)	DSM - Driver Front Seat Module	EXE
JK52-14C034-HEA.vbf	Range Rover (L405)	DSM - Driver Front Seat Module	EXE
JK52-14C034-HEB.vbf	Range Rover (L405)	DSM - Driver Front Seat Module	EXE
JK52-14C034-HEC.vbf	Range Rover (L405)	DSM - Driver Front Seat Module	EXE
JK52-14C034-JEA.vbf	Range Rover (L405)	DSM - Driver Front Seat Module	EXE
JK52-14C034-JEB.vbf	Range Rover (L405)	DSM - Driver Front Seat Module	EXE
JK52-14C034-JEC.vbf	Range Rover (L405)	DSM - Driver Front Seat Module	EXE
JK52-14C034-KEA.vbf	Range Rover (L405)	DSM - Driver Front Seat Module	EXE
JK52-14C034-KEB.vbf	Range Rover (L405)	DSM - Driver Front Seat Module	EXE
JK52-14C034-KEC.vbf	Range Rover (L405)	DSM - Driver Front Seat Module	EXE
JK52-14C034-LEA.vbf	Range Rover (L405)	DSM - Driver Front Seat Module	EXE
JK52-14C034-LEB.vbf	Range Rover (L405)	DSM - Driver Front Seat Module	EXE
JK52-14C034-LEC.vbf	Range Rover (L405)	DSM - Driver Front Seat Module	EXE
JK52-14C037-ABD.vbf	Range Rover (L405)	ABS - Anti-Lock Brake System Control Module	DATA

File name	Vehicle line (indicative)	Module (ECU)	Type
JK52-14C037-ABE.vbf	Range Rover (L405)	ABS - Anti-Lock Brake System Control Module	DATA
JK52-14C037-ABF.vbf	Range Rover (L405)	ABS - Anti-Lock Brake System Control Module	DATA
JK52-14C037-ABG.vbf	Range Rover (L405)	ABS - Anti-Lock Brake System Control Module	DATA
JK52-14C037-ABJ.vbf	Range Rover (L405)	ABS - Anti-Lock Brake System Control Module	DATA
JK52-14C037-ABK.vbf	Range Rover (L405)	ABS - Anti-Lock Brake System Control Module	DATA
JK52-14C037-ABL.vbf	Range Rover (L405)	ABS - Anti-Lock Brake System Control Module	DATA
JK52-14C037-ACD.vbf	Range Rover (L405)	ABS - Anti-Lock Brake System Control Module	DATA
JK52-14C037-ACE.vbf	Range Rover (L405)	ABS - Anti-Lock Brake System Control Module	DATA
JK52-14C037-ACF.vbf	Range Rover (L405)	ABS - Anti-Lock Brake System Control Module	DATA
JK52-14C037-ACG.vbf	Range Rover (L405)	ABS - Anti-Lock Brake System Control Module	DATA
JK52-14C037-ACJ.vbf	Range Rover (L405)	ABS - Anti-Lock Brake System Control Module	DATA
JK52-14C037-ACK.vbf	Range Rover (L405)	ABS - Anti-Lock Brake System Control Module	DATA
JK52-14C037-ACL.vbf	Range Rover (L405)	ABS - Anti-Lock Brake System Control Module	DATA
JK52-14C037-ADD.vbf	Range Rover (L405)	ABS - Anti-Lock Brake System Control Module	DATA
JK52-14C037-ADE.vbf	Range Rover (L405)	ABS - Anti-Lock Brake System Control Module	DATA
JK52-14C037-ADF.vbf	Range Rover (L405)	ABS - Anti-Lock Brake System Control Module	DATA
JK52-14C037-ADG.vbf	Range Rover (L405)	ABS - Anti-Lock Brake System Control Module	DATA
JK52-14C037-ADJ.vbf	Range Rover (L405)	ABS - Anti-Lock Brake System Control Module	DATA
JK52-14C037-ADK.vbf	Range Rover (L405)	ABS - Anti-Lock Brake System Control Module	DATA
JK52-14C037-ADL.vbf	Range Rover (L405)	ABS - Anti-Lock Brake System Control Module	DATA
JK52-14C037-AED.vbf	Range Rover (L405)	ABS - Anti-Lock Brake System Control Module	DATA
JK52-14C037-AEE.vbf	Range Rover (L405)	ABS - Anti-Lock Brake System Control Module	DATA
JK52-14C037-AEF.vbf	Range Rover (L405)	ABS - Anti-Lock Brake System Control Module	DATA
JK52-14C037-AEG.vbf	Range Rover (L405)	ABS - Anti-Lock Brake System Control Module	DATA
JK52-14C037-AEJ.vbf	Range Rover (L405)	ABS - Anti-Lock Brake System Control Module	DATA
JK52-14C037-AEK.vbf	Range Rover (L405)	ABS - Anti-Lock Brake System Control Module	DATA
JK52-14C037-AEL.vbf	Range Rover (L405)	ABS - Anti-Lock Brake System Control Module	DATA
JK52-14C037-AFD.vbf	Range Rover (L405)	ABS - Anti-Lock Brake System Control Module	DATA
JK52-14C037-AFE.vbf	Range Rover (L405)	ABS - Anti-Lock Brake System Control Module	DATA
JK52-14C037-AFF.vbf	Range Rover (L405)	ABS - Anti-Lock Brake System Control Module	DATA
JK52-14C037-AFG.vbf	Range Rover (L405)	ABS - Anti-Lock Brake System Control Module	DATA
JK52-14C037-AFJ.vbf	Range Rover (L405)	ABS - Anti-Lock Brake System Control Module	DATA
JK52-14C037-AFK.vbf	Range Rover (L405)	ABS - Anti-Lock Brake System Control Module	DATA
JK52-14C037-AFL.vbf	Range Rover (L405)	ABS - Anti-Lock Brake System Control Module	DATA
JK52-14C037-AMD.vbf	Range Rover (L405)	ABS - Anti-Lock Brake System Control Module	DATA
JK52-14C037-AME.vbf	Range Rover (L405)	ABS - Anti-Lock Brake System Control Module	DATA
JK52-14C037-AMF.vbf	Range Rover (L405)	ABS - Anti-Lock Brake System Control Module	DATA
JK52-14C037-AMG.vbf	Range Rover (L405)	ABS - Anti-Lock Brake System Control Module	DATA
JK52-14C037-AMJ.vbf	Range Rover (L405)	ABS - Anti-Lock Brake System Control Module	DATA
JK52-14C037-AMK.vbf	Range Rover (L405)	ABS - Anti-Lock Brake System Control Module	DATA
JK52-14C037-AML.vbf	Range Rover (L405)	ABS - Anti-Lock Brake System Control Module	DATA
JK52-14C037-AND.vbf	Range Rover (L405)	ABS - Anti-Lock Brake System Control Module	DATA
JK52-14C037-ANE.vbf	Range Rover (L405)	ABS - Anti-Lock Brake System Control Module	DATA
JK52-14C037-ANF.vbf	Range Rover (L405)	ABS - Anti-Lock Brake System Control Module	DATA
JK52-14C037-ANG.vbf	Range Rover (L405)	ABS - Anti-Lock Brake System Control Module	DATA
JK52-14C037-ANJ.vbf	Range Rover (L405)	ABS - Anti-Lock Brake System Control Module	DATA
JK52-14C037-ANK.vbf	Range Rover (L405)	ABS - Anti-Lock Brake System Control Module	DATA
JK52-14C037-ANL.vbf	Range Rover (L405)	ABS - Anti-Lock Brake System Control Module	DATA
JK52-14C037-APD.vbf	Range Rover (L405)	ABS - Anti-Lock Brake System Control Module	DATA
JK52-14C037-APE.vbf	Range Rover (L405)	ABS - Anti-Lock Brake System Control Module	DATA
JK52-14C037-APF.vbf	Range Rover (L405)	ABS - Anti-Lock Brake System Control Module	DATA
JK52-14C037-APG.vbf	Range Rover (L405)	ABS - Anti-Lock Brake System Control Module	DATA
JK52-14C037-APJ.vbf	Range Rover (L405)	ABS - Anti-Lock Brake System Control Module	DATA
JK52-14C037-APK.vbf	Range Rover (L405)	ABS - Anti-Lock Brake System Control Module	DATA
JK52-14C037-APL.vbf	Range Rover (L405)	ABS - Anti-Lock Brake System Control Module	DATA
JK52-14C037-ARD.vbf	Range Rover (L405)	ABS - Anti-Lock Brake System Control Module	DATA
JK52-14C037-ARE.vbf	Range Rover (L405)	ABS - Anti-Lock Brake System Control Module	DATA
JK52-14C037-ARF.vbf	Range Rover (L405)	ABS - Anti-Lock Brake System Control Module	DATA
JK52-14C037-ARG.vbf	Range Rover (L405)	ABS - Anti-Lock Brake System Control Module	DATA
JK52-14C037-ARJ.vbf	Range Rover (L405)	ABS - Anti-Lock Brake System Control Module	DATA
JK52-14C037-ARK.vbf	Range Rover (L405)	ABS - Anti-Lock Brake System Control Module	DATA
JK52-14C037-ARL.vbf	Range Rover (L405)	ABS - Anti-Lock Brake System Control Module	DATA
JK52-14C037-ATD.vbf	Range Rover (L405)	ABS - Anti-Lock Brake System Control Module	DATA
JK52-14C037-ATE.vbf	Range Rover (L405)	ABS - Anti-Lock Brake System Control Module	DATA
JK52-14C037-ATF.vbf	Range Rover (L405)	ABS - Anti-Lock Brake System Control Module	DATA
JK52-14C037-ATG.vbf	Range Rover (L405)	ABS - Anti-Lock Brake System Control Module	DATA
JK52-14C037-ATJ.vbf	Range Rover (L405)	ABS - Anti-Lock Brake System Control Module	DATA
JK52-14C037-ATK.vbf	Range Rover (L405)	ABS - Anti-Lock Brake System Control Module	DATA
JK52-14C037-ATL.vbf	Range Rover (L405)	ABS - Anti-Lock Brake System Control Module	DATA
JK52-14C037-AVD.vbf	Range Rover (L405)	ABS - Anti-Lock Brake System Control Module	DATA
JK52-14C037-AVE.vbf	Range Rover (L405)	ABS - Anti-Lock Brake System Control Module	DATA
JK52-14C037-AVF.vbf	Range Rover (L405)	ABS - Anti-Lock Brake System Control Module	DATA
JK52-14C037-AVG.vbf	Range Rover (L405)	ABS - Anti-Lock Brake System Control Module	DATA
JK52-14C037-AVJ.vbf	Range Rover (L405)	ABS - Anti-Lock Brake System Control Module	DATA
JK52-14C037-AVK.vbf	Range Rover (L405)	ABS - Anti-Lock Brake System Control Module	DATA
JK52-14C037-AVL.vbf	Range Rover (L405)	ABS - Anti-Lock Brake System Control Module	DATA

File name	Vehicle line (indicative)	Module (ECU)	Type
JK52-14C037-DLD.vbf	Range Rover (L405)	ABS - Anti-Lock Brake System Control Module	DATA
JK52-14C037-DLE.vbf	Range Rover (L405)	ABS - Anti-Lock Brake System Control Module	DATA
JK52-14C037-DLF.vbf	Range Rover (L405)	ABS - Anti-Lock Brake System Control Module	DATA
JK52-14C037-DLG.vbf	Range Rover (L405)	ABS - Anti-Lock Brake System Control Module	DATA
JK52-14C037-DLJ.vbf	Range Rover (L405)	ABS - Anti-Lock Brake System Control Module	DATA
JK52-14C037-DLK.vbf	Range Rover (L405)	ABS - Anti-Lock Brake System Control Module	DATA
JK52-14C037-DLL.vbf	Range Rover (L405)	ABS - Anti-Lock Brake System Control Module	DATA
JK52-14C037-DMD.vbf	Range Rover (L405)	ABS - Anti-Lock Brake System Control Module	DATA
JK52-14C037-DME.vbf	Range Rover (L405)	ABS - Anti-Lock Brake System Control Module	DATA
JK52-14C037-DMF.vbf	Range Rover (L405)	ABS - Anti-Lock Brake System Control Module	DATA
JK52-14C037-DMG.vbf	Range Rover (L405)	ABS - Anti-Lock Brake System Control Module	DATA
JK52-14C037-DMJ.vbf	Range Rover (L405)	ABS - Anti-Lock Brake System Control Module	DATA
JK52-14C037-DMK.vbf	Range Rover (L405)	ABS - Anti-Lock Brake System Control Module	DATA
JK52-14C037-DML.vbf	Range Rover (L405)	ABS - Anti-Lock Brake System Control Module	DATA
JK52-14C037-DRD.vbf	Range Rover (L405)	ABS - Anti-Lock Brake System Control Module	DATA
JK52-14C037-DRE.vbf	Range Rover (L405)	ABS - Anti-Lock Brake System Control Module	DATA
JK52-14C037-DUE.vbf	Range Rover (L405)	ABS - Anti-Lock Brake System Control Module	DATA
JK52-14C037-DUF.vbf	Range Rover (L405)	ABS - Anti-Lock Brake System Control Module	DATA
JK52-14C037-DUG.vbf	Range Rover (L405)	ABS - Anti-Lock Brake System Control Module	DATA
JK52-14C037-DUJ.vbf	Range Rover (L405)	ABS - Anti-Lock Brake System Control Module	DATA
JK52-14C037-DUK.vbf	Range Rover (L405)	ABS - Anti-Lock Brake System Control Module	DATA
JK52-14C037-DUL.vbf	Range Rover (L405)	ABS - Anti-Lock Brake System Control Module	DATA
JK52-14C037-DZD.vbf	Range Rover (L405)	ABS - Anti-Lock Brake System Control Module	DATA
JK52-14C037-DZE.vbf	Range Rover (L405)	ABS - Anti-Lock Brake System Control Module	DATA
JK52-14C037-DZF.vbf	Range Rover (L405)	ABS - Anti-Lock Brake System Control Module	DATA
JK52-14C037-DZG.vbf	Range Rover (L405)	ABS - Anti-Lock Brake System Control Module	DATA
JK52-14C037-DZJ.vbf	Range Rover (L405)	ABS - Anti-Lock Brake System Control Module	DATA
JK52-14C037-DZK.vbf	Range Rover (L405)	ABS - Anti-Lock Brake System Control Module	DATA
JK52-14C037-DZL.vbf	Range Rover (L405)	ABS - Anti-Lock Brake System Control Module	DATA
JK52-14C037-FAB.vbf	Range Rover (L405)	ABS - Anti-Lock Brake System Control Module	DATA
JK52-14C037-FAC.vbf	Range Rover (L405)	ABS - Anti-Lock Brake System Control Module	DATA
JK52-14C037-FAD.vbf	Range Rover (L405)	ABS - Anti-Lock Brake System Control Module	DATA
JK52-14C037-FAE.vbf	Range Rover (L405)	ABS - Anti-Lock Brake System Control Module	DATA
JK52-14C037-FAG.vbf	Range Rover (L405)	ABS - Anti-Lock Brake System Control Module	DATA
JK52-14C037-FAH.vbf	Range Rover (L405)	ABS - Anti-Lock Brake System Control Module	DATA
JK52-14C037-FAJ.vbf	Range Rover (L405)	ABS - Anti-Lock Brake System Control Module	DATA
JK52-14C037-FBB.vbf	Range Rover (L405)	ABS - Anti-Lock Brake System Control Module	DATA
JK52-14C037-FBC.vbf	Range Rover (L405)	ABS - Anti-Lock Brake System Control Module	DATA
JK52-14C037-FBD.vbf	Range Rover (L405)	ABS - Anti-Lock Brake System Control Module	DATA
JK52-14C037-FBE.vbf	Range Rover (L405)	ABS - Anti-Lock Brake System Control Module	DATA
JK52-14C037-FBG.vbf	Range Rover (L405)	ABS - Anti-Lock Brake System Control Module	DATA
JK52-14C037-FBH.vbf	Range Rover (L405)	ABS - Anti-Lock Brake System Control Module	DATA
JK52-14C037-FBJ.vbf	Range Rover (L405)	ABS - Anti-Lock Brake System Control Module	DATA
JK52-14C037-FCB.vbf	Range Rover (L405)	ABS - Anti-Lock Brake System Control Module	DATA
JK52-14C037-FCC.vbf	Range Rover (L405)	ABS - Anti-Lock Brake System Control Module	DATA
JK52-14C037-FCD.vbf	Range Rover (L405)	ABS - Anti-Lock Brake System Control Module	DATA
JK52-14C037-FCF.vbf	Range Rover (L405)	ABS - Anti-Lock Brake System Control Module	DATA
JK52-14C037-FCG.vbf	Range Rover (L405)	ABS - Anti-Lock Brake System Control Module	DATA
JK52-14C037-FCH.vbf	Range Rover (L405)	ABS - Anti-Lock Brake System Control Module	DATA
JK52-14C037-FDB.vbf	Range Rover (L405)	ABS - Anti-Lock Brake System Control Module	DATA
JK52-14C037-FDC.vbf	Range Rover (L405)	ABS - Anti-Lock Brake System Control Module	DATA
JK52-14C037-FDD.vbf	Range Rover (L405)	ABS - Anti-Lock Brake System Control Module	DATA
JK52-14C037-FDF.vbf	Range Rover (L405)	ABS - Anti-Lock Brake System Control Module	DATA
JK52-14C037-FDG.vbf	Range Rover (L405)	ABS - Anti-Lock Brake System Control Module	DATA
JK52-14C037-FDH.vbf	Range Rover (L405)	ABS - Anti-Lock Brake System Control Module	DATA
JK52-14C037-HAE.vbf	Range Rover (L405)	ABS - Anti-Lock Brake System Control Module	DATA
JK52-14C037-HAF.vbf	Range Rover (L405)	ABS - Anti-Lock Brake System Control Module	DATA
JK52-14C037-HAG.vbf	Range Rover (L405)	ABS - Anti-Lock Brake System Control Module	DATA
JK52-14C037-HAH.vbf	Range Rover (L405)	ABS - Anti-Lock Brake System Control Module	DATA
JK52-14C037-HAJ.vbf	Range Rover (L405)	ABS - Anti-Lock Brake System Control Module	DATA
JK52-14C037-HAK.vbf	Range Rover (L405)	ABS - Anti-Lock Brake System Control Module	DATA
JK52-14C037-HAL.vbf	Range Rover (L405)	ABS - Anti-Lock Brake System Control Module	DATA
JK52-14C037-HAM.vbf	Range Rover (L405)	ABS - Anti-Lock Brake System Control Module	DATA
JK52-14C037-HBE.vbf	Range Rover (L405)	ABS - Anti-Lock Brake System Control Module	DATA
JK52-14C037-HBF.vbf	Range Rover (L405)	ABS - Anti-Lock Brake System Control Module	DATA
JK52-14C037-HBG.vbf	Range Rover (L405)	ABS - Anti-Lock Brake System Control Module	DATA
JK52-14C037-HBH.vbf	Range Rover (L405)	ABS - Anti-Lock Brake System Control Module	DATA
JK52-14C037-HBJ.vbf	Range Rover (L405)	ABS - Anti-Lock Brake System Control Module	DATA
JK52-14C037-HBK.vbf	Range Rover (L405)	ABS - Anti-Lock Brake System Control Module	DATA
JK52-14C037-HBL.vbf	Range Rover (L405)	ABS - Anti-Lock Brake System Control Module	DATA
JK52-14C037-HBM.vbf	Range Rover (L405)	ABS - Anti-Lock Brake System Control Module	DATA
JK52-14C065-AB.vbf	Range Rover (L405)	DDM - Driver Front Door Module	DATA
JK52-14C065-AD.vbf	Range Rover (L405)	DDM - Driver Front Door Module	DATA
JK52-14C065-AF.vbf	Range Rover (L405)	DDM - Driver Front Door Module	DATA
JK52-14C065-AG.vbf	Range Rover (L405)	DDM - Driver Front Door Module	DATA
JK52-14C065-BB.vbf	Range Rover (L405)	DDM - Driver Front Door Module	DATA

File name	Vehicle line (indicative)	Module (ECU)	Type
JK52-14C065-BD.vbf	Range Rover (L405)	DDM - Driver Front Door Module	DATA
JK52-14C065-BF.vbf	Range Rover (L405)	DDM - Driver Front Door Module	DATA
JK52-14C065-BG.vbf	Range Rover (L405)	DDM - Driver Front Door Module	DATA
JK52-14C069-AB.vbf	Range Rover (L405)	DRDM - Driver Rear Door Module	DATA
JK52-14C069-AD.vbf	Range Rover (L405)	DRDM - Driver Rear Door Module	DATA
JK52-14C069-AF.vbf	Range Rover (L405)	DRDM - Driver Rear Door Module	DATA
JK52-14C069-AG.vbf	Range Rover (L405)	DRDM - Driver Rear Door Module	DATA
JK52-14C069-BB.vbf	Range Rover (L405)	DRDM - Driver Rear Door Module	DATA
JK52-14C069-BD.vbf	Range Rover (L405)	DRDM - Driver Rear Door Module	DATA
JK52-14C069-BF.vbf	Range Rover (L405)	DRDM - Driver Rear Door Module	DATA
JK52-14C069-BG.vbf	Range Rover (L405)	DRDM - Driver Rear Door Module	DATA
JK52-14C085-AB.vbf	Range Rover (L405)	HCM - Headlamp Control Module #1	DATA
JK52-14C085-AD.vbf	Range Rover (L405)	HCM - Headlamp Control Module #1	DATA
JK52-14C085-AE.vbf	Range Rover (L405)	HCM - Headlamp Control Module #1	DATA
JK52-14C085-AF.vbf	Range Rover (L405)	HCM - Headlamp Control Module #1	DATA
JK52-14C085-AG.vbf	Range Rover (L405)	HCM - Headlamp Control Module #1	DATA
JK52-14C085-AJ.vbf	Range Rover (L405)	HCM - Headlamp Control Module #1	DATA
JK52-14C085-AK.vbf	Range Rover (L405)	HCM - Headlamp Control Module #1	DATA
JK52-14C085-BB.vbf	Range Rover (L405)	Not specified	DATA
JK52-14C085-BD.vbf	Range Rover (L405)	Not specified	DATA
JK52-14C085-BE.vbf	Range Rover (L405)	Not specified	DATA
JK52-14C085-BF.vbf	Range Rover (L405)	Not specified	DATA
JK52-14C085-BG.vbf	Range Rover (L405)	Not specified	DATA
JK52-14C085-BJ.vbf	Range Rover (L405)	Not specified	DATA
JK52-14C085-BK.vbf	Range Rover (L405)	Not specified	DATA
JK52-14C091-AC.vbf	Range Rover (L405)	PAM - Parking Assist Control Module	CARCFG
JK52-14C091-AD.vbf	Range Rover (L405)	PAM - Parking Assist Control Module	CARCFG
JK52-14C091-AF.vbf	Range Rover (L405)	PAM - Parking Assist Control Module	CARCFG
JK52-14C091-AG.vbf	Range Rover (L405)	PAM - Parking Assist Control Module	CARCFG
JK52-14C091-AH.vbf	Range Rover (L405)	PAM - Parking Assist Control Module	CARCFG
JK52-14C091-AJ.vbf	Range Rover (L405)	PAM - Parking Assist Control Module	CARCFG
JK52-14C091-AK.vbf	Range Rover (L405)	PAM - Parking Assist Control Module	CARCFG
JK52-14C091-AL.vbf	Range Rover (L405)	PAM - Parking Assist Control Module	CARCFG
JK52-14C091-AM.vbf	Range Rover (L405)	PAM - Parking Assist Control Module	CARCFG
JK52-14C091-AP.vbf	Range Rover (L405)	PAM - Parking Assist Control Module	DATA
JK52-14C098-CA.vbf	Range Rover Sport (L494)	RCM - Restraints Control Module	DATA
JK52-14C098-DA.vbf	Range Rover Sport (L494)	RCM - Restraints Control Module	DATA
JK52-14C098-EA.vbf	Range Rover (L405)	RCM - Restraints Control Module	DATA
JK52-14C098-EB.vbf	Range Rover Sport (L494)	RCM - Restraints Control Module	DATA
JK52-14C098-EC.vbf	Range Rover Sport (L494)	RCM - Restraints Control Module	DATA
JK52-14C098-ED.vbf	Range Rover Sport (L494)	RCM - Restraints Control Module	DATA
JK52-14C098-EF.vbf	Range Rover Sport (L494)	RCM - Restraints Control Module	DATA
JK52-14C098-FA.vbf	Range Rover (L405)	RCM - Restraints Control Module	DATA
JK52-14C098-GA.vbf	Range Rover (L405)	RCM - Restraints Control Module	DATA
JK52-14C098-GB.vbf	Range Rover (L405)	RCM - Restraints Control Module	DATA
JK52-14C098-GC.vbf	Range Rover (L405)	RCM - Restraints Control Module	DATA
JK52-14C098-GD.vbf	Range Rover Sport (L494)	RCM - Restraints Control Module	DATA
JK52-14C098-GF.vbf	Range Rover (L405)	RCM - Restraints Control Module	DATA
JK52-14C105-AC.vbf	Range Rover (L405)	TMC Traffic Message Channel Module	EXE
JK52-14C105-AD.vbf	Range Rover (L405)	TMC Traffic Message Channel Module	EXE
JK52-14C105-AE.vbf	Range Rover (L405)	TMC Traffic Message Channel Module	EXE
JK52-14C105-BC.vbf	Range Rover (L405)	TMC Traffic Message Channel Module	EXE
JK52-14C105-BD.vbf	Range Rover (L405)	TMC Traffic Message Channel Module	EXE
JK52-14C105-BE.vbf	Range Rover (L405)	TMC Traffic Message Channel Module	EXE
JK52-14C109-AB.vbf	Range Rover (L405)	PDM - Passenger Front Door Module	DATA
JK52-14C109-AD.vbf	Range Rover (L405)	PDM - Passenger Front Door Module	DATA
JK52-14C109-AF.vbf	Range Rover (L405)	PDM - Passenger Front Door Module	DATA
JK52-14C109-AG.vbf	Range Rover (L405)	PDM - Passenger Front Door Module	DATA
JK52-14C109-BB.vbf	Range Rover (L405)	PDM - Passenger Front Door Module	DATA
JK52-14C109-BD.vbf	Range Rover (L405)	PDM - Passenger Front Door Module	DATA
JK52-14C109-BF.vbf	Range Rover (L405)	PDM - Passenger Front Door Module	DATA
JK52-14C109-BG.vbf	Range Rover (L405)	PDM - Passenger Front Door Module	DATA
JK52-14C113-AB.vbf	Range Rover (L405)	PRDM - Passenger Rear Door Module	DATA
JK52-14C113-AD.vbf	Range Rover (L405)	PRDM - Passenger Rear Door Module	DATA
JK52-14C113-AF.vbf	Range Rover (L405)	PRDM - Passenger Rear Door Module	DATA
JK52-14C113-AG.vbf	Range Rover (L405)	PRDM - Passenger Rear Door Module	DATA
JK52-14C113-BB.vbf	Range Rover (L405)	PRDM - Passenger Rear Door Module	DATA
JK52-14C113-BD.vbf	Range Rover (L405)	PRDM - Passenger Rear Door Module	DATA
JK52-14C113-BF.vbf	Range Rover (L405)	PRDM - Passenger Rear Door Module	DATA
JK52-14C113-BG.vbf	Range Rover (L405)	PRDM - Passenger Rear Door Module	DATA
JK52-14C152-AA.vbf	Range Rover (L405)	TPM - Tire Pressure Monitor Module	DATA
JK52-14C152-AB.vbf	Range Rover (L405)	TPM - Tire Pressure Monitor Module	DATA
JK52-14C152-AC.vbf	Range Rover (L405)	TPM - Tire Pressure Monitor Module	DATA
JK52-14C152-AD.vbf	Range Rover (L405)	TPM - Tire Pressure Monitor Module	DATA
JK52-14C185-AB.vbf	Range Rover (L405)	BCM - Body Control Module	DATA
JK52-14C185-AC.vbf	Range Rover (L405)	BCM - Body Control Module	DATA

File name	Vehicle line (indicative)	Module (ECU)	Type
JK52-14C185-AD.vbf	Range Rover (L405)	BCM - Body Control Module	DATA
JK52-14C185-AE.vbf	Range Rover (L405)	BCM - Body Control Module	DATA
JK52-14C185-AF.vbf	Range Rover (L405)	BCM - Body Control Module	DATA
JK52-14C218-AA.vbf	Range Rover (L405)	PSCM - Power Steering Control Module	EXE
JK52-14C218-BA.vbf	Range Rover (L405)	PSCM - Power Steering Control Module	EXE
JK52-14C218-BB.vbf	Range Rover (L405)	PSCM - Power Steering Control Module	EXE
JK52-14C218-CA.vbf	Range Rover (L405)	PSCM - Power Steering Control Module	EXE
JK52-14C218-CB.vbf	Range Rover (L405)	PSCM - Power Steering Control Module	EXE
JK52-14C218-DA.vbf	Range Rover (L405)	PSCM - Power Steering Control Module	EXE
JK52-14C218-DB.vbf	Range Rover (L405)	PSCM - Power Steering Control Module	EXE
JK52-14C527-BA.vbf	Range Rover (L405)	AAM - Audio Amplifier Module	DATA
JK52-14C527-BAA.vbf	Range Rover (L405)	AAM - Audio Amplifier Module	DATA
JK52-14C527-BAC.vbf	Range Rover (L405)	AAM - Audio Amplifier Module	DATA
JK52-14C527-BB.vbf	Range Rover (L405)	AAM - Audio Amplifier Module	DATA
JK52-14C527-BBA.vbf	Range Rover (L405)	AAM - Audio Amplifier Module	DATA
JK52-14C527-BC.vbf	Range Rover (L405)	AAM - Audio Amplifier Module	DATA
JK52-14C527-BCA.vbf	Range Rover (L405)	AAM - Audio Amplifier Module	DATA
JK52-14C527-BCB.vbf	Range Rover (L405)	AAM - Audio Amplifier Module	DATA
JK52-14C527-BDA.vbf	Range Rover (L405)	AAM - Audio Amplifier Module	DATA
JK52-14C527-BDB.vbf	Range Rover (L405)	AAM - Audio Amplifier Module	DATA
JK52-14C527-BEA.vbf	Range Rover (L405)	AAM - Audio Amplifier Module	DATA
JK52-14C527-BEB.vbf	Range Rover (L405)	AAM - Audio Amplifier Module	DATA
JK52-14C527-BFA.vbf	Range Rover (L405)	AAM - Audio Amplifier Module	DATA
JK52-14C527-CA.vbf	Range Rover (L405)	AAM - Audio Amplifier Module	DATA
JK52-14C527-CAA.vbf	Range Rover (L405)	AAM - Audio Amplifier Module	DATA
JK52-14C527-CAB.vbf	Range Rover (L405)	AAM - Audio Amplifier Module	DATA
JK52-14C527-CB.vbf	Range Rover (L405)	AAM - Audio Amplifier Module	DATA
JK52-14C527-CBA.vbf	Range Rover (L405)	AAM - Audio Amplifier Module	DATA
JK52-14C527-CBB.vbf	Range Rover (L405)	AAM - Audio Amplifier Module	DATA
JK52-14C527-CBC.vbf	Range Rover (L405)	AAM - Audio Amplifier Module	DATA
JK52-14C527-CBD.vbf	Range Rover (L405)	AAM - Audio Amplifier Module	DATA
JK52-14C527-CCA.vbf	Range Rover (L405)	AAM - Audio Amplifier Module	DATA
JK52-14C527-CCB.vbf	Range Rover (L405)	AAM - Audio Amplifier Module	DATA
JK52-14C527-CDA.vbf	Range Rover (L405)	AAM - Audio Amplifier Module	DATA
JK52-14C527-CDB.vbf	Range Rover (L405)	AAM - Audio Amplifier Module	DATA
JK52-14C527-CEA.vbf	Range Rover (L405)	AAM - Audio Amplifier Module	DATA
JK52-14C527-CEB.vbf	Range Rover (L405)	AAM - Audio Amplifier Module	DATA
JK52-14C527-CFA.vbf	Range Rover (L405)	AAM - Audio Amplifier Module	DATA
JK52-14C527-DA.vbf	Range Rover (L405)	AAM - Audio Amplifier Module	DATA
JK52-14C527-DAA.vbf	Range Rover (L405)	AAM - Audio Amplifier Module	DATA
JK52-14C527-DAB.vbf	Range Rover (L405)	AAM - Audio Amplifier Module	DATA
JK52-14C527-DAC.vbf	Range Rover (L405)	AAM - Audio Amplifier Module	DATA
JK52-14C527-DB.vbf	Range Rover (L405)	AAM - Audio Amplifier Module	DATA
JK52-14C527-DBA.vbf	Range Rover (L405)	AAM - Audio Amplifier Module	DATA
JK52-14C527-DBB.vbf	Range Rover (L405)	AAM - Audio Amplifier Module	DATA
JK52-14C527-DBC.vbf	Range Rover (L405)	AAM - Audio Amplifier Module	DATA
JK52-14C527-DBD.vbf	Range Rover (L405)	AAM - Audio Amplifier Module	DATA
JK52-14C527-DC.vbf	Range Rover (L405)	AAM - Audio Amplifier Module	DATA
JK52-14C527-DCA.vbf	Range Rover (L405)	AAM - Audio Amplifier Module	DATA
JK52-14C527-DCB.vbf	Range Rover (L405)	AAM - Audio Amplifier Module	DATA
JK52-14C527-DDA.vbf	Range Rover (L405)	AAM - Audio Amplifier Module	DATA
JK52-14C527-DDB.vbf	Range Rover (L405)	AAM - Audio Amplifier Module	DATA
JK52-14C527-DEA.vbf	Range Rover (L405)	AAM - Audio Amplifier Module	DATA
JK52-14C527-DEB.vbf	Range Rover (L405)	AAM - Audio Amplifier Module	DATA
JK52-14C527-DFA.vbf	Range Rover (L405)	AAM - Audio Amplifier Module	DATA
JK52-14C527-DFB.vbf	Range Rover (L405)	AAM - Audio Amplifier Module	DATA
JK52-14C527-DFC.vbf	Range Rover (L405)	AAM - Audio Amplifier Module	DATA
JK52-14C527-FA.vbf	Range Rover (L405)	AAM - Audio Amplifier Module	DATA
JK52-14C527-FAA.vbf	Range Rover (L405)	AAM - Audio Amplifier Module	DATA
JK52-14C527-FAB.vbf	Range Rover (L405)	AAM - Audio Amplifier Module	DATA
JK52-14C527-FB.vbf	Range Rover (L405)	AAM - Audio Amplifier Module	DATA
JK52-14C527-FCA.vbf	Range Rover (L405)	AAM - Audio Amplifier Module	DATA
JK52-14C527-FDA.vbf	Range Rover (L405)	AAM - Audio Amplifier Module	DATA
JK52-14C527-FEA.vbf	Range Rover (L405)	AAM - Audio Amplifier Module	DATA
JK52-14C527-GA.vbf	Range Rover (L405)	AAM - Audio Amplifier Module	DATA
JK52-14C527-GAA.vbf	Range Rover (L405)	AAM - Audio Amplifier Module	DATA
JK52-14C527-GB.vbf	Range Rover (L405)	AAM - Audio Amplifier Module	DATA
JK52-14C527-GBA.vbf	Range Rover (L405)	AAM - Audio Amplifier Module	DATA
JK52-14C527-GBB.vbf	Range Rover (L405)	AAM - Audio Amplifier Module	DATA
JK52-14C527-GBC.vbf	Range Rover (L405)	AAM - Audio Amplifier Module	DATA
JK52-14C527-GCA.vbf	Range Rover (L405)	AAM - Audio Amplifier Module	DATA
JK52-14C527-GDA.vbf	Range Rover (L405)	AAM - Audio Amplifier Module	DATA
JK52-14C527-GEA.vbf	Range Rover (L405)	AAM - Audio Amplifier Module	DATA
JK52-14C527-HA.vbf	Range Rover (L405)	AAM - Audio Amplifier Module	DATA
JK52-14C527-HAA.vbf	Range Rover (L405)	AAM - Audio Amplifier Module	DATA
JK52-14C527-HAB.vbf	Range Rover (L405)	AAM - Audio Amplifier Module	DATA

File name	Vehicle line (indicative)	Module (ECU)	Type
JK52-14C527-HB.vbf	Range Rover (L405)	AAM - Audio Amplifier Module	DATA
JK52-14C527-HBA.vbf	Range Rover (L405)	AAM - Audio Amplifier Module	DATA
JK52-14C527-HBB.vbf	Range Rover (L405)	AAM - Audio Amplifier Module	DATA
JK52-14C527-HBC.vbf	Range Rover (L405)	AAM - Audio Amplifier Module	DATA
JK52-14C527-HC.vbf	Range Rover (L405)	AAM - Audio Amplifier Module	DATA
JK52-14C527-HCA.vbf	Range Rover (L405)	AAM - Audio Amplifier Module	DATA
JK52-14C527-HDA.vbf	Range Rover (L405)	AAM - Audio Amplifier Module	DATA
JK52-14C527-HEA.vbf	Range Rover (L405)	AAM - Audio Amplifier Module	DATA
JK52-14C527-HFB.vbf	Range Rover (L405)	AAM - Audio Amplifier Module	DATA
JK52-14C527-HFC.vbf	Range Rover (L405)	AAM - Audio Amplifier Module	DATA
JK52-14C527-JB.vbf	Range Rover (L405)	AAM - Audio Amplifier Module	DATA
JK52-14C527-JC.vbf	Range Rover (L405)	AAM - Audio Amplifier Module	DATA
JK52-14C527-KA.vbf	Range Rover (L405)	AAM - Audio Amplifier Module	DATA
JK52-14C527-KB.vbf	Range Rover (L405)	AAM - Audio Amplifier Module	DATA
JK52-14C527-LA.vbf	Range Rover (L405)	AAM - Audio Amplifier Module	DATA
JK52-14C527-LB.vbf	Range Rover (L405)	AAM - Audio Amplifier Module	DATA
JK52-14C527-MA.vbf	Range Rover (L405)	AAM - Audio Amplifier Module	DATA
JK52-14C527-MB.vbf	Range Rover (L405)	AAM - Audio Amplifier Module	DATA
JK52-14C527-NB.vbf	Range Rover (L405)	AAM - Audio Amplifier Module	DATA
JK52-14C527-NC.vbf	Range Rover (L405)	AAM - Audio Amplifier Module	DATA
JK52-14C527-PA.vbf	Range Rover (L405)	AAM - Audio Amplifier Module	DATA
JK52-14C527-PB.vbf	Range Rover (L405)	AAM - Audio Amplifier Module	DATA
JK52-14C527-PC.vbf	Range Rover (L405)	AAM - Audio Amplifier Module	DATA
JK52-14C548-AA.vbf	Range Rover (L405)	PSM - Passenger Front Seat Module	EXE
JK52-14C548-AB.vbf	Range Rover (L405)	PSM - Passenger Front Seat Module	EXE
JK52-14C548-AC.vbf	Range Rover (L405)	PSM - Passenger Front Seat Module	EXE
JK52-14C548-AD.vbf	Range Rover (L405)	PSM - Passenger Front Seat Module	EXE
JK52-14C549-ABA.vbf	Range Rover (L405)	PSM - Passenger Front Seat Module	EXE
JK52-14C549-ABB.vbf	Range Rover (L405)	PSM - Passenger Front Seat Module	EXE
JK52-14C549-ACA.vbf	Range Rover (L405)	PSM - Passenger Front Seat Module	EXE
JK52-14C549-ACB.vbf	Range Rover (L405)	PSM - Passenger Front Seat Module	EXE
JK52-14C549-BEA.vbf	Range Rover (L405)	PSM - Passenger Front Seat Module	EXE
JK52-14C549-BEB.vbf	Range Rover (L405)	PSM - Passenger Front Seat Module	EXE
JK52-14C549-BEC.vbf	Range Rover (L405)	PSM - Passenger Front Seat Module	EXE
JK52-14C549-BED.vbf	Range Rover (L405)	PSM - Passenger Front Seat Module	EXE
JK52-14C549-BEE.vbf	Range Rover (L405)	PSM - Passenger Front Seat Module	EXE
JK52-14C549-CEA.vbf	Range Rover (L405)	PSM - Passenger Front Seat Module	EXE
JK52-14C549-CEB.vbf	Range Rover (L405)	PSM - Passenger Front Seat Module	EXE
JK52-14C549-CEC.vbf	Range Rover (L405)	DSM - Driver Front Seat Module	EXE
JK52-14C549-CED.vbf	Range Rover (L405)	DSM - Driver Front Seat Module	EXE
JK52-14C549-CEE.vbf	Range Rover (L405)	DSM - Driver Front Seat Module	EXE
JK52-14C549-CEF.vbf	Range Rover (L405)	DSM - Driver Front Seat Module	EXE
JK52-14C549-CEG.vbf	Range Rover (L405)	DSM - Driver Front Seat Module	EXE
JK52-14C549-DEB.vbf	Range Rover (L405)	PSM - Passenger Front Seat Module	EXE
JK52-14C549-DEC.vbf	Range Rover (L405)	DSM - Driver Front Seat Module	EXE
JK52-14C549-DED.vbf	Range Rover (L405)	DSM - Driver Front Seat Module	EXE
JK52-14C549-DEE.vbf	Range Rover (L405)	DSM - Driver Front Seat Module	EXE
JK52-14C549-DEF.vbf	Range Rover (L405)	DSM - Driver Front Seat Module	EXE
JK52-14C549-EEB.vbf	Range Rover (L405)	PSM - Passenger Front Seat Module	EXE
JK52-14C549-EEC.vbf	Range Rover (L405)	PSM - Passenger Front Seat Module	EXE
JK52-14C549-EED.vbf	Range Rover (L405)	PSM - Passenger Front Seat Module	EXE
JK52-14C549-EEE.vbf	Range Rover (L405)	PSM - Passenger Front Seat Module	EXE
JK52-14C549-FEB.vbf	Range Rover (L405)	PSM - Passenger Front Seat Module	EXE
JK52-14C549-FEC.vbf	Range Rover (L405)	PSM - Passenger Front Seat Module	EXE
JK52-14C549-GEA.vbf	Range Rover (L405)	PSM - Passenger Front Seat Module	EXE
JK52-14C549-GEB.vbf	Range Rover (L405)	PSM - Passenger Front Seat Module	EXE
JK52-14C549-HEA.vbf	Range Rover (L405)	DSM - Driver Front Seat Module	EXE
JK52-14C549-HEB.vbf	Range Rover (L405)	DSM - Driver Front Seat Module	EXE
JK52-14C549-HEC.vbf	Range Rover (L405)	DSM - Driver Front Seat Module	EXE
JK52-14C549-HED.vbf	Range Rover (L405)	DSM - Driver Front Seat Module	EXE
JK52-14C549-HEE.vbf	Range Rover (L405)	DSM - Driver Front Seat Module	EXE
JK52-14C549-JEA.vbf	Range Rover (L405)	DSM - Driver Front Seat Module	EXE
JK52-14C549-JEB.vbf	Range Rover (L405)	DSM - Driver Front Seat Module	EXE
JK52-14C549-JEC.vbf	Range Rover (L405)	DSM - Driver Front Seat Module	EXE
JK52-14C549-JED.vbf	Range Rover (L405)	DSM - Driver Front Seat Module	EXE
JK52-14C549-KEA.vbf	Range Rover (L405)	DSM - Driver Front Seat Module	EXE
JK52-14C549-KEB.vbf	Range Rover (L405)	DSM - Driver Front Seat Module	EXE
JK52-14C549-KEC.vbf	Range Rover (L405)	DSM - Driver Front Seat Module	EXE
JK52-14C549-KED.vbf	Range Rover (L405)	DSM - Driver Front Seat Module	EXE
JK52-14C549-KEE.vbf	Range Rover (L405)	DSM - Driver Front Seat Module	EXE
JK52-14C549-LEA.vbf	Range Rover (L405)	DSM - Driver Front Seat Module	EXE
JK52-14C549-LEB.vbf	Range Rover (L405)	DSM - Driver Front Seat Module	EXE
JK52-14C549-LEC.vbf	Range Rover (L405)	DSM - Driver Front Seat Module	EXE
JK52-14C549-LED.vbf	Range Rover (L405)	DSM - Driver Front Seat Module	EXE
JK52-14C549-MEA.vbf	Range Rover (L405)	DSM - Driver Front Seat Module	EXE
JK52-14C549-MEB.vbf	Range Rover (L405)	DSM - Driver Front Seat Module	EXE

File name	Vehicle line (indicative)	Module (ECU)	Type
JK52-14C549-MEC.vbf	Range Rover (L405)	DSM - Driver Front Seat Module	EXE
JK52-14C549-MED.vbf	Range Rover (L405)	DSM - Driver Front Seat Module	EXE
JK52-14C549-MEE.vbf	Range Rover (L405)	DSM - Driver Front Seat Module	EXE
JK52-14C549-NEA.vbf	Range Rover (L405)	DSM - Driver Front Seat Module	EXE
JK52-14C549-NEB.vbf	Range Rover (L405)	DSM - Driver Front Seat Module	EXE
JK52-14C549-NEC.vbf	Range Rover (L405)	DSM - Driver Front Seat Module	EXE
JK52-14C549-NED.vbf	Range Rover (L405)	DSM - Driver Front Seat Module	EXE
JK52-14C549-PEA.vbf	Range Rover (L405)	PSM - Passenger Front Seat Module	EXE
JK52-14C549-PEB.vbf	Range Rover (L405)	PSM - Passenger Front Seat Module	EXE
JK52-14C549-PEC.vbf	Range Rover (L405)	PSM - Passenger Front Seat Module	EXE
JK52-14C549-REA.vbf	Range Rover (L405)	PSM - Passenger Front Seat Module	EXE
JK52-14C549-REB.vbf	Range Rover (L405)	PSM - Passenger Front Seat Module	EXE
JK52-14C549-REC.vbf	Range Rover (L405)	PSM - Passenger Front Seat Module	EXE
JK52-14C570-SAB.vbf	Range Rover (L405)	PCM - Powertrain Control Module	EXE
JK52-14C570-SAD.vbf	Range Rover (L405)	PCM - Powertrain Control Module	EXE
JK52-14C570-SAF.vbf	Range Rover (L405)	PCM - Powertrain Control Module	EXE
JK52-14C570-SAG.vbf	Range Rover (L405)	PCM - Powertrain Control Module	EXE
JK52-14C570-SBD.vbf	Range Rover (L405)	PCM - Powertrain Control Module	EXE
JK52-14C570-SCB.vbf	Range Rover (L405)	PCM - Powertrain Control Module	EXE
JK52-14C570-SCD.vbf	Range Rover (L405)	PCM - Powertrain Control Module	EXE
JK52-14C570-SDD.vbf	Range Rover (L405)	PCM - Powertrain Control Module	EXE
JK52-14C570-SED.vbf	Range Rover (L405)	PCM - Powertrain Control Module	EXE
JK52-14C570-STB.vbf	Range Rover (L405)	PCM - Powertrain Control Module	EXE
JK52-14C570-STD.vbf	Range Rover (L405)	PCM - Powertrain Control Module	EXE
JK52-14C609-AA.vbf	Range Rover (L405)	PSCM - Power Steering Control Module	EXE
JK52-14C609-AB.vbf	Range Rover (L405)	PSCM - Power Steering Control Module	EXE
JK52-14D183-AB.vbf	Range Rover (L405)	OCS - Restraints Occupant Classification System Module	DATA
JK52-14D183-BA.vbf	Range Rover (L405)	OCS - Restraints Occupant Classification System Module	DATA
JK52-14D564-AA.vbf	Range Rover (L405)	SODL - Side Obstacle Detection Control Module - Left	DATA
JK52-14D564-AC.vbf	Range Rover (L405)	SODL - Side Obstacle Detection Control Module - Left	DATA
JK52-14D564-BA.vbf	Range Rover (L405)	SODR - Side Obstacle Detection Control Module - Right	DATA
JK52-14D564-BC.vbf	Range Rover (L405)	SODR - Side Obstacle Detection Control Module - Right	DATA
JK52-14E094-JAB.vbf	Range Rover (L405)	CHCM - Chassis Control Module	EXE
JK52-14E094-JAD.vbf	Range Rover (L405)	CHCM - Chassis Control Module	EXE
JK52-14E094-JAE.vbf	Range Rover (L405)	CHCM - Chassis Control Module	EXE
JK52-14E094-JAF.vbf	Range Rover (L405)	CHCM - Chassis Control Module	EXE
JK52-14E094-JAG.vbf	Range Rover (L405)	CHCM - Chassis Control Module	EXE
JK52-14E094-JAH.vbf	Range Rover (L405)	CHCM - Chassis Control Module	EXE
JK52-14E094-JAJ.vbf	Range Rover (L405)	CHCM - Chassis Control Module	EXE
JK52-14E094-JAK.vbf	Range Rover (L405)	CHCM - Chassis Control Module	EXE
JK52-14E094-JAL.vbf	Range Rover (L405)	CHCM - Chassis Control Module	EXE
JK52-14E094-JBB.vbf	Range Rover (L405)	CHCM - Chassis Control Module	EXE
JK52-14E094-JBD.vbf	Range Rover (L405)	CHCM - Chassis Control Module	EXE
JK52-14E094-JBE.vbf	Range Rover (L405)	CHCM - Chassis Control Module	EXE
JK52-14E094-JBF.vbf	Range Rover (L405)	CHCM - Chassis Control Module	EXE
JK52-14E094-JBG.vbf	Range Rover (L405)	CHCM - Chassis Control Module	EXE
JK52-14E094-JBH.vbf	Range Rover (L405)	CHCM - Chassis Control Module	EXE
JK52-14E094-JBJ.vbf	Range Rover (L405)	CHCM - Chassis Control Module	EXE
JK52-14E094-JBK.vbf	Range Rover (L405)	CHCM - Chassis Control Module	EXE
JK52-14E094-JBL.vbf	Range Rover (L405)	CHCM - Chassis Control Module	EXE
JK52-14E094-JCB.vbf	Range Rover (L405)	CHCM - Chassis Control Module	EXE
JK52-14E094-JCD.vbf	Range Rover (L405)	CHCM - Chassis Control Module	EXE
JK52-14E094-JCE.vbf	Range Rover (L405)	CHCM - Chassis Control Module	EXE
JK52-14E094-JCF.vbf	Range Rover (L405)	CHCM - Chassis Control Module	EXE
JK52-14E094-JCG.vbf	Range Rover (L405)	CHCM - Chassis Control Module	EXE
JK52-14E094-JCH.vbf	Range Rover (L405)	CHCM - Chassis Control Module	EXE
JK52-14E094-JCJ.vbf	Range Rover (L405)	CHCM - Chassis Control Module	EXE
JK52-14E094-JEB.vbf	Range Rover (L405)	CHCM - Chassis Control Module	EXE
JK52-14E094-JED.vbf	Range Rover (L405)	CHCM - Chassis Control Module	EXE
JK52-14E094-JEE.vbf	Range Rover (L405)	CHCM - Chassis Control Module	EXE
JK52-14E094-JEF.vbf	Range Rover (L405)	CHCM - Chassis Control Module	EXE
JK52-14E094-JEG.vbf	Range Rover (L405)	CHCM - Chassis Control Module	EXE
JK52-14E094-JEH.vbf	Range Rover (L405)	CHCM - Chassis Control Module	EXE
JK52-14E094-JEJ.vbf	Range Rover (L405)	CHCM - Chassis Control Module	EXE
JK52-14E094-JGB.vbf	Range Rover (L405)	CHCM - Chassis Control Module	EXE
JK52-14E094-JGD.vbf	Range Rover (L405)	CHCM - Chassis Control Module	EXE
JK52-14E094-JGE.vbf	Range Rover (L405)	CHCM - Chassis Control Module	EXE
JK52-14E094-JGF.vbf	Range Rover (L405)	CHCM - Chassis Control Module	EXE
JK52-14E094-JGG.vbf	Range Rover (L405)	CHCM - Chassis Control Module	EXE
JK52-14E094-JGH.vbf	Range Rover (L405)	CHCM - Chassis Control Module	EXE
JK52-14E094-JGJ.vbf	Range Rover (L405)	CHCM - Chassis Control Module	EXE
JK52-14E094-JHB.vbf	Range Rover (L405)	CHCM - Chassis Control Module	EXE
JK52-14E094-JHD.vbf	Range Rover (L405)	CHCM - Chassis Control Module	EXE
JK52-14E094-JHE.vbf	Range Rover (L405)	CHCM - Chassis Control Module	EXE
JK52-14E094-JHF.vbf	Range Rover (L405)	CHCM - Chassis Control Module	EXE
JK52-14E094-JHG.vbf	Range Rover (L405)	CHCM - Chassis Control Module	EXE

File name	Vehicle line (indicative)	Module (ECU)	Type
JK52-14E094-JHH.vbf	Range Rover (L405)	CHCM - Chassis Control Module	EXE
JK52-14E094-JHJ.vbf	Range Rover (L405)	CHCM - Chassis Control Module	EXE
JK52-14E094-JJB.vbf	Range Rover (L405)	CHCM - Chassis Control Module	EXE
JK52-14E094-JJD.vbf	Range Rover (L405)	CHCM - Chassis Control Module	EXE
JK52-14E094-JJE.vbf	Range Rover (L405)	CHCM - Chassis Control Module	EXE
JK52-14E094-JJF.vbf	Range Rover (L405)	CHCM - Chassis Control Module	EXE
JK52-14E094-JJG.vbf	Range Rover (L405)	CHCM - Chassis Control Module	EXE
JK52-14E094-JJH.vbf	Range Rover (L405)	CHCM - Chassis Control Module	EXE
JK52-14E094-JJJ.vbf	Range Rover (L405)	CHCM - Chassis Control Module	EXE
JK52-14E094-JKB.vbf	Range Rover (L405)	CHCM - Chassis Control Module	EXE
JK52-14E094-JKD.vbf	Range Rover (L405)	CHCM - Chassis Control Module	EXE
JK52-14E094-JKE.vbf	Range Rover (L405)	CHCM - Chassis Control Module	EXE
JK52-14E094-JKF.vbf	Range Rover (L405)	CHCM - Chassis Control Module	EXE
JK52-14E094-JKG.vbf	Range Rover (L405)	CHCM - Chassis Control Module	EXE
JK52-14E094-JKH.vbf	Range Rover (L405)	CHCM - Chassis Control Module	EXE
JK52-14E094-JKJ.vbf	Range Rover (L405)	CHCM - Chassis Control Module	EXE
JK52-14E094-JMB.vbf	Range Rover (L405)	CHCM - Chassis Control Module	EXE
JK52-14E094-JMD.vbf	Range Rover (L405)	CHCM - Chassis Control Module	EXE
JK52-14E094-JME.vbf	Range Rover (L405)	CHCM - Chassis Control Module	EXE
JK52-14E094-JMF.vbf	Range Rover (L405)	CHCM - Chassis Control Module	EXE
JK52-14E094-JMG.vbf	Range Rover (L405)	CHCM - Chassis Control Module	EXE
JK52-14E094-JMH.vbf	Range Rover (L405)	CHCM - Chassis Control Module	EXE
JK52-14E094-JMJ.vbf	Range Rover (L405)	CHCM - Chassis Control Module	EXE
JK52-14E094-JNB.vbf	Range Rover (L405)	CHCM - Chassis Control Module	EXE
JK52-14E094-JND.vbf	Range Rover (L405)	CHCM - Chassis Control Module	EXE
JK52-14E094-JNE.vbf	Range Rover (L405)	CHCM - Chassis Control Module	EXE
JK52-14E094-JNF.vbf	Range Rover (L405)	CHCM - Chassis Control Module	EXE
JK52-14E094-JNG.vbf	Range Rover (L405)	CHCM - Chassis Control Module	EXE
JK52-14E094-JNH.vbf	Range Rover (L405)	CHCM - Chassis Control Module	EXE
JK52-14E094-JNJ.vbf	Range Rover (L405)	CHCM - Chassis Control Module	EXE
JK52-14F022-AB.vbf	Range Rover (L405)	Not specified	DATA
JK52-14F022-AD.vbf	Range Rover (L405)	Not specified	DATA
JK52-14F022-AE.vbf	Range Rover (L405)	Not specified	DATA
JK52-14F022-AF.vbf	Range Rover (L405)	Not specified	DATA
JK52-14F022-AG.vbf	Range Rover (L405)	Not specified	DATA
JK52-14F022-AJ.vbf	Range Rover (L405)	Not specified	DATA
JK52-14F022-AL.vbf	Range Rover (L405)	Not specified	DATA
JK52-14F022-AM.vbf	Range Rover (L405)	Not specified	DATA
JK52-14F022-AN.vbf	Range Rover (L405)	Not specified	DATA
JK52-14F022-CB.vbf	Range Rover (L405)	Not specified	DATA
JK52-14F022-CD.vbf	Range Rover (L405)	Not specified	DATA
JK52-14F022-CE.vbf	Range Rover (L405)	Not specified	DATA
JK52-14F022-CF.vbf	Range Rover (L405)	Not specified	DATA
JK52-14F022-CG.vbf	Range Rover (L405)	Not specified	DATA
JK52-14F022-CJ.vbf	Range Rover (L405)	Not specified	DATA
JK52-14F022-CL.vbf	Range Rover (L405)	Not specified	DATA
JK52-14F022-CM.vbf	Range Rover (L405)	Not specified	DATA
JK52-14F022-CN.vbf	Range Rover (L405)	Not specified	DATA
JK52-14F216-AA.vbf	Range Rover (L405)	RHVAC - Rear HVAC Control Module	SIGCFG
JK52-14F216-BA.vbf	Range Rover (L405)	RHVAC - Rear HVAC Control Module	SIGCFG
JK52-14F217-AA.vbf	Range Rover (L405)	RHVAC - Rear HVAC Control Module	EXE
JK52-14F217-BA.vbf	Range Rover (L405)	RHVAC - Rear HVAC Control Module	EXE
JK52-14F217-BB.vbf	Range Rover (L405)	RHVAC - Rear HVAC Control Module	EXE
JK52-14F217-BC.vbf	Range Rover (L405)	RHVAC - Rear HVAC Control Module	EXE
JK52-14F217-BD.vbf	Range Rover (L405)	RHVAC - Rear HVAC Control Module	EXE
JK52-14F217-BE.vbf	Range Rover (L405)	RHVAC - Rear HVAC Control Module	EXE
JK52-14F217-BF.vbf	Range Rover (L405)	RHVAC - Rear HVAC Control Module	EXE
JK52-14F219-AA.vbf	Range Rover (L405)	RHVAC - Rear HVAC Control Module	SBL
JK52-14F219-AB.vbf	Range Rover (L405)	RHVAC - Rear HVAC Control Module	SBL
JK52-14F230-AB.vbf	Range Rover (L405)	HUD - Head Up Display	EXE
JK52-14F230-AC.vbf	Range Rover (L405)	HUD - Head Up Display	EXE
JK52-14F230-AE.vbf	Range Rover (L405)	HUD - Head Up Display	EXE
JK52-14F230-AF.vbf	Range Rover (L405)	HUD - Head Up Display	EXE
JK52-14F230-BA.vbf	Range Rover (L405)	HUD - Head Up Display	EXE
JK52-14F230-BB.vbf	Range Rover (L405)	HUD - Head Up Display	EXE
JK52-14F230-XA.vbf	Range Rover (L405)	HUD - Head Up Display	EXE
JK52-14F231-AB.vbf	Range Rover (L405)	HUD - Head Up Display	DATA
JK52-14F231-AC.vbf	Range Rover (L405)	HUD - Head Up Display	DATA
JK52-14F231-AD.vbf	Range Rover (L405)	HUD - Head Up Display	DATA
JK52-14F231-AE.vbf	Range Rover (L405)	HUD - Head Up Display	DATA
JK52-14F232-AA.vbf	Range Rover (L405)	HUD - Head Up Display	SBL
JK52-14F232-BA.vbf	Range Rover (L405)	: HUD - Head Up Display	SBL
JK52-14F435-NAB.vbf	Range Rover (L405)	CHCMB - Chassis Control Module B	EXE
JK52-14F435-NAC.vbf	Range Rover (L405)	CHCMB - Chassis Control Module B	EXE
JK52-14F435-NAD.vbf	Range Rover (L405)	CHCMB - Chassis Control Module B	EXE
JK52-14F435-NAE.vbf	Range Rover (L405)	CHCMB - Chassis Control Module B	EXE

File name	Vehicle line (indicative)	Module (ECU)	Type
JK52-14F435-NAF.vbf	Range Rover (L405)	CHCMB - Chassis Control Module B	EXE
JK52-14F435-NAG.vbf	Range Rover (L405)	CHCMB - Chassis Control Module B	EXE
JK52-14F435-NAH.vbf	Range Rover (L405)	CHCMB - Chassis Control Module B	EXE
JK52-14F435-NAJ.vbf	Range Rover (L405)	CHCMB - Chassis Control Module B	EXE
JK52-14F435-NBB.vbf	Range Rover (L405)	CHCMB - Chassis Control Module B	EXE
JK52-14F435-NBC.vbf	Range Rover (L405)	CHCMB - Chassis Control Module B	EXE
JK52-14F435-NBD.vbf	Range Rover (L405)	CHCMB - Chassis Control Module B	EXE
JK52-14F435-NBE.vbf	Range Rover (L405)	CHCMB - Chassis Control Module B	EXE
JK52-14F435-NBF.vbf	Range Rover (L405)	CHCMB - Chassis Control Module B	EXE
JK52-14F435-NBG.vbf	Range Rover (L405)	CHCMB - Chassis Control Module B	EXE
JK52-14F435-NBH.vbf	Range Rover (L405)	CHCMB - Chassis Control Module B	EXE
JK52-14F435-NBJ.vbf	Range Rover (L405)	CHCMB - Chassis Control Module B	EXE
JK52-14F435-NCB.vbf	Range Rover (L405)	CHCMB - Chassis Control Module B	EXE
JK52-14F435-NCC.vbf	Range Rover (L405)	CHCMB - Chassis Control Module B	EXE
JK52-14F435-NCD.vbf	Range Rover (L405)	CHCMB - Chassis Control Module B	EXE
JK52-14F435-NCE.vbf	Range Rover (L405)	CHCMB - Chassis Control Module B	EXE
JK52-14F435-NCF.vbf	Range Rover (L405)	CHCMB - Chassis Control Module B	EXE
JK52-14F435-NCG.vbf	Range Rover (L405)	CHCMB - Chassis Control Module B	EXE
JK52-14F435-NCH.vbf	Range Rover (L405)	CHCMB - Chassis Control Module B	EXE
JK52-14F435-NCJ.vbf	Range Rover (L405)	CHCMB - Chassis Control Module B	EXE
JK52-14F435-NDB.vbf	Range Rover (L405)	CHCMB - Chassis Control Module B	EXE
JK52-14F435-NDC.vbf	Range Rover (L405)	CHCMB - Chassis Control Module B	EXE
JK52-14F435-NDD.vbf	Range Rover (L405)	CHCMB - Chassis Control Module B	EXE
JK52-14F435-NDE.vbf	Range Rover (L405)	CHCMB - Chassis Control Module B	EXE
JK52-14F435-NDF.vbf	Range Rover (L405)	CHCMB - Chassis Control Module B	EXE
JK52-14F435-NDG.vbf	Range Rover (L405)	CHCMB - Chassis Control Module B	EXE
JK52-14F435-NDH.vbf	Range Rover (L405)	CHCMB - Chassis Control Module B	EXE
JK52-14F435-NDJ.vbf	Range Rover (L405)	CHCMB - Chassis Control Module B	EXE
JK52-14F529-BA.vbf	Range Rover (L405)	GWM - Gateway Module A	EXE
JK52-14F530-AC.vbf	Range Rover (L405)	GWM - Gateway Module A	EXE
JK52-14F530-AE.vbf	Range Rover (L405)	GWM - Gateway Module A	EXE
JK52-14F530-BA.vbf	Range Rover (L405)	GWM - Gateway Module A	EXE
JK52-14F530-BC.vbf	Range Rover (L405)	GWM - Gateway Module A	EXE
JK52-14F530-BE.vbf	Range Rover (L405)	GWM - Gateway Module A	EXE
JK52-14F530-CC.vbf	Range Rover (L405)	GWM - Gateway Module A	EXE
JK52-14F530-CF.vbf	Range Rover (L405)	GWM - Gateway Module A	EXE
JK52-14F530-DC.vbf	Range Rover (L405)	GWM - Gateway Module A	EXE
JK52-14F530-DF.vbf	Range Rover (L405)	GWM - Gateway Module A	EXE
JK52-14F530-DG.vbf	Range Rover (L405)	GWM - Gateway Module A	EXE
JK52-14F531-AC.vbf	Range Rover (L405)	GWM - Gateway Module A	DATA
JK52-14F531-AD.vbf	Range Rover (L405)	GWM - Gateway Module A	DATA
JK52-14F531-BA.vbf	Range Rover (L405)	GWM - Gateway Module A	DATA
JK52-14F531-BC.vbf	Range Rover (L405)	GWM - Gateway Module A	DATA
JK52-14F531-BD.vbf	Range Rover (L405)	GWM - Gateway Module A	DATA
JK52-14F531-CC.vbf	Range Rover (L405)	GWM - Gateway Module A	DATA
JK52-14F531-CD.vbf	Range Rover (L405)	GWM - Gateway Module A	DATA
JK52-14F531-DC.vbf	Range Rover (L405)	GWM - Gateway Module A	DATA
JK52-14F531-DD.vbf	Range Rover (L405)	GWM - Gateway Module A	DATA
JK52-14F531-DE.vbf	Range Rover (L405)	GWM - Gateway Module A	DATA
JK52-14G037-AA.vbf	Range Rover (L405)	RRSM - Rear Right Seat Module	EXE
JK52-14G037-AC.vbf	Range Rover (L405)	SCMC - Seat Control Module C	EXE
JK52-14G037-AD.vbf	Range Rover (L405)	SCMC - Seat Control Module C	EXE
JK52-14G037-AE.vbf	Range Rover (L405)	SCMC - Seat Control Module C	EXE
JK52-14G037-AF.vbf	Range Rover (L405)	SCMC - Seat Control Module C	EXE
JK52-14G037-AG.vbf	Range Rover (L405)	SCMC - Seat Control Module C	EXE
JK52-14G037-BC.vbf	Range Rover (L405)	SCMC - Seat Control Module C	EXE
JK52-14G037-BD.vbf	Range Rover (L405)	SCMC - Seat Control Module C	EXE
JK52-14G037-BE.vbf	Range Rover (L405)	SCMC - Seat Control Module C	EXE
JK52-14G037-BF.vbf	Range Rover (L405)	SCMC - Seat Control Module C	EXE
JK52-14G037-BG.vbf	Range Rover (L405)	SCMC - Seat Control Module C	EXE
JK52-14G037-CC.vbf	Range Rover (L405)	SCMC - Seat Control Module C	EXE
JK52-14G037-CD.vbf	Range Rover (L405)	SCMC - Seat Control Module C	EXE
JK52-14G037-CE.vbf	Range Rover (L405)	SCMC - Seat Control Module C	EXE
JK52-14G037-CF.vbf	Range Rover (L405)	SCMC - Seat Control Module C	EXE
JK52-14G037-CG.vbf	Range Rover (L405)	SCMC - Seat Control Module C	EXE
JK52-14G037-DC.vbf	Range Rover (L405)	SCMC - Seat Control Module C	EXE
JK52-14G037-DD.vbf	Range Rover (L405)	SCMC - Seat Control Module C	EXE
JK52-14G037-DE.vbf	Range Rover (L405)	SCMC - Seat Control Module C	EXE
JK52-14G037-DF.vbf	Range Rover (L405)	SCMC - Seat Control Module C	EXE
JK52-14G037-DG.vbf	Range Rover (L405)	SCMC - Seat Control Module C	EXE
JK52-14G037-DH.vbf	Range Rover (L405)	SCMC - Seat Control Module C	EXE
JK52-14G037-EC.vbf	Range Rover (L405)	SCMC - Seat Control Module C	EXE
JK52-14G037-ED.vbf	Range Rover (L405)	SCMC - Seat Control Module C	EXE
JK52-14G037-EE.vbf	Range Rover (L405)	SCMC - Seat Control Module C	EXE
JK52-14G037-EF.vbf	Range Rover (L405)	SCMC - Seat Control Module C	EXE
JK52-14G037-EG.vbf	Range Rover (L405)	SCMC - Seat Control Module C	EXE

File name	Vehicle line (indicative)	Module (ECU)	Type
JK52-14G037-EH.vbf	Range Rover (L405)	SCMC - Seat Control Module C	EXE
JK52-14G047-AA.vbf	Range Rover (L405)	RLSM - Rear Left Seat Module	EXE
JK52-14G047-AB.vbf	Range Rover (L405)	RLSM - Rear Left Seat Module	EXE
JK52-14G047-AC.vbf	Range Rover (L405)	SCMC - Seat Control Module C	EXE
JK52-14G047-AD.vbf	Range Rover (L405)	SCMC - Seat Control Module C	EXE
JK52-14G047-AE.vbf	Range Rover (L405)	SCMC - Seat Control Module C	EXE
JK52-14G047-AF.vbf	Range Rover (L405)	SCMC - Seat Control Module C	EXE
JK52-14G047-AG.vbf	Range Rover (L405)	SCMC - Seat Control Module C	EXE
JK52-14G047-AH.vbf	Range Rover (L405)	SCMC - Seat Control Module C	EXE
JK52-14G047-AJ.vbf	Range Rover (L405)	SCMC - Seat Control Module C	EXE
JK52-14G047-BB.vbf	Range Rover (L405)	RLSM - Rear Left Seat Module	EXE
JK52-14G047-BC.vbf	Range Rover (L405)	SCMC - Seat Control Module C	EXE
JK52-14G047-BD.vbf	Range Rover (L405)	SCMC - Seat Control Module C	EXE
JK52-14G047-BE.vbf	Range Rover (L405)	SCMC - Seat Control Module C	EXE
JK52-14G047-BF.vbf	Range Rover (L405)	SCMC - Seat Control Module C	EXE
JK52-14G047-BG.vbf	Range Rover (L405)	SCMC - Seat Control Module C	EXE
JK52-14G047-BH.vbf	Range Rover (L405)	SCMC - Seat Control Module C	EXE
JK52-14G047-BJ.vbf	Range Rover (L405)	SCMC - Seat Control Module C	EXE
JK52-14G047-CB.vbf	Range Rover (L405)	RLSM - Rear Left Seat Module	EXE
JK52-14G047-CC.vbf	Range Rover (L405)	SCMC - Seat Control Module C	EXE
JK52-14G047-CD.vbf	Range Rover (L405)	SCMC - Seat Control Module C	EXE
JK52-14G047-CE.vbf	Range Rover (L405)	SCMC - Seat Control Module C	EXE
JK52-14G047-CF.vbf	Range Rover (L405)	SCMC - Seat Control Module C	EXE
JK52-14G047-CG.vbf	Range Rover (L405)	SCMC - Seat Control Module C	EXE
JK52-14G047-CH.vbf	Range Rover (L405)	SCMC - Seat Control Module C	EXE
JK52-14G047-CJ.vbf	Range Rover (L405)	SCMC - Seat Control Module C	EXE
JK52-14G047-DB.vbf	Range Rover (L405)	RLSM - Rear Left Seat Module	EXE
JK52-14G047-DC.vbf	Range Rover (L405)	SCMC - Seat Control Module C	EXE
JK52-14G047-DD.vbf	Range Rover (L405)	SCMC - Seat Control Module C	EXE
JK52-14G047-DE.vbf	Range Rover (L405)	SCMC - Seat Control Module C	EXE
JK52-14G047-DF.vbf	Range Rover (L405)	SCMC - Seat Control Module C	EXE
JK52-14G047-DG.vbf	Range Rover (L405)	SCMC - Seat Control Module C	EXE
JK52-14G047-DH.vbf	Range Rover (L405)	SCMC - Seat Control Module C	EXE
JK52-14G047-DJ.vbf	Range Rover (L405)	SCMC - Seat Control Module C	EXE
JK52-14G047-DK.vbf	Range Rover (L405)	SCMC - Seat Control Module C	EXE
JK52-14G047-EB.vbf	Range Rover (L405)	RLSM - Rear Left Seat Module	EXE
JK52-14G047-EC.vbf	Range Rover (L405)	SCMC - Seat Control Module C	EXE
JK52-14G047-ED.vbf	Range Rover (L405)	SCMC - Seat Control Module C	EXE
JK52-14G047-EE.vbf	Range Rover (L405)	SCMC - Seat Control Module C	EXE
JK52-14G047-EF.vbf	Range Rover (L405)	SCMC - Seat Control Module C	EXE
JK52-14G047-EG.vbf	Range Rover (L405)	SCMC - Seat Control Module C	EXE
JK52-14G047-EH.vbf	Range Rover (L405)	SCMC - Seat Control Module C	EXE
JK52-14G047-EJ.vbf	Range Rover (L405)	SCMC - Seat Control Module C	EXE
JK52-14G047-EK.vbf	Range Rover (L405)	SCMC - Seat Control Module C	EXE
JK52-18D619-AA.vbf	Range Rover (L405)	HVAC - HVAC Control Module	EXE
JK52-18D619-AB.vbf	Range Rover (L405)	HVAC - HVAC Control Module	EXE
JK52-18D620-AC.vbf	Range Rover (L405)	HVAC - HVAC Control Module	DATA
JK52-18D620-AD.vbf	Range Rover (L405)	HVAC - HVAC Control Module	DATA
JK52-18D620-AE.vbf	Range Rover (L405)	HVAC - HVAC Control Module	DATA
JK52-18D620-AF.vbf	Range Rover (L405)	HVAC - HVAC Control Module	DATA
JK52-18D620-AJ.vbf	Range Rover (L405)	HVAC - HVAC Control Module	DATA
JK52-18D620-AK.vbf	Range Rover (L405)	HVAC - HVAC Control Module	DATA
JK52-18D620-AL.vbf	Range Rover (L405)	HVAC - HVAC Control Module	DATA
JK52-18D620-AM.vbf	Range Rover (L405)	HVAC - HVAC Control Module	DATA
JK52-18D620-AR.vbf	Range Rover (L405)	HVAC - HVAC Control Module	DATA
JK52-18D620-AU.vbf	Range Rover (L405)	HVAC - HVAC Control Module	DATA
JK52-18D620-AV.vbf	Range Rover (L405)	HVAC - HVAC Control Module	DATA
JK52-18D620-AX.vbf	Range Rover (L405)	HVAC - HVAC Control Module	DATA
JK52-18D620-BAA.vbf	Range Rover (L405)	HVAC - HVAC Control Module	DATA
JK52-18D620-BAB.vbf	Range Rover (L405)	HVAC - HVAC Control Module	DATA
JK52-18D620-BC.vbf	Range Rover (L405)	HVAC - HVAC Control Module	DATA
JK52-18D620-BD.vbf	Range Rover (L405)	HVAC - HVAC Control Module	DATA
JK52-18D620-BE.vbf	Range Rover (L405)	HVAC - HVAC Control Module	DATA
JK52-18D620-BF.vbf	Range Rover (L405)	HVAC - HVAC Control Module	DATA
JK52-18D620-BH.vbf	Range Rover (L405)	HVAC - HVAC Control Module	DATA
JK52-18D620-BJ.vbf	Range Rover (L405)	HVAC - HVAC Control Module	DATA
JK52-18D620-BK.vbf	Range Rover (L405)	HVAC - HVAC Control Module	DATA
JK52-18D620-BL.vbf	Range Rover (L405)	HVAC - HVAC Control Module	DATA
JK52-18D620-BM.vbf	Range Rover (L405)	HVAC - HVAC Control Module	DATA
JK52-18D620-BP.vbf	Range Rover (L405)	HVAC - HVAC Control Module	DATA
JK52-18D620-BR.vbf	Range Rover (L405)	HVAC - HVAC Control Module	DATA
JK52-18D620-BT.vbf	Range Rover (L405)	HVAC - HVAC Control Module	DATA
JK52-18D620-BV.vbf	Range Rover (L405)	HVAC - HVAC Control Module	DATA
JK52-18D620-BZ.vbf	Range Rover (L405)	HVAC - HVAC Control Module	DATA
JK52-18D620-CC.vbf	Range Rover (L405)	HVAC - HVAC Control Module	DATA
JK52-18D620-CD.vbf	Range Rover (L405)	HVAC - HVAC Control Module	DATA

File name	Vehicle line (indicative)	Module (ECU)	Type
JK52-18D620-CE.vbf	Range Rover (L405)	HVAC - HVAC Control Module	DATA
JK52-18D620-CF.vbf	Range Rover (L405)	HVAC - HVAC Control Module	DATA
JK52-18D620-CH.vbf	Range Rover (L405)	HVAC - HVAC Control Module	DATA
JK52-18D620-CJ.vbf	Range Rover (L405)	HVAC - HVAC Control Module	DATA
JK52-18D620-CK.vbf	Range Rover (L405)	HVAC - HVAC Control Module	DATA
JK52-18D620-CL.vbf	Range Rover (L405)	HVAC - HVAC Control Module	DATA
JK52-18D620-CM.vbf	Range Rover (L405)	HVAC - HVAC Control Module	DATA
JK52-18D620-CP.vbf	Range Rover (L405)	HVAC - HVAC Control Module	DATA
JK52-18D620-CS.vbf	Range Rover (L405)	HVAC - HVAC Control Module	DATA
JK52-18D620-CT.vbf	Range Rover (L405)	HVAC - HVAC Control Module	DATA
JK52-18D620-CU.vbf	Range Rover (L405)	HVAC - HVAC Control Module	DATA
JK52-18D620-DA.vbf	Range Rover (L405)	HVAC - HVAC Control Module	DATA
JK52-18D620-DB.vbf	Range Rover (L405)	HVAC - HVAC Control Module	DATA
JK52-18D620-DC.vbf	Range Rover (L405)	HVAC - HVAC Control Module	DATA
JK52-18D620-DE.vbf	Range Rover (L405)	HVAC - HVAC Control Module	DATA
JK52-18D620-DF.vbf	Range Rover (L405)	HVAC - HVAC Control Module	DATA
JK52-18D620-DG.vbf	Range Rover (L405)	HVAC - HVAC Control Module	DATA
JK52-18D620-DH.vbf	Range Rover (L405)	HVAC - HVAC Control Module	DATA
JK52-18D620-DJ.vbf	Range Rover (L405)	HVAC - HVAC Control Module	DATA
JK52-18D620-DL.vbf	Range Rover (L405)	HVAC - HVAC Control Module	DATA
JK52-18D620-DN.vbf	Range Rover (L405)	HVAC - HVAC Control Module	DATA
JK52-18D620-DP.vbf	Range Rover (L405)	HVAC - HVAC Control Module	DATA
JK52-18D620-DR.vbf	Range Rover (L405)	HVAC - HVAC Control Module	DATA
JK52-18D620-EA.vbf	Range Rover (L405)	HVAC - HVAC Control Module	DATA
JK52-18D620-EB.vbf	Range Rover (L405)	HVAC - HVAC Control Module	DATA
JK52-18D620-EE.vbf	Range Rover (L405)	HVAC - HVAC Control Module	DATA
JK52-18D620-EH.vbf	Range Rover (L405)	HVAC - HVAC Control Module	DATA
JK52-18D620-EJ.vbf	Range Rover (L405)	HVAC - HVAC Control Module	DATA
JK52-18D620-EK.vbf	Range Rover (L405)	HVAC - HVAC Control Module	DATA
JK52-18D620-FA.vbf	Range Rover (L405)	HVAC - HVAC Control Module	DATA
JK52-18D620-FB.vbf	Range Rover (L405)	HVAC - HVAC Control Module	DATA
JK52-18D620-FC.vbf	Range Rover (L405)	HVAC - HVAC Control Module	DATA
JK52-18D620-FE.vbf	Range Rover (L405)	HVAC - HVAC Control Module	DATA
JK52-18D620-FF.vbf	Range Rover (L405)	HVAC - HVAC Control Module	DATA
JK52-18D620-FH.vbf	Range Rover (L405)	HVAC - HVAC Control Module	DATA
JK52-18D620-FK.vbf	Range Rover (L405)	HVAC - HVAC Control Module	DATA
JK52-18D620-FN.vbf	Range Rover (L405)	HVAC - HVAC Control Module	DATA
JK52-18D620-FP.vbf	Range Rover (L405)	HVAC - HVAC Control Module	DATA
JK52-18D620-FR.vbf	Range Rover (L405)	HVAC - HVAC Control Module	DATA
JK52-18D620-GA.vbf	Range Rover (L405)	HVAC - HVAC Control Module	DATA
JK52-18D620-GB.vbf	Range Rover (L405)	HVAC - HVAC Control Module	DATA
JK52-18D620-GC.vbf	Range Rover (L405)	HVAC - HVAC Control Module	DATA
JK52-18D620-GE.vbf	Range Rover (L405)	HVAC - HVAC Control Module	DATA
JK52-18D620-GG.vbf	Range Rover (L405)	HVAC - HVAC Control Module	DATA
JK52-18D620-GH.vbf	Range Rover (L405)	HVAC - HVAC Control Module	DATA
JK52-18D620-GJ.vbf	Range Rover (L405)	HVAC - HVAC Control Module	DATA
JK52-18D620-HA.vbf	Range Rover (L405)	HVAC - HVAC Control Module	DATA
JK52-18D620-HB.vbf	Range Rover (L405)	HVAC - HVAC Control Module	DATA
JK52-18D620-HC.vbf	Range Rover (L405)	HVAC - HVAC Control Module	DATA
JK52-18D620-HE.vbf	Range Rover (L405)	HVAC - HVAC Control Module	DATA
JK52-18D620-HG.vbf	Range Rover (L405)	HVAC - HVAC Control Module	DATA
JK52-18D620-HH.vbf	Range Rover (L405)	HVAC - HVAC Control Module	DATA
JK52-18D620-HJ.vbf	Range Rover (L405)	HVAC - HVAC Control Module	DATA
JK52-19C264-AB.vbf	Range Rover (L405)	FDM - Front Display Interface Module	DATA
JK52-19C264-AC.vbf	Range Rover (L405)	FDM - Front Display Interface Module	DATA
JK52-19C264-AD.vbf	Range Rover (L405)	FDM - Front Display Interface Module	DATA
JK52-19C264-AE.vbf	Range Rover (L405)	FDM - Front Display Interface Module	DATA
JK52-19C274-AB.vbf	Range Rover (L405)	LPDM - Left Power Sliding Door Module	DATA
JK52-19C274-AC.vbf	Range Rover (L405)	LPDM - Left Power Sliding Door Module	DATA
JK52-19C274-AD.vbf	Range Rover (L405)	LPDM - Left Power Sliding Door Module	DATA
JK52-19C274-AE.vbf	Range Rover (L405)	LPDM - Left Power Sliding Door Module	DATA
JK52-2D513-AE.vbf	Range Rover (L405)	BBM - Brake BoosterModule	EXE
JK52-2D513-AF.vbf	Range Rover (L405)	BBM - Brake BoosterModule	EXE
JK52-2D513-AG.vbf	Range Rover (L405)	BBM - Brake BoosterModule	EXE
JK52-2D513-AH.vbf	Range Rover (L405)	BBM - Brake BoosterModule	EXE
JK52-2D513-AJ.vbf	Range Rover (L405)	BBM - Brake BoosterModule	EXE
JK52-2D514-AAE.vbf	Range Rover (L405)	BBM - Brake BoosterModule	DATA
JK52-2D514-AAF.vbf	Range Rover (L405)	BBM - Brake BoosterModule	DATA
JK52-2D514-AAG.vbf	Range Rover (L405)	BBM - Brake BoosterModule	DATA
JK52-2D514-AAH.vbf	Range Rover (L405)	BBM - Brake BoosterModule	DATA
JK52-2D514-AAJ.vbf	Range Rover (L405)	BBM - Brake BoosterModule	DATA
JK52-2D514-AAK.vbf	Range Rover (L405)	BBM - Brake BoosterModule	DATA
JK52-2D514-AAL.vbf	Range Rover (L405)	BBM - Brake BoosterModule	DATA
JK52-2D514-AAM.vbf	Range Rover (L405)	BBM - Brake BoosterModule	DATA
JK52-2D515-AC.vbf	Range Rover (L405)	ABS - Anti-Lock Brake System Control Module	SBL
JK52-2D515-AD.vbf	Range Rover (L405)	ABS - Anti-Lock Brake System Control Module	SBL

File name	Vehicle line (indicative)	Module (ECU)	Type
JK52-7J104-CZA.vbf	Range Rover (L405)	TCM - Transmission Control Module	EXE
JK52-7J104-CZB.vbf	Range Rover (L405)	TCM - Transmission Control Module	EXE
JK52-7J104-CZC.vbf	Range Rover (L405)	TCM - Transmission Control Module	EXE
JK52-7J104-CZD.vbf	Range Rover (L405)	TCM - Transmission Control Module	EXE
JK52-7J104-CZE.vbf	Range Rover (L405)	TCM - Transmission Control Module	EXE
JK52-7J104-CZF.vbf	Range Rover (L405)	TCM - Transmission Control Module	EXE
JK52-7J104-CZG.vbf	Range Rover (L405)	TCM - Transmission Control Module	EXE
JK52-7J104-CZH.vbf	Range Rover (L405)	TCM - Transmission Control Module	EXE
JK52-7J104-CZJ.vbf	Range Rover (L405)	TCM - Transmission Control Module	EXE
JK52-7J104-FAA.vbf	Range Rover (L405)	TCM - Transmission Control Module	EXE
JK52-7J104-FAB.vbf	Range Rover (L405)	TCM - Transmission Control Module	EXE
JK52-7J104-FAC.vbf	Range Rover (L405)	TCM - Transmission Control Module	EXE
JK52-7J104-FAE.vbf	Range Rover (L405)	TCM - Transmission Control Module	EXE
JK52-7J104-FAF.vbf	Range Rover (L405)	TCM - Transmission Control Module	EXE
JK52-7J104-FBB.vbf	Range Rover (L405)	TCM - Transmission Control Module	EXE
JK52-7J104-FBC.vbf	Range Rover (L405)	TCM - Transmission Control Module	EXE
JK52-7J104-FBD.vbf	Range Rover (L405)	TCM - Transmission Control Module	EXE
JK52-7J104-FBE.vbf	Range Rover (L405)	TCM - Transmission Control Module	EXE
JK52-7J104-FBF.vbf	Range Rover (L405)	TCM - Transmission Control Module	EXE
JK52-7J104-FCB.vbf	Range Rover (L405)	TCM - Transmission Control Module	EXE
JK52-7J104-FCC.vbf	Range Rover (L405)	TCM - Transmission Control Module	EXE
JK52-7J104-FCD.vbf	Range Rover (L405)	TCM - Transmission Control Module	EXE
JK52-7J104-FCE.vbf	Range Rover (L405)	TCM - Transmission Control Module	EXE
JK52-7J104-FCF.vbf	Range Rover (L405)	TCM - Transmission Control Module	EXE
JK52-7J104-FDB.vbf	Range Rover (L405)	TCM - Transmission Control Module	EXE
JK52-7J104-FDC.vbf	Range Rover (L405)	TCM - Transmission Control Module	EXE
JK52-7J104-FDD.vbf	Range Rover (L405)	TCM - Transmission Control Module	EXE
JK52-7J104-FDE.vbf	Range Rover (L405)	TCM - Transmission Control Module	EXE
JK52-7J104-FDF.vbf	Range Rover (L405)	TCM - Transmission Control Module	EXE
JK52-7J104-FDG.vbf	Range Rover (L405)	TCM - Transmission Control Module	EXE
JK52-7J104-FHB.vbf	Range Rover (L405)	TCM - Transmission Control Module	EXE
JK52-7J104-FHC.vbf	Range Rover (L405)	TCM - Transmission Control Module	EXE
JK52-7J104-FHD.vbf	Range Rover (L405)	TCM - Transmission Control Module	EXE
JK52-7J104-FHE.vbf	Range Rover (L405)	TCM - Transmission Control Module	EXE
JK52-7J104-FHF.vbf	Range Rover (L405)	TCM - Transmission Control Module	EXE
JK52-7J104-FHG.vbf	Range Rover (L405)	TCM - Transmission Control Module	EXE
JK52-7J104-FKA.vbf	Range Rover (L405)	TCM - Transmission Control Module	EXE
JK52-7J104-FKC.vbf	Range Rover (L405)	TCM - Transmission Control Module	EXE
JK52-7J104-FKD.vbf	Range Rover (L405)	TCM - Transmission Control Module	EXE
JK52-7J104-FKE.vbf	Range Rover (L405)	TCM - Transmission Control Module	EXE
JK52-7J104-FKF.vbf	Range Rover (L405)	TCM - Transmission Control Module	EXE
JK52-7J104-FKG.vbf	Range Rover (L405)	TCM - Transmission Control Module	EXE
JK52-7J104-FKH.vbf	Range Rover (L405)	TCM - Transmission Control Module	EXE
JK52-7J104-FYB.vbf	Range Rover (L405)	TCM - Transmission Control Module	EXE
JK52-7J104-FYC.vbf	Range Rover (L405)	TCM - Transmission Control Module	EXE
JK52-7J104-FYD.vbf	Range Rover (L405)	TCM - Transmission Control Module	EXE
JK52-7J104-FYE.vbf	Range Rover (L405)	TCM - Transmission Control Module	EXE
JK52-7J104-FYF.vbf	Range Rover (L405)	TCM - Transmission Control Module	EXE
JK5M-14C218-AA.vbf	Not specified	PSCM - Power Steering Control Module	EXE
JK5M-14C570-STD.vbf	Not specified	PCM - Powertrain Control Module	EXE
JK5M-14D092-AC.vbf	Not specified	TCM - Transmission Control Module	EXE
JK5M-14D094-AB.vbf	Not specified	PCM - Powertrain Control Module	SBL
JK5M-14E094-JSB.vbf	Not specified	CHCM - Chassis Control Module	EXE
JK5M-14E094-JSD.vbf	Not specified	CHCM - Chassis Control Module	EXE
JK5M-14E094-JSE.vbf	Not specified	CHCM - Chassis Control Module	EXE
JK5M-14E094-JSF.vbf	Not specified	CHCM - Chassis Control Module	EXE
JK5M-14E094-JSG.vbf	Not specified	CHCM - Chassis Control Module	EXE
JK5M-14E094-JSH.vbf	Not specified	CHCM - Chassis Control Module	EXE
JK5M-14E094-JSJ.vbf	Not specified	CHCM - Chassis Control Module	EXE
JK5M-14E094-JSK.vbf	Not specified	CHCM - Chassis Control Module	EXE
JK5M-14E094-JTB.vbf	Not specified	CHCM - Chassis Control Module	EXE
JK5M-14E094-JTD.vbf	Not specified	CHCM - Chassis Control Module	EXE
JK5M-14E094-JTE.vbf	Not specified	CHCM - Chassis Control Module	EXE
JK5M-14E094-JTF.vbf	Not specified	CHCM - Chassis Control Module	EXE
JK5M-14E094-JTG.vbf	Not specified	CHCM - Chassis Control Module	EXE
JK5M-14E094-JTH.vbf	Not specified	CHCM - Chassis Control Module	EXE
JK5M-14E094-JTJ.vbf	Not specified	CHCM - Chassis Control Module	EXE
JK5M-14E094-JUA.vbf	Not specified	CHCM - Chassis Control Module	EXE
JK5M-14E094-JUC.vbf	Not specified	CHCM - Chassis Control Module	EXE
JK5M-14E094-JUD.vbf	Not specified	CHCM - Chassis Control Module	EXE
JK5M-14E094-JUE.vbf	Not specified	CHCM - Chassis Control Module	EXE
JK5M-14E094-JUF.vbf	Not specified	CHCM - Chassis Control Module	EXE
JK5M-14E094-JUG.vbf	Not specified	CHCM - Chassis Control Module	EXE
JK5M-14E094-JUH.vbf	Not specified	CHCM - Chassis Control Module	EXE
JK5M-14E172-AC.vbf	Not specified	PCM - Powertrain Control Module	EXE
JK5M-14F435-NFB.vbf	Not specified	CHCMB - Chassis Control Module B	EXE

File name	Vehicle line (indicative)	Module (ECU)	Type
JK5M-14F435-NFC.vbf	Not specified	CHCMB - Chassis Control Module B	EXE
JK5M-14F435-NFD.vbf	Not specified	CHCMB - Chassis Control Module B	EXE
JK5M-14F435-NFE.vbf	Not specified	CHCMB - Chassis Control Module B	EXE
JK5M-14F435-NFF.vbf	Not specified	CHCMB - Chassis Control Module B	EXE
JK5M-14F435-NFG.vbf	Not specified	CHCMB - Chassis Control Module B	EXE
JK5M-14F435-NFH.vbf	Not specified	CHCMB - Chassis Control Module B	EXE
JK5M-14F435-NFJ.vbf	Not specified	CHCMB - Chassis Control Module B	EXE
JK5M-14F435-NGB.vbf	Not specified	CHCMB - Chassis Control Module B	EXE
JK5M-14F435-NGC.vbf	Not specified	CHCMB - Chassis Control Module B	EXE
JK5M-14F435-NGD.vbf	Not specified	CHCMB - Chassis Control Module B	EXE
JK5M-14F435-NGE.vbf	Not specified	CHCMB - Chassis Control Module B	EXE
JK5M-14F435-NGF.vbf	Not specified	CHCMB - Chassis Control Module B	EXE
JK5M-14F435-NGG.vbf	Not specified	CHCMB - Chassis Control Module B	EXE
JK5M-14F435-NGH.vbf	Not specified	CHCMB - Chassis Control Module B	EXE
JK5M-14F435-NGJ.vbf	Not specified	CHCMB - Chassis Control Module B	EXE
JK5M-14G037-AA.vbf	Not specified	RRSM - Rear Right Seat Module	EXE
JK5M-14G037-BA.vbf	Not specified	RRSM - Rear Right Seat Module	EXE
JK5M-14G037-BB.vbf	Not specified	SCMC - Seat Control Module C	EXE
JK5M-14G037-BC.vbf	Not specified	SCMC - Seat Control Module C	EXE
JK5M-14G037-BD.vbf	Not specified	SCMC - Seat Control Module C	EXE
JK5M-14G037-BE.vbf	Not specified	SCMC - Seat Control Module C	EXE
JK5M-14G037-BF.vbf	Not specified	SCMC - Seat Control Module C	EXE
JK5M-14G037-BG.vbf	Not specified	SCMC - Seat Control Module C	EXE
JK5M-14G037-CA.vbf	Not specified	SCMC - Seat Control Module C	EXE
JK5M-14G037-CB.vbf	Not specified	SCMC - Seat Control Module C	EXE
JK5M-14G037-CC.vbf	Not specified	SCMC - Seat Control Module C	EXE
JK5M-14G037-CD.vbf	Not specified	SCMC - Seat Control Module C	EXE
JK5M-14G037-CE.vbf	Not specified	SCMC - Seat Control Module C	EXE
JK5M-14G047-AA.vbf	Not specified	RLSM - Rear Left Seat Module	EXE
JK5M-14G047-BA.vbf	Not specified	RLSM - Rear Left Seat Module	EXE
JK5M-14G047-BB.vbf	Not specified	SCMC - Seat Control Module C	EXE
JK5M-14G047-BC.vbf	Not specified	SCMC - Seat Control Module C	EXE
JK5M-14G047-BD.vbf	Not specified	SCMC - Seat Control Module C	EXE
JK5M-14G047-BE.vbf	Not specified	SCMC - Seat Control Module C	EXE
JK5M-14G047-BF.vbf	Not specified	SCMC - Seat Control Module C	EXE
JK5M-14G047-BG.vbf	Not specified	SCMC - Seat Control Module C	EXE
JK5M-14G047-CA.vbf	Not specified	SCMC - Seat Control Module C	EXE
JK5M-14G047-CB.vbf	Not specified	SCMC - Seat Control Module C	EXE
JK5M-14G047-CC.vbf	Not specified	SCMC - Seat Control Module C	EXE
JK5M-14G047-CD.vbf	Not specified	SCMC - Seat Control Module C	EXE
JK5M-14G047-CE.vbf	Not specified	SCMC - Seat Control Module C	EXE
JK5M-14G047-CF.vbf	Not specified	SCMC - Seat Control Module C	EXE
JK62-12K532-FBA.vbf	Range Rover Sport (L494)	PCM - Powertrain Control Module	DATA
JK62-12K532-FBB.vbf	Range Rover Sport (L494)	PCM - Powertrain Control Module	DATA
JK62-12K532-FBC.vbf	Range Rover Sport (L494)	PCM - Powertrain Control Module	DATA
JK62-12K532-FBD.vbf	Range Rover Sport (L494)	PCM - Powertrain Control Module	DATA
JK62-12K532-FBE.vbf	Range Rover Sport (L494)	PCM - Powertrain Control Module	DATA
JK62-12K532-FBF.vbf	Range Rover Sport (L494)	PCM - Powertrain Control Module	DATA
JK62-12K532-FBG.vbf	Range Rover Sport (L494)	PCM - Powertrain Control Module	DATA
JK62-12K532-PCB.vbf	Range Rover Sport (L494)	PCM - Powertrain Control Module	DATA
JK62-12K532-PCC.vbf	Range Rover Sport (L494)	PCM - Powertrain Control Module	DATA
JK62-12K532-PCD.vbf	Range Rover Sport (L494)	PCM - Powertrain Control Module	DATA
JK62-12K532-PFB.vbf	Range Rover Sport (L494)	PCM - Powertrain Control Module	DATA
JK62-12K532-PFC.vbf	Range Rover Sport (L494)	PCM - Powertrain Control Module	DATA
JK62-12K532-PFD.vbf	Range Rover Sport (L494)	PCM - Powertrain Control Module	DATA
JK62-12K532-PFE.vbf	Range Rover Sport (L494)	PCM - Powertrain Control Module	DATA
JK62-12K532-PJC.vbf	Range Rover Sport (L494)	PCM - Powertrain Control Module	DATA
JK62-12K532-PJD.vbf	Range Rover Sport (L494)	PCM - Powertrain Control Module	DATA
JK62-12K532-PJE.vbf	Range Rover Sport (L494)	PCM - Powertrain Control Module	DATA
JK62-12K532-PJF.vbf	Range Rover Sport (L494)	PCM - Powertrain Control Module	DATA
JK62-12K532-PJG.vbf	Range Rover Sport (L494)	PCM - Powertrain Control Module	DATA
JK62-12K532-PJH.vbf	Range Rover Sport (L494)	PCM - Powertrain Control Module	EXE
JK62-12K532-PKB.vbf	Range Rover Sport (L494)	PCM - Powertrain Control Module	DATA
JK62-12K532-PKC.vbf	Range Rover Sport (L494)	PCM - Powertrain Control Module	DATA
JK62-12K532-PKD.vbf	Range Rover Sport (L494)	PCM - Powertrain Control Module	DATA
JK62-12K532-PKE.vbf	Range Rover Sport (L494)	PCM - Powertrain Control Module	DATA
JK62-12K532-PKF.vbf	Range Rover Sport (L494)	PCM - Powertrain Control Module	DATA
JK62-12K532-PKG.vbf	Range Rover Sport (L494)	PCM - Powertrain Control Module	DATA
JK62-12K532-PMD.vbf	Range Rover Sport (L494)	PCM - Powertrain Control Module	DATA
JK62-12K532-PNB.vbf	Range Rover Sport (L494)	PCM - Powertrain Control Module	DATA
JK62-12K532-PNC.vbf	Range Rover Sport (L494)	PCM - Powertrain Control Module	DATA
JK62-12K532-PND.vbf	Range Rover Sport (L494)	PCM - Powertrain Control Module	DATA
JK62-12K532-PNE.vbf	Range Rover Sport (L494)	PCM - Powertrain Control Module	DATA
JK62-12K532-PNF.vbf	Range Rover Sport (L494)	PCM - Powertrain Control Module	DATA
JK62-12K532-PNG.vbf	Range Rover Sport (L494)	PCM - Powertrain Control Module	DATA
JK62-12K532-PNH.vbf	Range Rover Sport (L494)	PCM - Powertrain Control Module	EXE

File name	Vehicle line (indicative)	Module (ECU)	Type
JK62-12K532-PRC.vbf	Range Rover Sport (L494)	PCM - Powertrain Control Module	DATA
JK62-12K532-PRD.vbf	Range Rover Sport (L494)	PCM - Powertrain Control Module	DATA
JK62-12K532-PSD.vbf	Range Rover Sport (L494)	PCM - Powertrain Control Module	DATA
JK62-12K532-PSE.vbf	Range Rover Sport (L494)	PCM - Powertrain Control Module	DATA
JK62-12K532-PSF.vbf	Range Rover Sport (L494)	PCM - Powertrain Control Module	DATA
JK62-14C030-AA.vbf	Range Rover Sport (L494)	DSM - Driver Front Seat Module	EXE
JK62-14C030-AB.vbf	Range Rover Sport (L494)	DSM - Driver Front Seat Module	EXE
JK62-14C030-AC.vbf	Range Rover Sport (L494)	DSM - Driver Front Seat Module	EXE
JK62-14C034-AAA.vbf	Range Rover Sport (L494)	DSM - Driver Front Seat Module	EXE
JK62-14C034-ABA.vbf	Range Rover Sport (L494)	DSM - Driver Front Seat Module	EXE
JK62-14C034-ABB.vbf	Range Rover Sport (L494)	DSM - Driver Front Seat Module	EXE
JK62-14C034-ABC.vbf	Range Rover Sport (L494)	DSM - Driver Front Seat Module	EXE
JK62-14C034-ACA.vbf	Range Rover Sport (L494)	DSM - Driver Front Seat Module	EXE
JK62-14C034-ACB.vbf	Range Rover Sport (L494)	DSM - Driver Front Seat Module	EXE
JK62-14C034-ACC.vbf	Range Rover Sport (L494)	DSM - Driver Front Seat Module	EXE
JK62-14C034-BAA.vbf	Range Rover Sport (L494)	DSM - Driver Front Seat Module	EXE
JK62-14C034-BAB.vbf	Range Rover Sport (L494)	DSM - Driver Front Seat Module	EXE
JK62-14C034-BBA.vbf	Range Rover Sport (L494)	DSM - Driver Front Seat Module	EXE
JK62-14C034-BBB.vbf	Range Rover Sport (L494)	DSM - Driver Front Seat Module	EXE
JK62-14C034-BBC.vbf	Range Rover Sport (L494)	DSM - Driver Front Seat Module	EXE
JK62-14C034-BBD.vbf	Range Rover Sport (L494)	DSM - Driver Front Seat Module	EXE
JK62-14C034-BCA.vbf	Range Rover Sport (L494)	DSM - Driver Front Seat Module	EXE
JK62-14C034-BCB.vbf	Range Rover Sport (L494)	DSM - Driver Front Seat Module	EXE
JK62-14C034-BCC.vbf	Range Rover Sport (L494)	DSM - Driver Front Seat Module	EXE
JK62-14C037-AAD.vbf	Range Rover Sport (L494)	ABS - Anti-Lock Brake System Control Module	DATA
JK62-14C037-AAE.vbf	Range Rover Sport (L494)	ABS - Anti-Lock Brake System Control Module	DATA
JK62-14C037-AAF.vbf	Range Rover Sport (L494)	ABS - Anti-Lock Brake System Control Module	DATA
JK62-14C037-AAG.vbf	Range Rover Sport (L494)	ABS - Anti-Lock Brake System Control Module	DATA
JK62-14C037-AAH.vbf	Range Rover Sport (L494)	ABS - Anti-Lock Brake System Control Module	DATA
JK62-14C037-AAJ.vbf	Range Rover Sport (L494)	ABS - Anti-Lock Brake System Control Module	DATA
JK62-14C037-AAK.vbf	Range Rover Sport (L494)	ABS - Anti-Lock Brake System Control Module	DATA
JK62-14C037-AAL.vbf	Range Rover Sport (L494)	ABS - Anti-Lock Brake System Control Module	DATA
JK62-14C037-ABD.vbf	Range Rover Sport (L494)	ABS - Anti-Lock Brake System Control Module	DATA
JK62-14C037-ABE.vbf	Range Rover Sport (L494)	ABS - Anti-Lock Brake System Control Module	DATA
JK62-14C037-ABF.vbf	Range Rover Sport (L494)	ABS - Anti-Lock Brake System Control Module	DATA
JK62-14C037-ABG.vbf	Range Rover Sport (L494)	ABS - Anti-Lock Brake System Control Module	DATA
JK62-14C037-ABH.vbf	Range Rover Sport (L494)	ABS - Anti-Lock Brake System Control Module	DATA
JK62-14C037-ABJ.vbf	Range Rover Sport (L494)	ABS - Anti-Lock Brake System Control Module	DATA
JK62-14C037-ABK.vbf	Range Rover Sport (L494)	ABS - Anti-Lock Brake System Control Module	DATA
JK62-14C037-ABL.vbf	Range Rover Sport (L494)	ABS - Anti-Lock Brake System Control Module	DATA
JK62-14C037-ACD.vbf	Range Rover Sport (L494)	ABS - Anti-Lock Brake System Control Module	DATA
JK62-14C037-ACE.vbf	Range Rover Sport (L494)	ABS - Anti-Lock Brake System Control Module	DATA
JK62-14C037-ACF.vbf	Range Rover Sport (L494)	ABS - Anti-Lock Brake System Control Module	DATA
JK62-14C037-ACG.vbf	Range Rover Sport (L494)	ABS - Anti-Lock Brake System Control Module	DATA
JK62-14C037-ACH.vbf	Range Rover Sport (L494)	ABS - Anti-Lock Brake System Control Module	DATA
JK62-14C037-ACJ.vbf	Range Rover Sport (L494)	ABS - Anti-Lock Brake System Control Module	DATA
JK62-14C037-ACK.vbf	Range Rover Sport (L494)	ABS - Anti-Lock Brake System Control Module	DATA
JK62-14C037-ACL.vbf	Range Rover Sport (L494)	ABS - Anti-Lock Brake System Control Module	DATA
JK62-14C037-ADD.vbf	Range Rover Sport (L494)	ABS - Anti-Lock Brake System Control Module	DATA
JK62-14C037-ADE.vbf	Range Rover Sport (L494)	ABS - Anti-Lock Brake System Control Module	DATA
JK62-14C037-ADF.vbf	Range Rover Sport (L494)	ABS - Anti-Lock Brake System Control Module	DATA
JK62-14C037-ADG.vbf	Range Rover Sport (L494)	ABS - Anti-Lock Brake System Control Module	DATA
JK62-14C037-ADH.vbf	Range Rover Sport (L494)	ABS - Anti-Lock Brake System Control Module	DATA
JK62-14C037-ADJ.vbf	Range Rover Sport (L494)	ABS - Anti-Lock Brake System Control Module	DATA
JK62-14C037-ADK.vbf	Range Rover Sport (L494)	ABS - Anti-Lock Brake System Control Module	DATA
JK62-14C037-ADL.vbf	Range Rover Sport (L494)	ABS - Anti-Lock Brake System Control Module	DATA
JK62-14C037-AED.vbf	Range Rover Sport (L494)	ABS - Anti-Lock Brake System Control Module	DATA
JK62-14C037-AEE.vbf	Range Rover Sport (L494)	ABS - Anti-Lock Brake System Control Module	DATA
JK62-14C037-AEF.vbf	Range Rover Sport (L494)	ABS - Anti-Lock Brake System Control Module	DATA
JK62-14C037-AEG.vbf	Range Rover Sport (L494)	ABS - Anti-Lock Brake System Control Module	DATA
JK62-14C037-AEH.vbf	Range Rover Sport (L494)	ABS - Anti-Lock Brake System Control Module	DATA
JK62-14C037-AEJ.vbf	Range Rover Sport (L494)	ABS - Anti-Lock Brake System Control Module	DATA
JK62-14C037-AEK.vbf	Range Rover Sport (L494)	ABS - Anti-Lock Brake System Control Module	DATA
JK62-14C037-AEL.vbf	Range Rover Sport (L494)	ABS - Anti-Lock Brake System Control Module	DATA
JK62-14C037-AFD.vbf	Range Rover Sport (L494)	ABS - Anti-Lock Brake System Control Module	DATA
JK62-14C037-AFE.vbf	Range Rover Sport (L494)	ABS - Anti-Lock Brake System Control Module	DATA
JK62-14C037-AFF.vbf	Range Rover Sport (L494)	ABS - Anti-Lock Brake System Control Module	DATA
JK62-14C037-AFG.vbf	Range Rover Sport (L494)	ABS - Anti-Lock Brake System Control Module	DATA
JK62-14C037-AFH.vbf	Range Rover Sport (L494)	ABS - Anti-Lock Brake System Control Module	DATA
JK62-14C037-AFJ.vbf	Range Rover Sport (L494)	ABS - Anti-Lock Brake System Control Module	DATA
JK62-14C037-AFK.vbf	Range Rover Sport (L494)	ABS - Anti-Lock Brake System Control Module	DATA
JK62-14C037-AFL.vbf	Range Rover Sport (L494)	ABS - Anti-Lock Brake System Control Module	DATA
JK62-14C037-AGD.vbf	Range Rover Sport (L494)	ABS - Anti-Lock Brake System Control Module	DATA
JK62-14C037-AGE.vbf	Range Rover Sport (L494)	ABS - Anti-Lock Brake System Control Module	DATA
JK62-14C037-AGF.vbf	Range Rover Sport (L494)	ABS - Anti-Lock Brake System Control Module	DATA
JK62-14C037-AGG.vbf	Range Rover Sport (L494)	ABS - Anti-Lock Brake System Control Module	DATA

File name	Vehicle line (indicative)	Module (ECU)	Type
JK62-14C037-AGH.vbf	Range Rover Sport (L494)	ABS - Anti-Lock Brake System Control Module	DATA
JK62-14C037-AGJ.vbf	Range Rover Sport (L494)	ABS - Anti-Lock Brake System Control Module	DATA
JK62-14C037-AGK.vbf	Range Rover Sport (L494)	ABS - Anti-Lock Brake System Control Module	DATA
JK62-14C037-AGL.vbf	Range Rover Sport (L494)	ABS - Anti-Lock Brake System Control Module	DATA
JK62-14C037-AHD.vbf	Range Rover Sport (L494)	ABS - Anti-Lock Brake System Control Module	DATA
JK62-14C037-AHE.vbf	Range Rover Sport (L494)	ABS - Anti-Lock Brake System Control Module	DATA
JK62-14C037-AHF.vbf	Range Rover Sport (L494)	ABS - Anti-Lock Brake System Control Module	DATA
JK62-14C037-AHG.vbf	Range Rover Sport (L494)	ABS - Anti-Lock Brake System Control Module	DATA
JK62-14C037-AHH.vbf	Range Rover Sport (L494)	ABS - Anti-Lock Brake System Control Module	DATA
JK62-14C037-AHJ.vbf	Range Rover Sport (L494)	ABS - Anti-Lock Brake System Control Module	DATA
JK62-14C037-AHK.vbf	Range Rover Sport (L494)	ABS - Anti-Lock Brake System Control Module	DATA
JK62-14C037-AHL.vbf	Range Rover Sport (L494)	ABS - Anti-Lock Brake System Control Module	DATA
JK62-14C037-AKD.vbf	Range Rover Sport (L494)	ABS - Anti-Lock Brake System Control Module	DATA
JK62-14C037-AKE.vbf	Range Rover Sport (L494)	ABS - Anti-Lock Brake System Control Module	DATA
JK62-14C037-AKF.vbf	Range Rover Sport (L494)	ABS - Anti-Lock Brake System Control Module	DATA
JK62-14C037-AKG.vbf	Range Rover Sport (L494)	ABS - Anti-Lock Brake System Control Module	DATA
JK62-14C037-AKH.vbf	Range Rover Sport (L494)	ABS - Anti-Lock Brake System Control Module	DATA
JK62-14C037-AKJ.vbf	Range Rover Sport (L494)	ABS - Anti-Lock Brake System Control Module	DATA
JK62-14C037-AKK.vbf	Range Rover Sport (L494)	ABS - Anti-Lock Brake System Control Module	DATA
JK62-14C037-AKL.vbf	Range Rover Sport (L494)	ABS - Anti-Lock Brake System Control Module	DATA
JK62-14C037-AVD.vbf	Range Rover Sport (L494)	ABS - Anti-Lock Brake System Control Module	DATA
JK62-14C037-AVE.vbf	Range Rover Sport (L494)	ABS - Anti-Lock Brake System Control Module	DATA
JK62-14C037-AVF.vbf	Range Rover Sport (L494)	ABS - Anti-Lock Brake System Control Module	DATA
JK62-14C037-AVG.vbf	Range Rover Sport (L494)	ABS - Anti-Lock Brake System Control Module	DATA
JK62-14C037-AVH.vbf	Range Rover Sport (L494)	ABS - Anti-Lock Brake System Control Module	DATA
JK62-14C037-AVJ.vbf	Range Rover Sport (L494)	ABS - Anti-Lock Brake System Control Module	DATA
JK62-14C037-AVK.vbf	Range Rover Sport (L494)	ABS - Anti-Lock Brake System Control Module	DATA
JK62-14C037-AVL.vbf	Range Rover Sport (L494)	ABS - Anti-Lock Brake System Control Module	DATA
JK62-14C037-AYD.vbf	Range Rover Sport (L494)	ABS - Anti-Lock Brake System Control Module	DATA
JK62-14C037-AYE.vbf	Range Rover Sport (L494)	ABS - Anti-Lock Brake System Control Module	DATA
JK62-14C037-AYF.vbf	Range Rover Sport (L494)	ABS - Anti-Lock Brake System Control Module	DATA
JK62-14C037-AYG.vbf	Range Rover Sport (L494)	ABS - Anti-Lock Brake System Control Module	DATA
JK62-14C037-AYH.vbf	Range Rover Sport (L494)	ABS - Anti-Lock Brake System Control Module	DATA
JK62-14C037-AYJ.vbf	Range Rover Sport (L494)	ABS - Anti-Lock Brake System Control Module	DATA
JK62-14C037-AYK.vbf	Range Rover Sport (L494)	ABS - Anti-Lock Brake System Control Module	DATA
JK62-14C037-AYL.vbf	Range Rover Sport (L494)	ABS - Anti-Lock Brake System Control Module	DATA
JK62-14C037-DKD.vbf	Range Rover Sport (L494)	ABS - Anti-Lock Brake System Control Module	DATA
JK62-14C037-DKE.vbf	Range Rover Sport (L494)	ABS - Anti-Lock Brake System Control Module	DATA
JK62-14C037-DKF.vbf	Range Rover Sport (L494)	ABS - Anti-Lock Brake System Control Module	DATA
JK62-14C037-DKG.vbf	Range Rover Sport (L494)	ABS - Anti-Lock Brake System Control Module	DATA
JK62-14C037-DKH.vbf	Range Rover Sport (L494)	ABS - Anti-Lock Brake System Control Module	DATA
JK62-14C037-DKJ.vbf	Range Rover Sport (L494)	ABS - Anti-Lock Brake System Control Module	DATA
JK62-14C037-DKK.vbf	Range Rover Sport (L494)	ABS - Anti-Lock Brake System Control Module	DATA
JK62-14C037-DLD.vbf	Range Rover Sport (L494)	ABS - Anti-Lock Brake System Control Module	DATA
JK62-14C037-DLE.vbf	Range Rover Sport (L494)	ABS - Anti-Lock Brake System Control Module	DATA
JK62-14C037-DLF.vbf	Range Rover Sport (L494)	ABS - Anti-Lock Brake System Control Module	DATA
JK62-14C037-DLG.vbf	Range Rover Sport (L494)	ABS - Anti-Lock Brake System Control Module	DATA
JK62-14C037-DLH.vbf	Range Rover Sport (L494)	ABS - Anti-Lock Brake System Control Module	DATA
JK62-14C037-DLJ.vbf	Range Rover Sport (L494)	ABS - Anti-Lock Brake System Control Module	DATA
JK62-14C037-DLK.vbf	Range Rover Sport (L494)	ABS - Anti-Lock Brake System Control Module	DATA
JK62-14C037-DMD.vbf	Range Rover Sport (L494)	ABS - Anti-Lock Brake System Control Module	DATA
JK62-14C037-DME.vbf	Range Rover Sport (L494)	ABS - Anti-Lock Brake System Control Module	DATA
JK62-14C037-DMF.vbf	Range Rover Sport (L494)	ABS - Anti-Lock Brake System Control Module	DATA
JK62-14C037-DMG.vbf	Range Rover Sport (L494)	ABS - Anti-Lock Brake System Control Module	DATA
JK62-14C037-DMH.vbf	Range Rover Sport (L494)	ABS - Anti-Lock Brake System Control Module	DATA
JK62-14C037-DMJ.vbf	Range Rover Sport (L494)	ABS - Anti-Lock Brake System Control Module	DATA
JK62-14C037-DMK.vbf	Range Rover Sport (L494)	ABS - Anti-Lock Brake System Control Module	DATA
JK62-14C037-DND.vbf	Range Rover Sport (L494)	ABS - Anti-Lock Brake System Control Module	DATA
JK62-14C037-DNE.vbf	Range Rover Sport (L494)	ABS - Anti-Lock Brake System Control Module	DATA
JK62-14C037-DNF.vbf	Range Rover Sport (L494)	ABS - Anti-Lock Brake System Control Module	DATA
JK62-14C037-DNG.vbf	Range Rover Sport (L494)	ABS - Anti-Lock Brake System Control Module	DATA
JK62-14C037-DNH.vbf	Range Rover Sport (L494)	ABS - Anti-Lock Brake System Control Module	DATA
JK62-14C037-DNJ.vbf	Range Rover Sport (L494)	ABS - Anti-Lock Brake System Control Module	DATA
JK62-14C037-DNK.vbf	Range Rover Sport (L494)	ABS - Anti-Lock Brake System Control Module	DATA
JK62-14C037-DPD.vbf	Range Rover Sport (L494)	ABS - Anti-Lock Brake System Control Module	DATA
JK62-14C037-DPE.vbf	Range Rover Sport (L494)	ABS - Anti-Lock Brake System Control Module	DATA
JK62-14C037-DPF.vbf	Range Rover Sport (L494)	ABS - Anti-Lock Brake System Control Module	DATA
JK62-14C037-DPG.vbf	Range Rover Sport (L494)	ABS - Anti-Lock Brake System Control Module	DATA
JK62-14C037-DPH.vbf	Range Rover Sport (L494)	ABS - Anti-Lock Brake System Control Module	DATA
JK62-14C037-DPJ.vbf	Range Rover Sport (L494)	ABS - Anti-Lock Brake System Control Module	DATA
JK62-14C037-DPK.vbf	Range Rover Sport (L494)	ABS - Anti-Lock Brake System Control Module	DATA
JK62-14C037-FAB.vbf	Range Rover Sport (L494)	ABS - Anti-Lock Brake System Control Module	DATA
JK62-14C037-FAC.vbf	Range Rover Sport (L494)	ABS - Anti-Lock Brake System Control Module	DATA
JK62-14C037-FAD.vbf	Range Rover Sport (L494)	ABS - Anti-Lock Brake System Control Module	DATA
JK62-14C037-FAE.vbf	Range Rover Sport (L494)	ABS - Anti-Lock Brake System Control Module	DATA
JK62-14C037-FAF.vbf	Range Rover Sport (L494)	ABS - Anti-Lock Brake System Control Module	DATA

File name	Vehicle line (indicative)	Module (ECU)	Type
JK62-14C037-FAG.vbf	Range Rover Sport (L494)	ABS - Anti-Lock Brake System Control Module	DATA
JK62-14C037-FAH.vbf	Range Rover Sport (L494)	ABS - Anti-Lock Brake System Control Module	DATA
JK62-14C037-FAJ.vbf	Range Rover Sport (L494)	ABS - Anti-Lock Brake System Control Module	DATA
JK62-14C037-FBB.vbf	Range Rover Sport (L494)	ABS - Anti-Lock Brake System Control Module	DATA
JK62-14C037-FBC.vbf	Range Rover Sport (L494)	ABS - Anti-Lock Brake System Control Module	DATA
JK62-14C037-FBD.vbf	Range Rover Sport (L494)	ABS - Anti-Lock Brake System Control Module	DATA
JK62-14C037-FBE.vbf	Range Rover Sport (L494)	ABS - Anti-Lock Brake System Control Module	DATA
JK62-14C037-FBF.vbf	Range Rover Sport (L494)	ABS - Anti-Lock Brake System Control Module	DATA
JK62-14C037-FBG.vbf	Range Rover Sport (L494)	ABS - Anti-Lock Brake System Control Module	DATA
JK62-14C037-FBH.vbf	Range Rover Sport (L494)	ABS - Anti-Lock Brake System Control Module	DATA
JK62-14C037-FBJ.vbf	Range Rover Sport (L494)	ABS - Anti-Lock Brake System Control Module	DATA
JK62-14C037-FCB.vbf	Range Rover Sport (L494)	ABS - Anti-Lock Brake System Control Module	DATA
JK62-14C037-FCC.vbf	Range Rover Sport (L494)	ABS - Anti-Lock Brake System Control Module	DATA
JK62-14C037-FCD.vbf	Range Rover Sport (L494)	ABS - Anti-Lock Brake System Control Module	DATA
JK62-14C037-FCE.vbf	Range Rover Sport (L494)	ABS - Anti-Lock Brake System Control Module	DATA
JK62-14C037-FCF.vbf	Range Rover Sport (L494)	ABS - Anti-Lock Brake System Control Module	DATA
JK62-14C037-FCG.vbf	Range Rover Sport (L494)	ABS - Anti-Lock Brake System Control Module	DATA
JK62-14C037-FCH.vbf	Range Rover Sport (L494)	ABS - Anti-Lock Brake System Control Module	DATA
JK62-14C037-FDB.vbf	Range Rover Sport (L494)	ABS - Anti-Lock Brake System Control Module	DATA
JK62-14C037-FDC.vbf	Range Rover Sport (L494)	ABS - Anti-Lock Brake System Control Module	DATA
JK62-14C037-FDD.vbf	Range Rover Sport (L494)	ABS - Anti-Lock Brake System Control Module	DATA
JK62-14C037-FDE.vbf	Range Rover Sport (L494)	ABS - Anti-Lock Brake System Control Module	DATA
JK62-14C037-FDF.vbf	Range Rover Sport (L494)	ABS - Anti-Lock Brake System Control Module	DATA
JK62-14C037-FDG.vbf	Range Rover Sport (L494)	ABS - Anti-Lock Brake System Control Module	DATA
JK62-14C037-FDH.vbf	Range Rover Sport (L494)	ABS - Anti-Lock Brake System Control Module	DATA
JK62-14C037-FEB.vbf	Range Rover Sport (L494)	ABS - Anti-Lock Brake System Control Module	DATA
JK62-14C037-FEC.vbf	Range Rover Sport (L494)	ABS - Anti-Lock Brake System Control Module	DATA
JK62-14C037-FED.vbf	Range Rover Sport (L494)	ABS - Anti-Lock Brake System Control Module	DATA
JK62-14C037-FEE.vbf	Range Rover Sport (L494)	ABS - Anti-Lock Brake System Control Module	DATA
JK62-14C037-FEF.vbf	Range Rover Sport (L494)	ABS - Anti-Lock Brake System Control Module	DATA
JK62-14C037-FEG.vbf	Range Rover Sport (L494)	ABS - Anti-Lock Brake System Control Module	DATA
JK62-14C037-FEH.vbf	Range Rover Sport (L494)	ABS - Anti-Lock Brake System Control Module	DATA
JK62-14C037-FFB.vbf	Range Rover Sport (L494)	ABS - Anti-Lock Brake System Control Module	DATA
JK62-14C037-FFC.vbf	Range Rover Sport (L494)	ABS - Anti-Lock Brake System Control Module	DATA
JK62-14C037-FFD.vbf	Range Rover Sport (L494)	ABS - Anti-Lock Brake System Control Module	DATA
JK62-14C037-FFE.vbf	Range Rover Sport (L494)	ABS - Anti-Lock Brake System Control Module	DATA
JK62-14C037-FFF.vbf	Range Rover Sport (L494)	ABS - Anti-Lock Brake System Control Module	DATA
JK62-14C037-FFG.vbf	Range Rover Sport (L494)	ABS - Anti-Lock Brake System Control Module	DATA
JK62-14C037-FFH.vbf	Range Rover Sport (L494)	ABS - Anti-Lock Brake System Control Module	DATA
JK62-14C037-FGB.vbf	Range Rover Sport (L494)	ABS - Anti-Lock Brake System Control Module	DATA
JK62-14C037-FGC.vbf	Range Rover Sport (L494)	ABS - Anti-Lock Brake System Control Module	DATA
JK62-14C037-FGD.vbf	Range Rover Sport (L494)	ABS - Anti-Lock Brake System Control Module	DATA
JK62-14C037-FGE.vbf	Range Rover Sport (L494)	ABS - Anti-Lock Brake System Control Module	DATA
JK62-14C037-FGF.vbf	Range Rover Sport (L494)	ABS - Anti-Lock Brake System Control Module	DATA
JK62-14C037-FGG.vbf	Range Rover Sport (L494)	ABS - Anti-Lock Brake System Control Module	DATA
JK62-14C037-FGH.vbf	Range Rover Sport (L494)	ABS - Anti-Lock Brake System Control Module	DATA
JK62-14C037-FHB.vbf	Range Rover Sport (L494)	ABS - Anti-Lock Brake System Control Module	DATA
JK62-14C037-FHC.vbf	Range Rover Sport (L494)	ABS - Anti-Lock Brake System Control Module	DATA
JK62-14C037-FHD.vbf	Range Rover Sport (L494)	ABS - Anti-Lock Brake System Control Module	DATA
JK62-14C037-FHE.vbf	Range Rover Sport (L494)	ABS - Anti-Lock Brake System Control Module	DATA
JK62-14C037-FHF.vbf	Range Rover Sport (L494)	ABS - Anti-Lock Brake System Control Module	DATA
JK62-14C037-FHG.vbf	Range Rover Sport (L494)	ABS - Anti-Lock Brake System Control Module	DATA
JK62-14C037-FHH.vbf	Range Rover Sport (L494)	ABS - Anti-Lock Brake System Control Module	DATA
JK62-14C037-FJB.vbf	Range Rover Sport (L494)	ABS - Anti-Lock Brake System Control Module	DATA
JK62-14C037-FJC.vbf	Range Rover Sport (L494)	ABS - Anti-Lock Brake System Control Module	DATA
JK62-14C037-FJD.vbf	Range Rover Sport (L494)	ABS - Anti-Lock Brake System Control Module	DATA
JK62-14C037-FJE.vbf	Range Rover Sport (L494)	ABS - Anti-Lock Brake System Control Module	DATA
JK62-14C037-FJF.vbf	Range Rover Sport (L494)	ABS - Anti-Lock Brake System Control Module	DATA
JK62-14C037-FJG.vbf	Range Rover Sport (L494)	ABS - Anti-Lock Brake System Control Module	DATA
JK62-14C037-FJH.vbf	Range Rover Sport (L494)	ABS - Anti-Lock Brake System Control Module	DATA
JK62-14C037-FKB.vbf	Range Rover Sport (L494)	ABS - Anti-Lock Brake System Control Module	DATA
JK62-14C037-FKC.vbf	Range Rover Sport (L494)	ABS - Anti-Lock Brake System Control Module	DATA
JK62-14C037-FKD.vbf	Range Rover Sport (L494)	ABS - Anti-Lock Brake System Control Module	DATA
JK62-14C037-FKE.vbf	Range Rover Sport (L494)	ABS - Anti-Lock Brake System Control Module	DATA
JK62-14C037-FKF.vbf	Range Rover Sport (L494)	ABS - Anti-Lock Brake System Control Module	DATA
JK62-14C037-FKG.vbf	Range Rover Sport (L494)	ABS - Anti-Lock Brake System Control Module	DATA
JK62-14C037-FKH.vbf	Range Rover Sport (L494)	ABS - Anti-Lock Brake System Control Module	DATA
JK62-14C037-FLB.vbf	Range Rover Sport (L494)	ABS - Anti-Lock Brake System Control Module	DATA
JK62-14C037-FLC.vbf	Range Rover Sport (L494)	ABS - Anti-Lock Brake System Control Module	DATA
JK62-14C037-FLD.vbf	Range Rover Sport (L494)	ABS - Anti-Lock Brake System Control Module	DATA
JK62-14C037-FLE.vbf	Range Rover Sport (L494)	ABS - Anti-Lock Brake System Control Module	DATA
JK62-14C037-FLF.vbf	Range Rover Sport (L494)	ABS - Anti-Lock Brake System Control Module	DATA
JK62-14C037-FLG.vbf	Range Rover Sport (L494)	ABS - Anti-Lock Brake System Control Module	DATA
JK62-14C037-FLH.vbf	Range Rover Sport (L494)	ABS - Anti-Lock Brake System Control Module	DATA
JK62-14C037-HAE.vbf	Range Rover Sport (L494)	ABS - Anti-Lock Brake System Control Module	DATA
JK62-14C037-HAF.vbf	Range Rover Sport (L494)	ABS - Anti-Lock Brake System Control Module	DATA

File name	Vehicle line (indicative)	Module (ECU)	Type
JK62-14C037-HAG.vbf	Range Rover Sport (L494)	ABS - Anti-Lock Brake System Control Module	DATA
JK62-14C037-HAH.vbf	Range Rover Sport (L494)	ABS - Anti-Lock Brake System Control Module	DATA
JK62-14C037-HAJ.vbf	Range Rover Sport (L494)	ABS - Anti-Lock Brake System Control Module	DATA
JK62-14C037-HAK.vbf	Range Rover Sport (L494)	ABS - Anti-Lock Brake System Control Module	DATA
JK62-14C037-HAL.vbf	Range Rover Sport (L494)	ABS - Anti-Lock Brake System Control Module	DATA
JK62-14C037-HAM.vbf	Range Rover Sport (L494)	ABS - Anti-Lock Brake System Control Module	DATA
JK62-14C065-AB.vbf	Range Rover Sport (L494)	DDM - Driver Front Door Module	DATA
JK62-14C065-AD.vbf	Range Rover Sport (L494)	DDM - Driver Front Door Module	DATA
JK62-14C065-AE.vbf	Range Rover Sport (L494)	DDM - Driver Front Door Module	DATA
JK62-14C065-AF.vbf	Range Rover Sport (L494)	DDM - Driver Front Door Module	DATA
JK62-14C069-AB.vbf	Range Rover Sport (L494)	DRDM - Driver Rear Door Module	DATA
JK62-14C069-AD.vbf	Range Rover Sport (L494)	DRDM - Driver Rear Door Module	DATA
JK62-14C069-AE.vbf	Range Rover Sport (L494)	DRDM - Driver Rear Door Module	DATA
JK62-14C069-AF.vbf	Range Rover Sport (L494)	DRDM - Driver Rear Door Module	DATA
JK62-14C085-AB.vbf	Range Rover Sport (L494)	HCM - Headlamp Control Module #1	DATA
JK62-14C085-AD.vbf	Range Rover Sport (L494)	HCM - Headlamp Control Module #1	DATA
JK62-14C085-AE.vbf	Range Rover Sport (L494)	HCM - Headlamp Control Module #1	DATA
JK62-14C085-AF.vbf	Range Rover Sport (L494)	HCM - Headlamp Control Module #1	DATA
JK62-14C085-AG.vbf	Range Rover Sport (L494)	HCM - Headlamp Control Module #1	DATA
JK62-14C085-AJ.vbf	Range Rover Sport (L494)	HCM - Headlamp Control Module #1	DATA
JK62-14C085-AK.vbf	Range Rover Sport (L494)	HCM - Headlamp Control Module #1	DATA
JK62-14C085-BB.vbf	Range Rover Sport (L494)	Not specified	DATA
JK62-14C085-BD.vbf	Range Rover Sport (L494)	Not specified	DATA
JK62-14C085-BE.vbf	Range Rover Sport (L494)	Not specified	DATA
JK62-14C085-BF.vbf	Range Rover Sport (L494)	Not specified	DATA
JK62-14C085-BG.vbf	Range Rover Sport (L494)	Not specified	DATA
JK62-14C085-BJ.vbf	Range Rover Sport (L494)	Not specified	DATA
JK62-14C085-BK.vbf	Range Rover Sport (L494)	Not specified	DATA
JK62-14C088-JA.vbf	Range Rover Sport (L494)	IPC - Instrument Panel Cluster (IPC) Control Module	DATA
JK62-14C088-JB.vbf	Range Rover Sport (L494)	IPC - Instrument Panel Cluster (IPC) Control Module	DATA
JK62-14C088-JD.vbf	Range Rover Sport (L494)	IPC - Instrument Panel Cluster (IPC) Control Module	DATA
JK62-14C088-JE.vbf	Range Rover Sport (L494)	IPC - Instrument Panel Cluster (IPC) Control Module	DATA
JK62-14C088-JG.vbf	Range Rover Sport (L494)	IPC - Instrument Panel Cluster (IPC) Control Module	DATA
JK62-14C088-JH.vbf	Range Rover Sport (L494)	IPC - Instrument Panel Cluster (IPC) Control Module	DATA
JK62-14C088-JM.vbf	Range Rover Sport (L494)	IPC - Instrument Panel Cluster (IPC) Control Module	DATA
JK62-14C091-AC.vbf	Range Rover Sport (L494)	PAM - Parking Assist Control Module	CARCFG
JK62-14C091-AD.vbf	Range Rover Sport (L494)	PAM - Parking Assist Control Module	DATA
JK62-14C091-AF.vbf	Range Rover Sport (L494)	PAM - Parking Assist Control Module	DATA
JK62-14C091-AG.vbf	Range Rover Sport (L494)	PAM - Parking Assist Control Module	DATA
JK62-14C091-AH.vbf	Range Rover Sport (L494)	PAM - Parking Assist Control Module	DATA
JK62-14C091-AJ.vbf	Range Rover Sport (L494)	PAM - Parking Assist Control Module	DATA
JK62-14C091-AK.vbf	Range Rover Sport (L494)	PAM - Parking Assist Control Module	DATA
JK62-14C091-AL.vbf	Range Rover Sport (L494)	PAM - Parking Assist Control Module	DATA
JK62-14C091-AM.vbf	Range Rover Sport (L494)	PAM - Parking Assist Control Module	DATA
JK62-14C091-AP.vbf	Range Rover Sport (L494)	PAM - Parking Assist Control Module	DATA
JK62-14C098-DA.vbf	Range Rover Sport (L494)	RCM - Restraints Control Module	DATA
JK62-14C098-EA.vbf	Range Rover Sport (L494)	RCM - Restraints Control Module	DATA
JK62-14C098-EB.vbf	Range Rover Sport (L494)	RCM - Restraints Control Module	DATA
JK62-14C098-EC.vbf	Range Rover Sport (L494)	RCM - Restraints Control Module	DATA
JK62-14C098-ED.vbf	Range Rover Sport (L494)	RCM - Restraints Control Module	DATA
JK62-14C098-EE.vbf	Range Rover Sport (L494)	RCM - Restraints Control Module	DATA
JK62-14C098-EF.vbf	Range Rover Sport (L494)	RCM - Restraints Control Module	DATA
JK62-14C098-FA.vbf	Range Rover Sport (L494)	RCM - Restraints Control Module	DATA
JK62-14C105-AC.vbf	Range Rover Sport (L494)	TMC Traffic Message Channel Module	EXE
JK62-14C105-AD.vbf	Range Rover Sport (L494)	TMC Traffic Message Channel Module	EXE
JK62-14C105-AE.vbf	Range Rover Sport (L494)	TMC Traffic Message Channel Module	EXE
JK62-14C105-BC.vbf	Range Rover Sport (L494)	TMC Traffic Message Channel Module	EXE
JK62-14C105-BD.vbf	Range Rover Sport (L494)	TMC Traffic Message Channel Module	EXE
JK62-14C105-BE.vbf	Range Rover Sport (L494)	TMC Traffic Message Channel Module	EXE
JK62-14C105-CB.vbf	Range Rover Sport (L494)	TMC Traffic Message Channel Module	EXE
JK62-14C105-CC.vbf	Range Rover Sport (L494)	TMC Traffic Message Channel Module	EXE
JK62-14C105-CD.vbf	Range Rover Sport (L494)	TMC Traffic Message Channel Module	EXE
JK62-14C105-CF.vbf	Range Rover Sport (L494)	TMC Traffic Message Channel Module	EXE
JK62-14C109-AB.vbf	Range Rover Sport (L494)	PDM - Passenger Front Door Module	DATA
JK62-14C109-AD.vbf	Range Rover Sport (L494)	PDM - Passenger Front Door Module	DATA
JK62-14C109-AE.vbf	Range Rover Sport (L494)	PDM - Passenger Front Door Module	DATA
JK62-14C109-AF.vbf	Range Rover Sport (L494)	PDM - Passenger Front Door Module	DATA
JK62-14C113-AB.vbf	Range Rover Sport (L494)	PRDM - Passenger Rear Door Module	DATA
JK62-14C113-AD.vbf	Range Rover Sport (L494)	PRDM - Passenger Rear Door Module	DATA
JK62-14C113-AE.vbf	Range Rover Sport (L494)	PRDM - Passenger Rear Door Module	DATA
JK62-14C113-AF.vbf	Range Rover Sport (L494)	PRDM - Passenger Rear Door Module	DATA
JK62-14C152-AA.vbf	Range Rover Sport (L494)	TPM - Tire Pressure Monitor Module	DATA
JK62-14C152-AB.vbf	Range Rover Sport (L494)	TPM - Tire Pressure Monitor Module	DATA
JK62-14C185-AB.vbf	Range Rover Sport (L494)	BCM - Body Control Module	DATA
JK62-14C185-AC.vbf	Range Rover Sport (L494)	BCM - Body Control Module	DATA
JK62-14C185-AD.vbf	Range Rover Sport (L494)	BCM - Body Control Module	DATA

File name	Vehicle line (indicative)	Module (ECU)	Type
JK62-14C185-AE.vbf	Range Rover Sport (L494)	BCM - Body Control Module	DATA
JK62-14C185-AF.vbf	Range Rover Sport (L494)	BCM - Body Control Module	DATA
JK62-14C218-AA.vbf	Range Rover Sport (L494)	PSCM - Power Steering Control Module	EXE
JK62-14C218-AB.vbf	Range Rover Sport (L494)	PSCM - Power Steering Control Module	EXE
JK62-14C218-BA.vbf	Range Rover Sport (L494)	PSCM - Power Steering Control Module	EXE
JK62-14C218-BB.vbf	Range Rover Sport (L494)	PSCM - Power Steering Control Module	EXE
JK62-14C218-BC.vbf	Range Rover Sport (L494)	PSCM - Power Steering Control Module	EXE
JK62-14C218-CA.vbf	Range Rover Sport (L494)	PSCM - Power Steering Control Module	EXE
JK62-14C218-CB.vbf	Range Rover Sport (L494)	PSCM - Power Steering Control Module	EXE
JK62-14C218-CC.vbf	Range Rover Sport (L494)	PSCM - Power Steering Control Module	EXE
JK62-14C527-AA.vbf	Range Rover Sport (L494)	AAM - Audio Amplifier Module	DATA
JK62-14C527-AAA.vbf	Range Rover Sport (L494)	AAM - Audio Amplifier Module	DATA
JK62-14C527-AAC.vbf	Range Rover Sport (L494)	AAM - Audio Amplifier Module	DATA
JK62-14C527-AAD.vbf	Range Rover Sport (L494)	AAM - Audio Amplifier Module	DATA
JK62-14C527-AAE.vbf	Range Rover Sport (L494)	AAM - Audio Amplifier Module	DATA
JK62-14C527-AB.vbf	Range Rover Sport (L494)	AAM - Audio Amplifier Module	DATA
JK62-14C527-ABA.vbf	Range Rover Sport (L494)	AAM - Audio Amplifier Module	DATA
JK62-14C527-ABB.vbf	Range Rover Sport (L494)	AAM - Audio Amplifier Module	DATA
JK62-14C527-ACA.vbf	Range Rover Sport (L494)	AAM - Audio Amplifier Module	DATA
JK62-14C527-ACB.vbf	Range Rover Sport (L494)	AAM - Audio Amplifier Module	DATA
JK62-14C527-ADA.vbf	Range Rover Sport (L494)	AAM - Audio Amplifier Module	DATA
JK62-14C527-AEA.vbf	Range Rover Sport (L494)	AAM - Audio Amplifier Module	DATA
JK62-14C527-AEB.vbf	Range Rover Sport (L494)	AAM - Audio Amplifier Module	DATA
JK62-14C527-AGA.vbf	Range Rover Sport (L494)	AAM - Audio Amplifier Module	DATA
JK62-14C527-AGB.vbf	Range Rover Sport (L494)	AAM - Audio Amplifier Module	DATA
JK62-14C527-AHA.vbf	Range Rover Sport (L494)	AAM - Audio Amplifier Module	DATA
JK62-14C527-AHB.vbf	Range Rover Sport (L494)	AAM - Audio Amplifier Module	DATA
JK62-14C527-AJA.vbf	Range Rover Sport (L494)	AAM - Audio Amplifier Module	DATA
JK62-14C527-BA.vbf	Range Rover Sport (L494)	AAM - Audio Amplifier Module	DATA
JK62-14C527-BAA.vbf	Range Rover Sport (L494)	AAM - Audio Amplifier Module	DATA
JK62-14C527-BB.vbf	Range Rover Sport (L494)	AAM - Audio Amplifier Module	DATA
JK62-14C527-BBA.vbf	Range Rover Sport (L494)	AAM - Audio Amplifier Module	DATA
JK62-14C527-BBB.vbf	Range Rover Sport (L494)	AAM - Audio Amplifier Module	DATA
JK62-14C527-BC.vbf	Range Rover Sport (L494)	AAM - Audio Amplifier Module	DATA
JK62-14C527-BCA.vbf	Range Rover Sport (L494)	AAM - Audio Amplifier Module	DATA
JK62-14C527-BCB.vbf	Range Rover Sport (L494)	AAM - Audio Amplifier Module	DATA
JK62-14C527-BDA.vbf	Range Rover Sport (L494)	AAM - Audio Amplifier Module	DATA
JK62-14C527-BEA.vbf	Range Rover Sport (L494)	AAM - Audio Amplifier Module	DATA
JK62-14C527-BEB.vbf	Range Rover Sport (L494)	AAM - Audio Amplifier Module	DATA
JK62-14C527-BGA.vbf	Range Rover Sport (L494)	AAM - Audio Amplifier Module	DATA
JK62-14C527-BGB.vbf	Range Rover Sport (L494)	AAM - Audio Amplifier Module	DATA
JK62-14C527-BHA.vbf	Range Rover Sport (L494)	AAM - Audio Amplifier Module	DATA
JK62-14C527-BHB.vbf	Range Rover Sport (L494)	AAM - Audio Amplifier Module	DATA
JK62-14C527-BJA.vbf	Range Rover Sport (L494)	AAM - Audio Amplifier Module	DATA
JK62-14C527-CA.vbf	Range Rover Sport (L494)	AAM - Audio Amplifier Module	DATA
JK62-14C527-CAA.vbf	Range Rover Sport (L494)	AAM - Audio Amplifier Module	DATA
JK62-14C527-CAC.vbf	Range Rover Sport (L494)	AAM - Audio Amplifier Module	DATA
JK62-14C527-CAD.vbf	Range Rover Sport (L494)	AAM - Audio Amplifier Module	DATA
JK62-14C527-CAE.vbf	Range Rover Sport (L494)	AAM - Audio Amplifier Module	DATA
JK62-14C527-CBA.vbf	Range Rover Sport (L494)	AAM - Audio Amplifier Module	DATA
JK62-14C527-CBB.vbf	Range Rover Sport (L494)	AAM - Audio Amplifier Module	DATA
JK62-14C527-CC.vbf	Range Rover Sport (L494)	AAM - Audio Amplifier Module	DATA
JK62-14C527-CCA.vbf	Range Rover Sport (L494)	AAM - Audio Amplifier Module	DATA
JK62-14C527-CCC.vbf	Range Rover Sport (L494)	AAM - Audio Amplifier Module	DATA
JK62-14C527-CDA.vbf	Range Rover Sport (L494)	AAM - Audio Amplifier Module	DATA
JK62-14C527-CDB.vbf	Range Rover Sport (L494)	AAM - Audio Amplifier Module	DATA
JK62-14C527-CDC.vbf	Range Rover Sport (L494)	AAM - Audio Amplifier Module	DATA
JK62-14C527-CDD.vbf	Range Rover Sport (L494)	AAM - Audio Amplifier Module	DATA
JK62-14C527-CDE.vbf	Range Rover Sport (L494)	AAM - Audio Amplifier Module	DATA
JK62-14C527-CEA.vbf	Range Rover Sport (L494)	AAM - Audio Amplifier Module	DATA
JK62-14C527-CEB.vbf	Range Rover Sport (L494)	AAM - Audio Amplifier Module	DATA
JK62-14C527-CEC.vbf	Range Rover Sport (L494)	AAM - Audio Amplifier Module	DATA
JK62-14C527-CGA.vbf	Range Rover Sport (L494)	AAM - Audio Amplifier Module	DATA
JK62-14C527-CGB.vbf	Range Rover Sport (L494)	AAM - Audio Amplifier Module	DATA
JK62-14C527-CHA.vbf	Range Rover Sport (L494)	AAM - Audio Amplifier Module	DATA
JK62-14C527-CHB.vbf	Range Rover Sport (L494)	AAM - Audio Amplifier Module	DATA
JK62-14C527-CJA.vbf	Range Rover Sport (L494)	AAM - Audio Amplifier Module	DATA
JK62-14C527-CJC.vbf	Range Rover Sport (L494)	AAM - Audio Amplifier Module	DATA
JK62-14C527-DA.vbf	Range Rover Sport (L494)	AAM - Audio Amplifier Module	DATA
JK62-14C527-DAA.vbf	Range Rover Sport (L494)	AAM - Audio Amplifier Module	DATA
JK62-14C527-DBA.vbf	Range Rover Sport (L494)	AAM - Audio Amplifier Module	DATA
JK62-14C527-DBB.vbf	Range Rover Sport (L494)	AAM - Audio Amplifier Module	DATA
JK62-14C527-DC.vbf	Range Rover Sport (L494)	AAM - Audio Amplifier Module	DATA
JK62-14C527-DCA.vbf	Range Rover Sport (L494)	AAM - Audio Amplifier Module	DATA
JK62-14C527-DCC.vbf	Range Rover Sport (L494)	AAM - Audio Amplifier Module	DATA
JK62-14C527-DD.vbf	Range Rover Sport (L494)	AAM - Audio Amplifier Module	DATA

File name	Vehicle line (indicative)	Module (ECU)	Type
JK62-14C527-DDA.vbf	Range Rover Sport (L494)	AAM - Audio Amplifier Module	DATA
JK62-14C527-DDB.vbf	Range Rover Sport (L494)	AAM - Audio Amplifier Module	DATA
JK62-14C527-DDC.vbf	Range Rover Sport (L494)	AAM - Audio Amplifier Module	DATA
JK62-14C527-DDD.vbf	Range Rover Sport (L494)	AAM - Audio Amplifier Module	DATA
JK62-14C527-DDE.vbf	Range Rover Sport (L494)	AAM - Audio Amplifier Module	DATA
JK62-14C527-DEA.vbf	Range Rover Sport (L494)	AAM - Audio Amplifier Module	DATA
JK62-14C527-DEB.vbf	Range Rover Sport (L494)	AAM - Audio Amplifier Module	DATA
JK62-14C527-DGA.vbf	Range Rover Sport (L494)	AAM - Audio Amplifier Module	DATA
JK62-14C527-DGB.vbf	Range Rover Sport (L494)	AAM - Audio Amplifier Module	DATA
JK62-14C527-DHA.vbf	Range Rover Sport (L494)	AAM - Audio Amplifier Module	DATA
JK62-14C527-DHB.vbf	Range Rover Sport (L494)	AAM - Audio Amplifier Module	DATA
JK62-14C527-DJA.vbf	Range Rover Sport (L494)	AAM - Audio Amplifier Module	DATA
JK62-14C527-DJB.vbf	Range Rover Sport (L494)	AAM - Audio Amplifier Module	DATA
JK62-14C527-DJC.vbf	Range Rover Sport (L494)	AAM - Audio Amplifier Module	DATA
JK62-14C527-EA.vbf	Range Rover Sport (L494)	AAM - Audio Amplifier Module	DATA
JK62-14C527-EB.vbf	Range Rover Sport (L494)	AAM - Audio Amplifier Module	DATA
JK62-14C527-GA.vbf	Range Rover Sport (L494)	AAM - Audio Amplifier Module	DATA
JK62-14C527-GB.vbf	Range Rover Sport (L494)	AAM - Audio Amplifier Module	DATA
JK62-14C527-GC.vbf	Range Rover Sport (L494)	AAM - Audio Amplifier Module	DATA
JK62-14C527-HA.vbf	Range Rover Sport (L494)	AAM - Audio Amplifier Module	DATA
JK62-14C527-HB.vbf	Range Rover Sport (L494)	AAM - Audio Amplifier Module	DATA
JK62-14C527-HC.vbf	Range Rover Sport (L494)	AAM - Audio Amplifier Module	DATA
JK62-14C527-JA.vbf	Range Rover Sport (L494)	AAM - Audio Amplifier Module	DATA
JK62-14C548-AA.vbf	Range Rover Sport (L494)	PSM - Passenger Front Seat Module	EXE
JK62-14C548-AB.vbf	Range Rover Sport (L494)	PSM - Passenger Front Seat Module	EXE
JK62-14C548-AC.vbf	Range Rover Sport (L494)	PSM - Passenger Front Seat Module	EXE
JK62-14C549-AAA.vbf	Range Rover Sport (L494)	PSM - Passenger Front Seat Module	EXE
JK62-14C549-ABA.vbf	Range Rover Sport (L494)	PSM - Passenger Front Seat Module	EXE
JK62-14C549-ABB.vbf	Range Rover Sport (L494)	PSM - Passenger Front Seat Module	EXE
JK62-14C549-ABC.vbf	Range Rover Sport (L494)	PSM - Passenger Front Seat Module	EXE
JK62-14C549-ACA.vbf	Range Rover Sport (L494)	PSM - Passenger Front Seat Module	EXE
JK62-14C549-ACB.vbf	Range Rover Sport (L494)	PSM - Passenger Front Seat Module	EXE
JK62-14C549-ACC.vbf	Range Rover Sport (L494)	PSM - Passenger Front Seat Module	EXE
JK62-14C549-BAA.vbf	Range Rover Sport (L494)	PSM - Passenger Front Seat Module	EXE
JK62-14C549-BAB.vbf	Range Rover Sport (L494)	PSM - Passenger Front Seat Module	EXE
JK62-14C549-BBA.vbf	Range Rover Sport (L494)	PSM - Passenger Front Seat Module	EXE
JK62-14C549-BBB.vbf	Range Rover Sport (L494)	PSM - Passenger Front Seat Module	EXE
JK62-14C549-BBC.vbf	Range Rover Sport (L494)	PSM - Passenger Front Seat Module	EXE
JK62-14C549-BBD.vbf	Range Rover Sport (L494)	PSM - Passenger Front Seat Module	EXE
JK62-14C549-BCA.vbf	Range Rover Sport (L494)	PSM - Passenger Front Seat Module	EXE
JK62-14C549-BCB.vbf	Range Rover Sport (L494)	PSM - Passenger Front Seat Module	EXE
JK62-14C549-BCC.vbf	Range Rover Sport (L494)	PSM - Passenger Front Seat Module	EXE
JK62-14C570-SAB.vbf	Range Rover Sport (L494)	PCM - Powertrain Control Module	EXE
JK62-14C570-SAD.vbf	Range Rover Sport (L494)	PCM - Powertrain Control Module	EXE
JK62-14C570-SAF.vbf	Range Rover Sport (L494)	PCM - Powertrain Control Module	EXE
JK62-14C570-SAG.vbf	Range Rover Sport (L494)	PCM - Powertrain Control Module	EXE
JK62-14C570-SAH.vbf	Range Rover Sport (L494)	PCM - Powertrain Control Module	EXE
JK62-14C570-SBB.vbf	Range Rover Sport (L494)	PCM - Powertrain Control Module	EXE
JK62-14C570-SBD.vbf	Range Rover Sport (L494)	PCM - Powertrain Control Module	EXE
JK62-14C570-SBE.vbf	Range Rover Sport (L494)	PCM - Powertrain Control Module	EXE
JK62-14C570-SCB.vbf	Range Rover Sport (L494)	PCM - Powertrain Control Module	EXE
JK62-14C570-SCD.vbf	Range Rover Sport (L494)	PCM - Powertrain Control Module	EXE
JK62-14C570-SCF.vbf	Range Rover Sport (L494)	PCM - Powertrain Control Module	EXE
JK62-14C570-SDB.vbf	Range Rover Sport (L494)	PCM - Powertrain Control Module	EXE
JK62-14C570-SDD.vbf	Range Rover Sport (L494)	PCM - Powertrain Control Module	EXE
JK62-14C570-SDE.vbf	Range Rover Sport (L494)	PCM - Powertrain Control Module	EXE
JK62-14C570-SED.vbf	Range Rover Sport (L494)	PCM - Powertrain Control Module	EXE
JK62-14C570-SEE.vbf	Range Rover Sport (L494)	PCM - Powertrain Control Module	EXE
JK62-14C570-STB.vbf	Range Rover Sport (L494)	PCM - Powertrain Control Module	EXE
JK62-14C570-STD.vbf	Range Rover Sport (L494)	PCM - Powertrain Control Module	EXE
JK62-14C570-STE.vbf	Range Rover Sport (L494)	PCM - Powertrain Control Module	EXE
JK62-14C609-AA.vbf	Range Rover Sport (L494)	PSCM - Power Steering Control Module	EXE
JK62-14C609-AB.vbf	Range Rover Sport (L494)	PSCM - Power Steering Control Module	EXE
JK62-14D183-AB.vbf	Range Rover Sport (L494)	OCS - Restraints Occupant Classification System Module	DATA
JK62-14D183-BA.vbf	Range Rover Sport (L494)	OCS - Restraints Occupant Classification System Module	DATA
JK62-14D564-AA.vbf	Range Rover Sport (L494)	SODL - Side Obstacle Detection Control Module - Left	DATA
JK62-14D564-AC.vbf	Range Rover Sport (L494)	SODL - Side Obstacle Detection Control Module - Left	DATA
JK62-14D564-BA.vbf	Range Rover Sport (L494)	SODR - Side Obstacle Detection Control Module - Right	DATA
JK62-14D564-BC.vbf	Range Rover Sport (L494)	SODR - Side Obstacle Detection Control Module - Right	DATA
JK62-14E094-HAB.vbf	Range Rover Sport (L494)	CHCM - Chassis Control Module	EXE
JK62-14E094-HAD.vbf	Range Rover Sport (L494)	CHCM - Chassis Control Module	EXE
JK62-14E094-HAE.vbf	Range Rover Sport (L494)	CHCM - Chassis Control Module	EXE
JK62-14E094-HAF.vbf	Range Rover Sport (L494)	CHCM - Chassis Control Module	EXE
JK62-14E094-HAG.vbf	Range Rover Sport (L494)	CHCM - Chassis Control Module	EXE
JK62-14E094-HAH.vbf	Range Rover Sport (L494)	CHCM - Chassis Control Module	EXE
JK62-14E094-HAJ.vbf	Range Rover Sport (L494)	CHCM - Chassis Control Module	EXE

File name	Vehicle line (indicative)	Module (ECU)	Type
JK62-14E094-HBB.vbf	Range Rover Sport (L494)	CHCM - Chassis Control Module	EXE
JK62-14E094-HBD.vbf	Range Rover Sport (L494)	CHCM - Chassis Control Module	EXE
JK62-14E094-HBE.vbf	Range Rover Sport (L494)	CHCM - Chassis Control Module	EXE
JK62-14E094-HBF.vbf	Range Rover Sport (L494)	CHCM - Chassis Control Module	EXE
JK62-14E094-HBG.vbf	Range Rover Sport (L494)	CHCM - Chassis Control Module	EXE
JK62-14E094-HBH.vbf	Range Rover Sport (L494)	CHCM - Chassis Control Module	EXE
JK62-14E094-HBJ.vbf	Range Rover Sport (L494)	CHCM - Chassis Control Module	EXE
JK62-14E094-HCB.vbf	Range Rover Sport (L494)	CHCM - Chassis Control Module	EXE
JK62-14E094-HCD.vbf	Range Rover Sport (L494)	CHCM - Chassis Control Module	EXE
JK62-14E094-HCE.vbf	Range Rover Sport (L494)	CHCM - Chassis Control Module	EXE
JK62-14E094-HCF.vbf	Range Rover Sport (L494)	CHCM - Chassis Control Module	EXE
JK62-14E094-HCG.vbf	Range Rover Sport (L494)	CHCM - Chassis Control Module	EXE
JK62-14E094-HCH.vbf	Range Rover Sport (L494)	CHCM - Chassis Control Module	EXE
JK62-14E094-HCJ.vbf	Range Rover Sport (L494)	CHCM - Chassis Control Module	EXE
JK62-14E094-JAB.vbf	Range Rover Sport (L494)	CHCM - Chassis Control Module	EXE
JK62-14E094-JAD.vbf	Range Rover Sport (L494)	CHCM - Chassis Control Module	EXE
JK62-14E094-JAE.vbf	Range Rover Sport (L494)	CHCM - Chassis Control Module	EXE
JK62-14E094-JAF.vbf	Range Rover Sport (L494)	CHCM - Chassis Control Module	EXE
JK62-14E094-JAG.vbf	Range Rover Sport (L494)	CHCM - Chassis Control Module	EXE
JK62-14E094-JAH.vbf	Range Rover Sport (L494)	CHCM - Chassis Control Module	EXE
JK62-14E094-JAJ.vbf	Range Rover Sport (L494)	CHCM - Chassis Control Module	EXE
JK62-14E094-JBB.vbf	Range Rover Sport (L494)	CHCM - Chassis Control Module	EXE
JK62-14E094-JBD.vbf	Range Rover Sport (L494)	CHCM - Chassis Control Module	EXE
JK62-14E094-JBE.vbf	Range Rover Sport (L494)	CHCM - Chassis Control Module	EXE
JK62-14E094-JBF.vbf	Range Rover Sport (L494)	CHCM - Chassis Control Module	EXE
JK62-14E094-JBG.vbf	Range Rover Sport (L494)	CHCM - Chassis Control Module	EXE
JK62-14E094-JBH.vbf	Range Rover Sport (L494)	CHCM - Chassis Control Module	EXE
JK62-14E094-JBJ.vbf	Range Rover Sport (L494)	CHCM - Chassis Control Module	EXE
JK62-14E094-JCB.vbf	Range Rover Sport (L494)	CHCM - Chassis Control Module	EXE
JK62-14E094-JCD.vbf	Range Rover Sport (L494)	CHCM - Chassis Control Module	EXE
JK62-14E094-JCE.vbf	Range Rover Sport (L494)	CHCM - Chassis Control Module	EXE
JK62-14E094-JCF.vbf	Range Rover Sport (L494)	CHCM - Chassis Control Module	EXE
JK62-14E094-JCG.vbf	Range Rover Sport (L494)	CHCM - Chassis Control Module	EXE
JK62-14E094-JCH.vbf	Range Rover Sport (L494)	CHCM - Chassis Control Module	EXE
JK62-14E094-JCJ.vbf	Range Rover Sport (L494)	CHCM - Chassis Control Module	EXE
JK62-14E094-JDB.vbf	Range Rover Sport (L494)	CHCM - Chassis Control Module	EXE
JK62-14E094-JDD.vbf	Range Rover Sport (L494)	CHCM - Chassis Control Module	EXE
JK62-14E094-JDE.vbf	Range Rover Sport (L494)	CHCM - Chassis Control Module	EXE
JK62-14E094-JDF.vbf	Range Rover Sport (L494)	CHCM - Chassis Control Module	EXE
JK62-14E094-JDG.vbf	Range Rover Sport (L494)	CHCM - Chassis Control Module	EXE
JK62-14E094-JDH.vbf	Range Rover Sport (L494)	CHCM - Chassis Control Module	EXE
JK62-14E094-JDJ.vbf	Range Rover Sport (L494)	CHCM - Chassis Control Module	EXE
JK62-14E094-JEB.vbf	Range Rover Sport (L494)	CHCM - Chassis Control Module	EXE
JK62-14E094-JED.vbf	Range Rover Sport (L494)	CHCM - Chassis Control Module	EXE
JK62-14E094-JEE.vbf	Range Rover Sport (L494)	CHCM - Chassis Control Module	EXE
JK62-14E094-JEF.vbf	Range Rover Sport (L494)	CHCM - Chassis Control Module	EXE
JK62-14E094-JEG.vbf	Range Rover Sport (L494)	CHCM - Chassis Control Module	EXE
JK62-14E094-JEH.vbf	Range Rover Sport (L494)	CHCM - Chassis Control Module	EXE
JK62-14E094-JEJ.vbf	Range Rover Sport (L494)	CHCM - Chassis Control Module	EXE
JK62-14E094-JGB.vbf	Range Rover Sport (L494)	CHCM - Chassis Control Module	EXE
JK62-14E094-JGD.vbf	Range Rover Sport (L494)	CHCM - Chassis Control Module	EXE
JK62-14E094-JGE.vbf	Range Rover Sport (L494)	CHCM - Chassis Control Module	EXE
JK62-14E094-JGF.vbf	Range Rover Sport (L494)	CHCM - Chassis Control Module	EXE
JK62-14E094-JGG.vbf	Range Rover Sport (L494)	CHCM - Chassis Control Module	EXE
JK62-14E094-JGH.vbf	Range Rover Sport (L494)	CHCM - Chassis Control Module	EXE
JK62-14E094-JGJ.vbf	Range Rover Sport (L494)	CHCM - Chassis Control Module	EXE
JK62-14E094-JKB.vbf	Range Rover Sport (L494)	CHCM - Chassis Control Module	EXE
JK62-14E094-JKD.vbf	Range Rover Sport (L494)	CHCM - Chassis Control Module	EXE
JK62-14E094-JKE.vbf	Range Rover Sport (L494)	CHCM - Chassis Control Module	EXE
JK62-14E094-JKF.vbf	Range Rover Sport (L494)	CHCM - Chassis Control Module	EXE
JK62-14E094-JKG.vbf	Range Rover Sport (L494)	CHCM - Chassis Control Module	EXE
JK62-14E094-JKH.vbf	Range Rover Sport (L494)	CHCM - Chassis Control Module	EXE
JK62-14E094-JKJ.vbf	Range Rover Sport (L494)	CHCM - Chassis Control Module	EXE
JK62-14E094-JMB.vbf	Range Rover Sport (L494)	CHCM - Chassis Control Module	EXE
JK62-14E094-JMD.vbf	Range Rover Sport (L494)	CHCM - Chassis Control Module	EXE
JK62-14E094-JME.vbf	Range Rover Sport (L494)	CHCM - Chassis Control Module	EXE
JK62-14E094-JMF.vbf	Range Rover Sport (L494)	CHCM - Chassis Control Module	EXE
JK62-14E094-JMG.vbf	Range Rover Sport (L494)	CHCM - Chassis Control Module	EXE
JK62-14E094-JMH.vbf	Range Rover Sport (L494)	CHCM - Chassis Control Module	EXE
JK62-14E094-JMJ.vbf	Range Rover Sport (L494)	CHCM - Chassis Control Module	EXE
JK62-14F022-AB.vbf	Range Rover Sport (L494)	Not specified	DATA
JK62-14F022-AC.vbf	Range Rover Sport (L494)	Not specified	DATA
JK62-14F022-AD.vbf	Range Rover Sport (L494)	Not specified	DATA
JK62-14F022-AE.vbf	Range Rover Sport (L494)	Not specified	DATA
JK62-14F022-AF.vbf	Range Rover Sport (L494)	Not specified	DATA
JK62-14F022-AG.vbf	Range Rover Sport (L494)	Not specified	DATA

File name	Vehicle line (indicative)	Module (ECU)	Type
JK62-14F022-AJ.vbf	Range Rover Sport (L494)	Not specified	DATA
JK62-14F022-AL.vbf	Range Rover Sport (L494)	Not specified	DATA
JK62-14F022-AM.vbf	Range Rover Sport (L494)	Not specified	DATA
JK62-14F022-AN.vbf	Range Rover Sport (L494)	Not specified	DATA
JK62-14F230-AB.vbf	Range Rover Sport (L494)	HUD - Head Up Display	EXE
JK62-14F230-AC.vbf	Range Rover Sport (L494)	HUD - Head Up Display	EXE
JK62-14F230-AE.vbf	Range Rover Sport (L494)	HUD - Head Up Display	EXE
JK62-14F230-AF.vbf	Range Rover Sport (L494)	HUD - Head Up Display	EXE
JK62-14F230-BA.vbf	Range Rover Sport (L494)	HUD - Head Up Display	EXE
JK62-14F230-BB.vbf	Range Rover Sport (L494)	HUD - Head Up Display	EXE
JK62-14F230-XA.vbf	Range Rover Sport (L494)	HUD - Head Up Display	EXE
JK62-14F231-AB.vbf	Range Rover Sport (L494)	HUD - Head Up Display	DATA
JK62-14F231-AC.vbf	Range Rover Sport (L494)	HUD - Head Up Display	DATA
JK62-14F231-AD.vbf	Range Rover Sport (L494)	HUD - Head Up Display	DATA
JK62-14F231-AE.vbf	Range Rover Sport (L494)	HUD - Head Up Display	DATA
JK62-14F435-NAB.vbf	Range Rover Sport (L494)	CHCMB - Chassis Control Module B	EXE
JK62-14F435-NAC.vbf	Range Rover Sport (L494)	CHCMB - Chassis Control Module B	EXE
JK62-14F435-NAD.vbf	Range Rover Sport (L494)	CHCMB - Chassis Control Module B	EXE
JK62-14F435-NAE.vbf	Range Rover Sport (L494)	CHCMB - Chassis Control Module B	EXE
JK62-14F435-NAF.vbf	Range Rover Sport (L494)	CHCMB - Chassis Control Module B	EXE
JK62-14F435-NAG.vbf	Range Rover Sport (L494)	CHCMB - Chassis Control Module B	EXE
JK62-14F435-NAH.vbf	Range Rover Sport (L494)	CHCMB - Chassis Control Module B	EXE
JK62-14F435-NAJ.vbf	Range Rover Sport (L494)	CHCMB - Chassis Control Module B	EXE
JK62-14F435-NBB.vbf	Range Rover Sport (L494)	CHCMB - Chassis Control Module B	EXE
JK62-14F435-NBC.vbf	Range Rover Sport (L494)	CHCMB - Chassis Control Module B	EXE
JK62-14F435-NBD.vbf	Range Rover Sport (L494)	CHCMB - Chassis Control Module B	EXE
JK62-14F435-NBE.vbf	Range Rover Sport (L494)	CHCMB - Chassis Control Module B	EXE
JK62-14F435-NBF.vbf	Range Rover Sport (L494)	CHCMB - Chassis Control Module B	EXE
JK62-14F435-NBG.vbf	Range Rover Sport (L494)	CHCMB - Chassis Control Module B	EXE
JK62-14F435-NBH.vbf	Range Rover Sport (L494)	CHCMB - Chassis Control Module B	EXE
JK62-14F435-NBJ.vbf	Range Rover Sport (L494)	CHCMB - Chassis Control Module B	EXE
JK62-14F435-NCB.vbf	Range Rover Sport (L494)	CHCMB - Chassis Control Module B	EXE
JK62-14F435-NCC.vbf	Range Rover Sport (L494)	CHCMB - Chassis Control Module B	EXE
JK62-14F435-NCD.vbf	Range Rover Sport (L494)	CHCMB - Chassis Control Module B	EXE
JK62-14F435-NCE.vbf	Range Rover Sport (L494)	CHCMB - Chassis Control Module B	EXE
JK62-14F435-NCF.vbf	Range Rover Sport (L494)	CHCMB - Chassis Control Module B	EXE
JK62-14F435-NCG.vbf	Range Rover Sport (L494)	CHCMB - Chassis Control Module B	EXE
JK62-14F435-NCH.vbf	Range Rover Sport (L494)	CHCMB - Chassis Control Module B	EXE
JK62-14F435-NCJ.vbf	Range Rover Sport (L494)	CHCMB - Chassis Control Module B	EXE
JK62-14F529-AA.vbf	Range Rover Sport (L494)	GWM - Gateway Module A	EXE
JK62-14F529-BB.vbf	Range Rover Sport (L494)	GWM - Gateway Module A	EXE
JK62-14F529-CA.vbf	Range Rover Sport (L494)	GWM - Gateway Module A	EXE
JK62-14F530-AA.vbf	Range Rover Sport (L494)	GWM - Gateway Module A	EXE
JK62-14F530-AE.vbf	Range Rover Sport (L494)	GWM - Gateway Module A	EXE
JK62-14F530-AF.vbf	Range Rover Sport (L494)	GWM - Gateway Module A	EXE
JK62-14F530-BB.vbf	Range Rover Sport (L494)	GWM - Gateway Module A	EXE
JK62-14F530-BE.vbf	Range Rover Sport (L494)	GWM - Gateway Module A	EXE
JK62-14F530-BH.vbf	Range Rover Sport (L494)	GWM - Gateway Module A	EXE
JK62-14F530-BJ.vbf	Range Rover Sport (L494)	GWM - Gateway Module A	EXE
JK62-14F530-CA.vbf	Range Rover Sport (L494)	GWM - Gateway Module A	EXE
JK62-14F530-CC.vbf	Range Rover Sport (L494)	GWM - Gateway Module A	EXE
JK62-14F530-CD.vbf	Range Rover Sport (L494)	GWM - Gateway Module A	EXE
JK62-14F530-CE.vbf	Range Rover Sport (L494)	GWM - Gateway Module A	EXE
JK62-14F530-CF.vbf	Range Rover Sport (L494)	GWM - Gateway Module A	EXE
JK62-14F530-DC.vbf	Range Rover Sport (L494)	GWM - Gateway Module A	EXE
JK62-14F530-DE.vbf	Range Rover Sport (L494)	GWM - Gateway Module A	EXE
JK62-14F530-DF.vbf	Range Rover Sport (L494)	GWM - Gateway Module A	EXE
JK62-14F530-DG.vbf	Range Rover Sport (L494)	GWM - Gateway Module A	EXE
JK62-14F531-AA.vbf	Range Rover Sport (L494)	GWM - Gateway Module A	DATA
JK62-14F531-AD.vbf	Range Rover Sport (L494)	GWM - Gateway Module A	DATA
JK62-14F531-BB.vbf	Range Rover Sport (L494)	GWM - Gateway Module A	EXE
JK62-14F531-BE.vbf	Range Rover Sport (L494)	GWM - Gateway Module A	DATA
JK62-14F531-BG.vbf	Range Rover Sport (L494)	GWM - Gateway Module A	DATA
JK62-14F531-CA.vbf	Range Rover Sport (L494)	GWM - Gateway Module A	DATA
JK62-14F531-CC.vbf	Range Rover Sport (L494)	GWM - Gateway Module A	DATA
JK62-14F531-CD.vbf	Range Rover Sport (L494)	GWM - Gateway Module A	DATA
JK62-14F531-DC.vbf	Range Rover Sport (L494)	GWM - Gateway Module A	DATA
JK62-14F531-DD.vbf	Range Rover Sport (L494)	GWM - Gateway Module A	DATA
JK62-14F531-DE.vbf	Range Rover Sport (L494)	GWM - Gateway Module A	DATA
JK62-18D620-AB.vbf	Range Rover Sport (L494)	HVAC - HVAC Control Module	DATA
JK62-18D620-AC.vbf	Range Rover Sport (L494)	HVAC - HVAC Control Module	DATA
JK62-18D620-AD.vbf	Range Rover Sport (L494)	HVAC - HVAC Control Module	DATA
JK62-18D620-AE.vbf	Range Rover Sport (L494)	HVAC - HVAC Control Module	DATA
JK62-18D620-AF.vbf	Range Rover Sport (L494)	HVAC - HVAC Control Module	DATA
JK62-18D620-AG.vbf	Range Rover Sport (L494)	HVAC - HVAC Control Module	DATA
JK62-18D620-AJ.vbf	Range Rover Sport (L494)	HVAC - HVAC Control Module	DATA

File name	Vehicle line (indicative)	Module (ECU)	Type
JK62-18D620-AK.vbf	Range Rover Sport (L494)	HVAC - HVAC Control Module	DATA
JK62-18D620-AL.vbf	Range Rover Sport (L494)	HVAC - HVAC Control Module	DATA
JK62-18D620-AM.vbf	Range Rover Sport (L494)	HVAC - HVAC Control Module	DATA
JK62-18D620-AR.vbf	Range Rover Sport (L494)	HVAC - HVAC Control Module	DATA
JK62-18D620-AU.vbf	Range Rover Sport (L494)	HVAC - HVAC Control Module	DATA
JK62-18D620-AV.vbf	Range Rover Sport (L494)	HVAC - HVAC Control Module	DATA
JK62-18D620-AX.vbf	Range Rover Sport (L494)	HVAC - HVAC Control Module	DATA
JK62-18D620-BAA.vbf	Range Rover Sport (L494)	HVAC - HVAC Control Module	DATA
JK62-18D620-BAB.vbf	Range Rover Sport (L494)	HVAC - HVAC Control Module	DATA
JK62-18D620-BB.vbf	Range Rover Sport (L494)	HVAC - HVAC Control Module	DATA
JK62-18D620-BC.vbf	Range Rover Sport (L494)	HVAC - HVAC Control Module	DATA
JK62-18D620-BD.vbf	Range Rover Sport (L494)	HVAC - HVAC Control Module	DATA
JK62-18D620-BE.vbf	Range Rover Sport (L494)	HVAC - HVAC Control Module	DATA
JK62-18D620-BF.vbf	Range Rover Sport (L494)	HVAC - HVAC Control Module	DATA
JK62-18D620-BG.vbf	Range Rover Sport (L494)	HVAC - HVAC Control Module	DATA
JK62-18D620-BH.vbf	Range Rover Sport (L494)	HVAC - HVAC Control Module	DATA
JK62-18D620-BJ.vbf	Range Rover Sport (L494)	HVAC - HVAC Control Module	DATA
JK62-18D620-BK.vbf	Range Rover Sport (L494)	HVAC - HVAC Control Module	DATA
JK62-18D620-BL.vbf	Range Rover Sport (L494)	HVAC - HVAC Control Module	DATA
JK62-18D620-BM.vbf	Range Rover Sport (L494)	HVAC - HVAC Control Module	DATA
JK62-18D620-BP.vbf	Range Rover Sport (L494)	HVAC - HVAC Control Module	DATA
JK62-18D620-BR.vbf	Range Rover Sport (L494)	HVAC - HVAC Control Module	DATA
JK62-18D620-BT.vbf	Range Rover Sport (L494)	HVAC - HVAC Control Module	DATA
JK62-18D620-BV.vbf	Range Rover Sport (L494)	HVAC - HVAC Control Module	DATA
JK62-18D620-BZ.vbf	Range Rover Sport (L494)	HVAC - HVAC Control Module	DATA
JK62-18D620-CB.vbf	Range Rover Sport (L494)	HVAC - HVAC Control Module	DATA
JK62-18D620-CC.vbf	Range Rover Sport (L494)	HVAC - HVAC Control Module	DATA
JK62-18D620-CD.vbf	Range Rover Sport (L494)	HVAC - HVAC Control Module	DATA
JK62-18D620-CE.vbf	Range Rover Sport (L494)	HVAC - HVAC Control Module	DATA
JK62-18D620-CF.vbf	Range Rover Sport (L494)	HVAC - HVAC Control Module	DATA
JK62-18D620-CG.vbf	Range Rover Sport (L494)	HVAC - HVAC Control Module	DATA
JK62-18D620-CH.vbf	Range Rover Sport (L494)	HVAC - HVAC Control Module	DATA
JK62-18D620-CJ.vbf	Range Rover Sport (L494)	HVAC - HVAC Control Module	DATA
JK62-18D620-CK.vbf	Range Rover Sport (L494)	HVAC - HVAC Control Module	DATA
JK62-18D620-CL.vbf	Range Rover Sport (L494)	HVAC - HVAC Control Module	DATA
JK62-18D620-CM.vbf	Range Rover Sport (L494)	HVAC - HVAC Control Module	DATA
JK62-18D620-CP.vbf	Range Rover Sport (L494)	HVAC - HVAC Control Module	DATA
JK62-18D620-CS.vbf	Range Rover Sport (L494)	HVAC - HVAC Control Module	DATA
JK62-18D620-CT.vbf	Range Rover Sport (L494)	HVAC - HVAC Control Module	DATA
JK62-18D620-CU.vbf	Range Rover Sport (L494)	HVAC - HVAC Control Module	DATA
JK62-18D620-DA.vbf	Range Rover Sport (L494)	HVAC - HVAC Control Module	DATA
JK62-18D620-DB.vbf	Range Rover Sport (L494)	HVAC - HVAC Control Module	DATA
JK62-18D620-DC.vbf	Range Rover Sport (L494)	HVAC - HVAC Control Module	DATA
JK62-18D620-DD.vbf	Range Rover Sport (L494)	HVAC - HVAC Control Module	DATA
JK62-18D620-DE.vbf	Range Rover Sport (L494)	HVAC - HVAC Control Module	DATA
JK62-18D620-DF.vbf	Range Rover Sport (L494)	HVAC - HVAC Control Module	DATA
JK62-18D620-DG.vbf	Range Rover Sport (L494)	HVAC - HVAC Control Module	DATA
JK62-18D620-DH.vbf	Range Rover Sport (L494)	HVAC - HVAC Control Module	DATA
JK62-18D620-DJ.vbf	Range Rover Sport (L494)	HVAC - HVAC Control Module	DATA
JK62-18D620-DL.vbf	Range Rover Sport (L494)	HVAC - HVAC Control Module	DATA
JK62-18D620-DN.vbf	Range Rover Sport (L494)	HVAC - HVAC Control Module	DATA
JK62-18D620-DP.vbf	Range Rover Sport (L494)	HVAC - HVAC Control Module	DATA
JK62-18D620-DR.vbf	Range Rover Sport (L494)	HVAC - HVAC Control Module	DATA
JK62-19C264-AB.vbf	Range Rover Sport (L494)	FDM - Front Display Interface Module	DATA
JK62-19C264-AC.vbf	Range Rover Sport (L494)	FDM - Front Display Interface Module	DATA
JK62-19C264-AD.vbf	Range Rover Sport (L494)	FDM - Front Display Interface Module	DATA
JK62-19C264-AE.vbf	Range Rover Sport (L494)	FDM - Front Display Interface Module	DATA
JK62-19C274-AB.vbf	Range Rover Sport (L494)	LPDM - Left Power Sliding Door Module	DATA
JK62-19C274-AC.vbf	Range Rover Sport (L494)	LPDM - Left Power Sliding Door Module	DATA
JK62-19C274-AD.vbf	Range Rover Sport (L494)	LPDM - Left Power Sliding Door Module	DATA
JK62-19C274-AE.vbf	Range Rover Sport (L494)	LPDM - Left Power Sliding Door Module	DATA
JK62-7J104-FBA.vbf	Range Rover Sport (L494)	TCM - Transmission Control Module	EXE
JK62-7J104-FBC.vbf	Range Rover Sport (L494)	TCM - Transmission Control Module	EXE
JK62-7J104-FBD.vbf	Range Rover Sport (L494)	TCM - Transmission Control Module	EXE
JK62-7J104-FBE.vbf	Range Rover Sport (L494)	TCM - Transmission Control Module	EXE
JK62-7J104-FBF.vbf	Range Rover Sport (L494)	TCM - Transmission Control Module	EXE
JK62-7J104-FBG.vbf	Range Rover Sport (L494)	TCM - Transmission Control Module	EXE
JK62-7J104-FBH.vbf	Range Rover Sport (L494)	TCM - Transmission Control Module	EXE
JK62-7J104-FCB.vbf	Range Rover Sport (L494)	TCM - Transmission Control Module	EXE
JK62-7J104-FCC.vbf	Range Rover Sport (L494)	TCM - Transmission Control Module	EXE
JK62-7J104-FCD.vbf	Range Rover Sport (L494)	TCM - Transmission Control Module	EXE
JK62-7J104-FCE.vbf	Range Rover Sport (L494)	TCM - Transmission Control Module	EXE
JK62-7J104-FCF.vbf	Range Rover Sport (L494)	TCM - Transmission Control Module	EXE
JK62-7J104-FDA.vbf	Range Rover Sport (L494)	TCM - Transmission Control Module	EXE
JK62-7J104-FDC.vbf	Range Rover Sport (L494)	TCM - Transmission Control Module	EXE
JK62-7J104-FDD.vbf	Range Rover Sport (L494)	TCM - Transmission Control Module	EXE

File name	Vehicle line (indicative)	Module (ECU)	Type
JK62-7J104-FDE.vbf	Range Rover Sport (L494)	TCM - Transmission Control Module	EXE
JK62-7J104-FDF.vbf	Range Rover Sport (L494)	TCM - Transmission Control Module	EXE
JK62-7J104-FDG.vbf	Range Rover Sport (L494)	TCM - Transmission Control Module	EXE
JK62-7J104-FDH.vbf	Range Rover Sport (L494)	TCM - Transmission Control Module	EXE
JK62-7J104-FHB.vbf	Range Rover Sport (L494)	TCM - Transmission Control Module	EXE
JK62-7J104-FHC.vbf	Range Rover Sport (L494)	TCM - Transmission Control Module	EXE
JK62-7J104-FHD.vbf	Range Rover Sport (L494)	TCM - Transmission Control Module	EXE
JK62-7J104-FHE.vbf	Range Rover Sport (L494)	TCM - Transmission Control Module	EXE
JK62-7J104-FHF.vbf	Range Rover Sport (L494)	TCM - Transmission Control Module	EXE
JK62-7J104-FHG.vbf	Range Rover Sport (L494)	TCM - Transmission Control Module	EXE
JK62-7J104-FKB.vbf	Range Rover Sport (L494)	TCM - Transmission Control Module	EXE
JK62-7J104-FKC.vbf	Range Rover Sport (L494)	TCM - Transmission Control Module	EXE
JK62-7J104-FKD.vbf	Range Rover Sport (L494)	TCM - Transmission Control Module	EXE
JK62-7J104-FKE.vbf	Range Rover Sport (L494)	TCM - Transmission Control Module	EXE
JK62-7J104-FKF.vbf	Range Rover Sport (L494)	TCM - Transmission Control Module	EXE
JK62-7J104-FLA.vbf	Range Rover Sport (L494)	TCM - Transmission Control Module	EXE
JK62-7J104-FMA.vbf	Range Rover Sport (L494)	TCM - Transmission Control Module	EXE
JK62-7J104-FMB.vbf	Range Rover Sport (L494)	TCM - Transmission Control Module	EXE
JK62-7J104-FMC.vbf	Range Rover Sport (L494)	TCM - Transmission Control Module	EXE
JK62-7J104-FMD.vbf	Range Rover Sport (L494)	TCM - Transmission Control Module	EXE
JK62-7J104-FME.vbf	Range Rover Sport (L494)	TCM - Transmission Control Module	EXE
JK62-7J104-FPB.vbf	Range Rover Sport (L494)	TCM - Transmission Control Module	EXE
JK62-7J104-FPC.vbf	Range Rover Sport (L494)	TCM - Transmission Control Module	EXE
JK62-7J104-FPD.vbf	Range Rover Sport (L494)	TCM - Transmission Control Module	EXE
JK62-7J104-FPE.vbf	Range Rover Sport (L494)	TCM - Transmission Control Module	EXE
JK62-7J104-FPF.vbf	Range Rover Sport (L494)	TCM - Transmission Control Module	EXE
JK62-7J104-FVA.vbf	Range Rover Sport (L494)	TCM - Transmission Control Module	EXE
JK62-7J104-FVC.vbf	Range Rover Sport (L494)	TCM - Transmission Control Module	EXE
JK62-7J104-FVD.vbf	Range Rover Sport (L494)	TCM - Transmission Control Module	EXE
JK62-7J104-FVE.vbf	Range Rover Sport (L494)	TCM - Transmission Control Module	EXE
JK62-7J104-FVF.vbf	Range Rover Sport (L494)	TCM - Transmission Control Module	EXE
JK62-7J104-FVG.vbf	Range Rover Sport (L494)	TCM - Transmission Control Module	EXE
JK62-7J104-FYB.vbf	Range Rover Sport (L494)	TCM - Transmission Control Module	EXE
JK62-7J104-FYC.vbf	Range Rover Sport (L494)	TCM - Transmission Control Module	EXE
JK62-7J104-FYE.vbf	Range Rover Sport (L494)	TCM - Transmission Control Module	EXE
JK62-7J104-FYF.vbf	Range Rover Sport (L494)	TCM - Transmission Control Module	EXE
JK62-7J104-FYG.vbf	Range Rover Sport (L494)	TCM - Transmission Control Module	EXE
JK62-7J104-FYH.vbf	Range Rover Sport (L494)	TCM - Transmission Control Module	EXE
JK6M-14C034-AAA.vbf	Range Rover Sport (L494)	DSM - Driver Front Seat Module	EXE
JK6M-14C034-AAB.vbf	Range Rover Sport (L494)	DSM - Driver Front Seat Module	EXE
JK6M-14C034-AAC.vbf	Range Rover Sport (L494)	DSM - Driver Front Seat Module	EXE
JK6M-14C218-AA.vbf	Range Rover Sport (L494)	PSCM - Power Steering Control Module	EXE
JK6M-14C549-AAA.vbf	Range Rover Sport (L494)	PSM - Passenger Front Seat Module	EXE
JK6M-14C549-AAB.vbf	Range Rover Sport (L494)	PSM - Passenger Front Seat Module	EXE
JK6M-14C549-AAC.vbf	Range Rover Sport (L494)	DSM - Driver Front Seat Module	EXE
JK6M-14E094-JHB.vbf	Range Rover Sport (L494)	CHCM - Chassis Control Module	EXE
JK6M-14E094-JHD.vbf	Range Rover Sport (L494)	CHCM - Chassis Control Module	EXE
JK6M-14E094-JHF.vbf	Range Rover Sport (L494)	CHCM - Chassis Control Module	EXE
JK6M-14E094-JHG.vbf	Range Rover Sport (L494)	CHCM - Chassis Control Module	EXE
JK6M-14E094-JHH.vbf	Range Rover Sport (L494)	CHCM - Chassis Control Module	EXE
JK6M-14E094-JHJ.vbf	Range Rover Sport (L494)	CHCM - Chassis Control Module	EXE
JK6M-14F435-NEB.vbf	Range Rover Sport (L494)	CHCMB - Chassis Control Module B	EXE
JK6M-14F435-NEC.vbf	Range Rover Sport (L494)	CHCMB - Chassis Control Module B	EXE
JK6M-14F435-NED.vbf	Range Rover Sport (L494)	CHCMB - Chassis Control Module B	EXE
JK6M-14F435-NEE.vbf	Range Rover Sport (L494)	CHCMB - Chassis Control Module B	EXE
JK6M-14F435-NEF.vbf	Range Rover Sport (L494)	CHCMB - Chassis Control Module B	EXE
JK6M-14F435-NEG.vbf	Range Rover Sport (L494)	CHCMB - Chassis Control Module B	EXE
JK6M-14F435-NEH.vbf	Range Rover Sport (L494)	CHCMB - Chassis Control Module B	EXE
JK6M-14F435-NEJ.vbf	Range Rover Sport (L494)	CHCMB - Chassis Control Module B	EXE
JK72-12K532-FBC.vbf	Discovery Sport (L550)	PCM - Powertrain Control Module	DATA
JK72-12K532-FBE.vbf	Discovery Sport (L550)	PCM - Powertrain Control Module	DATA
JK72-12K532-FBF.vbf	Discovery Sport (L550)	PCM - Powertrain Control Module	DATA
JK72-12K532-GAC.vbf	Discovery Sport (L550)	PCM - Powertrain Control Module	DATA
JK72-12K532-GAE.vbf	Discovery Sport (L550)	PCM - Powertrain Control Module	DATA
JK72-12K532-GAF.vbf	Discovery Sport (L550)	PCM - Powertrain Control Module	DATA
JK72-12K532-GAG.vbf	Discovery Sport (L550)	PCM - Powertrain Control Module	DATA
JK72-12K532-GBC.vbf	Discovery Sport (L550)	PCM - Powertrain Control Module	DATA
JK72-12K532-GBE.vbf	Discovery Sport (L550)	PCM - Powertrain Control Module	DATA
JK72-12K532-GCC.vbf	Discovery Sport (L550)	PCM - Powertrain Control Module	DATA
JK72-12K532-GCE.vbf	Discovery Sport (L550)	PCM - Powertrain Control Module	DATA
JK72-12K532-GCG.vbf	Discovery Sport (L550)	PCM - Powertrain Control Module	DATA
JK72-12K532-GCH.vbf	Discovery Sport (L550)	PCM - Powertrain Control Module	DATA
JK72-12K532-GDC.vbf	Discovery Sport (L550)	PCM - Powertrain Control Module	DATA
JK72-12K532-GDE.vbf	Discovery Sport (L550)	PCM - Powertrain Control Module	DATA
JK72-12K532-GDF.vbf	Discovery Sport (L550)	PCM - Powertrain Control Module	DATA
JK72-12K532-GEC.vbf	Discovery Sport (L550)	PCM - Powertrain Control Module	DATA

File name	Vehicle line (indicative)	Module (ECU)	Type
JK72-12K532-GED.vbf	Discovery Sport (L550)	PCM - Powertrain Control Module	DATA
JK72-12K532-GGC.vbf	Discovery Sport (L550)	PCM - Powertrain Control Module	DATA
JK72-12K532-GGD.vbf	Discovery Sport (L550)	PCM - Powertrain Control Module	DATA
JK72-12K532-GJC.vbf	Discovery Sport (L550)	PCM - Powertrain Control Module	DATA
JK72-12K532-GJD.vbf	Discovery Sport (L550)	PCM - Powertrain Control Module	DATA
JK72-12K532-GLC.vbf	Discovery Sport (L550)	PCM - Powertrain Control Module	DATA
JK72-12K532-GLE.vbf	Discovery Sport (L550)	PCM - Powertrain Control Module	DATA
JK72-12K532-GLF.vbf	Discovery Sport (L550)	PCM - Powertrain Control Module	DATA
JK72-12K532-GNC.vbf	Discovery Sport (L550)	PCM - Powertrain Control Module	DATA
JK72-12K532-GNE.vbf	Discovery Sport (L550)	PCM - Powertrain Control Module	DATA
JK72-12K532-GNF.vbf	Discovery Sport (L550)	PCM - Powertrain Control Module	DATA
JK72-12K532-GRC.vbf	Discovery Sport (L550)	PCM - Powertrain Control Module	DATA
JK72-12K532-GRD.vbf	Discovery Sport (L550)	PCM - Powertrain Control Module	DATA
JK72-12K532-GSC.vbf	Discovery Sport (L550)	PCM - Powertrain Control Module	DATA
JK72-12K532-GSD.vbf	Discovery Sport (L550)	PCM - Powertrain Control Module	DATA
JK72-12K532-GTC.vbf	Discovery Sport (L550)	PCM - Powertrain Control Module	DATA
JK72-12K532-GTE.vbf	Discovery Sport (L550)	PCM - Powertrain Control Module	DATA
JK72-12K532-GTF.vbf	Discovery Sport (L550)	PCM - Powertrain Control Module	DATA
JK72-12K532-GTG.vbf	Discovery Sport (L550)	PCM - Powertrain Control Module	DATA
JK72-12K532-GUA.vbf	Discovery Sport (L550)	PCM - Powertrain Control Module	DATA
JK72-12K532-GUC.vbf	Discovery Sport (L550)	PCM - Powertrain Control Module	DATA
JK72-12K532-GUD.vbf	Discovery Sport (L550)	PCM - Powertrain Control Module	DATA
JK72-12K532-GVC.vbf	Discovery Sport (L550)	PCM - Powertrain Control Module	DATA
JK72-12K532-GVD.vbf	Discovery Sport (L550)	PCM - Powertrain Control Module	DATA
JK72-12K532-KCC.vbf	Discovery Sport (L550)	PCM - Powertrain Control Module	DATA
JK72-12K532-KCD.vbf	Discovery Sport (L550)	PCM - Powertrain Control Module	DATA
JK72-12K532-KDC.vbf	Discovery Sport (L550)	PCM - Powertrain Control Module	DATA
JK72-12K532-KDD.vbf	Discovery Sport (L550)	PCM - Powertrain Control Module	DATA
JK72-14C025-AA.vbf	Discovery Sport (L550)	IPC - Instrument Panel Cluster (IPC) Control Module	SBL
JK72-14C025-AB.vbf	Discovery Sport (L550)	IPC - Instrument Panel Cluster (IPC) Control Module	SBL
JK72-14C026-AA.vbf	Discovery Sport (L550)	IPC - Instrument Panel Cluster (IPC) Control Module	EXE
JK72-14C026-AB.vbf	Discovery Sport (L550)	IPC - Instrument Panel Cluster (IPC) Control Module	EXE
JK72-14C026-AC.vbf	Discovery Sport (L550)	IPC - Instrument Panel Cluster (IPC) Control Module	EXE
JK72-14C026-AD.vbf	Discovery Sport (L550)	IPC - Instrument Panel Cluster (IPC) Control Module	EXE
JK72-14C026-AE.vbf	Discovery Sport (L550)	IPC - Instrument Panel Cluster (IPC) Control Module	EXE
JK72-14C026-AF.vbf	Discovery Sport (L550)	IPC - Instrument Panel Cluster (IPC) Control Module	EXE
JK72-14C088-BC.vbf	Discovery Sport (L550)	IPC - Instrument Panel Cluster (IPC) Control Module	DATA
JK72-14C088-CA.vbf	Discovery Sport (L550)	IPC - Instrument Panel Cluster (IPC) Control Module	EXE
JK72-14C088-CB.vbf	Discovery Sport (L550)	IPC - Instrument Panel Cluster (IPC) Control Module	EXE
JK72-14C088-CC.vbf	Discovery Sport (L550)	IPC - Instrument Panel Cluster (IPC) Control Module	EXE
JK72-14C088-CD.vbf	Discovery Sport (L550)	IPC - Instrument Panel Cluster (IPC) Control Module	EXE
JK72-14C217-AA.vbf	Discovery Sport (L550)	PSCM - Power Steering Control Module	EXE
JK72-14C218-AA.vbf	Discovery Sport (L550)	PSCM - Power Steering Control Module	EXE
JK72-14C218-BA.vbf	Discovery Sport (L550)	PSCM - Power Steering Control Module	EXE
JK72-14C337-CJA.vbf	Discovery Sport (L550)	TCM - Transmission Control Module	EXE
JK72-14C337-CJB.vbf	Discovery Sport (L550)	TCM - Transmission Control Module	EXE
JK72-14C337-CJD.vbf	Discovery Sport (L550)	TCM - Transmission Control Module	EXE
JK72-14C337-CJE.vbf	Discovery Sport (L550)	TCM - Transmission Control Module	EXE
JK72-14C337-CJH.vbf	Discovery Sport (L550)	TCM - Transmission Control Module	EXE
JK72-14C337-CJJ.vbf	Discovery Sport (L550)	TCM - Transmission Control Module	EXE
JK72-14C337-CJK.vbf	Discovery Sport (L550)	TCM - Transmission Control Module	EXE
JK72-14C337-CKA.vbf	Discovery Sport (L550)	TCM - Transmission Control Module	EXE
JK72-14C337-CKB.vbf	Discovery Sport (L550)	TCM - Transmission Control Module	EXE
JK72-14C337-CKE.vbf	Discovery Sport (L550)	TCM - Transmission Control Module	EXE
JK72-14C337-CKF.vbf	Discovery Sport (L550)	TCM - Transmission Control Module	EXE
JK72-14C337-CKG.vbf	Discovery Sport (L550)	TCM - Transmission Control Module	EXE
JK72-14C337-CKH.vbf	Discovery Sport (L550)	TCM - Transmission Control Module	EXE
JK72-14C337-CKJ.vbf	Discovery Sport (L550)	TCM - Transmission Control Module	EXE
JK72-14C337-CKK.vbf	Discovery Sport (L550)	TCM - Transmission Control Module	EXE
JK72-14C337-CMA.vbf	Discovery Sport (L550)	TCM - Transmission Control Module	EXE
JK72-14C337-CMB.vbf	Discovery Sport (L550)	TCM - Transmission Control Module	EXE
JK72-14C337-CMC.vbf	Discovery Sport (L550)	TCM - Transmission Control Module	EXE
JK72-14C337-CMD.vbf	Discovery Sport (L550)	TCM - Transmission Control Module	EXE
JK72-14C337-CME.vbf	Discovery Sport (L550)	TCM - Transmission Control Module	EXE
JK72-14C337-CMF.vbf	Discovery Sport (L550)	TCM - Transmission Control Module	EXE
JK72-14C337-CMG.vbf	Discovery Sport (L550)	TCM - Transmission Control Module	EXE
JK72-14C337-CMH.vbf	Discovery Sport (L550)	TCM - Transmission Control Module	EXE
JK72-14C337-CPA.vbf	Discovery Sport (L550)	TCM - Transmission Control Module	EXE
JK72-14C337-CPB.vbf	Discovery Sport (L550)	TCM - Transmission Control Module	EXE
JK72-14C337-CPC.vbf	Discovery Sport (L550)	TCM - Transmission Control Module	EXE
JK72-14C337-CPD.vbf	Discovery Sport (L550)	TCM - Transmission Control Module	EXE
JK72-14C337-CPE.vbf	Discovery Sport (L550)	TCM - Transmission Control Module	EXE
JK72-14C337-CPF.vbf	Discovery Sport (L550)	TCM - Transmission Control Module	EXE
JK72-14C337-CPG.vbf	Discovery Sport (L550)	TCM - Transmission Control Module	EXE
JK72-14C337-CPH.vbf	Discovery Sport (L550)	TCM - Transmission Control Module	EXE
JK72-14C337-CPJ.vbf	Discovery Sport (L550)	TCM - Transmission Control Module	EXE

File name	Vehicle line (indicative)	Module (ECU)	Type
JK72-14C337-CRA.vbf	Discovery Sport (L550)	TCM - Transmission Control Module	EXE
JK72-14C337-CRB.vbf	Discovery Sport (L550)	TCM - Transmission Control Module	EXE
JK72-14C337-CRC.vbf	Discovery Sport (L550)	TCM - Transmission Control Module	EXE
JK72-14C337-CRD.vbf	Discovery Sport (L550)	TCM - Transmission Control Module	EXE
JK72-14C337-CRE.vbf	Discovery Sport (L550)	TCM - Transmission Control Module	EXE
JK72-14C337-CRF.vbf	Discovery Sport (L550)	TCM - Transmission Control Module	EXE
JK72-14C337-CRG.vbf	Discovery Sport (L550)	TCM - Transmission Control Module	EXE
JK72-14C337-CRH.vbf	Discovery Sport (L550)	TCM - Transmission Control Module	EXE
JK72-14C337-CVA.vbf	Discovery Sport (L550)	TCM - Transmission Control Module	EXE
JK72-14C337-DLA.vbf	Discovery Sport (L550)	TCM - Transmission Control Module	EXE
JK72-14C337-DLB.vbf	Discovery Sport (L550)	TCM - Transmission Control Module	EXE
JK72-14C337-DTA.vbf	Discovery Sport (L550)	TCM - Transmission Control Module	EXE
JK72-14C337-DTB.vbf	Discovery Sport (L550)	TCM - Transmission Control Module	EXE
JK72-14C337-DUA.vbf	Discovery Sport (L550)	TCM - Transmission Control Module	EXE
JK72-14C337-DUB.vbf	Discovery Sport (L550)	TCM - Transmission Control Module	EXE
JK72-14C536-BA.vbf	Discovery Sport (L550)	HVAC - HVAC Control Module	DATA
JK72-14C570-BAA.vbf	Discovery Sport (L550)	PCM - Powertrain Control Module	EXE
JK72-14C570-BAB.vbf	Discovery Sport (L550)	PCM - Powertrain Control Module	EXE
JK72-14C570-BAC.vbf	Discovery Sport (L550)	PCM - Powertrain Control Module	EXE
JK72-14C570-BAE.vbf	Discovery Sport (L550)	PCM - Powertrain Control Module	EXE
JK72-14C570-BAF.vbf	Discovery Sport (L550)	PCM - Powertrain Control Module	EXE
JK72-14C570-BAG.vbf	Discovery Sport (L550)	PCM - Powertrain Control Module	EXE
JK72-14C570-BAJ.vbf	Discovery Sport (L550)	PCM - Powertrain Control Module	EXE
JK72-14C570-BCB.vbf	Discovery Sport (L550)	PCM - Powertrain Control Module	EXE
JK72-14C570-BCC.vbf	Discovery Sport (L550)	PCM - Powertrain Control Module	EXE
JK72-14C570-BCE.vbf	Discovery Sport (L550)	PCM - Powertrain Control Module	EXE
JK72-14C570-BEB.vbf	Discovery Sport (L550)	PCM - Powertrain Control Module	EXE
JK72-14C570-BEC.vbf	Discovery Sport (L550)	PCM - Powertrain Control Module	EXE
JK72-14C570-BEE.vbf	Discovery Sport (L550)	PCM - Powertrain Control Module	EXE
JK72-14C570-BGA.vbf	Discovery Sport (L550)	PCM - Powertrain Control Module	EXE
JK72-14C570-BGB.vbf	Discovery Sport (L550)	PCM - Powertrain Control Module	EXE
JK72-14C570-BGC.vbf	Discovery Sport (L550)	PCM - Powertrain Control Module	EXE
JK72-14C570-BGD.vbf	Discovery Sport (L550)	PCM - Powertrain Control Module	EXE
JK72-14C570-BGE.vbf	Discovery Sport (L550)	PCM - Powertrain Control Module	EXE
JK72-14C570-BGG.vbf	Discovery Sport (L550)	PCM - Powertrain Control Module	EXE
JK72-14C570-BLB.vbf	Discovery Sport (L550)	PCM - Powertrain Control Module	EXE
JK72-14C570-BLC.vbf	Discovery Sport (L550)	PCM - Powertrain Control Module	EXE
JK72-14C570-BLE.vbf	Discovery Sport (L550)	PCM - Powertrain Control Module	EXE
JK72-14C570-BNB.vbf	Discovery Sport (L550)	PCM - Powertrain Control Module	EXE
JK72-14C570-BNC.vbf	Discovery Sport (L550)	PCM - Powertrain Control Module	EXE
JK72-14C570-BNE.vbf	Discovery Sport (L550)	PCM - Powertrain Control Module	EXE
JK72-14C570-BTA.vbf	Discovery Sport (L550)	PCM - Powertrain Control Module	EXE
JK72-14C570-BTB.vbf	Discovery Sport (L550)	PCM - Powertrain Control Module	EXE
JK72-14C570-BTC.vbf	Discovery Sport (L550)	PCM - Powertrain Control Module	EXE
JK72-14C570-BTD.vbf	Discovery Sport (L550)	PCM - Powertrain Control Module	EXE
JK72-14C570-BTF.vbf	Discovery Sport (L550)	PCM - Powertrain Control Module	EXE
JK72-14C570-BTJ.vbf	Discovery Sport (L550)	PCM - Powertrain Control Module	EXE
JK72-14C570-BUA.vbf	Discovery Sport (L550)	PCM - Powertrain Control Module	EXE
JK72-14C570-BUB.vbf	Discovery Sport (L550)	PCM - Powertrain Control Module	EXE
JK72-14C570-BUC.vbf	Discovery Sport (L550)	PCM - Powertrain Control Module	EXE
JK72-14C570-BUD.vbf	Discovery Sport (L550)	PCM - Powertrain Control Module	EXE
JK72-14C570-BUE.vbf	Discovery Sport (L550)	PCM - Powertrain Control Module	EXE
JK72-14C570-BUH.vbf	Discovery Sport (L550)	PCM - Powertrain Control Module	EXE
JK72-14C609-AA.vbf	Discovery Sport (L550)	PSCM - Power Steering Control Module	EXE
JK72-14D481-BA.vbf	Discovery Sport (L550)	IPMB - Image Processing Module B	DATA
JK72-14D485-AE.vbf	Discovery Sport (L550)	IPMB - Image Processing Module B	EXE
JK72-14D485-AG.vbf	Discovery Sport (L550)	IPMB - Image Processing Module B	EXE
JK72-14D485-AJ.vbf	Discovery Sport (L550)	IPMB - Image Processing Module B	EXE
JK72-14D564-AB.vbf	Discovery Sport (L550)	SODL - Side Obstacle Detection Control Module - Left	DATA
JK72-14D564-AC.vbf	Discovery Sport (L550)	SODL - Side Obstacle Detection Control Module - Left	DATA
JK72-14D564-AD.vbf	Discovery Sport (L550)	SODL - Side Obstacle Detection Control Module - Left	DATA
JK72-14D564-AE.vbf	Discovery Sport (L550)	SODL - Side Obstacle Detection Control Module - Left	DATA
JK72-14D564-BB.vbf	Discovery Sport (L550)	SODR - Side Obstacle Detection Control Module - Right	DATA
JK72-14D564-BC.vbf	Discovery Sport (L550)	SODR - Side Obstacle Detection Control Module - Right	DATA
JK72-14D564-BD.vbf	Discovery Sport (L550)	SODR - Side Obstacle Detection Control Module - Right	DATA
JK72-14D564-BE.vbf	Discovery Sport (L550)	SODR - Side Obstacle Detection Control Module - Right	DATA
JK72-14F022-AA.vbf	Discovery Sport (L550)	IPMB - Image Processing Module B	DATA
JK72-14F022-AB.vbf	Discovery Sport (L550)	IPMB - Image Processing Module B	DATA
JK72-14F022-AC.vbf	Discovery Sport (L550)	IPMB - Image Processing Module B	DATA
JK72-14F022-BA.vbf	Discovery Sport (L550)	IPMB - Image Processing Module B	DATA
JK72-14F022-BB.vbf	Discovery Sport (L550)	IPMB - Image Processing Module B	DATA
JK72-14F022-BC.vbf	Discovery Sport (L550)	IPMB - Image Processing Module B	DATA
JK72-14F397-AA.vbf	Discovery Sport (L550)	IPMA - Image Processing Module A	EXE
JK72-14F397-AB.vbf	Discovery Sport (L550)	IPMA - Image Processing Module A	EXE
JK72-14F397-AC.vbf	Discovery Sport (L550)	IPMA - Image Processing Module A	EXE
JK72-14F397-BA.vbf	Discovery Sport (L550)	IPMA - Image Processing Module A	EXE

File name	Vehicle line (indicative)	Module (ECU)	Type
JK72-14F397-BB.vbf	Discovery Sport (L550)	IPMA - Image Processing Module A	EXE
JK72-14F397-BC.vbf	Discovery Sport (L550)	IPMA - Image Processing Module A	EXE
JK72-14F397-CA.vbf	Discovery Sport (L550)	IPMA - Image Processing Module A	EXE
JK72-14F397-CB.vbf	Discovery Sport (L550)	IPMA - Image Processing Module A	EXE
JK72-14F397-CC.vbf	Discovery Sport (L550)	IPMA - Image Processing Module A	EXE
JK72-14F397-DA.vbf	Discovery Sport (L550)	IPMA - Image Processing Module A	EXE
JK72-14F397-DB.vbf	Discovery Sport (L550)	IPMA - Image Processing Module A	EXE
JK72-14F397-DC.vbf	Discovery Sport (L550)	IPMA - Image Processing Module A	EXE
JK72-14F398-AB.vbf	Discovery Sport (L550)	IPMA - Image Processing Module A	EXE
JK72-14F398-AC.vbf	Discovery Sport (L550)	IPMA - Image Processing Module A	EXE
JK72-14F398-AD.vbf	Discovery Sport (L550)	IPMA - Image Processing Module A	EXE
JK72-14F398-AE.vbf	Discovery Sport (L550)	IPMA - Image Processing Module A	EXE
JK72-14F398-BB.vbf	Discovery Sport (L550)	IPMA - Image Processing Module A	EXE
JK72-14F398-BC.vbf	Discovery Sport (L550)	IPMA - Image Processing Module A	EXE
JK72-14F398-BD.vbf	Discovery Sport (L550)	IPMA - Image Processing Module A	EXE
JK72-14F398-BE.vbf	Discovery Sport (L550)	IPMA - Image Processing Module A	EXE
JK72-14F530-AA.vbf	Discovery Sport (L550)	GWM - Gateway Module A	EXE
JK72-14F530-AB.vbf	Discovery Sport (L550)	GWM - Gateway Module A	EXE
JK72-14F530-AC.vbf	Discovery Sport (L550)	GWM - Gateway Module A	EXE
JK72-14F530-AD.vbf	Discovery Sport (L550)	GWM - Gateway Module A	EXE
JK72-14F531-AA.vbf	Discovery Sport (L550)	GWM - Gateway Module A	DATA
JK72-14F531-AB.vbf	Discovery Sport (L550)	GWM - Gateway Module A	DATA
JK72-19C204-AB.vbf	Discovery Sport (L550)	IMC - Infotainment Master Controller	EXE
JK83-12K532-FAA.vbf	Jaguar F-Pace (X761)	PCM - Powertrain Control Module	DATA
JK83-12K532-FAB.vbf	Jaguar F-Pace (X761)	PCM - Powertrain Control Module	DATA
JK83-12K532-FAC.vbf	Jaguar F-Pace (X761)	PCM - Powertrain Control Module	DATA
JK83-12K532-FAD.vbf	Jaguar F-Pace (X761)	PCM - Powertrain Control Module	DATA
JK83-12K532-FAE.vbf	Jaguar F-Pace (X761)	PCM - Powertrain Control Module	DATA
JK83-12K532-FAF.vbf	Jaguar F-Pace (X761)	PCM - Powertrain Control Module	DATA
JK83-12K532-FAG.vbf	Jaguar F-Pace (X761)	PCM - Powertrain Control Module	DATA
JK83-12K532-FAH.vbf	Jaguar F-Pace (X761)	PCM - Powertrain Control Module	EXE
JK83-12K532-FAJ.vbf	Jaguar F-Pace (X761)	PCM - Powertrain Control Module	DATA
JK83-12K532-FBA.vbf	Jaguar F-Pace (X761)	PCM - Powertrain Control Module	DATA
JK83-12K532-FBB.vbf	Jaguar F-Pace (X761)	PCM - Powertrain Control Module	DATA
JK83-12K532-FBC.vbf	Jaguar F-Pace (X761)	PCM - Powertrain Control Module	DATA
JK83-12K532-FBD.vbf	Jaguar F-Pace (X761)	PCM - Powertrain Control Module	DATA
JK83-12K532-FBE.vbf	Jaguar F-Pace (X761)	PCM - Powertrain Control Module	DATA
JK83-12K532-FBF.vbf	Jaguar F-Pace (X761)	PCM - Powertrain Control Module	DATA
JK83-12K532-FBH.vbf	Jaguar F-Pace (X761)	PCM - Powertrain Control Module	DATA
JK83-12K532-FCA.vbf	Jaguar F-Pace (X761)	PCM - Powertrain Control Module	DATA
JK83-12K532-FCB.vbf	Jaguar F-Pace (X761)	PCM - Powertrain Control Module	DATA
JK83-12K532-FCC.vbf	Jaguar F-Pace (X761)	PCM - Powertrain Control Module	DATA
JK83-12K532-FCD.vbf	Jaguar F-Pace (X761)	PCM - Powertrain Control Module	DATA
JK83-12K532-FCE.vbf	Jaguar F-Pace (X761)	PCM - Powertrain Control Module	DATA
JK83-12K532-FCF.vbf	Jaguar F-Pace (X761)	PCM - Powertrain Control Module	DATA
JK83-12K532-FCH.vbf	Jaguar F-Pace (X761)	PCM - Powertrain Control Module	DATA
JK83-12K532-FDA.vbf	Jaguar F-Pace (X761)	PCM - Powertrain Control Module	DATA
JK83-12K532-FDB.vbf	Jaguar F-Pace (X761)	PCM - Powertrain Control Module	DATA
JK83-12K532-FDC.vbf	Jaguar F-Pace (X761)	PCM - Powertrain Control Module	DATA
JK83-12K532-FDD.vbf	Jaguar F-Pace (X761)	PCM - Powertrain Control Module	DATA
JK83-12K532-FDE.vbf	Jaguar F-Pace (X761)	PCM - Powertrain Control Module	DATA
JK83-12K532-FEB.vbf	Jaguar F-Pace (X761)	PCM - Powertrain Control Module	DATA
JK83-12K532-FEC.vbf	Jaguar F-Pace (X761)	PCM - Powertrain Control Module	DATA
JK83-12K532-FED.vbf	Jaguar F-Pace (X761)	PCM - Powertrain Control Module	DATA
JK83-12K532-FEE.vbf	Jaguar F-Pace (X761)	PCM - Powertrain Control Module	DATA
JK83-12K532-FFB.vbf	Jaguar F-Pace (X761)	PCM - Powertrain Control Module	DATA
JK83-12K532-FFC.vbf	Jaguar F-Pace (X761)	PCM - Powertrain Control Module	DATA
JK83-12K532-FFD.vbf	Jaguar F-Pace (X761)	PCM - Powertrain Control Module	DATA
JK83-12K532-FFE.vbf	Jaguar F-Pace (X761)	PCM - Powertrain Control Module	DATA
JK83-12K532-FGB.vbf	Jaguar F-Pace (X761)	PCM - Powertrain Control Module	DATA
JK83-12K532-FGC.vbf	Jaguar F-Pace (X761)	PCM - Powertrain Control Module	DATA
JK83-12K532-FHA.vbf	Jaguar F-Pace (X761)	PCM - Powertrain Control Module	DATA
JK83-12K532-FHB.vbf	Jaguar F-Pace (X761)	PCM - Powertrain Control Module	DATA
JK83-12K532-FHC.vbf	Jaguar F-Pace (X761)	PCM - Powertrain Control Module	DATA
JK83-12K532-FHD.vbf	Jaguar F-Pace (X761)	PCM - Powertrain Control Module	DATA
JK83-12K532-FHE.vbf	Jaguar F-Pace (X761)	PCM - Powertrain Control Module	DATA
JK83-12K532-FJA.vbf	Jaguar F-Pace (X761)	PCM - Powertrain Control Module	DATA
JK83-12K532-FJB.vbf	Jaguar F-Pace (X761)	PCM - Powertrain Control Module	DATA
JK83-12K532-FJD.vbf	Jaguar F-Pace (X761)	PCM - Powertrain Control Module	DATA
JK83-12K532-FJE.vbf	Jaguar F-Pace (X761)	PCM - Powertrain Control Module	DATA
JK83-12K532-FJF.vbf	Jaguar F-Pace (X761)	PCM - Powertrain Control Module	DATA
JK83-12K532-FJG.vbf	Jaguar F-Pace (X761)	PCM - Powertrain Control Module	DATA
JK83-12K532-FJH.vbf	Jaguar F-Pace (X761)	PCM - Powertrain Control Module	DATA
JK83-12K532-FKB.vbf	Jaguar F-Pace (X761)	PCM - Powertrain Control Module	DATA
JK83-12K532-FKC.vbf	Jaguar F-Pace (X761)	PCM - Powertrain Control Module	DATA
JK83-12K532-FKD.vbf	Jaguar F-Pace (X761)	PCM - Powertrain Control Module	DATA

File name	Vehicle line (indicative)	Module (ECU)	Type
JK83-12K532-FKE.vbf	Jaguar F-Pace (X761)	PCM - Powertrain Control Module	DATA
JK83-12K532-FLA.vbf	Jaguar F-Pace (X761)	PCM - Powertrain Control Module	DATA
JK83-12K532-FLB.vbf	Jaguar F-Pace (X761)	PCM - Powertrain Control Module	DATA
JK83-12K532-FLC.vbf	Jaguar F-Pace (X761)	PCM - Powertrain Control Module	DATA
JK83-12K532-FMB.vbf	Jaguar F-Pace (X761)	PCM - Powertrain Control Module	DATA
JK83-12K532-FMC.vbf	Jaguar F-Pace (X761)	PCM - Powertrain Control Module	DATA
JK83-12K532-FMD.vbf	Jaguar F-Pace (X761)	PCM - Powertrain Control Module	DATA
JK83-12K532-FPB.vbf	Jaguar F-Pace (X761)	PCM - Powertrain Control Module	DATA
JK83-12K532-FPC.vbf	Jaguar F-Pace (X761)	PCM - Powertrain Control Module	DATA
JK83-12K532-FPD.vbf	Jaguar F-Pace (X761)	PCM - Powertrain Control Module	DATA
JK83-12K532-FPE.vbf	Jaguar F-Pace (X761)	PCM - Powertrain Control Module	DATA
JK83-12K532-FPF.vbf	Jaguar F-Pace (X761)	PCM - Powertrain Control Module	DATA
JK83-12K532-GAB.vbf	Jaguar F-Pace (X761)	PCM - Powertrain Control Module	DATA
JK83-12K532-GAC.vbf	Jaguar F-Pace (X761)	PCM - Powertrain Control Module	DATA
JK83-12K532-GAD.vbf	Jaguar F-Pace (X761)	PCM - Powertrain Control Module	DATA
JK83-12K532-GAE.vbf	Jaguar F-Pace (X761)	PCM - Powertrain Control Module	DATA
JK83-12K532-GAF.vbf	Jaguar F-Pace (X761)	PCM - Powertrain Control Module	DATA
JK83-12K532-GAG.vbf	Jaguar F-Pace (X761)	PCM - Powertrain Control Module	DATA
JK83-12K532-GBA.vbf	Jaguar F-Pace (X761)	PCM - Powertrain Control Module	DATA
JK83-12K532-GBB.vbf	Jaguar F-Pace (X761)	PCM - Powertrain Control Module	DATA
JK83-12K532-GBC.vbf	Jaguar F-Pace (X761)	PCM - Powertrain Control Module	DATA
JK83-12K532-GBD.vbf	Jaguar F-Pace (X761)	PCM - Powertrain Control Module	DATA
JK83-12K532-GBE.vbf	Jaguar F-Pace (X761)	PCM - Powertrain Control Module	DATA
JK83-12K532-GBF.vbf	Jaguar F-Pace (X761)	PCM - Powertrain Control Module	DATA
JK83-12K532-GBG.vbf	Jaguar F-Pace (X761)	PCM - Powertrain Control Module	DATA
JK83-12K532-GCA.vbf	Jaguar F-Pace (X761)	PCM - Powertrain Control Module	DATA
JK83-12K532-GCB.vbf	Jaguar F-Pace (X761)	PCM - Powertrain Control Module	DATA
JK83-12K532-GCC.vbf	Jaguar F-Pace (X761)	PCM - Powertrain Control Module	DATA
JK83-12K532-GCD.vbf	Jaguar F-Pace (X761)	PCM - Powertrain Control Module	DATA
JK83-12K532-GCE.vbf	Jaguar F-Pace (X761)	PCM - Powertrain Control Module	DATA
JK83-12K532-GCF.vbf	Jaguar F-Pace (X761)	PCM - Powertrain Control Module	DATA
JK83-12K532-GCG.vbf	Jaguar F-Pace (X761)	PCM - Powertrain Control Module	DATA
JK83-12K532-PMD.vbf	Jaguar F-Pace (X761)	PCM - Powertrain Control Module	DATA
JK83-12K532-PNB.vbf	Jaguar F-Pace (X761)	PCM - Powertrain Control Module	DATA
JK83-12K532-PNC.vbf	Jaguar F-Pace (X761)	PCM - Powertrain Control Module	DATA
JK83-12K532-PND.vbf	Jaguar F-Pace (X761)	PCM - Powertrain Control Module	DATA
JK83-12K532-PNE.vbf	Jaguar F-Pace (X761)	PCM - Powertrain Control Module	DATA
JK83-12K532-PNF.vbf	Jaguar F-Pace (X761)	PCM - Powertrain Control Module	DATA
JK83-12K532-PNG.vbf	Jaguar F-Pace (X761)	PCM - Powertrain Control Module	DATA
JK83-12K532-PNH.vbf	Jaguar F-Pace (X761)	PCM - Powertrain Control Module	DATA
JK83-12K532-PTB.vbf	Jaguar F-Pace (X761)	PCM - Powertrain Control Module	DATA
JK83-14C025-AA.vbf	Jaguar F-Pace (X761)	IPC - Instrument Panel Cluster (IPC) Control Module	SBL
JK83-14C026-AA.vbf	Jaguar F-Pace (X761)	IPC - Instrument Panel Cluster (IPC) Control Module	EXE
JK83-14C026-AB.vbf	Jaguar F-Pace (X761)	IPC - Instrument Panel Cluster (IPC) Control Module	EXE
JK83-14C026-AC.vbf	Jaguar F-Pace (X761)	IPC - Instrument Panel Cluster (IPC) Control Module	EXE
JK83-14C026-AD.vbf	Jaguar F-Pace (X761)	IPC - Instrument Panel Cluster (IPC) Control Module	EXE
JK83-14C065-AC.vbf	Jaguar F-Pace (X761)	DDM - Driver Front Door Module	DATA
JK83-14C065-AD.vbf	Jaguar F-Pace (X761)	DDM - Driver Front Door Module	DATA
JK83-14C065-AE.vbf	Jaguar F-Pace (X761)	DDM - Driver Front Door Module	DATA
JK83-14C069-AC.vbf	Jaguar F-Pace (X761)	DRDM - Driver Rear Door Module	DATA
JK83-14C069-AD.vbf	Jaguar F-Pace (X761)	DRDM - Driver Rear Door Module	DATA
JK83-14C069-AE.vbf	Jaguar F-Pace (X761)	DRDM - Driver Rear Door Module	DATA
JK83-14C088-BB.vbf	Jaguar F-Pace (X761)	IPC - Instrument Panel Cluster (IPC) Control Module	DATA
JK83-14C088-BC.vbf	Jaguar F-Pace (X761)	IPC - Instrument Panel Cluster (IPC) Control Module	DATA
JK83-14C088-CA.vbf	Jaguar F-Pace (X761)	IPC - Instrument Panel Cluster (IPC) Control Module	EXE
JK83-14C088-CB.vbf	Jaguar F-Pace (X761)	IPC - Instrument Panel Cluster (IPC) Control Module	EXE
JK83-14C088-CC.vbf	Jaguar F-Pace (X761)	IPC - Instrument Panel Cluster (IPC) Control Module	EXE
JK83-14C088-CD.vbf	Jaguar F-Pace (X761)	IPC - Instrument Panel Cluster (IPC) Control Module	EXE
JK83-14C088-CE.vbf	Jaguar F-Pace (X761)	IPC - Instrument Panel Cluster (IPC) Control Module	EXE
JK83-14C105-AA.vbf	Jaguar F-Pace (X761)	TMC Traffic Message Channel Module	DATA
JK83-14C105-AD.vbf	Jaguar F-Pace (X761)	TMC Traffic Message Channel Module	DATA
JK83-14C109-AC.vbf	Jaguar F-Pace (X761)	PDM - Passenger Front Door Module	DATA
JK83-14C109-AD.vbf	Jaguar F-Pace (X761)	PDM - Passenger Front Door Module	DATA
JK83-14C109-AE.vbf	Jaguar F-Pace (X761)	PDM - Passenger Front Door Module	DATA
JK83-14C113-AC.vbf	Jaguar F-Pace (X761)	PRDM - Passenger Rear Door Module	DATA
JK83-14C113-AD.vbf	Jaguar F-Pace (X761)	PRDM - Passenger Rear Door Module	DATA
JK83-14C113-AE.vbf	Jaguar F-Pace (X761)	PRDM - Passenger Rear Door Module	DATA
JK83-14C121-AB.vbf	Jaguar F-Pace (X761)	RGTM - Rear Gate / Trunk Module	EXE
JK83-14C122-AB.vbf	Jaguar F-Pace (X761)	RGTM - Rear Gate / Trunk Module	DATA
JK83-14C124-AA.vbf	Jaguar F-Pace (X761)	RGTM - Rear Gate / Trunk Module	SBL
JK83-14C185-AC.vbf	Jaguar F-Pace (X761)	BCM - Body Control Module	DATA
JK83-14C204-PAA.vbf	Jaguar F-Pace (X761)	PCM - Powertrain Control Module	EXE
JK83-14C204-PAB.vbf	Jaguar F-Pace (X761)	PCM - Powertrain Control Module	EXE
JK83-14C217-AA.vbf	Jaguar F-Pace (X761)	PSCM - Power Steering Control Module	EXE
JK83-14C218-AA.vbf	Jaguar F-Pace (X761)	PSCM - Power Steering Control Module	DATA
JK83-14C218-BA.vbf	Jaguar F-Pace (X761)	PSCM - Power Steering Control Module	DATA

File name	Vehicle line (indicative)	Module (ECU)	Type
JK83-14C218-BB.vbf	Jaguar F-Pace (X761)	PSCM - Power Steering Control Module	DATA
JK83-14C218-CA.vbf	Jaguar F-Pace (X761)	PSCM - Power Steering Control Module	DATA
JK83-14C218-DA.vbf	Jaguar F-Pace (X761)	PSCM - Power Steering Control Module	DATA
JK83-14C218-DB.vbf	Jaguar F-Pace (X761)	PSCM - Power Steering Control Module	DATA
JK83-14C273-PAA.vbf	Jaguar F-Pace (X761)	PCM - Powertrain Control Module	SBL
JK83-14C366-AA.vbf	Jaguar F-Pace (X761)	TCCM - Transfer Case Control Module	EXE
JK83-14C367-AA.vbf	Jaguar F-Pace (X761)	TCCM - Transfer Case Control Module	DATA
JK83-14C367-BA.vbf	Jaguar F-Pace (X761)	TCCM - Transfer Case Control Module	DATA
JK83-14C386-AA.vbf	Jaguar F-Pace (X761)	PSCM - Power Steering Control Module	SIGCFG
JK83-14C527-BAB.vbf	Jaguar F-Pace (X761)	AAM - Audio Amplifier Module	DATA
JK83-14C527-BB.vbf	Jaguar F-Pace (X761)	AAM - Audio Amplifier Module	DATA
JK83-14C527-BBB.vbf	Jaguar F-Pace (X761)	AAM - Audio Amplifier Module	DATA
JK83-14C527-BBC.vbf	Jaguar F-Pace (X761)	AAM - Audio Amplifier Module	DATA
JK83-14C527-BCB.vbf	Jaguar F-Pace (X761)	AAM - Audio Amplifier Module	DATA
JK83-14C527-BEB.vbf	Jaguar F-Pace (X761)	AAM - Audio Amplifier Module	DATA
JK83-14C527-BFB.vbf	Jaguar F-Pace (X761)	AAM - Audio Amplifier Module	DATA
JK83-14C527-CAB.vbf	Jaguar F-Pace (X761)	AAM - Audio Amplifier Module	DATA
JK83-14C527-CB.vbf	Jaguar F-Pace (X761)	AAM - Audio Amplifier Module	DATA
JK83-14C527-CBB.vbf	Jaguar F-Pace (X761)	AAM - Audio Amplifier Module	DATA
JK83-14C527-CBC.vbf	Jaguar F-Pace (X761)	AAM - Audio Amplifier Module	DATA
JK83-14C527-CCB.vbf	Jaguar F-Pace (X761)	AAM - Audio Amplifier Module	DATA
JK83-14C527-CEB.vbf	Jaguar F-Pace (X761)	AAM - Audio Amplifier Module	DATA
JK83-14C527-CFB.vbf	Jaguar F-Pace (X761)	AAM - Audio Amplifier Module	DATA
JK83-14C536-BAA.vbf	Jaguar F-Pace (X761)	FCIM - Front Controls Interface Module	DATA
JK83-14C536-BBA.vbf	Jaguar F-Pace (X761)	FCIM - Front Controls Interface Module	DATA
JK83-14C536-BEA.vbf	Jaguar F-Pace (X761)	FCIM - Front Controls Interface Module	DATA
JK83-14C536-BFA.vbf	Jaguar F-Pace (X761)	FCIM - Front Controls Interface Module	DATA
JK83-14C536-BJA.vbf	Jaguar F-Pace (X761)	FCIM - Front Controls Interface Module	DATA
JK83-14C536-BKA.vbf	Jaguar F-Pace (X761)	FCIM - Front Controls Interface Module	DATA
JK83-14C536-BNA.vbf	Jaguar F-Pace (X761)	FCIM - Front Controls Interface Module	DATA
JK83-14C536-BPA.vbf	Jaguar F-Pace (X761)	FCIM - Front Controls Interface Module	DATA
JK83-14C536-BTA.vbf	Jaguar F-Pace (X761)	FCIM - Front Controls Interface Module	DATA
JK83-14C536-BUA.vbf	Jaguar F-Pace (X761)	FCIM - Front Controls Interface Module	DATA
JK83-14C536-BXA.vbf	Jaguar F-Pace (X761)	FCIM - Front Controls Interface Module	DATA
JK83-14C536-BYA.vbf	Jaguar F-Pace (X761)	FCIM - Front Controls Interface Module	DATA
JK83-14C536-CBA.vbf	Jaguar F-Pace (X761)	FCIM - Front Controls Interface Module	DATA
JK83-14C536-CCA.vbf	Jaguar F-Pace (X761)	FCIM - Front Controls Interface Module	DATA
JK83-14C536-CFA.vbf	Jaguar F-Pace (X761)	FCIM - Front Controls Interface Module	DATA
JK83-14C536-CGA.vbf	Jaguar F-Pace (X761)	FCIM - Front Controls Interface Module	DATA
JK83-14C570-UAA.vbf	Jaguar F-Pace (X761)	PCM - Powertrain Control Module	EXE
JK83-14C570-UAB.vbf	Jaguar F-Pace (X761)	PCM - Powertrain Control Module	EXE
JK83-14C570-UAC.vbf	Jaguar F-Pace (X761)	PCM - Powertrain Control Module	EXE
JK83-14C570-UAD.vbf	Jaguar F-Pace (X761)	PCM - Powertrain Control Module	EXE
JK83-14C570-UAE.vbf	Jaguar F-Pace (X761)	PCM - Powertrain Control Module	EXE
JK83-14C570-UBA.vbf	Jaguar F-Pace (X761)	PCM - Powertrain Control Module	EXE
JK83-14C570-UCB.vbf	Jaguar F-Pace (X761)	PCM - Powertrain Control Module	EXE
JK83-14C570-UCC.vbf	Jaguar F-Pace (X761)	PCM - Powertrain Control Module	EXE
JK83-14C570-UEA.vbf	Jaguar F-Pace (X761)	PCM - Powertrain Control Module	EXE
JK83-14C570-UEB.vbf	Jaguar F-Pace (X761)	PCM - Powertrain Control Module	EXE
JK83-14C570-UTA.vbf	Jaguar F-Pace (X761)	PCM - Powertrain Control Module	EXE
JK83-14C570-UTB.vbf	Jaguar F-Pace (X761)	PCM - Powertrain Control Module	EXE
JK83-14C570-UTC.vbf	Jaguar F-Pace (X761)	PCM - Powertrain Control Module	EXE
JK83-14C570-UTD.vbf	Jaguar F-Pace (X761)	PCM - Powertrain Control Module	EXE
JK83-14C609-AA.vbf	Jaguar F-Pace (X761)	PSCM - Power Steering Control Module	DATA
JK83-14C653-AB.vbf	Jaguar F-Pace (X761)	ACM - Audio Front Control Module	DATA
JK83-14D481-BA.vbf	Jaguar F-Pace (X761)	IPMB - Image Processing Module B	DATA
JK83-14D481-BB.vbf	Jaguar F-Pace (X761)	IPMB - Image Processing Module B	DATA
JK83-14D485-AA.vbf	Jaguar F-Pace (X761)	IPMB - Image Processing Module B	EXE
JK83-14D485-AB.vbf	Jaguar F-Pace (X761)	IPMB - Image Processing Module B	EXE
JK83-14D485-AC.vbf	Jaguar F-Pace (X761)	IPMB - Image Processing Module B	EXE
JK83-14D485-AE.vbf	Jaguar F-Pace (X761)	IPMB - Image Processing Module B	EXE
JK83-14D485-AF.vbf	Jaguar F-Pace (X761)	IPMB - Image Processing Module B	EXE
JK83-14D485-AG.vbf	Jaguar F-Pace (X761)	IPMB - Image Processing Module B	EXE
JK83-14D485-BA.vbf	Jaguar F-Pace (X761)	IPMB - Image Processing Module B	DATA
JK83-14D564-AB.vbf	Jaguar F-Pace (X761)	SODL - Side Obstacle Detection Control Module - Left	DATA
JK83-14D564-AC.vbf	Jaguar F-Pace (X761)	SODL - Side Obstacle Detection Control Module - Left	DATA
JK83-14D564-AD.vbf	Jaguar F-Pace (X761)	SODL - Side Obstacle Detection Control Module - Left	DATA
JK83-14D564-BB.vbf	Jaguar F-Pace (X761)	SODR - Side Obstacle Detection Control Module - Right	DATA
JK83-14D564-BC.vbf	Jaguar F-Pace (X761)	SODR - Side Obstacle Detection Control Module - Right	DATA
JK83-14D564-BD.vbf	Jaguar F-Pace (X761)	SODR - Side Obstacle Detection Control Module - Right	DATA
JK83-14E094-DAB.vbf	Jaguar F-Pace (X761)	CHCM - Chassis Control Module	EXE
JK83-14E094-DAC.vbf	Jaguar F-Pace (X761)	CHCM - Chassis Control Module	EXE
JK83-14E094-DBB.vbf	Jaguar F-Pace (X761)	CHCM - Chassis Control Module	EXE
JK83-14E094-DBC.vbf	Jaguar F-Pace (X761)	CHCM - Chassis Control Module	EXE
JK83-14E094-DCB.vbf	Jaguar F-Pace (X761)	CHCM - Chassis Control Module	EXE
JK83-14E094-DCC.vbf	Jaguar F-Pace (X761)	CHCM - Chassis Control Module	EXE

File name	Vehicle line (indicative)	Module (ECU)	Type
JK83-14E094-DDB.vbf	Jaguar F-Pace (X761)	CHCM - Chassis Control Module	EXE
JK83-14E094-DDC.vbf	Jaguar F-Pace (X761)	CHCM - Chassis Control Module	EXE
JK83-14E094-DEB.vbf	Jaguar F-Pace (X761)	CHCM - Chassis Control Module	EXE
JK83-14E094-DEC.vbf	Jaguar F-Pace (X761)	CHCM - Chassis Control Module	EXE
JK83-14E094-DFB.vbf	Jaguar F-Pace (X761)	CHCM - Chassis Control Module	EXE
JK83-14E094-DFC.vbf	Jaguar F-Pace (X761)	CHCM - Chassis Control Module	EXE
JK83-14E094-DFD.vbf	Jaguar F-Pace (X761)	CHCM - Chassis Control Module	EXE
JK83-14F022-AD.vbf	Jaguar F-Pace (X761)	IPMB - Image Processing Module B	DATA
JK83-14F022-AE.vbf	Jaguar F-Pace (X761)	IPMB - Image Processing Module B	DATA
JK83-14F022-AF.vbf	Jaguar F-Pace (X761)	IPMB - Image Processing Module B	DATA
JK83-14F022-AG.vbf	Jaguar F-Pace (X761)	IPMB - Image Processing Module B	DATA
JK83-14F022-BD.vbf	Jaguar F-Pace (X761)	IPMB - Image Processing Module B	DATA
JK83-14F022-BE.vbf	Jaguar F-Pace (X761)	IPMB - Image Processing Module B	DATA
JK83-14F022-BF.vbf	Jaguar F-Pace (X761)	IPMB - Image Processing Module B	DATA
JK83-14F022-BG.vbf	Jaguar F-Pace (X761)	IPMB - Image Processing Module B	DATA
JK83-14F397-AC.vbf	Jaguar F-Pace (X761)	IPMA - Image Processing Module A	EXE
JK83-14F397-AD.vbf	Jaguar F-Pace (X761)	IPMA - Image Processing Module A	EXE
JK83-14F397-AE.vbf	Jaguar F-Pace (X761)	IPMA - Image Processing Module A	EXE
JK83-14F397-AF.vbf	Jaguar F-Pace (X761)	IPMA - Image Processing Module A	EXE
JK83-14F397-BC.vbf	Jaguar F-Pace (X761)	IPMA - Image Processing Module A	EXE
JK83-14F397-BD.vbf	Jaguar F-Pace (X761)	IPMA - Image Processing Module A	EXE
JK83-14F397-BE.vbf	Jaguar F-Pace (X761)	IPMA - Image Processing Module A	EXE
JK83-14F397-BF.vbf	Jaguar F-Pace (X761)	IPMA - Image Processing Module A	EXE
JK83-14F397-CC.vbf	Jaguar F-Pace (X761)	IPMA - Image Processing Module A	EXE
JK83-14F397-CD.vbf	Jaguar F-Pace (X761)	IPMA - Image Processing Module A	EXE
JK83-14F397-CE.vbf	Jaguar F-Pace (X761)	IPMA - Image Processing Module A	EXE
JK83-14F397-CF.vbf	Jaguar F-Pace (X761)	IPMA - Image Processing Module A	EXE
JK83-14F397-DC.vbf	Jaguar F-Pace (X761)	IPMA - Image Processing Module A	EXE
JK83-14F397-DD.vbf	Jaguar F-Pace (X761)	IPMA - Image Processing Module A	EXE
JK83-14F397-DE.vbf	Jaguar F-Pace (X761)	IPMA - Image Processing Module A	EXE
JK83-14F397-DF.vbf	Jaguar F-Pace (X761)	IPMA - Image Processing Module A	EXE
JK83-14F398-AC.vbf	Jaguar F-Pace (X761)	IPMA - Image Processing Module A	EXE
JK83-14F398-AD.vbf	Jaguar F-Pace (X761)	IPMA - Image Processing Module A	EXE
JK83-14F398-AE.vbf	Jaguar F-Pace (X761)	IPMA - Image Processing Module A	EXE
JK83-14F398-AF.vbf	Jaguar F-Pace (X761)	IPMA - Image Processing Module A	EXE
JK83-14F398-BC.vbf	Jaguar F-Pace (X761)	IPMA - Image Processing Module A	EXE
JK83-14F398-BD.vbf	Jaguar F-Pace (X761)	IPMA - Image Processing Module A	EXE
JK83-14F398-BE.vbf	Jaguar F-Pace (X761)	IPMA - Image Processing Module A	EXE
JK83-14F398-BF.vbf	Jaguar F-Pace (X761)	IPMA - Image Processing Module A	EXE
JK83-7J104-FAA.vbf	Jaguar F-Pace (X761)	TCM - Transmission Control Module	EXE
JK83-7J104-FAB.vbf	Jaguar F-Pace (X761)	TCM - Transmission Control Module	EXE
JK83-7J104-FAC.vbf	Jaguar F-Pace (X761)	TCM - Transmission Control Module	EXE
JK83-7J104-FBA.vbf	Jaguar F-Pace (X761)	TCM - Transmission Control Module	EXE
JK83-7J104-FBB.vbf	Jaguar F-Pace (X761)	TCM - Transmission Control Module	EXE
JK83-7J104-FBC.vbf	Jaguar F-Pace (X761)	TCM - Transmission Control Module	EXE
JK83-7J104-FBD.vbf	Jaguar F-Pace (X761)	TCM - Transmission Control Module	EXE
JK83-7J104-FBE.vbf	Jaguar F-Pace (X761)	TCM - Transmission Control Module	EXE
JK83-7J104-FCA.vbf	Jaguar F-Pace (X761)	TCM - Transmission Control Module	EXE
JK83-7J104-FCB.vbf	Jaguar F-Pace (X761)	TCM - Transmission Control Module	EXE
JK83-7J104-FCC.vbf	Jaguar F-Pace (X761)	TCM - Transmission Control Module	EXE
JK83-7J104-FCD.vbf	Jaguar F-Pace (X761)	TCM - Transmission Control Module	EXE
JK83-7J104-FCE.vbf	Jaguar F-Pace (X761)	TCM - Transmission Control Module	EXE
JK83-7J104-FFA.vbf	Jaguar F-Pace (X761)	TCM - Transmission Control Module	EXE
JK83-7J104-FFB.vbf	Jaguar F-Pace (X761)	TCM - Transmission Control Module	EXE
JK83-7J104-FFC.vbf	Jaguar F-Pace (X761)	TCM - Transmission Control Module	EXE
JK83-7J104-FFD.vbf	Jaguar F-Pace (X761)	TCM - Transmission Control Module	EXE
JK83-7J104-FFE.vbf	Jaguar F-Pace (X761)	TCM - Transmission Control Module	EXE
JK83-7J104-FFF.vbf	Jaguar F-Pace (X761)	TCM - Transmission Control Module	EXE
JK83-7J104-FFG.vbf	Jaguar F-Pace (X761)	TCM - Transmission Control Module	EXE
JK83-7J104-FHA.vbf	Jaguar F-Pace (X761)	TCM - Transmission Control Module	EXE
JK83-7J104-FHB.vbf	Jaguar F-Pace (X761)	TCM - Transmission Control Module	EXE
JK83-7J104-FHC.vbf	Jaguar F-Pace (X761)	TCM - Transmission Control Module	EXE
JK83-7J104-FHD.vbf	Jaguar F-Pace (X761)	TCM - Transmission Control Module	EXE
JK83-7J104-FHE.vbf	Jaguar F-Pace (X761)	TCM - Transmission Control Module	EXE
JK83-7J104-FKA.vbf	Jaguar F-Pace (X761)	TCM - Transmission Control Module	EXE
JK83-7J104-FKB.vbf	Jaguar F-Pace (X761)	TCM - Transmission Control Module	EXE
JK83-7J104-FKC.vbf	Jaguar F-Pace (X761)	TCM - Transmission Control Module	EXE
JK83-7J104-FKD.vbf	Jaguar F-Pace (X761)	TCM - Transmission Control Module	EXE
JK83-7J104-FKE.vbf	Jaguar F-Pace (X761)	TCM - Transmission Control Module	EXE
JK83-7J104-FLA.vbf	Jaguar F-Pace (X761)	TCM - Transmission Control Module	EXE
JK83-7J104-FLB.vbf	Jaguar F-Pace (X761)	TCM - Transmission Control Module	EXE
JK83-7J104-FLC.vbf	Jaguar F-Pace (X761)	TCM - Transmission Control Module	EXE
JK83-7J104-FLD.vbf	Jaguar F-Pace (X761)	TCM - Transmission Control Module	EXE
JK83-7J104-FLE.vbf	Jaguar F-Pace (X761)	TCM - Transmission Control Module	EXE
JK83-7J104-FLF.vbf	Jaguar F-Pace (X761)	TCM - Transmission Control Module	EXE
JK83-7J104-FLG.vbf	Jaguar F-Pace (X761)	TCM - Transmission Control Module	EXE

File name	Vehicle line (indicative)	Module (ECU)	Type
JK83-7J104-FUA.vbf	Jaguar F-Pace (X761)	TCM - Transmission Control Module	EXE
JK83-7J104-FUB.vbf	Jaguar F-Pace (X761)	TCM - Transmission Control Module	EXE
JK83-7J104-FUC.vbf	Jaguar F-Pace (X761)	TCM - Transmission Control Module	EXE
JK83-7J104-FUD.vbf	Jaguar F-Pace (X761)	TCM - Transmission Control Module	EXE
JK83-7J104-FUE.vbf	Jaguar F-Pace (X761)	TCM - Transmission Control Module	EXE
JK83-7J104-FUF.vbf	Jaguar F-Pace (X761)	TCM - Transmission Control Module	EXE
JK83-7J104-FUG.vbf	Jaguar F-Pace (X761)	TCM - Transmission Control Module	EXE
JK83-7J104-FVA.vbf	Jaguar F-Pace (X761)	TCM - Transmission Control Module	EXE
JK83-7J104-FVB.vbf	Jaguar F-Pace (X761)	TCM - Transmission Control Module	EXE
JK83-7J104-FVC.vbf	Jaguar F-Pace (X761)	TCM - Transmission Control Module	EXE
JK83-7J104-FVD.vbf	Jaguar F-Pace (X761)	TCM - Transmission Control Module	EXE
JK83-7J104-FVE.vbf	Jaguar F-Pace (X761)	TCM - Transmission Control Module	EXE
JK83-7J104-FVF.vbf	Jaguar F-Pace (X761)	TCM - Transmission Control Module	EXE
JK83-7J104-FXA.vbf	Jaguar F-Pace (X761)	TCM - Transmission Control Module	EXE
JK83-7J104-FXB.vbf	Jaguar F-Pace (X761)	TCM - Transmission Control Module	EXE
JK83-7J104-FXC.vbf	Jaguar F-Pace (X761)	TCM - Transmission Control Module	EXE
JK83-7J104-FXD.vbf	Jaguar F-Pace (X761)	TCM - Transmission Control Module	EXE
JK83-7J104-FXE.vbf	Jaguar F-Pace (X761)	TCM - Transmission Control Module	EXE
JPLA-10C772-AAA.vbf	Multiple models (shared module)	Not specified	EXE
JPLA-10C772-AAC.vbf	Multiple models (shared module)	Not specified	EXE
JPLA-10C772-AAE.vbf	Multiple models (shared module)	Not specified	EXE
JPLA-10C772-AAG.vbf	Multiple models (shared module)	Not specified	EXE
JPLA-10C772-AAJ.vbf	Multiple models (shared module)	Not specified	EXE
JPLA-10C772-AG.vbf	Multiple models (shared module)	Not specified	EXE
JPLA-10C772-AJ.vbf	Multiple models (shared module)	Not specified	EXE
JPLA-10C772-AM.vbf	Multiple models (shared module)	Not specified	EXE
JPLA-10C772-AP.vbf	Multiple models (shared module)	Not specified	EXE
JPLA-10C772-AR.vbf	Multiple models (shared module)	Not specified	EXE
JPLA-10C772-AU.vbf	Multiple models (shared module)	Not specified	EXE
JPLA-10C772-AV.vbf	Multiple models (shared module)	Not specified	EXE
JPLA-10C772-AX.vbf	Multiple models (shared module)	Not specified	EXE
JPLA-10C772-AY.vbf	Multiple models (shared module)	Not specified	EXE
JPLA-10C772-AZ.vbf	Multiple models (shared module)	Not specified	EXE
JPLA-10C772-BA.vbf	Multiple models (shared module)	Not specified	EXE
JPLA-10C772-BB.vbf	Multiple models (shared module)	Not specified	EXE
JPLA-10C772-BC.vbf	Multiple models (shared module)	Not specified	EXE
JPLA-10C772-BD.vbf	Multiple models (shared module)	Not specified	EXE
JPLA-10C772-BE.vbf	Multiple models (shared module)	Not specified	EXE
JPLA-10C773-AA.vbf	Multiple models (shared module)	Not specified	EXE
JPLA-10C773-AB.vbf	Multiple models (shared module)	Not specified	EXE
JPLA-10C773-AC.vbf	Multiple models (shared module)	Not specified	EXE
JPLA-10C773-AD.vbf	Multiple models (shared module)	Not specified	EXE
JPLA-10C773-AE.vbf	Multiple models (shared module)	Not specified	EXE
JPLA-10C773-BA.vbf	Multiple models (shared module)	Not specified	EXE
JPLA-10C773-BB.vbf	Multiple models (shared module)	Not specified	EXE
JPLA-10C773-BC.vbf	Multiple models (shared module)	Not specified	EXE
JPLA-10C773-BD.vbf	Multiple models (shared module)	Not specified	EXE
JPLA-10C773-BE.vbf	Multiple models (shared module)	Not specified	EXE
JPLA-10C774-AB.vbf	Multiple models (shared module)	Not specified	SBL
JPLA-10C774-AC.vbf	Multiple models (shared module)	Not specified	SBL
JPLA-10C774-AD.vbf	Multiple models (shared module)	Not specified	SBL
JPLA-12K532-NLB.vbf	Multiple models (shared module)	PCM - Powertrain Control Module	DATA
JPLA-12K532-NLC.vbf	Multiple models (shared module)	PCM - Powertrain Control Module	DATA
JPLA-12K532-NLD.vbf	Multiple models (shared module)	PCM - Powertrain Control Module	DATA
JPLA-12K532-NLE.vbf	Multiple models (shared module)	PCM - Powertrain Control Module	DATA
JPLA-12K532-NMD.vbf	Multiple models (shared module)	PCM - Powertrain Control Module	DATA
JPLA-12K532-NME.vbf	Multiple models (shared module)	PCM - Powertrain Control Module	DATA
JPLA-12K532-NMF.vbf	Multiple models (shared module)	PCM - Powertrain Control Module	DATA
JPLA-12K532-NNB.vbf	Multiple models (shared module)	PCM - Powertrain Control Module	DATA
JPLA-12K532-NNC.vbf	Multiple models (shared module)	PCM - Powertrain Control Module	DATA
JPLA-12K532-NND.vbf	Multiple models (shared module)	PCM - Powertrain Control Module	DATA
JPLA-12K532-NNE.vbf	Multiple models (shared module)	PCM - Powertrain Control Module	DATA
JPLA-12K532-NNF.vbf	Multiple models (shared module)	PCM - Powertrain Control Module	DATA
JPLA-12K532-NNG.vbf	Multiple models (shared module)	PCM - Powertrain Control Module	DATA
JPLA-12K532-NNH.vbf	Multiple models (shared module)	PCM - Powertrain Control Module	DATA
JPLA-12K532-NNJ.vbf	Multiple models (shared module)	PCM - Powertrain Control Module	EXE
JPLA-12K532-NRD.vbf	Multiple models (shared module)	PCM - Powertrain Control Module	DATA
JPLA-12K532-NRE.vbf	Multiple models (shared module)	PCM - Powertrain Control Module	DATA
JPLA-12K532-NRG.vbf	Multiple models (shared module)	PCM - Powertrain Control Module	DATA
JPLA-14C026-JB.vbf	Multiple models (shared module)	IPC - Instrument Panel Cluster (IPC) Control Module	EXE
JPLA-14C026-JD.vbf	Multiple models (shared module)	IPC - Instrument Panel Cluster (IPC) Control Module	EXE
JPLA-14C026-JF.vbf	Multiple models (shared module)	IPC - Instrument Panel Cluster (IPC) Control Module	EXE
JPLA-14C026-JG.vbf	Multiple models (shared module)	IPC - Instrument Panel Cluster (IPC) Control Module	EXE
JPLA-14C026-JH.vbf	Multiple models (shared module)	IPC - Instrument Panel Cluster (IPC) Control Module	EXE
JPLA-14C026-KB.vbf	Multiple models (shared module)	IPC - Instrument Panel Cluster (IPC) Control Module	EXE
JPLA-14C026-KD.vbf	Multiple models (shared module)	IPC - Instrument Panel Cluster (IPC) Control Module	EXE

File name	Vehicle line (indicative)	Module (ECU)	Type
JPLA-14C026-KE.vbf	Multiple models (shared module)	IPC - Instrument Panel Cluster (IPC) Control Module	EXE
JPLA-14C026-KF.vbf	Multiple models (shared module)	IPC - Instrument Panel Cluster (IPC) Control Module	EXE
JPLA-14C026-LA.vbf	Multiple models (shared module)	IPC - Instrument Panel Cluster (IPC) Control Module	EXE
JPLA-14C027-BA.vbf	Multiple models (shared module)	RCM - Restraints Control Module	SBL
JPLA-14C028-AA.vbf	Multiple models (shared module)	RCM - Restraints Control Module	EXE
JPLA-14C028-AB.vbf	Multiple models (shared module)	RCM - Restraints Control Module	EXE
JPLA-14C028-AC.vbf	Multiple models (shared module)	RCM - Restraints Control Module	EXE
JPLA-14C028-AD.vbf	Multiple models (shared module)	RCM - Restraints Control Module	EXE
JPLA-14C028-AE.vbf	Multiple models (shared module)	RCM - Restraints Control Module	EXE
JPLA-14C030-AA.vbf	Multiple models (shared module)	DSM - Driver Front Seat Module	EXE
JPLA-14C030-AC.vbf	Multiple models (shared module)	DSM - Driver Front Seat Module	EXE
JPLA-14C030-AD.vbf	Multiple models (shared module)	DSM - Driver Front Seat Module	EXE
JPLA-14C030-AE.vbf	Multiple models (shared module)	DSM - Driver Front Seat Module	EXE
JPLA-14C030-AF.vbf	Multiple models (shared module)	DSM - Driver Front Seat Module	EXE
JPLA-14C030-AG.vbf	Multiple models (shared module)	DSM - Driver Front Seat Module	EXE
JPLA-14C030-AH.vbf	Multiple models (shared module)	DSM - Driver Front Seat Module	EXE
JPLA-14C036-AD.vbf	Multiple models (shared module)	ABS - Anti-Lock Brake System Control Module	EXE
JPLA-14C036-AE.vbf	Multiple models (shared module)	ABS - Anti-Lock Brake System Control Module	EXE
JPLA-14C036-AF.vbf	Multiple models (shared module)	ABS - Anti-Lock Brake System Control Module	EXE
JPLA-14C036-AG.vbf	Multiple models (shared module)	ABS - Anti-Lock Brake System Control Module	EXE
JPLA-14C036-AH.vbf	Multiple models (shared module)	ABS - Anti-Lock Brake System Control Module	EXE
JPLA-14C036-AJ.vbf	Multiple models (shared module)	ABS - Anti-Lock Brake System Control Module	EXE
JPLA-14C036-AK.vbf	Multiple models (shared module)	ABS - Anti-Lock Brake System Control Module	EXE
JPLA-14C036-HE.vbf	Multiple models (shared module)	ABS - Anti-Lock Brake System Control Module	EXE
JPLA-14C036-HF.vbf	Multiple models (shared module)	ABS - Anti-Lock Brake System Control Module	EXE
JPLA-14C036-HG.vbf	Multiple models (shared module)	ABS - Anti-Lock Brake System Control Module	EXE
JPLA-14C036-HH.vbf	Multiple models (shared module)	ABS - Anti-Lock Brake System Control Module	EXE
JPLA-14C036-HJ.vbf	Multiple models (shared module)	ABS - Anti-Lock Brake System Control Module	EXE
JPLA-14C036-HK.vbf	Multiple models (shared module)	ABS - Anti-Lock Brake System Control Module	EXE
JPLA-14C036-HL.vbf	Multiple models (shared module)	ABS - Anti-Lock Brake System Control Module	EXE
JPLA-14C039-AA.vbf	Multiple models (shared module)	ABS - Anti-Lock Brake System Control Module	SBL
JPLA-14C039-HC.vbf	Multiple models (shared module)	ABS - Anti-Lock Brake System Control Module	SBL
JPLA-14C064-BA.vbf	Multiple models (shared module)	DDM - Driver Front Door Module	EXE
JPLA-14C064-BB.vbf	Multiple models (shared module)	DDM - Driver Front Door Module	EXE
JPLA-14C064-CA.vbf	Multiple models (shared module)	DDM - Driver Front Door Module	EXE
JPLA-14C064-CB.vbf	Multiple models (shared module)	DDM - Driver Front Door Module	EXE
JPLA-14C068-BA.vbf	Multiple models (shared module)	DRDM - Driver Rear Door Module	EXE
JPLA-14C068-BB.vbf	Multiple models (shared module)	DRDM - Driver Rear Door Module	EXE
JPLA-14C068-CA.vbf	Multiple models (shared module)	DRDM - Driver Rear Door Module	EXE
JPLA-14C068-CB.vbf	Multiple models (shared module)	DRDM - Driver Rear Door Module	EXE
JPLA-14C084-AA.vbf	Multiple models (shared module)	HCM - Headlamp Control Module #1	EXE
JPLA-14C084-AB.vbf	Multiple models (shared module)	HCM - Headlamp Control Module #1	EXE
JPLA-14C084-AC.vbf	Multiple models (shared module)	HCM - Headlamp Control Module #1	EXE
JPLA-14C084-AD.vbf	Multiple models (shared module)	HCM - Headlamp Control Module #1	EXE
JPLA-14C084-AE.vbf	Multiple models (shared module)	HCM - Headlamp Control Module #1	EXE
JPLA-14C084-AF.vbf	Multiple models (shared module)	HCM - Headlamp Control Module #1	EXE
JPLA-14C084-AG.vbf	Multiple models (shared module)	HCM - Headlamp Control Module #1	EXE
JPLA-14C084-AH.vbf	Multiple models (shared module)	HCM - Headlamp Control Module #1	EXE
JPLA-14C084-BA.vbf	Multiple models (shared module)	Not specified	EXE
JPLA-14C084-BB.vbf	Multiple models (shared module)	Not specified	EXE
JPLA-14C084-BC.vbf	Multiple models (shared module)	Not specified	EXE
JPLA-14C084-BD.vbf	Multiple models (shared module)	Not specified	EXE
JPLA-14C084-BE.vbf	Multiple models (shared module)	Not specified	EXE
JPLA-14C084-BF.vbf	Multiple models (shared module)	Not specified	EXE
JPLA-14C084-BG.vbf	Multiple models (shared module)	Not specified	EXE
JPLA-14C084-BH.vbf	Multiple models (shared module)	Not specified	EXE
JPLA-14C088-JC.vbf	Multiple models (shared module)	IPC - Instrument Panel Cluster (IPC) Control Module	DATA
JPLA-14C088-JD.vbf	Multiple models (shared module)	IPC - Instrument Panel Cluster (IPC) Control Module	DATA
JPLA-14C088-JF.vbf	Multiple models (shared module)	IPC - Instrument Panel Cluster (IPC) Control Module	DATA
JPLA-14C088-JG.vbf	Multiple models (shared module)	IPC - Instrument Panel Cluster (IPC) Control Module	DATA
JPLA-14C088-JJ.vbf	Multiple models (shared module)	IPC - Instrument Panel Cluster (IPC) Control Module	DATA
JPLA-14C088-JK.vbf	Multiple models (shared module)	IPC - Instrument Panel Cluster (IPC) Control Module	DATA
JPLA-14C088-JN.vbf	Multiple models (shared module)	IPC - Instrument Panel Cluster (IPC) Control Module	DATA
JPLA-14C090-AC.vbf	Multiple models (shared module)	PAM - Parking Assist Control Module	EXE
JPLA-14C090-AD.vbf	Multiple models (shared module)	PAM - Parking Assist Control Module	EXE
JPLA-14C090-AF.vbf	Multiple models (shared module)	PAM - Parking Assist Control Module	EXE
JPLA-14C090-AG.vbf	Multiple models (shared module)	PAM - Parking Assist Control Module	EXE
JPLA-14C090-AH.vbf	Multiple models (shared module)	PAM - Parking Assist Control Module	EXE
JPLA-14C090-AJ.vbf	Multiple models (shared module)	PAM - Parking Assist Control Module	EXE
JPLA-14C090-AK.vbf	Multiple models (shared module)	PAM - Parking Assist Control Module	EXE
JPLA-14C090-AL.vbf	Multiple models (shared module)	PAM - Parking Assist Control Module	EXE
JPLA-14C090-AM.vbf	Multiple models (shared module)	PAM - Parking Assist Control Module	EXE
JPLA-14C090-AP.vbf	Multiple models (shared module)	PAM - Parking Assist Control Module	EXE
JPLA-14C090-AR.vbf	Multiple models (shared module)	PAM - Parking Assist Control Module	EXE
JPLA-14C093-AA.vbf	Multiple models (shared module)	PAM - Parking Assist Control Module	SBL
JPLA-14C093-AB.vbf	Multiple models (shared module)	PAM - Parking Assist Control Module	SBL

File name	Vehicle line (indicative)	Module (ECU)	Type
JPLA-14C104-AC.vbf	Multiple models (shared module)	RFA - Remote Function Actuator	EXE
JPLA-14C104-AE.vbf	Multiple models (shared module)	RFA - Remote Function Actuator	EXE
JPLA-14C104-AF.vbf	Multiple models (shared module)	RFA - Remote Function Actuator	EXE
JPLA-14C104-AH.vbf	Multiple models (shared module)	RFA - Remote Function Actuator	EXE
JPLA-14C104-AJ.vbf	Multiple models (shared module)	RFA - Remote Function Actuator	EXE
JPLA-14C104-AK.vbf	Multiple models (shared module)	RFA - Remote Function Actuator	EXE
JPLA-14C104-AL.vbf	Multiple models (shared module)	RFA - Remote Function Actuator	EXE
JPLA-14C107-BA.vbf	Multiple models (shared module)	TMC Traffic Message Channel Module	SBL
JPLA-14C108-BA.vbf	Multiple models (shared module)	PDM - Passenger Front Door Module	EXE
JPLA-14C108-BB.vbf	Multiple models (shared module)	PDM - Passenger Front Door Module	EXE
JPLA-14C108-CA.vbf	Multiple models (shared module)	PDM - Passenger Front Door Module	EXE
JPLA-14C108-CB.vbf	Multiple models (shared module)	PDM - Passenger Front Door Module	EXE
JPLA-14C112-BA.vbf	Multiple models (shared module)	PRDM - Passenger Rear Door Module	EXE
JPLA-14C112-BB.vbf	Multiple models (shared module)	PRDM - Passenger Rear Door Module	EXE
JPLA-14C112-CA.vbf	Multiple models (shared module)	PRDM - Passenger Rear Door Module	EXE
JPLA-14C112-CB.vbf	Multiple models (shared module)	PRDM - Passenger Rear Door Module	EXE
JPLA-14C184-BB.vbf	Multiple models (shared module)	BCM - Body Control Module	CUSTOM
JPLA-14C184-BC.vbf	Multiple models (shared module)	BCM - Body Control Module	CUSTOM
JPLA-14C184-BD.vbf	Multiple models (shared module)	BCM - Body Control Module	CUSTOM
JPLA-14C184-BE.vbf	Multiple models (shared module)	BCM - Body Control Module	CUSTOM
JPLA-14C184-BF.vbf	Multiple models (shared module)	BCM - Body Control Module	CUSTOM
JPLA-14C184-BG.vbf	Multiple models (shared module)	BCM - Body Control Module	CUSTOM
JPLA-14C184-BH.vbf	Multiple models (shared module)	BCM - Body Control Module	CUSTOM
JPLA-14C184-BJ.vbf	Multiple models (shared module)	BCM - Body Control Module	CUSTOM
JPLA-14C184-BK.vbf	Multiple models (shared module)	BCM - Body Control Module	CUSTOM
JPLA-14C184-BL.vbf	Multiple models (shared module)	BCM - Body Control Module	CUSTOM
JPLA-14C184-BM.vbf	Multiple models (shared module)	BCM - Body Control Module	CUSTOM
JPLA-14C184-BN.vbf	Multiple models (shared module)	BCM - Body Control Module	CUSTOM
JPLA-14C184-BP.vbf	Multiple models (shared module)	BCM - Body Control Module	CUSTOM
JPLA-14C184-BS.vbf	Multiple models (shared module)	BCM - Body Control Module	CUSTOM
JPLA-14C184-BT.vbf	Multiple models (shared module)	BCM - Body Control Module	CUSTOM
JPLA-14C184-BU.vbf	Multiple models (shared module)	BCM - Body Control Module	CUSTOM
JPLA-14C187-AA.vbf	Multiple models (shared module)	BCM - Body Control Module	SBL
JPLA-14C197-AD.vbf	Multiple models (shared module)	BECM - Battery Energy Control Module	EXE
JPLA-14C197-AE.vbf	Multiple models (shared module)	BECM - Battery Energy Control Module	EXE
JPLA-14C197-AF.vbf	Multiple models (shared module)	BECM - Battery Energy Control Module	EXE
JPLA-14C197-AG.vbf	Multiple models (shared module)	BECM - Battery Energy Control Module	EXE
JPLA-14C197-AM.vbf	Multiple models (shared module)	BECM - Battery Energy Control Module	EXE
JPLA-14C197-AN.vbf	Multiple models (shared module)	BECM - Battery Energy Control Module	EXE
JPLA-14C197-AP.vbf	Multiple models (shared module)	BECM - Battery Energy Control Module	EXE
JPLA-14C197-AR.vbf	Multiple models (shared module)	BECM - Battery Energy Control Module	EXE
JPLA-14C197-AS.vbf	Multiple models (shared module)	BECM - Battery Energy Control Module	EXE
JPLA-14C197-AT.vbf	Multiple models (shared module)	BECM - Battery Energy Control Module	EXE
JPLA-14C197-ZA.vbf	Multiple models (shared module)	BECM - Battery Energy Control Module	EXE
JPLA-14C200-AB.vbf	Multiple models (shared module)	BECM - Battery Energy Control Module	SBL
JPLA-14C204-NAB.vbf	Multiple models (shared module)	PCM - Powertrain Control Module	EXE
JPLA-14C204-NAC.vbf	Multiple models (shared module)	PCM - Powertrain Control Module	EXE
JPLA-14C204-NAD.vbf	Multiple models (shared module)	PCM - Powertrain Control Module	EXE
JPLA-14C204-NAE.vbf	Multiple models (shared module)	PCM - Powertrain Control Module	EXE
JPLA-14C204-PAA.vbf	Multiple models (shared module)	PCM - Powertrain Control Module	EXE
JPLA-14C204-PAB.vbf	Multiple models (shared module)	PCM - Powertrain Control Module	EXE
JPLA-14C204-PAC.vbf	Multiple models (shared module)	PCM - Powertrain Control Module	EXE
JPLA-14C204-PAD.vbf	Multiple models (shared module)	PCM - Powertrain Control Module	EXE
JPLA-14C217-AA.vbf	Multiple models (shared module)	PSCM - Power Steering Control Module	EXE
JPLA-14C217-AB.vbf	Multiple models (shared module)	PSCM - Power Steering Control Module	EXE
JPLA-14C386-AA.vbf	Multiple models (shared module)	PSCM - Power Steering Control Module	EXE
JPLA-14C386-AB.vbf	Multiple models (shared module)	PSCM - Power Steering Control Module	EXE
JPLA-14C399-AA.vbf	Multiple models (shared module)	HCM - Headlamp Control Module #1	SIGCFG
JPLA-14C399-AB.vbf	Multiple models (shared module)	HCM - Headlamp Control Module #1	SIGCFG
JPLA-14C399-BA.vbf	Multiple models (shared module)	Not specified	SIGCFG
JPLA-14C399-BB.vbf	Multiple models (shared module)	Not specified	SIGCFG
JPLA-14C408-AC.vbf	Multiple models (shared module)	BCM - Body Control Module	SIGCFG
JPLA-14C408-AD.vbf	Multiple models (shared module)	BCM - Body Control Module	SIGCFG
JPLA-14C408-AE.vbf	Multiple models (shared module)	BCM - Body Control Module	SIGCFG
JPLA-14C413-AA.vbf	Multiple models (shared module)	DSM - Driver Front Seat Module	EXE
JPLA-14C413-AB.vbf	Multiple models (shared module)	DSM - Driver Front Seat Module	EXE
JPLA-14C430-AA.vbf	Multiple models (shared module)	TMC Traffic Message Channel Module	EXE
JPLA-14C430-AB.vbf	Multiple models (shared module)	TMC Traffic Message Channel Module	EXE
JPLA-14C430-AC.vbf	Multiple models (shared module)	TMC Traffic Message Channel Module	EXE
JPLA-14C526-AB.vbf	Multiple models (shared module)	AAM - Audio Amplifier Module	EXE
JPLA-14C526-AF.vbf	Multiple models (shared module)	AAM - Audio Amplifier Module	EXE
JPLA-14C526-BB.vbf	Multiple models (shared module)	AAM - Audio Amplifier Module	EXE
JPLA-14C526-BD.vbf	Multiple models (shared module)	AAM - Audio Amplifier Module	EXE
JPLA-14C526-BF.vbf	Multiple models (shared module)	AAM - Audio Amplifier Module	EXE
JPLA-14C526-CB.vbf	Multiple models (shared module)	AAM - Audio Amplifier Module	EXE
JPLA-14C526-CE.vbf	Multiple models (shared module)	AAM - Audio Amplifier Module	EXE

File name	Vehicle line (indicative)	Module (ECU)	Type
JPLA-14C526-CF.vbf	Multiple models (shared module)	AAM - Audio Amplifier Module	EXE
JPLA-14C526-CH.vbf	Multiple models (shared module)	AAM - Audio Amplifier Module	EXE
JPLA-14C526-CJ.vbf	Multiple models (shared module)	AAM - Audio Amplifier Module	EXE
JPLA-14C526-DB.vbf	Multiple models (shared module)	AAM - Audio Amplifier Module	EXE
JPLA-14C526-DC.vbf	Multiple models (shared module)	AAM - Audio Amplifier Module	EXE
JPLA-14C526-DE.vbf	Multiple models (shared module)	AAM - Audio Amplifier Module	EXE
JPLA-14C526-DF.vbf	Multiple models (shared module)	AAM - Audio Amplifier Module	EXE
JPLA-14C526-DG.vbf	Multiple models (shared module)	AAM - Audio Amplifier Module	EXE
JPLA-14C526-DJ.vbf	Multiple models (shared module)	AAM - Audio Amplifier Module	EXE
JPLA-14C526-DK.vbf	Multiple models (shared module)	AAM - Audio Amplifier Module	EXE
JPLA-14C528-AA.vbf	Multiple models (shared module)	AAM - Audio Amplifier Module	SBL
JPLA-14C528-CA.vbf	Multiple models (shared module)	AAM - Audio Amplifier Module	SBL
JPLA-14C547-AA.vbf	Multiple models (shared module)	PSM - Passenger Front Seat Module	EXE
JPLA-14C547-AB.vbf	Multiple models (shared module)	PSM - Passenger Front Seat Module	EXE
JPLA-14C548-AA.vbf	Multiple models (shared module)	PSM - Passenger Front Seat Module	EXE
JPLA-14C548-AC.vbf	Multiple models (shared module)	PSM - Passenger Front Seat Module	EXE
JPLA-14C548-AD.vbf	Multiple models (shared module)	PSM - Passenger Front Seat Module	EXE
JPLA-14C548-AE.vbf	Multiple models (shared module)	PSM - Passenger Front Seat Module	EXE
JPLA-14C548-AF.vbf	Multiple models (shared module)	PSM - Passenger Front Seat Module	EXE
JPLA-14C548-AG.vbf	Multiple models (shared module)	PSM - Passenger Front Seat Module	EXE
JPLA-14C548-AH.vbf	Multiple models (shared module)	PSM - Passenger Front Seat Module	EXE
JPLA-14C570-BGC.vbf	Multiple models (shared module)	PCM - Powertrain Control Module	EXE
JPLA-14C570-BLA.vbf	Multiple models (shared module)	PCM - Powertrain Control Module	EXE
JPLA-14C570-BLC.vbf	Multiple models (shared module)	PCM - Powertrain Control Module	EXE
JPLA-14C570-BLD.vbf	Multiple models (shared module)	PCM - Powertrain Control Module	EXE
JPLA-14C570-BLE.vbf	Multiple models (shared module)	PCM - Powertrain Control Module	EXE
JPLA-14C570-BND.vbf	Multiple models (shared module)	PCM - Powertrain Control Module	EXE
JPLA-14C570-BNE.vbf	Multiple models (shared module)	PCM - Powertrain Control Module	EXE
JPLA-14C570-BPA.vbf	Multiple models (shared module)	PCM - Powertrain Control Module	EXE
JPLA-14C570-BUA.vbf	Multiple models (shared module)	PCM - Powertrain Control Module	EXE
JPLA-14C570-BUC.vbf	Multiple models (shared module)	PCM - Powertrain Control Module	EXE
JPLA-14C570-BUD.vbf	Multiple models (shared module)	PCM - Powertrain Control Module	EXE
JPLA-14C570-BUE.vbf	Multiple models (shared module)	PCM - Powertrain Control Module	EXE
JPLA-14C570-BUF.vbf	Multiple models (shared module)	PCM - Powertrain Control Module	EXE
JPLA-14C570-DGD.vbf	Multiple models (shared module)	PCM - Powertrain Control Module	EXE
JPLA-14C570-DGE.vbf	Multiple models (shared module)	PCM - Powertrain Control Module	EXE
JPLA-14C570-DGG.vbf	Multiple models (shared module)	PCM - Powertrain Control Module	EXE
JPLA-14C570-DGH.vbf	Multiple models (shared module)	PCM - Powertrain Control Module	EXE
JPLA-14C570-DGJ.vbf	Multiple models (shared module)	PCM - Powertrain Control Module	EXE
JPLA-14C570-DGK.vbf	Multiple models (shared module)	PCM - Powertrain Control Module	EXE
JPLA-14C570-DND.vbf	Multiple models (shared module)	PCM - Powertrain Control Module	EXE
JPLA-14C570-DNG.vbf	Multiple models (shared module)	PCM - Powertrain Control Module	EXE
JPLA-14C570-DNH.vbf	Multiple models (shared module)	PCM - Powertrain Control Module	EXE
JPLA-14C570-DNJ.vbf	Multiple models (shared module)	PCM - Powertrain Control Module	EXE
JPLA-14C570-DNK.vbf	Multiple models (shared module)	PCM - Powertrain Control Module	EXE
JPLA-14C570-DUD.vbf	Multiple models (shared module)	PCM - Powertrain Control Module	EXE
JPLA-14C570-DUE.vbf	Multiple models (shared module)	PCM - Powertrain Control Module	EXE
JPLA-14C570-DUG.vbf	Multiple models (shared module)	PCM - Powertrain Control Module	EXE
JPLA-14C570-DUH.vbf	Multiple models (shared module)	PCM - Powertrain Control Module	EXE
JPLA-14C570-DUJ.vbf	Multiple models (shared module)	PCM - Powertrain Control Module	EXE
JPLA-14C570-DUK.vbf	Multiple models (shared module)	PCM - Powertrain Control Module	EXE
JPLA-14C570-DUM.vbf	Multiple models (shared module)	PCM - Powertrain Control Module	EXE
JPLA-14C570-DUN.vbf	Multiple models (shared module)	PCM - Powertrain Control Module	EXE
JPLA-14C570-DUR.vbf	Multiple models (shared module)	PCM - Powertrain Control Module	EXE
JPLA-14C570-DUS.vbf	Multiple models (shared module)	PCM - Powertrain Control Module	EXE
JPLA-14C570-DUT.vbf	Multiple models (shared module)	PCM - Powertrain Control Module	EXE
JPLA-14C570-SAB.vbf	Multiple models (shared module)	PCM - Powertrain Control Module	EXE
JPLA-14C570-SAD.vbf	Multiple models (shared module)	PCM - Powertrain Control Module	EXE
JPLA-14C570-SAF.vbf	Multiple models (shared module)	PCM - Powertrain Control Module	EXE
JPLA-14C570-SAG.vbf	Multiple models (shared module)	PCM - Powertrain Control Module	EXE
JPLA-14C570-SCB.vbf	Multiple models (shared module)	PCM - Powertrain Control Module	EXE
JPLA-14C570-SCD.vbf	Multiple models (shared module)	PCM - Powertrain Control Module	EXE
JPLA-14C570-SED.vbf	Multiple models (shared module)	PCM - Powertrain Control Module	EXE
JPLA-14C570-STB.vbf	Multiple models (shared module)	PCM - Powertrain Control Module	EXE
JPLA-14C570-STD.vbf	Multiple models (shared module)	PCM - Powertrain Control Module	EXE
JPLA-14C570-UAB.vbf	Multiple models (shared module)	PCM - Powertrain Control Module	EXE
JPLA-14C570-UAC.vbf	Multiple models (shared module)	PCM - Powertrain Control Module	EXE
JPLA-14C570-UAF.vbf	Multiple models (shared module)	PCM - Powertrain Control Module	EXE
JPLA-14C570-UCB.vbf	Multiple models (shared module)	PCM - Powertrain Control Module	EXE
JPLA-14C570-UCC.vbf	Multiple models (shared module)	PCM - Powertrain Control Module	EXE
JPLA-14C570-UEC.vbf	Multiple models (shared module)	PCM - Powertrain Control Module	EXE
JPLA-14C570-UED.vbf	Multiple models (shared module)	PCM - Powertrain Control Module	EXE
JPLA-14C570-UFB.vbf	Multiple models (shared module)	PCM - Powertrain Control Module	EXE
JPLA-14C570-UTB.vbf	Multiple models (shared module)	PCM - Powertrain Control Module	EXE
JPLA-14C570-UTC.vbf	Multiple models (shared module)	PCM - Powertrain Control Module	EXE
JPLA-14C572-BA.vbf	Multiple models (shared module)	PCM - Powertrain Control Module	SBL

File name	Vehicle line (indicative)	Module (ECU)	Type
JPLA-14D023-AA.vbf	Multiple models (shared module)	ATCM - All Terrain Control Module	SIGCFG
JPLA-14D024-AB.vbf	Multiple models (shared module)	ATCM - All Terrain Control Module	EXE
JPLA-14D024-AC.vbf	Multiple models (shared module)	ATCM - All Terrain Control Module	EXE
JPLA-14D024-AD.vbf	Multiple models (shared module)	ATCM - All Terrain Control Module	EXE
JPLA-14D024-AE.vbf	Multiple models (shared module)	ATCM - All Terrain Control Module	EXE
JPLA-14D025-AB.vbf	Multiple models (shared module)	ATCM - All Terrain Control Module	DATA
JPLA-14D025-AC.vbf	Multiple models (shared module)	ATCM - All Terrain Control Module	DATA
JPLA-14D025-AD.vbf	Multiple models (shared module)	ATCM - All Terrain Control Module	DATA
JPLA-14D026-AA.vbf	Multiple models (shared module)	ATCM - All Terrain Control Module	SBL
JPLA-14D026-AB.vbf	Multiple models (shared module)	ATCM - All Terrain Control Module	SBL
JPLA-14D026-AC.vbf	Multiple models (shared module)	ATCM - All Terrain Control Module	SBL
JPLA-14D049-AB.vbf	Multiple models (shared module)	CCM - Cruise Control Module	EXE
JPLA-14D049-AC.vbf	Multiple models (shared module)	CCM - Cruise Control Module	EXE
JPLA-14D049-AD.vbf	Multiple models (shared module)	CCM - Cruise Control Module	EXE
JPLA-14D049-AE.vbf	Multiple models (shared module)	CCM - Cruise Control Module	EXE
JPLA-14D049-AF.vbf	Multiple models (shared module)	CCM - Cruise Control Module	EXE
JPLA-14D049-AG.vbf	Multiple models (shared module)	CCM - Cruise Control Module	EXE
JPLA-14D051-AA.vbf	Multiple models (shared module)	CCM - Cruise Control Module	SBL
JPLA-14D367-AA.vbf	Multiple models (shared module)	SODL - Side Obstacle Detection Control Module - Left	SIGCFG
JPLA-14D367-BA.vbf	Multiple models (shared module)	SODR - Side Obstacle Detection Control Module - Right	SIGCFG
JPLA-14D368-AA.vbf	Multiple models (shared module)	SODL - Side Obstacle Detection Control Module - Left	EXE
JPLA-14D368-AC.vbf	Multiple models (shared module)	SODL - Side Obstacle Detection Control Module - Left	EXE
JPLA-14D368-AD.vbf	Multiple models (shared module)	SODL - Side Obstacle Detection Control Module - Left	EXE
JPLA-14D368-BA.vbf	Multiple models (shared module)	SODL - Side Obstacle Detection Control Module - Left	EXE
JPLA-14D368-BC.vbf	Multiple models (shared module)	SODL - Side Obstacle Detection Control Module - Left	EXE
JPLA-14D368-BD.vbf	Multiple models (shared module)	SODL - Side Obstacle Detection Control Module - Left	EXE
JPLA-14D370-AA.vbf	Multiple models (shared module)	SODL - Side Obstacle Detection Control Module - Left	SBL
JPLA-14D370-AB.vbf	Multiple models (shared module)	SODL - Side Obstacle Detection Control Module - Left	SBL
JPLA-14D459-AD.vbf	Multiple models (shared module)	HDCDC - High Voltage DC-DC Converter Control Module	EXE
JPLA-14D459-AE.vbf	Multiple models (shared module)	HDCDC - High Voltage DC-DC Converter Control Module	EXE
JPLA-14D459-AF.vbf	Multiple models (shared module)	HDCDC - High Voltage DC-DC Converter Control Module	EXE
JPLA-14D461-AC.vbf	Multiple models (shared module)	HDCDC - High Voltage DC-DC Converter Control Module	SBL
JPLA-14E093-JB.vbf	Multiple models (shared module)	CHCM - Chassis Control Module	EXE
JPLA-14E093-JC.vbf	Multiple models (shared module)	CHCM - Chassis Control Module	EXE
JPLA-14E093-JE.vbf	Multiple models (shared module)	CHCM - Chassis Control Module	EXE
JPLA-14E093-JG.vbf	Multiple models (shared module)	CHCM - Chassis Control Module	EXE
JPLA-14E093-JH.vbf	Multiple models (shared module)	CHCM - Chassis Control Module	EXE
JPLA-14E093-JJ.vbf	Multiple models (shared module)	CHCM - Chassis Control Module	EXE
JPLA-14E093-JK.vbf	Multiple models (shared module)	CHCM - Chassis Control Module	EXE
JPLA-14E093-JL.vbf	Multiple models (shared module)	CHCM - Chassis Control Module	EXE
JPLA-14E093-JM.vbf	Multiple models (shared module)	CHCM - Chassis Control Module	EXE
JPLA-14F017-AB.vbf	Multiple models (shared module)	Not specified	EXE
JPLA-14F017-AC.vbf	Multiple models (shared module)	Not specified	EXE
JPLA-14F017-AD.vbf	Multiple models (shared module)	Not specified	EXE
JPLA-14F017-AE.vbf	Multiple models (shared module)	Not specified	EXE
JPLA-14F017-AF.vbf	Multiple models (shared module)	Not specified	EXE
JPLA-14F017-AG.vbf	Multiple models (shared module)	Not specified	EXE
JPLA-14F017-AJ.vbf	Multiple models (shared module)	Not specified	EXE
JPLA-14F017-DA.vbf	Multiple models (shared module)	Not specified	EXE
JPLA-14F017-DD.vbf	Multiple models (shared module)	Not specified	EXE
JPLA-14F017-DE.vbf	Multiple models (shared module)	Not specified	EXE
JPLA-14F017-DF.vbf	Multiple models (shared module)	Not specified	EXE
JPLA-14F017-DG.vbf	Multiple models (shared module)	Not specified	EXE
JPLA-14F019-AB.vbf	Multiple models (shared module)	Not specified	SBL
JPLA-14F396-AA.vbf	Multiple models (shared module)	IPMA - Image Processing Module A	EXE
JPLA-14F396-AC.vbf	Multiple models (shared module)	IPMA - Image Processing Module A	EXE
JPLA-14F397-AA.vbf	Multiple models (shared module)	IPMA - Image Processing Module A	EXE
JPLA-14F397-AB.vbf	Multiple models (shared module)	IPMA - Image Processing Module A	EXE
JPLA-14F397-AC.vbf	Multiple models (shared module)	IPMA - Image Processing Module A	EXE
JPLA-14F397-AD.vbf	Multiple models (shared module)	IPMA - Image Processing Module A	EXE
JPLA-14F397-AE.vbf	Multiple models (shared module)	IPMA - Image Processing Module A	EXE
JPLA-14F397-AF.vbf	Multiple models (shared module)	IPMA - Image Processing Module A	EXE
JPLA-14F397-AG.vbf	Multiple models (shared module)	IPMA - Image Processing Module A	EXE
JPLA-14F397-AH.vbf	Multiple models (shared module)	IPMA - Image Processing Module A	EXE
JPLA-14F397-AJ.vbf	Multiple models (shared module)	IPMA - Image Processing Module A	EXE
JPLA-14F397-AK.vbf	Multiple models (shared module)	IPMA - Image Processing Module A	EXE
JPLA-14F397-AM.vbf	Multiple models (shared module)	IPMA - Image Processing Module A	EXE
JPLA-14F397-BA.vbf	Multiple models (shared module)	IPMA - Image Processing Module A	EXE
JPLA-14F397-BB.vbf	Multiple models (shared module)	IPMA - Image Processing Module A	EXE
JPLA-14F397-BC.vbf	Multiple models (shared module)	IPMA - Image Processing Module A	EXE
JPLA-14F397-BD.vbf	Multiple models (shared module)	IPMA - Image Processing Module A	EXE
JPLA-14F397-BE.vbf	Multiple models (shared module)	IPMA - Image Processing Module A	EXE
JPLA-14F397-BF.vbf	Multiple models (shared module)	IPMA - Image Processing Module A	EXE
JPLA-14F397-BG.vbf	Multiple models (shared module)	IPMA - Image Processing Module A	EXE
JPLA-14F397-BH.vbf	Multiple models (shared module)	IPMA - Image Processing Module A	EXE
JPLA-14F397-BJ.vbf	Multiple models (shared module)	IPMA - Image Processing Module A	EXE

File name	Vehicle line (indicative)	Module (ECU)	Type
JPLA-14F397-BK.vbf	Multiple models (shared module)	IPMA - Image Processing Module A	EXE
JPLA-14F397-BM.vbf	Multiple models (shared module)	IPMA - Image Processing Module A	EXE
JPLA-14F397-CA.vbf	Multiple models (shared module)	IPMA - Image Processing Module A	EXE
JPLA-14F397-CB.vbf	Multiple models (shared module)	IPMA - Image Processing Module A	EXE
JPLA-14F397-CC.vbf	Multiple models (shared module)	IPMA - Image Processing Module A	EXE
JPLA-14F397-CD.vbf	Multiple models (shared module)	IPMA - Image Processing Module A	EXE
JPLA-14F397-CE.vbf	Multiple models (shared module)	IPMA - Image Processing Module A	EXE
JPLA-14F397-CF.vbf	Multiple models (shared module)	IPMA - Image Processing Module A	EXE
JPLA-14F397-CG.vbf	Multiple models (shared module)	IPMA - Image Processing Module A	EXE
JPLA-14F397-CH.vbf	Multiple models (shared module)	IPMA - Image Processing Module A	EXE
JPLA-14F397-CJ.vbf	Multiple models (shared module)	IPMA - Image Processing Module A	EXE
JPLA-14F397-CK.vbf	Multiple models (shared module)	IPMA - Image Processing Module A	EXE
JPLA-14F397-CM.vbf	Multiple models (shared module)	IPMA - Image Processing Module A	EXE
JPLA-14F397-DA.vbf	Multiple models (shared module)	IPMA - Image Processing Module A	EXE
JPLA-14F397-DB.vbf	Multiple models (shared module)	IPMA - Image Processing Module A	EXE
JPLA-14F397-DC.vbf	Multiple models (shared module)	IPMA - Image Processing Module A	EXE
JPLA-14F397-DD.vbf	Multiple models (shared module)	IPMA - Image Processing Module A	EXE
JPLA-14F397-DE.vbf	Multiple models (shared module)	IPMA - Image Processing Module A	EXE
JPLA-14F397-DF.vbf	Multiple models (shared module)	IPMA - Image Processing Module A	EXE
JPLA-14F397-DG.vbf	Multiple models (shared module)	IPMA - Image Processing Module A	EXE
JPLA-14F397-DH.vbf	Multiple models (shared module)	IPMA - Image Processing Module A	EXE
JPLA-14F397-DJ.vbf	Multiple models (shared module)	IPMA - Image Processing Module A	EXE
JPLA-14F397-DK.vbf	Multiple models (shared module)	IPMA - Image Processing Module A	EXE
JPLA-14F397-DM.vbf	Multiple models (shared module)	IPMA - Image Processing Module A	EXE
JPLA-14F397-EB.vbf	Multiple models (shared module)	IPMA - Image Processing Module A	EXE
JPLA-14F397-ED.vbf	Multiple models (shared module)	IPMA - Image Processing Module A	EXE
JPLA-14F397-EE.vbf	Multiple models (shared module)	IPMA - Image Processing Module A	EXE
JPLA-14F397-EF.vbf	Multiple models (shared module)	IPMA - Image Processing Module A	EXE
JPLA-14F397-EG.vbf	Multiple models (shared module)	IPMA - Image Processing Module A	EXE
JPLA-14F397-EH.vbf	Multiple models (shared module)	IPMA - Image Processing Module A	EXE
JPLA-14F397-EJ.vbf	Multiple models (shared module)	IPMA - Image Processing Module A	EXE
JPLA-14F397-EK.vbf	Multiple models (shared module)	IPMA - Image Processing Module A	EXE
JPLA-14F397-EM.vbf	Multiple models (shared module)	IPMA - Image Processing Module A	EXE
JPLA-14F397-FB.vbf	Multiple models (shared module)	IPMA - Image Processing Module A	EXE
JPLA-14F397-FD.vbf	Multiple models (shared module)	IPMA - Image Processing Module A	EXE
JPLA-14F397-FE.vbf	Multiple models (shared module)	IPMA - Image Processing Module A	EXE
JPLA-14F397-FF.vbf	Multiple models (shared module)	IPMA - Image Processing Module A	EXE
JPLA-14F397-FG.vbf	Multiple models (shared module)	IPMA - Image Processing Module A	EXE
JPLA-14F397-FH.vbf	Multiple models (shared module)	IPMA - Image Processing Module A	EXE
JPLA-14F397-FJ.vbf	Multiple models (shared module)	IPMA - Image Processing Module A	EXE
JPLA-14F397-FK.vbf	Multiple models (shared module)	IPMA - Image Processing Module A	EXE
JPLA-14F397-FM.vbf	Multiple models (shared module)	IPMA - Image Processing Module A	EXE
JPLA-14F398-AA.vbf	Multiple models (shared module)	IPMA - Image Processing Module A	EXE
JPLA-14F398-AB.vbf	Multiple models (shared module)	IPMA - Image Processing Module A	EXE
JPLA-14F398-AC.vbf	Multiple models (shared module)	IPMA - Image Processing Module A	EXE
JPLA-14F398-AD.vbf	Multiple models (shared module)	IPMA - Image Processing Module A	EXE
JPLA-14F398-AE.vbf	Multiple models (shared module)	IPMA - Image Processing Module A	EXE
JPLA-14F398-AF.vbf	Multiple models (shared module)	IPMA - Image Processing Module A	EXE
JPLA-14F398-AG.vbf	Multiple models (shared module)	IPMA - Image Processing Module A	EXE
JPLA-14F398-AH.vbf	Multiple models (shared module)	IPMA - Image Processing Module A	EXE
JPLA-14F398-AJ.vbf	Multiple models (shared module)	IPMA - Image Processing Module A	EXE
JPLA-14F398-AK.vbf	Multiple models (shared module)	IPMA - Image Processing Module A	EXE
JPLA-14F398-AM.vbf	Multiple models (shared module)	IPMA - Image Processing Module A	EXE
JPLA-14F398-BA.vbf	Multiple models (shared module)	IPMA - Image Processing Module A	EXE
JPLA-14F398-BB.vbf	Multiple models (shared module)	IPMA - Image Processing Module A	EXE
JPLA-14F398-BC.vbf	Multiple models (shared module)	IPMA - Image Processing Module A	EXE
JPLA-14F398-BD.vbf	Multiple models (shared module)	IPMA - Image Processing Module A	EXE
JPLA-14F398-BE.vbf	Multiple models (shared module)	IPMA - Image Processing Module A	EXE
JPLA-14F398-BF.vbf	Multiple models (shared module)	IPMA - Image Processing Module A	EXE
JPLA-14F398-BG.vbf	Multiple models (shared module)	IPMA - Image Processing Module A	EXE
JPLA-14F398-BH.vbf	Multiple models (shared module)	IPMA - Image Processing Module A	EXE
JPLA-14F398-BJ.vbf	Multiple models (shared module)	IPMA - Image Processing Module A	EXE
JPLA-14F398-BK.vbf	Multiple models (shared module)	IPMA - Image Processing Module A	EXE
JPLA-14F398-BM.vbf	Multiple models (shared module)	IPMA - Image Processing Module A	EXE
JPLA-14F398-CB.vbf	Multiple models (shared module)	IPMA - Image Processing Module A	EXE
JPLA-14F398-CD.vbf	Multiple models (shared module)	IPMA - Image Processing Module A	EXE
JPLA-14F398-CE.vbf	Multiple models (shared module)	IPMA - Image Processing Module A	EXE
JPLA-14F398-CF.vbf	Multiple models (shared module)	IPMA - Image Processing Module A	EXE
JPLA-14F398-CG.vbf	Multiple models (shared module)	IPMA - Image Processing Module A	EXE
JPLA-14F398-CH.vbf	Multiple models (shared module)	IPMA - Image Processing Module A	EXE
JPLA-14F398-CJ.vbf	Multiple models (shared module)	IPMA - Image Processing Module A	EXE
JPLA-14F398-CK.vbf	Multiple models (shared module)	IPMA - Image Processing Module A	EXE
JPLA-14F398-CM.vbf	Multiple models (shared module)	IPMA - Image Processing Module A	EXE
JPLA-14F434-NB.vbf	Multiple models (shared module)	CHCMB - Chassis Control Module B	EXE
JPLA-14F434-NC.vbf	Multiple models (shared module)	CHCMB - Chassis Control Module B	EXE
JPLA-14F434-ND.vbf	Multiple models (shared module)	CHCMB - Chassis Control Module B	EXE

File name	Vehicle line (indicative)	Module (ECU)	Type
JPLA-14F434-NE.vbf	Multiple models (shared module)	CHCMB - Chassis Control Module B	EXE
JPLA-14F434-NF.vbf	Multiple models (shared module)	CHCMB - Chassis Control Module B	EXE
JPLA-14F434-NG.vbf	Multiple models (shared module)	CHCMB - Chassis Control Module B	EXE
JPLA-14F434-NH.vbf	Multiple models (shared module)	CHCMB - Chassis Control Module B	EXE
JPLA-14F532-BA.vbf	Multiple models (shared module)	GWM - Gateway Module A	SBL
JPLA-14F532-BC.vbf	Multiple models (shared module)	GWM - Gateway Module A	SBL
JPLA-14F532-BD.vbf	Multiple models (shared module)	GWM - Gateway Module A	SBL
JPLA-14F532-BE.vbf	Multiple models (shared module)	GWM - Gateway Module A	SBL
JPLA-14F532-BF.vbf	Multiple models (shared module)	GWM - Gateway Module A	SBL
JPLA-14G035-AA.vbf	Multiple models (shared module)	SCMD - Seat Control Module D	EXE
JPLA-14G035-AB.vbf	Multiple models (shared module)	SCMD - Seat Control Module D	EXE
JPLA-14G036-AA.vbf	Multiple models (shared module)	SCMD - Seat Control Module D	EXE
JPLA-14G036-AB.vbf	Multiple models (shared module)	SCMD - Seat Control Module D	EXE
JPLA-14G036-AC.vbf	Multiple models (shared module)	SCMD - Seat Control Module D	EXE
JPLA-14G036-AD.vbf	Multiple models (shared module)	SCMD - Seat Control Module D	EXE
JPLA-14G036-AE.vbf	Multiple models (shared module)	SCMD - Seat Control Module D	EXE
JPLA-14G036-AF.vbf	Multiple models (shared module)	SCMD - Seat Control Module D	EXE
JPLA-14G036-AG.vbf	Multiple models (shared module)	SCMD - Seat Control Module D	EXE
JPLA-14G036-AH.vbf	Multiple models (shared module)	SCMD - Seat Control Module D	EXE
JPLA-14G036-AJ.vbf	Multiple models (shared module)	SCMD - Seat Control Module D	EXE
JPLA-14G036-AK.vbf	Multiple models (shared module)	SCMD - Seat Control Module D	EXE
JPLA-14G045-AA.vbf	Multiple models (shared module)	SCMC - Seat Control Module C	EXE
JPLA-14G045-AB.vbf	Multiple models (shared module)	SCMC - Seat Control Module C	EXE
JPLA-14G046-AA.vbf	Multiple models (shared module)	SCMC - Seat Control Module C	EXE
JPLA-14G046-AB.vbf	Multiple models (shared module)	SCMC - Seat Control Module C	EXE
JPLA-14G046-AC.vbf	Multiple models (shared module)	SCMC - Seat Control Module C	EXE
JPLA-14G046-AD.vbf	Multiple models (shared module)	SCMC - Seat Control Module C	EXE
JPLA-14G046-AE.vbf	Multiple models (shared module)	SCMC - Seat Control Module C	EXE
JPLA-14G046-AF.vbf	Multiple models (shared module)	SCMC - Seat Control Module C	EXE
JPLA-14G046-AG.vbf	Multiple models (shared module)	SCMC - Seat Control Module C	EXE
JPLA-14G046-AH.vbf	Multiple models (shared module)	SCMC - Seat Control Module C	EXE
JPLA-14G046-AJ.vbf	Multiple models (shared module)	SCMC - Seat Control Module C	EXE
JPLA-14G131-AC.vbf	X746	EPIC - Electric Power Inverter Converter Control Module	EXE
JPLA-14G131-AD.vbf	Multiple models (shared module)	EPIC - Electric Power Inverter Converter Control Module	EXE
JPLA-14G131-AF.vbf	X815	EPIC - Electric Power Inverter Converter Control Module	EXE
JPLA-14G131-AG.vbf	X819	EPIC - Electric Power Inverter Converter Control Module	EXE
JPLA-14G131-AH.vbf	X934	EPIC - Electric Power Inverter Converter Control Module	EXE
JPLA-14G131-AJ.vbf	X015	EPIC - Electric Power Inverter Converter Control Module	EXE
JPLA-14G131-AK.vbf	X030	EPIC - Electric Power Inverter Converter Control Module	EXE
JPLA-14G132-AB.vbf	X746	EPIC - Electric Power Inverter Converter Control Module	DATA
JPLA-14G132-AC.vbf	X804	EPIC - Electric Power Inverter Converter Control Module	DATA
JPLA-14G132-AE.vbf	X815	EPIC - Electric Power Inverter Converter Control Module	DATA
JPLA-14G132-AF.vbf	X819	EPIC - Electric Power Inverter Converter Control Module	DATA
JPLA-14G132-AG.vbf	X934	EPIC - Electric Power Inverter Converter Control Module	DATA
JPLA-14G132-AH.vbf	X015	EPIC - Electric Power Inverter Converter Control Module	DATA
JPLA-14G132-AJ.vbf	X030	EPIC - Electric Power Inverter Converter Control Module	DATA
JPLA-18D618-AA.vbf	Multiple models (shared module)	HVAC - HVAC Control Module	SBL
JPLA-18D618-BA.vbf	Multiple models (shared module)	HVAC - HVAC Control Module	SBL
JPLA-18D619-AA.vbf	Multiple models (shared module)	HVAC - HVAC Control Module	EXE
JPLA-18D619-BA.vbf	Multiple models (shared module)	HVAC - HVAC Control Module	EXE
JPLA-18D619-BB.vbf	Multiple models (shared module)	HVAC - HVAC Control Module	EXE
JPLA-18D619-BC.vbf	Multiple models (shared module)	HVAC - HVAC Control Module	EXE
JPLA-18D619-BD.vbf	Multiple models (shared module)	HVAC - HVAC Control Module	EXE
JPLA-18D619-BE.vbf	Multiple models (shared module)	HVAC - HVAC Control Module	EXE
JPLA-18D619-BF.vbf	Multiple models (shared module)	HVAC - HVAC Control Module	EXE
JPLA-18D619-CA.vbf	Multiple models (shared module)	HVAC - HVAC Control Module	EXE
JPLA-18D619-CB.vbf	Multiple models (shared module)	HVAC - HVAC Control Module	EXE
JPLA-19C204-AA.vbf	Multiple models (shared module)	IMC - Infotainment Master Controller	EXE
JPLA-19C226-AB.vbf	Multiple models (shared module)	ACM - Audio Front Control Module	EXE
JPLA-19C226-AC.vbf	Multiple models (shared module)	ACM - Audio Front Control Module	EXE
JPLA-19C226-CB.vbf	Multiple models (shared module)	ACM - Audio Front Control Module	DATA
JPLA-19C227-AB.vbf	Multiple models (shared module)	ACM - Audio Front Control Module	EXE
JPLA-19C227-AC.vbf	Multiple models (shared module)	ACM - Audio Front Control Module	EXE
JPLA-19C227-CB.vbf	Multiple models (shared module)	ACM - Audio Front Control Module	DATA
JPLA-19C230-AA.vbf	Multiple models (shared module)	ACM - Audio Front Control Module	SBL
JPLA-19C231-AA.vbf	Multiple models (shared module)	ACM - Audio Front Control Module	SBL
JPLA-19C263-AC.vbf	Multiple models (shared module)	FDM - Front Display Interface Module	EXE
JPLA-19C263-AD.vbf	Multiple models (shared module)	FDM - Front Display Interface Module	EXE
JPLA-19C263-AE.vbf	Multiple models (shared module)	FDM - Front Display Interface Module	EXE
JPLA-19C263-AF.vbf	Multiple models (shared module)	FDM - Front Display Interface Module	EXE
JPLA-19C263-AG.vbf	Multiple models (shared module)	FDM - Front Display Interface Module	EXE
JPLA-19C263-AJ.vbf	Multiple models (shared module)	FDM - Front Display Interface Module	EXE
JPLA-19C263-AK.vbf	Multiple models (shared module)	FDM - Front Display Interface Module	EXE
JPLA-19C263-AL.vbf	Multiple models (shared module)	FDM - Front Display Interface Module	EXE
JPLA-19C263-AN.vbf	Multiple models (shared module)	FDM - Front Display Interface Module	EXE
JPLA-19C263-BB.vbf	Multiple models (shared module)	FDM - Front Display Interface Module	EXE

File name	Vehicle line (indicative)	Module (ECU)	Type
JPLA-19C263-BC.vbf	Multiple models (shared module)	FDM - Front Display Interface Module	EXE
JPLA-19C263-BD.vbf	Multiple models (shared module)	FDM - Front Display Interface Module	EXE
JPLA-19C265-AA.vbf	Multiple models (shared module)	LPDM - Left Power Sliding Door Module	SBL
JPLA-19C273-AB.vbf	Multiple models (shared module)	LPDM - Left Power Sliding Door Module	EXE
JPLA-19C273-AC.vbf	Multiple models (shared module)	LPDM - Left Power Sliding Door Module	EXE
JPLA-19C273-AD.vbf	Multiple models (shared module)	LPDM - Left Power Sliding Door Module	EXE
JPLA-19C273-AE.vbf	Multiple models (shared module)	LPDM - Left Power Sliding Door Module	EXE
JPLA-19C273-AF.vbf	Multiple models (shared module)	LPDM - Left Power Sliding Door Module	EXE
JPLA-19C273-AG.vbf	Multiple models (shared module)	LPDM - Left Power Sliding Door Module	EXE
JPLA-19C273-AH.vbf	Multiple models (shared module)	LPDM - Left Power Sliding Door Module	EXE
JPLA-19C273-AJ.vbf	Multiple models (shared module)	LPDM - Left Power Sliding Door Module	EXE
JPLA-19C273-AL.vbf	Multiple models (shared module)	LPDM - Left Power Sliding Door Module	EXE
JPLA-19C273-AM.vbf	Multiple models (shared module)	LPDM - Left Power Sliding Door Module	EXE
JPLA-19C273-BB.vbf	Multiple models (shared module)	LPDM - Left Power Sliding Door Module	EXE
JPLA-19C273-BC.vbf	Multiple models (shared module)	LPDM - Left Power Sliding Door Module	EXE
JPLA-19C273-BD.vbf	Multiple models (shared module)	LPDM - Left Power Sliding Door Module	EXE
JPLA-19C275-AA.vbf	Multiple models (shared module)	LPDM - Left Power Sliding Door Module	SBL
JW93-12K532-PCA.vbf	Jaguar XJ (X351)	PCM - Powertrain Control Module	DATA
JW93-12K532-PCB.vbf	Jaguar XJ (X351)	PCM - Powertrain Control Module	DATA
JW93-12K532-PHA.vbf	Jaguar XJ (X351)	PCM - Powertrain Control Module	DATA
JW93-12K532-PKA.vbf	Jaguar XJ (X351)	PCM - Powertrain Control Module	DATA
JW93-12K532-PLA.vbf	Jaguar XJ (X351)	PCM - Powertrain Control Module	DATA
JW93-14C026-AA.vbf	Jaguar XJ (X351)	IPC - Instrument Panel Cluster (IPC) Control Module	EXE
JW93-14C026-AB.vbf	Jaguar XJ (X351)	IPC - Instrument Panel Cluster (IPC) Control Module	EXE
JW93-14C026-AC.vbf	Jaguar XJ (X351)	IPC - Instrument Panel Cluster (IPC) Control Module	EXE
JW93-14C026-AD.vbf	Jaguar XJ (X351)	IPC - Instrument Panel Cluster (IPC) Control Module	EXE
JW93-14C026-AF.vbf	Jaguar XJ (X351)	IPC - Instrument Panel Cluster (IPC) Control Module	EXE
JW93-14C026-BA.vbf	Jaguar XJ (X351)	IPC - Instrument Panel Cluster (IPC) Control Module	DATA
JW93-14C026-BB.vbf	Jaguar XJ (X351)	IPC - Instrument Panel Cluster (IPC) Control Module	EXE
JW93-14C026-BC.vbf	Jaguar XJ (X351)	IPC - Instrument Panel Cluster (IPC) Control Module	EXE
JW93-14C026-BD.vbf	Jaguar XJ (X351)	IPC - Instrument Panel Cluster (IPC) Control Module	EXE
JW93-14C026-CA.vbf	Jaguar XJ (X351)	IPC - Instrument Panel Cluster (IPC) Control Module	DATA
JW93-14C026-MA.vbf	Jaguar XJ (X351)	IPC - Instrument Panel Cluster (IPC) Control Module	EXE
JW93-14C026-MB.vbf	Jaguar XJ (X351)	IPC - Instrument Panel Cluster (IPC) Control Module	EXE
JW93-14C026-MC.vbf	Jaguar XJ (X351)	IPC - Instrument Panel Cluster (IPC) Control Module	EXE
JW93-14C027-AA.vbf	Jaguar XJ (X351)	RCM - Restraints Control Module	SBL
JW93-14C028-AB.VBF	Jaguar XJ (X351)	RCM - Restraints Control Module	EXE
JW93-14C028-AC.VBF	Jaguar XJ (X351)	RCM - Restraints Control Module	EXE
JW93-14C036-AA.vbf	Jaguar XJ (X351)	SPCM - Secondary Powertrain Control Module	EXE
JW93-14C036-AB.vbf	Jaguar XJ (X351)	SPCM - Secondary Powertrain Control Module	EXE
JW93-14C037-AA.vbf	Jaguar XJ (X351)	SPCM - Secondary Powertrain Control Module	DATA
JW93-14C037-BA.vbf	Jaguar XJ (X351)	SPCM - Secondary Powertrain Control Module	DATA
JW93-14C037-CA.vbf	Jaguar XJ (X351)	SPCM - Secondary Powertrain Control Module	DATA
JW93-14C037-CB.vbf	Jaguar XJ (X351)	SPCM - Secondary Powertrain Control Module	DATA
JW93-14C037-DA.vbf	Jaguar XJ (X351)	SPCM - Secondary Powertrain Control Module	DATA
JW93-14C037-DB.vbf	Jaguar XJ (X351)	SPCM - Secondary Powertrain Control Module	DATA
JW93-14C037-EA.vbf	Jaguar XJ (X351)	SPCM - Secondary Powertrain Control Module	DATA
JW93-14C037-EB.vbf	Jaguar XJ (X351)	SPCM - Secondary Powertrain Control Module	DATA
JW93-14C037-FA.vbf	Jaguar XJ (X351)	SPCM - Secondary Powertrain Control Module	DATA
JW93-14C037-FB.vbf	Jaguar XJ (X351)	SPCM - Secondary Powertrain Control Module	DATA
JW93-14C037-JA.vbf	Jaguar XJ (X351)	SPCM - Secondary Powertrain Control Module	DATA
JW93-14C037-JB.vbf	Jaguar XJ (X351)	SPCM - Secondary Powertrain Control Module	DATA
JW93-14C037-KA.vbf	Jaguar XJ (X351)	SPCM - Secondary Powertrain Control Module	DATA
JW93-14C037-KB.vbf	Jaguar XJ (X351)	SPCM - Secondary Powertrain Control Module	DATA
JW93-14C037-LA.vbf	Jaguar XJ (X351)	SPCM - Secondary Powertrain Control Module	DATA
JW93-14C037-LB.vbf	Jaguar XJ (X351)	SPCM - Secondary Powertrain Control Module	DATA
JW93-14C037-MA.vbf	Jaguar XJ (X351)	SPCM - Secondary Powertrain Control Module	DATA
JW93-14C037-MB.vbf	Jaguar XJ (X351)	SPCM - Secondary Powertrain Control Module	DATA
JW93-14C037-NA.vbf	Jaguar XJ (X351)	SPCM - Secondary Powertrain Control Module	DATA
JW93-14C037-NB.vbf	Jaguar XJ (X351)	SPCM - Secondary Powertrain Control Module	DATA
JW93-14C037-PA.vbf	Jaguar XJ (X351)	SPCM - Secondary Powertrain Control Module	DATA
JW93-14C037-PB.vbf	Jaguar XJ (X351)	SPCM - Secondary Powertrain Control Module	DATA
JW93-14C088-AA.vbf	Jaguar XJ (X351)	IPC - Instrument Panel Cluster (IPC) Control Module	DATA
JW93-14C088-AB.vbf	Jaguar XJ (X351)	IPC - Instrument Panel Cluster (IPC) Control Module	DATA
JW93-14C088-AC.vbf	Jaguar XJ (X351)	IPC - Instrument Panel Cluster (IPC) Control Module	DATA
JW93-14C088-AD.vbf	Jaguar XJ (X351)	IPC - Instrument Panel Cluster (IPC) Control Module	DATA
JW93-14C098-AB.vbf	Jaguar XJ (X351)	RCM - Restraints Control Module	DATA
JW93-14C098-AC.VBF	Jaguar XJ (X351)	RCM - Restraints Control Module	DATA
JW93-14C098-BB.VBF	Jaguar XJ (X351)	RCM - Restraints Control Module	DATA
JW93-14C098-BC.VBF	Jaguar XJ (X351)	RCM - Restraints Control Module	DATA
JW93-14C152-AA.vbf	Jaguar XJ (X351)	TPM - Tire Pressure Monitor Module	DATA
JW93-14C204-JAF.vbf	Jaguar XJ (X351)	PCM - Powertrain Control Module	EXE
JW93-14C204-JAG.vbf	Jaguar XJ (X351)	PCM - Powertrain Control Module	EXE
JW93-14C204-JCD.vbf	Jaguar XJ (X351)	PCM - Powertrain Control Module	EXE
JW93-14C204-JTF.vbf	Jaguar XJ (X351)	PCM - Powertrain Control Module	EXE
JW93-14C204-TAF.vbf	Jaguar XJ (X351)	PCM - Powertrain Control Module	EXE

File name	Vehicle line (indicative)	Module (ECU)	Type
JW93-14C204-TAG.vbf	Jaguar XJ (X351)	PCM - Powertrain Control Module	EXE
JW93-14C204-TCD.vbf	Jaguar XJ (X351)	PCM - Powertrain Control Module	EXE
JW93-14C204-TED.vbf	Jaguar XJ (X351)	PCM - Powertrain Control Module	EXE
JW93-14C204-TFA.vbf	Jaguar XJ (X351)	PCM - Powertrain Control Module	EXE
JW93-14C204-TTF.vbf	Jaguar XJ (X351)	PCM - Powertrain Control Module	EXE
JW93-14C217-AA.vbf	Jaguar XJ (X351)	PSCM - Power Steering Control Module	EXE
JW93-14C218-AA.vbf	Jaguar XJ (X351)	PSCM - Power Steering Control Module	DATA
JW93-14C218-BA.vbf	Jaguar XJ (X351)	PSCM - Power Steering Control Module	DATA
JW93-14C218-CA.vbf	Jaguar XJ (X351)	PSCM - Power Steering Control Module	DATA
JW93-14C218-DA.vbf	Jaguar XJ (X351)	PSCM - Power Steering Control Module	DATA
JW93-14C407-AB.VBF	Jaguar XJ (X351)	RCM - Restraints Control Module	SIGCFG
JW93-14C407-AC.VBF	Jaguar XJ (X351)	RCM - Restraints Control Module	SIGCFG
JW93-14C609-AA.vbf	Jaguar XJ (X351)	PSCM - Power Steering Control Module	DATA
JW93-14D367-AA.vbf	Jaguar XJ (X351)	SODL - Side Obstacle Detection Control Module - Left	SIGCFG
JW93-14D367-BA.vbf	Jaguar XJ (X351)	SODR - Side Obstacle Detection Control Module - Right	SIGCFG
JW93-14D368-AB.vbf	Jaguar XJ (X351)	SODL - Side Obstacle Detection Control Module - Left	EXE
JW93-14D368-AC.vbf	Jaguar XJ (X351)	SODL - Side Obstacle Detection Control Module - Left	EXE
JW93-14D368-BA.vbf	Jaguar XJ (X351)	SODL - Side Obstacle Detection Control Module - Left	EXE
JW93-14D368-BB.vbf	Jaguar XJ (X351)	SODL - Side Obstacle Detection Control Module - Left	EXE
JW93-14D370-AA.vbf	Jaguar XJ (X351)	SODL - Side Obstacle Detection Control Module - Left	SBL
JW93-14D564-AB.vbf	Jaguar XJ (X351)	SODL - Side Obstacle Detection Control Module - Left	DATA
JW93-14D564-BB.vbf	Jaguar XJ (X351)	SODR - Side Obstacle Detection Control Module - Right	DATA
JW93-14F022-AA.vbf	Jaguar XJ (X351)	IPMB - Image Processing Module B	DATA
JW93-14F022-AB.vbf	Jaguar XJ (X351)	IPMB - Image Processing Module B	DATA
JW93-14F022-AC.vbf	Jaguar XJ (X351)	IPMB - Image Processing Module B	DATA
JW93-14F022-BA.vbf	Jaguar XJ (X351)	IPMB - Image Processing Module B	DATA
JW93-14F022-BB.vbf	Jaguar XJ (X351)	IPMB - Image Processing Module B	DATA
JW93-14F022-BC.vbf	Jaguar XJ (X351)	IPMB - Image Processing Module B	DATA
JW93-14F397-AB.vbf	Jaguar XJ (X351)	IPMA - Image Processing Module A	EXE
JW93-14F397-AC.vbf	Jaguar XJ (X351)	IPMA - Image Processing Module A	EXE
JW93-14F397-BB.vbf	Jaguar XJ (X351)	IPMA - Image Processing Module A	EXE
JW93-14F397-BC.vbf	Jaguar XJ (X351)	IPMA - Image Processing Module A	EXE
JW93-14F397-CB.vbf	Jaguar XJ (X351)	IPMA - Image Processing Module A	EXE
JW93-14F397-CC.vbf	Jaguar XJ (X351)	IPMA - Image Processing Module A	EXE
JW93-14F397-DB.vbf	Jaguar XJ (X351)	IPMA - Image Processing Module A	EXE
JW93-14F397-DC.vbf	Jaguar XJ (X351)	IPMA - Image Processing Module A	EXE
JW93-14F398-AB.vbf	Jaguar XJ (X351)	IPMA - Image Processing Module A	EXE
JW93-14F398-AC.vbf	Jaguar XJ (X351)	IPMA - Image Processing Module A	EXE
JW93-14F398-BB.vbf	Jaguar XJ (X351)	IPMA - Image Processing Module A	EXE
JW93-14F398-BC.vbf	Jaguar XJ (X351)	IPMA - Image Processing Module A	EXE
JW93-14F530-BA.vbf	Jaguar XJ (X351)	GWM - Gateway Module A	EXE
JW93-14F531-BA.vbf	Jaguar XJ (X351)	GWM - Gateway Module A	DATA
JW93-14F531-BB.vbf	Jaguar XJ (X351)	GWM - Gateway Module A	DATA
JW93-19C204-AA.vbf	Jaguar XJ (X351)	IMC - Infotainment Master Controller	EXE
JW93-19C204-AB.vbf	Jaguar XJ (X351)	IMC - Infotainment Master Controller	EXE
JW9M-14C152-AA.vbf	Not specified	TPM - Tire Pressure Monitor Module	DATA
JW9M-14C204-ZAA.vbf	Not specified	PCM - Powertrain Control Module	EXE
JW9M-14C204-ZAB.vbf	Not specified	PCM - Powertrain Control Module	EXE
JW9M-14C204-ZCB.vbf	Not specified	PCM - Powertrain Control Module	EXE
JW9M-14C204-ZTA.vbf	Not specified	PCM - Powertrain Control Module	EXE
JW9M-14C204-ZTB.vbf	Not specified	PCM - Powertrain Control Module	EXE
JW9M-7J104-BNA.vbf	Not specified	TCM - Transmission Control Module	EXE
JW9M-7J104-BNB.vbf	Not specified	TCM - Transmission Control Module	EXE
JW9M-7J104-BND.vbf	Not specified	TCM - Transmission Control Module	EXE
JX53-14C025-AA.vbf	Jaguar F-Type (X152)	IPC - Instrument Panel Cluster (IPC) Control Module	SBL
JX53-14C026-AB.vbf	Jaguar F-Type (X152)	IPC - Instrument Panel Cluster (IPC) Control Module	EXE
JX53-14C026-AC.vbf	Jaguar F-Type (X152)	IPC - Instrument Panel Cluster (IPC) Control Module	EXE
JX53-14C026-AD.vbf	Jaguar F-Type (X152)	IPC - Instrument Panel Cluster (IPC) Control Module	EXE
JX53-14C026-ZA.vbf	Jaguar F-Type (X152)	IPC - Instrument Panel Cluster (IPC) Control Module	EXE
JX53-14C026-ZB.vbf	Jaguar F-Type (X152)	IPC - Instrument Panel Cluster (IPC) Control Module	EXE
JX53-14C026-ZC.vbf	Jaguar F-Type (X152)	IPC - Instrument Panel Cluster (IPC) Control Module	EXE
JX53-14C027-AB.vbf	Jaguar F-Type (X152)	RCM - Restraints Control Module	SBL
JX53-14C028-AB.vbf	Jaguar F-Type (X152)	SRS - Airbag	EXE
JX53-14C030-AA.vbf	Jaguar F-Type (X152)	DSM - Driver Front Seat Module	EXE
JX53-14C030-AB.vbf	Jaguar F-Type (X152)	DSM - Driver Front Seat Module	EXE
JX53-14C034-AA.vbf	Jaguar F-Type (X152)	DSM - Driver Front Seat Module	EXE
JX53-14C034-AB.vbf	Jaguar F-Type (X152)	DSM - Driver Front Seat Module	EXE
JX53-14C034-AC.vbf	Jaguar F-Type (X152)	DSM - Driver Front Seat Module	EXE
JX53-14C034-AD.vbf	Jaguar F-Type (X152)	DSM - Driver Front Seat Module	EXE
JX53-14C034-AE.vbf	Jaguar F-Type (X152)	DSM - Driver Front Seat Module	EXE
JX53-14C034-CA.vbf	Jaguar F-Type (X152)	DSM - Driver Front Seat Module	EXE
JX53-14C034-CB.vbf	Jaguar F-Type (X152)	DSM - Driver Front Seat Module	EXE
JX53-14C034-CC.vbf	Jaguar F-Type (X152)	DSM - Driver Front Seat Module	EXE
JX53-14C036-AD.vbf	Jaguar F-Type (X152)	SPCM - Secondary Powertrain Control Module	EXE
JX53-14C036-AE.vbf	Jaguar F-Type (X152)	SPCM - Secondary Powertrain Control Module	EXE
JX53-14C037-ADD.vbf	Jaguar F-Type (X152)	SPCM - Secondary Powertrain Control Module	DATA

File name	Vehicle line (indicative)	Module (ECU)	Type
JX53-14C037-AED.vbf	Jaguar F-Type (X152)	SPCM - Secondary Powertrain Control Module	DATA
JX53-14C037-AHD.vbf	Jaguar F-Type (X152)	SPCM - Secondary Powertrain Control Module	DATA
JX53-14C037-AHE.vbf	Jaguar F-Type (X152)	SPCM - Secondary Powertrain Control Module	DATA
JX53-14C037-AHF.vbf	Jaguar F-Type (X152)	SPCM - Secondary Powertrain Control Module	DATA
JX53-14C037-AHG.vbf	Jaguar F-Type (X152)	SPCM - Secondary Powertrain Control Module	DATA
JX53-14C037-AJD.vbf	Jaguar F-Type (X152)	SPCM - Secondary Powertrain Control Module	DATA
JX53-14C037-AJE.vbf	Jaguar F-Type (X152)	SPCM - Secondary Powertrain Control Module	DATA
JX53-14C037-AJF.vbf	Jaguar F-Type (X152)	SPCM - Secondary Powertrain Control Module	DATA
JX53-14C037-AJG.vbf	Jaguar F-Type (X152)	SPCM - Secondary Powertrain Control Module	DATA
JX53-14C037-AMD.vbf	Jaguar F-Type (X152)	SPCM - Secondary Powertrain Control Module	DATA
JX53-14C037-AME.vbf	Jaguar F-Type (X152)	SPCM - Secondary Powertrain Control Module	DATA
JX53-14C037-AMF.vbf	Jaguar F-Type (X152)	SPCM - Secondary Powertrain Control Module	DATA
JX53-14C037-AND.vbf	Jaguar F-Type (X152)	SPCM - Secondary Powertrain Control Module	DATA
JX53-14C037-ANE.vbf	Jaguar F-Type (X152)	SPCM - Secondary Powertrain Control Module	DATA
JX53-14C037-ANF.vbf	Jaguar F-Type (X152)	SPCM - Secondary Powertrain Control Module	DATA
JX53-14C037-APD.vbf	Jaguar F-Type (X152)	SPCM - Secondary Powertrain Control Module	DATA
JX53-14C037-APE.vbf	Jaguar F-Type (X152)	SPCM - Secondary Powertrain Control Module	DATA
JX53-14C037-APF.vbf	Jaguar F-Type (X152)	SPCM - Secondary Powertrain Control Module	DATA
JX53-14C037-ARD.vbf	Jaguar F-Type (X152)	SPCM - Secondary Powertrain Control Module	DATA
JX53-14C037-ARE.vbf	Jaguar F-Type (X152)	SPCM - Secondary Powertrain Control Module	DATA
JX53-14C037-ARF.vbf	Jaguar F-Type (X152)	SPCM - Secondary Powertrain Control Module	DATA
JX53-14C037-ASD.vbf	Jaguar F-Type (X152)	SPCM - Secondary Powertrain Control Module	DATA
JX53-14C037-ASE.vbf	Jaguar F-Type (X152)	SPCM - Secondary Powertrain Control Module	DATA
JX53-14C037-ASF.vbf	Jaguar F-Type (X152)	SPCM - Secondary Powertrain Control Module	DATA
JX53-14C037-ATD.vbf	Jaguar F-Type (X152)	SPCM - Secondary Powertrain Control Module	DATA
JX53-14C037-ATE.vbf	Jaguar F-Type (X152)	SPCM - Secondary Powertrain Control Module	DATA
JX53-14C037-ATF.vbf	Jaguar F-Type (X152)	SPCM - Secondary Powertrain Control Module	DATA
JX53-14C037-AUD.vbf	Jaguar F-Type (X152)	SPCM - Secondary Powertrain Control Module	DATA
JX53-14C037-AUE.vbf	Jaguar F-Type (X152)	SPCM - Secondary Powertrain Control Module	DATA
JX53-14C037-AUF.vbf	Jaguar F-Type (X152)	SPCM - Secondary Powertrain Control Module	DATA
JX53-14C037-AVD.vbf	Jaguar F-Type (X152)	SPCM - Secondary Powertrain Control Module	DATA
JX53-14C037-AVE.vbf	Jaguar F-Type (X152)	SPCM - Secondary Powertrain Control Module	DATA
JX53-14C037-AVF.vbf	Jaguar F-Type (X152)	SPCM - Secondary Powertrain Control Module	DATA
JX53-14C037-AYD.vbf	Jaguar F-Type (X152)	SPCM - Secondary Powertrain Control Module	DATA
JX53-14C037-AYE.vbf	Jaguar F-Type (X152)	SPCM - Secondary Powertrain Control Module	DATA
JX53-14C037-AYF.vbf	Jaguar F-Type (X152)	SPCM - Secondary Powertrain Control Module	DATA
JX53-14C037-AZD.vbf	Jaguar F-Type (X152)	SPCM - Secondary Powertrain Control Module	DATA
JX53-14C037-AZE.vbf	Jaguar F-Type (X152)	SPCM - Secondary Powertrain Control Module	DATA
JX53-14C037-AZF.vbf	Jaguar F-Type (X152)	SPCM - Secondary Powertrain Control Module	DATA
JX53-14C037-BAD.vbf	Jaguar F-Type (X152)	SPCM - Secondary Powertrain Control Module	DATA
JX53-14C037-BAE.vbf	Jaguar F-Type (X152)	SPCM - Secondary Powertrain Control Module	DATA
JX53-14C037-BAF.vbf	Jaguar F-Type (X152)	SPCM - Secondary Powertrain Control Module	DATA
JX53-14C037-BBD.vbf	Jaguar F-Type (X152)	SPCM - Secondary Powertrain Control Module	DATA
JX53-14C037-BBE.vbf	Jaguar F-Type (X152)	SPCM - Secondary Powertrain Control Module	DATA
JX53-14C037-BBF.vbf	Jaguar F-Type (X152)	SPCM - Secondary Powertrain Control Module	DATA
JX53-14C037-BCD.vbf	Jaguar F-Type (X152)	SPCM - Secondary Powertrain Control Module	DATA
JX53-14C037-BCE.vbf	Jaguar F-Type (X152)	SPCM - Secondary Powertrain Control Module	DATA
JX53-14C037-BCF.vbf	Jaguar F-Type (X152)	SPCM - Secondary Powertrain Control Module	DATA
JX53-14C037-BDD.vbf	Jaguar F-Type (X152)	SPCM - Secondary Powertrain Control Module	DATA
JX53-14C037-BDE.vbf	Jaguar F-Type (X152)	SPCM - Secondary Powertrain Control Module	DATA
JX53-14C037-BDF.vbf	Jaguar F-Type (X152)	SPCM - Secondary Powertrain Control Module	DATA
JX53-14C037-BED.vbf	Jaguar F-Type (X152)	SPCM - Secondary Powertrain Control Module	DATA
JX53-14C037-BEE.vbf	Jaguar F-Type (X152)	SPCM - Secondary Powertrain Control Module	DATA
JX53-14C037-BEF.vbf	Jaguar F-Type (X152)	SPCM - Secondary Powertrain Control Module	DATA
JX53-14C037-BFD.vbf	Jaguar F-Type (X152)	SPCM - Secondary Powertrain Control Module	DATA
JX53-14C037-BGD.vbf	Jaguar F-Type (X152)	SPCM - Secondary Powertrain Control Module	DATA
JX53-14C037-BHD.vbf	Jaguar F-Type (X152)	SPCM - Secondary Powertrain Control Module	DATA
JX53-14C037-BHE.vbf	Jaguar F-Type (X152)	SPCM - Secondary Powertrain Control Module	DATA
JX53-14C037-BHF.vbf	Jaguar F-Type (X152)	SPCM - Secondary Powertrain Control Module	DATA
JX53-14C037-BHG.vbf	Jaguar F-Type (X152)	SPCM - Secondary Powertrain Control Module	DATA
JX53-14C037-BJD.vbf	Jaguar F-Type (X152)	SPCM - Secondary Powertrain Control Module	DATA
JX53-14C037-BJE.vbf	Jaguar F-Type (X152)	SPCM - Secondary Powertrain Control Module	DATA
JX53-14C037-BJF.vbf	Jaguar F-Type (X152)	SPCM - Secondary Powertrain Control Module	DATA
JX53-14C037-BJG.vbf	Jaguar F-Type (X152)	SPCM - Secondary Powertrain Control Module	DATA
JX53-14C037-BKD.vbf	Jaguar F-Type (X152)	SPCM - Secondary Powertrain Control Module	DATA
JX53-14C037-BKE.vbf	Jaguar F-Type (X152)	SPCM - Secondary Powertrain Control Module	DATA
JX53-14C037-BKF.vbf	Jaguar F-Type (X152)	SPCM - Secondary Powertrain Control Module	DATA
JX53-14C037-BLD.vbf	Jaguar F-Type (X152)	SPCM - Secondary Powertrain Control Module	DATA
JX53-14C037-BLE.vbf	Jaguar F-Type (X152)	SPCM - Secondary Powertrain Control Module	DATA
JX53-14C037-BLF.vbf	Jaguar F-Type (X152)	SPCM - Secondary Powertrain Control Module	DATA
JX53-14C037-BVD.vbf	Jaguar F-Type (X152)	SPCM - Secondary Powertrain Control Module	DATA
JX53-14C037-BYD.vbf	Jaguar F-Type (X152)	SPCM - Secondary Powertrain Control Module	DATA
JX53-14C037-BZD.vbf	Jaguar F-Type (X152)	SPCM - Secondary Powertrain Control Module	DATA
JX53-14C037-BZE.vbf	Jaguar F-Type (X152)	SPCM - Secondary Powertrain Control Module	DATA
JX53-14C037-BZF.vbf	Jaguar F-Type (X152)	SPCM - Secondary Powertrain Control Module	DATA
JX53-14C037-CAD.vbf	Jaguar F-Type (X152)	SPCM - Secondary Powertrain Control Module	DATA

File name	Vehicle line (indicative)	Module (ECU)	Type
JX53-14C037-CAE.vbf	Jaguar F-Type (X152)	SPCM - Secondary Powertrain Control Module	DATA
JX53-14C037-CAF.vbf	Jaguar F-Type (X152)	SPCM - Secondary Powertrain Control Module	DATA
JX53-14C037-CBD.vbf	Jaguar F-Type (X152)	SPCM - Secondary Powertrain Control Module	DATA
JX53-14C037-CCD.vbf	Jaguar F-Type (X152)	SPCM - Secondary Powertrain Control Module	DATA
JX53-14C037-CDD.vbf	Jaguar F-Type (X152)	SPCM - Secondary Powertrain Control Module	DATA
JX53-14C037-CDE.vbf	Jaguar F-Type (X152)	SPCM - Secondary Powertrain Control Module	DATA
JX53-14C037-CDF.vbf	Jaguar F-Type (X152)	SPCM - Secondary Powertrain Control Module	DATA
JX53-14C037-CED.vbf	Jaguar F-Type (X152)	SPCM - Secondary Powertrain Control Module	DATA
JX53-14C037-CEE.vbf	Jaguar F-Type (X152)	SPCM - Secondary Powertrain Control Module	DATA
JX53-14C037-CEF.vbf	Jaguar F-Type (X152)	SPCM - Secondary Powertrain Control Module	DATA
JX53-14C037-CFD.vbf	Jaguar F-Type (X152)	SPCM - Secondary Powertrain Control Module	DATA
JX53-14C037-CFE.vbf	Jaguar F-Type (X152)	SPCM - Secondary Powertrain Control Module	DATA
JX53-14C037-CFF.vbf	Jaguar F-Type (X152)	SPCM - Secondary Powertrain Control Module	DATA
JX53-14C039-AB.vbf	Jaguar F-Type (X152)	SPCM - Secondary Powertrain Control Module	SBL
JX53-14C064-CA.vbf	Jaguar F-Type (X152)	DDM - Driver Front Door Module	EXE
JX53-14C064-CC.vbf	Jaguar F-Type (X152)	DDM - Driver Front Door Module	EXE
JX53-14C065-AC.vbf	Jaguar F-Type (X152)	DDM - Driver Front Door Module	DATA
JX53-14C065-AD.vbf	Jaguar F-Type (X152)	DDM - Driver Front Door Module	DATA
JX53-14C065-AF.vbf	Jaguar F-Type (X152)	DDM - Driver Front Door Module	DATA
JX53-14C065-AG.vbf	Jaguar F-Type (X152)	DDM - Driver Front Door Module	DATA
JX53-14C065-AH.vbf	Jaguar F-Type (X152)	DDM - Driver Front Door Module	DATA
JX53-14C065-BB.vbf	Jaguar F-Type (X152)	DDM - Driver Front Door Module	DATA
JX53-14C065-BC.vbf	Jaguar F-Type (X152)	DDM - Driver Front Door Module	DATA
JX53-14C065-BE.vbf	Jaguar F-Type (X152)	DDM - Driver Front Door Module	DATA
JX53-14C065-BF.vbf	Jaguar F-Type (X152)	DDM - Driver Front Door Module	DATA
JX53-14C065-BG.vbf	Jaguar F-Type (X152)	DDM - Driver Front Door Module	DATA
JX53-14C084-AA.vbf	Jaguar F-Type (X152)	HCM - Headlamp Control Module #1	EXE
JX53-14C084-AB.vbf	Jaguar F-Type (X152)	HCM - Headlamp Control Module #1	EXE
JX53-14C084-AC.vbf	Jaguar F-Type (X152)	HCM - Headlamp Control Module #1	EXE
JX53-14C084-AD.vbf	Jaguar F-Type (X152)	HCM - Headlamp Control Module #1	EXE
JX53-14C084-BA.vbf	Jaguar F-Type (X152)	Not specified	EXE
JX53-14C084-BB.vbf	Jaguar F-Type (X152)	Not specified	EXE
JX53-14C084-BC.vbf	Jaguar F-Type (X152)	Not specified	EXE
JX53-14C084-BD.vbf	Jaguar F-Type (X152)	Not specified	EXE
JX53-14C085-AA.vbf	Jaguar F-Type (X152)	HCM - Headlamp Control Module #1	DATA
JX53-14C085-AB.vbf	Jaguar F-Type (X152)	HCM - Headlamp Control Module #1	DATA
JX53-14C085-AC.vbf	Jaguar F-Type (X152)	HCM - Headlamp Control Module #1	DATA
JX53-14C085-BA.vbf	Jaguar F-Type (X152)	Not specified	DATA
JX53-14C085-BB.vbf	Jaguar F-Type (X152)	Not specified	DATA
JX53-14C085-BC.vbf	Jaguar F-Type (X152)	Not specified	DATA
JX53-14C088-CC.vbf	Jaguar F-Type (X152)	IPC - Instrument Panel Cluster (IPC) Control Module	EXE
JX53-14C088-CD.vbf	Jaguar F-Type (X152)	IPC - Instrument Panel Cluster (IPC) Control Module	EXE
JX53-14C088-WB.vbf	Jaguar F-Type (X152)	IPC - Instrument Panel Cluster (IPC) Control Module	DATA
JX53-14C088-XA.vbf	Jaguar F-Type (X152)	IPC - Instrument Panel Cluster (IPC) Control Module	EXE
JX53-14C088-XB.vbf	Jaguar F-Type (X152)	IPC - Instrument Panel Cluster (IPC) Control Module	EXE
JX53-14C088-XC.vbf	Jaguar F-Type (X152)	IPC - Instrument Panel Cluster (IPC) Control Module	EXE
JX53-14C088-YB.vbf	Jaguar F-Type (X152)	IPC - Instrument Panel Cluster (IPC) Control Module	DATA
JX53-14C091-AA.vbf	Jaguar F-Type (X152)	PAM - Parking Assist Control Module	DATA
JX53-14C091-AB.vbf	Jaguar F-Type (X152)	PAM - Parking Assist Control Module	DATA
JX53-14C091-AC.vbf	Jaguar F-Type (X152)	PAM - Parking Assist Control Module	DATA
JX53-14C098-AB.vbf	Jaguar F-Type (X152)	RCM - Restraints Control Module	DATA
JX53-14C098-BB.vbf	Jaguar F-Type (X152)	RCM - Restraints Control Module	DATA
JX53-14C098-BC.VBF	Jaguar F-Type (X152)	RCM - Restraints Control Module	DATA
JX53-14C108-CA.vbf	Jaguar F-Type (X152)	PDM - Passenger Front Door Module	EXE
JX53-14C108-CC.vbf	Jaguar F-Type (X152)	PDM - Passenger Front Door Module	EXE
JX53-14C109-AC.vbf	Jaguar F-Type (X152)	PDM - Passenger Front Door Module	DATA
JX53-14C109-AD.vbf	Jaguar F-Type (X152)	PDM - Passenger Front Door Module	DATA
JX53-14C109-AF.vbf	Jaguar F-Type (X152)	PDM - Passenger Front Door Module	DATA
JX53-14C109-AG.vbf	Jaguar F-Type (X152)	PDM - Passenger Front Door Module	DATA
JX53-14C109-AH.vbf	Jaguar F-Type (X152)	PDM - Passenger Front Door Module	DATA
JX53-14C109-BB.vbf	Jaguar F-Type (X152)	PDM - Passenger Front Door Module	DATA
JX53-14C109-BC.vbf	Jaguar F-Type (X152)	PDM - Passenger Front Door Module	DATA
JX53-14C109-BE.vbf	Jaguar F-Type (X152)	PDM - Passenger Front Door Module	DATA
JX53-14C109-BF.vbf	Jaguar F-Type (X152)	PDM - Passenger Front Door Module	DATA
JX53-14C109-BG.vbf	Jaguar F-Type (X152)	PDM - Passenger Front Door Module	DATA
JX53-14C152-AA.vbf	Jaguar F-Type (X152)	TPM - Tire Pressure Monitor Module	DATA
JX53-14C168-AA.vbf	Jaguar F-Type (X152)	PBM - Park Brake Control Module	EXE
JX53-14C185-AD.vbf	Jaguar F-Type (X152)	BCM - Body Control Module	DATA
JX53-14C185-AE.vbf	Jaguar F-Type (X152)	BCM - Body Control Module	DATA
JX53-14C185-AF.vbf	Jaguar F-Type (X152)	BCM - Body Control Module	DATA
JX53-14C204-AAA.vbf	Jaguar F-Type (X152)	PCM - Powertrain Control Module	EXE
JX53-14C204-AAC.vbf	Jaguar F-Type (X152)	PCM - Powertrain Control Module	EXE
JX53-14C204-AAD.vbf	Jaguar F-Type (X152)	PCM - Powertrain Control Module	EXE
JX53-14C204-AAE.vbf	Jaguar F-Type (X152)	PCM - Powertrain Control Module	EXE
JX53-14C204-ACA.vbf	Jaguar F-Type (X152)	PCM - Powertrain Control Module	EXE
JX53-14C204-ACB.vbf	Jaguar F-Type (X152)	PCM - Powertrain Control Module	EXE

File name	Vehicle line (indicative)	Module (ECU)	Type
JX53-14C204-ADA.vbf	Jaguar F-Type (X152)	PCM - Powertrain Control Module	EXE
JX53-14C204-ADB.vbf	Jaguar F-Type (X152)	PCM - Powertrain Control Module	EXE
JX53-14C204-ATA.vbf	Jaguar F-Type (X152)	PCM - Powertrain Control Module	EXE
JX53-14C204-ATC.vbf	Jaguar F-Type (X152)	PCM - Powertrain Control Module	EXE
JX53-14C204-ATD.vbf	Jaguar F-Type (X152)	PCM - Powertrain Control Module	EXE
JX53-14C204-BAA.vbf	Jaguar F-Type (X152)	PCM - Powertrain Control Module	EXE
JX53-14C204-BAB.vbf	Jaguar F-Type (X152)	PCM - Powertrain Control Module	EXE
JX53-14C204-BAC.vbf	Jaguar F-Type (X152)	PCM - Powertrain Control Module	EXE
JX53-14C204-BAD.vbf	Jaguar F-Type (X152)	PCM - Powertrain Control Module	EXE
JX53-14C204-BCA.vbf	Jaguar F-Type (X152)	PCM - Powertrain Control Module	EXE
JX53-14C204-BCB.vbf	Jaguar F-Type (X152)	PCM - Powertrain Control Module	EXE
JX53-14C204-BEA.vbf	Jaguar F-Type (X152)	PCM - Powertrain Control Module	EXE
JX53-14C204-BEB.vbf	Jaguar F-Type (X152)	PCM - Powertrain Control Module	EXE
JX53-14C204-BTA.vbf	Jaguar F-Type (X152)	PCM - Powertrain Control Module	EXE
JX53-14C204-BTC.vbf	Jaguar F-Type (X152)	PCM - Powertrain Control Module	EXE
JX53-14C204-BTD.vbf	Jaguar F-Type (X152)	PCM - Powertrain Control Module	EXE
JX53-14C204-CAA.vbf	Jaguar F-Type (X152)	PCM - Powertrain Control Module	EXE
JX53-14C204-CAC.vbf	Jaguar F-Type (X152)	PCM - Powertrain Control Module	EXE
JX53-14C204-CAD.vbf	Jaguar F-Type (X152)	PCM - Powertrain Control Module	EXE
JX53-14C204-CCA.vbf	Jaguar F-Type (X152)	PCM - Powertrain Control Module	EXE
JX53-14C204-CTA.vbf	Jaguar F-Type (X152)	PCM - Powertrain Control Module	EXE
JX53-14C204-CTC.vbf	Jaguar F-Type (X152)	PCM - Powertrain Control Module	EXE
JX53-14C204-EAA.vbf	Jaguar F-Type (X152)	PCM - Powertrain Control Module	EXE
JX53-14C204-EAB.vbf	Jaguar F-Type (X152)	PCM - Powertrain Control Module	EXE
JX53-14C204-ECA.vbf	Jaguar F-Type (X152)	PCM - Powertrain Control Module	EXE
JX53-14C204-ECB.vbf	Jaguar F-Type (X152)	PCM - Powertrain Control Module	EXE
JX53-14C204-ETA.vbf	Jaguar F-Type (X152)	PCM - Powertrain Control Module	EXE
JX53-14C204-ETB.vbf	Jaguar F-Type (X152)	PCM - Powertrain Control Module	EXE
JX53-14C204-MAA.vbf	Jaguar F-Type (X152)	PCM - Powertrain Control Module	EXE
JX53-14C204-MAC.vbf	Jaguar F-Type (X152)	PCM - Powertrain Control Module	EXE
JX53-14C204-MAD.vbf	Jaguar F-Type (X152)	PCM - Powertrain Control Module	EXE
JX53-14C204-MCA.vbf	Jaguar F-Type (X152)	PCM - Powertrain Control Module	EXE
JX53-14C204-MEA.vbf	Jaguar F-Type (X152)	PCM - Powertrain Control Module	EXE
JX53-14C204-MTA.vbf	Jaguar F-Type (X152)	PCM - Powertrain Control Module	EXE
JX53-14C204-MTD.vbf	Jaguar F-Type (X152)	PCM - Powertrain Control Module	EXE
JX53-14C204-TAA.vbf	Jaguar F-Type (X152)	PCM - Powertrain Control Module	EXE
JX53-14C204-TAB.vbf	Jaguar F-Type (X152)	PCM - Powertrain Control Module	EXE
JX53-14C204-TCA.vbf	Jaguar F-Type (X152)	PCM - Powertrain Control Module	EXE
JX53-14C204-TEA.vbf	Jaguar F-Type (X152)	PCM - Powertrain Control Module	EXE
JX53-14C204-TTA.vbf	Jaguar F-Type (X152)	PCM - Powertrain Control Module	EXE
JX53-14C204-TTC.vbf	Jaguar F-Type (X152)	PCM - Powertrain Control Module	EXE
JX53-14C204-UAA.vbf	Jaguar F-Type (X152)	PCM - Powertrain Control Module	EXE
JX53-14C204-UAB.vbf	Jaguar F-Type (X152)	PCM - Powertrain Control Module	EXE
JX53-14C204-UAD.vbf	Jaguar F-Type (X152)	PCM - Powertrain Control Module	EXE
JX53-14C204-UAE.vbf	Jaguar F-Type (X152)	PCM - Powertrain Control Module	EXE
JX53-14C204-UCA.vbf	Jaguar F-Type (X152)	PCM - Powertrain Control Module	EXE
JX53-14C204-UEA.vbf	Jaguar F-Type (X152)	PCM - Powertrain Control Module	EXE
JX53-14C204-UTA.vbf	Jaguar F-Type (X152)	PCM - Powertrain Control Module	EXE
JX53-14C204-UTD.vbf	Jaguar F-Type (X152)	PCM - Powertrain Control Module	EXE
JX53-14C204-XAA.vbf	Jaguar F-Type (X152)	PCM - Powertrain Control Module	EXE
JX53-14C204-XAB.vbf	Jaguar F-Type (X152)	PCM - Powertrain Control Module	EXE
JX53-14C204-XAC.vbf	Jaguar F-Type (X152)	PCM - Powertrain Control Module	EXE
JX53-14C204-XCA.vbf	Jaguar F-Type (X152)	PCM - Powertrain Control Module	EXE
JX53-14C204-XCB.vbf	Jaguar F-Type (X152)	PCM - Powertrain Control Module	EXE
JX53-14C204-XTA.vbf	Jaguar F-Type (X152)	PCM - Powertrain Control Module	EXE
JX53-14C204-XTB.vbf	Jaguar F-Type (X152)	PCM - Powertrain Control Module	EXE
JX53-14C204-YAA.vbf	Jaguar F-Type (X152)	PCM - Powertrain Control Module	EXE
JX53-14C204-YAC.vbf	Jaguar F-Type (X152)	PCM - Powertrain Control Module	EXE
JX53-14C204-YAD.vbf	Jaguar F-Type (X152)	PCM - Powertrain Control Module	EXE
JX53-14C204-YCA.vbf	Jaguar F-Type (X152)	PCM - Powertrain Control Module	EXE
JX53-14C204-YTA.vbf	Jaguar F-Type (X152)	PCM - Powertrain Control Module	EXE
JX53-14C204-YTC.vbf	Jaguar F-Type (X152)	PCM - Powertrain Control Module	EXE
JX53-14C204-ZAA.vbf	Jaguar F-Type (X152)	PCM - Powertrain Control Module	EXE
JX53-14C204-ZAB.vbf	Jaguar F-Type (X152)	PCM - Powertrain Control Module	EXE
JX53-14C204-ZAC.vbf	Jaguar F-Type (X152)	PCM - Powertrain Control Module	EXE
JX53-14C204-ZAD.vbf	Jaguar F-Type (X152)	PCM - Powertrain Control Module	EXE
JX53-14C204-ZCA.vbf	Jaguar F-Type (X152)	PCM - Powertrain Control Module	EXE
JX53-14C204-ZCB.vbf	Jaguar F-Type (X152)	PCM - Powertrain Control Module	EXE
JX53-14C204-ZEA.vbf	Jaguar F-Type (X152)	PCM - Powertrain Control Module	EXE
JX53-14C204-ZEB.vbf	Jaguar F-Type (X152)	PCM - Powertrain Control Module	EXE
JX53-14C204-ZTA.vbf	Jaguar F-Type (X152)	PCM - Powertrain Control Module	EXE
JX53-14C204-ZTB.vbf	Jaguar F-Type (X152)	PCM - Powertrain Control Module	EXE
JX53-14C204-ZTC.vbf	Jaguar F-Type (X152)	PCM - Powertrain Control Module	EXE
JX53-14C204-ZTD.vbf	Jaguar F-Type (X152)	PCM - Powertrain Control Module	EXE
JX53-14C217-AA.vbf	Jaguar F-Type (X152)	PSCM - Power Steering Control Module	EXE
JX53-14C218-AA.vbf	Jaguar F-Type (X152)	PSCM - Power Steering Control Module	DATA

File name	Vehicle line (indicative)	Module (ECU)	Type
JX53-14C218-BA.vbf	Jaguar F-Type (X152)	PSCM - Power Steering Control Module	DATA
JX53-14C218-CA.vbf	Jaguar F-Type (X152)	PSCM - Power Steering Control Module	DATA
JX53-14C399-AA.vbf	Jaguar F-Type (X152)	HCM - Headlamp Control Module #1	SIGCFG
JX53-14C399-BA.vbf	Jaguar F-Type (X152)	Not specified	SIGCFG
JX53-14C407-AB.vbf	Jaguar F-Type (X152)	SRS - Airbag	SIGCFG
JX53-14C526-BA.vbf	Jaguar F-Type (X152)	AAM - Audio Amplifier Module	EXE
JX53-14C526-CA.vbf	Jaguar F-Type (X152)	AAM - Audio Amplifier Module	EXE
JX53-14C527-BAB.vbf	Jaguar F-Type (X152)	AAM - Audio Amplifier Module	DATA
JX53-14C527-BB.vbf	Jaguar F-Type (X152)	AAM - Audio Amplifier Module	DATA
JX53-14C527-BBB.vbf	Jaguar F-Type (X152)	AAM - Audio Amplifier Module	DATA
JX53-14C527-BBC.vbf	Jaguar F-Type (X152)	AAM - Audio Amplifier Module	DATA
JX53-14C527-BC.vbf	Jaguar F-Type (X152)	AAM - Audio Amplifier Module	DATA
JX53-14C527-CAB.vbf	Jaguar F-Type (X152)	AAM - Audio Amplifier Module	DATA
JX53-14C527-CB.vbf	Jaguar F-Type (X152)	AAM - Audio Amplifier Module	DATA
JX53-14C527-CBB.vbf	Jaguar F-Type (X152)	AAM - Audio Amplifier Module	DATA
JX53-14C527-CBC.vbf	Jaguar F-Type (X152)	AAM - Audio Amplifier Module	DATA
JX53-14C527-CC.vbf	Jaguar F-Type (X152)	AAM - Audio Amplifier Module	DATA
JX53-14C527-FAB.vbf	Jaguar F-Type (X152)	AAM - Audio Amplifier Module	DATA
JX53-14C527-FB.vbf	Jaguar F-Type (X152)	AAM - Audio Amplifier Module	DATA
JX53-14C527-FBB.vbf	Jaguar F-Type (X152)	AAM - Audio Amplifier Module	DATA
JX53-14C527-FBC.vbf	Jaguar F-Type (X152)	AAM - Audio Amplifier Module	DATA
JX53-14C527-FBD.vbf	Jaguar F-Type (X152)	AAM - Audio Amplifier Module	DATA
JX53-14C527-FC.vbf	Jaguar F-Type (X152)	AAM - Audio Amplifier Module	DATA
JX53-14C527-GAB.vbf	Jaguar F-Type (X152)	AAM - Audio Amplifier Module	DATA
JX53-14C527-GB.vbf	Jaguar F-Type (X152)	AAM - Audio Amplifier Module	DATA
JX53-14C527-GBB.vbf	Jaguar F-Type (X152)	AAM - Audio Amplifier Module	DATA
JX53-14C527-GBC.vbf	Jaguar F-Type (X152)	AAM - Audio Amplifier Module	DATA
JX53-14C527-GBD.vbf	Jaguar F-Type (X152)	AAM - Audio Amplifier Module	DATA
JX53-14C527-GC.vbf	Jaguar F-Type (X152)	AAM - Audio Amplifier Module	DATA
JX53-14C534-AA.vbf	Jaguar F-Type (X152)	FCIM - Front Controls Interface Module	SIGCFG
JX53-14C535-AA.vbf	Jaguar F-Type (X152)	FCIM - Front Controls Interface Module	EXE
JX53-14C535-AB.vbf	Jaguar F-Type (X152)	FCIM - Front Controls Interface Module	EXE
JX53-14C536-AA.vbf	Jaguar F-Type (X152)	FCIM - Front Controls Interface Module	DATA
JX53-14C536-AB.vbf	Jaguar F-Type (X152)	FCIM - Front Controls Interface Module	DATA
JX53-14C537-AA.vbf	Jaguar F-Type (X152)	FCIM - Front Controls Interface Module	SBL
JX53-14C548-AA.vbf	Jaguar F-Type (X152)	PSM - Passenger Front Seat Module	EXE
JX53-14C548-AB.vbf	Jaguar F-Type (X152)	PSM - Passenger Front Seat Module	EXE
JX53-14C549-AA.vbf	Jaguar F-Type (X152)	PSM - Passenger Front Seat Module	EXE
JX53-14C549-AB.vbf	Jaguar F-Type (X152)	PSM - Passenger Front Seat Module	EXE
JX53-14C549-AC.vbf	Jaguar F-Type (X152)	PSM - Passenger Front Seat Module	EXE
JX53-14C549-AD.vbf	Jaguar F-Type (X152)	PSM - Passenger Front Seat Module	EXE
JX53-14C549-AE.vbf	Jaguar F-Type (X152)	DSM - Driver Front Seat Module	EXE
JX53-14C549-CA.vbf	Jaguar F-Type (X152)	PSM - Passenger Front Seat Module	EXE
JX53-14C549-CB.vbf	Jaguar F-Type (X152)	PSM - Passenger Front Seat Module	EXE
JX53-14C549-CC.vbf	Jaguar F-Type (X152)	DSM - Driver Front Seat Module	EXE
JX53-14C570-BGA.vbf	Jaguar F-Type (X152)	PCM - Powertrain Control Module	EXE
JX53-14C570-BGD.vbf	Jaguar F-Type (X152)	PCM - Powertrain Control Module	EXE
JX53-14C570-BGE.vbf	Jaguar F-Type (X152)	PCM - Powertrain Control Module	EXE
JX53-14C570-BGF.vbf	Jaguar F-Type (X152)	PCM - Powertrain Control Module	EXE
JX53-14C570-BGG.vbf	Jaguar F-Type (X152)	PCM - Powertrain Control Module	EXE
JX53-14C570-BGH.vbf	Jaguar F-Type (X152)	PCM - Powertrain Control Module	EXE
JX53-14C570-BLD.vbf	Jaguar F-Type (X152)	PCM - Powertrain Control Module	EXE
JX53-14C570-BLE.vbf	Jaguar F-Type (X152)	PCM - Powertrain Control Module	EXE
JX53-14C570-BLF.vbf	Jaguar F-Type (X152)	PCM - Powertrain Control Module	EXE
JX53-14C570-BLG.vbf	Jaguar F-Type (X152)	PCM - Powertrain Control Module	EXE
JX53-14C570-BND.vbf	Jaguar F-Type (X152)	PCM - Powertrain Control Module	EXE
JX53-14C570-BNE.vbf	Jaguar F-Type (X152)	PCM - Powertrain Control Module	EXE
JX53-14C570-BNF.vbf	Jaguar F-Type (X152)	PCM - Powertrain Control Module	EXE
JX53-14C570-BNG.vbf	Jaguar F-Type (X152)	PCM - Powertrain Control Module	EXE
JX53-14C570-BUA.vbf	Jaguar F-Type (X152)	PCM - Powertrain Control Module	EXE
JX53-14C570-BUD.vbf	Jaguar F-Type (X152)	PCM - Powertrain Control Module	EXE
JX53-14C570-BUE.vbf	Jaguar F-Type (X152)	PCM - Powertrain Control Module	EXE
JX53-14C570-BUF.vbf	Jaguar F-Type (X152)	PCM - Powertrain Control Module	EXE
JX53-14C570-BUG.vbf	Jaguar F-Type (X152)	PCM - Powertrain Control Module	EXE
JX53-14C570-BUH.vbf	Jaguar F-Type (X152)	PCM - Powertrain Control Module	EXE
JX53-14C572-AA.vbf	Jaguar F-Type (X152)	PCM - Powertrain Control Module	SBL
JX53-14C609-AA.vbf	Jaguar F-Type (X152)	PSCM - Power Steering Control Module	DATA
JX53-14D024-AB.vbf	Jaguar F-Type (X152)	ATCM - All Terrain Control Module	EXE
JX53-14D183-AA.vbf	Jaguar F-Type (X152)	OCS - Restraints Occupant Classification System Module	DATA
JX53-14D183-AB.vbf	Jaguar F-Type (X152)	OCS - Restraints Occupant Classification System Module	DATA
JX53-14D479-AA.vbf	Jaguar F-Type (X152)	IPMB - Image Processing Module B	SIGCFG
JX53-14D479-BB.vbf	Jaguar F-Type (X152)	IPMB - Image Processing Module B	SIGCFG
JX53-14D480-AC.vbf	Jaguar F-Type (X152)	IPMB - Image Processing Module B	EXE
JX53-14D480-AD.vbf	Jaguar F-Type (X152)	IPMB - Image Processing Module B	EXE
JX53-14D480-AE.vbf	Jaguar F-Type (X152)	IPMB - Image Processing Module B	EXE
JX53-14D480-AF.vbf	Jaguar F-Type (X152)	IPMB - Image Processing Module B	EXE

File name	Vehicle line (indicative)	Module (ECU)	Type
JX53-14D480-AG.vbf	Jaguar F-Type (X152)	IPMB - Image Processing Module B	EXE
JX53-14D480-AH.vbf	Jaguar F-Type (X152)	IPMB - Image Processing Module B	EXE
JX53-14D485-AD.vbf	Jaguar F-Type (X152)	IPMB - Image Processing Module B	EXE
JX53-14D485-AE.vbf	Jaguar F-Type (X152)	IPMB - Image Processing Module B	EXE
JX53-14D485-AF.vbf	Jaguar F-Type (X152)	IPMB - Image Processing Module B	EXE
JX53-14D485-AG.vbf	Jaguar F-Type (X152)	IPMB - Image Processing Module B	EXE
JX53-14D485-AH.vbf	Jaguar F-Type (X152)	IPMB - Image Processing Module B	EXE
JX53-14D519-AB.vbf	Jaguar F-Type (X152)	HVAC - HVAC Control Module	EXE
JX53-14D520-AB.vbf	Jaguar F-Type (X152)	HVAC - HVAC Control Module	DATA
JX53-14D520-AC.vbf	Jaguar F-Type (X152)	HVAC - HVAC Control Module	DATA
JX53-14D520-BB.vbf	Jaguar F-Type (X152)	HVAC - HVAC Control Module	DATA
JX53-14D520-BC.vbf	Jaguar F-Type (X152)	HVAC - HVAC Control Module	DATA
JX53-14D520-BD.vbf	Jaguar F-Type (X152)	HVAC - HVAC Control Module	DATA
JX53-14D564-AA.vbf	Jaguar F-Type (X152)	SODL - Side Obstacle Detection Control Module - Left	DATA
JX53-14D564-BA.vbf	Jaguar F-Type (X152)	SODR - Side Obstacle Detection Control Module - Right	DATA
JX53-14E094-DAB.vbf	Jaguar F-Type (X152)	CHCM - Chassis Control Module	EXE
JX53-14E094-DBB.vbf	Jaguar F-Type (X152)	CHCM - Chassis Control Module	EXE
JX53-14E094-DCB.vbf	Jaguar F-Type (X152)	CHCM - Chassis Control Module	EXE
JX53-14E094-DDB.vbf	Jaguar F-Type (X152)	CHCM - Chassis Control Module	EXE
JX53-14E094-DEB.vbf	Jaguar F-Type (X152)	CHCM - Chassis Control Module	EXE
JX53-14E094-DFB.vbf	Jaguar F-Type (X152)	CHCM - Chassis Control Module	EXE
JX53-14E094-DGB.vbf	Jaguar F-Type (X152)	CHCM - Chassis Control Module	EXE
JX53-14E094-DHB.vbf	Jaguar F-Type (X152)	CHCM - Chassis Control Module	EXE
JX53-14E094-DJB.vbf	Jaguar F-Type (X152)	CHCM - Chassis Control Module	EXE
JX53-14E094-DKB.vbf	Jaguar F-Type (X152)	CHCM - Chassis Control Module	EXE
JX53-14E094-DLB.vbf	Jaguar F-Type (X152)	CHCM - Chassis Control Module	EXE
JX53-14E094-DLC.vbf	Jaguar F-Type (X152)	CHCM - Chassis Control Module	EXE
JX53-14E094-DMB.vbf	Jaguar F-Type (X152)	CHCM - Chassis Control Module	EXE
JX53-14E094-DMC.vbf	Jaguar F-Type (X152)	CHCM - Chassis Control Module	EXE
JX53-14F396-AA.vbf	Jaguar F-Type (X152)	IPMA - Image Processing Module A	SIGCFG
JX53-14F397-AC.vbf	Jaguar F-Type (X152)	IPMA - Image Processing Module A	EXE
JX53-14F397-CC.vbf	Jaguar F-Type (X152)	IPMA - Image Processing Module A	EXE
JX53-14F397-CD.vbf	Jaguar F-Type (X152)	IPMA - Image Processing Module A	EXE
JX53-14F397-CE.vbf	Jaguar F-Type (X152)	IPMA - Image Processing Module A	EXE
JX53-14F397-CF.vbf	Jaguar F-Type (X152)	IPMA - Image Processing Module A	EXE
JX53-14F397-DC.vbf	Jaguar F-Type (X152)	IPMA - Image Processing Module A	EXE
JX53-14F397-DD.vbf	Jaguar F-Type (X152)	IPMA - Image Processing Module A	EXE
JX53-14F397-DE.vbf	Jaguar F-Type (X152)	IPMA - Image Processing Module A	EXE
JX53-14F397-DF.vbf	Jaguar F-Type (X152)	IPMA - Image Processing Module A	EXE
JX53-14F397-EB.vbf	Jaguar F-Type (X152)	IPMA - Image Processing Module A	EXE
JX53-14F397-EC.vbf	Jaguar F-Type (X152)	IPMA - Image Processing Module A	EXE
JX53-14F397-ED.vbf	Jaguar F-Type (X152)	IPMA - Image Processing Module A	EXE
JX53-14F397-EE.vbf	Jaguar F-Type (X152)	IPMA - Image Processing Module A	EXE
JX53-14F397-FB.vbf	Jaguar F-Type (X152)	IPMA - Image Processing Module A	EXE
JX53-14F397-FC.vbf	Jaguar F-Type (X152)	IPMA - Image Processing Module A	EXE
JX53-14F397-FD.vbf	Jaguar F-Type (X152)	IPMA - Image Processing Module A	EXE
JX53-14F397-FE.vbf	Jaguar F-Type (X152)	IPMA - Image Processing Module A	EXE
JX53-14F398-AC.vbf	Jaguar F-Type (X152)	IPMA - Image Processing Module A	DATA
JX53-14F398-CB.vbf	Jaguar F-Type (X152)	IPMA - Image Processing Module A	EXE
JX53-14F398-CC.vbf	Jaguar F-Type (X152)	IPMA - Image Processing Module A	EXE
JX53-14F398-CD.vbf	Jaguar F-Type (X152)	IPMA - Image Processing Module A	EXE
JX53-14F398-CE.vbf	Jaguar F-Type (X152)	IPMA - Image Processing Module A	EXE
JX53-14F398-DB.vbf	Jaguar F-Type (X152)	IPMA - Image Processing Module A	EXE
JX53-14F398-DC.vbf	Jaguar F-Type (X152)	IPMA - Image Processing Module A	EXE
JX53-14F398-DD.vbf	Jaguar F-Type (X152)	IPMA - Image Processing Module A	EXE
JX53-14F398-DE.vbf	Jaguar F-Type (X152)	IPMA - Image Processing Module A	EXE
JX53-14F399-AA.vbf	Jaguar F-Type (X152)	IPMA - Image Processing Module A	SBL
JX53-14F530-AB.vbf	Jaguar F-Type (X152)	GWM - Gateway Module A	EXE
JX53-14F530-BA.vbf	Jaguar F-Type (X152)	GWM - Gateway Module A	EXE
JX53-14F531-AB.vbf	Jaguar F-Type (X152)	GWM - Gateway Module A	DATA
JX53-14F531-AC.vbf	Jaguar F-Type (X152)	GWM - Gateway Module A	DATA
JX53-14F531-AD.vbf	Jaguar F-Type (X152)	GWM - Gateway Module A	DATA
JX53-14F531-BA.vbf	Jaguar F-Type (X152)	GWM - Gateway Module A	DATA
JX53-14F531-BC.vbf	Jaguar F-Type (X152)	GWM - Gateway Module A	DATA
JX53-19C204-AB.vbf	Jaguar F-Type (X152)	IMC - Infotainment Master Controller	EXE
JX53-7J104-BRA.vbf	Jaguar F-Type (X152)	TCM - Transmission Control Module	EXE
JX53-7J104-BRB.vbf	Jaguar F-Type (X152)	TCM - Transmission Control Module	EXE
JX53-7J104-BRC.vbf	Jaguar F-Type (X152)	TCM - Transmission Control Module	EXE
JX53-7J104-BRD.vbf	Jaguar F-Type (X152)	TCM - Transmission Control Module	EXE
JX53-7J104-BRF.vbf	Jaguar F-Type (X152)	TCM - Transmission Control Module	EXE
JX53-7J104-BVA.vbf	Jaguar F-Type (X152)	TCM - Transmission Control Module	EXE
JX53-7J104-BVB.vbf	Jaguar F-Type (X152)	TCM - Transmission Control Module	EXE
JX53-7J104-BVC.vbf	Jaguar F-Type (X152)	TCM - Transmission Control Module	EXE
JX5M-14C218-AA.vbf	Not specified	PSCM - Power Steering Control Module	DATA
JX5M-14E094-DAA.vbf	Not specified	CHCM - Chassis Control Module	EXE
JX5M-14E094-DBA.vbf	Not specified	CHCM - Chassis Control Module	EXE

File name	Vehicle line (indicative)	Module (ECU)	Type
JX5M-14E094-DCA.vbf	Not specified	CHCM - Chassis Control Module	EXE
JX5M-14E094-DDA.vbf	Not specified	CHCM - Chassis Control Module	EXE
JX63-12K532-FAA.vbf	Jaguar XF (X260)	PCM - Powertrain Control Module	DATA
JX63-12K532-FAB.vbf	Jaguar XF (X260)	PCM - Powertrain Control Module	DATA
JX63-12K532-FAC.vbf	Jaguar XF (X260)	PCM - Powertrain Control Module	DATA
JX63-12K532-FAD.vbf	Jaguar XF (X260)	PCM - Powertrain Control Module	DATA
JX63-12K532-FAE.vbf	Jaguar XF (X260)	PCM - Powertrain Control Module	DATA
JX63-12K532-FAF.vbf	Jaguar XF (X260)	PCM - Powertrain Control Module	DATA
JX63-12K532-FAG.vbf	Jaguar XF (X260)	PCM - Powertrain Control Module	DATA
JX63-12K532-FAH.vbf	Jaguar XF (X260)	PCM - Powertrain Control Module	DATA
JX63-12K532-FBA.vbf	Jaguar XF (X260)	PCM - Powertrain Control Module	DATA
JX63-12K532-FBB.vbf	Jaguar XF (X260)	PCM - Powertrain Control Module	DATA
JX63-12K532-FBC.vbf	Jaguar XF (X260)	PCM - Powertrain Control Module	DATA
JX63-12K532-FBD.vbf	Jaguar XF (X260)	PCM - Powertrain Control Module	DATA
JX63-12K532-FBE.vbf	Jaguar XF (X260)	PCM - Powertrain Control Module	DATA
JX63-12K532-FBF.vbf	Jaguar XF (X260)	PCM - Powertrain Control Module	DATA
JX63-12K532-FBG.vbf	Jaguar XF (X260)	PCM - Powertrain Control Module	EXE
JX63-12K532-FBH.vbf	Jaguar XF (X260)	PCM - Powertrain Control Module	DATA
JX63-12K532-FCA.vbf	Jaguar XF (X260)	PCM - Powertrain Control Module	DATA
JX63-12K532-FCB.vbf	Jaguar XF (X260)	PCM - Powertrain Control Module	DATA
JX63-12K532-FCC.vbf	Jaguar XF (X260)	PCM - Powertrain Control Module	DATA
JX63-12K532-FCD.vbf	Jaguar XF (X260)	PCM - Powertrain Control Module	DATA
JX63-12K532-FCE.vbf	Jaguar XF (X260)	PCM - Powertrain Control Module	DATA
JX63-12K532-FCG.vbf	Jaguar XF (X260)	PCM - Powertrain Control Module	DATA
JX63-12K532-FDA.vbf	Jaguar XF (X260)	PCM - Powertrain Control Module	DATA
JX63-12K532-FDB.vbf	Jaguar XF (X260)	PCM - Powertrain Control Module	DATA
JX63-12K532-FDC.vbf	Jaguar XF (X260)	PCM - Powertrain Control Module	DATA
JX63-12K532-FDD.vbf	Jaguar XF (X260)	PCM - Powertrain Control Module	DATA
JX63-12K532-FDE.vbf	Jaguar XF (X260)	PCM - Powertrain Control Module	DATA
JX63-12K532-FDG.vbf	Jaguar XF (X260)	PCM - Powertrain Control Module	DATA
JX63-12K532-FEA.vbf	Jaguar XF (X260)	PCM - Powertrain Control Module	DATA
JX63-12K532-FEB.vbf	Jaguar XF (X260)	PCM - Powertrain Control Module	DATA
JX63-12K532-FEC.vbf	Jaguar XF (X260)	PCM - Powertrain Control Module	DATA
JX63-12K532-FED.vbf	Jaguar XF (X260)	PCM - Powertrain Control Module	DATA
JX63-12K532-FEE.vbf	Jaguar XF (X260)	PCM - Powertrain Control Module	DATA
JX63-12K532-FEG.vbf	Jaguar XF (X260)	PCM - Powertrain Control Module	DATA
JX63-12K532-FFB.vbf	Jaguar XF (X260)	PCM - Powertrain Control Module	DATA
JX63-12K532-FFC.vbf	Jaguar XF (X260)	PCM - Powertrain Control Module	DATA
JX63-12K532-FFD.vbf	Jaguar XF (X260)	PCM - Powertrain Control Module	DATA
JX63-12K532-FGB.vbf	Jaguar XF (X260)	PCM - Powertrain Control Module	DATA
JX63-12K532-FGC.vbf	Jaguar XF (X260)	PCM - Powertrain Control Module	DATA
JX63-12K532-FGD.vbf	Jaguar XF (X260)	PCM - Powertrain Control Module	DATA
JX63-12K532-FHB.vbf	Jaguar XF (X260)	PCM - Powertrain Control Module	DATA
JX63-12K532-FHC.vbf	Jaguar XF (X260)	PCM - Powertrain Control Module	DATA
JX63-12K532-FHD.vbf	Jaguar XF (X260)	PCM - Powertrain Control Module	DATA
JX63-12K532-FJB.vbf	Jaguar XF (X260)	PCM - Powertrain Control Module	DATA
JX63-12K532-FJC.vbf	Jaguar XF (X260)	PCM - Powertrain Control Module	DATA
JX63-12K532-FJD.vbf	Jaguar XF (X260)	PCM - Powertrain Control Module	DATA
JX63-12K532-FKA.vbf	Jaguar XF (X260)	PCM - Powertrain Control Module	DATA
JX63-12K532-FKB.vbf	Jaguar XF (X260)	PCM - Powertrain Control Module	DATA
JX63-12K532-FKC.vbf	Jaguar XF (X260)	PCM - Powertrain Control Module	DATA
JX63-12K532-FLA.vbf	Jaguar XF (X260)	PCM - Powertrain Control Module	DATA
JX63-12K532-FLB.vbf	Jaguar XF (X260)	PCM - Powertrain Control Module	DATA
JX63-12K532-FLD.vbf	Jaguar XF (X260)	PCM - Powertrain Control Module	DATA
JX63-12K532-FLF.vbf	Jaguar XF (X260)	PCM - Powertrain Control Module	DATA
JX63-12K532-FLG.vbf	Jaguar XF (X260)	PCM - Powertrain Control Module	DATA
JX63-12K532-FLH.vbf	Jaguar XF (X260)	PCM - Powertrain Control Module	DATA
JX63-12K532-FMA.vbf	Jaguar XF (X260)	PCM - Powertrain Control Module	DATA
JX63-12K532-FMB.vbf	Jaguar XF (X260)	PCM - Powertrain Control Module	DATA
JX63-12K532-FMD.vbf	Jaguar XF (X260)	PCM - Powertrain Control Module	DATA
JX63-12K532-FMF.vbf	Jaguar XF (X260)	PCM - Powertrain Control Module	DATA
JX63-12K532-FMG.vbf	Jaguar XF (X260)	PCM - Powertrain Control Module	DATA
JX63-12K532-FMH.vbf	Jaguar XF (X260)	PCM - Powertrain Control Module	DATA
JX63-12K532-FNA.vbf	Jaguar XF (X260)	PCM - Powertrain Control Module	DATA
JX63-12K532-FNB.vbf	Jaguar XF (X260)	PCM - Powertrain Control Module	DATA
JX63-12K532-FNC.vbf	Jaguar XF (X260)	PCM - Powertrain Control Module	DATA
JX63-12K532-FNE.vbf	Jaguar XF (X260)	PCM - Powertrain Control Module	DATA
JX63-12K532-FPC.vbf	Jaguar XF (X260)	PCM - Powertrain Control Module	DATA
JX63-12K532-FPD.vbf	Jaguar XF (X260)	PCM - Powertrain Control Module	DATA
JX63-12K532-FRC.vbf	Jaguar XF (X260)	PCM - Powertrain Control Module	DATA
JX63-12K532-FSC.vbf	Jaguar XF (X260)	PCM - Powertrain Control Module	DATA
JX63-12K532-FSD.vbf	Jaguar XF (X260)	PCM - Powertrain Control Module	DATA
JX63-12K532-FTC.vbf	Jaguar XF (X260)	PCM - Powertrain Control Module	DATA
JX63-12K532-FTE.vbf	Jaguar XF (X260)	PCM - Powertrain Control Module	DATA
JX63-12K532-GAA.vbf	Jaguar XF (X260)	PCM - Powertrain Control Module	DATA
JX63-12K532-GAB.vbf	Jaguar XF (X260)	PCM - Powertrain Control Module	DATA

File name	Vehicle line (indicative)	Module (ECU)	Type
JX63-12K532-GAC.vbf	Jaguar XF (X260)	PCM - Powertrain Control Module	DATA
JX63-12K532-GAD.vbf	Jaguar XF (X260)	PCM - Powertrain Control Module	DATA
JX63-12K532-GAE.vbf	Jaguar XF (X260)	PCM - Powertrain Control Module	DATA
JX63-12K532-GAF.vbf	Jaguar XF (X260)	PCM - Powertrain Control Module	DATA
JX63-12K532-GAG.vbf	Jaguar XF (X260)	PCM - Powertrain Control Module	DATA
JX63-12K532-GBA.vbf	Jaguar XF (X260)	PCM - Powertrain Control Module	DATA
JX63-12K532-GBB.vbf	Jaguar XF (X260)	PCM - Powertrain Control Module	DATA
JX63-12K532-GBC.vbf	Jaguar XF (X260)	PCM - Powertrain Control Module	DATA
JX63-12K532-GBD.vbf	Jaguar XF (X260)	PCM - Powertrain Control Module	DATA
JX63-12K532-GBE.vbf	Jaguar XF (X260)	PCM - Powertrain Control Module	DATA
JX63-12K532-GBF.vbf	Jaguar XF (X260)	PCM - Powertrain Control Module	DATA
JX63-12K532-GDB.vbf	Jaguar XF (X260)	PCM - Powertrain Control Module	DATA
JX63-12K532-GDC.vbf	Jaguar XF (X260)	PCM - Powertrain Control Module	DATA
JX63-12K532-GEB.vbf	Jaguar XF (X260)	PCM - Powertrain Control Module	DATA
JX63-12K532-GEC.vbf	Jaguar XF (X260)	PCM - Powertrain Control Module	DATA
JX63-12K532-GED.vbf	Jaguar XF (X260)	PCM - Powertrain Control Module	DATA
JX63-12K532-GEE.vbf	Jaguar XF (X260)	PCM - Powertrain Control Module	DATA
JX63-12K532-GEF.vbf	Jaguar XF (X260)	PCM - Powertrain Control Module	DATA
JX63-12K532-GEG.vbf	Jaguar XF (X260)	PCM - Powertrain Control Module	DATA
JX63-12K532-PMB.vbf	Jaguar XF (X260)	PCM - Powertrain Control Module	DATA
JX63-12K532-PMD.vbf	Jaguar XF (X260)	PCM - Powertrain Control Module	DATA
JX63-12K532-PNB.vbf	Jaguar XF (X260)	PCM - Powertrain Control Module	DATA
JX63-12K532-PNC.vbf	Jaguar XF (X260)	PCM - Powertrain Control Module	DATA
JX63-12K532-PNE.vbf	Jaguar XF (X260)	PCM - Powertrain Control Module	DATA
JX63-12K532-PNF.vbf	Jaguar XF (X260)	PCM - Powertrain Control Module	DATA
JX63-12K532-PNG.vbf	Jaguar XF (X260)	PCM - Powertrain Control Module	DATA
JX63-14C025-AA.vbf	Jaguar XF (X260)	IPC - Instrument Panel Cluster (IPC) Control Module	SBL
JX63-14C026-AA.vbf	Jaguar XF (X260)	IPC - Instrument Panel Cluster (IPC) Control Module	EXE
JX63-14C026-AB.vbf	Jaguar XF (X260)	IPC - Instrument Panel Cluster (IPC) Control Module	EXE
JX63-14C026-AC.vbf	Jaguar XF (X260)	IPC - Instrument Panel Cluster (IPC) Control Module	EXE
JX63-14C026-AD.vbf	Jaguar XF (X260)	IPC - Instrument Panel Cluster (IPC) Control Module	EXE
JX63-14C026-AE.vbf	Jaguar XF (X260)	AUM - Audio Module	EXE
JX63-14C037-AAE.vbf	Jaguar XF (X260)	ABS - Anti-Lock Brake System Control Module	DATA
JX63-14C037-AAF.vbf	Jaguar XF (X260)	ABS - Anti-Lock Brake System Control Module	DATA
JX63-14C037-AAG.vbf	Jaguar XF (X260)	ABS - Anti-Lock Brake System Control Module	DATA
JX63-14C037-ABC.vbf	Jaguar XF (X260)	ABS - Anti-Lock Brake System Control Module	DATA
JX63-14C037-ABE.vbf	Jaguar XF (X260)	ABS - Anti-Lock Brake System Control Module	DATA
JX63-14C037-ABF.vbf	Jaguar XF (X260)	ABS - Anti-Lock Brake System Control Module	DATA
JX63-14C037-ABG.vbf	Jaguar XF (X260)	ABS - Anti-Lock Brake System Control Module	DATA
JX63-14C037-ACC.vbf	Jaguar XF (X260)	ABS - Anti-Lock Brake System Control Module	DATA
JX63-14C037-ACE.vbf	Jaguar XF (X260)	ABS - Anti-Lock Brake System Control Module	DATA
JX63-14C037-ACF.vbf	Jaguar XF (X260)	ABS - Anti-Lock Brake System Control Module	DATA
JX63-14C037-ACG.vbf	Jaguar XF (X260)	ABS - Anti-Lock Brake System Control Module	DATA
JX63-14C037-ADC.vbf	Jaguar XF (X260)	ABS - Anti-Lock Brake System Control Module	DATA
JX63-14C037-ADE.vbf	Jaguar XF (X260)	ABS - Anti-Lock Brake System Control Module	DATA
JX63-14C037-ADF.vbf	Jaguar XF (X260)	ABS - Anti-Lock Brake System Control Module	DATA
JX63-14C037-ADG.vbf	Jaguar XF (X260)	ABS - Anti-Lock Brake System Control Module	DATA
JX63-14C037-AED.vbf	Jaguar XF (X260)	ABS - Anti-Lock Brake System Control Module	DATA
JX63-14C037-AEE.vbf	Jaguar XF (X260)	ABS - Anti-Lock Brake System Control Module	DATA
JX63-14C037-AEG.vbf	Jaguar XF (X260)	ABS - Anti-Lock Brake System Control Module	DATA
JX63-14C037-AFE.vbf	Jaguar XF (X260)	ABS - Anti-Lock Brake System Control Module	DATA
JX63-14C037-AFG.vbf	Jaguar XF (X260)	ABS - Anti-Lock Brake System Control Module	DATA
JX63-14C037-AGC.vbf	Jaguar XF (X260)	ABS - Anti-Lock Brake System Control Module	DATA
JX63-14C037-AGE.vbf	Jaguar XF (X260)	ABS - Anti-Lock Brake System Control Module	DATA
JX63-14C037-AGF.vbf	Jaguar XF (X260)	ABS - Anti-Lock Brake System Control Module	DATA
JX63-14C037-AGG.vbf	Jaguar XF (X260)	ABS - Anti-Lock Brake System Control Module	DATA
JX63-14C037-AHE.vbf	Jaguar XF (X260)	ABS - Anti-Lock Brake System Control Module	DATA
JX63-14C037-AHF.vbf	Jaguar XF (X260)	ABS - Anti-Lock Brake System Control Module	DATA
JX63-14C037-AHG.vbf	Jaguar XF (X260)	ABS - Anti-Lock Brake System Control Module	DATA
JX63-14C037-AJE.vbf	Jaguar XF (X260)	ABS - Anti-Lock Brake System Control Module	DATA
JX63-14C037-AJF.vbf	Jaguar XF (X260)	ABS - Anti-Lock Brake System Control Module	DATA
JX63-14C037-AJG.vbf	Jaguar XF (X260)	ABS - Anti-Lock Brake System Control Module	DATA
JX63-14C037-AKE.vbf	Jaguar XF (X260)	ABS - Anti-Lock Brake System Control Module	DATA
JX63-14C037-AKF.vbf	Jaguar XF (X260)	ABS - Anti-Lock Brake System Control Module	DATA
JX63-14C037-AKG.vbf	Jaguar XF (X260)	ABS - Anti-Lock Brake System Control Module	DATA
JX63-14C037-ALE.vbf	Jaguar XF (X260)	ABS - Anti-Lock Brake System Control Module	DATA
JX63-14C037-AMC.vbf	Jaguar XF (X260)	ABS - Anti-Lock Brake System Control Module	DATA
JX63-14C037-AME.vbf	Jaguar XF (X260)	ABS - Anti-Lock Brake System Control Module	DATA
JX63-14C037-AMF.vbf	Jaguar XF (X260)	ABS - Anti-Lock Brake System Control Module	DATA
JX63-14C037-AMG.vbf	Jaguar XF (X260)	ABS - Anti-Lock Brake System Control Module	DATA
JX63-14C037-ANC.vbf	Jaguar XF (X260)	ABS - Anti-Lock Brake System Control Module	DATA
JX63-14C037-ANE.vbf	Jaguar XF (X260)	ABS - Anti-Lock Brake System Control Module	DATA
JX63-14C037-ANF.vbf	Jaguar XF (X260)	ABS - Anti-Lock Brake System Control Module	DATA
JX63-14C037-ANG.vbf	Jaguar XF (X260)	ABS - Anti-Lock Brake System Control Module	DATA
JX63-14C037-APE.vbf	Jaguar XF (X260)	ABS - Anti-Lock Brake System Control Module	DATA
JX63-14C037-APF.vbf	Jaguar XF (X260)	ABS - Anti-Lock Brake System Control Module	DATA

File name	Vehicle line (indicative)	Module (ECU)	Type
JX63-14C037-APG.vbf	Jaguar XF (X260)	ABS - Anti-Lock Brake System Control Module	DATA
JX63-14C037-ARE.vbf	Jaguar XF (X260)	ABS - Anti-Lock Brake System Control Module	DATA
JX63-14C037-ARF.vbf	Jaguar XF (X260)	ABS - Anti-Lock Brake System Control Module	DATA
JX63-14C037-ARG.vbf	Jaguar XF (X260)	ABS - Anti-Lock Brake System Control Module	DATA
JX63-14C037-ASC.vbf	Jaguar XF (X260)	ABS - Anti-Lock Brake System Control Module	DATA
JX63-14C037-ASE.vbf	Jaguar XF (X260)	ABS - Anti-Lock Brake System Control Module	DATA
JX63-14C037-ASF.vbf	Jaguar XF (X260)	ABS - Anti-Lock Brake System Control Module	DATA
JX63-14C037-ASG.vbf	Jaguar XF (X260)	ABS - Anti-Lock Brake System Control Module	DATA
JX63-14C037-ATE.vbf	Jaguar XF (X260)	ABS - Anti-Lock Brake System Control Module	DATA
JX63-14C037-ATF.vbf	Jaguar XF (X260)	ABS - Anti-Lock Brake System Control Module	DATA
JX63-14C037-ATG.vbf	Jaguar XF (X260)	ABS - Anti-Lock Brake System Control Module	DATA
JX63-14C037-AUE.vbf	Jaguar XF (X260)	ABS - Anti-Lock Brake System Control Module	DATA
JX63-14C037-AUF.vbf	Jaguar XF (X260)	ABS - Anti-Lock Brake System Control Module	DATA
JX63-14C037-AUG.vbf	Jaguar XF (X260)	ABS - Anti-Lock Brake System Control Module	DATA
JX63-14C037-AVC.vbf	Jaguar XF (X260)	ABS - Anti-Lock Brake System Control Module	DATA
JX63-14C037-AVE.vbf	Jaguar XF (X260)	ABS - Anti-Lock Brake System Control Module	DATA
JX63-14C037-AVF.vbf	Jaguar XF (X260)	ABS - Anti-Lock Brake System Control Module	DATA
JX63-14C037-AVG.vbf	Jaguar XF (X260)	ABS - Anti-Lock Brake System Control Module	DATA
JX63-14C037-AXE.vbf	Jaguar XF (X260)	ABS - Anti-Lock Brake System Control Module	DATA
JX63-14C037-AXF.vbf	Jaguar XF (X260)	ABS - Anti-Lock Brake System Control Module	DATA
JX63-14C037-AXG.vbf	Jaguar XF (X260)	ABS - Anti-Lock Brake System Control Module	DATA
JX63-14C037-AYE.vbf	Jaguar XF (X260)	ABS - Anti-Lock Brake System Control Module	DATA
JX63-14C037-AYF.vbf	Jaguar XF (X260)	ABS - Anti-Lock Brake System Control Module	DATA
JX63-14C037-AYG.vbf	Jaguar XF (X260)	ABS - Anti-Lock Brake System Control Module	DATA
JX63-14C037-AZE.vbf	Jaguar XF (X260)	ABS - Anti-Lock Brake System Control Module	DATA
JX63-14C037-AZF.vbf	Jaguar XF (X260)	ABS - Anti-Lock Brake System Control Module	DATA
JX63-14C037-AZG.vbf	Jaguar XF (X260)	ABS - Anti-Lock Brake System Control Module	DATA
JX63-14C037-BAC.vbf	Jaguar XF (X260)	ABS - Anti-Lock Brake System Control Module	DATA
JX63-14C037-BAE.vbf	Jaguar XF (X260)	ABS - Anti-Lock Brake System Control Module	DATA
JX63-14C037-BAF.vbf	Jaguar XF (X260)	ABS - Anti-Lock Brake System Control Module	DATA
JX63-14C037-BAG.vbf	Jaguar XF (X260)	ABS - Anti-Lock Brake System Control Module	DATA
JX63-14C037-MAE.vbf	Jaguar XF (X260)	ABS - Anti-Lock Brake System Control Module	DATA
JX63-14C037-MAF.vbf	Jaguar XF (X260)	ABS - Anti-Lock Brake System Control Module	DATA
JX63-14C037-MAG.vbf	Jaguar XF (X260)	ABS - Anti-Lock Brake System Control Module	DATA
JX63-14C037-MBC.vbf	Jaguar XF (X260)	ABS - Anti-Lock Brake System Control Module	DATA
JX63-14C037-MBE.vbf	Jaguar XF (X260)	ABS - Anti-Lock Brake System Control Module	DATA
JX63-14C037-MBF.vbf	Jaguar XF (X260)	ABS - Anti-Lock Brake System Control Module	DATA
JX63-14C037-MBG.vbf	Jaguar XF (X260)	ABS - Anti-Lock Brake System Control Module	DATA
JX63-14C037-MCC.vbf	Jaguar XF (X260)	ABS - Anti-Lock Brake System Control Module	DATA
JX63-14C037-MCE.vbf	Jaguar XF (X260)	ABS - Anti-Lock Brake System Control Module	DATA
JX63-14C037-MCF.vbf	Jaguar XF (X260)	ABS - Anti-Lock Brake System Control Module	DATA
JX63-14C037-MCG.vbf	Jaguar XF (X260)	ABS - Anti-Lock Brake System Control Module	DATA
JX63-14C037-MDC.vbf	Jaguar XF (X260)	ABS - Anti-Lock Brake System Control Module	DATA
JX63-14C037-MDE.vbf	Jaguar XF (X260)	ABS - Anti-Lock Brake System Control Module	DATA
JX63-14C037-MDF.vbf	Jaguar XF (X260)	ABS - Anti-Lock Brake System Control Module	DATA
JX63-14C037-MDG.vbf	Jaguar XF (X260)	ABS - Anti-Lock Brake System Control Module	DATA
JX63-14C037-MEE.vbf	Jaguar XF (X260)	ABS - Anti-Lock Brake System Control Module	DATA
JX63-14C037-MEG.vbf	Jaguar XF (X260)	ABS - Anti-Lock Brake System Control Module	DATA
JX63-14C037-MFE.vbf	Jaguar XF (X260)	ABS - Anti-Lock Brake System Control Module	DATA
JX63-14C037-MFG.vbf	Jaguar XF (X260)	ABS - Anti-Lock Brake System Control Module	DATA
JX63-14C037-MGE.vbf	Jaguar XF (X260)	ABS - Anti-Lock Brake System Control Module	DATA
JX63-14C037-MGF.vbf	Jaguar XF (X260)	ABS - Anti-Lock Brake System Control Module	DATA
JX63-14C037-MGG.vbf	Jaguar XF (X260)	ABS - Anti-Lock Brake System Control Module	DATA
JX63-14C037-MHE.vbf	Jaguar XF (X260)	ABS - Anti-Lock Brake System Control Module	DATA
JX63-14C037-MHF.vbf	Jaguar XF (X260)	ABS - Anti-Lock Brake System Control Module	DATA
JX63-14C037-MHG.vbf	Jaguar XF (X260)	ABS - Anti-Lock Brake System Control Module	DATA
JX63-14C037-MJE.vbf	Jaguar XF (X260)	ABS - Anti-Lock Brake System Control Module	DATA
JX63-14C037-MJF.vbf	Jaguar XF (X260)	ABS - Anti-Lock Brake System Control Module	DATA
JX63-14C037-MJG.vbf	Jaguar XF (X260)	ABS - Anti-Lock Brake System Control Module	DATA
JX63-14C037-MKE.vbf	Jaguar XF (X260)	ABS - Anti-Lock Brake System Control Module	DATA
JX63-14C037-MKF.vbf	Jaguar XF (X260)	ABS - Anti-Lock Brake System Control Module	DATA
JX63-14C037-MKG.vbf	Jaguar XF (X260)	ABS - Anti-Lock Brake System Control Module	DATA
JX63-14C037-MMG.vbf	Jaguar XF (X260)	ABS - Anti-Lock Brake System Control Module	DATA
JX63-14C037-MNE.vbf	Jaguar XF (X260)	ABS - Anti-Lock Brake System Control Module	DATA
JX63-14C037-MNF.vbf	Jaguar XF (X260)	ABS - Anti-Lock Brake System Control Module	DATA
JX63-14C037-MNG.vbf	Jaguar XF (X260)	ABS - Anti-Lock Brake System Control Module	DATA
JX63-14C037-MPC.vbf	Jaguar XF (X260)	ABS - Anti-Lock Brake System Control Module	DATA
JX63-14C037-MPE.vbf	Jaguar XF (X260)	ABS - Anti-Lock Brake System Control Module	DATA
JX63-14C037-MPF.vbf	Jaguar XF (X260)	ABS - Anti-Lock Brake System Control Module	DATA
JX63-14C037-MPG.vbf	Jaguar XF (X260)	ABS - Anti-Lock Brake System Control Module	DATA
JX63-14C037-MRC.vbf	Jaguar XF (X260)	ABS - Anti-Lock Brake System Control Module	DATA
JX63-14C037-MRE.vbf	Jaguar XF (X260)	ABS - Anti-Lock Brake System Control Module	DATA
JX63-14C037-MRF.vbf	Jaguar XF (X260)	ABS - Anti-Lock Brake System Control Module	DATA
JX63-14C037-MRG.vbf	Jaguar XF (X260)	ABS - Anti-Lock Brake System Control Module	DATA
JX63-14C037-MSE.vbf	Jaguar XF (X260)	ABS - Anti-Lock Brake System Control Module	DATA
JX63-14C037-MSF.vbf	Jaguar XF (X260)	ABS - Anti-Lock Brake System Control Module	DATA

File name	Vehicle line (indicative)	Module (ECU)	Type
JX63-14C037-MSG.vbf	Jaguar XF (X260)	ABS - Anti-Lock Brake System Control Module	DATA
JX63-14C037-MTC.vbf	Jaguar XF (X260)	ABS - Anti-Lock Brake System Control Module	DATA
JX63-14C037-MTE.vbf	Jaguar XF (X260)	ABS - Anti-Lock Brake System Control Module	DATA
JX63-14C037-MTF.vbf	Jaguar XF (X260)	ABS - Anti-Lock Brake System Control Module	DATA
JX63-14C037-MTG.vbf	Jaguar XF (X260)	ABS - Anti-Lock Brake System Control Module	DATA
JX63-14C037-MUD.vbf	Jaguar XF (X260)	ABS - Anti-Lock Brake System Control Module	DATA
JX63-14C037-MUE.vbf	Jaguar XF (X260)	ABS - Anti-Lock Brake System Control Module	DATA
JX63-14C037-MUF.vbf	Jaguar XF (X260)	ABS - Anti-Lock Brake System Control Module	DATA
JX63-14C037-MUG.vbf	Jaguar XF (X260)	ABS - Anti-Lock Brake System Control Module	DATA
JX63-14C037-MVC.vbf	Jaguar XF (X260)	ABS - Anti-Lock Brake System Control Module	DATA
JX63-14C037-MVD.vbf	Jaguar XF (X260)	ABS - Anti-Lock Brake System Control Module	DATA
JX63-14C037-MVE.vbf	Jaguar XF (X260)	ABS - Anti-Lock Brake System Control Module	DATA
JX63-14C037-MVF.vbf	Jaguar XF (X260)	ABS - Anti-Lock Brake System Control Module	DATA
JX63-14C037-MVG.vbf	Jaguar XF (X260)	ABS - Anti-Lock Brake System Control Module	DATA
JX63-14C037-MXE.vbf	Jaguar XF (X260)	ABS - Anti-Lock Brake System Control Module	DATA
JX63-14C037-MXF.vbf	Jaguar XF (X260)	ABS - Anti-Lock Brake System Control Module	DATA
JX63-14C037-MXG.vbf	Jaguar XF (X260)	ABS - Anti-Lock Brake System Control Module	DATA
JX63-14C037-MYE.vbf	Jaguar XF (X260)	ABS - Anti-Lock Brake System Control Module	DATA
JX63-14C037-MYF.vbf	Jaguar XF (X260)	ABS - Anti-Lock Brake System Control Module	DATA
JX63-14C037-MYG.vbf	Jaguar XF (X260)	ABS - Anti-Lock Brake System Control Module	DATA
JX63-14C037-MZC.vbf	Jaguar XF (X260)	ABS - Anti-Lock Brake System Control Module	DATA
JX63-14C037-MZD.vbf	Jaguar XF (X260)	ABS - Anti-Lock Brake System Control Module	DATA
JX63-14C037-MZE.vbf	Jaguar XF (X260)	ABS - Anti-Lock Brake System Control Module	DATA
JX63-14C037-MZF.vbf	Jaguar XF (X260)	ABS - Anti-Lock Brake System Control Module	DATA
JX63-14C037-MZG.vbf	Jaguar XF (X260)	ABS - Anti-Lock Brake System Control Module	DATA
JX63-14C037-NAC.vbf	Jaguar XF (X260)	ABS - Anti-Lock Brake System Control Module	DATA
JX63-14C037-NAE.vbf	Jaguar XF (X260)	ABS - Anti-Lock Brake System Control Module	DATA
JX63-14C037-NAF.vbf	Jaguar XF (X260)	ABS - Anti-Lock Brake System Control Module	DATA
JX63-14C037-NAG.vbf	Jaguar XF (X260)	ABS - Anti-Lock Brake System Control Module	DATA
JX63-14C065-BA.vbf	Jaguar XF (X260)	DDM - Driver Front Door Module	DATA
JX63-14C065-BD.vbf	Jaguar XF (X260)	DDM - Driver Front Door Module	DATA
JX63-14C065-BE.vbf	Jaguar XF (X260)	DDM - Driver Front Door Module	DATA
JX63-14C065-BF.vbf	Jaguar XF (X260)	DDM - Driver Front Door Module	DATA
JX63-14C065-BG.vbf	Jaguar XF (X260)	DDM - Driver Front Door Module	DATA
JX63-14C069-BA.vbf	Jaguar XF (X260)	DRDM - Driver Rear Door Module	DATA
JX63-14C069-BD.vbf	Jaguar XF (X260)	DRDM - Driver Rear Door Module	DATA
JX63-14C069-BE.vbf	Jaguar XF (X260)	DRDM - Driver Rear Door Module	DATA
JX63-14C069-BF.vbf	Jaguar XF (X260)	DRDM - Driver Rear Door Module	DATA
JX63-14C069-BG.vbf	Jaguar XF (X260)	DRDM - Driver Rear Door Module	DATA
JX63-14C088-BB.vbf	Jaguar XF (X260)	IPC - Instrument Panel Cluster (IPC) Control Module	DATA
JX63-14C088-BC.vbf	Jaguar XF (X260)	IPC - Instrument Panel Cluster (IPC) Control Module	DATA
JX63-14C088-CA.vbf	Jaguar XF (X260)	IPC - Instrument Panel Cluster (IPC) Control Module	EXE
JX63-14C088-CB.vbf	Jaguar XF (X260)	IPC - Instrument Panel Cluster (IPC) Control Module	EXE
JX63-14C088-CC.vbf	Jaguar XF (X260)	IPC - Instrument Panel Cluster (IPC) Control Module	EXE
JX63-14C088-CD.vbf	Jaguar XF (X260)	IPC - Instrument Panel Cluster (IPC) Control Module	EXE
JX63-14C088-CE.vbf	Jaguar XF (X260)	IPC - Instrument Panel Cluster (IPC) Control Module	EXE
JX63-14C088-CF.vbf	Jaguar XF (X260)	AUM - Audio Module	EXE
JX63-14C105-AA.vbf	Jaguar XF (X260)	TMC Traffic Message Channel Module	DATA
JX63-14C105-AD.vbf	Jaguar XF (X260)	TMC Traffic Message Channel Module	DATA
JX63-14C105-AG.vbf	Jaguar XF (X260)	TMC Traffic Message Channel Module	DATA
JX63-14C105-BC.vbf	Jaguar XF (X260)	TMC Traffic Message Channel Module	DATA
JX63-14C105-BE.vbf	Jaguar XF (X260)	TMC Traffic Message Channel Module	DATA
JX63-14C109-BA.vbf	Jaguar XF (X260)	PDM - Passenger Front Door Module	DATA
JX63-14C109-BD.vbf	Jaguar XF (X260)	PDM - Passenger Front Door Module	DATA
JX63-14C109-BE.vbf	Jaguar XF (X260)	PDM - Passenger Front Door Module	DATA
JX63-14C109-BF.vbf	Jaguar XF (X260)	PDM - Passenger Front Door Module	DATA
JX63-14C109-BG.vbf	Jaguar XF (X260)	PDM - Passenger Front Door Module	DATA
JX63-14C113-BA.vbf	Jaguar XF (X260)	PRDM - Passenger Rear Door Module	DATA
JX63-14C113-BD.vbf	Jaguar XF (X260)	PRDM - Passenger Rear Door Module	DATA
JX63-14C113-BE.vbf	Jaguar XF (X260)	PRDM - Passenger Rear Door Module	DATA
JX63-14C113-BF.vbf	Jaguar XF (X260)	PRDM - Passenger Rear Door Module	DATA
JX63-14C113-BG.vbf	Jaguar XF (X260)	PRDM - Passenger Rear Door Module	DATA
JX63-14C121-AA.vbf	Jaguar XF (X260)	RGTM - Rear Gate / Trunk Module	EXE
JX63-14C121-AB.vbf	Jaguar XF (X260)	RGTM - Rear Gate / Trunk Module	EXE
JX63-14C121-AC.vbf	Jaguar XF (X260)	RGTM - Rear Gate / Trunk Module	EXE
JX63-14C121-AD.vbf	Jaguar XF (X260)	RGTM - Rear Gate / Trunk Module	EXE
JX63-14C121-AE.VBF	Jaguar XF (X260)	RGTM - Rear Gate / Trunk Module	EXE
JX63-14C122-AA.vbf	Jaguar XF (X260)	RGTM - Rear Gate / Trunk Module	DATA
JX63-14C122-AB.vbf	Jaguar XF (X260)	RGTM - Rear Gate / Trunk Module	DATA
JX63-14C122-AC.vbf	Jaguar XF (X260)	RGTM - Rear Gate / Trunk Module	DATA
JX63-14C122-AD.vbf	Jaguar XF (X260)	RGTM - Rear Gate / Trunk Module	DATA
JX63-14C122-AE.VBF	Jaguar XF (X260)	RGTM - Rear Gate / Trunk Module	DATA
JX63-14C124-AA.vbf	Jaguar XF (X260)	RGTM - Rear Gate / Trunk Module	SBL
JX63-14C185-AC.vbf	Jaguar XF (X260)	BCM - Body Control Module	DATA
JX63-14C218-AB.vbf	Jaguar XF (X260)	PSCM - Power Steering Control Module	DATA
JX63-14C218-AC.vbf	Jaguar XF (X260)	PSCM - Power Steering Control Module	DATA

File name	Vehicle line (indicative)	Module (ECU)	Type
JX63-14C218-BB.vbf	Jaguar XF (X260)	PSCM - Power Steering Control Module	DATA
JX63-14C218-BC.vbf	Jaguar XF (X260)	PSCM - Power Steering Control Module	DATA
JX63-14C218-CB.vbf	Jaguar XF (X260)	PSCM - Power Steering Control Module	DATA
JX63-14C218-CC.vbf	Jaguar XF (X260)	PSCM - Power Steering Control Module	DATA
JX63-14C218-DB.vbf	Jaguar XF (X260)	PSCM - Power Steering Control Module	DATA
JX63-14C218-DC.vbf	Jaguar XF (X260)	PSCM - Power Steering Control Module	DATA
JX63-14C218-EB.vbf	Jaguar XF (X260)	PSCM - Power Steering Control Module	DATA
JX63-14C218-EC.vbf	Jaguar XF (X260)	PSCM - Power Steering Control Module	DATA
JX63-14C218-FB.vbf	Jaguar XF (X260)	PSCM - Power Steering Control Module	DATA
JX63-14C218-FC.vbf	Jaguar XF (X260)	PSCM - Power Steering Control Module	DATA
JX63-14C218-GA.vbf	Jaguar XF (X260)	PSCM - Power Steering Control Module	DATA
JX63-14C218-GB.vbf	Jaguar XF (X260)	PSCM - Power Steering Control Module	DATA
JX63-14C218-HA.vbf	Jaguar XF (X260)	PSCM - Power Steering Control Module	DATA
JX63-14C218-HB.vbf	Jaguar XF (X260)	PSCM - Power Steering Control Module	DATA
JX63-14C218-JA.vbf	Jaguar XF (X260)	PSCM - Power Steering Control Module	DATA
JX63-14C527-BAB.vbf	Jaguar XF (X260)	AAM - Audio Amplifier Module	DATA
JX63-14C527-BB.vbf	Jaguar XF (X260)	AAM - Audio Amplifier Module	DATA
JX63-14C527-BBB.vbf	Jaguar XF (X260)	AAM - Audio Amplifier Module	DATA
JX63-14C527-BBC.vbf	Jaguar XF (X260)	AAM - Audio Amplifier Module	DATA
JX63-14C527-BCB.vbf	Jaguar XF (X260)	AAM - Audio Amplifier Module	DATA
JX63-14C527-BEB.vbf	Jaguar XF (X260)	AAM - Audio Amplifier Module	DATA
JX63-14C527-BFB.vbf	Jaguar XF (X260)	AAM - Audio Amplifier Module	DATA
JX63-14C527-CAB.vbf	Jaguar XF (X260)	AAM - Audio Amplifier Module	DATA
JX63-14C527-CB.vbf	Jaguar XF (X260)	AAM - Audio Amplifier Module	DATA
JX63-14C527-CBB.vbf	Jaguar XF (X260)	AAM - Audio Amplifier Module	DATA
JX63-14C527-CBC.vbf	Jaguar XF (X260)	AAM - Audio Amplifier Module	DATA
JX63-14C527-CCB.vbf	Jaguar XF (X260)	AAM - Audio Amplifier Module	DATA
JX63-14C527-CEB.vbf	Jaguar XF (X260)	AAM - Audio Amplifier Module	DATA
JX63-14C527-CFB.vbf	Jaguar XF (X260)	AAM - Audio Amplifier Module	DATA
JX63-14C527-FA.vbf	Jaguar XF (X260)	AAM - Audio Amplifier Module	DATA
JX63-14C527-FAA.vbf	Jaguar XF (X260)	AAM - Audio Amplifier Module	DATA
JX63-14C527-FB.vbf	Jaguar XF (X260)	AAM - Audio Amplifier Module	DATA
JX63-14C527-FBA.vbf	Jaguar XF (X260)	AAM - Audio Amplifier Module	DATA
JX63-14C527-FBB.vbf	Jaguar XF (X260)	AAM - Audio Amplifier Module	DATA
JX63-14C527-FBC.vbf	Jaguar XF (X260)	AAM - Audio Amplifier Module	DATA
JX63-14C527-FCA.vbf	Jaguar XF (X260)	AAM - Audio Amplifier Module	DATA
JX63-14C527-FDA.vbf	Jaguar XF (X260)	AAM - Audio Amplifier Module	DATA
JX63-14C527-FEA.vbf	Jaguar XF (X260)	AAM - Audio Amplifier Module	DATA
JX63-14C527-GA.vbf	Jaguar XF (X260)	AAM - Audio Amplifier Module	DATA
JX63-14C527-GAA.vbf	Jaguar XF (X260)	AAM - Audio Amplifier Module	DATA
JX63-14C527-GB.vbf	Jaguar XF (X260)	AAM - Audio Amplifier Module	DATA
JX63-14C527-GBA.vbf	Jaguar XF (X260)	AAM - Audio Amplifier Module	DATA
JX63-14C527-GBB.vbf	Jaguar XF (X260)	AAM - Audio Amplifier Module	DATA
JX63-14C527-GBC.vbf	Jaguar XF (X260)	AAM - Audio Amplifier Module	DATA
JX63-14C527-GCA.vbf	Jaguar XF (X260)	AAM - Audio Amplifier Module	DATA
JX63-14C527-GDA.vbf	Jaguar XF (X260)	AAM - Audio Amplifier Module	DATA
JX63-14C527-GEA.vbf	Jaguar XF (X260)	AAM - Audio Amplifier Module	DATA
JX63-14C534-AA.vbf	Jaguar XF (X260)	FCIM - Front Controls Interface Module	SIGCFG
JX63-14C535-AA.vbf	Jaguar XF (X260)	FCIM - Front Controls Interface Module	EXE
JX63-14C535-AB.vbf	Jaguar XF (X260)	FCIM - Front Controls Interface Module	EXE
JX63-14C536-AA.vbf	Jaguar XF (X260)	FCIM - Front Controls Interface Module	DATA
JX63-14C536-AB.vbf	Jaguar XF (X260)	FCIM - Front Controls Interface Module	DATA
JX63-14C536-BAA.vbf	Jaguar XF (X260)	FCIM - Front Controls Interface Module	DATA
JX63-14C536-BBA.vbf	Jaguar XF (X260)	FCIM - Front Controls Interface Module	DATA
JX63-14C536-BCA.vbf	Jaguar XF (X260)	FCIM - Front Controls Interface Module	DATA
JX63-14C536-BDA.vbf	Jaguar XF (X260)	FCIM - Front Controls Interface Module	DATA
JX63-14C536-BEA.vbf	Jaguar XF (X260)	FCIM - Front Controls Interface Module	DATA
JX63-14C536-BFA.vbf	Jaguar XF (X260)	FCIM - Front Controls Interface Module	DATA
JX63-14C536-BGA.vbf	Jaguar XF (X260)	FCIM - Front Controls Interface Module	DATA
JX63-14C536-BHA.vbf	Jaguar XF (X260)	FCIM - Front Controls Interface Module	DATA
JX63-14C536-BJA.vbf	Jaguar XF (X260)	FCIM - Front Controls Interface Module	DATA
JX63-14C536-BKA.vbf	Jaguar XF (X260)	FCIM - Front Controls Interface Module	DATA
JX63-14C536-BLA.vbf	Jaguar XF (X260)	FCIM - Front Controls Interface Module	DATA
JX63-14C536-BMA.vbf	Jaguar XF (X260)	FCIM - Front Controls Interface Module	DATA
JX63-14C536-BNA.vbf	Jaguar XF (X260)	FCIM - Front Controls Interface Module	DATA
JX63-14C536-BPA.vbf	Jaguar XF (X260)	FCIM - Front Controls Interface Module	DATA
JX63-14C536-BRA.vbf	Jaguar XF (X260)	FCIM - Front Controls Interface Module	DATA
JX63-14C536-BSA.vbf	Jaguar XF (X260)	FCIM - Front Controls Interface Module	DATA
JX63-14C536-BTA.vbf	Jaguar XF (X260)	FCIM - Front Controls Interface Module	DATA
JX63-14C536-BUA.vbf	Jaguar XF (X260)	FCIM - Front Controls Interface Module	DATA
JX63-14C536-BVA.vbf	Jaguar XF (X260)	FCIM - Front Controls Interface Module	DATA
JX63-14C536-BXA.vbf	Jaguar XF (X260)	FCIM - Front Controls Interface Module	DATA
JX63-14C536-BYA.vbf	Jaguar XF (X260)	FCIM - Front Controls Interface Module	DATA
JX63-14C536-BZA.vbf	Jaguar XF (X260)	FCIM - Front Controls Interface Module	DATA
JX63-14C536-CAA.vbf	Jaguar XF (X260)	FCIM - Front Controls Interface Module	DATA
JX63-14C536-CBA.vbf	Jaguar XF (X260)	FCIM - Front Controls Interface Module	DATA

File name	Vehicle line (indicative)	Module (ECU)	Type
JX63-14C536-CCA.vbf	Jaguar XF (X260)	FCIM - Front Controls Interface Module	DATA
JX63-14C536-CDA.vbf	Jaguar XF (X260)	FCIM - Front Controls Interface Module	DATA
JX63-14C536-CEA.vbf	Jaguar XF (X260)	FCIM - Front Controls Interface Module	DATA
JX63-14C536-CFA.vbf	Jaguar XF (X260)	FCIM - Front Controls Interface Module	DATA
JX63-14C536-CGA.vbf	Jaguar XF (X260)	FCIM - Front Controls Interface Module	DATA
JX63-14C536-CHA.vbf	Jaguar XF (X260)	FCIM - Front Controls Interface Module	DATA
JX63-14C536-CJA.vbf	Jaguar XF (X260)	FCIM - Front Controls Interface Module	DATA
JX63-14C536-CKA.vbf	Jaguar XF (X260)	FCIM - Front Controls Interface Module	DATA
JX63-14C536-CLA.vbf	Jaguar XF (X260)	FCIM - Front Controls Interface Module	DATA
JX63-14C536-CMA.vbf	Jaguar XF (X260)	FCIM - Front Controls Interface Module	DATA
JX63-14C536-CNA.vbf	Jaguar XF (X260)	FCIM - Front Controls Interface Module	DATA
JX63-14C536-CPA.vbf	Jaguar XF (X260)	FCIM - Front Controls Interface Module	DATA
JX63-14C536-CRA.vbf	Jaguar XF (X260)	FCIM - Front Controls Interface Module	DATA
JX63-14C536-CSA.vbf	Jaguar XF (X260)	FCIM - Front Controls Interface Module	DATA
JX63-14C536-CTA.vbf	Jaguar XF (X260)	FCIM - Front Controls Interface Module	DATA
JX63-14C536-CUA.vbf	Jaguar XF (X260)	FCIM - Front Controls Interface Module	DATA
JX63-14C570-BAA.vbf	Jaguar XF (X260)	PCM - Powertrain Control Module	EXE
JX63-14C570-BAB.vbf	Jaguar XF (X260)	PCM - Powertrain Control Module	EXE
JX63-14C570-BAD.vbf	Jaguar XF (X260)	PCM - Powertrain Control Module	EXE
JX63-14C570-BAE.vbf	Jaguar XF (X260)	PCM - Powertrain Control Module	EXE
JX63-14C570-BAF.vbf	Jaguar XF (X260)	PCM - Powertrain Control Module	EXE
JX63-14C570-BAG.vbf	Jaguar XF (X260)	PCM - Powertrain Control Module	EXE
JX63-14C570-BAH.vbf	Jaguar XF (X260)	PCM - Powertrain Control Module	EXE
JX63-14C570-BAJ.vbf	Jaguar XF (X260)	PCM - Powertrain Control Module	EXE
JX63-14C570-BCD.vbf	Jaguar XF (X260)	PCM - Powertrain Control Module	EXE
JX63-14C570-BCE.vbf	Jaguar XF (X260)	PCM - Powertrain Control Module	EXE
JX63-14C570-BCG.vbf	Jaguar XF (X260)	PCM - Powertrain Control Module	EXE
JX63-14C570-BCH.vbf	Jaguar XF (X260)	PCM - Powertrain Control Module	EXE
JX63-14C570-BEA.vbf	Jaguar XF (X260)	PCM - Powertrain Control Module	EXE
JX63-14C570-BED.vbf	Jaguar XF (X260)	PCM - Powertrain Control Module	EXE
JX63-14C570-BEE.vbf	Jaguar XF (X260)	PCM - Powertrain Control Module	EXE
JX63-14C570-BEG.vbf	Jaguar XF (X260)	PCM - Powertrain Control Module	EXE
JX63-14C570-BEH.vbf	Jaguar XF (X260)	PCM - Powertrain Control Module	EXE
JX63-14C570-BGB.vbf	Jaguar XF (X260)	PCM - Powertrain Control Module	EXE
JX63-14C570-BGD.vbf	Jaguar XF (X260)	PCM - Powertrain Control Module	EXE
JX63-14C570-BGE.vbf	Jaguar XF (X260)	PCM - Powertrain Control Module	EXE
JX63-14C570-BGF.vbf	Jaguar XF (X260)	PCM - Powertrain Control Module	EXE
JX63-14C570-BGG.vbf	Jaguar XF (X260)	PCM - Powertrain Control Module	EXE
JX63-14C570-BLB.vbf	Jaguar XF (X260)	PCM - Powertrain Control Module	EXE
JX63-14C570-BLD.vbf	Jaguar XF (X260)	PCM - Powertrain Control Module	EXE
JX63-14C570-BLE.vbf	Jaguar XF (X260)	PCM - Powertrain Control Module	EXE
JX63-14C570-BLF.vbf	Jaguar XF (X260)	PCM - Powertrain Control Module	EXE
JX63-14C570-BNB.vbf	Jaguar XF (X260)	PCM - Powertrain Control Module	EXE
JX63-14C570-BND.vbf	Jaguar XF (X260)	PCM - Powertrain Control Module	EXE
JX63-14C570-BNE.vbf	Jaguar XF (X260)	PCM - Powertrain Control Module	EXE
JX63-14C570-BNF.vbf	Jaguar XF (X260)	PCM - Powertrain Control Module	EXE
JX63-14C570-BNG.vbf	Jaguar XF (X260)	PCM - Powertrain Control Module	EXE
JX63-14C570-BTA.vbf	Jaguar XF (X260)	PCM - Powertrain Control Module	EXE
JX63-14C570-BTB.vbf	Jaguar XF (X260)	PCM - Powertrain Control Module	EXE
JX63-14C570-BTD.vbf	Jaguar XF (X260)	PCM - Powertrain Control Module	EXE
JX63-14C570-BTE.vbf	Jaguar XF (X260)	PCM - Powertrain Control Module	EXE
JX63-14C570-BTG.vbf	Jaguar XF (X260)	PCM - Powertrain Control Module	EXE
JX63-14C570-BTH.vbf	Jaguar XF (X260)	PCM - Powertrain Control Module	EXE
JX63-14C570-BTJ.vbf	Jaguar XF (X260)	PCM - Powertrain Control Module	EXE
JX63-14C570-BTL.vbf	Jaguar XF (X260)	PCM - Powertrain Control Module	EXE
JX63-14C570-BTM.vbf	Jaguar XF (X260)	PCM - Powertrain Control Module	EXE
JX63-14C570-BUB.vbf	Jaguar XF (X260)	PCM - Powertrain Control Module	EXE
JX63-14C570-BUD.vbf	Jaguar XF (X260)	PCM - Powertrain Control Module	EXE
JX63-14C570-BUE.vbf	Jaguar XF (X260)	PCM - Powertrain Control Module	EXE
JX63-14C570-BUG.vbf	Jaguar XF (X260)	PCM - Powertrain Control Module	EXE
JX63-14C570-BUH.vbf	Jaguar XF (X260)	PCM - Powertrain Control Module	EXE
JX63-14C570-TAA.vbf	Jaguar XF (X260)	PCM - Powertrain Control Module	EXE
JX63-14C570-TAB.vbf	Jaguar XF (X260)	PCM - Powertrain Control Module	EXE
JX63-14C570-TAC.vbf	Jaguar XF (X260)	PCM - Powertrain Control Module	EXE
JX63-14C570-TAD.vbf	Jaguar XF (X260)	PCM - Powertrain Control Module	EXE
JX63-14C570-TAE.vbf	Jaguar XF (X260)	PCM - Powertrain Control Module	EXE
JX63-14C570-TBA.vbf	Jaguar XF (X260)	PCM - Powertrain Control Module	EXE
JX63-14C570-TCB.vbf	Jaguar XF (X260)	PCM - Powertrain Control Module	EXE
JX63-14C570-TCC.vbf	Jaguar XF (X260)	PCM - Powertrain Control Module	EXE
JX63-14C570-TEA.vbf	Jaguar XF (X260)	PCM - Powertrain Control Module	EXE
JX63-14C570-TEB.vbf	Jaguar XF (X260)	PCM - Powertrain Control Module	EXE
JX63-14C570-TTA.vbf	Jaguar XF (X260)	PCM - Powertrain Control Module	EXE
JX63-14C570-TTB.vbf	Jaguar XF (X260)	PCM - Powertrain Control Module	EXE
JX63-14C570-TTC.vbf	Jaguar XF (X260)	PCM - Powertrain Control Module	EXE
JX63-14C570-UAA.vbf	Jaguar XF (X260)	PCM - Powertrain Control Module	EXE
JX63-14C570-UAB.vbf	Jaguar XF (X260)	PCM - Powertrain Control Module	EXE

File name	Vehicle line (indicative)	Module (ECU)	Type
JX63-14C570-UAC.vbf	Jaguar XF (X260)	PCM - Powertrain Control Module	EXE
JX63-14C570-UAD.vbf	Jaguar XF (X260)	PCM - Powertrain Control Module	EXE
JX63-14C570-UAE.vbf	Jaguar XF (X260)	PCM - Powertrain Control Module	EXE
JX63-14C570-UBA.vbf	Jaguar XF (X260)	PCM - Powertrain Control Module	EXE
JX63-14C570-UCB.vbf	Jaguar XF (X260)	PCM - Powertrain Control Module	EXE
JX63-14C570-UCC.vbf	Jaguar XF (X260)	PCM - Powertrain Control Module	EXE
JX63-14C570-UTA.vbf	Jaguar XF (X260)	PCM - Powertrain Control Module	EXE
JX63-14C570-UTB.vbf	Jaguar XF (X260)	PCM - Powertrain Control Module	EXE
JX63-14C570-UTC.vbf	Jaguar XF (X260)	PCM - Powertrain Control Module	EXE
JX63-14C609-AB.vbf	Jaguar XF (X260)	PSCM - Power Steering Control Module	DATA
JX63-14C653-AB.vbf	Jaguar XF (X260)	ACM - Audio Front Control Module	DATA
JX63-14D367-AA.vbf	Jaguar XF (X260)	SODL - Side Obstacle Detection Control Module - Left	SIGCFG
JX63-14D367-BA.vbf	Jaguar XF (X260)	SODR - Side Obstacle Detection Control Module - Right	SIGCFG
JX63-14D368-AB.vbf	Jaguar XF (X260)	SODL - Side Obstacle Detection Control Module - Left	EXE
JX63-14D368-AC.vbf	Jaguar XF (X260)	SODL - Side Obstacle Detection Control Module - Left	EXE
JX63-14D368-AD.vbf	Jaguar XF (X260)	SODL - Side Obstacle Detection Control Module - Left	EXE
JX63-14D368-AE.vbf	Jaguar XF (X260)	SODL - Side Obstacle Detection Control Module - Left	EXE
JX63-14D368-AF.vbf	Jaguar XF (X260)	SODL - Side Obstacle Detection Control Module - Left	EXE
JX63-14D368-BB.vbf	Jaguar XF (X260)	SODL - Side Obstacle Detection Control Module - Left	EXE
JX63-14D368-BC.vbf	Jaguar XF (X260)	SODL - Side Obstacle Detection Control Module - Left	EXE
JX63-14D368-BD.vbf	Jaguar XF (X260)	SODL - Side Obstacle Detection Control Module - Left	EXE
JX63-14D368-BE.vbf	Jaguar XF (X260)	SODL - Side Obstacle Detection Control Module - Left	EXE
JX63-14D368-BF.vbf	Jaguar XF (X260)	SODL - Side Obstacle Detection Control Module - Left	EXE
JX63-14D370-AB.vbf	Jaguar XF (X260)	SODL - Side Obstacle Detection Control Module - Left	SBL
JX63-14D370-AC.vbf	Jaguar XF (X260)	SODL - Side Obstacle Detection Control Module - Left	SBL
JX63-14D370-AD.vbf	Jaguar XF (X260)	SODL - Side Obstacle Detection Control Module - Left	SBL
JX63-14D481-BA.vbf	Jaguar XF (X260)	IPMB - Image Processing Module B	DATA
JX63-14D481-CA.vbf	Jaguar XF (X260)	IPMB - Image Processing Module B	DATA
JX63-14D481-CB.vbf	Jaguar XF (X260)	IPMB - Image Processing Module B	DATA
JX63-14D485-AA.vbf	Jaguar XF (X260)	IPMB - Image Processing Module B	EXE
JX63-14D485-AC.vbf	Jaguar XF (X260)	IPMB - Image Processing Module B	EXE
JX63-14D485-AE.vbf	Jaguar XF (X260)	IPMB - Image Processing Module B	EXE
JX63-14D485-AF.vbf	Jaguar XF (X260)	IPMB - Image Processing Module B	EXE
JX63-14D485-AG.vbf	Jaguar XF (X260)	IPMB - Image Processing Module B	EXE
JX63-14D485-BA.vbf	Jaguar XF (X260)	IPMB - Image Processing Module B	DATA
JX63-14D485-CC.vbf	Jaguar XF (X260)	IPMB - Image Processing Module B	EXE
JX63-14D485-CD.vbf	Jaguar XF (X260)	IPMB - Image Processing Module B	EXE
JX63-14D485-CE.vbf	Jaguar XF (X260)	IPMB - Image Processing Module B	EXE
JX63-14D485-DA.vbf	Jaguar XF (X260)	IPMB - Image Processing Module B	DATA
JX63-14D485-DB.vbf	Jaguar XF (X260)	IPMB - Image Processing Module B	DATA
JX63-14D519-AB.vbf	Jaguar XF (X260)	HVAC - HVAC Control Module	EXE
JX63-14D519-AD.vbf	Jaguar XF (X260)	HVAC - HVAC Control Module	EXE
JX63-14D520-AB.vbf	Jaguar XF (X260)	HVAC - HVAC Control Module	DATA
JX63-14D520-AC.vbf	Jaguar XF (X260)	HVAC - HVAC Control Module	DATA
JX63-14D520-AE.vbf	Jaguar XF (X260)	HVAC - HVAC Control Module	DATA
JX63-14D520-BB.vbf	Jaguar XF (X260)	HVAC - HVAC Control Module	DATA
JX63-14D520-BC.vbf	Jaguar XF (X260)	HVAC - HVAC Control Module	DATA
JX63-14D520-BD.vbf	Jaguar XF (X260)	HVAC - HVAC Control Module	DATA
JX63-14D520-BE.vbf	Jaguar XF (X260)	HVAC - HVAC Control Module	DATA
JX63-14D520-CB.vbf	Jaguar XF (X260)	HVAC - HVAC Control Module	DATA
JX63-14D520-CD.vbf	Jaguar XF (X260)	HVAC - HVAC Control Module	DATA
JX63-14D520-DB.vbf	Jaguar XF (X260)	HVAC - HVAC Control Module	DATA
JX63-14D520-DC.vbf	Jaguar XF (X260)	HVAC - HVAC Control Module	DATA
JX63-14D520-DD.vbf	Jaguar XF (X260)	HVAC - HVAC Control Module	DATA
JX63-14D520-DE.vbf	Jaguar XF (X260)	HVAC - HVAC Control Module	DATA
JX63-14D520-EA.vbf	Jaguar XF (X260)	HVAC - HVAC Control Module	DATA
JX63-14D520-FA.vbf	Jaguar XF (X260)	HVAC - HVAC Control Module	DATA
JX63-14D564-AB.vbf	Jaguar XF (X260)	SODL - Side Obstacle Detection Control Module - Left	DATA
JX63-14D564-AC.vbf	Jaguar XF (X260)	SODL - Side Obstacle Detection Control Module - Left	DATA
JX63-14D564-AD.vbf	Jaguar XF (X260)	SODL - Side Obstacle Detection Control Module - Left	DATA
JX63-14D564-BB.vbf	Jaguar XF (X260)	SODR - Side Obstacle Detection Control Module - Right	DATA
JX63-14D564-BC.vbf	Jaguar XF (X260)	SODR - Side Obstacle Detection Control Module - Right	DATA
JX63-14D564-BD.vbf	Jaguar XF (X260)	SODR - Side Obstacle Detection Control Module - Right	DATA
JX63-14D564-CA.vbf	Jaguar XF (X260)	SODL - Side Obstacle Detection Control Module - Left	DATA
JX63-14D564-CB.vbf	Jaguar XF (X260)	SODL - Side Obstacle Detection Control Module - Left	DATA
JX63-14D564-CC.vbf	Jaguar XF (X260)	SODL - Side Obstacle Detection Control Module - Left	DATA
JX63-14D564-DA.vbf	Jaguar XF (X260)	SODR - Side Obstacle Detection Control Module - Right	DATA
JX63-14D564-DB.vbf	Jaguar XF (X260)	SODR - Side Obstacle Detection Control Module - Right	DATA
JX63-14D564-DC.vbf	Jaguar XF (X260)	SODR - Side Obstacle Detection Control Module - Right	DATA
JX63-14E093-DB.vbf	Jaguar XF (X260)	CHCM - Chassis Control Module	EXE
JX63-14E093-DC.vbf	Jaguar XF (X260)	CHCM - Chassis Control Module	EXE
JX63-14E093-DD.vbf	Jaguar XF (X260)	CHCM - Chassis Control Module	EXE
JX63-14E093-DE.vbf	Jaguar XF (X260)	CHCM - Chassis Control Module	EXE
JX63-14E093-JA.vbf	Jaguar XF (X260)	CHCM - Chassis Control Module	EXE
JX63-14E093-JB.vbf	Jaguar XF (X260)	CHCM - Chassis Control Module	EXE
JX63-14E093-JC.vbf	Jaguar XF (X260)	CHCM - Chassis Control Module	EXE

File name	Vehicle line (indicative)	Module (ECU)	Type
JX63-14E093-JD.vbf	Jaguar XF (X260)	CHCM - Chassis Control Module	EXE
JX63-14E093-JE.vbf	Jaguar XF (X260)	CHCM - Chassis Control Module	EXE
JX63-14E094-DAB.vbf	Jaguar XF (X260)	CHCM - Chassis Control Module	EXE
JX63-14E094-DAC.vbf	Jaguar XF (X260)	CHCM - Chassis Control Module	EXE
JX63-14E094-DAD.vbf	Jaguar XF (X260)	CHCM - Chassis Control Module	EXE
JX63-14E094-DBB.vbf	Jaguar XF (X260)	CHCM - Chassis Control Module	EXE
JX63-14E094-DBC.vbf	Jaguar XF (X260)	CHCM - Chassis Control Module	EXE
JX63-14E094-DCB.vbf	Jaguar XF (X260)	CHCM - Chassis Control Module	EXE
JX63-14E094-DCC.vbf	Jaguar XF (X260)	CHCM - Chassis Control Module	EXE
JX63-14E094-DCD.vbf	Jaguar XF (X260)	CHCM - Chassis Control Module	EXE
JX63-14E094-DEB.vbf	Jaguar XF (X260)	CHCM - Chassis Control Module	EXE
JX63-14E094-DEC.vbf	Jaguar XF (X260)	CHCM - Chassis Control Module	EXE
JX63-14E094-DED.vbf	Jaguar XF (X260)	CHCM - Chassis Control Module	EXE
JX63-14E094-DFB.vbf	Jaguar XF (X260)	CHCM - Chassis Control Module	EXE
JX63-14E094-DFC.vbf	Jaguar XF (X260)	CHCM - Chassis Control Module	EXE
JX63-14E094-DFD.vbf	Jaguar XF (X260)	CHCM - Chassis Control Module	EXE
JX63-14E094-DGB.vbf	Jaguar XF (X260)	CHCM - Chassis Control Module	EXE
JX63-14E094-DGC.vbf	Jaguar XF (X260)	CHCM - Chassis Control Module	EXE
JX63-14E094-DGD.vbf	Jaguar XF (X260)	CHCM - Chassis Control Module	EXE
JX63-14E094-DHB.vbf	Jaguar XF (X260)	CHCM - Chassis Control Module	EXE
JX63-14E094-DHC.vbf	Jaguar XF (X260)	CHCM - Chassis Control Module	EXE
JX63-14E094-DHD.vbf	Jaguar XF (X260)	CHCM - Chassis Control Module	EXE
JX63-14E094-JAA.vbf	Jaguar XF (X260)	CHCM - Chassis Control Module	EXE
JX63-14E094-JAB.vbf	Jaguar XF (X260)	CHCM - Chassis Control Module	EXE
JX63-14E094-JAC.vbf	Jaguar XF (X260)	CHCM - Chassis Control Module	EXE
JX63-14E094-JAD.vbf	Jaguar XF (X260)	CHCM - Chassis Control Module	EXE
JX63-14E094-JAE.vbf	Jaguar XF (X260)	CHCM - Chassis Control Module	EXE
JX63-14E094-JBA.vbf	Jaguar XF (X260)	CHCM - Chassis Control Module	EXE
JX63-14E094-JBB.vbf	Jaguar XF (X260)	CHCM - Chassis Control Module	EXE
JX63-14E094-JBC.vbf	Jaguar XF (X260)	CHCM - Chassis Control Module	EXE
JX63-14E094-JBD.vbf	Jaguar XF (X260)	CHCM - Chassis Control Module	EXE
JX63-14E094-JBE.vbf	Jaguar XF (X260)	CHCM - Chassis Control Module	EXE
JX63-14E094-JCA.vbf	Jaguar XF (X260)	CHCM - Chassis Control Module	EXE
JX63-14E094-JCB.vbf	Jaguar XF (X260)	CHCM - Chassis Control Module	EXE
JX63-14E094-JCC.vbf	Jaguar XF (X260)	CHCM - Chassis Control Module	EXE
JX63-14E094-JCD.vbf	Jaguar XF (X260)	CHCM - Chassis Control Module	EXE
JX63-14E094-JCE.vbf	Jaguar XF (X260)	CHCM - Chassis Control Module	EXE
JX63-14E094-JDA.vbf	Jaguar XF (X260)	CHCM - Chassis Control Module	EXE
JX63-14E094-JEA.vbf	Jaguar XF (X260)	CHCM - Chassis Control Module	EXE
JX63-14E094-JFA.vbf	Jaguar XF (X260)	CHCM - Chassis Control Module	EXE
JX63-14E094-JGA.vbf	Jaguar XF (X260)	CHCM - Chassis Control Module	EXE
JX63-14E094-JGB.vbf	Jaguar XF (X260)	CHCM - Chassis Control Module	EXE
JX63-14E094-JGC.vbf	Jaguar XF (X260)	CHCM - Chassis Control Module	EXE
JX63-14E094-JGD.vbf	Jaguar XF (X260)	CHCM - Chassis Control Module	EXE
JX63-14E094-JGE.vbf	Jaguar XF (X260)	CHCM - Chassis Control Module	EXE
JX63-14E094-JHA.vbf	Jaguar XF (X260)	CHCM - Chassis Control Module	EXE
JX63-14E094-JHB.vbf	Jaguar XF (X260)	CHCM - Chassis Control Module	EXE
JX63-14E094-JHC.vbf	Jaguar XF (X260)	CHCM - Chassis Control Module	EXE
JX63-14E094-JHD.vbf	Jaguar XF (X260)	CHCM - Chassis Control Module	EXE
JX63-14E094-JHE.vbf	Jaguar XF (X260)	CHCM - Chassis Control Module	EXE
JX63-14E094-JJA.vbf	Jaguar XF (X260)	CHCM - Chassis Control Module	EXE
JX63-14E094-JJB.vbf	Jaguar XF (X260)	CHCM - Chassis Control Module	EXE
JX63-14E094-JJC.vbf	Jaguar XF (X260)	CHCM - Chassis Control Module	EXE
JX63-14E094-JJD.vbf	Jaguar XF (X260)	CHCM - Chassis Control Module	EXE
JX63-14E094-JJE.vbf	Jaguar XF (X260)	CHCM - Chassis Control Module	EXE
JX63-14E094-JKA.vbf	Jaguar XF (X260)	CHCM - Chassis Control Module	EXE
JX63-14E094-JKB.vbf	Jaguar XF (X260)	CHCM - Chassis Control Module	EXE
JX63-14E094-JKC.vbf	Jaguar XF (X260)	CHCM - Chassis Control Module	EXE
JX63-14E094-JKD.vbf	Jaguar XF (X260)	CHCM - Chassis Control Module	EXE
JX63-14E094-JKE.vbf	Jaguar XF (X260)	CHCM - Chassis Control Module	EXE
JX63-14E094-JLA.vbf	Jaguar XF (X260)	CHCM - Chassis Control Module	EXE
JX63-14E094-JLB.vbf	Jaguar XF (X260)	CHCM - Chassis Control Module	EXE
JX63-14E094-JLC.vbf	Jaguar XF (X260)	CHCM - Chassis Control Module	EXE
JX63-14E094-JLD.vbf	Jaguar XF (X260)	CHCM - Chassis Control Module	EXE
JX63-14E094-JLE.vbf	Jaguar XF (X260)	CHCM - Chassis Control Module	EXE
JX63-14E094-JMA.vbf	Jaguar XF (X260)	CHCM - Chassis Control Module	EXE
JX63-14E094-JMB.vbf	Jaguar XF (X260)	CHCM - Chassis Control Module	EXE
JX63-14E094-JMC.vbf	Jaguar XF (X260)	CHCM - Chassis Control Module	EXE
JX63-14E094-JMD.vbf	Jaguar XF (X260)	CHCM - Chassis Control Module	EXE
JX63-14E094-JME.vbf	Jaguar XF (X260)	CHCM - Chassis Control Module	EXE
JX63-14E094-JNA.vbf	Jaguar XF (X260)	CHCM - Chassis Control Module	EXE
JX63-14E094-JNB.vbf	Jaguar XF (X260)	CHCM - Chassis Control Module	EXE
JX63-14E094-JNC.vbf	Jaguar XF (X260)	CHCM - Chassis Control Module	EXE
JX63-14E094-JND.vbf	Jaguar XF (X260)	CHCM - Chassis Control Module	EXE
JX63-14E094-JNE.vbf	Jaguar XF (X260)	CHCM - Chassis Control Module	EXE
JX63-14E094-JPA.vbf	Jaguar XF (X260)	CHCM - Chassis Control Module	EXE

File name	Vehicle line (indicative)	Module (ECU)	Type
JX63-14E094-JPB.vbf	Jaguar XF (X260)	CHCM - Chassis Control Module	EXE
JX63-14E094-JPC.vbf	Jaguar XF (X260)	CHCM - Chassis Control Module	EXE
JX63-14E094-JPD.vbf	Jaguar XF (X260)	CHCM - Chassis Control Module	EXE
JX63-14E094-JPE.vbf	Jaguar XF (X260)	CHCM - Chassis Control Module	EXE
JX63-14E094-JRA.vbf	Jaguar XF (X260)	CHCM - Chassis Control Module	EXE
JX63-14E094-JRB.vbf	Jaguar XF (X260)	CHCM - Chassis Control Module	EXE
JX63-14E094-JRC.vbf	Jaguar XF (X260)	CHCM - Chassis Control Module	EXE
JX63-14F022-AD.vbf	Jaguar XF (X260)	IPMB - Image Processing Module B	DATA
JX63-14F022-AE.vbf	Jaguar XF (X260)	IPMB - Image Processing Module B	DATA
JX63-14F022-AF.vbf	Jaguar XF (X260)	IPMB - Image Processing Module B	DATA
JX63-14F022-AG.vbf	Jaguar XF (X260)	IPMB - Image Processing Module B	DATA
JX63-14F022-BE.vbf	Jaguar XF (X260)	IPMB - Image Processing Module B	DATA
JX63-14F022-BF.vbf	Jaguar XF (X260)	IPMB - Image Processing Module B	DATA
JX63-14F022-BG.vbf	Jaguar XF (X260)	IPMB - Image Processing Module B	DATA
JX63-14F022-CD.vbf	Jaguar XF (X260)	IPMB - Image Processing Module B	DATA
JX63-14F022-CE.vbf	Jaguar XF (X260)	IPMB - Image Processing Module B	DATA
JX63-14F022-CF.vbf	Jaguar XF (X260)	IPMB - Image Processing Module B	DATA
JX63-14F022-DE.vbf	Jaguar XF (X260)	IPMB - Image Processing Module B	DATA
JX63-14F022-DF.vbf	Jaguar XF (X260)	IPMB - Image Processing Module B	DATA
JX63-14F022-DG.vbf	Jaguar XF (X260)	IPMB - Image Processing Module B	DATA
JX63-14F216-AA.vbf	Jaguar XF (X260)	RHVAC - Rear HVAC Control Module	SIGCFG
JX63-14F217-AA.vbf	Jaguar XF (X260)	RHVAC - Rear HVAC Control Module	EXE
JX63-14F218-AA.vbf	Jaguar XF (X260)	RHVAC - Rear HVAC Control Module	CUSTOM
JX63-14F529-BB.vbf	Jaguar XF (X260)	GWM - Gateway Module A	EXE
JX63-14F529-BC.vbf	Jaguar XF (X260)	GWM - Gateway Module A	SIGCFG
JX63-14F529-BD.vbf	Jaguar XF (X260)	GWM - Gateway Module A	EXE
JX63-14F529-BE.vbf	Jaguar XF (X260)	GWM - Gateway Module A	EXE
JX63-14F530-BC.vbf	Jaguar XF (X260)	GWM - Gateway Module A	EXE
JX63-14F530-BD.vbf	Jaguar XF (X260)	GWM - Gateway Module A	EXE
JX63-14F530-BF.vbf	Jaguar XF (X260)	GWM - Gateway Module A	EXE
JX63-14F530-BG.vbf	Jaguar XF (X260)	GWM - Gateway Module A	EXE
JX63-14F530-BH.vbf	Jaguar XF (X260)	GWM - Gateway Module A	EXE
JX63-14F531-BB.vbf	Jaguar XF (X260)	GWM - Gateway Module A	DATA
JX63-14F531-BC.vbf	Jaguar XF (X260)	GWM - Gateway Module A	DATA
JX63-14F531-BD.vbf	Jaguar XF (X260)	GWM - Gateway Module A	DATA
JX63-14F531-BE.vbf	Jaguar XF (X260)	GWM - Gateway Module A	DATA
JX63-14F531-BF.vbf	Jaguar XF (X260)	GWM - Gateway Module A	DATA
JX63-19C204-AA.vbf	Jaguar XF (X260)	IMC - Infotainment Master Controller	EXE
JX63-19C204-AB.vbf	Jaguar XF (X260)	IMC - Infotainment Master Controller	EXE
JX63-7J104-FBA.vbf	Jaguar XF (X260)	TCM - Transmission Control Module	EXE
JX63-7J104-FBB.vbf	Jaguar XF (X260)	TCM - Transmission Control Module	EXE
JX63-7J104-FBC.vbf	Jaguar XF (X260)	TCM - Transmission Control Module	EXE
JX63-7J104-FBD.vbf	Jaguar XF (X260)	TCM - Transmission Control Module	EXE
JX63-7J104-FBE.vbf	Jaguar XF (X260)	TCM - Transmission Control Module	EXE
JX63-7J104-FCA.vbf	Jaguar XF (X260)	TCM - Transmission Control Module	EXE
JX63-7J104-FCB.vbf	Jaguar XF (X260)	TCM - Transmission Control Module	EXE
JX63-7J104-FCC.vbf	Jaguar XF (X260)	TCM - Transmission Control Module	EXE
JX63-7J104-FCD.vbf	Jaguar XF (X260)	TCM - Transmission Control Module	EXE
JX63-7J104-FCE.vbf	Jaguar XF (X260)	TCM - Transmission Control Module	EXE
JX63-7J104-FDA.vbf	Jaguar XF (X260)	TCM - Transmission Control Module	EXE
JX63-7J104-FDB.vbf	Jaguar XF (X260)	TCM - Transmission Control Module	EXE
JX63-7J104-FDC.vbf	Jaguar XF (X260)	TCM - Transmission Control Module	EXE
JX63-7J104-FDD.vbf	Jaguar XF (X260)	TCM - Transmission Control Module	EXE
JX63-7J104-FDE.vbf	Jaguar XF (X260)	TCM - Transmission Control Module	EXE
JX63-7J104-FDF.vbf	Jaguar XF (X260)	TCM - Transmission Control Module	EXE
JX63-7J104-FDG.vbf	Jaguar XF (X260)	TCM - Transmission Control Module	EXE
JX63-7J104-FFA.vbf	Jaguar XF (X260)	TCM - Transmission Control Module	EXE
JX63-7J104-FFB.vbf	Jaguar XF (X260)	TCM - Transmission Control Module	EXE
JX63-7J104-FFC.vbf	Jaguar XF (X260)	TCM - Transmission Control Module	EXE
JX63-7J104-FFD.vbf	Jaguar XF (X260)	TCM - Transmission Control Module	EXE
JX63-7J104-FFE.vbf	Jaguar XF (X260)	TCM - Transmission Control Module	EXE
JX63-7J104-FFF.vbf	Jaguar XF (X260)	TCM - Transmission Control Module	EXE
JX63-7J104-FGA.vbf	Jaguar XF (X260)	TCM - Transmission Control Module	EXE
JX63-7J104-FGB.vbf	Jaguar XF (X260)	TCM - Transmission Control Module	EXE
JX63-7J104-FGC.vbf	Jaguar XF (X260)	TCM - Transmission Control Module	EXE
JX63-7J104-FGD.vbf	Jaguar XF (X260)	TCM - Transmission Control Module	EXE
JX63-7J104-FJA.vbf	Jaguar XF (X260)	TCM - Transmission Control Module	EXE
JX63-7J104-FJB.vbf	Jaguar XF (X260)	TCM - Transmission Control Module	EXE
JX63-7J104-FJC.vbf	Jaguar XF (X260)	TCM - Transmission Control Module	EXE
JX63-7J104-FJD.vbf	Jaguar XF (X260)	TCM - Transmission Control Module	EXE
JX63-7J104-FJE.vbf	Jaguar XF (X260)	TCM - Transmission Control Module	EXE
JX63-7J104-FKA.vbf	Jaguar XF (X260)	TCM - Transmission Control Module	EXE
JX63-7J104-FKB.vbf	Jaguar XF (X260)	TCM - Transmission Control Module	EXE
JX63-7J104-FKC.vbf	Jaguar XF (X260)	TCM - Transmission Control Module	EXE
JX63-7J104-FKD.vbf	Jaguar XF (X260)	TCM - Transmission Control Module	EXE
JX63-7J104-FKE.vbf	Jaguar XF (X260)	TCM - Transmission Control Module	EXE

File name	Vehicle line (indicative)	Module (ECU)	Type
JX63-7J104-FLA.vbf	Jaguar XF (X260)	TCM - Transmission Control Module	EXE
JX63-7J104-FLB.vbf	Jaguar XF (X260)	TCM - Transmission Control Module	EXE
JX63-7J104-FLC.vbf	Jaguar XF (X260)	TCM - Transmission Control Module	EXE
JX63-7J104-FLD.vbf	Jaguar XF (X260)	TCM - Transmission Control Module	EXE
JX63-7J104-FLE.vbf	Jaguar XF (X260)	TCM - Transmission Control Module	EXE
JX63-7J104-FLF.vbf	Jaguar XF (X260)	TCM - Transmission Control Module	EXE
JX63-7J104-FMA.vbf	Jaguar XF (X260)	TCM - Transmission Control Module	EXE
JX63-7J104-FMB.vbf	Jaguar XF (X260)	TCM - Transmission Control Module	EXE
JX63-7J104-FMC.vbf	Jaguar XF (X260)	TCM - Transmission Control Module	EXE
JX63-7J104-FMD.vbf	Jaguar XF (X260)	TCM - Transmission Control Module	EXE
JX63-7J104-FME.vbf	Jaguar XF (X260)	TCM - Transmission Control Module	EXE
JX63-7J104-FNA.vbf	Jaguar XF (X260)	TCM - Transmission Control Module	EXE
JX63-7J104-FNB.vbf	Jaguar XF (X260)	TCM - Transmission Control Module	EXE
JX63-7J104-FNC.vbf	Jaguar XF (X260)	TCM - Transmission Control Module	EXE
JX63-7J104-FND.vbf	Jaguar XF (X260)	TCM - Transmission Control Module	EXE
JX63-7J104-FTA.vbf	Jaguar XF (X260)	TCM - Transmission Control Module	EXE
JX63-7J104-FTB.vbf	Jaguar XF (X260)	TCM - Transmission Control Module	EXE
JX63-7J104-FTC.vbf	Jaguar XF (X260)	TCM - Transmission Control Module	EXE
JX63-7J104-FTD.vbf	Jaguar XF (X260)	TCM - Transmission Control Module	EXE
JX63-7J104-FTE.vbf	Jaguar XF (X260)	TCM - Transmission Control Module	EXE
JX63-7J104-FTF.vbf	Jaguar XF (X260)	TCM - Transmission Control Module	EXE
JX63-7J104-FUA.vbf	Jaguar XF (X260)	TCM - Transmission Control Module	EXE
JX63-7J104-FUB.vbf	Jaguar XF (X260)	TCM - Transmission Control Module	EXE
JX63-7J104-FUC.vbf	Jaguar XF (X260)	TCM - Transmission Control Module	EXE
JX63-7J104-FUD.vbf	Jaguar XF (X260)	TCM - Transmission Control Module	EXE
JX63-7J104-FUE.vbf	Jaguar XF (X260)	TCM - Transmission Control Module	EXE
JX63-7J104-FVA.vbf	Jaguar XF (X260)	TCM - Transmission Control Module	EXE
JX63-7J104-FVB.vbf	Jaguar XF (X260)	TCM - Transmission Control Module	EXE
JX63-7J104-FVC.vbf	Jaguar XF (X260)	TCM - Transmission Control Module	EXE
JX63-7J104-FVD.vbf	Jaguar XF (X260)	TCM - Transmission Control Module	EXE
JX63-7J104-FVE.vbf	Jaguar XF (X260)	TCM - Transmission Control Module	EXE
JX63-7J104-FVF.vbf	Jaguar XF (X260)	TCM - Transmission Control Module	EXE
JX63-7J104-FXA.vbf	Jaguar XF (X260)	TCM - Transmission Control Module	EXE
JX63-7J104-FXB.vbf	Jaguar XF (X260)	TCM - Transmission Control Module	EXE
JX63-7J104-FXC.vbf	Jaguar XF (X260)	TCM - Transmission Control Module	EXE
JX63-7J104-FXD.vbf	Jaguar XF (X260)	TCM - Transmission Control Module	EXE
JX63-7J104-FXE.vbf	Jaguar XF (X260)	TCM - Transmission Control Module	EXE
JX63-7J104-FYA.vbf	Jaguar XF (X260)	TCM - Transmission Control Module	EXE
JX63-7J104-FYB.vbf	Jaguar XF (X260)	TCM - Transmission Control Module	EXE
JX63-7J104-FYC.vbf	Jaguar XF (X260)	TCM - Transmission Control Module	EXE
JX63-7J104-FYD.vbf	Jaguar XF (X260)	TCM - Transmission Control Module	EXE
JX63-7J104-FYE.vbf	Jaguar XF (X260)	TCM - Transmission Control Module	EXE
JX6M-14C152-AA.vbf	Not specified	TPM - Tire Pressure Monitor Module	DATA
JX6M-14C152-AB.vbf	Not specified	TPM - Tire Pressure Monitor Module	DATA
JX73-12K532-FAA.vbf	Jaguar XE (X760)	PCM - Powertrain Control Module	DATA
JX73-12K532-FAB.vbf	Jaguar XE (X760)	PCM - Powertrain Control Module	DATA
JX73-12K532-FAC.vbf	Jaguar XE (X760)	PCM - Powertrain Control Module	DATA
JX73-12K532-FAD.vbf	Jaguar XE (X760)	PCM - Powertrain Control Module	DATA
JX73-12K532-FAE.vbf	Jaguar XE (X760)	PCM - Powertrain Control Module	DATA
JX73-12K532-FAF.vbf	Jaguar XE (X760)	PCM - Powertrain Control Module	DATA
JX73-12K532-FAG.vbf	Jaguar XE (X760)	PCM - Powertrain Control Module	DATA
JX73-12K532-FAH.vbf	Jaguar XE (X760)	PCM - Powertrain Control Module	DATA
JX73-12K532-FCB.vbf	Jaguar XE (X760)	PCM - Powertrain Control Module	DATA
JX73-12K532-FCC.vbf	Jaguar XE (X760)	PCM - Powertrain Control Module	DATA
JX73-12K532-FCD.vbf	Jaguar XE (X760)	PCM - Powertrain Control Module	DATA
JX73-12K532-FCE.vbf	Jaguar XE (X760)	PCM - Powertrain Control Module	DATA
JX73-12K532-FCG.vbf	Jaguar XE (X760)	PCM - Powertrain Control Module	DATA
JX73-12K532-FDA.vbf	Jaguar XE (X760)	PCM - Powertrain Control Module	DATA
JX73-12K532-FDB.vbf	Jaguar XE (X760)	PCM - Powertrain Control Module	DATA
JX73-12K532-FDC.vbf	Jaguar XE (X760)	PCM - Powertrain Control Module	DATA
JX73-12K532-FDD.vbf	Jaguar XE (X760)	PCM - Powertrain Control Module	DATA
JX73-12K532-FDE.vbf	Jaguar XE (X760)	PCM - Powertrain Control Module	DATA
JX73-12K532-FDG.vbf	Jaguar XE (X760)	PCM - Powertrain Control Module	DATA
JX73-12K532-FEB.vbf	Jaguar XE (X760)	PCM - Powertrain Control Module	DATA
JX73-12K532-FEC.vbf	Jaguar XE (X760)	PCM - Powertrain Control Module	DATA
JX73-12K532-FED.vbf	Jaguar XE (X760)	PCM - Powertrain Control Module	DATA
JX73-12K532-FEE.vbf	Jaguar XE (X760)	PCM - Powertrain Control Module	DATA
JX73-12K532-FEG.vbf	Jaguar XE (X760)	PCM - Powertrain Control Module	DATA
JX73-12K532-FFB.vbf	Jaguar XE (X760)	PCM - Powertrain Control Module	DATA
JX73-12K532-FFC.vbf	Jaguar XE (X760)	PCM - Powertrain Control Module	DATA
JX73-12K532-FFD.vbf	Jaguar XE (X760)	PCM - Powertrain Control Module	EXE
JX73-12K532-FHA.vbf	Jaguar XE (X760)	PCM - Powertrain Control Module	DATA
JX73-12K532-FHB.vbf	Jaguar XE (X760)	PCM - Powertrain Control Module	DATA
JX73-12K532-FHC.vbf	Jaguar XE (X760)	PCM - Powertrain Control Module	DATA
JX73-12K532-FHD.vbf	Jaguar XE (X760)	PCM - Powertrain Control Module	EXE
JX73-12K532-FJB.vbf	Jaguar XE (X760)	PCM - Powertrain Control Module	DATA

File name	Vehicle line (indicative)	Module (ECU)	Type
JX73-12K532-FJC.vbf	Jaguar XE (X760)	PCM - Powertrain Control Module	DATA
JX73-12K532-FJD.vbf	Jaguar XE (X760)	PCM - Powertrain Control Module	EXE
JX73-12K532-FKA.vbf	Jaguar XE (X760)	PCM - Powertrain Control Module	DATA
JX73-12K532-FKB.vbf	Jaguar XE (X760)	PCM - Powertrain Control Module	DATA
JX73-12K532-FKC.vbf	Jaguar XE (X760)	PCM - Powertrain Control Module	DATA
JX73-12K532-FKD.vbf	Jaguar XE (X760)	PCM - Powertrain Control Module	DATA
JX73-12K532-FLA.vbf	Jaguar XE (X760)	PCM - Powertrain Control Module	DATA
JX73-12K532-FLB.vbf	Jaguar XE (X760)	PCM - Powertrain Control Module	DATA
JX73-12K532-FLD.vbf	Jaguar XE (X760)	PCM - Powertrain Control Module	DATA
JX73-12K532-FLF.vbf	Jaguar XE (X760)	PCM - Powertrain Control Module	DATA
JX73-12K532-FLG.vbf	Jaguar XE (X760)	PCM - Powertrain Control Module	DATA
JX73-12K532-FLH.vbf	Jaguar XE (X760)	PCM - Powertrain Control Module	DATA
JX73-12K532-FMA.vbf	Jaguar XE (X760)	PCM - Powertrain Control Module	DATA
JX73-12K532-FMB.vbf	Jaguar XE (X760)	PCM - Powertrain Control Module	DATA
JX73-12K532-FMD.vbf	Jaguar XE (X760)	PCM - Powertrain Control Module	DATA
JX73-12K532-FMF.vbf	Jaguar XE (X760)	PCM - Powertrain Control Module	DATA
JX73-12K532-FMG.vbf	Jaguar XE (X760)	PCM - Powertrain Control Module	DATA
JX73-12K532-FMH.vbf	Jaguar XE (X760)	PCM - Powertrain Control Module	DATA
JX73-12K532-FNA.vbf	Jaguar XE (X760)	PCM - Powertrain Control Module	DATA
JX73-12K532-FNB.vbf	Jaguar XE (X760)	PCM - Powertrain Control Module	DATA
JX73-12K532-FNC.vbf	Jaguar XE (X760)	PCM - Powertrain Control Module	DATA
JX73-12K532-FNE.vbf	Jaguar XE (X760)	PCM - Powertrain Control Module	DATA
JX73-12K532-FPC.vbf	Jaguar XE (X760)	PCM - Powertrain Control Module	DATA
JX73-12K532-FPD.vbf	Jaguar XE (X760)	PCM - Powertrain Control Module	EXE
JX73-12K532-FTC.vbf	Jaguar XE (X760)	PCM - Powertrain Control Module	DATA
JX73-12K532-FTE.vbf	Jaguar XE (X760)	PCM - Powertrain Control Module	DATA
JX73-12K532-GAA.vbf	Jaguar XE (X760)	PCM - Powertrain Control Module	DATA
JX73-12K532-GAB.vbf	Jaguar XE (X760)	PCM - Powertrain Control Module	DATA
JX73-12K532-GAC.vbf	Jaguar XE (X760)	PCM - Powertrain Control Module	DATA
JX73-12K532-GAD.vbf	Jaguar XE (X760)	PCM - Powertrain Control Module	DATA
JX73-12K532-GAE.vbf	Jaguar XE (X760)	PCM - Powertrain Control Module	DATA
JX73-12K532-GAF.vbf	Jaguar XE (X760)	PCM - Powertrain Control Module	DATA
JX73-12K532-GBA.vbf	Jaguar XE (X760)	PCM - Powertrain Control Module	DATA
JX73-12K532-GBB.vbf	Jaguar XE (X760)	PCM - Powertrain Control Module	DATA
JX73-12K532-GBC.vbf	Jaguar XE (X760)	PCM - Powertrain Control Module	DATA
JX73-12K532-GBE.vbf	Jaguar XE (X760)	PCM - Powertrain Control Module	DATA
JX73-12K532-GBF.vbf	Jaguar XE (X760)	PCM - Powertrain Control Module	EXE
JX73-12K532-GBG.vbf	Jaguar XE (X760)	PCM - Powertrain Control Module	DATA
JX73-12K532-GBH.vbf	Jaguar XE (X760)	PCM - Powertrain Control Module	DATA
JX73-12K532-GBJ.vbf	Jaguar XE (X760)	PCM - Powertrain Control Module	DATA
JX73-12K532-GCB.vbf	Jaguar XE (X760)	PCM - Powertrain Control Module	DATA
JX73-12K532-GCC.vbf	Jaguar XE (X760)	PCM - Powertrain Control Module	DATA
JX73-14B792-AA.vbf	Jaguar XE (X760)	ATCM - All Terrain Control Module	SIGCFG
JX73-14B793-AA.vbf	Jaguar XE (X760)	ATCM - All Terrain Control Module	EXE
JX73-14C025-AA.vbf	Jaguar XE (X760)	IPC - Instrument Panel Cluster (IPC) Control Module	SBL
JX73-14C025-AB.vbf	Jaguar XE (X760)	IPC - Instrument Panel Cluster (IPC) Control Module	SBL
JX73-14C026-AA.vbf	Jaguar XE (X760)	IPC - Instrument Panel Cluster (IPC) Control Module	EXE
JX73-14C026-AB.vbf	Jaguar XE (X760)	IPC - Instrument Panel Cluster (IPC) Control Module	EXE
JX73-14C026-AC.vbf	Jaguar XE (X760)	IPC - Instrument Panel Cluster (IPC) Control Module	EXE
JX73-14C026-AD.vbf	Jaguar XE (X760)	IPC - Instrument Panel Cluster (IPC) Control Module	EXE
JX73-14C026-AE.vbf	Jaguar XE (X760)	IPC - Instrument Panel Cluster (IPC) Control Module	EXE
JX73-14C088-BB.vbf	Jaguar XE (X760)	IPC - Instrument Panel Cluster (IPC) Control Module	DATA
JX73-14C088-BC.vbf	Jaguar XE (X760)	IPC - Instrument Panel Cluster (IPC) Control Module	DATA
JX73-14C088-CA.vbf	Jaguar XE (X760)	IPC - Instrument Panel Cluster (IPC) Control Module	EXE
JX73-14C088-CB.vbf	Jaguar XE (X760)	IPC - Instrument Panel Cluster (IPC) Control Module	EXE
JX73-14C088-CC.vbf	Jaguar XE (X760)	IPC - Instrument Panel Cluster (IPC) Control Module	EXE
JX73-14C088-CD.vbf	Jaguar XE (X760)	IPC - Instrument Panel Cluster (IPC) Control Module	EXE
JX73-14C088-CE.vbf	Jaguar XE (X760)	IPC - Instrument Panel Cluster (IPC) Control Module	EXE
JX73-14C088-CF.vbf	Jaguar XE (X760)	IPC - Instrument Panel Cluster (IPC) Control Module	EXE
JX73-14C105-AA.vbf	Jaguar XE (X760)	TMC Traffic Message Channel Module	DATA
JX73-14C105-AE.vbf	Jaguar XE (X760)	TMC Traffic Message Channel Module	DATA
JX73-14C185-AC.vbf	Jaguar XE (X760)	BCM - Body Control Module	DATA
JX73-14C217-AA.vbf	Jaguar XE (X760)	PSCM - Power Steering Control Module	EXE
JX73-14C218-AA.vbf	Jaguar XE (X760)	PSCM - Power Steering Control Module	DATA
JX73-14C218-AB.vbf	Jaguar XE (X760)	PSCM - Power Steering Control Module	DATA
JX73-14C218-BA.vbf	Jaguar XE (X760)	PSCM - Power Steering Control Module	DATA
JX73-14C218-BB.vbf	Jaguar XE (X760)	PSCM - Power Steering Control Module	DATA
JX73-14C218-CB.vbf	Jaguar XE (X760)	PSCM - Power Steering Control Module	DATA
JX73-14C218-DB.vbf	Jaguar XE (X760)	PSCM - Power Steering Control Module	DATA
JX73-14C218-EB.vbf	Jaguar XE (X760)	PSCM - Power Steering Control Module	DATA
JX73-14C218-FC.vbf	Jaguar XE (X760)	PSCM - Power Steering Control Module	DATA
JX73-14C527-BAB.vbf	Jaguar XE (X760)	AAM - Audio Amplifier Module	DATA
JX73-14C527-BB.vbf	Jaguar XE (X760)	AAM - Audio Amplifier Module	DATA
JX73-14C527-BBB.vbf	Jaguar XE (X760)	AAM - Audio Amplifier Module	DATA
JX73-14C527-BBC.vbf	Jaguar XE (X760)	AAM - Audio Amplifier Module	DATA
JX73-14C527-BBD.vbf	Jaguar XE (X760)	AAM - Audio Amplifier Module	DATA

File name	Vehicle line (indicative)	Module (ECU)	Type
JX73-14C527-BCB.vbf	Jaguar XE (X760)	AAM - Audio Amplifier Module	DATA
JX73-14C527-BEB.vbf	Jaguar XE (X760)	AAM - Audio Amplifier Module	DATA
JX73-14C527-CAB.vbf	Jaguar XE (X760)	AAM - Audio Amplifier Module	DATA
JX73-14C527-CB.vbf	Jaguar XE (X760)	AAM - Audio Amplifier Module	DATA
JX73-14C527-CBB.vbf	Jaguar XE (X760)	AAM - Audio Amplifier Module	DATA
JX73-14C527-CBC.vbf	Jaguar XE (X760)	AAM - Audio Amplifier Module	DATA
JX73-14C527-CBD.vbf	Jaguar XE (X760)	AAM - Audio Amplifier Module	DATA
JX73-14C527-CCB.vbf	Jaguar XE (X760)	AAM - Audio Amplifier Module	DATA
JX73-14C527-CEB.vbf	Jaguar XE (X760)	AAM - Audio Amplifier Module	DATA
JX73-14C570-BAA.vbf	Jaguar XE (X760)	PCM - Powertrain Control Module	EXE
JX73-14C570-BAB.vbf	Jaguar XE (X760)	PCM - Powertrain Control Module	EXE
JX73-14C570-BAD.vbf	Jaguar XE (X760)	PCM - Powertrain Control Module	EXE
JX73-14C570-BAE.vbf	Jaguar XE (X760)	PCM - Powertrain Control Module	EXE
JX73-14C570-BAF.vbf	Jaguar XE (X760)	PCM - Powertrain Control Module	EXE
JX73-14C570-BAG.vbf	Jaguar XE (X760)	PCM - Powertrain Control Module	EXE
JX73-14C570-BAH.vbf	Jaguar XE (X760)	PCM - Powertrain Control Module	EXE
JX73-14C570-BAJ.vbf	Jaguar XE (X760)	PCM - Powertrain Control Module	EXE
JX73-14C570-BAK.vbf	Jaguar XE (X760)	PCM - Powertrain Control Module	EXE
JX73-14C570-BCD.vbf	Jaguar XE (X760)	PCM - Powertrain Control Module	EXE
JX73-14C570-BCE.vbf	Jaguar XE (X760)	PCM - Powertrain Control Module	EXE
JX73-14C570-BCG.vbf	Jaguar XE (X760)	PCM - Powertrain Control Module	EXE
JX73-14C570-BCH.vbf	Jaguar XE (X760)	PCM - Powertrain Control Module	EXE
JX73-14C570-BEA.vbf	Jaguar XE (X760)	PCM - Powertrain Control Module	EXE
JX73-14C570-BED.vbf	Jaguar XE (X760)	PCM - Powertrain Control Module	EXE
JX73-14C570-BEE.vbf	Jaguar XE (X760)	PCM - Powertrain Control Module	EXE
JX73-14C570-BEG.vbf	Jaguar XE (X760)	PCM - Powertrain Control Module	EXE
JX73-14C570-BEH.vbf	Jaguar XE (X760)	PCM - Powertrain Control Module	EXE
JX73-14C570-BGB.vbf	Jaguar XE (X760)	PCM - Powertrain Control Module	EXE
JX73-14C570-BGD.vbf	Jaguar XE (X760)	PCM - Powertrain Control Module	EXE
JX73-14C570-BGE.vbf	Jaguar XE (X760)	PCM - Powertrain Control Module	EXE
JX73-14C570-BGF.vbf	Jaguar XE (X760)	PCM - Powertrain Control Module	EXE
JX73-14C570-BGG.vbf	Jaguar XE (X760)	PCM - Powertrain Control Module	EXE
JX73-14C570-BLB.vbf	Jaguar XE (X760)	PCM - Powertrain Control Module	EXE
JX73-14C570-BLD.vbf	Jaguar XE (X760)	PCM - Powertrain Control Module	EXE
JX73-14C570-BLE.vbf	Jaguar XE (X760)	PCM - Powertrain Control Module	EXE
JX73-14C570-BLF.vbf	Jaguar XE (X760)	PCM - Powertrain Control Module	EXE
JX73-14C570-BNB.vbf	Jaguar XE (X760)	PCM - Powertrain Control Module	EXE
JX73-14C570-BND.vbf	Jaguar XE (X760)	PCM - Powertrain Control Module	EXE
JX73-14C570-BNE.vbf	Jaguar XE (X760)	PCM - Powertrain Control Module	EXE
JX73-14C570-BNF.vbf	Jaguar XE (X760)	PCM - Powertrain Control Module	EXE
JX73-14C570-BTA.vbf	Jaguar XE (X760)	PCM - Powertrain Control Module	EXE
JX73-14C570-BTB.vbf	Jaguar XE (X760)	PCM - Powertrain Control Module	EXE
JX73-14C570-BTD.vbf	Jaguar XE (X760)	PCM - Powertrain Control Module	EXE
JX73-14C570-BTE.vbf	Jaguar XE (X760)	PCM - Powertrain Control Module	EXE
JX73-14C570-BTG.vbf	Jaguar XE (X760)	PCM - Powertrain Control Module	EXE
JX73-14C570-BTH.vbf	Jaguar XE (X760)	PCM - Powertrain Control Module	EXE
JX73-14C570-BTJ.vbf	Jaguar XE (X760)	PCM - Powertrain Control Module	EXE
JX73-14C570-BTK.vbf	Jaguar XE (X760)	PCM - Powertrain Control Module	EXE
JX73-14C570-BTL.vbf	Jaguar XE (X760)	PCM - Powertrain Control Module	EXE
JX73-14C570-BUB.vbf	Jaguar XE (X760)	PCM - Powertrain Control Module	EXE
JX73-14C570-BUD.vbf	Jaguar XE (X760)	PCM - Powertrain Control Module	EXE
JX73-14C570-BUE.vbf	Jaguar XE (X760)	PCM - Powertrain Control Module	EXE
JX73-14C570-BUG.vbf	Jaguar XE (X760)	PCM - Powertrain Control Module	EXE
JX73-14C570-BUH.vbf	Jaguar XE (X760)	PCM - Powertrain Control Module	EXE
JX73-14C570-TAA.vbf	Jaguar XE (X760)	PCM - Powertrain Control Module	EXE
JX73-14C570-TAB.vbf	Jaguar XE (X760)	PCM - Powertrain Control Module	EXE
JX73-14C570-TAC.vbf	Jaguar XE (X760)	PCM - Powertrain Control Module	EXE
JX73-14C570-TAD.vbf	Jaguar XE (X760)	PCM - Powertrain Control Module	EXE
JX73-14C570-TAE.vbf	Jaguar XE (X760)	PCM - Powertrain Control Module	EXE
JX73-14C570-TBA.vbf	Jaguar XE (X760)	PCM - Powertrain Control Module	EXE
JX73-14C570-TCB.vbf	Jaguar XE (X760)	PCM - Powertrain Control Module	EXE
JX73-14C570-TCC.vbf	Jaguar XE (X760)	PCM - Powertrain Control Module	EXE
JX73-14C570-TEB.vbf	Jaguar XE (X760)	PCM - Powertrain Control Module	EXE
JX73-14C570-TEC.vbf	Jaguar XE (X760)	PCM - Powertrain Control Module	EXE
JX73-14C570-TTA.vbf	Jaguar XE (X760)	PCM - Powertrain Control Module	EXE
JX73-14C570-TTB.vbf	Jaguar XE (X760)	PCM - Powertrain Control Module	EXE
JX73-14C570-TTC.vbf	Jaguar XE (X760)	PCM - Powertrain Control Module	EXE
JX73-14C570-UAA.vbf	Jaguar XE (X760)	PCM - Powertrain Control Module	EXE
JX73-14C570-UAB.vbf	Jaguar XE (X760)	PCM - Powertrain Control Module	EXE
JX73-14C570-UAC.vbf	Jaguar XE (X760)	PCM - Powertrain Control Module	EXE
JX73-14C570-UAD.vbf	Jaguar XE (X760)	PCM - Powertrain Control Module	EXE
JX73-14C570-UAE.vbf	Jaguar XE (X760)	PCM - Powertrain Control Module	EXE
JX73-14C570-UBA.vbf	Jaguar XE (X760)	PCM - Powertrain Control Module	EXE
JX73-14C609-AA.vbf	Jaguar XE (X760)	PSCM - Power Steering Control Module	DATA
JX73-14C609-AB.vbf	Jaguar XE (X760)	PSCM - Power Steering Control Module	DATA
JX73-14C653-AB.vbf	Jaguar XE (X760)	ACM - Audio Front Control Module	DATA

File name	Vehicle line (indicative)	Module (ECU)	Type
JX73-14D481-BA.vbf	Jaguar XE (X760)	IPMB - Image Processing Module B	DATA
JX73-14D481-BB.vbf	Jaguar XE (X760)	IPMB - Image Processing Module B	DATA
JX73-14D485-AA.vbf	Jaguar XE (X760)	IPMB - Image Processing Module B	EXE
JX73-14D485-AC.vbf	Jaguar XE (X760)	IPMB - Image Processing Module B	EXE
JX73-14D485-AE.vbf	Jaguar XE (X760)	IPMB - Image Processing Module B	EXE
JX73-14D485-AF.vbf	Jaguar XE (X760)	IPMB - Image Processing Module B	EXE
JX73-14D485-AG.vbf	Jaguar XE (X760)	IPMB - Image Processing Module B	EXE
JX73-14D485-BA.vbf	Jaguar XE (X760)	IPMB - Image Processing Module B	DATA
JX73-14D564-AB.vbf	Jaguar XE (X760)	SODL - Side Obstacle Detection Control Module - Left	DATA
JX73-14D564-AC.vbf	Jaguar XE (X760)	SODL - Side Obstacle Detection Control Module - Left	DATA
JX73-14D564-AD.vbf	Jaguar XE (X760)	SODL - Side Obstacle Detection Control Module - Left	DATA
JX73-14D564-BB.vbf	Jaguar XE (X760)	SODR - Side Obstacle Detection Control Module - Right	DATA
JX73-14D564-BC.vbf	Jaguar XE (X760)	SODR - Side Obstacle Detection Control Module - Right	DATA
JX73-14D564-BD.vbf	Jaguar XE (X760)	SODR - Side Obstacle Detection Control Module - Right	DATA
JX73-14E094-DAB.vbf	Jaguar XE (X760)	CHCM - Chassis Control Module	EXE
JX73-14E094-DAC.vbf	Jaguar XE (X760)	CHCM - Chassis Control Module	EXE
JX73-14E094-DAD.vbf	Jaguar XE (X760)	CHCM - Chassis Control Module	EXE
JX73-14E094-DCB.vbf	Jaguar XE (X760)	CHCM - Chassis Control Module	EXE
JX73-14E094-DCC.vbf	Jaguar XE (X760)	CHCM - Chassis Control Module	EXE
JX73-14E094-DCD.vbf	Jaguar XE (X760)	CHCM - Chassis Control Module	EXE
JX73-14E094-DDB.vbf	Jaguar XE (X760)	CHCM - Chassis Control Module	EXE
JX73-14E094-DDC.vbf	Jaguar XE (X760)	CHCM - Chassis Control Module	EXE
JX73-14E094-DDD.vbf	Jaguar XE (X760)	CHCM - Chassis Control Module	EXE
JX73-14E094-DEB.vbf	Jaguar XE (X760)	CHCM - Chassis Control Module	EXE
JX73-14E094-DEC.vbf	Jaguar XE (X760)	CHCM - Chassis Control Module	EXE
JX73-14E094-DED.vbf	Jaguar XE (X760)	CHCM - Chassis Control Module	EXE
JX73-14E094-DFB.vbf	Jaguar XE (X760)	CHCM - Chassis Control Module	EXE
JX73-14E094-DFC.vbf	Jaguar XE (X760)	CHCM - Chassis Control Module	EXE
JX73-14E094-DFD.vbf	Jaguar XE (X760)	CHCM - Chassis Control Module	EXE
JX73-14E094-DGB.vbf	Jaguar XE (X760)	CHCM - Chassis Control Module	EXE
JX73-14E094-DGC.vbf	Jaguar XE (X760)	CHCM - Chassis Control Module	EXE
JX73-14E094-DGD.vbf	Jaguar XE (X760)	CHCM - Chassis Control Module	EXE
JX73-14F022-AD.vbf	Jaguar XE (X760)	IPMB - Image Processing Module B	DATA
JX73-14F022-AE.vbf	Jaguar XE (X760)	IPMB - Image Processing Module B	DATA
JX73-14F022-AF.vbf	Jaguar XE (X760)	IPMB - Image Processing Module B	DATA
JX73-14F022-AG.vbf	Jaguar XE (X760)	IPMB - Image Processing Module B	DATA
JX73-14F022-BD.vbf	Jaguar XE (X760)	IPMB - Image Processing Module B	DATA
JX73-14F022-BE.vbf	Jaguar XE (X760)	IPMB - Image Processing Module B	DATA
JX73-14F022-BF.vbf	Jaguar XE (X760)	IPMB - Image Processing Module B	DATA
JX73-14F022-BG.vbf	Jaguar XE (X760)	IPMB - Image Processing Module B	DATA
JX73-7J104-FBA.vbf	Jaguar XE (X760)	TCM - Transmission Control Module	EXE
JX73-7J104-FBB.vbf	Jaguar XE (X760)	TCM - Transmission Control Module	EXE
JX73-7J104-FBC.vbf	Jaguar XE (X760)	TCM - Transmission Control Module	EXE
JX73-7J104-FBD.vbf	Jaguar XE (X760)	TCM - Transmission Control Module	EXE
JX73-7J104-FBE.vbf	Jaguar XE (X760)	TCM - Transmission Control Module	EXE
JX73-7J104-FCA.vbf	Jaguar XE (X760)	TCM - Transmission Control Module	EXE
JX73-7J104-FCB.vbf	Jaguar XE (X760)	TCM - Transmission Control Module	EXE
JX73-7J104-FCC.vbf	Jaguar XE (X760)	TCM - Transmission Control Module	EXE
JX73-7J104-FCD.vbf	Jaguar XE (X760)	TCM - Transmission Control Module	EXE
JX73-7J104-FCE.vbf	Jaguar XE (X760)	TCM - Transmission Control Module	EXE
JX73-7J104-FDA.vbf	Jaguar XE (X760)	TCM - Transmission Control Module	EXE
JX73-7J104-FDB.vbf	Jaguar XE (X760)	TCM - Transmission Control Module	EXE
JX73-7J104-FDC.vbf	Jaguar XE (X760)	TCM - Transmission Control Module	EXE
JX73-7J104-FDD.vbf	Jaguar XE (X760)	TCM - Transmission Control Module	EXE
JX73-7J104-FDE.vbf	Jaguar XE (X760)	TCM - Transmission Control Module	EXE
JX73-7J104-FDF.vbf	Jaguar XE (X760)	TCM - Transmission Control Module	EXE
JX73-7J104-FFA.vbf	Jaguar XE (X760)	TCM - Transmission Control Module	EXE
JX73-7J104-FFB.vbf	Jaguar XE (X760)	TCM - Transmission Control Module	EXE
JX73-7J104-FFC.vbf	Jaguar XE (X760)	TCM - Transmission Control Module	EXE
JX73-7J104-FFD.vbf	Jaguar XE (X760)	TCM - Transmission Control Module	EXE
JX73-7J104-FFE.vbf	Jaguar XE (X760)	TCM - Transmission Control Module	EXE
JX73-7J104-FFF.vbf	Jaguar XE (X760)	TCM - Transmission Control Module	EXE
JX73-7J104-FGA.vbf	Jaguar XE (X760)	TCM - Transmission Control Module	EXE
JX73-7J104-FGB.vbf	Jaguar XE (X760)	TCM - Transmission Control Module	EXE
JX73-7J104-FGC.vbf	Jaguar XE (X760)	TCM - Transmission Control Module	EXE
JX73-7J104-FGD.vbf	Jaguar XE (X760)	TCM - Transmission Control Module	EXE
JX73-7J104-FKA.vbf	Jaguar XE (X760)	TCM - Transmission Control Module	EXE
JX73-7J104-FKB.vbf	Jaguar XE (X760)	TCM - Transmission Control Module	EXE
JX73-7J104-FKC.vbf	Jaguar XE (X760)	TCM - Transmission Control Module	EXE
JX73-7J104-FKE.vbf	Jaguar XE (X760)	TCM - Transmission Control Module	EXE
JX73-7J104-FLA.vbf	Jaguar XE (X760)	TCM - Transmission Control Module	EXE
JX73-7J104-FLB.vbf	Jaguar XE (X760)	TCM - Transmission Control Module	EXE
JX73-7J104-FLC.vbf	Jaguar XE (X760)	TCM - Transmission Control Module	EXE
JX73-7J104-FLD.vbf	Jaguar XE (X760)	TCM - Transmission Control Module	EXE
JX73-7J104-FLE.vbf	Jaguar XE (X760)	TCM - Transmission Control Module	EXE
JX73-7J104-FLF.vbf	Jaguar XE (X760)	TCM - Transmission Control Module	EXE

File name	Vehicle line (indicative)	Module (ECU)	Type
JX73-7J104-FNA.vbf	Jaguar XE (X760)	TCM - Transmission Control Module	EXE
JX73-7J104-FNB.vbf	Jaguar XE (X760)	TCM - Transmission Control Module	EXE
JX73-7J104-FNC.vbf	Jaguar XE (X760)	TCM - Transmission Control Module	EXE
JX73-7J104-FND.vbf	Jaguar XE (X760)	TCM - Transmission Control Module	EXE
JX73-7J104-FTB.vbf	Jaguar XE (X760)	TCM - Transmission Control Module	EXE
JX73-7J104-FTC.vbf	Jaguar XE (X760)	TCM - Transmission Control Module	EXE
JX73-7J104-FTD.vbf	Jaguar XE (X760)	TCM - Transmission Control Module	EXE
JX73-7J104-FTE.vbf	Jaguar XE (X760)	TCM - Transmission Control Module	EXE
JX73-7J104-FTF.vbf	Jaguar XE (X760)	TCM - Transmission Control Module	EXE
JX73-7J104-FUA.vbf	Jaguar XE (X760)	TCM - Transmission Control Module	EXE
JX73-7J104-FUB.vbf	Jaguar XE (X760)	TCM - Transmission Control Module	EXE
JX73-7J104-FUC.vbf	Jaguar XE (X760)	TCM - Transmission Control Module	EXE
JX73-7J104-FUD.vbf	Jaguar XE (X760)	TCM - Transmission Control Module	EXE
JX73-7J104-FUE.vbf	Jaguar XE (X760)	TCM - Transmission Control Module	EXE
JX73-7J104-FUF.vbf	Jaguar XE (X760)	TCM - Transmission Control Module	EXE
JX73-7J104-FVB.vbf	Jaguar XE (X760)	TCM - Transmission Control Module	EXE
JX73-7J104-FVC.vbf	Jaguar XE (X760)	TCM - Transmission Control Module	EXE
JX73-7J104-FVD.vbf	Jaguar XE (X760)	TCM - Transmission Control Module	EXE
JX73-7J104-FVE.vbf	Jaguar XE (X760)	TCM - Transmission Control Module	EXE
JX73-7J104-FVF.vbf	Jaguar XE (X760)	TCM - Transmission Control Module	EXE
JX73-7J104-FXA.vbf	Jaguar XE (X760)	TCM - Transmission Control Module	EXE
JX73-7J104-FXB.vbf	Jaguar XE (X760)	TCM - Transmission Control Module	EXE
JX73-7J104-FXC.vbf	Jaguar XE (X760)	TCM - Transmission Control Module	EXE
JX73-7J104-FXD.vbf	Jaguar XE (X760)	TCM - Transmission Control Module	EXE
JX73-7J104-FXE.vbf	Jaguar XE (X760)	TCM - Transmission Control Module	EXE
JX73-7J104-FYA.vbf	Jaguar XE (X760)	TCM - Transmission Control Module	EXE
JX73-7J104-FYB.vbf	Jaguar XE (X760)	TCM - Transmission Control Module	EXE
JX73-7J104-FYC.vbf	Jaguar XE (X760)	TCM - Transmission Control Module	EXE
JX73-7J104-FYD.vbf	Jaguar XE (X760)	TCM - Transmission Control Module	EXE
JX73-7J104-FYE.vbf	Jaguar XE (X760)	TCM - Transmission Control Module	EXE
JY32-14C029-AA.vbf	Not specified	DSM - Driver Front Seat Module	SBL
JY32-14C204-FAA.vbf	Not specified	PCM - Powertrain Control Module	EXE
JY32-14C204-FAB.vbf	Not specified	PCM - Powertrain Control Module	EXE
JY32-14C204-FAC.vbf	Not specified	PCM - Powertrain Control Module	EXE
JY32-14C550-AA.vbf	Not specified	PSM - Passenger Front Seat Module	SBL
JY32-14G038-AA.vbf	Not specified	RRSM - Rear Right Module	SBL
JY32-14G048-AA.vbf	Not specified	RLSM - Rear Left Seat Module	SBL
JY32-19C204-AA.vbf	Not specified	IMC - Infotainment Master Controller	EXE
K2C2-14C034-AA.vbf	Discovery Sport (L550)	DSM - Driver Front Seat Module	EXE
K2C2-14C549-AA.vbf	Discovery Sport (L550)	DSM - Driver Front Seat Module	EXE
K2H2-14C034-AA.vbf	Not specified	DSM - Driver Front Seat Module	EXE
K2H2-14C549-AA.vbf	Not specified	PSM - Passenger Front Seat Module	EXE
K2H2-19C273-AB.vbf	Not specified	LPDM - Left Power Sliding Door Module	EXE
K2H2-19C273-AC.vbf	Not specified	LPDM - Left Power Sliding Door Module	EXE
K2H2-19C273-AD.vbf	Not specified	LPDM - Left Power Sliding Door Module	EXE
K2H2-19C273-BA.vbf	Not specified	LPDM - Left Power Sliding Door Module	EXE
K2H2-19C274-AB.vbf	Not specified	LPDM - Left Power Sliding Door Module	EXE
K2H2-19C275-AB.vbf	Not specified	LPDM - Left Power Sliding Door Module	SBL
K2H2-19C275-AC.vbf	Not specified	LPDM - Left Power Sliding Door Module	SBL
K7A3-14C273-FA.vbf	Jaguar XE (X760)	PCM - Powertrain Control Module	SBL
K8A2-14C273-PAA.vbf	Not specified	PCM - Powertrain Control Module	SBL
K8A2-14C570-BAC.vbf	Not specified	PCM - Powertrain Control Module	EXE
K8A2-14C570-BAD.vbf	Not specified	PCM - Powertrain Control Module	EXE
K8A2-14C570-BAE.vbf	Not specified	PCM - Powertrain Control Module	EXE
K8A2-14C570-BAF.vbf	Not specified	PCM - Powertrain Control Module	EXE
K8A2-14C570-BCC.vbf	Not specified	PCM - Powertrain Control Module	EXE
K8A2-14C570-BCD.vbf	Not specified	PCM - Powertrain Control Module	EXE
K8A2-14C570-BCE.vbf	Not specified	PCM - Powertrain Control Module	EXE
K8A2-14C570-BEC.vbf	Not specified	PCM - Powertrain Control Module	EXE
K8A2-14C570-BED.vbf	Not specified	PCM - Powertrain Control Module	EXE
K8A2-14C570-BEE.vbf	Not specified	PCM - Powertrain Control Module	EXE
K8A2-14C570-BFB.vbf	Check in SDD (unconfirmed)	PCM - Powertrain Control Module	EXE
K8A2-14C570-BFC.vbf	Not specified	PCM - Powertrain Control Module	EXE
K8A2-14C570-BFD.vbf	Not specified	PCM - Powertrain Control Module	EXE
K8A2-14C570-BFE.vbf	Not specified	PCM - Powertrain Control Module	EXE
K8A2-14C570-BFF.vbf	Not specified	PCM - Powertrain Control Module	EXE
K8A2-14C570-BFG.vbf	Not specified	PCM - Powertrain Control Module	EXE
K8A2-14C570-BGC.vbf	Not specified	PCM - Powertrain Control Module	EXE
K8A2-14C570-BGD.vbf	Not specified	PCM - Powertrain Control Module	EXE
K8A2-14C570-BGE.vbf	Not specified	PCM - Powertrain Control Module	EXE
K8A2-14C570-BGF.vbf	Not specified	PCM - Powertrain Control Module	EXE
K8A2-14C570-BHA.vbf	Not specified	PCM - Powertrain Control Module	EXE
K8A2-14C570-BHB.vbf	Check in SDD (unconfirmed)	PCM - Powertrain Control Module	EXE
K8A2-14C570-BHC.vbf	Not specified	PCM - Powertrain Control Module	EXE
K8A2-14C570-BHD.vbf	Not specified	PCM - Powertrain Control Module	EXE
K8A2-14C570-BHE.vbf	Not specified	PCM - Powertrain Control Module	EXE

File name	Vehicle line (indicative)	Module (ECU)	Type
K8A2-14C570-BHF.vbf	Not specified	PCM - Powertrain Control Module	EXE
K8A2-14C570-BLC.vbf	Not specified	PCM - Powertrain Control Module	EXE
K8A2-14C570-BLD.vbf	Not specified	PCM - Powertrain Control Module	EXE
K8A2-14C570-BLE.vbf	Not specified	PCM - Powertrain Control Module	EXE
K8A2-14C570-BNC.vbf	Not specified	PCM - Powertrain Control Module	EXE
K8A2-14C570-BND.vbf	Not specified	PCM - Powertrain Control Module	EXE
K8A2-14C570-BNE.vbf	Not specified	PCM - Powertrain Control Module	EXE
K8A2-14C570-BPA.vbf	Not specified	PCM - Powertrain Control Module	EXE
K8A2-14C570-BPB.vbf	Check in SDD (unconfirmed)	PCM - Powertrain Control Module	EXE
K8A2-14C570-BPC.vbf	Not specified	PCM - Powertrain Control Module	EXE
K8A2-14C570-BPD.vbf	Not specified	PCM - Powertrain Control Module	EXE
K8A2-14C570-BPE.vbf	Not specified	PCM - Powertrain Control Module	EXE
K8A2-14C570-BPF.vbf	Not specified	PCM - Powertrain Control Module	EXE
K8A2-14C570-BRA.vbf	Not specified	PCM - Powertrain Control Module	EXE
K8A2-14C570-BRB.vbf	Check in SDD (unconfirmed)	PCM - Powertrain Control Module	EXE
K8A2-14C570-BRC.vbf	Not specified	PCM - Powertrain Control Module	EXE
K8A2-14C570-BRD.vbf	Not specified	PCM - Powertrain Control Module	EXE
K8A2-14C570-BRE.vbf	Not specified	PCM - Powertrain Control Module	EXE
K8A2-14C570-BRF.vbf	Not specified	PCM - Powertrain Control Module	EXE
K8A2-14C570-BTC.vbf	Not specified	PCM - Powertrain Control Module	EXE
K8A2-14C570-BTD.vbf	Not specified	PCM - Powertrain Control Module	EXE
K8A2-14C570-BTE.vbf	Not specified	PCM - Powertrain Control Module	EXE
K8A2-14C570-BTF.vbf	Not specified	PCM - Powertrain Control Module	EXE
K8A2-14C570-BUC.vbf	Not specified	PCM - Powertrain Control Module	EXE
K8A2-14C570-BUD.vbf	Not specified	PCM - Powertrain Control Module	EXE
K8A2-14C570-BUE.vbf	Not specified	PCM - Powertrain Control Module	EXE
K8AM-14C218-DA.vbf	Not specified	PSCM - Power Steering Control Module	DATA
K8AM-14C218-DB.vbf	Not specified	PSCM - Power Steering Control Module	DATA
K8AM-14C549-AA.vbf	Not specified	DSM - Driver Front Seat Module	EXE
K8D2-14C030-AB.vbf	Check in SDD (unconfirmed)	DSM - Driver Front Seat Module	EXE
K8D2-14C030-AC.vbf	Check in SDD (unconfirmed)	DSM - Driver Front Seat Module	EXE
K8D2-14C034-AA.vbf	Check in SDD (unconfirmed)	DSM - Driver Front Seat Module	EXE
K8D2-14C036-AL.vbf	Check in SDD (unconfirmed)	ABS - Anit-Lock Brake System (ABS) Control Module	EXE
K8D2-14C036-AN.vbf	Check in SDD (unconfirmed)	ABS - Anit-Lock Brake System (ABS) Control Module	EXE
K8D2-14C036-AP.vbf	Check in SDD (unconfirmed)	ABS - Anit-Lock Brake System (ABS) Control Module	EXE
K8D2-14C036-AR.vbf	Check in SDD (unconfirmed)	ABS - Anit-Lock Brake System (ABS) Control Module	EXE
K8D2-14C039-AA.vbf	Check in SDD (unconfirmed)	ABS - Anit-Lock Brake System (ABS) Control Module	SBL
K8D2-14C090-AE.vbf	Check in SDD (unconfirmed)	PAM - Parking Assist Control Module	EXE
K8D2-14C090-AF.vbf	Check in SDD (unconfirmed)	PAM - Parking Assist Control Module	EXE
K8D2-14C090-AG.vbf	Check in SDD (unconfirmed)	PAM - Parking Assist Control Module	EXE
K8D2-14C090-AH.vbf	Check in SDD (unconfirmed)	PAM - Parking Assist Control Module	EXE
K8D2-14C104-AB.vbf	Check in SDD (unconfirmed)	RFA - Remote Function Actuator	EXE
K8D2-14C104-AC.vbf	Check in SDD (unconfirmed)	RFA - Remote Function Actuator	EXE
K8D2-14C104-AD.vbf	Check in SDD (unconfirmed)	RFA - Remote Function Actuator	EXE
K8D2-14C104-AF.vbf	Check in SDD (unconfirmed)	RFA - Remote Function Actuator	EXE
K8D2-14C104-AG.vbf	Check in SDD (unconfirmed)	RFA - Remote Function Actuator	EXE
K8D2-14C107-AA.vbf	Check in SDD (unconfirmed)	TMC Traffic Message Channel Module	SBL
K8D2-14C152-AC.vbf	Check in SDD (unconfirmed)	TPM - Tire Pressure Monitor Module	DATA
K8D2-14C152-AD.vbf	Check in SDD (unconfirmed)	TPM - Tire Pressure Monitor Module	DATA
K8D2-14C152-AE.vbf	Check in SDD (unconfirmed)	TPM - Tire Pressure Monitor Module	DATA
K8D2-14C152-AF.vbf	Check in SDD (unconfirmed)	TPM - Tire Pressure Monitor Module	DATA
K8D2-14C185-AA.vbf	Check in SDD (unconfirmed)	BCM - Body Control Module	DATA
K8D2-14C185-AB.vbf	Check in SDD (unconfirmed)	BCM - Body Control Module	DATA
K8D2-14C185-AC.VBF	Check in SDD (unconfirmed)	BCM - Body Control Module	DATA
K8D2-14C197-AD.vbf	Check in SDD (unconfirmed)	BECM - Battery Energy Control Module	EXE
K8D2-14C197-AF.vbf	Check in SDD (unconfirmed)	BECM - Battery Energy Control Module	EXE
K8D2-14C197-AG.vbf	Check in SDD (unconfirmed)	BECM - Battery Energy Control Module	EXE
K8D2-14C197-AH.vbf	Check in SDD (unconfirmed)	BECM - Battery Energy Control Module	EXE
K8D2-14C197-AJ.vbf	Check in SDD (unconfirmed)	BECM - Battery Energy Control Module	EXE
K8D2-14C197-AK.vbf	Check in SDD (unconfirmed)	BECM - Battery Energy Control Module	EXE
K8D2-14C197-AM.vbf	Check in SDD (unconfirmed)	BECM - Battery Energy Control Module	EXE
K8D2-14C197-AN.vbf	Check in SDD (unconfirmed)	BECM - Battery Energy Control Module	EXE
K8D2-14C197-AP.vbf	Check in SDD (unconfirmed)	BECM - Battery Energy Control Module	EXE
K8D2-14C197-AR.vbf	Check in SDD (unconfirmed)	BECM - Battery Energy Control Module	EXE
K8D2-14C198-AD.vbf	Check in SDD (unconfirmed)	BECM - Battery Energy Control Module	EXE
K8D2-14C198-AF.vbf	Check in SDD (unconfirmed)	BECM - Battery Energy Control Module	EXE
K8D2-14C198-AG.vbf	Check in SDD (unconfirmed)	BECM - Battery Energy Control Module	EXE
K8D2-14C198-AH.vbf	Check in SDD (unconfirmed)	BECM - Battery Energy Control Module	EXE
K8D2-14C198-AJ.vbf	Check in SDD (unconfirmed)	BECM - Battery Energy Control Module	EXE
K8D2-14C198-AK.vbf	Check in SDD (unconfirmed)	BECM - Battery Energy Control Module	EXE
K8D2-14C198-AM.vbf	Check in SDD (unconfirmed)	BECM - Battery Energy Control Module	EXE
K8D2-14C198-AN.vbf	Check in SDD (unconfirmed)	BECM - Battery Energy Control Module	EXE
K8D2-14C198-AP.vbf	Check in SDD (unconfirmed)	BECM - Battery Energy Control Module	EXE
K8D2-14C198-AR.vbf	Check in SDD (unconfirmed)	BECM - Battery Energy Control Module	EXE
K8D2-14C200-AA.vbf	Check in SDD (unconfirmed)	BECM - Battery Energy Control Module	SBL
K8D2-14C217-AC.vbf	Check in SDD (unconfirmed)	PSCM - Power Steering Control Module	EXE

File name	Vehicle line (indicative)	Module (ECU)	Type
K8D2-14C217-AD.vbf	Check in SDD (unconfirmed)	PSCM - Power Steering Control Module	EXE
K8D2-14C217-AE.vbf	Check in SDD (unconfirmed)	PSCM - Power Steering Control Module	EXE
K8D2-14C217-AF.vbf	Check in SDD (unconfirmed)	PSCM - Power Steering Control Module	EXE
K8D2-14C218-BA.vbf	Check in SDD (unconfirmed)	PSCM - Power Steering Control Module	DATA
K8D2-14C218-BB.vbf	Check in SDD (unconfirmed)	PSCM - Power Steering Control Module	DATA
K8D2-14C218-CA.vbf	Check in SDD (unconfirmed)	PSCM - Power Steering Control Module	DATA
K8D2-14C218-CB.vbf	Check in SDD (unconfirmed)	PSCM - Power Steering Control Module	DATA
K8D2-14C218-EA.vbf	Check in SDD (unconfirmed)	PSCM - Power Steering Control Module	DATA
K8D2-14C218-EB.vbf	Check in SDD (unconfirmed)	PSCM - Power Steering Control Module	DATA
K8D2-14C220-AB.vbf	Check in SDD (unconfirmed)	PSCM - Power Steering Control Module	SBL
K8D2-14C339-AA.vbf	Check in SDD (unconfirmed)	TCM - Transmission Control Module	SBL
K8D2-14C386-AA.vbf	Check in SDD (unconfirmed)	PSCM - Power Steering Control Module	SIGCFG
K8D2-14C413-AA.vbf	Check in SDD (unconfirmed)	DSM - Driver Front Seat Module	EXE
K8D2-14C430-AB.vbf	Check in SDD (unconfirmed)	TMC Traffic Message Channel Module	EXE
K8D2-14C526-AA.vbf	Check in SDD (unconfirmed)	AAM - Audio Amplifier Module	EXE
K8D2-14C549-AA.vbf	Check in SDD (unconfirmed)	PSM - Passenger Front Seat Module	EXE
K8D2-14C609-AC.vbf	Check in SDD (unconfirmed)	PSCM - Power Steering Control Module	DATA
K8D2-14C609-AD.vbf	Check in SDD (unconfirmed)	PSCM - Power Steering Control Module	DATA
K8D2-14C609-AE.vbf	Check in SDD (unconfirmed)	PSCM - Power Steering Control Module	DATA
K8D2-14D368-AJ.vbf	Check in SDD (unconfirmed)	SODR - Side Obstacle Detection Control Module - Right	EXE
K8D2-14D368-AL.vbf	Check in SDD (unconfirmed)	SODR - Side Obstacle Detection Control Module - Right	EXE
K8D2-14D368-AM.vbf	Check in SDD (unconfirmed)	SODR - Side Obstacle Detection Control Module - Right	EXE
K8D2-14D368-AN.vbf	Check in SDD (unconfirmed)	SODR - Side Obstacle Detection Control Module - Right	EXE
K8D2-14D368-BA.vbf	Check in SDD (unconfirmed)	SODR - Side Obstacle Detection Control Module - Right	EXE
K8D2-14D370-AB.vbf	Check in SDD (unconfirmed)	SODR - Side Obstacle Detection Control Module - Right	SBL
K8D2-14D370-AC.vbf	Check in SDD (unconfirmed)	SODR - Side Obstacle Detection Control Module - Right	SBL
K8D2-14D370-AD.vbf	Check in SDD (unconfirmed)	SODR - Side Obstacle Detection Control Module - Right	SBL
K8D2-14D370-BA.vbf	Check in SDD (unconfirmed)	SODR - Side Obstacle Detection Control Module - Right	SBL
K8D2-14D458-AA.vbf	Check in SDD (unconfirmed)	EPICD - Electric Power Inverter Converter Control Module	SIGCFG
K8D2-14D459-AC.vbf	Check in SDD (unconfirmed)	EPICD - Electric Power Inverter Converter Control Module	EXE
K8D2-14D459-AD.vbf	Check in SDD (unconfirmed)	EPICD - Electric Power Inverter Converter Control Module	EXE
K8D2-14D459-AE.vbf	Check in SDD (unconfirmed)	EPICD - Electric Power Inverter Converter Control Module	EXE
K8D2-14D459-AH.vbf	Check in SDD (unconfirmed)	EPICD - Electric Power Inverter Converter Control Module	EXE
K8D2-14D459-AJ.vbf	Check in SDD (unconfirmed)	EPICD - Electric Power Inverter Converter Control Module	EXE
K8D2-14D459-AK.vbf	Check in SDD (unconfirmed)	EPICD - Electric Power Inverter Converter Control Module	EXE
K8D2-14D459-AL.vbf	Check in SDD (unconfirmed)	EPICD - Electric Power Inverter Converter Control Module	EXE
K8D2-14D459-AM.vbf	Check in SDD (unconfirmed)	HDCDC - High Voltage DC-DC Converter Control Module	EXE
K8D2-14D461-AA.vbf	Check in SDD (unconfirmed)	EPICD - Electric Power Inverter Converter Control Module	SBL
K8D2-14D461-AB.vbf	Check in SDD (unconfirmed)	EPICD - Electric Power Inverter Converter Control Module	SBL
K8D2-14D461-AC.vbf	Check in SDD (unconfirmed)	EPICD - Electric Power Inverter Converter Control Module	SBL
K8D2-14E093-UC.vbf	Check in SDD (unconfirmed)	CHCM - Chassis Control Module	EXE
K8D2-14E093-UE.vbf	Check in SDD (unconfirmed)	CHCM - Chassis Control Module	EXE
K8D2-14F396-AA.vbf	Check in SDD (unconfirmed)	IPMA - Image Processing Module A	EXE
K8D2-14F396-BA.vbf	Check in SDD (unconfirmed)	IPMA - Image Processing Module A	EXE
K8D2-14F530-BG.vbf	Check in SDD (unconfirmed)	GWM - Gateway Module A	EXE
K8D2-14F530-CG.vbf	Check in SDD (unconfirmed)	GWM - Gateway Module A	EXE
K8D2-14F530-CH.vbf	Check in SDD (unconfirmed)	GWM - Gateway Module A	EXE
K8D2-14F530-DD.vbf	Check in SDD (unconfirmed)	GWM - Gateway Module A	EXE
K8D2-14F530-DF.vbf	Check in SDD (unconfirmed)	GWM - Gateway Module A	EXE
K8D2-14F530-DG.vbf	Check in SDD (unconfirmed)	GWM - Gateway Module A	EXE
K8D2-14F530-DH.vbf	Check in SDD (unconfirmed)	GWM - Gateway Module A	EXE
K8D2-14F530-DJ.vbf	Check in SDD (unconfirmed)	GWM - Gateway Module A	EXE
K8D2-14F530-DK.vbf	Check in SDD (unconfirmed)	GWM - Gateway Module A	EXE
K8D2-14F530-EE.vbf	Check in SDD (unconfirmed)	GWM - Gateway Module A	EXE
K8D2-14F530-EF.vbf	Check in SDD (unconfirmed)	GWM - Gateway Module A	EXE
K8D2-14F530-EG.vbf	Check in SDD (unconfirmed)	GWM - Gateway Module A	EXE
K8D2-14F530-EH.vbf	Check in SDD (unconfirmed)	GWM - Gateway Module A	EXE
K8D2-14F530-EK.vbf	Check in SDD (unconfirmed)	GWM - Gateway Module A	EXE
K8D2-14F530-EL.vbf	Check in SDD (unconfirmed)	GWM - Gateway Module A	EXE
K8D2-14F531-BG.vbf	Check in SDD (unconfirmed)	GWM - Gateway Module A	DATA
K8D2-14F531-CG.vbf	Check in SDD (unconfirmed)	GWM - Gateway Module A	DATA
K8D2-14F531-CH.vbf	Check in SDD (unconfirmed)	GWM - Gateway Module A	DATA
K8D2-14F531-DD.vbf	Check in SDD (unconfirmed)	GWM - Gateway Module A	DATA
K8D2-14F531-DF.vbf	Check in SDD (unconfirmed)	GWM - Gateway Module A	DATA
K8D2-14F531-DG.vbf	Check in SDD (unconfirmed)	GWM - Gateway Module A	DATA
K8D2-14F531-DH.vbf	Check in SDD (unconfirmed)	GWM - Gateway Module A	DATA
K8D2-14F531-DJ.vbf	Check in SDD (unconfirmed)	GWM - Gateway Module A	DATA
K8D2-14F531-DK.vbf	Check in SDD (unconfirmed)	GWM - Gateway Module A	DATA
K8D2-14F531-EE.vbf	Check in SDD (unconfirmed)	GWM - Gateway Module A	DATA
K8D2-14F531-EF.vbf	Check in SDD (unconfirmed)	GWM - Gateway Module A	DATA
K8D2-14F531-EG.vbf	Check in SDD (unconfirmed)	GWM - Gateway Module A	DATA
K8D2-14F531-EH.vbf	Check in SDD (unconfirmed)	GWM - Gateway Module A	DATA
K8D2-14F531-EK.vbf	Check in SDD (unconfirmed)	GWM - Gateway Module A	DATA
K8D2-14G131-AD.vbf	Check in SDD (unconfirmed)	SOBDMB - Secondary OBD Control Module B	EXE
K8D2-14G131-AF.vbf	Check in SDD (unconfirmed)	SOBDMB - Secondary OBD Control Module B	EXE
K8D2-14G131-AG.vbf	Check in SDD (unconfirmed)	SOBDMB - Secondary OBD Control Module B	EXE

File name	Vehicle line (indicative)	Module (ECU)	Type
K8D2-14G131-AH.vbf	Check in SDD (unconfirmed)	SOBDMB - Secondary OBD Control Module B	EXE
K8D2-14G131-AJ.vbf	Check in SDD (unconfirmed)	SOBDMB - Secondary OBD Control Module B	EXE
K8D2-14G131-BA.vbf	Check in SDD (unconfirmed)	SOBDMB - Secondary OBD Control Module B	EXE
K8D2-14G131-BB.vbf	Check in SDD (unconfirmed)	SGM - Starter / Generator Control Module	EXE
K8D2-14G133-AA.vbf	Check in SDD (unconfirmed)	SOBDMB - Secondary OBD Control Module B	SBL
K8D2-14G133-AB.vbf	Check in SDD (unconfirmed)	SOBDMB - Secondary OBD Control Module B	EXE
K8D2-14G133-BC.vbf	Check in SDD (unconfirmed)	SGM - Starter / Generator Control Module	EXE
K8D2-14G133-CA.vbf	Check in SDD (unconfirmed)	SOBDMB - Secondary OBD Control Module B	EXE
K8D2-18D619-AA.vbf	Check in SDD (unconfirmed)	HVAC - HVAC Control Module	EXE
K8D2-18D619-AB.vbf	Check in SDD (unconfirmed)	HVAC - HVAC Control Module	EXE
K8D2-18D619-BA.vbf	Check in SDD (unconfirmed)	HVAC - HVAC Control Module	EXE
K8D2-19C273-AA.vbf	Check in SDD (unconfirmed)	LPDM - Left Power Sliding Door Module	EXE
K8D2-19C273-AB.vbf	Check in SDD (unconfirmed)	LPDM - Left Power Sliding Door Module	EXE
K8D2-19C273-AC.vbf	Check in SDD (unconfirmed)	LPDM - Left Power Sliding Door Module	EXE
K8D2-19C273-AD.vbf	Check in SDD (unconfirmed)	LPDM - Left Power Sliding Door Module	EXE
K8D2-19C273-BB.vbf	Check in SDD (unconfirmed)	LPDM - Left Power Sliding Door Module	EXE
K8D2-19C273-BC.vbf	Check in SDD (unconfirmed)	LPDM - Left Power Sliding Door Module	EXE
K8D2-19C273-BD.vbf	Check in SDD (unconfirmed)	LPDM - Left Power Sliding Door Module	EXE
K8D2-19C274-BA.vbf	Check in SDD (unconfirmed)	LPDM - Left Power Sliding Door Module	DATA
K8D2-19C274-BB.vbf	Check in SDD (unconfirmed)	LPDM - Left Power Sliding Door Module	DATA
K8D2-19C274-BC.vbf	Check in SDD (unconfirmed)	LPDM - Left Power Sliding Door Module	DATA
K8D2-19C275-BA.vbf	Check in SDD (unconfirmed)	LPDM - Left Power Sliding Door Module	SBL
K8D2-19C275-BB.vbf	Check in SDD (unconfirmed)	LPDM - Left Power Sliding Door Module	SBL
K8D2-4C178-AE.vbf	Check in SDD (unconfirmed)	Not specified	SIGCFG
K8D2-4C179-AA.vbf	Check in SDD (unconfirmed)	Not specified	EXE
K8D2-4C179-AB.vbf	Check in SDD (unconfirmed)	Not specified	EXE
K8D2-4C179-AC.vbf	Check in SDD (unconfirmed)	Not specified	EXE
K8D2-4C179-AD.vbf	Check in SDD (unconfirmed)	Not specified	EXE
K8D2-4C179-AE.vbf	Check in SDD (unconfirmed)	Not specified	EXE
K8D2-4C179-AF.vbf	Check in SDD (unconfirmed)	Not specified	EXE
K8D2-4C180-AA.vbf	Check in SDD (unconfirmed)	Not specified	DATA
K8D2-4C180-AB.vbf	Check in SDD (unconfirmed)	Not specified	DATA
K8D2-4C180-AC.vbf	Check in SDD (unconfirmed)	Not specified	DATA
K8D2-4C180-AD.vbf	Check in SDD (unconfirmed)	Not specified	DATA
K8D2-4C180-AE.vbf	Check in SDD (unconfirmed)	Not specified	DATA
K8D2-4C180-AF.vbf	Check in SDD (unconfirmed)	Not specified	DATA
K8D2-4C181-AA.vbf	Check in SDD (unconfirmed)	Not specified	SBL
K8D2-70713-AA.vbf	Check in SDD (unconfirmed)	TCU - Telematic Control Unit Module	DATA
K8D2-70713-AB.vbf	Jaguar XE (X760)	TCU - Telematic Control Unit Module	DATA
K8D2-70713-AC.vbf	Check in SDD (unconfirmed)	TCU - Telematic Control Unit Module	DATA
K8D2-70713-AD.vbf	Check in SDD (unconfirmed)	TCU - Telematic Control Unit Module	DATA
K8D2-70713-AE.vbf	Check in SDD (unconfirmed)	TCU - Telematic Control Unit Module	DATA
K8D2-70713-AF.vbf	Check in SDD (unconfirmed)	TCU - Telematic Control Unit Module	DATA
K8D2-70713-AG.vbf	Check in SDD (unconfirmed)	TCU - Telematic Control Unit Module	DATA
K8D2-70713-AH.vbf	Check in SDD (unconfirmed)	TCU - Telematic Control Unit Module	DATA
K8D2-70713-AJ.vbf	Check in SDD (unconfirmed)	TCU - Telematic Control Unit Module	DATA
K8D2-70713-AK.vbf	Check in SDD (unconfirmed)	TCU - Telematic Control Unit Module	DATA
K8D2-70713-ANF.vbf	Check in SDD (unconfirmed)	TCU - Telematic Control Unit Module	DATA
K8D2-70713-ANX.vbf	Check in SDD (unconfirmed)	TCU - Telematic Control Unit Module	DATA
K8D2-70713-APF.vbf	Check in SDD (unconfirmed)	TCU - Telematic Control Unit Module	DATA
K8D2-70713-CA.vbf	Check in SDD (unconfirmed)	TCU - Telematic Control Unit Module	DATA
K8D2-70713-CB.vbf	Jaguar XE (X760)	TCU - Telematic Control Unit Module	DATA
K8D2-70713-CC.vbf	Check in SDD (unconfirmed)	TCU - Telematic Control Unit Module	DATA
K8D2-70713-CD.vbf	Check in SDD (unconfirmed)	TCU - Telematic Control Unit Module	DATA
K8D2-70713-CE.vbf	Check in SDD (unconfirmed)	TCU - Telematic Control Unit Module	DATA
K8D2-70713-CF.vbf	Check in SDD (unconfirmed)	TCU - Telematic Control Unit Module	DATA
K8D2-70713-CG.vbf	Check in SDD (unconfirmed)	TCU - Telematic Control Unit Module	DATA
K8D2-70713-CH.vbf	Check in SDD (unconfirmed)	TCU - Telematic Control Unit Module	DATA
K8D2-70713-CJ.vbf	Check in SDD (unconfirmed)	TCU - Telematic Control Unit Module	DATA
K8D2-70713-CK.vbf	Check in SDD (unconfirmed)	TCU - Telematic Control Unit Module	DATA
K8D2-70713-CNF.vbf	Check in SDD (unconfirmed)	TCU - Telematic Control Unit Module	DATA
K8D2-70713-CNX.vbf	Check in SDD (unconfirmed)	TCU - Telematic Control Unit Module	DATA
K8D2-70713-CPF.vbf	Check in SDD (unconfirmed)	TCU - Telematic Control Unit Module	DATA
K8D2-70713-DA.vbf	Check in SDD (unconfirmed)	TCU - Telematic Control Unit Module	DATA
K8D2-70713-DB.vbf	Jaguar XE (X760)	TCU - Telematic Control Unit Module	DATA
K8D2-70713-DC.vbf	Check in SDD (unconfirmed)	TCU - Telematic Control Unit Module	DATA
K8D2-70713-DD.vbf	Check in SDD (unconfirmed)	TCU - Telematic Control Unit Module	DATA
K8D2-70713-DE.vbf	Check in SDD (unconfirmed)	TCU - Telematic Control Unit Module	DATA
K8D2-70713-DF.vbf	Check in SDD (unconfirmed)	TCU - Telematic Control Unit Module	DATA
K8D2-70713-DG.vbf	Check in SDD (unconfirmed)	TCU - Telematic Control Unit Module	DATA
K8D2-70713-DH.vbf	Check in SDD (unconfirmed)	TCU - Telematic Control Unit Module	DATA
K8D2-70713-DJ.vbf	Check in SDD (unconfirmed)	TCU - Telematic Control Unit Module	DATA
K8D2-70713-DK.vbf	Check in SDD (unconfirmed)	TCU - Telematic Control Unit Module	DATA
K8D2-70713-DNX.vbf	Check in SDD (unconfirmed)	TCU - Telematic Control Unit Module	DATA
K8D2-70713-DPF.vbf	Check in SDD (unconfirmed)	TCU - Telematic Control Unit Module	DATA
K8D2-70713-FA.vbf	Check in SDD (unconfirmed)	TCU - Telematic Control Unit Module	DATA

File name	Vehicle line (indicative)	Module (ECU)	Type
K8D2-70713-FB.vbf	Jaguar XE (X760)	TCU - Telematic Control Unit Module	DATA
K8D2-70713-FC.vbf	Check in SDD (unconfirmed)	TCU - Telematic Control Unit Module	DATA
K8D2-70713-FD.vbf	Check in SDD (unconfirmed)	TCU - Telematic Control Unit Module	DATA
K8D2-70713-FE.vbf	Check in SDD (unconfirmed)	TCU - Telematic Control Unit Module	DATA
K8D2-70713-FF.vbf	Check in SDD (unconfirmed)	TCU - Telematic Control Unit Module	DATA
K8D2-70713-FG.vbf	Check in SDD (unconfirmed)	TCU - Telematic Control Unit Module	DATA
K8D2-70713-FH.vbf	Check in SDD (unconfirmed)	TCU - Telematic Control Unit Module	DATA
K8D2-70713-FJ.vbf	Check in SDD (unconfirmed)	TCU - Telematic Control Unit Module	DATA
K8D2-70713-FK.vbf	Check in SDD (unconfirmed)	TCU - Telematic Control Unit Module	DATA
K8D2-70713-FNF.vbf	Check in SDD (unconfirmed)	TCU - Telematic Control Unit Module	DATA
K8D2-70713-FNX.vbf	Check in SDD (unconfirmed)	TCU - Telematic Control Unit Module	DATA
K8D2-70713-FPF.vbf	Check in SDD (unconfirmed)	TCU - Telematic Control Unit Module	DATA
K8D2-70713-GA.vbf	Check in SDD (unconfirmed)	TCU - Telematic Control Unit Module	DATA
K8D2-70713-GB.vbf	Jaguar XE (X760)	TCU - Telematic Control Unit Module	DATA
K8D2-70713-GC.vbf	Check in SDD (unconfirmed)	TCU - Telematic Control Unit Module	DATA
K8D2-70713-GD.vbf	Check in SDD (unconfirmed)	TCU - Telematic Control Unit Module	DATA
K8D2-70713-GE.vbf	Check in SDD (unconfirmed)	TCU - Telematic Control Unit Module	DATA
K8D2-70713-GF.vbf	Check in SDD (unconfirmed)	TCU - Telematic Control Unit Module	DATA
K8D2-70713-GG.vbf	Check in SDD (unconfirmed)	TCU - Telematic Control Unit Module	DATA
K8D2-70713-GH.vbf	Check in SDD (unconfirmed)	TCU - Telematic Control Unit Module	DATA
K8D2-70713-GJ.vbf	Check in SDD (unconfirmed)	TCU - Telematic Control Unit Module	DATA
K8D2-70713-GK.vbf	Check in SDD (unconfirmed)	TCU - Telematic Control Unit Module	DATA
K8D2-70713-GNF.vbf	Check in SDD (unconfirmed)	TCU - Telematic Control Unit Module	DATA
K8D2-70713-GNX.vbf	Check in SDD (unconfirmed)	TCU - Telematic Control Unit Module	DATA
K8D2-70713-GPF.vbf	Check in SDD (unconfirmed)	TCU - Telematic Control Unit Module	DATA
K8D2-70713-KB.vbf	Jaguar XE (X760)	TCU - Telematic Control Unit Module	DATA
K8D2-70713-KC.vbf	Check in SDD (unconfirmed)	TCU - Telematic Control Unit Module	DATA
K8D2-70713-KD.vbf	Check in SDD (unconfirmed)	TCU - Telematic Control Unit Module	DATA
K8D2-70713-KE.vbf	Check in SDD (unconfirmed)	TCU - Telematic Control Unit Module	DATA
K8D2-70713-KF.vbf	Check in SDD (unconfirmed)	TCU - Telematic Control Unit Module	DATA
K8D2-70713-KG.vbf	Check in SDD (unconfirmed)	TCU - Telematic Control Unit Module	DATA
K8D2-70713-KH.vbf	Check in SDD (unconfirmed)	TCU - Telematic Control Unit Module	DATA
K8D2-70713-KJ.vbf	Check in SDD (unconfirmed)	TCU - Telematic Control Unit Module	DATA
K8D2-70713-KK.vbf	Check in SDD (unconfirmed)	TCU - Telematic Control Unit Module	DATA
K8D2-70713-KNF.vbf	Check in SDD (unconfirmed)	TCU - Telematic Control Unit Module	DATA
K8D2-70713-KNX.vbf	Check in SDD (unconfirmed)	TCU - Telematic Control Unit Module	DATA
K8D2-70713-KPF.vbf	Check in SDD (unconfirmed)	TCU - Telematic Control Unit Module	DATA
K8D2-7B762-AE.vbf	Check in SDD (unconfirmed)	AWD - All Wheel Drive Module	EXE
K8D2-7B762-AF.vbf	Check in SDD (unconfirmed)	AWD - All Wheel Drive Module	EXE
K8D2-7B762-AJ.vbf	Check in SDD (unconfirmed)	AWD - All Wheel Drive Module	EXE
K8D2-7B762-BE.vbf	Check in SDD (unconfirmed)	AWD - All Wheel Drive Module	EXE
K8D2-7B762-BF.vbf	Check in SDD (unconfirmed)	AWD - All Wheel Drive Module	EXE
K8D2-7B762-BH.vbf	Check in SDD (unconfirmed)	AWD - All Wheel Drive Module	EXE
K8D2-7B762-CA.vbf	Check in SDD (unconfirmed)	AWD - All Wheel Drive Module	EXE
K8D2-7B762-CC.vbf	Check in SDD (unconfirmed)	AWD - All Wheel Drive Module	EXE
K8D2-7B762-DA.vbf	Check in SDD (unconfirmed)	AWD - All Wheel Drive Module	EXE
K8D2-7B762-DB.vbf	Check in SDD (unconfirmed)	AWD - All Wheel Drive Module	EXE
K8D2-7B763-AE.vbf	Check in SDD (unconfirmed)	AWD - All Wheel Drive Module	DATA
K8D2-7B763-AF.vbf	Check in SDD (unconfirmed)	AWD - All Wheel Drive Module	DATA
K8D2-7B763-AJ.vbf	Check in SDD (unconfirmed)	AWD - All Wheel Drive Module	DATA
K8D2-7B763-BE.vbf	Check in SDD (unconfirmed)	AWD - All Wheel Drive Module	DATA
K8D2-7B763-BF.vbf	Check in SDD (unconfirmed)	AWD - All Wheel Drive Module	DATA
K8D2-7B763-BH.vbf	Check in SDD (unconfirmed)	AWD - All Wheel Drive Module	DATA
K8D2-7B763-CA.vbf	Check in SDD (unconfirmed)	AWD - All Wheel Drive Module	DATA
K8D2-7B763-CC.vbf	Check in SDD (unconfirmed)	AWD - All Wheel Drive Module	DATA
K8D2-7B763-DA.vbf	Check in SDD (unconfirmed)	AWD - All Wheel Drive Module	DATA
K8D2-7B763-DB.vbf	Check in SDD (unconfirmed)	AWD - All Wheel Drive Module	DATA
K8D2-7B764-AB.vbf	Check in SDD (unconfirmed)	AWD - All Wheel Drive Module	SBL
K8D2-7B764-BB.vbf	Check in SDD (unconfirmed)	AWD - All Wheel Drive Module	SBL
K8D2-7B772-BE.vbf	Check in SDD (unconfirmed)	AWD - All Wheel Drive Module	EXE
K8D2-7B772-BF.vbf	Check in SDD (unconfirmed)	AWD - All Wheel Drive Module	EXE
K8D2-7B772-BH.vbf	Check in SDD (unconfirmed)	AWD - All Wheel Drive Module	EXE
K8D2-7B772-DA.vbf	Check in SDD (unconfirmed)	AWD - All Wheel Drive Module	EXE
K8D2-7B773-BE.vbf	Check in SDD (unconfirmed)	AWD - All Wheel Drive Module	DATA
K8D2-7B773-BF.vbf	Check in SDD (unconfirmed)	AWD - All Wheel Drive Module	DATA
K8D2-7B773-BH.vbf	Check in SDD (unconfirmed)	AWD - All Wheel Drive Module	DATA
K8D2-7B773-DA.vbf	Check in SDD (unconfirmed)	AWD - All Wheel Drive Module	DATA
K8D2-7B774-BB.vbf	Check in SDD (unconfirmed)	AWD - All Wheel Drive Module	SBL
K9A3-14C034-AA.vbf	Not specified	DSM - Driver Front Seat Module	EXE
K9A3-14C034-AB.vbf	Not specified	DSM - Driver Front Seat Module	EXE
K9A3-14C034-BA.vbf	Not specified	DSM - Driver Front Seat Module	EXE
K9A3-14C034-BB.vbf	Not specified	DSM - Driver Front Seat Module	EXE
K9A3-14C036-AA.vbf	Not specified	ABS - Anti-Lock Brake System Control Module	EXE
K9A3-14C036-AB.vbf	Not specified	ABS - Anti-Lock Brake System Control Module	EXE
K9A3-14C036-AC.vbf	Not specified	ABS - Anti-Lock Brake System Control Module	EXE
K9A3-14C036-BA.vbf	Not specified	ABS - Anti-Lock Brake System Control Module	EXE

File name	Vehicle line (indicative)	Module (ECU)	Type
K9A3-14C036-BB.vbf	Not specified	ABS - Anti-Lock Brake System Control Module	EXE
K9A3-14C036-BC.vbf	Not specified	ABS - Anti-Lock Brake System Control Module	EXE
K9A3-14C037-AAA.vbf	Not specified	ABS - Anti-Lock Brake System Control Module	DATA
K9A3-14C037-AAB.vbf	Not specified	ABS - Anti-Lock Brake System Control Module	DATA
K9A3-14C037-AAC.vbf	Not specified	ABS - Anti-Lock Brake System Control Module	DATA
K9A3-14C037-AAE.vbf	Not specified	ABS - Anti-Lock Brake System Control Module	DATA
K9A3-14C037-ABA.vbf	Not specified	ABS - Anti-Lock Brake System Control Module	DATA
K9A3-14C037-ABB.vbf	Not specified	ABS - Anti-Lock Brake System Control Module	DATA
K9A3-14C037-ABC.vbf	Not specified	ABS - Anti-Lock Brake System Control Module	DATA
K9A3-14C037-ABE.vbf	Not specified	ABS - Anti-Lock Brake System Control Module	DATA
K9A3-14C037-MAA.vbf	Not specified	ABS - Anti-Lock Brake System Control Module	DATA
K9A3-14C037-MAB.vbf	Not specified	ABS - Anti-Lock Brake System Control Module	DATA
K9A3-14C037-MAC.vbf	Not specified	ABS - Anti-Lock Brake System Control Module	DATA
K9A3-14C037-MAE.vbf	Not specified	ABS - Anti-Lock Brake System Control Module	DATA
K9A3-14C037-MBA.vbf	Not specified	ABS - Anti-Lock Brake System Control Module	DATA
K9A3-14C037-MBB.vbf	Not specified	ABS - Anti-Lock Brake System Control Module	DATA
K9A3-14C037-MBC.vbf	Not specified	ABS - Anti-Lock Brake System Control Module	DATA
K9A3-14C037-MBE.vbf	Not specified	ABS - Anti-Lock Brake System Control Module	DATA
K9A3-14C527-BA.vbf	Not specified	AAM - Audio Amplifier Module	DATA
K9A3-14C527-BAA.vbf	Not specified	AAM - Audio Amplifier Module	DATA
K9A3-14C527-BB.vbf	Not specified	AAM - Audio Amplifier Module	DATA
K9A3-14C527-BBA.vbf	Not specified	AAM - Audio Amplifier Module	DATA
K9A3-14C527-BBB.vbf	Not specified	AAM - Audio Amplifier Module	DATA
K9A3-14C549-AA.vbf	Not specified	PSM - Passenger Front Seat Module	EXE
K9A3-14C549-AB.vbf	Not specified	PSM - Passenger Front Seat Module	EXE
K9A3-14C549-BA.vbf	Not specified	PSM - Passenger Front Seat Module	EXE
K9A3-14C549-BB.vbf	Not specified	PSM - Passenger Front Seat Module	EXE
K9A3-14E094-DAA.vbf	Not specified	CHCM - Chassis Control Module	EXE
K9A3-14E094-DAB.vbf	Not specified	CHCM - Chassis Control Module	EXE
K9A3-14E094-DAC.vbf	Not specified	CHCM - Chassis Control Module	EXE
K9A3-14E094-DBB.vbf	Not specified	CHCM - Chassis Control Module	EXE
K9A3-14E094-DBC.vbf	Not specified	CHCM - Chassis Control Module	EXE
K9W3-14C034-AA.vbf	Jaguar XE (X760)	DSM - Driver Front Seat Module	EXE
K9W3-14C034-AB.vbf	Jaguar XE (X760)	PSM - Passenger Front Seat Module	EXE
K9W3-14C034-AC.vbf	Jaguar XE (X760)	DSM - Driver Front Seat Module	EXE
K9W3-14C034-AD.vbf	Jaguar XE (X760)	DSM - Driver Front Seat Module	EXE
K9W3-14C034-BA.vbf	Jaguar XE (X760)	DSM - Driver Front Seat Module	EXE
K9W3-14C034-CA.vbf	Jaguar XE (X760)	DSM - Driver Front Seat Module	EXE
K9W3-14C034-DA.vbf	Jaguar XE (X760)	DSM - Driver Front Seat Module	EXE
K9W3-14C034-DB.vbf	Jaguar XE (X760)	PSM - Passenger Front Seat Module	EXE
K9W3-14C034-DC.vbf	Jaguar XE (X760)	DSM - Driver Front Seat Module	EXE
K9W3-14C034-DD.vbf	Jaguar XE (X760)	DSM - Driver Front Seat Module	EXE
K9W3-14C034-DE.vbf	Jaguar XE (X760)	DSM - Driver Front Seat Module	EXE
K9W3-14C037-AAC.vbf	Jaguar XE (X760)	ABS - Anti-Lock Brake System Control Module	DATA
K9W3-14C037-AAD.vbf	Jaguar XE (X760)	ABS - Anti-Lock Brake System Control Module	DATA
K9W3-14C037-AAE.vbf	Jaguar XE (X760)	ABS - Anti-Lock Brake System Control Module	DATA
K9W3-14C037-AAF.vbf	Jaguar XE (X760)	ABS - Anti-Lock Brake System Control Module	DATA
K9W3-14C037-AAG.vbf	Jaguar XE (X760)	ABS - Anti-Lock Brake System Control Module	DATA
K9W3-14C037-ABC.vbf	Jaguar XE (X760)	ABS - Anti-Lock Brake System Control Module	DATA
K9W3-14C037-ABD.vbf	Jaguar XE (X760)	ABS - Anti-Lock Brake System Control Module	DATA
K9W3-14C037-ABE.vbf	Jaguar XE (X760)	ABS - Anti-Lock Brake System Control Module	DATA
K9W3-14C037-ABF.vbf	Jaguar XE (X760)	ABS - Anti-Lock Brake System Control Module	DATA
K9W3-14C037-ABG.vbf	Jaguar XE (X760)	ABS - Anti-Lock Brake System Control Module	DATA
K9W3-14C037-MAC.vbf	Jaguar XE (X760)	ABS - Anti-Lock Brake System Control Module	DATA
K9W3-14C037-MAD.vbf	Jaguar XE (X760)	ABS - Anti-Lock Brake System Control Module	DATA
K9W3-14C037-MAE.vbf	Jaguar XE (X760)	ABS - Anti-Lock Brake System Control Module	DATA
K9W3-14C037-MAF.vbf	Jaguar XE (X760)	ABS - Anti-Lock Brake System Control Module	DATA
K9W3-14C037-MAG.vbf	Jaguar XE (X760)	ABS - Anti-Lock Brake System Control Module	DATA
K9W3-14C037-MBC.vbf	Jaguar XE (X760)	ABS - Anti-Lock Brake System Control Module	DATA
K9W3-14C037-MBD.vbf	Jaguar XE (X760)	ABS - Anti-Lock Brake System Control Module	DATA
K9W3-14C037-MBE.vbf	Jaguar XE (X760)	ABS - Anti-Lock Brake System Control Module	DATA
K9W3-14C037-MBF.vbf	Jaguar XE (X760)	ABS - Anti-Lock Brake System Control Module	DATA
K9W3-14C037-MBG.vbf	Jaguar XE (X760)	ABS - Anti-Lock Brake System Control Module	DATA
K9W3-14C091-AB.vbf	Jaguar XE (X760)	PAM - Parking Assist Control Module	DATA
K9W3-14C091-AC.vbf	Jaguar XE (X760)	PAM - Parking Assist Control Module	DATA
K9W3-14C105-BC.vbf	Jaguar XE (X760)	TMC Traffic Message Channel Module	DATA
K9W3-14C105-BD.vbf	Jaguar XE (X760)	TMC Traffic Message Channel Module	DATA
K9W3-14C527-EA.vbf	Jaguar XE (X760)	AAM - Audio Amplifier Module	DATA
K9W3-14C527-FA.vbf	Jaguar XE (X760)	AAM - Audio Amplifier Module	DATA
K9W3-14C527-GA.vbf	Jaguar XE (X760)	AAM - Audio Amplifier Module	DATA
K9W3-14C549-AA.vbf	Jaguar XE (X760)	PSM - Passenger Front Seat Module	EXE
K9W3-14C549-AB.vbf	Jaguar XE (X760)	PSM - Passenger Front Seat Module	EXE
K9W3-14C549-AC.vbf	Jaguar XE (X760)	DSM - Driver Front Seat Module	EXE
K9W3-14C549-AD.vbf	Jaguar XE (X760)	PSM - Passenger Front Seat Module	EXE
K9W3-14C549-BA.vbf	Jaguar XE (X760)	PSM - Passenger Front Seat Module	EXE
K9W3-14C549-CA.vbf	Jaguar XE (X760)	PSM - Passenger Front Seat Module	EXE

File name	Vehicle line (indicative)	Module (ECU)	Type
K9W3-14C549-DA.vbf	Jaguar XE (X760)	PSM - Passenger Front Seat Module	EXE
K9W3-14C549-DB.vbf	Jaguar XE (X760)	PSM - Passenger Front Seat Module	EXE
K9W3-14C549-DC.vbf	Jaguar XE (X760)	SCMC - Seat Control Module C	EXE
K9W3-14C549-DD.vbf	Jaguar XE (X760)	PSM - Passenger Front Seat Module	EXE
K9W3-14C549-DE.vbf	Jaguar XE (X760)	SCMC - Seat Control Module C	EXE
K9W3-14D481-BA.vbf	Jaguar XE (X760)	IPMB - Image Processing Module B	DATA
K9W3-14D481-BB.vbf	Jaguar XE (X760)	IPMB - Image Processing Module B	DATA
K9W3-14D485-AC.vbf	Jaguar XE (X760)	IPMB - Image Processing Module B	EXE
K9W3-14D485-AD.vbf	Jaguar XE (X760)	IPMB - Image Processing Module B	EXE
K9W3-14D485-AE.vbf	Jaguar XE (X760)	IPMB - Image Processing Module B	EXE
K9W3-14D485-BA.vbf	Jaguar XE (X760)	IPMB - Image Processing Module B	DATA
K9W3-14D485-BB.vbf	Jaguar XE (X760)	IPMB - Image Processing Module B	DATA
K9W3-14E094-DAB.vbf	Jaguar XE (X760)	CHCM - Chassis Control Module	EXE
K9W3-14E094-DAC.vbf	Jaguar XE (X760)	CHCM - Chassis Control Module	EXE
K9W3-14E094-DAD.vbf	Jaguar XE (X760)	CHCM - Chassis Control Module	EXE
K9W3-14E094-DAE.vbf	Jaguar XE (X760)	CHCM - Chassis Control Module	EXE
K9W3-14F022-AD.vbf	Jaguar XE (X760)	IPMB - Image Processing Module B	DATA
K9W3-14F022-AF.vbf	Jaguar XE (X760)	IPMB - Image Processing Module B	DATA
K9W3-14F022-AG.vbf	Jaguar XE (X760)	IPMB - Image Processing Module B	DATA
K9W3-14F022-BD.vbf	Jaguar XE (X760)	IPMB - Image Processing Module B	DATA
K9W3-14F022-BF.vbf	Jaguar XE (X760)	IPMB - Image Processing Module B	DATA
K9W3-14F022-BG.vbf	Jaguar XE (X760)	IPMB - Image Processing Module B	DATA
KJ32-12K532-FBA.vbf	Range Rover Evoque (L538)	PCM - Powertrain Control Module	DATA
KJ32-12K532-FBB.vbf	Range Rover Evoque (L538)	PCM - Powertrain Control Module	DATA
KJ32-12K532-FBC.vbf	Range Rover Evoque (L538)	PCM - Powertrain Control Module	DATA
KJ32-12K532-FBD.vbf	Range Rover Evoque (L538)	PCM - Powertrain Control Module	DATA
KJ32-12K532-FBE.vbf	Range Rover Evoque (L538)	PCM - Powertrain Control Module	DATA
KJ32-12K532-FCA.vbf	Range Rover Evoque (L538)	PCM - Powertrain Control Module	DATA
KJ32-12K532-FCB.vbf	Range Rover Evoque (L538)	PCM - Powertrain Control Module	DATA
KJ32-12K532-FCC.vbf	Range Rover Evoque (L538)	PCM - Powertrain Control Module	DATA
KJ32-12K532-FCD.vbf	Range Rover Evoque (L538)	PCM - Powertrain Control Module	DATA
KJ32-12K532-FCE.vbf	Range Rover Evoque (L538)	PCM - Powertrain Control Module	DATA
KJ32-12K532-GAA.vbf	Range Rover Evoque (L538)	PCM - Powertrain Control Module	DATA
KJ32-12K532-GAB.vbf	Range Rover Evoque (L538)	PCM - Powertrain Control Module	DATA
KJ32-12K532-GAC.vbf	Range Rover Evoque (L538)	PCM - Powertrain Control Module	DATA
KJ32-12K532-GAD.vbf	Range Rover Evoque (L538)	PCM - Powertrain Control Module	DATA
KJ32-12K532-GAE.vbf	Range Rover Evoque (L538)	PCM - Powertrain Control Module	DATA
KJ32-12K532-GBA.vbf	Range Rover Evoque (L538)	PCM - Powertrain Control Module	DATA
KJ32-12K532-GBB.vbf	Range Rover Evoque (L538)	PCM - Powertrain Control Module	DATA
KJ32-12K532-GBC.vbf	Range Rover Evoque (L538)	PCM - Powertrain Control Module	DATA
KJ32-12K532-GBD.vbf	Range Rover Evoque (L538)	PCM - Powertrain Control Module	DATA
KJ32-12K532-GBE.vbf	Range Rover Evoque (L538)	PCM - Powertrain Control Module	DATA
KJ32-12K532-GCA.vbf	Range Rover Evoque (L538)	PCM - Powertrain Control Module	DATA
KJ32-12K532-GCB.vbf	Range Rover Evoque (L538)	PCM - Powertrain Control Module	DATA
KJ32-12K532-GCC.vbf	Range Rover Evoque (L538)	PCM - Powertrain Control Module	DATA
KJ32-12K532-GCD.vbf	Range Rover Evoque (L538)	PCM - Powertrain Control Module	DATA
KJ32-12K532-GCE.vbf	Range Rover Evoque (L538)	PCM - Powertrain Control Module	DATA
KJ32-14C036-AB.vbf	Range Rover Evoque (L538)	ABS - Anit-Lock Brake System (ABS) Control Module	EXE
KJ32-14C036-AC.vbf	Range Rover Evoque (L538)	ABS - Anit-Lock Brake System (ABS) Control Module	EXE
KJ32-14C036-AD.vbf	Range Rover Evoque (L538)	ABS - Anit-Lock Brake System (ABS) Control Module	EXE
KJ32-14C337-CJA.vbf	Range Rover Evoque (L538)	TCM - Transmission Control Module	EXE
KJ32-14C337-CJB.vbf	Range Rover Evoque (L538)	TCM - Transmission Control Module	EXE
KJ32-14C337-CJC.vbf	Range Rover Evoque (L538)	TCM - Transmission Control Module	EXE
KJ32-14C337-CJD.vbf	Range Rover Evoque (L538)	TCM - Transmission Control Module	EXE
KJ32-14C337-CKA.vbf	Range Rover Evoque (L538)	TCM - Transmission Control Module	EXE
KJ32-14C337-CKB.vbf	Range Rover Evoque (L538)	TCM - Transmission Control Module	EXE
KJ32-14C337-CKC.vbf	Range Rover Evoque (L538)	TCM - Transmission Control Module	EXE
KJ32-14C337-CKD.vbf	Range Rover Evoque (L538)	TCM - Transmission Control Module	EXE
KJ32-14C337-CLA.vbf	Range Rover Evoque (L538)	TCM - Transmission Control Module	EXE
KJ32-14C337-CLB.vbf	Range Rover Evoque (L538)	TCM - Transmission Control Module	EXE
KJ32-14C337-CLC.vbf	Range Rover Evoque (L538)	TCM - Transmission Control Module	EXE
KJ32-14C337-CLD.vbf	Range Rover Evoque (L538)	TCM - Transmission Control Module	EXE
KJ32-14C337-CMA.vbf	Range Rover Evoque (L538)	TCM - Transmission Control Module	EXE
KJ32-14C337-CMB.vbf	Range Rover Evoque (L538)	TCM - Transmission Control Module	EXE
KJ32-14C337-CMC.vbf	Range Rover Evoque (L538)	TCM - Transmission Control Module	EXE
KJ32-14C337-CMD.vbf	Range Rover Evoque (L538)	TCM - Transmission Control Module	EXE
KJ32-14C337-CPA.vbf	Range Rover Evoque (L538)	TCM - Transmission Control Module	EXE
KJ32-14C337-CPB.vbf	Range Rover Evoque (L538)	TCM - Transmission Control Module	EXE
KJ32-14C337-CPC.vbf	Range Rover Evoque (L538)	TCM - Transmission Control Module	EXE
KJ32-14C337-CPD.vbf	Range Rover Evoque (L538)	TCM - Transmission Control Module	EXE
KJ32-14C337-CRA.vbf	Range Rover Evoque (L538)	TCM - Transmission Control Module	EXE
KJ32-14C337-CRB.vbf	Range Rover Evoque (L538)	TCM - Transmission Control Module	EXE
KJ32-14C337-CRC.vbf	Range Rover Evoque (L538)	TCM - Transmission Control Module	EXE
KJ32-14C337-CRD.vbf	Range Rover Evoque (L538)	TCM - Transmission Control Module	EXE
KJ32-14C337-CUA.vbf	Range Rover Evoque (L538)	TCM - Transmission Control Module	EXE
KJ32-14C337-CUB.vbf	Range Rover Evoque (L538)	TCM - Transmission Control Module	EXE

File name	Vehicle line (indicative)	Module (ECU)	Type
KJ32-14C337-CUC.vbf	Range Rover Evoque (L538)	TCM - Transmission Control Module	EXE
KJ32-14C337-CUD.vbf	Range Rover Evoque (L538)	TCM - Transmission Control Module	EXE
KJ32-14C570-BAC.vbf	Range Rover Evoque (L538)	PCM - Powertrain Control Module	EXE
KJ32-14C570-BAD.vbf	Range Rover Evoque (L538)	PCM - Powertrain Control Module	EXE
KJ32-14C570-BAE.vbf	Range Rover Evoque (L538)	PCM - Powertrain Control Module	EXE
KJ32-14C570-BAF.vbf	Range Rover Evoque (L538)	PCM - Powertrain Control Module	EXE
KJ32-14C570-BCD.vbf	Range Rover Evoque (L538)	PCM - Powertrain Control Module	EXE
KJ32-14C570-BFC.vbf	Range Rover Evoque (L538)	PCM - Powertrain Control Module	EXE
KJ32-14C570-BFD.vbf	Range Rover Evoque (L538)	PCM - Powertrain Control Module	EXE
KJ32-14C570-BFE.vbf	Range Rover Evoque (L538)	PCM - Powertrain Control Module	EXE
KJ32-14C570-BFG.vbf	Range Rover Evoque (L538)	PCM - Powertrain Control Module	EXE
KJ32-14C570-BFH.vbf	Range Rover Evoque (L538)	PCM - Powertrain Control Module	EXE
KJ32-14C570-BGC.vbf	Range Rover Evoque (L538)	PCM - Powertrain Control Module	EXE
KJ32-14C570-BGD.vbf	Range Rover Evoque (L538)	PCM - Powertrain Control Module	EXE
KJ32-14C570-BGE.vbf	Range Rover Evoque (L538)	PCM - Powertrain Control Module	EXE
KJ32-14C570-BGF.vbf	Range Rover Evoque (L538)	PCM - Powertrain Control Module	EXE
KJ32-14C570-BHA.vbf	Range Rover Evoque (L538)	PCM - Powertrain Control Module	EXE
KJ32-14C570-BHD.vbf	Range Rover Evoque (L538)	PCM - Powertrain Control Module	EXE
KJ32-14C570-BHF.vbf	Range Rover Evoque (L538)	PCM - Powertrain Control Module	EXE
KJ32-14C570-BHG.vbf	Range Rover Evoque (L538)	PCM - Powertrain Control Module	EXE
KJ32-14C570-BHH.vbf	Range Rover Evoque (L538)	PCM - Powertrain Control Module	EXE
KJ32-14C570-BHK.vbf	Range Rover Evoque (L538)	PCM - Powertrain Control Module	EXE
KJ32-14C570-BJC.vbf	Range Rover Evoque (L538)	PCM - Powertrain Control Module	EXE
KJ32-14C570-BJD.vbf	Range Rover Evoque (L538)	PCM - Powertrain Control Module	EXE
KJ32-14C570-BJE.vbf	Range Rover Evoque (L538)	PCM - Powertrain Control Module	EXE
KJ32-14C570-BJF.vbf	Range Rover Evoque (L538)	PCM - Powertrain Control Module	EXE
KJ32-14C570-BLD.vbf	Range Rover Evoque (L538)	PCM - Powertrain Control Module	EXE
KJ32-14C570-BND.vbf	Range Rover Evoque (L538)	PCM - Powertrain Control Module	EXE
KJ32-14C570-BTD.vbf	Range Rover Evoque (L538)	PCM - Powertrain Control Module	EXE
KJ32-14C570-EAC.vbf	Range Rover Evoque (L538)	PCM - Powertrain Control Module	EXE
KJ32-14C570-EAD.vbf	Range Rover Evoque (L538)	PCM - Powertrain Control Module	EXE
KJ32-14C570-EAE.vbf	Range Rover Evoque (L538)	PCM - Powertrain Control Module	EXE
KJ32-14C570-EAF.vbf	Range Rover Evoque (L538)	PCM - Powertrain Control Module	EXE
KJ32-14F531-AA.vbf	Range Rover Evoque (L538)	GWM - Gateway Module A	DATA
KJ32-14F531-AB.vbf	Range Rover Evoque (L538)	GWM - Gateway Module A	DATA
KK52-12K532-NLD.vbf	Range Rover (L405)	PCM - Powertrain Control Module	EXE
KK52-12K532-NLE.vbf	Range Rover (L405)	PCM - Powertrain Control Module	EXE
KK52-12K532-NLF.vbf	Range Rover (L405)	PCM - Powertrain Control Module	EXE
KK52-12K532-NMD.vbf	Range Rover (L405)	PCM - Powertrain Control Module	EXE
KK52-12K532-NME.vbf	Range Rover (L405)	PCM - Powertrain Control Module	EXE
KK52-12K532-NMF.vbf	Range Rover (L405)	PCM - Powertrain Control Module	EXE
KK52-12K532-NMG.vbf	Range Rover (L405)	PCM - Powertrain Control Module	EXE
KK52-12K532-NRD.vbf	Range Rover (L405)	PCM - Powertrain Control Module	EXE
KK52-12K532-NRE.vbf	Range Rover (L405)	PCM - Powertrain Control Module	EXE
KK52-12K532-NRG.vbf	Range Rover (L405)	PCM - Powertrain Control Module	EXE
KK52-12K532-NRH.vbf	Range Rover (L405)	PCM - Powertrain Control Module	EXE
KK52-12K532-PCC.vbf	Range Rover (L405)	PCM - Powertrain Control Module	EXE
KK52-12K532-PCD.vbf	Range Rover (L405)	PCM - Powertrain Control Module	EXE
KK52-12K532-PFC.vbf	Range Rover (L405)	PCM - Powertrain Control Module	EXE
KK52-12K532-PFD.vbf	Range Rover (L405)	PCM - Powertrain Control Module	EXE
KK52-12K532-PFF.vbf	Range Rover (L405)	PCM - Powertrain Control Module	EXE
KK52-12K532-PKC.vbf	Range Rover (L405)	PCM - Powertrain Control Module	EXE
KK52-12K532-PKD.vbf	Range Rover (L405)	PCM - Powertrain Control Module	EXE
KK52-12K532-PKE.vbf	Range Rover (L405)	PCM - Powertrain Control Module	EXE
KK52-12K532-PKF.vbf	Range Rover (L405)	PCM - Powertrain Control Module	EXE
KK52-12K532-PKG.vbf	Range Rover (L405)	PCM - Powertrain Control Module	EXE
KK52-12K532-PPC.vbf	Range Rover (L405)	PCM - Powertrain Control Module	EXE
KK52-12K532-PPE.vbf	Range Rover (L405)	PCM - Powertrain Control Module	EXE
KK52-12K532-PSC.vbf	Range Rover (L405)	PCM - Powertrain Control Module	EXE
KK52-12K532-PSD.vbf	Range Rover (L405)	PCM - Powertrain Control Module	EXE
KK52-12K532-PSE.vbf	Range Rover (L405)	PCM - Powertrain Control Module	EXE
KK52-12K532-PSF.vbf	Range Rover (L405)	PCM - Powertrain Control Module	EXE
KK52-12K532-PSG.vbf	Range Rover (L405)	PCM - Powertrain Control Module	EXE
KK52-12K532-PXA.vbf	Range Rover (L405)	PCM - Powertrain Control Module	DATA
KK52-12K532-PXB.vbf	Range Rover (L405)	PCM - Powertrain Control Module	DATA
KK52-12K532-PXC.vbf	Range Rover (L405)	PCM - Powertrain Control Module	EXE
KK52-12K532-PXD.vbf	Range Rover (L405)	PCM - Powertrain Control Module	EXE
KK52-12K532-PXE.vbf	Range Rover (L405)	PCM - Powertrain Control Module	EXE
KK52-12K532-PXF.vbf	Range Rover (L405)	PCM - Powertrain Control Module	EXE
KK52-12K532-PXG.vbf	Range Rover (L405)	PCM - Powertrain Control Module	EXE
KK52-12K532-PXH.vbf	Range Rover (L405)	PCM - Powertrain Control Module	EXE
KK52-12K532-PXJ.vbf	Range Rover (L405)	PCM - Powertrain Control Module	EXE
KK52-14C037-ABD.vbf	Range Rover (L405)	ABS - Anti-Lock Brake System Control Module	DATA
KK52-14C037-ABE.vbf	Range Rover (L405)	ABS - Anti-Lock Brake System Control Module	DATA
KK52-14C037-ABF.vbf	Range Rover (L405)	ABS - Anti-Lock Brake System Control Module	DATA
KK52-14C037-ABG.vbf	Range Rover (L405)	ABS - Anti-Lock Brake System Control Module	DATA

File name	Vehicle line (indicative)	Module (ECU)	Type
KK52-14C037-ABH.vbf	Range Rover (L405)	ABS - Anti-Lock Brake System Control Module	DATA
KK52-14C037-ABJ.vbf	Range Rover (L405)	ABS - Anti-Lock Brake System Control Module	DATA
KK52-14C037-ABK.vbf	Range Rover (L405)	ABS - Anti-Lock Brake System Control Module	DATA
KK52-14C037-ACD.vbf	Range Rover (L405)	ABS - Anti-Lock Brake System Control Module	DATA
KK52-14C037-ACE.vbf	Range Rover (L405)	ABS - Anti-Lock Brake System Control Module	DATA
KK52-14C037-ACF.vbf	Range Rover (L405)	ABS - Anti-Lock Brake System Control Module	DATA
KK52-14C037-ACG.vbf	Range Rover (L405)	ABS - Anti-Lock Brake System Control Module	DATA
KK52-14C037-ACH.vbf	Range Rover (L405)	ABS - Anti-Lock Brake System Control Module	DATA
KK52-14C037-ACJ.vbf	Range Rover (L405)	ABS - Anti-Lock Brake System Control Module	DATA
KK52-14C037-ACK.vbf	Range Rover (L405)	ABS - Anti-Lock Brake System Control Module	DATA
KK52-14C037-ADD.vbf	Range Rover (L405)	ABS - Anti-Lock Brake System Control Module	DATA
KK52-14C037-ADE.vbf	Range Rover (L405)	ABS - Anti-Lock Brake System Control Module	DATA
KK52-14C037-ADF.vbf	Range Rover (L405)	ABS - Anti-Lock Brake System Control Module	DATA
KK52-14C037-ADG.vbf	Range Rover (L405)	ABS - Anti-Lock Brake System Control Module	DATA
KK52-14C037-ADH.vbf	Range Rover (L405)	ABS - Anti-Lock Brake System Control Module	DATA
KK52-14C037-ADJ.vbf	Range Rover (L405)	ABS - Anti-Lock Brake System Control Module	DATA
KK52-14C037-ADK.vbf	Range Rover (L405)	ABS - Anti-Lock Brake System Control Module	DATA
KK52-14C037-AEB.vbf	Range Rover (L405)	ABS - Anti-Lock Brake System Control Module	DATA
KK52-14C037-AEE.vbf	Range Rover (L405)	ABS - Anti-Lock Brake System Control Module	DATA
KK52-14C037-AEF.vbf	Range Rover (L405)	ABS - Anti-Lock Brake System Control Module	DATA
KK52-14C037-AEG.vbf	Range Rover (L405)	ABS - Anti-Lock Brake System Control Module	DATA
KK52-14C037-AEH.vbf	Range Rover (L405)	ABS - Anti-Lock Brake System Control Module	DATA
KK52-14C037-AEJ.vbf	Range Rover (L405)	ABS - Anti-Lock Brake System Control Module	DATA
KK52-14C037-AEK.vbf	Range Rover (L405)	ABS - Anti-Lock Brake System Control Module	DATA
KK52-14C037-AFE.vbf	Range Rover (L405)	ABS - Anti-Lock Brake System Control Module	DATA
KK52-14C037-AFF.vbf	Range Rover (L405)	ABS - Anti-Lock Brake System Control Module	DATA
KK52-14C037-AFG.vbf	Range Rover (L405)	ABS - Anti-Lock Brake System Control Module	DATA
KK52-14C037-AFH.vbf	Range Rover (L405)	ABS - Anti-Lock Brake System Control Module	DATA
KK52-14C037-AFJ.vbf	Range Rover (L405)	ABS - Anti-Lock Brake System Control Module	DATA
KK52-14C037-AFK.vbf	Range Rover (L405)	ABS - Anti-Lock Brake System Control Module	DATA
KK52-14C037-AMD.vbf	Range Rover (L405)	ABS - Anti-Lock Brake System Control Module	DATA
KK52-14C037-AME.vbf	Range Rover (L405)	ABS - Anti-Lock Brake System Control Module	DATA
KK52-14C037-AMF.vbf	Range Rover (L405)	ABS - Anti-Lock Brake System Control Module	DATA
KK52-14C037-AMG.vbf	Range Rover (L405)	ABS - Anti-Lock Brake System Control Module	DATA
KK52-14C037-AMH.vbf	Range Rover (L405)	ABS - Anti-Lock Brake System Control Module	DATA
KK52-14C037-AMJ.vbf	Range Rover (L405)	ABS - Anti-Lock Brake System Control Module	DATA
KK52-14C037-AMK.vbf	Range Rover (L405)	ABS - Anti-Lock Brake System Control Module	DATA
KK52-14C037-AND.vbf	Range Rover (L405)	ABS - Anti-Lock Brake System Control Module	DATA
KK52-14C037-ANE.vbf	Range Rover (L405)	ABS - Anti-Lock Brake System Control Module	DATA
KK52-14C037-ANF.vbf	Range Rover (L405)	ABS - Anti-Lock Brake System Control Module	DATA
KK52-14C037-ANG.vbf	Range Rover (L405)	ABS - Anti-Lock Brake System Control Module	DATA
KK52-14C037-ANH.vbf	Range Rover (L405)	ABS - Anti-Lock Brake System Control Module	DATA
KK52-14C037-ANJ.vbf	Range Rover (L405)	ABS - Anti-Lock Brake System Control Module	DATA
KK52-14C037-ANK.vbf	Range Rover (L405)	ABS - Anti-Lock Brake System Control Module	DATA
KK52-14C037-APE.vbf	Range Rover (L405)	ABS - Anti-Lock Brake System Control Module	DATA
KK52-14C037-APF.vbf	Range Rover (L405)	ABS - Anti-Lock Brake System Control Module	DATA
KK52-14C037-APG.vbf	Range Rover (L405)	ABS - Anti-Lock Brake System Control Module	DATA
KK52-14C037-APH.vbf	Range Rover (L405)	ABS - Anti-Lock Brake System Control Module	DATA
KK52-14C037-APJ.vbf	Range Rover (L405)	ABS - Anti-Lock Brake System Control Module	DATA
KK52-14C037-APK.vbf	Range Rover (L405)	ABS - Anti-Lock Brake System Control Module	DATA
KK52-14C037-ARE.vbf	Range Rover (L405)	ABS - Anti-Lock Brake System Control Module	DATA
KK52-14C037-ARF.vbf	Range Rover (L405)	ABS - Anti-Lock Brake System Control Module	DATA
KK52-14C037-ARG.vbf	Range Rover (L405)	ABS - Anti-Lock Brake System Control Module	DATA
KK52-14C037-ARH.vbf	Range Rover (L405)	ABS - Anti-Lock Brake System Control Module	DATA
KK52-14C037-ARJ.vbf	Range Rover (L405)	ABS - Anti-Lock Brake System Control Module	DATA
KK52-14C037-ARK.vbf	Range Rover (L405)	ABS - Anti-Lock Brake System Control Module	DATA
KK52-14C037-ATD.vbf	Range Rover (L405)	ABS - Anti-Lock Brake System Control Module	DATA
KK52-14C037-ATE.vbf	Range Rover (L405)	ABS - Anti-Lock Brake System Control Module	DATA
KK52-14C037-ATF.vbf	Range Rover (L405)	ABS - Anti-Lock Brake System Control Module	DATA
KK52-14C037-ATG.vbf	Range Rover (L405)	ABS - Anti-Lock Brake System Control Module	DATA
KK52-14C037-ATH.vbf	Range Rover (L405)	ABS - Anti-Lock Brake System Control Module	DATA
KK52-14C037-ATJ.vbf	Range Rover (L405)	ABS - Anti-Lock Brake System Control Module	DATA
KK52-14C037-ATK.vbf	Range Rover (L405)	ABS - Anti-Lock Brake System Control Module	DATA
KK52-14C037-AVD.vbf	Range Rover (L405)	ABS - Anti-Lock Brake System Control Module	DATA
KK52-14C037-AVE.vbf	Range Rover (L405)	ABS - Anti-Lock Brake System Control Module	DATA
KK52-14C037-AVF.vbf	Range Rover (L405)	ABS - Anti-Lock Brake System Control Module	DATA
KK52-14C037-AVG.vbf	Range Rover (L405)	ABS - Anti-Lock Brake System Control Module	DATA
KK52-14C037-AVH.vbf	Range Rover (L405)	ABS - Anti-Lock Brake System Control Module	DATA
KK52-14C037-AVJ.vbf	Range Rover (L405)	ABS - Anti-Lock Brake System Control Module	DATA
KK52-14C037-AVK.vbf	Range Rover (L405)	ABS - Anti-Lock Brake System Control Module	DATA
KK52-14C037-DLD.vbf	Range Rover (L405)	ABS - Anti-Lock Brake System Control Module	DATA
KK52-14C037-DLE.vbf	Range Rover (L405)	ABS - Anti-Lock Brake System Control Module	DATA
KK52-14C037-DLF.vbf	Range Rover (L405)	ABS - Anti-Lock Brake System Control Module	DATA
KK52-14C037-DLG.vbf	Range Rover (L405)	ABS - Anti-Lock Brake System Control Module	DATA
KK52-14C037-DLH.vbf	Range Rover (L405)	ABS - Anti-Lock Brake System Control Module	DATA
KK52-14C037-DLJ.vbf	Range Rover (L405)	ABS - Anti-Lock Brake System Control Module	DATA

File name	Vehicle line (indicative)	Module (ECU)	Type
KK52-14C037-DLK.vbf	Range Rover (L405)	ABS - Anti-Lock Brake System Control Module	DATA
KK52-14C037-DMD.vbf	Range Rover (L405)	ABS - Anti-Lock Brake System Control Module	DATA
KK52-14C037-DME.vbf	Range Rover (L405)	ABS - Anti-Lock Brake System Control Module	DATA
KK52-14C037-DMF.vbf	Range Rover (L405)	ABS - Anti-Lock Brake System Control Module	DATA
KK52-14C037-DMG.vbf	Range Rover (L405)	ABS - Anti-Lock Brake System Control Module	DATA
KK52-14C037-DMH.vbf	Range Rover (L405)	ABS - Anti-Lock Brake System Control Module	DATA
KK52-14C037-DMJ.vbf	Range Rover (L405)	ABS - Anti-Lock Brake System Control Module	DATA
KK52-14C037-DMK.vbf	Range Rover (L405)	ABS - Anti-Lock Brake System Control Module	DATA
KK52-14C037-DUC.vbf	Range Rover (L405)	ABS - Anti-Lock Brake System Control Module	DATA
KK52-14C037-DUD.vbf	Range Rover (L405)	ABS - Anti-Lock Brake System Control Module	DATA
KK52-14C037-DUE.vbf	Range Rover (L405)	ABS - Anti-Lock Brake System Control Module	DATA
KK52-14C037-DUF.vbf	Range Rover (L405)	ABS - Anti-Lock Brake System Control Module	DATA
KK52-14C037-DUG.vbf	Range Rover (L405)	ABS - Anti-Lock Brake System Control Module	DATA
KK52-14C037-DUH.vbf	Range Rover (L405)	ABS - Anti-Lock Brake System Control Module	DATA
KK52-14C037-DUJ.vbf	Range Rover (L405)	ABS - Anti-Lock Brake System Control Module	DATA
KK52-14C037-DZD.vbf	Range Rover (L405)	ABS - Anti-Lock Brake System Control Module	DATA
KK52-14C037-DZE.vbf	Range Rover (L405)	ABS - Anti-Lock Brake System Control Module	DATA
KK52-14C037-DZF.vbf	Range Rover (L405)	ABS - Anti-Lock Brake System Control Module	DATA
KK52-14C037-DZG.vbf	Range Rover (L405)	ABS - Anti-Lock Brake System Control Module	DATA
KK52-14C037-DZH.vbf	Range Rover (L405)	ABS - Anti-Lock Brake System Control Module	DATA
KK52-14C037-DZJ.vbf	Range Rover (L405)	ABS - Anti-Lock Brake System Control Module	DATA
KK52-14C037-DZK.vbf	Range Rover (L405)	ABS - Anti-Lock Brake System Control Module	DATA
KK52-14C037-EGB.vbf	Range Rover (L405)	ABS - Anti-Lock Brake System Control Module	DATA
KK52-14C037-EGC.vbf	Range Rover (L405)	ABS - Anti-Lock Brake System Control Module	DATA
KK52-14C037-EGD.vbf	Range Rover (L405)	ABS - Anti-Lock Brake System Control Module	DATA
KK52-14C037-EGE.vbf	Range Rover (L405)	ABS - Anti-Lock Brake System Control Module	DATA
KK52-14C037-EGF.vbf	Range Rover (L405)	ABS - Anti-Lock Brake System Control Module	DATA
KK52-14C037-EGG.vbf	Range Rover (L405)	ABS - Anti-Lock Brake System Control Module	DATA
KK52-14C037-EGH.vbf	Range Rover (L405)	ABS - Anti-Lock Brake System Control Module	DATA
KK52-14C037-EJB.vbf	Range Rover (L405)	ABS - Anti-Lock Brake System Control Module	DATA
KK52-14C037-EJC.vbf	Range Rover (L405)	ABS - Anti-Lock Brake System Control Module	DATA
KK52-14C037-EJD.vbf	Range Rover (L405)	ABS - Anti-Lock Brake System Control Module	DATA
KK52-14C037-EJE.vbf	Range Rover (L405)	ABS - Anti-Lock Brake System Control Module	DATA
KK52-14C037-EJF.vbf	Range Rover (L405)	ABS - Anti-Lock Brake System Control Module	DATA
KK52-14C037-EJG.vbf	Range Rover (L405)	ABS - Anti-Lock Brake System Control Module	DATA
KK52-14C037-EJH.vbf	Range Rover (L405)	ABS - Anti-Lock Brake System Control Module	DATA
KK52-14C037-FAD.vbf	Range Rover (L405)	ABS - Anti-Lock Brake System Control Module	DATA
KK52-14C037-FAE.vbf	Range Rover (L405)	ABS - Anti-Lock Brake System Control Module	DATA
KK52-14C037-FAF.vbf	Range Rover (L405)	ABS - Anti-Lock Brake System Control Module	DATA
KK52-14C037-FAG.vbf	Range Rover (L405)	ABS - Anti-Lock Brake System Control Module	DATA
KK52-14C037-FAH.vbf	Range Rover (L405)	ABS - Anti-Lock Brake System Control Module	DATA
KK52-14C037-FAJ.vbf	Range Rover (L405)	ABS - Anti-Lock Brake System Control Module	DATA
KK52-14C037-FAK.vbf	Range Rover (L405)	ABS - Anti-Lock Brake System Control Module	DATA
KK52-14C037-FBD.vbf	Range Rover (L405)	ABS - Anti-Lock Brake System Control Module	DATA
KK52-14C037-FBE.vbf	Range Rover (L405)	ABS - Anti-Lock Brake System Control Module	DATA
KK52-14C037-FBF.vbf	Range Rover (L405)	ABS - Anti-Lock Brake System Control Module	DATA
KK52-14C037-FBG.vbf	Range Rover (L405)	ABS - Anti-Lock Brake System Control Module	DATA
KK52-14C037-FBH.vbf	Range Rover (L405)	ABS - Anti-Lock Brake System Control Module	DATA
KK52-14C037-FBJ.vbf	Range Rover (L405)	ABS - Anti-Lock Brake System Control Module	DATA
KK52-14C037-FBK.vbf	Range Rover (L405)	ABS - Anti-Lock Brake System Control Module	DATA
KK52-14C037-FCE.vbf	Range Rover (L405)	ABS - Anti-Lock Brake System Control Module	DATA
KK52-14C037-FCF.vbf	Range Rover (L405)	ABS - Anti-Lock Brake System Control Module	DATA
KK52-14C037-FCG.vbf	Range Rover (L405)	ABS - Anti-Lock Brake System Control Module	DATA
KK52-14C037-FCH.vbf	Range Rover (L405)	ABS - Anti-Lock Brake System Control Module	DATA
KK52-14C037-FCJ.vbf	Range Rover (L405)	ABS - Anti-Lock Brake System Control Module	DATA
KK52-14C037-FCK.vbf	Range Rover (L405)	ABS - Anti-Lock Brake System Control Module	DATA
KK52-14C037-FDE.vbf	Range Rover (L405)	ABS - Anti-Lock Brake System Control Module	DATA
KK52-14C037-FDF.vbf	Range Rover (L405)	ABS - Anti-Lock Brake System Control Module	DATA
KK52-14C037-FDG.vbf	Range Rover (L405)	ABS - Anti-Lock Brake System Control Module	DATA
KK52-14C037-FDH.vbf	Range Rover (L405)	ABS - Anti-Lock Brake System Control Module	DATA
KK52-14C037-FDJ.vbf	Range Rover (L405)	ABS - Anti-Lock Brake System Control Module	DATA
KK52-14C037-FDK.vbf	Range Rover (L405)	ABS - Anti-Lock Brake System Control Module	DATA
KK52-14C037-FFC.vbf	Range Rover (L405)	ABS - Anti-Lock Brake System Control Module	DATA
KK52-14C037-FFD.vbf	Range Rover (L405)	ABS - Anti-Lock Brake System Control Module	DATA
KK52-14C037-FFE.vbf	Range Rover (L405)	ABS - Anti-Lock Brake System Control Module	DATA
KK52-14C037-FFF.vbf	Range Rover (L405)	ABS - Anti-Lock Brake System Control Module	DATA
KK52-14C037-FFG.vbf	Range Rover (L405)	ABS - Anti-Lock Brake System Control Module	DATA
KK52-14C037-FFH.vbf	Range Rover (L405)	ABS - Anti-Lock Brake System Control Module	DATA
KK52-14C037-FFJ.vbf	Range Rover (L405)	ABS - Anti-Lock Brake System Control Module	DATA
KK52-14C037-FRB.vbf	Range Rover (L405)	ABS - Anti-Lock Brake System Control Module	DATA
KK52-14C037-FRC.vbf	Range Rover (L405)	ABS - Anti-Lock Brake System Control Module	DATA
KK52-14C037-FRD.vbf	Range Rover (L405)	ABS - Anti-Lock Brake System Control Module	DATA
KK52-14C037-FRE.vbf	Range Rover (L405)	ABS - Anti-Lock Brake System Control Module	DATA
KK52-14C037-FRF.vbf	Range Rover (L405)	ABS - Anti-Lock Brake System Control Module	DATA
KK52-14C037-FRG.vbf	Range Rover (L405)	ABS - Anti-Lock Brake System Control Module	DATA
KK52-14C037-FRH.vbf	Range Rover (L405)	ABS - Anti-Lock Brake System Control Module	DATA

File name	Vehicle line (indicative)	Module (ECU)	Type
KK52-14C037-FTB.vbf	Range Rover (L405)	ABS - Anti-Lock Brake System Control Module	DATA
KK52-14C037-FTC.vbf	Range Rover (L405)	ABS - Anti-Lock Brake System Control Module	DATA
KK52-14C037-FTD.vbf	Range Rover (L405)	ABS - Anti-Lock Brake System Control Module	DATA
KK52-14C037-FTE.vbf	Range Rover (L405)	ABS - Anti-Lock Brake System Control Module	DATA
KK52-14C037-FTF.vbf	Range Rover (L405)	ABS - Anti-Lock Brake System Control Module	DATA
KK52-14C037-FTG.vbf	Range Rover (L405)	ABS - Anti-Lock Brake System Control Module	DATA
KK52-14C037-FTH.vbf	Range Rover (L405)	ABS - Anti-Lock Brake System Control Module	DATA
KK52-14C037-HAA.vbf	Range Rover (L405)	ABS - Anti-Lock Brake System Control Module	DATA
KK52-14C037-HAB.vbf	Range Rover (L405)	ABS - Anti-Lock Brake System Control Module	DATA
KK52-14C037-HAC.vbf	Range Rover (L405)	ABS - Anti-Lock Brake System Control Module	DATA
KK52-14C037-HBA.vbf	Range Rover (L405)	ABS - Anti-Lock Brake System Control Module	DATA
KK52-14C037-HBB.vbf	Range Rover (L405)	ABS - Anti-Lock Brake System Control Module	DATA
KK52-14C037-HBC.vbf	Range Rover (L405)	ABS - Anti-Lock Brake System Control Module	DATA
KK52-14C185-AA.vbf	Range Rover (L405)	BCM - Body Control Module	DATA
KK52-14C185-AB.vbf	Range Rover (L405)	BCM - Body Control Module	DATA
KK52-14C273-NAA.vbf	Range Rover (L405)	PCM - Powertrain Control Module	SBL
KK52-14C527-DGA.vbf	Range Rover (L405)	AAM - Audio Amplifier Module	DATA
KK52-14C527-HGA.vbf	Range Rover (L405)	AAM - Audio Amplifier Module	DATA
KK52-14C570-SAA.vbf	Range Rover (L405)	PCM - Powertrain Control Module	EXE
KK52-14C570-SAC.vbf	Range Rover (L405)	PCM - Powertrain Control Module	EXE
KK52-14C570-SAD.vbf	Range Rover (L405)	PCM - Powertrain Control Module	EXE
KK52-14C570-SAE.vbf	Range Rover (L405)	PCM - Powertrain Control Module	EXE
KK52-14C570-SAF.vbf	Range Rover (L405)	PCM - Powertrain Control Module	EXE
KK52-14C570-SCC.vbf	Range Rover (L405)	PCM - Powertrain Control Module	EXE
KK52-14C570-SCD.vbf	Range Rover (L405)	PCM - Powertrain Control Module	EXE
KK52-14C570-SEC.vbf	Range Rover (L405)	PCM - Powertrain Control Module	EXE
KK52-14C570-SED.vbf	Range Rover (L405)	PCM - Powertrain Control Module	EXE
KK52-14C570-SHB.vbf	Range Rover (L405)	PCM - Powertrain Control Module	EXE
KK52-14C570-SHC.vbf	Range Rover (L405)	PCM - Powertrain Control Module	EXE
KK52-14C570-SHD.vbf	Range Rover (L405)	PCM - Powertrain Control Module	EXE
KK52-14C570-STC.vbf	Range Rover (L405)	PCM - Powertrain Control Module	EXE
KK52-14C570-STD.vbf	Range Rover (L405)	PCM - Powertrain Control Module	EXE
KK52-14D368-AB.vbf	Range Rover (L405)	SODR - Side Obstacle Detection Control Module - Right	EXE
KK52-14D368-AC.vbf	Range Rover (L405)	SODR - Side Obstacle Detection Control Module - Right	EXE
KK52-14D368-AD.vbf	Range Rover (L405)	SODR - Side Obstacle Detection Control Module - Right	EXE
KK52-14D368-AE.vbf	Range Rover (L405)	SODR - Side Obstacle Detection Control Module - Right	EXE
KK52-14D368-AF.vbf	Range Rover (L405)	SODR - Side Obstacle Detection Control Module - Right	EXE
KK52-14D368-AG.vbf	Range Rover (L405)	SODR - Side Obstacle Detection Control Module - Right	EXE
KK52-14D368-AH.vbf	Range Rover (L405)	SODR - Side Obstacle Detection Control Module - Right	EXE
KK52-14D368-AJ.vbf	Range Rover (L405)	SODR - Side Obstacle Detection Control Module - Right	EXE
KK52-14D368-AK.vbf	Range Rover (L405)	SODR - Side Obstacle Detection Control Module - Right	EXE
KK52-14D368-AL.vbf	Range Rover (L405)	SODR - Side Obstacle Detection Control Module - Right	EXE
KK52-14D368-BA.vbf	Range Rover (L405)	SODR - Side Obstacle Detection Control Module - Right	EXE
KK52-14D370-BA.vbf	Range Rover (L405)	SODR - Side Obstacle Detection Control Module - Right	SBL
KK52-14D564-AB.vbf	Range Rover (L405)	SODR - Side Obstacle Detection Control Module - Right	DATA
KK52-14D564-AC.vbf	Range Rover (L405)	SODR - Side Obstacle Detection Control Module - Right	DATA
KK52-14D564-AD.vbf	Range Rover (L405)	SODR - Side Obstacle Detection Control Module - Right	DATA
KK52-14D564-AE.vbf	Range Rover (L405)	SODR - Side Obstacle Detection Control Module - Right	DATA
KK52-14D564-AF.vbf	Range Rover (L405)	SODR - Side Obstacle Detection Control Module - Right	DATA
KK52-14D564-AG.vbf	Range Rover (L405)	SODR - Side Obstacle Detection Control Module - Right	DATA
KK52-14D564-AH.vbf	Range Rover (L405)	SODR - Side Obstacle Detection Control Module - Right	DATA
KK52-14D564-BA.vbf	Range Rover (L405)	SODR - Side Obstacle Detection Control Module - Right	DATA
KK52-14E094-JAA.vbf	Range Rover (L405)	CHCM - Chassis Control Module	EXE
KK52-14E094-JAB.vbf	Range Rover (L405)	CHCM - Chassis Control Module	EXE
KK52-14E094-JAC.vbf	Range Rover (L405)	CHCM - Chassis Control Module	EXE
KK52-14E094-JAD.vbf	Range Rover (L405)	CHCM - Chassis Control Module	EXE
KK52-14E094-JAF.vbf	Range Rover (L405)	CHCM - Chassis Control Module	EXE
KK52-14E094-JAG.vbf	Range Rover (L405)	CHCM - Chassis Control Module	EXE
KK52-14E094-JAH.vbf	Range Rover (L405)	CHCM - Chassis Control Module	EXE
KK52-14E094-JBA.vbf	Range Rover (L405)	CHCM - Chassis Control Module	EXE
KK52-14E094-JBB.vbf	Range Rover (L405)	CHCM - Chassis Control Module	EXE
KK52-14E094-JBC.vbf	Range Rover (L405)	CHCM - Chassis Control Module	EXE
KK52-14E094-JBD.vbf	Range Rover (L405)	CHCM - Chassis Control Module	EXE
KK52-14E094-JBF.vbf	Range Rover (L405)	CHCM - Chassis Control Module	EXE
KK52-14E094-JBG.vbf	Range Rover (L405)	CHCM - Chassis Control Module	EXE
KK52-14E094-JBH.vbf	Range Rover (L405)	CHCM - Chassis Control Module	EXE
KK52-14E094-JCA.vbf	Range Rover (L405)	CHCM - Chassis Control Module	EXE
KK52-14E094-JCB.vbf	Range Rover (L405)	CHCM - Chassis Control Module	EXE
KK52-14E094-JCC.vbf	Range Rover (L405)	CHCM - Chassis Control Module	EXE
KK52-14E094-JCD.vbf	Range Rover (L405)	CHCM - Chassis Control Module	EXE
KK52-14E094-JCE.vbf	Range Rover (L405)	CHCM - Chassis Control Module	EXE
KK52-14E094-JCF.vbf	Range Rover (L405)	CHCM - Chassis Control Module	EXE
KK52-14E094-JCG.vbf	Range Rover (L405)	CHCM - Chassis Control Module	EXE
KK52-14E094-JDA.vbf	Range Rover (L405)	CHCM - Chassis Control Module	EXE
KK52-14E094-JDB.vbf	Range Rover (L405)	CHCM - Chassis Control Module	EXE
KK52-14E094-JDC.vbf	Range Rover (L405)	CHCM - Chassis Control Module	EXE

File name	Vehicle line (indicative)	Module (ECU)	Type
KK52-14E094-JDD.vbf	Range Rover (L405)	CHCM - Chassis Control Module	EXE
KK52-14E094-JDE.vbf	Range Rover (L405)	CHCM - Chassis Control Module	EXE
KK52-14E094-JDF.vbf	Range Rover (L405)	CHCM - Chassis Control Module	EXE
KK52-14E094-JDG.vbf	Range Rover (L405)	CHCM - Chassis Control Module	EXE
KK52-14E094-JEA.vbf	Range Rover (L405)	CHCM - Chassis Control Module	EXE
KK52-14E094-JEB.vbf	Range Rover (L405)	CHCM - Chassis Control Module	EXE
KK52-14E094-JEC.vbf	Range Rover (L405)	CHCM - Chassis Control Module	EXE
KK52-14E094-JED.vbf	Range Rover (L405)	CHCM - Chassis Control Module	EXE
KK52-14E094-JEE.vbf	Range Rover (L405)	CHCM - Chassis Control Module	EXE
KK52-14E094-JEF.vbf	Range Rover (L405)	CHCM - Chassis Control Module	EXE
KK52-14E094-JEG.vbf	Range Rover (L405)	CHCM - Chassis Control Module	EXE
KK52-14E094-JFA.vbf	Range Rover (L405)	CHCM - Chassis Control Module	EXE
KK52-14E094-JFB.vbf	Range Rover (L405)	CHCM - Chassis Control Module	EXE
KK52-14E094-JFC.vbf	Range Rover (L405)	CHCM - Chassis Control Module	EXE
KK52-14E094-JFD.vbf	Range Rover (L405)	CHCM - Chassis Control Module	EXE
KK52-14E094-JFE.vbf	Range Rover (L405)	CHCM - Chassis Control Module	EXE
KK52-14E094-JFF.vbf	Range Rover (L405)	CHCM - Chassis Control Module	EXE
KK52-14E094-JFG.vbf	Range Rover (L405)	CHCM - Chassis Control Module	EXE
KK52-14E094-JGA.vbf	Range Rover (L405)	CHCM - Chassis Control Module	EXE
KK52-14E094-JGB.vbf	Range Rover (L405)	CHCM - Chassis Control Module	EXE
KK52-14E094-JGC.vbf	Range Rover (L405)	CHCM - Chassis Control Module	EXE
KK52-14E094-JGD.vbf	Range Rover (L405)	CHCM - Chassis Control Module	EXE
KK52-14E094-JGE.vbf	Range Rover (L405)	CHCM - Chassis Control Module	EXE
KK52-14E094-JGF.vbf	Range Rover (L405)	CHCM - Chassis Control Module	EXE
KK52-14E094-JGG.vbf	Range Rover (L405)	CHCM - Chassis Control Module	EXE
KK52-14E094-JHA.vbf	Range Rover (L405)	CHCM - Chassis Control Module	EXE
KK52-14E094-JHB.vbf	Range Rover (L405)	CHCM - Chassis Control Module	EXE
KK52-14E094-JHC.vbf	Range Rover (L405)	CHCM - Chassis Control Module	EXE
KK52-14E094-JHD.vbf	Range Rover (L405)	CHCM - Chassis Control Module	EXE
KK52-14E094-JHE.vbf	Range Rover (L405)	CHCM - Chassis Control Module	EXE
KK52-14E094-JHF.vbf	Range Rover (L405)	CHCM - Chassis Control Module	EXE
KK52-14E094-JHG.vbf	Range Rover (L405)	CHCM - Chassis Control Module	EXE
KK52-14E094-JJA.vbf	Range Rover (L405)	CHCM - Chassis Control Module	EXE
KK52-14E094-JJB.vbf	Range Rover (L405)	CHCM - Chassis Control Module	EXE
KK52-14E094-JJC.vbf	Range Rover (L405)	CHCM - Chassis Control Module	EXE
KK52-14E094-JJD.vbf	Range Rover (L405)	CHCM - Chassis Control Module	EXE
KK52-14E094-JJE.vbf	Range Rover (L405)	CHCM - Chassis Control Module	EXE
KK52-14E094-JJF.vbf	Range Rover (L405)	CHCM - Chassis Control Module	EXE
KK52-14E094-JJG.vbf	Range Rover (L405)	CHCM - Chassis Control Module	EXE
KK52-14E094-JKA.vbf	Range Rover (L405)	CHCM - Chassis Control Module	EXE
KK52-14E094-JKB.vbf	Range Rover (L405)	CHCM - Chassis Control Module	EXE
KK52-14E094-JKC.vbf	Range Rover (L405)	CHCM - Chassis Control Module	EXE
KK52-14E094-JKD.vbf	Range Rover (L405)	CHCM - Chassis Control Module	EXE
KK52-14E094-JKE.vbf	Range Rover (L405)	CHCM - Chassis Control Module	EXE
KK52-14E094-JKF.vbf	Range Rover (L405)	CHCM - Chassis Control Module	EXE
KK52-14E094-JKG.vbf	Range Rover (L405)	CHCM - Chassis Control Module	EXE
KK52-14E094-JMA.vbf	Range Rover (L405)	CHCM - Chassis Control Module	EXE
KK52-14E094-JMB.vbf	Range Rover (L405)	CHCM - Chassis Control Module	EXE
KK52-14E094-JMC.vbf	Range Rover (L405)	CHCM - Chassis Control Module	EXE
KK52-14E094-JMD.vbf	Range Rover (L405)	CHCM - Chassis Control Module	EXE
KK52-14E094-JME.vbf	Range Rover (L405)	CHCM - Chassis Control Module	EXE
KK52-14E094-JMF.vbf	Range Rover (L405)	CHCM - Chassis Control Module	EXE
KK52-14E094-JMG.vbf	Range Rover (L405)	CHCM - Chassis Control Module	EXE
KK52-14E094-JNA.vbf	Range Rover (L405)	CHCM - Chassis Control Module	EXE
KK52-14E094-JNB.vbf	Range Rover (L405)	CHCM - Chassis Control Module	EXE
KK52-14E094-JNC.vbf	Range Rover (L405)	CHCM - Chassis Control Module	EXE
KK52-14E094-JND.vbf	Range Rover (L405)	CHCM - Chassis Control Module	EXE
KK52-14E094-JNE.vbf	Range Rover (L405)	CHCM - Chassis Control Module	EXE
KK52-14E094-JNF.vbf	Range Rover (L405)	CHCM - Chassis Control Module	EXE
KK52-14E094-JNG.vbf	Range Rover (L405)	CHCM - Chassis Control Module	EXE
KK52-14F230-AA.vbf	Range Rover (L405)	HUD - Head Up Display	EXE
KK52-14F230-AB.vbf	Range Rover (L405)	HUD - Head Up Display	EXE
KK52-14F230-AC.vbf	Range Rover (L405)	HUD - Head Up Display	EXE
KK52-14F231-AA.vbf	Range Rover (L405)	HUD - Head Up Display	DATA
KK52-14F231-AB.vbf	Range Rover (L405)	HUD - Head Up Display	DATA
KK52-14F231-AC.vbf	Range Rover (L405)	HUD - Head Up Display	DATA
KK52-14F435-NAA.vbf	Range Rover (L405)	CHCMB - Chassis Control Module B	EXE
KK52-14F435-NAB.vbf	Range Rover (L405)	CHCMB - Chassis Control Module B	EXE
KK52-14F435-NAD.vbf	Range Rover (L405)	CHCMB - Chassis Control Module B	EXE
KK52-14F435-NAE.vbf	Range Rover (L405)	CHCMB - Chassis Control Module B	EXE
KK52-14F435-NAF.vbf	Range Rover (L405)	CHCMB - Chassis Control Module B	EXE
KK52-14F435-NBA.vbf	Range Rover (L405)	CHCMB - Chassis Control Module B	EXE
KK52-14F435-NBB.vbf	Range Rover (L405)	CHCMB - Chassis Control Module B	EXE
KK52-14F435-NBC.vbf	Range Rover (L405)	CHCMB - Chassis Control Module B	EXE
KK52-14F435-NBD.vbf	Range Rover (L405)	CHCMB - Chassis Control Module B	EXE
KK52-14F435-NBE.vbf	Range Rover (L405)	CHCMB - Chassis Control Module B	EXE

File name	Vehicle line (indicative)	Module (ECU)	Type
KK52-14F435-NCA.vbf	Range Rover (L405)	CHCMB - Chassis Control Module B	EXE
KK52-14F435-NCB.vbf	Range Rover (L405)	CHCMB - Chassis Control Module B	EXE
KK52-14F435-NCC.vbf	Range Rover (L405)	CHCMB - Chassis Control Module B	EXE
KK52-14F435-NCD.vbf	Range Rover (L405)	CHCMB - Chassis Control Module B	EXE
KK52-14F435-NCE.vbf	Range Rover (L405)	CHCMB - Chassis Control Module B	EXE
KK52-14F435-NDA.vbf	Range Rover (L405)	CHCMB - Chassis Control Module B	EXE
KK52-14F435-NDB.vbf	Range Rover (L405)	CHCMB - Chassis Control Module B	EXE
KK52-14F435-NDC.vbf	Range Rover (L405)	CHCMB - Chassis Control Module B	EXE
KK52-14F435-NDD.vbf	Range Rover (L405)	CHCMB - Chassis Control Module B	EXE
KK52-14F435-NDE.vbf	Range Rover (L405)	CHCMB - Chassis Control Module B	EXE
KK52-14F530-AA.vbf	Range Rover (L405)	GWM - Gateway Module A	EXE
KK52-14F530-AC.vbf	Range Rover (L405)	GWM - Gateway Module A	EXE
KK52-14F530-AD.vbf	Range Rover (L405)	GWM - Gateway Module A	EXE
KK52-14F530-AE.vbf	Range Rover (L405)	GWM - Gateway Module A	EXE
KK52-14F530-AF.vbf	Range Rover (L405)	GWM - Gateway Module A	EXE
KK52-14F530-AG.vbf	Range Rover (L405)	GWM - Gateway Module A	EXE
KK52-14F530-BA.vbf	Range Rover (L405)	GWM - Gateway Module A	EXE
KK52-14F530-BC.vbf	Range Rover (L405)	GWM - Gateway Module A	EXE
KK52-14F530-BD.vbf	Range Rover (L405)	GWM - Gateway Module A	EXE
KK52-14F530-BE.vbf	Range Rover (L405)	GWM - Gateway Module A	EXE
KK52-14F530-BF.vbf	Range Rover (L405)	GWM - Gateway Module A	EXE
KK52-14F530-CA.vbf	Range Rover (L405)	GWM - Gateway Module A	EXE
KK52-14F530-CC.vbf	Range Rover (L405)	GWM - Gateway Module A	EXE
KK52-14F530-CD.vbf	Range Rover (L405)	GWM - Gateway Module A	EXE
KK52-14F530-CE.vbf	Range Rover (L405)	GWM - Gateway Module A	EXE
KK52-14F530-CF.vbf	Range Rover (L405)	GWM - Gateway Module A	EXE
KK52-14F530-DA.vbf	Range Rover (L405)	GWM - Gateway Module A	EXE
KK52-14F530-DB.vbf	Range Rover (L405)	GWM - Gateway Module A	EXE
KK52-14F530-DC.vbf	Range Rover (L405)	GWM - Gateway Module A	EXE
KK52-14F530-DD.vbf	Range Rover (L405)	GWM - Gateway Module A	EXE
KK52-14F530-DE.vbf	Range Rover (L405)	GWM - Gateway Module A	EXE
KK52-14F530-DF.vbf	Range Rover (L405)	GWM - Gateway Module A	EXE
KK52-14F530-DG.vbf	Range Rover (L405)	GWM - Gateway Module A	EXE
KK52-14F530-DH.vbf	Range Rover (L405)	GWM - Gateway Module A	EXE
KK52-14F530-DJ.vbf	Range Rover (L405)	GWM - Gateway Module A	EXE
KK52-14F531-AA.vbf	Range Rover (L405)	GWM - Gateway Module A	DATA
KK52-14F531-AC.vbf	Range Rover (L405)	GWM - Gateway Module A	DATA
KK52-14F531-AD.vbf	Range Rover (L405)	GWM - Gateway Module A	DATA
KK52-14F531-AE.vbf	Range Rover (L405)	GWM - Gateway Module A	DATA
KK52-14F531-BA.vbf	Range Rover (L405)	GWM - Gateway Module A	DATA
KK52-14F531-BC.vbf	Range Rover (L405)	GWM - Gateway Module A	DATA
KK52-14F531-BD.vbf	Range Rover (L405)	GWM - Gateway Module A	DATA
KK52-14F531-BE.vbf	Range Rover (L405)	GWM - Gateway Module A	DATA
KK52-14F531-CA.vbf	Range Rover (L405)	GWM - Gateway Module A	DATA
KK52-14F531-CC.vbf	Range Rover (L405)	GWM - Gateway Module A	DATA
KK52-14F531-CD.vbf	Range Rover (L405)	GWM - Gateway Module A	DATA
KK52-14F531-CE.vbf	Range Rover (L405)	GWM - Gateway Module A	DATA
KK52-14F531-DA.vbf	Range Rover (L405)	GWM - Gateway Module A	DATA
KK52-14F531-DB.vbf	Range Rover (L405)	GWM - Gateway Module A	DATA
KK52-14F531-DC.vbf	Range Rover (L405)	GWM - Gateway Module A	DATA
KK52-14F531-DD.vbf	Range Rover (L405)	GWM - Gateway Module A	DATA
KK52-14F531-DE.vbf	Range Rover (L405)	GWM - Gateway Module A	DATA
KK52-7J104-CZA.vbf	Range Rover (L405)	TCM - Transmission Control Module	EXE
KK52-7J104-CZB.vbf	Range Rover (L405)	TCM - Transmission Control Module	EXE
KK52-7J104-CZC.vbf	Range Rover (L405)	TCM - Transmission Control Module	EXE
KK52-7J104-FCB.vbf	Range Rover (L405)	TCM - Transmission Control Module	EXE
KK52-7J104-FCC.vbf	Range Rover (L405)	TCM - Transmission Control Module	EXE
KK52-7J104-FCD.vbf	Range Rover (L405)	TCM - Transmission Control Module	EXE
KK52-7J104-FCE.vbf	Range Rover (L405)	TCM - Transmission Control Module	EXE
KK52-7J104-FCF.vbf	Range Rover (L405)	TCM - Transmission Control Module	EXE
KK52-7J104-FEA.vbf	Range Rover (L405)	TCM - Transmission Control Module	EXE
KK52-7J104-FEB.vbf	Range Rover (L405)	TCM - Transmission Control Module	EXE
KK52-7J104-FEC.vbf	Range Rover (L405)	TCM - Transmission Control Module	EXE
KK52-7J104-FED.vbf	Range Rover (L405)	TCM - Transmission Control Module	EXE
KK52-7J104-FFA.vbf	Range Rover (L405)	TCM - Transmission Control Module	EXE
KK52-7J104-FFB.vbf	Range Rover (L405)	TCM - Transmission Control Module	EXE
KK52-7J104-FFC.vbf	Range Rover (L405)	TCM - Transmission Control Module	EXE
KK52-7J104-FGA.vbf	Range Rover (L405)	TCM - Transmission Control Module	EXE
KK52-7J104-FGB.vbf	Range Rover (L405)	TCM - Transmission Control Module	EXE
KK52-7J104-FGC.vbf	Range Rover (L405)	TCM - Transmission Control Module	EXE
KK52-7J104-FGD.vbf	Range Rover (L405)	TCM - Transmission Control Module	EXE
KK52-7J104-GHB.vbf	Range Rover (L405)	TCM - Transmission Control Module	EXE
KK52-7J104-GHD.vbf	Range Rover (L405)	TCM - Transmission Control Module	EXE
KK52-7J104-GHE.vbf	Range Rover (L405)	TCM - Transmission Control Module	EXE
KK52-7J104-GHG.vbf	Range Rover (L405)	TCM - Transmission Control Module	EXE
KK52-7J104-GHJ.vbf	Range Rover (L405)	TCM - Transmission Control Module	EXE

File name	Vehicle line (indicative)	Module (ECU)	Type
KK52-7J104-GHK.vbf	Range Rover (L405)	TCM - Transmission Control Module	EXE
KK5M-14C030-AA.vbf	Not specified	DSM - Driver Front Seat Module	EXE
KK5M-14C034-AA.vbf	Not specified	DSM - Driver Front Seat Module	EXE
KK5M-14C065-AB.vbf	Range Rover (L405)	DDM - Driver Front Door Module	DATA
KK5M-14C065-AC.vbf	Range Rover (L405)	DDM - Driver Front Door Module	DATA
KK5M-14C098-AA.vbf	Range Rover Sport (L494)	RCM - Restraints Control Module	DATA
KK5M-14C105-AA.vbf	Not specified	TMC Traffic Message Channel Module	EXE
KK5M-14C105-AB.vbf	Not specified	TMC Traffic Message Channel Module	EXE
KK5M-14C109-AB.vbf	Range Rover (L405)	PDM - Passenger Front Door Module	DATA
KK5M-14C109-AC.vbf	Range Rover (L405)	PDM - Passenger Front Door Module	DATA
KK5M-14C121-AB.vbf	Range Rover (L405)	RGTM - Rear Gate / Trunk Module	EXE
KK5M-14C122-AA.vbf	Range Rover (L405)	RGTM - Rear Gate / Trunk Module	DATA
KK5M-14C124-AA.vbf	Not specified	RGTM - Rear Gate / Trunk Module	SBL
KK5M-14C152-AA.vbf	Not specified	TPM - Tire Pressure Monitor Module	DATA
KK5M-14C152-AB.vbf	Not specified	TPM - Tire Pressure Monitor Module	DATA
KK5M-14C218-BA.vbf	Not specified	PSCM - Power Steering Control Module	EXE
KK5M-14C218-BB.vbf	Not specified	PSCM - Power Steering Control Module	EXE
KK5M-14C527-DA.vbf	Not specified	AAM - Audio Amplifier Module	DATA
KK5M-14C527-DAA.vbf	Not specified	AAM - Audio Amplifier Module	DATA
KK5M-14C527-DAB.vbf	Not specified	AAM - Audio Amplifier Module	DATA
KK5M-14C527-DAC.vbf	Not specified	AAM - Audio Amplifier Module	DATA
KK5M-14C527-DB.vbf	Not specified	AAM - Audio Amplifier Module	DATA
KK5M-14C527-DBA.vbf	Not specified	AAM - Audio Amplifier Module	DATA
KK5M-14C527-DBB.vbf	Not specified	AAM - Audio Amplifier Module	DATA
KK5M-14C548-AA.vbf	Not specified	PSM - Passenger Front Seat Module	EXE
KK5M-14C549-AA.vbf	Not specified	DSM - Driver Front Seat Module	EXE
KK5M-14C570-SCA.vbf	Not specified	PCM - Powertrain Control Module	EXE
KK5M-14C570-SHA.vbf	Not specified	PCM - Powertrain Control Module	EXE
KK5M-14C570-STA.vbf	Not specified	PCM - Powertrain Control Module	EXE
KK5M-14D092-AA.vbf	Not specified	TCM - Transmission Control Module	EXE
KK5M-14D183-AA.vbf	Not specified	OCS - Restraints Occupant Classification System Module	DATA
KK5M-14E094-JSA.vbf	Not specified	CHCM - Chassis Control Module	EXE
KK5M-14E094-JSB.vbf	Not specified	CHCM - Chassis Control Module	EXE
KK5M-14E094-JSC.vbf	Not specified	CHCM - Chassis Control Module	EXE
KK5M-14E094-JSD.vbf	Not specified	CHCM - Chassis Control Module	EXE
KK5M-14E094-JSE.vbf	Not specified	CHCM - Chassis Control Module	EXE
KK5M-14E094-JSF.vbf	Not specified	CHCM - Chassis Control Module	EXE
KK5M-14E094-JSG.vbf	Not specified	CHCM - Chassis Control Module	EXE
KK5M-14E094-JSH.vbf	Not specified	CHCM - Chassis Control Module	EXE
KK5M-14E094-JTA.vbf	Not specified	CHCM - Chassis Control Module	EXE
KK5M-14E094-JTB.vbf	Not specified	CHCM - Chassis Control Module	EXE
KK5M-14E094-JTC.vbf	Not specified	CHCM - Chassis Control Module	EXE
KK5M-14E094-JTD.vbf	Not specified	CHCM - Chassis Control Module	EXE
KK5M-14E094-JTE.vbf	Not specified	CHCM - Chassis Control Module	EXE
KK5M-14E094-JTF.vbf	Not specified	CHCM - Chassis Control Module	EXE
KK5M-14E094-JTG.vbf	Not specified	CHCM - Chassis Control Module	EXE
KK5M-14E094-JUA.vbf	Not specified	CHCM - Chassis Control Module	EXE
KK5M-14E094-JUB.vbf	Not specified	CHCM - Chassis Control Module	EXE
KK5M-14E094-JUC.vbf	Not specified	CHCM - Chassis Control Module	EXE
KK5M-14E094-JUD.vbf	Not specified	CHCM - Chassis Control Module	EXE
KK5M-14E094-JUE.vbf	Not specified	CHCM - Chassis Control Module	EXE
KK5M-14E094-JUF.vbf	Not specified	CHCM - Chassis Control Module	EXE
KK5M-14E094-JUG.vbf	Not specified	CHCM - Chassis Control Module	EXE
KK5M-14E094-JVA.vbf	Not specified	CHCM - Chassis Control Module	EXE
KK5M-14E094-JVB.vbf	Not specified	CHCM - Chassis Control Module	EXE
KK5M-14E094-JVC.vbf	Not specified	CHCM - Chassis Control Module	EXE
KK5M-14E094-JVD.vbf	Not specified	CHCM - Chassis Control Module	EXE
KK5M-14E094-JVE.vbf	Not specified	CHCM - Chassis Control Module	EXE
KK5M-14E094-JVF.vbf	Not specified	CHCM - Chassis Control Module	EXE
KK5M-14E172-AA.vbf	Not specified	PCM - Powertrain Control Module	EXE
KK5M-14F435-NFA.vbf	Not specified	CHCMB - Chassis Control Module B	EXE
KK5M-14F435-NFB.vbf	Not specified	CHCMB - Chassis Control Module B	EXE
KK5M-14F435-NFC.vbf	Not specified	CHCMB - Chassis Control Module B	EXE
KK5M-14F435-NFD.vbf	Not specified	CHCMB - Chassis Control Module B	EXE
KK5M-14F435-NFE.vbf	Not specified	CHCMB - Chassis Control Module B	EXE
KK5M-14F435-NGA.vbf	Not specified	CHCMB - Chassis Control Module B	EXE
KK5M-14F435-NGB.vbf	Not specified	CHCMB - Chassis Control Module B	EXE
KK5M-14F435-NGC.vbf	Not specified	CHCMB - Chassis Control Module B	EXE
KK5M-14F435-NGD.vbf	Not specified	CHCMB - Chassis Control Module B	EXE
KK5M-14F435-NGE.vbf	Not specified	CHCMB - Chassis Control Module B	EXE
KK5M-14F435-NHA.vbf	Not specified	CHCMB - Chassis Control Module B	EXE
KK5M-14F435-NHB.vbf	Not specified	CHCMB - Chassis Control Module B	EXE
KK5M-14F435-NHD.vbf	Not specified	CHCMB - Chassis Control Module B	EXE
KK5M-14F435-NHE.vbf	Not specified	CHCMB - Chassis Control Module B	EXE
KK5M-14F435-NHF.vbf	Not specified	CHCMB - Chassis Control Module B	EXE
KK5M-14G036-AA.vbf	Not specified	SCMD - Seat Control Module D	EXE

File name	Vehicle line (indicative)	Module (ECU)	Type
KK5M-14G037-AA.vbf	Not specified	SCMC - Seat Control Module C	EXE
KK5M-14G046-AA.vbf	Not specified	SCMC - Seat Control Module C	EXE
KK5M-14G047-AA.vbf	Not specified	SCMC - Seat Control Module C	EXE
KK5M-14G047-BA.vbf	Not specified	SCMC - Seat Control Module C	EXE
KK62-12K532-PCC.vbf	Range Rover Sport (L494)	PCM - Powertrain Control Module	EXE
KK62-12K532-PCD.vbf	Range Rover Sport (L494)	PCM - Powertrain Control Module	EXE
KK62-12K532-PFC.vbf	Range Rover Sport (L494)	PCM - Powertrain Control Module	EXE
KK62-12K532-PFD.vbf	Range Rover Sport (L494)	PCM - Powertrain Control Module	EXE
KK62-12K532-PFF.vbf	Range Rover Sport (L494)	PCM - Powertrain Control Module	EXE
KK62-12K532-PKC.vbf	Range Rover Sport (L494)	PCM - Powertrain Control Module	EXE
KK62-12K532-PKD.vbf	Range Rover Sport (L494)	PCM - Powertrain Control Module	EXE
KK62-12K532-PKE.vbf	Range Rover Sport (L494)	PCM - Powertrain Control Module	EXE
KK62-12K532-PKF.vbf	Range Rover Sport (L494)	PCM - Powertrain Control Module	EXE
KK62-12K532-PKG.vbf	Range Rover Sport (L494)	PCM - Powertrain Control Module	EXE
KK62-12K532-PMC.vbf	Range Rover Sport (L494)	PCM - Powertrain Control Module	EXE
KK62-12K532-PMD.vbf	Range Rover Sport (L494)	PCM - Powertrain Control Module	EXE
KK62-12K532-PME.vbf	Range Rover Sport (L494)	PCM - Powertrain Control Module	EXE
KK62-12K532-PRC.vbf	Range Rover Sport (L494)	PCM - Powertrain Control Module	EXE
KK62-12K532-PRD.vbf	Range Rover Sport (L494)	PCM - Powertrain Control Module	EXE
KK62-12K532-PRE.vbf	Range Rover Sport (L494)	PCM - Powertrain Control Module	EXE
KK62-12K532-PSC.vbf	Range Rover Sport (L494)	PCM - Powertrain Control Module	EXE
KK62-12K532-PSD.vbf	Range Rover Sport (L494)	PCM - Powertrain Control Module	EXE
KK62-12K532-PSE.vbf	Range Rover Sport (L494)	PCM - Powertrain Control Module	EXE
KK62-12K532-PSF.vbf	Range Rover Sport (L494)	PCM - Powertrain Control Module	EXE
KK62-12K532-PSG.vbf	Range Rover Sport (L494)	PCM - Powertrain Control Module	EXE
KK62-12K532-PYA.vbf	Range Rover Sport (L494)	PCM - Powertrain Control Module	DATA
KK62-12K532-PYB.vbf	Range Rover Sport (L494)	PCM - Powertrain Control Module	DATA
KK62-12K532-PYD.vbf	Range Rover Sport (L494)	PCM - Powertrain Control Module	EXE
KK62-12K532-PYE.vbf	Range Rover Sport (L494)	PCM - Powertrain Control Module	EXE
KK62-12K532-PYF.vbf	Range Rover Sport (L494)	PCM - Powertrain Control Module	EXE
KK62-12K532-PYG.vbf	Range Rover Sport (L494)	PCM - Powertrain Control Module	EXE
KK62-12K532-PYH.vbf	Range Rover Sport (L494)	PCM - Powertrain Control Module	EXE
KK62-12K532-PYJ.vbf	Range Rover Sport (L494)	PCM - Powertrain Control Module	EXE
KK62-14C026-KA.vbf	Range Rover Sport (L494)	IPC - Instrument Panel Cluster (IPC) Control Module	EXE
KK62-14C037-AAD.vbf	Range Rover Sport (L494)	ABS - Anti-Lock Brake System Control Module	DATA
KK62-14C037-AAE.vbf	Range Rover Sport (L494)	ABS - Anti-Lock Brake System Control Module	DATA
KK62-14C037-AAF.vbf	Range Rover Sport (L494)	ABS - Anti-Lock Brake System Control Module	DATA
KK62-14C037-AAG.vbf	Range Rover Sport (L494)	ABS - Anti-Lock Brake System Control Module	DATA
KK62-14C037-AAH.vbf	Range Rover Sport (L494)	ABS - Anti-Lock Brake System Control Module	DATA
KK62-14C037-AAJ.vbf	Range Rover Sport (L494)	ABS - Anti-Lock Brake System Control Module	DATA
KK62-14C037-AAK.vbf	Range Rover Sport (L494)	ABS - Anti-Lock Brake System Control Module	DATA
KK62-14C037-ABD.vbf	Range Rover Sport (L494)	ABS - Anti-Lock Brake System Control Module	DATA
KK62-14C037-ABE.vbf	Range Rover Sport (L494)	ABS - Anti-Lock Brake System Control Module	DATA
KK62-14C037-ABF.vbf	Range Rover Sport (L494)	ABS - Anti-Lock Brake System Control Module	DATA
KK62-14C037-ABG.vbf	Range Rover Sport (L494)	ABS - Anti-Lock Brake System Control Module	DATA
KK62-14C037-ABH.vbf	Range Rover Sport (L494)	ABS - Anti-Lock Brake System Control Module	DATA
KK62-14C037-ABJ.vbf	Range Rover Sport (L494)	ABS - Anti-Lock Brake System Control Module	DATA
KK62-14C037-ABK.vbf	Range Rover Sport (L494)	ABS - Anti-Lock Brake System Control Module	DATA
KK62-14C037-ACD.vbf	Range Rover Sport (L494)	ABS - Anti-Lock Brake System Control Module	DATA
KK62-14C037-ACE.vbf	Range Rover Sport (L494)	ABS - Anti-Lock Brake System Control Module	DATA
KK62-14C037-ACF.vbf	Range Rover Sport (L494)	ABS - Anti-Lock Brake System Control Module	DATA
KK62-14C037-ACG.vbf	Range Rover Sport (L494)	ABS - Anti-Lock Brake System Control Module	DATA
KK62-14C037-ACH.vbf	Range Rover Sport (L494)	ABS - Anti-Lock Brake System Control Module	DATA
KK62-14C037-ACJ.vbf	Range Rover Sport (L494)	ABS - Anti-Lock Brake System Control Module	DATA
KK62-14C037-ACK.vbf	Range Rover Sport (L494)	ABS - Anti-Lock Brake System Control Module	DATA
KK62-14C037-ADD.vbf	Range Rover Sport (L494)	ABS - Anti-Lock Brake System Control Module	DATA
KK62-14C037-ADE.vbf	Range Rover Sport (L494)	ABS - Anti-Lock Brake System Control Module	DATA
KK62-14C037-ADF.vbf	Range Rover Sport (L494)	ABS - Anti-Lock Brake System Control Module	DATA
KK62-14C037-ADG.vbf	Range Rover Sport (L494)	ABS - Anti-Lock Brake System Control Module	DATA
KK62-14C037-ADH.vbf	Range Rover Sport (L494)	ABS - Anti-Lock Brake System Control Module	DATA
KK62-14C037-ADJ.vbf	Range Rover Sport (L494)	ABS - Anti-Lock Brake System Control Module	DATA
KK62-14C037-ADK.vbf	Range Rover Sport (L494)	ABS - Anti-Lock Brake System Control Module	DATA
KK62-14C037-AED.vbf	Range Rover Sport (L494)	ABS - Anti-Lock Brake System Control Module	DATA
KK62-14C037-AEE.vbf	Range Rover Sport (L494)	ABS - Anti-Lock Brake System Control Module	DATA
KK62-14C037-AEF.vbf	Range Rover Sport (L494)	ABS - Anti-Lock Brake System Control Module	DATA
KK62-14C037-AEG.vbf	Range Rover Sport (L494)	ABS - Anti-Lock Brake System Control Module	DATA
KK62-14C037-AEH.vbf	Range Rover Sport (L494)	ABS - Anti-Lock Brake System Control Module	DATA
KK62-14C037-AEJ.vbf	Range Rover Sport (L494)	ABS - Anti-Lock Brake System Control Module	DATA
KK62-14C037-AEK.vbf	Range Rover Sport (L494)	ABS - Anti-Lock Brake System Control Module	DATA
KK62-14C037-AFD.vbf	Range Rover Sport (L494)	ABS - Anti-Lock Brake System Control Module	DATA
KK62-14C037-AFE.vbf	Range Rover Sport (L494)	ABS - Anti-Lock Brake System Control Module	DATA
KK62-14C037-AFF.vbf	Range Rover Sport (L494)	ABS - Anti-Lock Brake System Control Module	DATA
KK62-14C037-AFG.vbf	Range Rover Sport (L494)	ABS - Anti-Lock Brake System Control Module	DATA
KK62-14C037-AFH.vbf	Range Rover Sport (L494)	ABS - Anti-Lock Brake System Control Module	DATA
KK62-14C037-AFJ.vbf	Range Rover Sport (L494)	ABS - Anti-Lock Brake System Control Module	DATA
KK62-14C037-AFK.vbf	Range Rover Sport (L494)	ABS - Anti-Lock Brake System Control Module	DATA

File name	Vehicle line (indicative)	Module (ECU)	Type
KK62-14C037-AGD.vbf	Range Rover Sport (L494)	ABS - Anti-Lock Brake System Control Module	DATA
KK62-14C037-AGE.vbf	Range Rover Sport (L494)	ABS - Anti-Lock Brake System Control Module	DATA
KK62-14C037-AGF.vbf	Range Rover Sport (L494)	ABS - Anti-Lock Brake System Control Module	DATA
KK62-14C037-AGG.vbf	Range Rover Sport (L494)	ABS - Anti-Lock Brake System Control Module	DATA
KK62-14C037-AGH.vbf	Range Rover Sport (L494)	ABS - Anti-Lock Brake System Control Module	DATA
KK62-14C037-AGJ.vbf	Range Rover Sport (L494)	ABS - Anti-Lock Brake System Control Module	DATA
KK62-14C037-AGK.vbf	Range Rover Sport (L494)	ABS - Anti-Lock Brake System Control Module	DATA
KK62-14C037-AHD.vbf	Range Rover Sport (L494)	ABS - Anti-Lock Brake System Control Module	DATA
KK62-14C037-AHE.vbf	Range Rover Sport (L494)	ABS - Anti-Lock Brake System Control Module	DATA
KK62-14C037-AHF.vbf	Range Rover Sport (L494)	ABS - Anti-Lock Brake System Control Module	DATA
KK62-14C037-AHG.vbf	Range Rover Sport (L494)	ABS - Anti-Lock Brake System Control Module	DATA
KK62-14C037-AHH.vbf	Range Rover Sport (L494)	ABS - Anti-Lock Brake System Control Module	DATA
KK62-14C037-AHJ.vbf	Range Rover Sport (L494)	ABS - Anti-Lock Brake System Control Module	DATA
KK62-14C037-AHK.vbf	Range Rover Sport (L494)	ABS - Anti-Lock Brake System Control Module	DATA
KK62-14C037-AKD.vbf	Range Rover Sport (L494)	ABS - Anti-Lock Brake System Control Module	DATA
KK62-14C037-AKE.vbf	Range Rover Sport (L494)	ABS - Anti-Lock Brake System Control Module	DATA
KK62-14C037-AKF.vbf	Range Rover Sport (L494)	ABS - Anti-Lock Brake System Control Module	DATA
KK62-14C037-AKG.vbf	Range Rover Sport (L494)	ABS - Anti-Lock Brake System Control Module	DATA
KK62-14C037-AKH.vbf	Range Rover Sport (L494)	ABS - Anti-Lock Brake System Control Module	DATA
KK62-14C037-AKJ.vbf	Range Rover Sport (L494)	ABS - Anti-Lock Brake System Control Module	DATA
KK62-14C037-AKK.vbf	Range Rover Sport (L494)	ABS - Anti-Lock Brake System Control Module	DATA
KK62-14C037-AVD.vbf	Range Rover Sport (L494)	ABS - Anti-Lock Brake System Control Module	DATA
KK62-14C037-AVE.vbf	Range Rover Sport (L494)	ABS - Anti-Lock Brake System Control Module	DATA
KK62-14C037-AVF.vbf	Range Rover Sport (L494)	ABS - Anti-Lock Brake System Control Module	DATA
KK62-14C037-AVG.vbf	Range Rover Sport (L494)	ABS - Anti-Lock Brake System Control Module	DATA
KK62-14C037-AVH.vbf	Range Rover Sport (L494)	ABS - Anti-Lock Brake System Control Module	DATA
KK62-14C037-AVJ.vbf	Range Rover Sport (L494)	ABS - Anti-Lock Brake System Control Module	DATA
KK62-14C037-AVK.vbf	Range Rover Sport (L494)	ABS - Anti-Lock Brake System Control Module	DATA
KK62-14C037-AYD.vbf	Range Rover Sport (L494)	ABS - Anti-Lock Brake System Control Module	DATA
KK62-14C037-AYE.vbf	Range Rover Sport (L494)	ABS - Anti-Lock Brake System Control Module	DATA
KK62-14C037-AYF.vbf	Range Rover Sport (L494)	ABS - Anti-Lock Brake System Control Module	DATA
KK62-14C037-AYG.vbf	Range Rover Sport (L494)	ABS - Anti-Lock Brake System Control Module	DATA
KK62-14C037-AYH.vbf	Range Rover Sport (L494)	ABS - Anti-Lock Brake System Control Module	DATA
KK62-14C037-AYJ.vbf	Range Rover Sport (L494)	ABS - Anti-Lock Brake System Control Module	DATA
KK62-14C037-AYK.vbf	Range Rover Sport (L494)	ABS - Anti-Lock Brake System Control Module	DATA
KK62-14C037-DKD.vbf	Range Rover Sport (L494)	ABS - Anti-Lock Brake System Control Module	DATA
KK62-14C037-DKE.vbf	Range Rover Sport (L494)	ABS - Anti-Lock Brake System Control Module	DATA
KK62-14C037-DKF.vbf	Range Rover Sport (L494)	ABS - Anti-Lock Brake System Control Module	DATA
KK62-14C037-DKG.vbf	Range Rover Sport (L494)	ABS - Anti-Lock Brake System Control Module	DATA
KK62-14C037-DKH.vbf	Range Rover Sport (L494)	ABS - Anti-Lock Brake System Control Module	DATA
KK62-14C037-DKJ.vbf	Range Rover Sport (L494)	ABS - Anti-Lock Brake System Control Module	DATA
KK62-14C037-DKK.vbf	Range Rover Sport (L494)	ABS - Anti-Lock Brake System Control Module	DATA
KK62-14C037-DLD.vbf	Range Rover Sport (L494)	ABS - Anti-Lock Brake System Control Module	DATA
KK62-14C037-DMD.vbf	Range Rover Sport (L494)	ABS - Anti-Lock Brake System Control Module	DATA
KK62-14C037-DME.vbf	Range Rover Sport (L494)	ABS - Anti-Lock Brake System Control Module	DATA
KK62-14C037-DMF.vbf	Range Rover Sport (L494)	ABS - Anti-Lock Brake System Control Module	DATA
KK62-14C037-DMG.vbf	Range Rover Sport (L494)	ABS - Anti-Lock Brake System Control Module	DATA
KK62-14C037-DMH.vbf	Range Rover Sport (L494)	ABS - Anti-Lock Brake System Control Module	DATA
KK62-14C037-DMJ.vbf	Range Rover Sport (L494)	ABS - Anti-Lock Brake System Control Module	DATA
KK62-14C037-DND.vbf	Range Rover Sport (L494)	ABS - Anti-Lock Brake System Control Module	DATA
KK62-14C037-DNE.vbf	Range Rover Sport (L494)	ABS - Anti-Lock Brake System Control Module	DATA
KK62-14C037-DNF.vbf	Range Rover Sport (L494)	ABS - Anti-Lock Brake System Control Module	DATA
KK62-14C037-DNG.vbf	Range Rover Sport (L494)	ABS - Anti-Lock Brake System Control Module	DATA
KK62-14C037-DNH.vbf	Range Rover Sport (L494)	ABS - Anti-Lock Brake System Control Module	DATA
KK62-14C037-DNJ.vbf	Range Rover Sport (L494)	ABS - Anti-Lock Brake System Control Module	DATA
KK62-14C037-DNK.vbf	Range Rover Sport (L494)	ABS - Anti-Lock Brake System Control Module	DATA
KK62-14C037-DPD.vbf	Range Rover Sport (L494)	ABS - Anti-Lock Brake System Control Module	DATA
KK62-14C037-DPE.vbf	Range Rover Sport (L494)	ABS - Anti-Lock Brake System Control Module	DATA
KK62-14C037-DPF.vbf	Range Rover Sport (L494)	ABS - Anti-Lock Brake System Control Module	DATA
KK62-14C037-DPG.vbf	Range Rover Sport (L494)	ABS - Anti-Lock Brake System Control Module	DATA
KK62-14C037-DPH.vbf	Range Rover Sport (L494)	ABS - Anti-Lock Brake System Control Module	DATA
KK62-14C037-DPJ.vbf	Range Rover Sport (L494)	ABS - Anti-Lock Brake System Control Module	DATA
KK62-14C037-DPK.vbf	Range Rover Sport (L494)	ABS - Anti-Lock Brake System Control Module	DATA
KK62-14C037-ECD.vbf	Range Rover Sport (L494)	ABS - Anti-Lock Brake System Control Module	DATA
KK62-14C037-ECE.vbf	Range Rover Sport (L494)	ABS - Anti-Lock Brake System Control Module	DATA
KK62-14C037-ECF.vbf	Range Rover Sport (L494)	ABS - Anti-Lock Brake System Control Module	DATA
KK62-14C037-ECG.vbf	Range Rover Sport (L494)	ABS - Anti-Lock Brake System Control Module	DATA
KK62-14C037-ECH.vbf	Range Rover Sport (L494)	ABS - Anti-Lock Brake System Control Module	DATA
KK62-14C037-ECJ.vbf	Range Rover Sport (L494)	ABS - Anti-Lock Brake System Control Module	DATA
KK62-14C037-ECK.vbf	Range Rover Sport (L494)	ABS - Anti-Lock Brake System Control Module	DATA
KK62-14C037-EDA.vbf	Range Rover Sport (L494)	ABS - Anti-Lock Brake System Control Module	DATA
KK62-14C037-EED.vbf	Range Rover Sport (L494)	ABS - Anti-Lock Brake System Control Module	DATA
KK62-14C037-EEE.vbf	Range Rover Sport (L494)	ABS - Anti-Lock Brake System Control Module	DATA
KK62-14C037-EEF.vbf	Range Rover Sport (L494)	ABS - Anti-Lock Brake System Control Module	DATA
KK62-14C037-EEG.vbf	Range Rover Sport (L494)	ABS - Anti-Lock Brake System Control Module	DATA
KK62-14C037-EEH.vbf	Range Rover Sport (L494)	ABS - Anti-Lock Brake System Control Module	DATA

File name	Vehicle line (indicative)	Module (ECU)	Type
KK62-14C037-EEJ.vbf	Range Rover Sport (L494)	ABS - Anti-Lock Brake System Control Module	DATA
KK62-14C037-EEK.vbf	Range Rover Sport (L494)	ABS - Anti-Lock Brake System Control Module	DATA
KK62-14C037-EFD.vbf	Range Rover Sport (L494)	ABS - Anti-Lock Brake System Control Module	DATA
KK62-14C037-EFE.vbf	Range Rover Sport (L494)	ABS - Anti-Lock Brake System Control Module	DATA
KK62-14C037-EFF.vbf	Range Rover Sport (L494)	ABS - Anti-Lock Brake System Control Module	DATA
KK62-14C037-EFG.vbf	Range Rover Sport (L494)	ABS - Anti-Lock Brake System Control Module	DATA
KK62-14C037-EFH.vbf	Range Rover Sport (L494)	ABS - Anti-Lock Brake System Control Module	DATA
KK62-14C037-EFJ.vbf	Range Rover Sport (L494)	ABS - Anti-Lock Brake System Control Module	DATA
KK62-14C037-EFK.vbf	Range Rover Sport (L494)	ABS - Anti-Lock Brake System Control Module	DATA
KK62-14C037-EGD.vbf	Range Rover Sport (L494)	ABS - Anti-Lock Brake System Control Module	DATA
KK62-14C037-EGE.vbf	Range Rover Sport (L494)	ABS - Anti-Lock Brake System Control Module	DATA
KK62-14C037-EGF.vbf	Range Rover Sport (L494)	ABS - Anti-Lock Brake System Control Module	DATA
KK62-14C037-EGG.vbf	Range Rover Sport (L494)	ABS - Anti-Lock Brake System Control Module	DATA
KK62-14C037-EGH.vbf	Range Rover Sport (L494)	ABS - Anti-Lock Brake System Control Module	DATA
KK62-14C037-EGJ.vbf	Range Rover Sport (L494)	ABS - Anti-Lock Brake System Control Module	DATA
KK62-14C037-EGK.vbf	Range Rover Sport (L494)	ABS - Anti-Lock Brake System Control Module	DATA
KK62-14C037-FAD.vbf	Range Rover Sport (L494)	ABS - Anti-Lock Brake System Control Module	DATA
KK62-14C037-FAE.vbf	Range Rover Sport (L494)	ABS - Anti-Lock Brake System Control Module	DATA
KK62-14C037-FAF.vbf	Range Rover Sport (L494)	ABS - Anti-Lock Brake System Control Module	DATA
KK62-14C037-FAG.vbf	Range Rover Sport (L494)	ABS - Anti-Lock Brake System Control Module	DATA
KK62-14C037-FAH.vbf	Range Rover Sport (L494)	ABS - Anti-Lock Brake System Control Module	DATA
KK62-14C037-FAJ.vbf	Range Rover Sport (L494)	ABS - Anti-Lock Brake System Control Module	DATA
KK62-14C037-FAK.vbf	Range Rover Sport (L494)	ABS - Anti-Lock Brake System Control Module	DATA
KK62-14C037-FBD.vbf	Range Rover Sport (L494)	ABS - Anti-Lock Brake System Control Module	DATA
KK62-14C037-FBE.vbf	Range Rover Sport (L494)	ABS - Anti-Lock Brake System Control Module	DATA
KK62-14C037-FBF.vbf	Range Rover Sport (L494)	ABS - Anti-Lock Brake System Control Module	DATA
KK62-14C037-FBG.vbf	Range Rover Sport (L494)	ABS - Anti-Lock Brake System Control Module	DATA
KK62-14C037-FBH.vbf	Range Rover Sport (L494)	ABS - Anti-Lock Brake System Control Module	DATA
KK62-14C037-FBJ.vbf	Range Rover Sport (L494)	ABS - Anti-Lock Brake System Control Module	DATA
KK62-14C037-FBK.vbf	Range Rover Sport (L494)	ABS - Anti-Lock Brake System Control Module	DATA
KK62-14C037-FCD.vbf	Range Rover Sport (L494)	ABS - Anti-Lock Brake System Control Module	DATA
KK62-14C037-FCE.vbf	Range Rover Sport (L494)	ABS - Anti-Lock Brake System Control Module	DATA
KK62-14C037-FCF.vbf	Range Rover Sport (L494)	ABS - Anti-Lock Brake System Control Module	DATA
KK62-14C037-FCG.vbf	Range Rover Sport (L494)	ABS - Anti-Lock Brake System Control Module	DATA
KK62-14C037-FCH.vbf	Range Rover Sport (L494)	ABS - Anti-Lock Brake System Control Module	DATA
KK62-14C037-FCJ.vbf	Range Rover Sport (L494)	ABS - Anti-Lock Brake System Control Module	DATA
KK62-14C037-FCK.vbf	Range Rover Sport (L494)	ABS - Anti-Lock Brake System Control Module	DATA
KK62-14C037-FDD.vbf	Range Rover Sport (L494)	ABS - Anti-Lock Brake System Control Module	DATA
KK62-14C037-FDE.vbf	Range Rover Sport (L494)	ABS - Anti-Lock Brake System Control Module	DATA
KK62-14C037-FDF.vbf	Range Rover Sport (L494)	ABS - Anti-Lock Brake System Control Module	DATA
KK62-14C037-FDG.vbf	Range Rover Sport (L494)	ABS - Anti-Lock Brake System Control Module	DATA
KK62-14C037-FDH.vbf	Range Rover Sport (L494)	ABS - Anti-Lock Brake System Control Module	DATA
KK62-14C037-FDJ.vbf	Range Rover Sport (L494)	ABS - Anti-Lock Brake System Control Module	DATA
KK62-14C037-FDK.vbf	Range Rover Sport (L494)	ABS - Anti-Lock Brake System Control Module	DATA
KK62-14C037-FED.vbf	Range Rover Sport (L494)	ABS - Anti-Lock Brake System Control Module	DATA
KK62-14C037-FEE.vbf	Range Rover Sport (L494)	ABS - Anti-Lock Brake System Control Module	DATA
KK62-14C037-FEF.vbf	Range Rover Sport (L494)	ABS - Anti-Lock Brake System Control Module	DATA
KK62-14C037-FEG.vbf	Range Rover Sport (L494)	ABS - Anti-Lock Brake System Control Module	DATA
KK62-14C037-FEH.vbf	Range Rover Sport (L494)	ABS - Anti-Lock Brake System Control Module	DATA
KK62-14C037-FEJ.vbf	Range Rover Sport (L494)	ABS - Anti-Lock Brake System Control Module	DATA
KK62-14C037-FEK.vbf	Range Rover Sport (L494)	ABS - Anti-Lock Brake System Control Module	DATA
KK62-14C037-FFD.vbf	Range Rover Sport (L494)	ABS - Anti-Lock Brake System Control Module	DATA
KK62-14C037-FFE.vbf	Range Rover Sport (L494)	ABS - Anti-Lock Brake System Control Module	DATA
KK62-14C037-FFF.vbf	Range Rover Sport (L494)	ABS - Anti-Lock Brake System Control Module	DATA
KK62-14C037-FFG.vbf	Range Rover Sport (L494)	ABS - Anti-Lock Brake System Control Module	DATA
KK62-14C037-FFH.vbf	Range Rover Sport (L494)	ABS - Anti-Lock Brake System Control Module	DATA
KK62-14C037-FFJ.vbf	Range Rover Sport (L494)	ABS - Anti-Lock Brake System Control Module	DATA
KK62-14C037-FFK.vbf	Range Rover Sport (L494)	ABS - Anti-Lock Brake System Control Module	DATA
KK62-14C037-FGD.vbf	Range Rover Sport (L494)	ABS - Anti-Lock Brake System Control Module	DATA
KK62-14C037-FGE.vbf	Range Rover Sport (L494)	ABS - Anti-Lock Brake System Control Module	DATA
KK62-14C037-FGF.vbf	Range Rover Sport (L494)	ABS - Anti-Lock Brake System Control Module	DATA
KK62-14C037-FGG.vbf	Range Rover Sport (L494)	ABS - Anti-Lock Brake System Control Module	DATA
KK62-14C037-FGH.vbf	Range Rover Sport (L494)	ABS - Anti-Lock Brake System Control Module	DATA
KK62-14C037-FGJ.vbf	Range Rover Sport (L494)	ABS - Anti-Lock Brake System Control Module	DATA
KK62-14C037-FGK.vbf	Range Rover Sport (L494)	ABS - Anti-Lock Brake System Control Module	DATA
KK62-14C037-FHD.vbf	Range Rover Sport (L494)	ABS - Anti-Lock Brake System Control Module	DATA
KK62-14C037-FJD.vbf	Range Rover Sport (L494)	ABS - Anti-Lock Brake System Control Module	DATA
KK62-14C037-FJE.vbf	Range Rover Sport (L494)	ABS - Anti-Lock Brake System Control Module	DATA
KK62-14C037-FJF.vbf	Range Rover Sport (L494)	ABS - Anti-Lock Brake System Control Module	DATA
KK62-14C037-FJG.vbf	Range Rover Sport (L494)	ABS - Anti-Lock Brake System Control Module	DATA
KK62-14C037-FJJ.vbf	Range Rover Sport (L494)	ABS - Anti-Lock Brake System Control Module	DATA
KK62-14C037-FKD.vbf	Range Rover Sport (L494)	ABS - Anti-Lock Brake System Control Module	DATA
KK62-14C037-FKE.vbf	Range Rover Sport (L494)	ABS - Anti-Lock Brake System Control Module	DATA
KK62-14C037-FKF.vbf	Range Rover Sport (L494)	ABS - Anti-Lock Brake System Control Module	DATA
KK62-14C037-FKG.vbf	Range Rover Sport (L494)	ABS - Anti-Lock Brake System Control Module	DATA
KK62-14C037-FKH.vbf	Range Rover Sport (L494)	ABS - Anti-Lock Brake System Control Module	DATA

File name	Vehicle line (indicative)	Module (ECU)	Type
KK62-14C037-FKJ.vbf	Range Rover Sport (L494)	ABS - Anti-Lock Brake System Control Module	DATA
KK62-14C037-FKK.vbf	Range Rover Sport (L494)	ABS - Anti-Lock Brake System Control Module	DATA
KK62-14C037-FLD.vbf	Range Rover Sport (L494)	ABS - Anti-Lock Brake System Control Module	DATA
KK62-14C037-FLE.vbf	Range Rover Sport (L494)	ABS - Anti-Lock Brake System Control Module	DATA
KK62-14C037-FLF.vbf	Range Rover Sport (L494)	ABS - Anti-Lock Brake System Control Module	DATA
KK62-14C037-FLG.vbf	Range Rover Sport (L494)	ABS - Anti-Lock Brake System Control Module	DATA
KK62-14C037-FLH.vbf	Range Rover Sport (L494)	ABS - Anti-Lock Brake System Control Module	DATA
KK62-14C037-FLJ.vbf	Range Rover Sport (L494)	ABS - Anti-Lock Brake System Control Module	DATA
KK62-14C037-FLK.vbf	Range Rover Sport (L494)	ABS - Anti-Lock Brake System Control Module	DATA
KK62-14C037-FMB.vbf	Range Rover Sport (L494)	ABS - Anti-Lock Brake System Control Module	DATA
KK62-14C037-FMC.vbf	Range Rover Sport (L494)	ABS - Anti-Lock Brake System Control Module	DATA
KK62-14C037-FMD.vbf	Range Rover Sport (L494)	ABS - Anti-Lock Brake System Control Module	DATA
KK62-14C037-FME.vbf	Range Rover Sport (L494)	ABS - Anti-Lock Brake System Control Module	DATA
KK62-14C037-FMF.vbf	Range Rover Sport (L494)	ABS - Anti-Lock Brake System Control Module	DATA
KK62-14C037-FMH.vbf	Range Rover Sport (L494)	ABS - Anti-Lock Brake System Control Module	DATA
KK62-14C037-FNC.vbf	Range Rover Sport (L494)	ABS - Anti-Lock Brake System Control Module	DATA
KK62-14C037-FND.vbf	Range Rover Sport (L494)	ABS - Anti-Lock Brake System Control Module	DATA
KK62-14C037-FNE.vbf	Range Rover Sport (L494)	ABS - Anti-Lock Brake System Control Module	DATA
KK62-14C037-FNG.vbf	Range Rover Sport (L494)	ABS - Anti-Lock Brake System Control Module	DATA
KK62-14C037-HAA.vbf	Range Rover Sport (L494)	ABS - Anti-Lock Brake System Control Module	DATA
KK62-14C037-HAB.vbf	Range Rover Sport (L494)	ABS - Anti-Lock Brake System Control Module	DATA
KK62-14C037-HAC.vbf	Range Rover Sport (L494)	ABS - Anti-Lock Brake System Control Module	DATA
KK62-14C037-HAD.vbf	Range Rover Sport (L494)	ABS - Anti-Lock Brake System Control Module	DATA
KK62-14C185-AA.vbf	Range Rover Sport (L494)	BCM - Body Control Module	DATA
KK62-14C218-DA.vbf	Range Rover Sport (L494)	PSCM - Power Steering Control Module	EXE
KK62-14C218-DB.vbf	Range Rover Sport (L494)	PSCM - Power Steering Control Module	EXE
KK62-14C218-EA.vbf	Range Rover Sport (L494)	PSCM - Power Steering Control Module	EXE
KK62-14C218-EB.vbf	Range Rover Sport (L494)	PSCM - Power Steering Control Module	EXE
KK62-14C273-NAA.vbf	Range Rover Sport (L494)	PCM - Powertrain Control Module	SBL
KK62-14C527-AKA.vbf	Range Rover Sport (L494)	AAM - Audio Amplifier Module	DATA
KK62-14C527-AKB.vbf	Range Rover Sport (L494)	AAM - Audio Amplifier Module	DATA
KK62-14C527-AKC.vbf	Range Rover Sport (L494)	AAM - Audio Amplifier Module	DATA
KK62-14C527-BKA.vbf	Range Rover Sport (L494)	AAM - Audio Amplifier Module	DATA
KK62-14C527-BKB.vbf	Range Rover Sport (L494)	AAM - Audio Amplifier Module	DATA
KK62-14C527-BKC.vbf	Range Rover Sport (L494)	AAM - Audio Amplifier Module	DATA
KK62-14C527-CKA.vbf	Range Rover Sport (L494)	AAM - Audio Amplifier Module	DATA
KK62-14C527-CKB.vbf	Range Rover Sport (L494)	AAM - Audio Amplifier Module	DATA
KK62-14C527-CKC.vbf	Range Rover Sport (L494)	AAM - Audio Amplifier Module	DATA
KK62-14C527-CLA.vbf	Range Rover Sport (L494)	AAM - Audio Amplifier Module	DATA
KK62-14C527-CLB.vbf	Range Rover Sport (L494)	AAM - Audio Amplifier Module	DATA
KK62-14C527-DKA.vbf	Range Rover Sport (L494)	AAM - Audio Amplifier Module	DATA
KK62-14C527-DKB.vbf	Range Rover Sport (L494)	AAM - Audio Amplifier Module	DATA
KK62-14C527-DKC.vbf	Range Rover Sport (L494)	AAM - Audio Amplifier Module	DATA
KK62-14C527-DLA.vbf	Range Rover Sport (L494)	AAM - Audio Amplifier Module	DATA
KK62-14C527-DLB.vbf	Range Rover Sport (L494)	AAM - Audio Amplifier Module	DATA
KK62-14C527-EA.vbf	Range Rover Sport (L494)	AAM - Audio Amplifier Module	DATA
KK62-14C527-EB.vbf	Range Rover Sport (L494)	AAM - Audio Amplifier Module	DATA
KK62-14C527-FA.vbf	Range Rover Sport (L494)	AAM - Audio Amplifier Module	DATA
KK62-14C527-FB.vbf	Range Rover Sport (L494)	AAM - Audio Amplifier Module	DATA
KK62-14C527-GA.vbf	Range Rover Sport (L494)	AAM - Audio Amplifier Module	DATA
KK62-14C527-HA.vbf	Range Rover Sport (L494)	AAM - Audio Amplifier Module	DATA
KK62-14C527-HB.vbf	Range Rover Sport (L494)	AAM - Audio Amplifier Module	DATA
KK62-14C561-AA.vbf	Range Rover Sport (L494)	GSM - Gear Shift Module	EXE
KK62-14C570-BNB.vbf	Range Rover Sport (L494)	PCM - Powertrain Control Module	EXE
KK62-14C570-BNC.vbf	Range Rover Sport (L494)	PCM - Powertrain Control Module	EXE
KK62-14C570-BND.vbf	Range Rover Sport (L494)	PCM - Powertrain Control Module	EXE
KK62-14C570-BPB.vbf	Range Rover Sport (L494)	PCM - Powertrain Control Module	EXE
KK62-14C570-BPC.vbf	Range Rover Sport (L494)	PCM - Powertrain Control Module	EXE
KK62-14C570-BPD.vbf	Range Rover Sport (L494)	PCM - Powertrain Control Module	EXE
KK62-14C570-BPE.vbf	Range Rover Sport (L494)	PCM - Powertrain Control Module	EXE
KK62-14C570-BRA.vbf	Range Rover Sport (L494)	PCM - Powertrain Control Module	EXE
KK62-14C570-BRB.vbf	Range Rover Sport (L494)	PCM - Powertrain Control Module	EXE
KK62-14C570-BRC.vbf	Range Rover Sport (L494)	PCM - Powertrain Control Module	EXE
KK62-14C570-BRD.vbf	Range Rover Sport (L494)	PCM - Powertrain Control Module	EXE
KK62-14C570-BRE.vbf	Range Rover Sport (L494)	PCM - Powertrain Control Module	EXE
KK62-14C570-BUB.vbf	Range Rover Sport (L494)	PCM - Powertrain Control Module	EXE
KK62-14C570-BUC.vbf	Range Rover Sport (L494)	PCM - Powertrain Control Module	EXE
KK62-14C570-BUD.vbf	Range Rover Sport (L494)	PCM - Powertrain Control Module	EXE
KK62-14C570-JAC.vbf	Range Rover Sport (L494)	PCM - Powertrain Control Module	EXE
KK62-14C570-JAD.vbf	Range Rover Sport (L494)	PCM - Powertrain Control Module	EXE
KK62-14C570-JFC.vbf	Range Rover Sport (L494)	PCM - Powertrain Control Module	EXE
KK62-14C570-JFD.vbf	Range Rover Sport (L494)	PCM - Powertrain Control Module	EXE
KK62-14C570-JGB.vbf	Range Rover Sport (L494)	PCM - Powertrain Control Module	EXE
KK62-14C570-JGD.vbf	Range Rover Sport (L494)	PCM - Powertrain Control Module	EXE
KK62-14C570-JGE.vbf	Range Rover Sport (L494)	PCM - Powertrain Control Module	EXE
KK62-14C570-JGG.vbf	Range Rover Sport (L494)	PCM - Powertrain Control Module	EXE

File name	Vehicle line (indicative)	Module (ECU)	Type
KK62-14C570-JGH.vbf	Range Rover Sport (L494)	PCM - Powertrain Control Module	EXE
KK62-14C570-JGK.vbf	Range Rover Sport (L494)	PCM - Powertrain Control Module	EXE
KK62-14C570-JGL.vbf	Range Rover Sport (L494)	PCM - Powertrain Control Module	EXE
KK62-14C570-JGM.vbf	Range Rover Sport (L494)	PCM - Powertrain Control Module	EXE
KK62-14C570-JGN.vbf	Range Rover Sport (L494)	PCM - Powertrain Control Module	EXE
KK62-14C570-JGP.vbf	Range Rover Sport (L494)	PCM - Powertrain Control Module	EXE
KK62-14C570-JGR.vbf	Range Rover Sport (L494)	PCM - Powertrain Control Module	EXE
KK62-14C570-JGU.vbf	Range Rover Sport (L494)	PCM - Powertrain Control Module	EXE
KK62-14C570-JGX.vbf	Range Rover Sport (L494)	PCM - Powertrain Control Module	EXE
KK62-14C570-JGZ.vbf	Range Rover Sport (L494)	PCM - Powertrain Control Module	EXE
KK62-14C570-JHC.vbf	Range Rover Sport (L494)	PCM - Powertrain Control Module	EXE
KK62-14C570-JHD.vbf	Range Rover Sport (L494)	PCM - Powertrain Control Module	EXE
KK62-14C570-JPB.vbf	Range Rover Sport (L494)	PCM - Powertrain Control Module	EXE
KK62-14C570-JPD.vbf	Range Rover Sport (L494)	PCM - Powertrain Control Module	EXE
KK62-14C570-JPF.vbf	Range Rover Sport (L494)	PCM - Powertrain Control Module	EXE
KK62-14C570-JPH.vbf	Range Rover Sport (L494)	PCM - Powertrain Control Module	EXE
KK62-14C570-JPJ.vbf	Range Rover Sport (L494)	PCM - Powertrain Control Module	EXE
KK62-14C570-JPL.vbf	Range Rover Sport (L494)	PCM - Powertrain Control Module	EXE
KK62-14C570-JPN.vbf	Range Rover Sport (L494)	PCM - Powertrain Control Module	EXE
KK62-14C570-JPP.vbf	Range Rover Sport (L494)	PCM - Powertrain Control Module	EXE
KK62-14C570-JPR.vbf	Range Rover Sport (L494)	PCM - Powertrain Control Module	EXE
KK62-14C570-JPU.vbf	Range Rover Sport (L494)	PCM - Powertrain Control Module	EXE
KK62-14C570-JPV.vbf	Range Rover Sport (L494)	PCM - Powertrain Control Module	EXE
KK62-14C570-JPY.vbf	Range Rover Sport (L494)	PCM - Powertrain Control Module	EXE
KK62-14C570-JRB.vbf	Range Rover Sport (L494)	PCM - Powertrain Control Module	EXE
KK62-14C570-JRD.vbf	Range Rover Sport (L494)	PCM - Powertrain Control Module	EXE
KK62-14C570-JRF.vbf	Range Rover Sport (L494)	PCM - Powertrain Control Module	EXE
KK62-14C570-JRH.vbf	Range Rover Sport (L494)	PCM - Powertrain Control Module	EXE
KK62-14C570-JRJ.vbf	Range Rover Sport (L494)	PCM - Powertrain Control Module	EXE
KK62-14C570-JRL.vbf	Range Rover Sport (L494)	PCM - Powertrain Control Module	EXE
KK62-14C570-JRM.vbf	Range Rover Sport (L494)	PCM - Powertrain Control Module	EXE
KK62-14C570-JRN.vbf	Range Rover Sport (L494)	PCM - Powertrain Control Module	EXE
KK62-14C570-JRP.vbf	Range Rover Sport (L494)	PCM - Powertrain Control Module	EXE
KK62-14C570-JRR.vbf	Range Rover Sport (L494)	PCM - Powertrain Control Module	EXE
KK62-14C570-JRU.vbf	Range Rover Sport (L494)	PCM - Powertrain Control Module	EXE
KK62-14C570-JRV.vbf	Range Rover Sport (L494)	PCM - Powertrain Control Module	EXE
KK62-14C570-JRY.vbf	Range Rover Sport (L494)	PCM - Powertrain Control Module	EXE
KK62-14C570-JRZ.vbf	Range Rover Sport (L494)	PCM - Powertrain Control Module	EXE
KK62-14C570-SAB.vbf	Range Rover Sport (L494)	PCM - Powertrain Control Module	EXE
KK62-14C570-SAC.vbf	Range Rover Sport (L494)	PCM - Powertrain Control Module	EXE
KK62-14C570-SAD.vbf	Range Rover Sport (L494)	PCM - Powertrain Control Module	EXE
KK62-14C570-SAE.vbf	Range Rover Sport (L494)	PCM - Powertrain Control Module	EXE
KK62-14C570-SAF.vbf	Range Rover Sport (L494)	PCM - Powertrain Control Module	EXE
KK62-14C570-SCC.vbf	Range Rover Sport (L494)	PCM - Powertrain Control Module	EXE
KK62-14C570-SCD.vbf	Range Rover Sport (L494)	PCM - Powertrain Control Module	EXE
KK62-14C570-SEC.vbf	Range Rover Sport (L494)	PCM - Powertrain Control Module	EXE
KK62-14C570-SED.vbf	Range Rover Sport (L494)	PCM - Powertrain Control Module	EXE
KK62-14C570-SHB.vbf	Range Rover Sport (L494)	PCM - Powertrain Control Module	EXE
KK62-14C570-SHC.vbf	Range Rover Sport (L494)	PCM - Powertrain Control Module	EXE
KK62-14C570-SHD.vbf	Range Rover Sport (L494)	PCM - Powertrain Control Module	EXE
KK62-14C570-SHE.vbf	Range Rover Sport (L494)	PCM - Powertrain Control Module	EXE
KK62-14C570-STC.vbf	Range Rover Sport (L494)	PCM - Powertrain Control Module	EXE
KK62-14C570-STD.vbf	Range Rover Sport (L494)	PCM - Powertrain Control Module	EXE
KK62-14C572-BC.vbf	Range Rover Sport (L494)	PCM - Powertrain Control Module	SBL
KK62-14C572-BD.vbf	Range Rover Sport (L494)	PCM - Powertrain Control Module	SBL
KK62-14C609-AA.vbf	Range Rover Sport (L494)	PSCM - Power Steering Control Module	EXE
KK62-14D564-AA.vbf	Range Rover Sport (L494)	SODR - Side Obstacle Detection Control Module - Right	DATA
KK62-14D564-AB.vbf	Range Rover Sport (L494)	SODR - Side Obstacle Detection Control Module - Right	DATA
KK62-14D564-AC.vbf	Range Rover Sport (L494)	SODR - Side Obstacle Detection Control Module - Right	DATA
KK62-14D564-AD.vbf	Range Rover Sport (L494)	SODR - Side Obstacle Detection Control Module - Right	DATA
KK62-14D564-AE.vbf	Range Rover Sport (L494)	SODR - Side Obstacle Detection Control Module - Right	DATA
KK62-14D564-AF.vbf	Range Rover Sport (L494)	SODR - Side Obstacle Detection Control Module - Right	DATA
KK62-14D564-AG.vbf	Range Rover Sport (L494)	SODR - Side Obstacle Detection Control Module - Right	DATA
KK62-14D564-BA.vbf	Range Rover Sport (L494)	SODR - Side Obstacle Detection Control Module - Right	DATA
KK62-14E094-HAA.vbf	Range Rover Sport (L494)	CHCM - Chassis Control Module	EXE
KK62-14E094-HAB.vbf	Range Rover Sport (L494)	CHCM - Chassis Control Module	EXE
KK62-14E094-HAC.vbf	Range Rover Sport (L494)	CHCM - Chassis Control Module	EXE
KK62-14E094-HAD.vbf	Range Rover Sport (L494)	CHCM - Chassis Control Module	EXE
KK62-14E094-HAE.vbf	Range Rover Sport (L494)	CHCM - Chassis Control Module	EXE
KK62-14E094-HAF.vbf	Range Rover Sport (L494)	CHCM - Chassis Control Module	EXE
KK62-14E094-HAG.vbf	Range Rover Sport (L494)	CHCM - Chassis Control Module	EXE
KK62-14E094-HBA.vbf	Range Rover Sport (L494)	CHCM - Chassis Control Module	EXE
KK62-14E094-HBB.vbf	Range Rover Sport (L494)	CHCM - Chassis Control Module	EXE
KK62-14E094-HBC.vbf	Range Rover Sport (L494)	CHCM - Chassis Control Module	EXE
KK62-14E094-HBD.vbf	Range Rover Sport (L494)	CHCM - Chassis Control Module	EXE
KK62-14E094-HBE.vbf	Range Rover Sport (L494)	CHCM - Chassis Control Module	EXE

File name	Vehicle line (indicative)	Module (ECU)	Type
KK62-14E094-HBF.vbf	Range Rover Sport (L494)	CHCM - Chassis Control Module	EXE
KK62-14E094-HBG.vbf	Range Rover Sport (L494)	CHCM - Chassis Control Module	EXE
KK62-14E094-HCA.vbf	Range Rover Sport (L494)	CHCM - Chassis Control Module	EXE
KK62-14E094-HCB.vbf	Range Rover Sport (L494)	CHCM - Chassis Control Module	EXE
KK62-14E094-HCC.vbf	Range Rover Sport (L494)	CHCM - Chassis Control Module	EXE
KK62-14E094-HCD.vbf	Range Rover Sport (L494)	CHCM - Chassis Control Module	EXE
KK62-14E094-HCE.vbf	Range Rover Sport (L494)	CHCM - Chassis Control Module	EXE
KK62-14E094-HCF.vbf	Range Rover Sport (L494)	CHCM - Chassis Control Module	EXE
KK62-14E094-HCG.vbf	Range Rover Sport (L494)	CHCM - Chassis Control Module	EXE
KK62-14E094-JBA.vbf	Range Rover Sport (L494)	CHCM - Chassis Control Module	EXE
KK62-14E094-JBB.vbf	Range Rover Sport (L494)	CHCM - Chassis Control Module	EXE
KK62-14E094-JBC.vbf	Range Rover Sport (L494)	CHCM - Chassis Control Module	EXE
KK62-14E094-JBD.vbf	Range Rover Sport (L494)	CHCM - Chassis Control Module	EXE
KK62-14E094-JBE.vbf	Range Rover Sport (L494)	CHCM - Chassis Control Module	EXE
KK62-14E094-JBF.vbf	Range Rover Sport (L494)	CHCM - Chassis Control Module	EXE
KK62-14E094-JBG.vbf	Range Rover Sport (L494)	CHCM - Chassis Control Module	EXE
KK62-14E094-JCA.vbf	Range Rover Sport (L494)	CHCM - Chassis Control Module	EXE
KK62-14E094-JCB.vbf	Range Rover Sport (L494)	CHCM - Chassis Control Module	EXE
KK62-14E094-JCC.vbf	Range Rover Sport (L494)	CHCM - Chassis Control Module	EXE
KK62-14E094-JCD.vbf	Range Rover Sport (L494)	CHCM - Chassis Control Module	EXE
KK62-14E094-JCE.vbf	Range Rover Sport (L494)	CHCM - Chassis Control Module	EXE
KK62-14E094-JCF.vbf	Range Rover Sport (L494)	CHCM - Chassis Control Module	EXE
KK62-14E094-JCG.vbf	Range Rover Sport (L494)	CHCM - Chassis Control Module	EXE
KK62-14E094-JDA.vbf	Range Rover Sport (L494)	CHCM - Chassis Control Module	EXE
KK62-14E094-JDB.vbf	Range Rover Sport (L494)	CHCM - Chassis Control Module	EXE
KK62-14E094-JDC.vbf	Range Rover Sport (L494)	CHCM - Chassis Control Module	EXE
KK62-14E094-JDD.vbf	Range Rover Sport (L494)	CHCM - Chassis Control Module	EXE
KK62-14E094-JDE.vbf	Range Rover Sport (L494)	CHCM - Chassis Control Module	EXE
KK62-14E094-JDF.vbf	Range Rover Sport (L494)	CHCM - Chassis Control Module	EXE
KK62-14E094-JDG.vbf	Range Rover Sport (L494)	CHCM - Chassis Control Module	EXE
KK62-14E094-JEA.vbf	Range Rover Sport (L494)	CHCM - Chassis Control Module	EXE
KK62-14E094-JEB.vbf	Range Rover Sport (L494)	CHCM - Chassis Control Module	EXE
KK62-14E094-JEC.vbf	Range Rover Sport (L494)	CHCM - Chassis Control Module	EXE
KK62-14E094-JED.vbf	Range Rover Sport (L494)	CHCM - Chassis Control Module	EXE
KK62-14E094-JEE.vbf	Range Rover Sport (L494)	CHCM - Chassis Control Module	EXE
KK62-14E094-JEF.vbf	Range Rover Sport (L494)	CHCM - Chassis Control Module	EXE
KK62-14E094-JEG.vbf	Range Rover Sport (L494)	CHCM - Chassis Control Module	EXE
KK62-14E094-JFA.vbf	Range Rover Sport (L494)	CHCM - Chassis Control Module	EXE
KK62-14E094-JFB.vbf	Range Rover Sport (L494)	CHCM - Chassis Control Module	EXE
KK62-14E094-JFC.vbf	Range Rover Sport (L494)	CHCM - Chassis Control Module	EXE
KK62-14E094-JFD.vbf	Range Rover Sport (L494)	CHCM - Chassis Control Module	EXE
KK62-14E094-JFE.vbf	Range Rover Sport (L494)	CHCM - Chassis Control Module	EXE
KK62-14E094-JFF.vbf	Range Rover Sport (L494)	CHCM - Chassis Control Module	EXE
KK62-14E094-JFG.vbf	Range Rover Sport (L494)	CHCM - Chassis Control Module	EXE
KK62-14E094-JKA.vbf	Range Rover Sport (L494)	CHCM - Chassis Control Module	EXE
KK62-14E094-JKB.vbf	Range Rover Sport (L494)	CHCM - Chassis Control Module	EXE
KK62-14E094-JLA.vbf	Range Rover Sport (L494)	CHCM - Chassis Control Module	EXE
KK62-14E094-JLB.vbf	Range Rover Sport (L494)	CHCM - Chassis Control Module	EXE
KK62-14E094-JLC.vbf	Range Rover Sport (L494)	CHCM - Chassis Control Module	EXE
KK62-14E094-JLD.vbf	Range Rover Sport (L494)	CHCM - Chassis Control Module	EXE
KK62-14E094-JLE.vbf	Range Rover Sport (L494)	CHCM - Chassis Control Module	EXE
KK62-14E094-JLF.vbf	Range Rover Sport (L494)	CHCM - Chassis Control Module	EXE
KK62-14E094-JLG.vbf	Range Rover Sport (L494)	CHCM - Chassis Control Module	EXE
KK62-14E094-JLH.vbf	Range Rover Sport (L494)	CHCM - Chassis Control Module	EXE
KK62-14E094-JMA.vbf	Range Rover Sport (L494)	CHCM - Chassis Control Module	EXE
KK62-14E094-JMB.vbf	Range Rover Sport (L494)	CHCM - Chassis Control Module	EXE
KK62-14E094-JMC.vbf	Range Rover Sport (L494)	CHCM - Chassis Control Module	EXE
KK62-14E094-JMD.vbf	Range Rover Sport (L494)	CHCM - Chassis Control Module	EXE
KK62-14E094-JME.vbf	Range Rover Sport (L494)	CHCM - Chassis Control Module	EXE
KK62-14E094-JMF.vbf	Range Rover Sport (L494)	CHCM - Chassis Control Module	EXE
KK62-14E094-JMG.vbf	Range Rover Sport (L494)	CHCM - Chassis Control Module	EXE
KK62-14E094-JNA.vbf	Range Rover Sport (L494)	CHCM - Chassis Control Module	EXE
KK62-14E094-JNB.vbf	Range Rover Sport (L494)	CHCM - Chassis Control Module	EXE
KK62-14E094-JNC.vbf	Range Rover Sport (L494)	CHCM - Chassis Control Module	EXE
KK62-14E094-JND.vbf	Range Rover Sport (L494)	CHCM - Chassis Control Module	EXE
KK62-14E094-JNE.vbf	Range Rover Sport (L494)	CHCM - Chassis Control Module	EXE
KK62-14E094-JNF.vbf	Range Rover Sport (L494)	CHCM - Chassis Control Module	EXE
KK62-14E094-JNG.vbf	Range Rover Sport (L494)	CHCM - Chassis Control Module	EXE
KK62-14E094-JNH.vbf	Range Rover Sport (L494)	CHCM - Chassis Control Module	EXE
KK62-14F230-AA.vbf	Range Rover Sport (L494)	HUD - Head Up Display	EXE
KK62-14F230-AB.vbf	Range Rover Sport (L494)	HUD - Head Up Display	EXE
KK62-14F230-AC.vbf	Range Rover Sport (L494)	HUD - Head Up Display	EXE
KK62-14F230-AD.vbf	Range Rover Sport (L494)	HUD - Head Up Display	EXE
KK62-14F231-AA.vbf	Range Rover Sport (L494)	HUD - Head Up Display	DATA
KK62-14F231-AB.vbf	Range Rover Sport (L494)	HUD - Head Up Display	DATA
KK62-14F231-AC.vbf	Range Rover Sport (L494)	HUD - Head Up Display	DATA

File name	Vehicle line (indicative)	Module (ECU)	Type
KK62-14F435-NAA.vbf	Range Rover Sport (L494)	CHCMB - Chassis Control Module B	EXE
KK62-14F435-NAB.vbf	Range Rover Sport (L494)	CHCMB - Chassis Control Module B	EXE
KK62-14F435-NAC.vbf	Range Rover Sport (L494)	CHCMB - Chassis Control Module B	EXE
KK62-14F435-NAD.vbf	Range Rover Sport (L494)	CHCMB - Chassis Control Module B	EXE
KK62-14F435-NAE.vbf	Range Rover Sport (L494)	CHCMB - Chassis Control Module B	EXE
KK62-14F435-NBA.vbf	Range Rover Sport (L494)	CHCMB - Chassis Control Module B	EXE
KK62-14F435-NBB.vbf	Range Rover Sport (L494)	CHCMB - Chassis Control Module B	EXE
KK62-14F435-NBC.vbf	Range Rover Sport (L494)	CHCMB - Chassis Control Module B	EXE
KK62-14F435-NBD.vbf	Range Rover Sport (L494)	CHCMB - Chassis Control Module B	EXE
KK62-14F435-NBE.vbf	Range Rover Sport (L494)	CHCMB - Chassis Control Module B	EXE
KK62-14F435-NCA.vbf	Range Rover Sport (L494)	CHCMB - Chassis Control Module B	EXE
KK62-14F435-NCB.vbf	Range Rover Sport (L494)	CHCMB - Chassis Control Module B	EXE
KK62-14F435-NCC.vbf	Range Rover Sport (L494)	CHCMB - Chassis Control Module B	EXE
KK62-14F435-NCD.vbf	Range Rover Sport (L494)	CHCMB - Chassis Control Module B	EXE
KK62-14F435-NCE.vbf	Range Rover Sport (L494)	CHCMB - Chassis Control Module B	EXE
KK62-14F530-AA.vbf	Range Rover Sport (L494)	GWM - Gateway Module A	EXE
KK62-14F530-AC.vbf	Range Rover Sport (L494)	GWM - Gateway Module A	EXE
KK62-14F530-AD.vbf	Range Rover Sport (L494)	GWM - Gateway Module A	EXE
KK62-14F530-BA.vbf	Range Rover Sport (L494)	GWM - Gateway Module A	EXE
KK62-14F530-BC.vbf	Range Rover Sport (L494)	GWM - Gateway Module A	EXE
KK62-14F530-BD.vbf	Range Rover Sport (L494)	GWM - Gateway Module A	EXE
KK62-14F530-BE.vbf	Range Rover Sport (L494)	GWM - Gateway Module A	EXE
KK62-14F530-BF.vbf	Range Rover Sport (L494)	GWM - Gateway Module A	EXE
KK62-14F530-CA.vbf	Range Rover Sport (L494)	GWM - Gateway Module A	EXE
KK62-14F530-CC.vbf	Range Rover Sport (L494)	GWM - Gateway Module A	EXE
KK62-14F530-CD.vbf	Range Rover Sport (L494)	GWM - Gateway Module A	EXE
KK62-14F530-CF.vbf	Range Rover Sport (L494)	GWM - Gateway Module A	EXE
KK62-14F530-DA.vbf	Range Rover Sport (L494)	GWM - Gateway Module A	EXE
KK62-14F530-DC.vbf	Range Rover Sport (L494)	GWM - Gateway Module A	EXE
KK62-14F530-DD.vbf	Range Rover Sport (L494)	GWM - Gateway Module A	EXE
KK62-14F530-EB.vbf	Range Rover Sport (L494)	GWM - Gateway Module A	EXE
KK62-14F530-EC.vbf	Range Rover Sport (L494)	GWM - Gateway Module A	EXE
KK62-14F530-ED.vbf	Range Rover Sport (L494)	GWM - Gateway Module A	EXE
KK62-14F530-FB.vbf	Range Rover Sport (L494)	GWM - Gateway Module A	EXE
KK62-14F530-FC.vbf	Range Rover Sport (L494)	GWM - Gateway Module A	EXE
KK62-14F530-FD.vbf	Range Rover Sport (L494)	GWM - Gateway Module A	EXE
KK62-14F531-AA.vbf	Range Rover Sport (L494)	GWM - Gateway Module A	DATA
KK62-14F531-AC.vbf	Range Rover Sport (L494)	GWM - Gateway Module A	DATA
KK62-14F531-BA.vbf	Range Rover Sport (L494)	GWM - Gateway Module A	DATA
KK62-14F531-BC.vbf	Range Rover Sport (L494)	GWM - Gateway Module A	DATA
KK62-14F531-BD.vbf	Range Rover Sport (L494)	GWM - Gateway Module A	DATA
KK62-14F531-BE.vbf	Range Rover Sport (L494)	GWM - Gateway Module A	DATA
KK62-14F531-CA.vbf	Range Rover Sport (L494)	GWM - Gateway Module A	DATA
KK62-14F531-CC.vbf	Range Rover Sport (L494)	GWM - Gateway Module A	DATA
KK62-14F531-CE.vbf	Range Rover Sport (L494)	GWM - Gateway Module A	DATA
KK62-14F531-DA.vbf	Range Rover Sport (L494)	GWM - Gateway Module A	DATA
KK62-14F531-DC.vbf	Range Rover Sport (L494)	GWM - Gateway Module A	DATA
KK62-14F531-EB.vbf	Range Rover Sport (L494)	GWM - Gateway Module A	DATA
KK62-14F531-EC.vbf	Range Rover Sport (L494)	GWM - Gateway Module A	DATA
KK62-14F531-ED.vbf	Range Rover Sport (L494)	GWM - Gateway Module A	DATA
KK62-14F531-FB.vbf	Range Rover Sport (L494)	GWM - Gateway Module A	DATA
KK62-14F531-FC.vbf	Range Rover Sport (L494)	GWM - Gateway Module A	DATA
KK62-14F531-FD.vbf	Range Rover Sport (L494)	GWM - Gateway Module A	DATA
KK62-7J104-FEA.vbf	Range Rover Sport (L494)	TCM - Transmission Control Module	EXE
KK62-7J104-FEB.vbf	Range Rover Sport (L494)	TCM - Transmission Control Module	EXE
KK62-7J104-FEC.vbf	Range Rover Sport (L494)	TCM - Transmission Control Module	EXE
KK62-7J104-FED.vbf	Range Rover Sport (L494)	TCM - Transmission Control Module	EXE
KK62-7J104-FFA.vbf	Range Rover Sport (L494)	TCM - Transmission Control Module	EXE
KK62-7J104-FFB.vbf	Range Rover Sport (L494)	TCM - Transmission Control Module	EXE
KK62-7J104-FFC.vbf	Range Rover Sport (L494)	TCM - Transmission Control Module	EXE
KK62-7J104-FGA.vbf	Range Rover Sport (L494)	TCM - Transmission Control Module	EXE
KK62-7J104-FGB.vbf	Range Rover Sport (L494)	TCM - Transmission Control Module	EXE
KK62-7J104-FGC.vbf	Range Rover Sport (L494)	TCM - Transmission Control Module	EXE
KK62-7J104-FMA.vbf	Range Rover Sport (L494)	TCM - Transmission Control Module	EXE
KK62-7J104-FMB.vbf	Range Rover Sport (L494)	TCM - Transmission Control Module	EXE
KK62-7J104-FMC.vbf	Range Rover Sport (L494)	TCM - Transmission Control Module	EXE
KK62-7J104-FMD.vbf	Range Rover Sport (L494)	TCM - Transmission Control Module	EXE
KK62-7J104-FME.vbf	Range Rover Sport (L494)	TCM - Transmission Control Module	EXE
KK62-7J104-FNA.vbf	Range Rover Sport (L494)	TCM - Transmission Control Module	EXE
KK62-7J104-FNB.vbf	Range Rover Sport (L494)	TCM - Transmission Control Module	EXE
KK62-7J104-FNC.vbf	Range Rover Sport (L494)	TCM - Transmission Control Module	EXE
KK62-7J104-GHB.vbf	Range Rover Sport (L494)	TCM - Transmission Control Module	EXE
KK62-7J104-GHD.vbf	Range Rover Sport (L494)	TCM - Transmission Control Module	EXE
KK62-7J104-GHE.vbf	Range Rover Sport (L494)	TCM - Transmission Control Module	EXE
KK62-7J104-GHG.vbf	Range Rover Sport (L494)	TCM - Transmission Control Module	EXE
KK62-7J104-GHJ.vbf	Range Rover Sport (L494)	TCM - Transmission Control Module	EXE

File name	Vehicle line (indicative)	Module (ECU)	Type
KK62-7J104-GHK.vbf	Range Rover Sport (L494)	TCM - Transmission Control Module	EXE
KK62-7J104-GRA.vbf	Range Rover Sport (L494)	TCM - Transmission Control Module	EXE
KK62-7J104-GRB.vbf	Range Rover Sport (L494)	TCM - Transmission Control Module	EXE
KK62-7J104-GRC.vbf	Range Rover Sport (L494)	TCM - Transmission Control Module	EXE
KK62-7J104-GRD.vbf	Range Rover Sport (L494)	TCM - Transmission Control Module	EXE
KK62-7J104-GRE.vbf	Range Rover Sport (L494)	TCM - Transmission Control Module	EXE
KK62-7J104-GRF.vbf	Range Rover Sport (L494)	TCM - Transmission Control Module	EXE
KK62-7J104-GRH.vbf	Range Rover Sport (L494)	TCM - Transmission Control Module	EXE
KK62-7J104-GRJ.vbf	Range Rover Sport (L494)	TCM - Transmission Control Module	EXE
KK62-7J104-GRK.vbf	Range Rover Sport (L494)	TCM - Transmission Control Module	EXE
KK62-7J104-GRL.vbf	Range Rover Sport (L494)	TCM - Transmission Control Module	EXE
KK6M-14E094-JHA.vbf	Range Rover Sport (L494)	CHCM - Chassis Control Module	EXE
KK6M-14E094-JHB.vbf	Range Rover Sport (L494)	CHCM - Chassis Control Module	EXE
KK6M-14E094-JHC.vbf	Range Rover Sport (L494)	CHCM - Chassis Control Module	EXE
KK6M-14E094-JHD.vbf	Range Rover Sport (L494)	CHCM - Chassis Control Module	EXE
KK6M-14E094-JHE.vbf	Range Rover Sport (L494)	CHCM - Chassis Control Module	EXE
KK6M-14E094-JHF.vbf	Range Rover Sport (L494)	CHCM - Chassis Control Module	EXE
KK6M-14E094-JHG.vbf	Range Rover Sport (L494)	CHCM - Chassis Control Module	EXE
KK6M-14F435-NEA.vbf	Range Rover Sport (L494)	CHCMB - Chassis Control Module B	EXE
KK6M-14F435-NEB.vbf	Range Rover Sport (L494)	CHCMB - Chassis Control Module B	EXE
KK6M-14F435-NEC.vbf	Range Rover Sport (L494)	CHCMB - Chassis Control Module B	EXE
KK6M-14F435-NEE.vbf	Range Rover Sport (L494)	CHCMB - Chassis Control Module B	EXE
KK6M-14F435-NEF.vbf	Range Rover Sport (L494)	CHCMB - Chassis Control Module B	EXE
KK6M-14F435-NEG.vbf	Range Rover Sport (L494)	CHCMB - Chassis Control Module B	EXE
KK72-12K532-FAA.vbf	Discovery Sport (L550)	PCM - Powertrain Control Module	DATA
KK72-12K532-FAB.vbf	Discovery Sport (L550)	PCM - Powertrain Control Module	DATA
KK72-12K532-FAC.vbf	Discovery Sport (L550)	PCM - Powertrain Control Module	DATA
KK72-12K532-FAD.vbf	Discovery Sport (L550)	PCM - Powertrain Control Module	DATA
KK72-12K532-FAE.vbf	Discovery Sport (L550)	PCM - Powertrain Control Module	DATA
KK72-12K532-FBA.vbf	Discovery Sport (L550)	PCM - Powertrain Control Module	DATA
KK72-12K532-FBB.vbf	Discovery Sport (L550)	PCM - Powertrain Control Module	DATA
KK72-12K532-FBC.vbf	Discovery Sport (L550)	PCM - Powertrain Control Module	DATA
KK72-12K532-FBD.vbf	Discovery Sport (L550)	PCM - Powertrain Control Module	DATA
KK72-12K532-FBE.vbf	Discovery Sport (L550)	PCM - Powertrain Control Module	DATA
KK72-12K532-FCA.vbf	Discovery Sport (L550)	PCM - Powertrain Control Module	DATA
KK72-12K532-FCB.vbf	Discovery Sport (L550)	PCM - Powertrain Control Module	DATA
KK72-12K532-FCC.vbf	Discovery Sport (L550)	PCM - Powertrain Control Module	DATA
KK72-12K532-FCD.vbf	Discovery Sport (L550)	PCM - Powertrain Control Module	DATA
KK72-12K532-FCE.vbf	Discovery Sport (L550)	PCM - Powertrain Control Module	DATA
KK72-12K532-GAA.vbf	Discovery Sport (L550)	PCM - Powertrain Control Module	DATA
KK72-12K532-GAB.vbf	Discovery Sport (L550)	PCM - Powertrain Control Module	DATA
KK72-12K532-GAC.vbf	Discovery Sport (L550)	PCM - Powertrain Control Module	DATA
KK72-12K532-GAD.vbf	Discovery Sport (L550)	PCM - Powertrain Control Module	DATA
KK72-12K532-GAE.vbf	Discovery Sport (L550)	PCM - Powertrain Control Module	DATA
KK72-12K532-GAF.vbf	Discovery Sport (L550)	PCM - Powertrain Control Module	DATA
KK72-12K532-GAG.vbf	Discovery Sport (L550)	PCM - Powertrain Control Module	DATA
KK72-12K532-GBA.vbf	Discovery Sport (L550)	PCM - Powertrain Control Module	DATA
KK72-12K532-GBB.vbf	Discovery Sport (L550)	PCM - Powertrain Control Module	DATA
KK72-12K532-GBC.vbf	Discovery Sport (L550)	PCM - Powertrain Control Module	DATA
KK72-12K532-GBD.vbf	Discovery Sport (L550)	PCM - Powertrain Control Module	DATA
KK72-12K532-GBE.vbf	Discovery Sport (L550)	PCM - Powertrain Control Module	DATA
KK72-12K532-GBF.vbf	Discovery Sport (L550)	PCM - Powertrain Control Module	DATA
KK72-12K532-GBG.vbf	Discovery Sport (L550)	PCM - Powertrain Control Module	DATA
KK72-12K532-GCA.vbf	Discovery Sport (L550)	PCM - Powertrain Control Module	DATA
KK72-12K532-GCB.vbf	Discovery Sport (L550)	PCM - Powertrain Control Module	DATA
KK72-12K532-GCC.vbf	Discovery Sport (L550)	PCM - Powertrain Control Module	DATA
KK72-12K532-GCD.vbf	Discovery Sport (L550)	PCM - Powertrain Control Module	DATA
KK72-12K532-GCE.vbf	Discovery Sport (L550)	PCM - Powertrain Control Module	DATA
KK72-12K532-GCF.vbf	Discovery Sport (L550)	PCM - Powertrain Control Module	DATA
KK72-12K532-GCG.vbf	Discovery Sport (L550)	PCM - Powertrain Control Module	DATA
KK72-14C204-FAA.vbf	Discovery Sport (L550)	PCM - Powertrain Control Module	EXE
KK72-14C204-FAB.vbf	Discovery Sport (L550)	PCM - Powertrain Control Module	EXE
KK72-14C204-FAC.vbf	Discovery Sport (L550)	PCM - Powertrain Control Module	EXE
KK72-14C204-FBA.vbf	Discovery Sport (L550)	PCM - Powertrain Control Module	EXE
KK72-14C204-FBB.vbf	Discovery Sport (L550)	PCM - Powertrain Control Module	EXE
KK72-14C204-FBC.vbf	Discovery Sport (L550)	PCM - Powertrain Control Module	EXE
KK72-14C204-FCB.vbf	Discovery Sport (L550)	PCM - Powertrain Control Module	EXE
KK72-14C273-FA.vbf	Discovery Sport (L550)	PCM - Powertrain Control Module	SBL
KK72-14C337-CJA.vbf	Discovery Sport (L550)	TCM - Transmission Control Module	EXE
KK72-14C337-CJB.vbf	Discovery Sport (L550)	TCM - Transmission Control Module	EXE
KK72-14C337-CJC.vbf	Discovery Sport (L550)	TCM - Transmission Control Module	EXE
KK72-14C337-CJD.vbf	Discovery Sport (L550)	TCM - Transmission Control Module	EXE
KK72-14C337-CKA.vbf	Discovery Sport (L550)	TCM - Transmission Control Module	EXE
KK72-14C337-CKB.vbf	Discovery Sport (L550)	TCM - Transmission Control Module	EXE
KK72-14C337-CKC.vbf	Discovery Sport (L550)	TCM - Transmission Control Module	EXE
KK72-14C337-CKD.vbf	Discovery Sport (L550)	TCM - Transmission Control Module	EXE

File name	Vehicle line (indicative)	Module (ECU)	Type
KK72-14C337-CLA.vbf	Discovery Sport (L550)	TCM - Transmission Control Module	EXE
KK72-14C337-CLB.vbf	Discovery Sport (L550)	TCM - Transmission Control Module	EXE
KK72-14C337-CLC.vbf	Discovery Sport (L550)	TCM - Transmission Control Module	EXE
KK72-14C337-CLD.vbf	Discovery Sport (L550)	TCM - Transmission Control Module	EXE
KK72-14C337-CMA.vbf	Discovery Sport (L550)	TCM - Transmission Control Module	EXE
KK72-14C337-CMB.vbf	Discovery Sport (L550)	TCM - Transmission Control Module	EXE
KK72-14C337-CMC.vbf	Discovery Sport (L550)	TCM - Transmission Control Module	EXE
KK72-14C337-CMD.vbf	Discovery Sport (L550)	TCM - Transmission Control Module	EXE
KK72-14C337-CPA.vbf	Discovery Sport (L550)	TCM - Transmission Control Module	EXE
KK72-14C337-CPB.vbf	Discovery Sport (L550)	TCM - Transmission Control Module	EXE
KK72-14C337-CPC.vbf	Discovery Sport (L550)	TCM - Transmission Control Module	EXE
KK72-14C337-CPD.vbf	Discovery Sport (L550)	TCM - Transmission Control Module	EXE
KK72-14C337-CRA.vbf	Discovery Sport (L550)	TCM - Transmission Control Module	EXE
KK72-14C337-CRB.vbf	Discovery Sport (L550)	TCM - Transmission Control Module	EXE
KK72-14C337-CRC.vbf	Discovery Sport (L550)	TCM - Transmission Control Module	EXE
KK72-14C337-CRD.vbf	Discovery Sport (L550)	TCM - Transmission Control Module	EXE
KK72-14C337-CTA.vbf	Discovery Sport (L550)	TCM - Transmission Control Module	EXE
KK72-14C337-CTB.vbf	Discovery Sport (L550)	TCM - Transmission Control Module	EXE
KK72-14C337-CTC.vbf	Discovery Sport (L550)	TCM - Transmission Control Module	EXE
KK72-14C337-CTD.vbf	Discovery Sport (L550)	TCM - Transmission Control Module	EXE
KK72-14C570-BAD.vbf	Discovery Sport (L550)	PCM - Powertrain Control Module	EXE
KK72-14C570-BAE.vbf	Discovery Sport (L550)	PCM - Powertrain Control Module	EXE
KK72-14C570-BAF.vbf	Discovery Sport (L550)	PCM - Powertrain Control Module	EXE
KK72-14C570-BAG.vbf	Discovery Sport (L550)	PCM - Powertrain Control Module	EXE
KK72-14C570-BCE.vbf	Discovery Sport (L550)	PCM - Powertrain Control Module	EXE
KK72-14C570-BEE.vbf	Discovery Sport (L550)	PCM - Powertrain Control Module	EXE
KK72-14C570-BFA.vbf	Discovery Sport (L550)	PCM - Powertrain Control Module	EXE
KK72-14C570-BFD.vbf	Discovery Sport (L550)	PCM - Powertrain Control Module	EXE
KK72-14C570-BFE.vbf	Discovery Sport (L550)	PCM - Powertrain Control Module	EXE
KK72-14C570-BFF.vbf	Discovery Sport (L550)	PCM - Powertrain Control Module	EXE
KK72-14C570-BFH.vbf	Discovery Sport (L550)	PCM - Powertrain Control Module	EXE
KK72-14C570-BFK.vbf	Discovery Sport (L550)	PCM - Powertrain Control Module	EXE
KK72-14C570-BFL.vbf	Discovery Sport (L550)	PCM - Powertrain Control Module	EXE
KK72-14C570-BGD.vbf	Discovery Sport (L550)	PCM - Powertrain Control Module	EXE
KK72-14C570-BGE.vbf	Discovery Sport (L550)	PCM - Powertrain Control Module	EXE
KK72-14C570-BGF.vbf	Discovery Sport (L550)	PCM - Powertrain Control Module	EXE
KK72-14C570-BGG.vbf	Discovery Sport (L550)	PCM - Powertrain Control Module	EXE
KK72-14C570-BHA.vbf	Discovery Sport (L550)	PCM - Powertrain Control Module	EXE
KK72-14C570-BHE.vbf	Discovery Sport (L550)	PCM - Powertrain Control Module	EXE
KK72-14C570-BHG.vbf	Discovery Sport (L550)	PCM - Powertrain Control Module	EXE
KK72-14C570-BHH.vbf	Discovery Sport (L550)	PCM - Powertrain Control Module	EXE
KK72-14C570-BHJ.vbf	Discovery Sport (L550)	PCM - Powertrain Control Module	EXE
KK72-14C570-BHL.vbf	Discovery Sport (L550)	PCM - Powertrain Control Module	EXE
KK72-14C570-BJD.vbf	Discovery Sport (L550)	PCM - Powertrain Control Module	EXE
KK72-14C570-BJE.vbf	Discovery Sport (L550)	PCM - Powertrain Control Module	EXE
KK72-14C570-BJF.vbf	Discovery Sport (L550)	PCM - Powertrain Control Module	EXE
KK72-14C570-BJG.vbf	Discovery Sport (L550)	PCM - Powertrain Control Module	EXE
KK72-14C570-BLE.vbf	Discovery Sport (L550)	PCM - Powertrain Control Module	EXE
KK72-14C570-BNE.vbf	Discovery Sport (L550)	PCM - Powertrain Control Module	EXE
KK72-14C570-BRA.vbf	Discovery Sport (L550)	PCM - Powertrain Control Module	EXE
KK72-14C570-BRB.vbf	Discovery Sport (L550)	PCM - Powertrain Control Module	EXE
KK72-14C570-BRC.vbf	Discovery Sport (L550)	PCM - Powertrain Control Module	EXE
KK72-14C570-BRE.vbf	Discovery Sport (L550)	PCM - Powertrain Control Module	EXE
KK72-14C570-BRG.vbf	Discovery Sport (L550)	PCM - Powertrain Control Module	EXE
KK72-14C570-BRH.vbf	Discovery Sport (L550)	PCM - Powertrain Control Module	EXE
KK72-14C570-BRJ.vbf	Discovery Sport (L550)	PCM - Powertrain Control Module	EXE
KK72-14C570-BRL.vbf	Discovery Sport (L550)	PCM - Powertrain Control Module	EXE
KK72-14C570-BTE.vbf	Discovery Sport (L550)	PCM - Powertrain Control Module	EXE
KK72-14C570-BUE.vbf	Discovery Sport (L550)	PCM - Powertrain Control Module	EXE
KK72-14F530-AA.vbf	Discovery Sport (L550)	GWM - Gateway Module A	EXE
KK72-14F531-AA.vbf	Discovery Sport (L550)	GWM - Gateway Module A	DATA
KK72-14F531-AB.vbf	Discovery Sport (L550)	GWM - Gateway Module A	DATA
KK83-12K532-FAA.vbf	Jaguar F-Pace (X761)	PCM - Powertrain Control Module	DATA
KK83-12K532-FAB.vbf	Jaguar F-Pace (X761)	PCM - Powertrain Control Module	EXE
KK83-12K532-FAC.vbf	Jaguar F-Pace (X761)	PCM - Powertrain Control Module	EXE
KK83-12K532-FAD.vbf	Jaguar F-Pace (X761)	PCM - Powertrain Control Module	EXE
KK83-12K532-FAE.vbf	Jaguar F-Pace (X761)	PCM - Powertrain Control Module	EXE
KK83-12K532-FAF.vbf	Jaguar F-Pace (X761)	PCM - Powertrain Control Module	EXE
KK83-12K532-FAG.vbf	Jaguar F-Pace (X761)	PCM - Powertrain Control Module	EXE
KK83-12K532-FAH.vbf	Jaguar F-Pace (X761)	PCM - Powertrain Control Module	EXE
KK83-12K532-FBA.vbf	Jaguar F-Pace (X761)	PCM - Powertrain Control Module	DATA
KK83-12K532-FBB.vbf	Jaguar F-Pace (X761)	PCM - Powertrain Control Module	EXE
KK83-12K532-FBD.vbf	Jaguar F-Pace (X761)	PCM - Powertrain Control Module	EXE
KK83-12K532-FBE.vbf	Jaguar F-Pace (X761)	PCM - Powertrain Control Module	EXE
KK83-12K532-FBF.vbf	Jaguar F-Pace (X761)	PCM - Powertrain Control Module	EXE
KK83-12K532-FBG.vbf	Jaguar F-Pace (X761)	PCM - Powertrain Control Module	EXE

File name	Vehicle line (indicative)	Module (ECU)	Type
KK83-12K532-FBH.vbf	Jaguar F-Pace (X761)	PCM - Powertrain Control Module	EXE
KK83-12K532-FCA.vbf	Jaguar F-Pace (X761)	PCM - Powertrain Control Module	DATA
KK83-12K532-FCB.vbf	Jaguar F-Pace (X761)	PCM - Powertrain Control Module	EXE
KK83-12K532-FCD.vbf	Jaguar F-Pace (X761)	PCM - Powertrain Control Module	EXE
KK83-12K532-FCE.vbf	Jaguar F-Pace (X761)	PCM - Powertrain Control Module	EXE
KK83-12K532-FCF.vbf	Jaguar F-Pace (X761)	PCM - Powertrain Control Module	EXE
KK83-12K532-FCG.vbf	Jaguar F-Pace (X761)	PCM - Powertrain Control Module	EXE
KK83-12K532-FCH.vbf	Jaguar F-Pace (X761)	PCM - Powertrain Control Module	EXE
KK83-12K532-FDB.vbf	Jaguar F-Pace (X761)	PCM - Powertrain Control Module	EXE
KK83-12K532-FDC.vbf	Jaguar F-Pace (X761)	PCM - Powertrain Control Module	EXE
KK83-12K532-FEB.vbf	Jaguar F-Pace (X761)	PCM - Powertrain Control Module	EXE
KK83-12K532-FEC.vbf	Jaguar F-Pace (X761)	PCM - Powertrain Control Module	EXE
KK83-12K532-FFB.vbf	Jaguar F-Pace (X761)	PCM - Powertrain Control Module	EXE
KK83-12K532-FFC.vbf	Jaguar F-Pace (X761)	PCM - Powertrain Control Module	EXE
KK83-12K532-FGB.vbf	Jaguar F-Pace (X761)	PCM - Powertrain Control Module	EXE
KK83-12K532-FHB.vbf	Jaguar F-Pace (X761)	PCM - Powertrain Control Module	EXE
KK83-12K532-FHC.vbf	Jaguar F-Pace (X761)	PCM - Powertrain Control Module	EXE
KK83-12K532-FHD.vbf	Jaguar F-Pace (X761)	PCM - Powertrain Control Module	EXE
KK83-12K532-FJB.vbf	Jaguar F-Pace (X761)	PCM - Powertrain Control Module	EXE
KK83-12K532-FJC.vbf	Jaguar F-Pace (X761)	PCM - Powertrain Control Module	EXE
KK83-12K532-FJD.vbf	Jaguar F-Pace (X761)	PCM - Powertrain Control Module	EXE
KK83-12K532-FJE.vbf	Jaguar F-Pace (X761)	PCM - Powertrain Control Module	EXE
KK83-12K532-FKB.vbf	Jaguar F-Pace (X761)	PCM - Powertrain Control Module	EXE
KK83-12K532-FKC.vbf	Jaguar F-Pace (X761)	PCM - Powertrain Control Module	EXE
KK83-12K532-FMB.vbf	Jaguar F-Pace (X761)	PCM - Powertrain Control Module	EXE
KK83-12K532-FPB.vbf	Jaguar F-Pace (X761)	PCM - Powertrain Control Module	EXE
KK83-12K532-FPD.vbf	Jaguar F-Pace (X761)	PCM - Powertrain Control Module	EXE
KK83-12K532-GCA.vbf	Jaguar F-Pace (X761)	PCM - Powertrain Control Module	DATA
KK83-12K532-GCB.vbf	Jaguar F-Pace (X761)	PCM - Powertrain Control Module	EXE
KK83-12K532-GCC.vbf	Jaguar F-Pace (X761)	PCM - Powertrain Control Module	EXE
KK83-12K532-GCD.vbf	Jaguar F-Pace (X761)	PCM - Powertrain Control Module	EXE
KK83-12K532-GCE.vbf	Jaguar F-Pace (X761)	PCM - Powertrain Control Module	EXE
KK83-12K532-GCF.vbf	Jaguar F-Pace (X761)	PCM - Powertrain Control Module	EXE
KK83-12K532-GCG.vbf	Jaguar F-Pace (X761)	PCM - Powertrain Control Module	EXE
KK83-12K532-GCH.vbf	Jaguar F-Pace (X761)	PCM - Powertrain Control Module	EXE
KK83-12K532-GCJ.vbf	Jaguar F-Pace (X761)	PCM - Powertrain Control Module	EXE
KK83-12K532-PMC.vbf	Jaguar F-Pace (X761)	PCM - Powertrain Control Module	EXE
KK83-12K532-PMD.vbf	Jaguar F-Pace (X761)	PCM - Powertrain Control Module	EXE
KK83-12K532-PRB.vbf	Jaguar F-Pace (X761)	PCM - Powertrain Control Module	EXE
KK83-12K532-PRC.vbf	Jaguar F-Pace (X761)	PCM - Powertrain Control Module	EXE
KK83-12K532-PRD.vbf	Jaguar F-Pace (X761)	PCM - Powertrain Control Module	EXE
KK83-12K532-PTC.vbf	Jaguar F-Pace (X761)	PCM - Powertrain Control Module	EXE
KK83-12K532-PTD.vbf	Jaguar F-Pace (X761)	PCM - Powertrain Control Module	EXE
KK83-12K532-PYA.vbf	Jaguar F-Pace (X761)	PCM - Powertrain Control Module	DATA
KK83-12K532-PYB.vbf	Jaguar F-Pace (X761)	PCM - Powertrain Control Module	DATA
KK83-12K532-PYC.vbf	Jaguar F-Pace (X761)	PCM - Powertrain Control Module	EXE
KK83-12K532-PYD.vbf	Jaguar F-Pace (X761)	PCM - Powertrain Control Module	EXE
KK83-12K532-PYE.vbf	Jaguar F-Pace (X761)	PCM - Powertrain Control Module	EXE
KK83-12K532-PYF.vbf	Jaguar F-Pace (X761)	PCM - Powertrain Control Module	EXE
KK83-12K532-PYG.vbf	Jaguar F-Pace (X761)	PCM - Powertrain Control Module	EXE
KK83-12K532-PYJ.vbf	Jaguar F-Pace (X761)	PCM - Powertrain Control Module	EXE
KK83-12K532-PYK.vbf	Jaguar F-Pace (X761)	PCM - Powertrain Control Module	EXE
KK83-14C025-AA.vbf	Jaguar F-Pace (X761)	IPC - Instrument Panel Cluster (IPC) Control Module	SBL
KK83-14C025-AB.vbf	Jaguar F-Pace (X761)	IPC - Instrument Panel Cluster (IPC) Control Module	SBL
KK83-14C026-AA.vbf	Jaguar F-Pace (X761)	IPC - Instrument Panel Cluster (IPC) Control Module	EXE
KK83-14C026-AB.vbf	Jaguar F-Pace (X761)	IPC - Instrument Panel Cluster (IPC) Control Module	EXE
KK83-14C026-AC.vbf	Jaguar F-Pace (X761)	IPC - Instrument Panel Cluster (IPC) Control Module	EXE
KK83-14C026-AE.vbf	Jaguar F-Pace (X761)	IPC - Instrument Panel Cluster (IPC) Control Module	EXE
KK83-14C026-AF.vbf	Jaguar F-Pace (X761)	IPC - Instrument Panel Cluster (IPC) Control Module	EXE
KK83-14C026-AG.vbf	Jaguar F-Pace (X761)	IPC - Instrument Panel Cluster (IPC) Control Module	EXE
KK83-14C026-JA.vbf	Jaguar F-Pace (X761)	IPC - Instrument Panel Cluster (IPC) Control Module	EXE
KK83-14C026-JB.vbf	Jaguar F-Pace (X761)	IPC - Instrument Panel Cluster (IPC) Control Module	EXE
KK83-14C026-JC.vbf	Jaguar F-Pace (X761)	IPC - Instrument Panel Cluster (IPC) Control Module	EXE
KK83-14C026-JE.vbf	Jaguar F-Pace (X761)	IPC - Instrument Panel Cluster (IPC) Control Module	EXE
KK83-14C026-KA.vbf	Jaguar F-Pace (X761)	IPC - Instrument Panel Cluster (IPC) Control Module	EXE
KK83-14C026-KB.vbf	Jaguar F-Pace (X761)	IPC - Instrument Panel Cluster (IPC) Control Module	EXE
KK83-14C026-KC.vbf	Jaguar F-Pace (X761)	IPC - Instrument Panel Cluster (IPC) Control Module	EXE
KK83-14C026-KE.vbf	Jaguar F-Pace (X761)	IPC - Instrument Panel Cluster (IPC) Control Module	EXE
KK83-14C036-GA.vbf	Jaguar F-Pace (X761)	ABS - Anti-Lock Brake System Control Module	EXE
KK83-14C036-GB.vbf	Jaguar F-Pace (X761)	ABS - Anti-Lock Brake System Control Module	EXE
KK83-14C037-MAA.vbf	Jaguar F-Pace (X761)	ABS - Anti-Lock Brake System Control Module	DATA
KK83-14C037-MAB.vbf	Jaguar F-Pace (X761)	ABS - Anti-Lock Brake System Control Module	DATA
KK83-14C037-MAC.vbf	Jaguar F-Pace (X761)	ABS - Anti-Lock Brake System Control Module	DATA
KK83-14C037-MBA.vbf	Jaguar F-Pace (X761)	ABS - Anti-Lock Brake System Control Module	DATA
KK83-14C037-MBB.vbf	Jaguar F-Pace (X761)	ABS - Anti-Lock Brake System Control Module	DATA
KK83-14C037-MBC.vbf	Jaguar F-Pace (X761)	ABS - Anti-Lock Brake System Control Module	DATA

File name	Vehicle line (indicative)	Module (ECU)	Type
KK83-14C037-MCA.vbf	Jaguar F-Pace (X761)	ABS - Anti-Lock Brake System Control Module	DATA
KK83-14C037-MCB.vbf	Jaguar F-Pace (X761)	ABS - Anti-Lock Brake System Control Module	DATA
KK83-14C037-MCC.vbf	Jaguar F-Pace (X761)	ABS - Anti-Lock Brake System Control Module	DATA
KK83-14C037-MDA.vbf	Jaguar F-Pace (X761)	ABS - Anti-Lock Brake System Control Module	DATA
KK83-14C037-MDB.vbf	Jaguar F-Pace (X761)	ABS - Anti-Lock Brake System Control Module	DATA
KK83-14C037-MDC.vbf	Jaguar F-Pace (X761)	ABS - Anti-Lock Brake System Control Module	DATA
KK83-14C037-MEA.vbf	Jaguar F-Pace (X761)	ABS - Anti-Lock Brake System Control Module	DATA
KK83-14C037-MEB.vbf	Jaguar F-Pace (X761)	ABS - Anti-Lock Brake System Control Module	DATA
KK83-14C037-MEC.vbf	Jaguar F-Pace (X761)	ABS - Anti-Lock Brake System Control Module	DATA
KK83-14C037-MFA.vbf	Jaguar F-Pace (X761)	ABS - Anti-Lock Brake System Control Module	DATA
KK83-14C037-MFB.vbf	Jaguar F-Pace (X761)	ABS - Anti-Lock Brake System Control Module	DATA
KK83-14C037-MFC.vbf	Jaguar F-Pace (X761)	ABS - Anti-Lock Brake System Control Module	DATA
KK83-14C037-MGA.vbf	Jaguar F-Pace (X761)	ABS - Anti-Lock Brake System Control Module	DATA
KK83-14C037-MGB.vbf	Jaguar F-Pace (X761)	ABS - Anti-Lock Brake System Control Module	DATA
KK83-14C037-MGC.vbf	Jaguar F-Pace (X761)	ABS - Anti-Lock Brake System Control Module	DATA
KK83-14C037-MHA.vbf	Jaguar F-Pace (X761)	ABS - Anti-Lock Brake System Control Module	DATA
KK83-14C037-MHB.vbf	Jaguar F-Pace (X761)	ABS - Anti-Lock Brake System Control Module	DATA
KK83-14C037-MHC.vbf	Jaguar F-Pace (X761)	ABS - Anti-Lock Brake System Control Module	DATA
KK83-14C037-MJA.vbf	Jaguar F-Pace (X761)	ABS - Anti-Lock Brake System Control Module	DATA
KK83-14C037-MJB.vbf	Jaguar F-Pace (X761)	ABS - Anti-Lock Brake System Control Module	DATA
KK83-14C037-MJC.vbf	Jaguar F-Pace (X761)	ABS - Anti-Lock Brake System Control Module	DATA
KK83-14C037-MKA.vbf	Jaguar F-Pace (X761)	ABS - Anti-Lock Brake System Control Module	DATA
KK83-14C037-MKB.vbf	Jaguar F-Pace (X761)	ABS - Anti-Lock Brake System Control Module	DATA
KK83-14C037-MKC.vbf	Jaguar F-Pace (X761)	ABS - Anti-Lock Brake System Control Module	DATA
KK83-14C037-MLA.vbf	Jaguar F-Pace (X761)	ABS - Anti-Lock Brake System Control Module	DATA
KK83-14C037-MLB.vbf	Jaguar F-Pace (X761)	ABS - Anti-Lock Brake System Control Module	DATA
KK83-14C037-MLC.vbf	Jaguar F-Pace (X761)	ABS - Anti-Lock Brake System Control Module	DATA
KK83-14C037-MMA.vbf	Jaguar F-Pace (X761)	ABS - Anti-Lock Brake System Control Module	DATA
KK83-14C037-MMB.vbf	Jaguar F-Pace (X761)	ABS - Anti-Lock Brake System Control Module	DATA
KK83-14C037-MMC.vbf	Jaguar F-Pace (X761)	ABS - Anti-Lock Brake System Control Module	DATA
KK83-14C037-MNA.vbf	Jaguar F-Pace (X761)	ABS - Anti-Lock Brake System Control Module	DATA
KK83-14C037-MNB.vbf	Jaguar F-Pace (X761)	ABS - Anti-Lock Brake System Control Module	DATA
KK83-14C037-MNC.vbf	Jaguar F-Pace (X761)	ABS - Anti-Lock Brake System Control Module	DATA
KK83-14C037-MPA.vbf	Jaguar F-Pace (X761)	ABS - Anti-Lock Brake System Control Module	DATA
KK83-14C037-MPB.vbf	Jaguar F-Pace (X761)	ABS - Anti-Lock Brake System Control Module	DATA
KK83-14C037-MPC.vbf	Jaguar F-Pace (X761)	ABS - Anti-Lock Brake System Control Module	DATA
KK83-14C037-MRA.vbf	Jaguar F-Pace (X761)	ABS - Anti-Lock Brake System Control Module	DATA
KK83-14C037-MRB.vbf	Jaguar F-Pace (X761)	ABS - Anti-Lock Brake System Control Module	DATA
KK83-14C037-MRC.vbf	Jaguar F-Pace (X761)	ABS - Anti-Lock Brake System Control Module	DATA
KK83-14C037-MSA.vbf	Jaguar F-Pace (X761)	ABS - Anti-Lock Brake System Control Module	DATA
KK83-14C037-MSB.vbf	Jaguar F-Pace (X761)	ABS - Anti-Lock Brake System Control Module	DATA
KK83-14C037-MSC.vbf	Jaguar F-Pace (X761)	ABS - Anti-Lock Brake System Control Module	DATA
KK83-14C088-BA.vbf	Jaguar F-Pace (X761)	IPC - Instrument Panel Cluster (IPC) Control Module	DATA
KK83-14C088-BB.vbf	Jaguar F-Pace (X761)	IPC - Instrument Panel Cluster (IPC) Control Module	DATA
KK83-14C088-CA.vbf	Jaguar F-Pace (X761)	IPC - Instrument Panel Cluster (IPC) Control Module	EXE
KK83-14C088-CB.vbf	Jaguar F-Pace (X761)	IPC - Instrument Panel Cluster (IPC) Control Module	EXE
KK83-14C088-CC.vbf	Jaguar F-Pace (X761)	IPC - Instrument Panel Cluster (IPC) Control Module	EXE
KK83-14C088-CD.vbf	Jaguar F-Pace (X761)	IPC - Instrument Panel Cluster (IPC) Control Module	EXE
KK83-14C088-CE.vbf	Jaguar F-Pace (X761)	IPC - Instrument Panel Cluster (IPC) Control Module	EXE
KK83-14C088-CEX.vbf	Jaguar F-Pace (X761)	IPC - Instrument Panel Cluster (IPC) Control Module	DATA
KK83-14C088-CF.vbf	Jaguar F-Pace (X761)	IPC - Instrument Panel Cluster (IPC) Control Module	EXE
KK83-14C088-CG.vbf	Jaguar F-Pace (X761)	IPC - Instrument Panel Cluster (IPC) Control Module	DATA
KK83-14C088-JA.vbf	Jaguar F-Pace (X761)	IPC - Instrument Panel Cluster (IPC) Control Module	DATA
KK83-14C088-JB.vbf	Jaguar F-Pace (X761)	IPC - Instrument Panel Cluster (IPC) Control Module	DATA
KK83-14C088-JC.vbf	Jaguar F-Pace (X761)	IPC - Instrument Panel Cluster (IPC) Control Module	DATA
KK83-14C088-JE.vbf	Jaguar F-Pace (X761)	IPC - Instrument Panel Cluster (IPC) Control Module	DATA
KK83-14C088-JEX.vbf	Jaguar F-Pace (X761)	IPC - Instrument Panel Cluster (IPC) Control Module	DATA
KK83-14C088-JF.vbf	Jaguar F-Pace (X761)	IPC - Instrument Panel Cluster (IPC) Control Module	DATA
KK83-14C088-JG.vbf	Jaguar F-Pace (X761)	IPC - Instrument Panel Cluster (IPC) Control Module	DATA
KK83-14C088-JK.vbf	Jaguar F-Pace (X761)	IPC - Instrument Panel Cluster (IPC) Control Module	DATA
KK83-14C091-AC.vbf	Jaguar F-Pace (X761)	PAM - Parking Assist Control Module	DATA
KK83-14C091-AD.vbf	Jaguar F-Pace (X761)	PAM - Parking Assist Control Module	DATA
KK83-14C091-AE.vbf	Jaguar F-Pace (X761)	PAM - Parking Assist Control Module	DATA
KK83-14C091-AH.vbf	Jaguar F-Pace (X761)	PAM - Parking Assist Control Module	DATA
KK83-14C185-AA.vbf	Jaguar F-Pace (X761)	BCM - Body Control Module	DATA
KK83-14C185-AB.vbf	Jaguar F-Pace (X761)	BCM - Body Control Module	DATA
KK83-14C217-AA.vbf	Jaguar F-Pace (X761)	PSCM - Power Steering Control Module	EXE
KK83-14C217-AB.vbf	Jaguar F-Pace (X761)	PSCM - Power Steering Control Module	EXE
KK83-14C218-AB.vbf	Jaguar F-Pace (X761)	PSCM - Power Steering Control Module	DATA
KK83-14C218-AC.vbf	Jaguar F-Pace (X761)	PSCM - Power Steering Control Module	DATA
KK83-14C218-BA.vbf	Jaguar F-Pace (X761)	PSCM - Power Steering Control Module	DATA
KK83-14C218-BB.vbf	Jaguar F-Pace (X761)	PSCM - Power Steering Control Module	DATA
KK83-14C218-CA.vbf	Jaguar F-Pace (X761)	PSCM - Power Steering Control Module	DATA
KK83-14C218-CB.vbf	Jaguar F-Pace (X761)	PSCM - Power Steering Control Module	DATA
KK83-14C218-DA.vbf	Jaguar F-Pace (X761)	PSCM - Power Steering Control Module	DATA
KK83-14C218-DB.vbf	Jaguar F-Pace (X761)	PSCM - Power Steering Control Module	DATA

File name	Vehicle line (indicative)	Module (ECU)	Type
KK83-14C220-AA.vbf	Jaguar F-Pace (X761)	PSCM - Power Steering Control Module	SBL
KK83-14C273-PAA.vbf	Jaguar F-Pace (X761)	PCM - Powertrain Control Module	SBL
KK83-14C386-AA.vbf	Jaguar F-Pace (X761)	PSCM - Power Steering Control Module	SIGCFG
KK83-14C527-AA.vbf	Jaguar F-Pace (X761)	AAM - Audio Amplifier Module	DATA
KK83-14C527-AAA.vbf	Jaguar F-Pace (X761)	AAM - Audio Amplifier Module	DATA
KK83-14C527-ABA.vbf	Jaguar F-Pace (X761)	AAM - Audio Amplifier Module	DATA
KK83-14C527-ACA.vbf	Jaguar F-Pace (X761)	AAM - Audio Amplifier Module	DATA
KK83-14C527-AFA.vbf	Jaguar F-Pace (X761)	AAM - Audio Amplifier Module	DATA
KK83-14C527-AHA.vbf	Jaguar F-Pace (X761)	AAM - Audio Amplifier Module	DATA
KK83-14C527-BFA.vbf	Jaguar F-Pace (X761)	AAM - Audio Amplifier Module	DATA
KK83-14C527-BHA.vbf	Jaguar F-Pace (X761)	AAM - Audio Amplifier Module	DATA
KK83-14C527-CFA.vbf	Jaguar F-Pace (X761)	AAM - Audio Amplifier Module	DATA
KK83-14C527-CHA.vbf	Jaguar F-Pace (X761)	AAM - Audio Amplifier Module	DATA
KK83-14C570-UAA.vbf	Jaguar F-Pace (X761)	PCM - Powertrain Control Module	EXE
KK83-14C570-UAB.vbf	Jaguar F-Pace (X761)	PCM - Powertrain Control Module	EXE
KK83-14C570-UBB.vbf	Jaguar F-Pace (X761)	PCM - Powertrain Control Module	EXE
KK83-14C570-UCB.vbf	Jaguar F-Pace (X761)	PCM - Powertrain Control Module	EXE
KK83-14C570-UEB.vbf	Jaguar F-Pace (X761)	PCM - Powertrain Control Module	EXE
KK83-14C570-UFA.vbf	Jaguar F-Pace (X761)	PCM - Powertrain Control Module	EXE
KK83-14C570-UFB.vbf	Jaguar F-Pace (X761)	PCM - Powertrain Control Module	EXE
KK83-14C570-UTA.vbf	Jaguar F-Pace (X761)	PCM - Powertrain Control Module	EXE
KK83-14C570-UTB.vbf	Jaguar F-Pace (X761)	PCM - Powertrain Control Module	EXE
KK83-14C609-AA.vbf	Jaguar F-Pace (X761)	PSCM - Power Steering Control Module	DATA
KK83-14C609-BA.vbf	Jaguar F-Pace (X761)	PSCM - Power Steering Control Module	DATA
KK83-14C609-BB.vbf	Jaguar F-Pace (X761)	PSCM - Power Steering Control Module	DATA
KK83-14D049-AB.vbf	Jaguar F-Pace (X761)	CCM - Cruise Control Module	EXE
KK83-14D049-AC.vbf	Jaguar F-Pace (X761)	CCM - Cruise Control Module	EXE
KK83-14D049-AD.vbf	Jaguar F-Pace (X761)	CCM - Cruise Control Module	EXE
KK83-14D049-AE.vbf	Jaguar F-Pace (X761)	CCM - Cruise Control Module	EXE
KK83-14D049-AF.vbf	Jaguar F-Pace (X761)	CCM - Cruise Control Module	EXE
KK83-14D051-AB.vbf	Jaguar F-Pace (X761)	CCM - Cruise Control Module	SBL
KK83-14D564-AA.vbf	Jaguar F-Pace (X761)	SODL - Side Obstacle Detection Control Module - Left	DATA
KK83-14D564-BA.vbf	Jaguar F-Pace (X761)	SODR - Side Obstacle Detection Control Module - Right	DATA
KK83-14F396-AB.vbf	Jaguar F-Pace (X761)	IPMA - Image Processing Module A	EXE
KK83-14F397-CA.vbf	Jaguar F-Pace (X761)	IPMA - Image Processing Module A	EXE
KK83-14F397-CB.vbf	Jaguar F-Pace (X761)	IPMA - Image Processing Module A	EXE
KK83-14F397-CC.vbf	Jaguar F-Pace (X761)	IPMA - Image Processing Module A	EXE
KK83-14F397-CD.vbf	Jaguar F-Pace (X761)	IPMA - Image Processing Module A	EXE
KK83-14F397-CF.vbf	Jaguar F-Pace (X761)	IPMA - Image Processing Module A	EXE
KK83-14F397-CG.vbf	Jaguar F-Pace (X761)	IPMA - Image Processing Module A	EXE
KK83-14F397-CH.vbf	Jaguar F-Pace (X761)	IPMA - Image Processing Module A	EXE
KK83-14F397-CJ.vbf	Jaguar F-Pace (X761)	IPMA - Image Processing Module A	EXE
KK83-14F397-CK.vbf	Jaguar F-Pace (X761)	IPMA - Image Processing Module A	EXE
KK83-14F397-DA.vbf	Jaguar F-Pace (X761)	IPMA - Image Processing Module A	EXE
KK83-14F397-DB.vbf	Jaguar F-Pace (X761)	IPMA - Image Processing Module A	EXE
KK83-14F397-DC.vbf	Jaguar F-Pace (X761)	IPMA - Image Processing Module A	EXE
KK83-14F397-DD.vbf	Jaguar F-Pace (X761)	IPMA - Image Processing Module A	EXE
KK83-14F397-DF.vbf	Jaguar F-Pace (X761)	IPMA - Image Processing Module A	EXE
KK83-14F397-DG.vbf	Jaguar F-Pace (X761)	IPMA - Image Processing Module A	EXE
KK83-14F397-DH.vbf	Jaguar F-Pace (X761)	IPMA - Image Processing Module A	EXE
KK83-14F397-DJ.vbf	Jaguar F-Pace (X761)	IPMA - Image Processing Module A	EXE
KK83-14F397-DK.vbf	Jaguar F-Pace (X761)	IPMA - Image Processing Module A	EXE
KK83-14F397-EA.vbf	Jaguar F-Pace (X761)	IPMA - Image Processing Module A	EXE
KK83-14F397-EB.vbf	Jaguar F-Pace (X761)	IPMA - Image Processing Module A	EXE
KK83-14F397-EC.vbf	Jaguar F-Pace (X761)	IPMA - Image Processing Module A	EXE
KK83-14F397-ED.vbf	Jaguar F-Pace (X761)	IPMA - Image Processing Module A	EXE
KK83-14F397-EF.vbf	Jaguar F-Pace (X761)	IPMA - Image Processing Module A	EXE
KK83-14F397-EG.vbf	Jaguar F-Pace (X761)	IPMA - Image Processing Module A	EXE
KK83-14F397-EH.vbf	Jaguar F-Pace (X761)	IPMA - Image Processing Module A	EXE
KK83-14F397-EJ.vbf	Jaguar F-Pace (X761)	IPMA - Image Processing Module A	EXE
KK83-14F397-EK.vbf	Jaguar F-Pace (X761)	IPMA - Image Processing Module A	EXE
KK83-14F397-FA.vbf	Jaguar F-Pace (X761)	IPMA - Image Processing Module A	EXE
KK83-14F397-FB.vbf	Jaguar F-Pace (X761)	IPMA - Image Processing Module A	EXE
KK83-14F397-FC.vbf	Jaguar F-Pace (X761)	IPMA - Image Processing Module A	EXE
KK83-14F397-FD.vbf	Jaguar F-Pace (X761)	IPMA - Image Processing Module A	EXE
KK83-14F397-FF.vbf	Jaguar F-Pace (X761)	IPMA - Image Processing Module A	EXE
KK83-14F397-FG.vbf	Jaguar F-Pace (X761)	IPMA - Image Processing Module A	EXE
KK83-14F397-FH.vbf	Jaguar F-Pace (X761)	IPMA - Image Processing Module A	EXE
KK83-14F397-FJ.vbf	Jaguar F-Pace (X761)	IPMA - Image Processing Module A	EXE
KK83-14F397-FK.vbf	Jaguar F-Pace (X761)	IPMA - Image Processing Module A	EXE
KK83-14F398-BA.vbf	Jaguar F-Pace (X761)	IPMA - Image Processing Module A	EXE
KK83-14F398-BB.vbf	Jaguar F-Pace (X761)	IPMA - Image Processing Module A	EXE
KK83-14F398-BC.vbf	Jaguar F-Pace (X761)	IPMA - Image Processing Module A	EXE
KK83-14F398-BD.vbf	Jaguar F-Pace (X761)	IPMA - Image Processing Module A	EXE
KK83-14F398-BF.vbf	Jaguar F-Pace (X761)	IPMA - Image Processing Module A	EXE
KK83-14F398-BG.vbf	Jaguar F-Pace (X761)	IPMA - Image Processing Module A	EXE

File name	Vehicle line (indicative)	Module (ECU)	Type
KK83-14F398-BH.vbf	Jaguar F-Pace (X761)	IPMA - Image Processing Module A	EXE
KK83-14F398-BJ.vbf	Jaguar F-Pace (X761)	IPMA - Image Processing Module A	EXE
KK83-14F398-BK.vbf	Jaguar F-Pace (X761)	IPMA - Image Processing Module A	EXE
KK83-14F398-CA.vbf	Jaguar F-Pace (X761)	IPMA - Image Processing Module A	EXE
KK83-14F398-CB.vbf	Jaguar F-Pace (X761)	IPMA - Image Processing Module A	EXE
KK83-14F398-CC.vbf	Jaguar F-Pace (X761)	IPMA - Image Processing Module A	EXE
KK83-14F398-CD.vbf	Jaguar F-Pace (X761)	IPMA - Image Processing Module A	EXE
KK83-14F398-CF.vbf	Jaguar F-Pace (X761)	IPMA - Image Processing Module A	EXE
KK83-14F398-CG.vbf	Jaguar F-Pace (X761)	IPMA - Image Processing Module A	EXE
KK83-14F398-CH.vbf	Jaguar F-Pace (X761)	IPMA - Image Processing Module A	EXE
KK83-14F398-CJ.vbf	Jaguar F-Pace (X761)	IPMA - Image Processing Module A	EXE
KK83-14F398-CK.vbf	Jaguar F-Pace (X761)	IPMA - Image Processing Module A	EXE
KK83-14F529-BB.vbf	Jaguar F-Pace (X761)	GWM - Gateway Module A	EXE
KK83-14F529-BC.vbf	Jaguar F-Pace (X761)	GWM - Gateway Module A	EXE
KK83-14F529-BD.vbf	Jaguar F-Pace (X761)	GWM - Gateway Module A	EXE
KK83-14F529-BE.vbf	Jaguar F-Pace (X761)	GWM - Gateway Module A	EXE
KK83-14F529-BF.vbf	Jaguar F-Pace (X761)	GWM - Gateway Module A	EXE
KK83-14F529-BG.vbf	Jaguar F-Pace (X761)	GWM - Gateway Module A	EXE
KK83-14F530-BB.vbf	Jaguar F-Pace (X761)	GWM - Gateway Module A	EXE
KK83-14F530-BC.vbf	Jaguar F-Pace (X761)	GWM - Gateway Module A	EXE
KK83-14F530-BD.vbf	Jaguar F-Pace (X761)	GWM - Gateway Module A	EXE
KK83-14F530-BE.vbf	Jaguar F-Pace (X761)	GWM - Gateway Module A	EXE
KK83-14F530-BF.vbf	Jaguar F-Pace (X761)	GWM - Gateway Module A	EXE
KK83-14F530-BG.vbf	Jaguar F-Pace (X761)	GWM - Gateway Module A	EXE
KK83-14F530-BH.vbf	Jaguar F-Pace (X761)	GWM - Gateway Module A	EXE
KK83-14F531-BB.vbf	Jaguar F-Pace (X761)	GWM - Gateway Module A	DATA
KK83-14F531-BC.vbf	Jaguar F-Pace (X761)	GWM - Gateway Module A	DATA
KK83-14F531-BD.vbf	Jaguar F-Pace (X761)	GWM - Gateway Module A	DATA
KK83-14F531-BE.vbf	Jaguar F-Pace (X761)	GWM - Gateway Module A	DATA
KK83-14F531-BF.vbf	Jaguar F-Pace (X761)	GWM - Gateway Module A	DATA
KK83-14F531-BG.vbf	Jaguar F-Pace (X761)	GWM - Gateway Module A	DATA
KK83-7J104-DFA.vbf	Jaguar F-Pace (X761)	TCM - Transmission Control Module	EXE
KK83-7J104-DFB.vbf	Jaguar F-Pace (X761)	TCM - Transmission Control Module	EXE
KK83-7J104-DFC.vbf	Jaguar F-Pace (X761)	TCM - Transmission Control Module	EXE
KK83-7J104-DFD.vbf	Jaguar F-Pace (X761)	TCM - Transmission Control Module	EXE
KK83-7J104-DLA.vbf	Jaguar F-Pace (X761)	TCM - Transmission Control Module	EXE
KK83-7J104-DLB.vbf	Jaguar F-Pace (X761)	TCM - Transmission Control Module	EXE
KK83-7J104-DLC.vbf	Jaguar F-Pace (X761)	TCM - Transmission Control Module	EXE
KK83-7J104-DLD.vbf	Jaguar F-Pace (X761)	TCM - Transmission Control Module	EXE
KK83-7J104-DUA.vbf	Jaguar F-Pace (X761)	TCM - Transmission Control Module	EXE
KK83-7J104-DUB.vbf	Jaguar F-Pace (X761)	TCM - Transmission Control Module	EXE
KK83-7J104-DUC.vbf	Jaguar F-Pace (X761)	TCM - Transmission Control Module	EXE
KK83-7J104-DUD.vbf	Jaguar F-Pace (X761)	TCM - Transmission Control Module	EXE
KK83-7J104-DVA.vbf	Jaguar F-Pace (X761)	TCM - Transmission Control Module	EXE
KK83-7J104-DVB.vbf	Jaguar F-Pace (X761)	TCM - Transmission Control Module	EXE
KK83-7J104-DVC.vbf	Jaguar F-Pace (X761)	TCM - Transmission Control Module	EXE
KK83-7J104-DVD.vbf	Jaguar F-Pace (X761)	TCM - Transmission Control Module	EXE
KK83-7J104-FBA.vbf	Jaguar F-Pace (X761)	TCM - Transmission Control Module	EXE
KK83-7J104-FBB.vbf	Jaguar F-Pace (X761)	TCM - Transmission Control Module	EXE
KK83-7J104-FBC.vbf	Jaguar F-Pace (X761)	TCM - Transmission Control Module	EXE
KK83-7J104-FBD.vbf	Jaguar F-Pace (X761)	TCM - Transmission Control Module	EXE
KK83-7J104-FBE.vbf	Jaguar F-Pace (X761)	TCM - Transmission Control Module	EXE
KK83-7J104-FCA.vbf	Jaguar F-Pace (X761)	TCM - Transmission Control Module	EXE
KK83-7J104-FCB.vbf	Jaguar F-Pace (X761)	TCM - Transmission Control Module	EXE
KK83-7J104-FCC.vbf	Jaguar F-Pace (X761)	TCM - Transmission Control Module	EXE
KK83-7J104-FCD.vbf	Jaguar F-Pace (X761)	TCM - Transmission Control Module	EXE
KK83-7J104-FCE.vbf	Jaguar F-Pace (X761)	TCM - Transmission Control Module	EXE
KK83-7J104-FHA.vbf	Jaguar F-Pace (X761)	TCM - Transmission Control Module	EXE
KK83-7J104-FHB.vbf	Jaguar F-Pace (X761)	TCM - Transmission Control Module	EXE
KK83-7J104-FHC.vbf	Jaguar F-Pace (X761)	TCM - Transmission Control Module	EXE
KK83-7J104-FHD.vbf	Jaguar F-Pace (X761)	TCM - Transmission Control Module	EXE
KK83-7J104-FHE.vbf	Jaguar F-Pace (X761)	TCM - Transmission Control Module	EXE
KK83-7J104-FKA.vbf	Jaguar F-Pace (X761)	TCM - Transmission Control Module	EXE
KK83-7J104-FKB.vbf	Jaguar F-Pace (X761)	TCM - Transmission Control Module	EXE
KK83-7J104-FKC.vbf	Jaguar F-Pace (X761)	TCM - Transmission Control Module	EXE
KK83-7J104-FKD.vbf	Jaguar F-Pace (X761)	TCM - Transmission Control Module	EXE
KK83-7J104-FKE.vbf	Jaguar F-Pace (X761)	TCM - Transmission Control Module	EXE
KK8M-14B793-AC.vbf	Not specified	ATCM - All Terrain Control Module	EXE
KK8M-14C036-AB.vbf	Not specified	ABS - Anti-Lock Brake System Control Module	EXE
KK8M-14C036-AC.vbf	Not specified	ABS - Anti-Lock Brake System Control Module	EXE
KK8M-14C036-AD.vbf	Not specified	ABS - Anti-Lock Brake System Control Module	EXE
KK8M-14C037-AB.vbf	Not specified	ABS - Anti-Lock Brake System Control Module	DATA
KK8M-14C037-AC.vbf	Not specified	ABS - Anti-Lock Brake System Control Module	DATA
KK8M-14C037-AD.vbf	Not specified	ABS - Anti-Lock Brake System Control Module	DATA
KK8M-14C037-AE.vbf	Not specified	ABS - Anti-Lock Brake System Control Module	DATA
KK8M-14C037-BA.vbf	Not specified	ABS - Anti-Lock Brake System Control Module	DATA

File name	Vehicle line (indicative)	Module (ECU)	Type
KK8M-14C037-BC.vbf	Not specified	ABS - Anti-Lock Brake System Control Module	DATA
KK8M-14C037-BD.vbf	Not specified	ABS - Anti-Lock Brake System Control Module	DATA
KK8M-14C152-BA.vbf	Not specified	TPM - Tire Pressure Monitor Module	DATA
KK8M-14C152-BB.vbf	Not specified	TPM - Tire Pressure Monitor Module	DATA
KK8M-14C218-AA.vbf	Not specified	PSCM - Power Steering Control Module	DATA
KK8M-14C218-AB.vbf	Not specified	PSCM - Power Steering Control Module	DATA
KK8M-14C527-BGA.vbf	Not specified	AAM - Audio Amplifier Module	DATA
KK8M-14C527-BGB.vbf	Not specified	AAM - Audio Amplifier Module	DATA
KK8M-14C527-CGA.vbf	Not specified	AAM - Audio Amplifier Module	DATA
KK8M-14C527-CGB.vbf	Not specified	AAM - Audio Amplifier Module	DATA
KK8M-14C549-AA.vbf	Not specified	DSM - Driver Front Seat Module	EXE
KK8M-14C570-SAA.vbf	Not specified	PCM - Powertrain Control Module	EXE
KK8M-14C570-SAC.vbf	Jaguar F-Pace (X761)	PCM - Powertrain Control Module	EXE
KK8M-14C570-SAD.vbf	Not specified	PCM - Powertrain Control Module	EXE
KK8M-14C570-SAF.vbf	Not specified	PCM - Powertrain Control Module	EXE
KK8M-14C570-SCD.vbf	Not specified	PCM - Powertrain Control Module	EXE
KK8M-14C570-SCF.vbf	Not specified	PCM - Powertrain Control Module	EXE
KK8M-14C570-SED.vbf	Not specified	PCM - Powertrain Control Module	EXE
KK8M-14C570-SEF.vbf	Not specified	PCM - Powertrain Control Module	EXE
KK8M-14C570-SHA.vbf	Not specified	PCM - Powertrain Control Module	EXE
KK8M-14C570-SHC.vbf	Jaguar F-Pace (X761)	PCM - Powertrain Control Module	EXE
KK8M-14C570-SHD.vbf	Not specified	PCM - Powertrain Control Module	EXE
KK8M-14C570-SHE.vbf	Not specified	PCM - Powertrain Control Module	EXE
KK8M-14C570-SHG.vbf	Not specified	PCM - Powertrain Control Module	EXE
KK8M-14C570-STC.vbf	Jaguar F-Pace (X761)	PCM - Powertrain Control Module	EXE
KK8M-14C570-STD.vbf	Not specified	PCM - Powertrain Control Module	EXE
KK8M-14C570-STF.vbf	Not specified	PCM - Powertrain Control Module	EXE
KK8M-14C609-AA.vbf	Not specified	PSCM - Power Steering Control Module	DATA
KK8M-14C609-AB.vbf	Not specified	PSCM - Power Steering Control Module	DATA
KK8M-14D564-AA.vbf	Not specified	SODL - Side Obstacle Detection Control Module - Left	DATA
KK8M-14D564-AB.vbf	Not specified	SODL - Side Obstacle Detection Control Module - Left	DATA
KK8M-14D564-BA.vbf	Not specified	SODR - Side Obstacle Detection Control Module - Right	DATA
KK8M-14D564-BB.vbf	Not specified	SODR - Side Obstacle Detection Control Module - Right	DATA
KK8M-14E094-DAA.vbf	Not specified	CHCM - Chassis Control Module	EXE
KK8M-14E094-DAB.vbf	Not specified	CHCM - Chassis Control Module	EXE
KK8M-14E094-DAC.vbf	Not specified	CHCM - Chassis Control Module	EXE
KK8M-7J104-FZA.vbf	Not specified	TCM - Transmission Control Module	EXE
KK8M-7J104-FZB.vbf	Not specified	TCM - Transmission Control Module	EXE
KK8M-7J104-FZC.vbf	Not specified	TCM - Transmission Control Module	EXE
KK8M-7J104-FZD.vbf	Not specified	TCM - Transmission Control Module	EXE
KK8M-7J104-FZE.vbf	Not specified	TCM - Transmission Control Module	EXE
KK8M-7J104-FZF.vbf	Not specified	TCM - Transmission Control Module	EXE
KPLA-12K532-NYA.vbf	Multiple models (shared module)	PCM - Powertrain Control Module	DATA
KPLA-12K532-NYB.vbf	Multiple models (shared module)	PCM - Powertrain Control Module	DATA
KPLA-12K532-NYC.vbf	Multiple models (shared module)	PCM - Powertrain Control Module	EXE
KPLA-12K532-NYD.vbf	Multiple models (shared module)	PCM - Powertrain Control Module	EXE
KPLA-12K532-NYE.vbf	Multiple models (shared module)	PCM - Powertrain Control Module	EXE
KPLA-12K532-NYF.vbf	Multiple models (shared module)	PCM - Powertrain Control Module	EXE
KPLA-12K532-NYG.vbf	Multiple models (shared module)	PCM - Powertrain Control Module	EXE
KPLA-12K532-NYH.vbf	Multiple models (shared module)	PCM - Powertrain Control Module	EXE
KPLA-12K532-NYJ.vbf	Multiple models (shared module)	PCM - Powertrain Control Module	EXE
KPLA-12K532-NYK.vbf	Multiple models (shared module)	PCM - Powertrain Control Module	EXE
KPLA-14C026-JA.vbf	Multiple models (shared module)	IPC - Instrument Panel Cluster (IPC) Control Module	EXE
KPLA-14C026-JB.vbf	Multiple models (shared module)	IPC - Instrument Panel Cluster (IPC) Control Module	EXE
KPLA-14C026-JC.vbf	Multiple models (shared module)	IPC - Instrument Panel Cluster (IPC) Control Module	EXE
KPLA-14C026-JD.vbf	Multiple models (shared module)	IPC - Instrument Panel Cluster (IPC) Control Module	EXE
KPLA-14C026-JE.vbf	Multiple models (shared module)	IPC - Instrument Panel Cluster (IPC) Control Module	EXE
KPLA-14C026-JF.vbf	Multiple models (shared module)	IPC - Instrument Panel Cluster (IPC) Control Module	EXE
KPLA-14C026-JK.vbf	Multiple models (shared module)	IPC - Instrument Panel Cluster (IPC) Control Module	EXE
KPLA-14C026-KA.vbf	Multiple models (shared module)	IPC - Instrument Panel Cluster (IPC) Control Module	EXE
KPLA-14C026-KC.vbf	Multiple models (shared module)	IPC - Instrument Panel Cluster (IPC) Control Module	EXE
KPLA-14C026-KE.vbf	Multiple models (shared module)	IPC - Instrument Panel Cluster (IPC) Control Module	EXE
KPLA-14C036-AB.vbf	Multiple models (shared module)	ABS - Anti-Lock Brake System Control Module	EXE
KPLA-14C036-AD.vbf	Multiple models (shared module)	ABS - Anti-Lock Brake System Control Module	EXE
KPLA-14C036-AE.vbf	Multiple models (shared module)	ABS - Anti-Lock Brake System Control Module	EXE
KPLA-14C036-AF.vbf	Multiple models (shared module)	ABS - Anti-Lock Brake System Control Module	EXE
KPLA-14C036-AG.vbf	Multiple models (shared module)	ABS - Anti-Lock Brake System Control Module	EXE
KPLA-14C036-AH.vbf	Multiple models (shared module)	ABS - Anti-Lock Brake System Control Module	EXE
KPLA-14C036-HA.vbf	Multiple models (shared module)	ABS - Anti-Lock Brake System Control Module	EXE
KPLA-14C036-HB.vbf	Multiple models (shared module)	ABS - Anti-Lock Brake System Control Module	EXE
KPLA-14C036-HC.vbf	Multiple models (shared module)	ABS - Anti-Lock Brake System Control Module	EXE
KPLA-14C039-AB.vbf	Multiple models (shared module)	ABS - Anti-Lock Brake System Control Module	SBL
KPLA-14C039-AC.vbf	Multiple models (shared module)	ABS - Anti-Lock Brake System Control Module	SBL
KPLA-14C039-AD.vbf	Multiple models (shared module)	ABS - Anti-Lock Brake System Control Module	SBL
KPLA-14C088-JA.vbf	Multiple models (shared module)	IPC - Instrument Panel Cluster (IPC) Control Module	DATA
KPLA-14C088-JB.vbf	Multiple models (shared module)	IPC - Instrument Panel Cluster (IPC) Control Module	DATA

File name	Vehicle line (indicative)	Module (ECU)	Type
KPLA-14C088-JC.vbf	Multiple models (shared module)	IPC - Instrument Panel Cluster (IPC) Control Module	DATA
KPLA-14C088-JD.vbf	Multiple models (shared module)	IPC - Instrument Panel Cluster (IPC) Control Module	DATA
KPLA-14C088-JDX.vbf	Multiple models (shared module)	IPC - Instrument Panel Cluster (IPC) Control Module	DATA
KPLA-14C088-JE.vbf	Multiple models (shared module)	IPC - Instrument Panel Cluster (IPC) Control Module	DATA
KPLA-14C088-JF.vbf	Multiple models (shared module)	IPC - Instrument Panel Cluster (IPC) Control Module	DATA
KPLA-14C088-JJ.vbf	Multiple models (shared module)	IPC - Instrument Panel Cluster (IPC) Control Module	DATA
KPLA-14C204-NAA.vbf	Multiple models (shared module)	PCM - Powertrain Control Module	EXE
KPLA-14C204-NAB.vbf	Multiple models (shared module)	PCM - Powertrain Control Module	EXE
KPLA-14C204-PAA.vbf	Multiple models (shared module)	PCM - Powertrain Control Module	EXE
KPLA-14C204-PAB.vbf	Multiple models (shared module)	PCM - Powertrain Control Module	EXE
KPLA-14C273-PAA.vbf	Multiple models (shared module)	PCM - Powertrain Control Module	SBL
KPLA-14C408-AC.vbf	Multiple models (shared module)	BCM - Body Control Module	SIGCFG
KPLA-14C526-DA.vbf	Multiple models (shared module)	AAM - Audio Amplifier Module	EXE
KPLA-14C526-DB.vbf	Multiple models (shared module)	AAM - Audio Amplifier Module	EXE
KPLA-14C570-DGA.vbf	Multiple models (shared module)	PCM - Powertrain Control Module	EXE
KPLA-14C570-DGB.vbf	Multiple models (shared module)	PCM - Powertrain Control Module	EXE
KPLA-14C570-DGC.vbf	Multiple models (shared module)	PCM - Powertrain Control Module	EXE
KPLA-14C570-DMC.vbf	Multiple models (shared module)	PCM - Powertrain Control Module	EXE
KPLA-14C570-DME.vbf	Multiple models (shared module)	PCM - Powertrain Control Module	EXE
KPLA-14C570-DMF.vbf	Multiple models (shared module)	PCM - Powertrain Control Module	EXE
KPLA-14C570-DNA.vbf	Multiple models (shared module)	PCM - Powertrain Control Module	EXE
KPLA-14C570-DNC.vbf	Multiple models (shared module)	PCM - Powertrain Control Module	EXE
KPLA-14C570-DND.vbf	Multiple models (shared module)	PCM - Powertrain Control Module	EXE
KPLA-14C570-DNE.vbf	Multiple models (shared module)	PCM - Powertrain Control Module	EXE
KPLA-14C570-DNG.vbf	Multiple models (shared module)	PCM - Powertrain Control Module	EXE
KPLA-14C570-DNH.vbf	Multiple models (shared module)	PCM - Powertrain Control Module	EXE
KPLA-14C570-DPA.vbf	Multiple models (shared module)	PCM - Powertrain Control Module	EXE
KPLA-14C570-DPB.vbf	Multiple models (shared module)	PCM - Powertrain Control Module	EXE
KPLA-14C570-DPC.vbf	Multiple models (shared module)	PCM - Powertrain Control Module	EXE
KPLA-14C570-DPE.vbf	Multiple models (shared module)	PCM - Powertrain Control Module	EXE
KPLA-14C570-DPF.vbf	Multiple models (shared module)	PCM - Powertrain Control Module	EXE
KPLA-14C570-DRA.vbf	Multiple models (shared module)	PCM - Powertrain Control Module	EXE
KPLA-14C570-DRC.vbf	Multiple models (shared module)	PCM - Powertrain Control Module	EXE
KPLA-14C570-DRD.vbf	Multiple models (shared module)	PCM - Powertrain Control Module	EXE
KPLA-14C570-DRE.vbf	Multiple models (shared module)	PCM - Powertrain Control Module	EXE
KPLA-14C570-DRG.vbf	Multiple models (shared module)	PCM - Powertrain Control Module	EXE
KPLA-14C570-DRH.vbf	Multiple models (shared module)	PCM - Powertrain Control Module	EXE
KPLA-14C570-DRJ.vbf	Multiple models (shared module)	PCM - Powertrain Control Module	EXE
KPLA-14C570-DUA.vbf	Multiple models (shared module)	PCM - Powertrain Control Module	EXE
KPLA-14C570-DUC.vbf	Multiple models (shared module)	PCM - Powertrain Control Module	EXE
KPLA-14C570-DUD.vbf	Multiple models (shared module)	PCM - Powertrain Control Module	EXE
KPLA-14C570-DUF.vbf	Multiple models (shared module)	PCM - Powertrain Control Module	EXE
KPLA-14C570-DUG.vbf	Multiple models (shared module)	PCM - Powertrain Control Module	EXE
KPLA-14C570-SAB.vbf	Multiple models (shared module)	PCM - Powertrain Control Module	EXE
KPLA-14C570-SAC.vbf	Multiple models (shared module)	PCM - Powertrain Control Module	EXE
KPLA-14C570-SAD.vbf	Multiple models (shared module)	PCM - Powertrain Control Module	EXE
KPLA-14C570-SAE.vbf	Multiple models (shared module)	PCM - Powertrain Control Module	EXE
KPLA-14C570-SAF.vbf	Multiple models (shared module)	PCM - Powertrain Control Module	EXE
KPLA-14C570-SCC.vbf	Multiple models (shared module)	PCM - Powertrain Control Module	EXE
KPLA-14C570-SCD.vbf	Multiple models (shared module)	PCM - Powertrain Control Module	EXE
KPLA-14C570-SEC.vbf	Multiple models (shared module)	PCM - Powertrain Control Module	EXE
KPLA-14C570-SED.vbf	Multiple models (shared module)	PCM - Powertrain Control Module	EXE
KPLA-14C570-SHB.vbf	Multiple models (shared module)	PCM - Powertrain Control Module	EXE
KPLA-14C570-SHC.vbf	Multiple models (shared module)	PCM - Powertrain Control Module	EXE
KPLA-14C570-SHD.vbf	Multiple models (shared module)	PCM - Powertrain Control Module	EXE
KPLA-14C570-STC.vbf	Multiple models (shared module)	PCM - Powertrain Control Module	EXE
KPLA-14C570-STD.vbf	Multiple models (shared module)	PCM - Powertrain Control Module	EXE
KPLA-14C570-UAC.vbf	Multiple models (shared module)	PCM - Powertrain Control Module	EXE
KPLA-14C570-UAE.vbf	Multiple models (shared module)	PCM - Powertrain Control Module	EXE
KPLA-14C570-UAF.vbf	Multiple models (shared module)	PCM - Powertrain Control Module	EXE
KPLA-14C570-UCC.vbf	Multiple models (shared module)	PCM - Powertrain Control Module	EXE
KPLA-14C570-UCD.vbf	Multiple models (shared module)	PCM - Powertrain Control Module	EXE
KPLA-14C570-UEC.vbf	Multiple models (shared module)	PCM - Powertrain Control Module	EXE
KPLA-14C570-UED.vbf	Multiple models (shared module)	PCM - Powertrain Control Module	EXE
KPLA-14C570-UFC.vbf	Multiple models (shared module)	PCM - Powertrain Control Module	EXE
KPLA-14C570-UFD.vbf	Multiple models (shared module)	PCM - Powertrain Control Module	EXE
KPLA-14C570-UFE.vbf	Multiple models (shared module)	PCM - Powertrain Control Module	EXE
KPLA-14C570-UFF.vbf	Multiple models (shared module)	PCM - Powertrain Control Module	EXE
KPLA-14C570-UTC.vbf	Multiple models (shared module)	PCM - Powertrain Control Module	EXE
KPLA-14C570-UTD.vbf	Multiple models (shared module)	PCM - Powertrain Control Module	EXE
KPLA-14E093-JA.vbf	Multiple models (shared module)	CHCM - Chassis Control Module	EXE
KPLA-14E093-JB.vbf	Multiple models (shared module)	CHCM - Chassis Control Module	EXE
KPLA-14E093-JC.vbf	Multiple models (shared module)	CHCM - Chassis Control Module	EXE
KPLA-14E093-JD.vbf	Multiple models (shared module)	CHCM - Chassis Control Module	EXE
KPLA-14E093-JE.vbf	Multiple models (shared module)	CHCM - Chassis Control Module	EXE
KPLA-14E093-JF.vbf	Multiple models (shared module)	CHCM - Chassis Control Module	EXE

File name	Vehicle line (indicative)	Module (ECU)	Type
KPLA-14E093-JG.vbf	Multiple models (shared module)	CHCM - Chassis Control Module	EXE
KPLA-14F397-AA.vbf	Multiple models (shared module)	IPMA - Image Processing Module A	EXE
KPLA-14F397-AB.vbf	Multiple models (shared module)	IPMA - Image Processing Module A	EXE
KPLA-14F397-AC.vbf	Multiple models (shared module)	IPMA - Image Processing Module A	EXE
KPLA-14F397-AD.vbf	Multiple models (shared module)	IPMA - Image Processing Module A	EXE
KPLA-14F397-BA.vbf	Multiple models (shared module)	IPMA - Image Processing Module A	EXE
KPLA-14F397-BB.vbf	Multiple models (shared module)	IPMA - Image Processing Module A	EXE
KPLA-14F397-BC.vbf	Multiple models (shared module)	IPMA - Image Processing Module A	EXE
KPLA-14F397-BD.vbf	Multiple models (shared module)	IPMA - Image Processing Module A	EXE
KPLA-14F397-CA.vbf	Multiple models (shared module)	IPMA - Image Processing Module A	EXE
KPLA-14F397-CB.vbf	Multiple models (shared module)	IPMA - Image Processing Module A	EXE
KPLA-14F397-CC.vbf	Multiple models (shared module)	IPMA - Image Processing Module A	EXE
KPLA-14F397-CD.vbf	Multiple models (shared module)	IPMA - Image Processing Module A	EXE
KPLA-14F397-DA.vbf	Multiple models (shared module)	IPMA - Image Processing Module A	EXE
KPLA-14F397-DB.vbf	Multiple models (shared module)	IPMA - Image Processing Module A	EXE
KPLA-14F397-DC.vbf	Multiple models (shared module)	IPMA - Image Processing Module A	EXE
KPLA-14F397-DD.vbf	Multiple models (shared module)	IPMA - Image Processing Module A	EXE
KPLA-14F397-EA.vbf	Multiple models (shared module)	IPMA - Image Processing Module A	EXE
KPLA-14F397-EB.vbf	Multiple models (shared module)	IPMA - Image Processing Module A	EXE
KPLA-14F397-EC.vbf	Multiple models (shared module)	IPMA - Image Processing Module A	EXE
KPLA-14F397-ED.vbf	Multiple models (shared module)	IPMA - Image Processing Module A	EXE
KPLA-14F397-FA.vbf	Multiple models (shared module)	IPMA - Image Processing Module A	EXE
KPLA-14F397-FB.vbf	Multiple models (shared module)	IPMA - Image Processing Module A	EXE
KPLA-14F397-FC.vbf	Multiple models (shared module)	IPMA - Image Processing Module A	EXE
KPLA-14F397-FD.vbf	Multiple models (shared module)	IPMA - Image Processing Module A	EXE
KPLA-14F398-AA.vbf	Multiple models (shared module)	IPMA - Image Processing Module A	EXE
KPLA-14F398-AB.vbf	Multiple models (shared module)	IPMA - Image Processing Module A	EXE
KPLA-14F398-AC.vbf	Multiple models (shared module)	IPMA - Image Processing Module A	EXE
KPLA-14F398-AD.vbf	Multiple models (shared module)	IPMA - Image Processing Module A	EXE
KPLA-14F398-BA.vbf	Multiple models (shared module)	IPMA - Image Processing Module A	EXE
KPLA-14F398-BB.vbf	Multiple models (shared module)	IPMA - Image Processing Module A	EXE
KPLA-14F398-BC.vbf	Multiple models (shared module)	IPMA - Image Processing Module A	EXE
KPLA-14F398-BD.vbf	Multiple models (shared module)	IPMA - Image Processing Module A	EXE
KPLA-14F398-CA.vbf	Multiple models (shared module)	IPMA - Image Processing Module A	EXE
KPLA-14F398-CB.vbf	Multiple models (shared module)	IPMA - Image Processing Module A	EXE
KPLA-14F398-CC.vbf	Multiple models (shared module)	IPMA - Image Processing Module A	EXE
KPLA-14F398-CD.vbf	Multiple models (shared module)	IPMA - Image Processing Module A	EXE
KPLA-14F434-NA.vbf	Multiple models (shared module)	CHCMB - Chassis Control Module B	EXE
KPLA-14F434-NB.vbf	Multiple models (shared module)	CHCMB - Chassis Control Module B	EXE
KPLA-14F434-NC.vbf	Multiple models (shared module)	CHCMB - Chassis Control Module B	EXE
KPLA-14F434-ND.vbf	Multiple models (shared module)	CHCMB - Chassis Control Module B	EXE
KPLA-14F434-NE.vbf	Multiple models (shared module)	CHCMB - Chassis Control Module B	EXE
KPLA-14F532-BA.vbf	Multiple models (shared module)	GWM - Gateway Module A	SBL
KPLA-18D619-AA.vbf	Multiple models (shared module)	HVAC - HVAC Control Module	EXE
KPLA-7J244-AA.vbf	Multiple models (shared module)	TCM - Transmission Control Module	SBL
KPLA-7J244-AC.vbf	Multiple models (shared module)	TCM - Transmission Control Module	SBL
KPLA-7J244-AD.vbf	Multiple models (shared module)	TCM - Transmission Control Module	SBL
KW93-12K532-PYB.vbf	Jaguar XJ (X351)	PCM - Powertrain Control Module	DATA
KW93-12K532-PYC.vbf	Jaguar XJ (X351)	PCM - Powertrain Control Module	DATA
KW93-14C026-AA.vbf	Jaguar XJ (X351)	IPC - Instrument Panel Cluster (IPC) Control Module	EXE
KW93-14C026-AB.vbf	Jaguar XJ (X351)	IPC - Instrument Panel Cluster (IPC) Control Module	EXE
KW93-14C026-BA.vbf	Jaguar XJ (X351)	IPC - Instrument Panel Cluster (IPC) Control Module	EXE
KW93-14C026-BB.vbf	Jaguar XJ (X351)	IPC - Instrument Panel Cluster (IPC) Control Module	EXE
KW93-14C026-MA.vbf	Jaguar XJ (X351)	IPC - Instrument Panel Cluster (IPC) Control Module	EXE
KW93-14C026-MB.vbf	Jaguar XJ (X351)	IPC - Instrument Panel Cluster (IPC) Control Module	EXE
KW93-14C088-AA.vbf	Jaguar XJ (X351)	IPC - Instrument Panel Cluster (IPC) Control Module	DATA
KW93-14C088-AB.vbf	Jaguar XJ (X351)	IPC - Instrument Panel Cluster (IPC) Control Module	DATA
KW93-14C204-PAB.vbf	Jaguar XJ (X351)	PCM - Powertrain Control Module	EXE
KW93-14C204-TFB.vbf	Jaguar XJ (X351)	PCM - Powertrain Control Module	EXE
KW93-14C204-TFC.vbf	Jaguar XJ (X351)	PCM - Powertrain Control Module	EXE
KW93-14F397-AA.vbf	Jaguar XJ (X351)	IPMA - Image Processing Module A	EXE
KW93-14F397-BA.vbf	Jaguar XJ (X351)	IPMA - Image Processing Module A	EXE
KW93-14F397-CA.vbf	Jaguar XJ (X351)	IPMA - Image Processing Module A	EXE
KW93-14F397-DA.vbf	Jaguar XJ (X351)	IPMA - Image Processing Module A	EXE
KW93-14F398-AA.vbf	Jaguar XJ (X351)	IPMA - Image Processing Module A	EXE
KW93-14F398-BA.vbf	Jaguar XJ (X351)	IPMA - Image Processing Module A	EXE
KW93-14F531-AA.vbf	Jaguar XJ (X351)	GWM - Gateway Module A	DATA
KW93-7J104-BCA.vbf	Jaguar XJ (X351)	TCM - Transmission Control Module	EXE
KW93-7J104-BCB.vbf	Jaguar XJ (X351)	TCM - Transmission Control Module	EXE
KW93-7J104-BCC.vbf	Jaguar XJ (X351)	TCM - Transmission Control Module	EXE
KW93-7J104-BCD.vbf	Jaguar XJ (X351)	TCM - Transmission Control Module	EXE
KX53-14C025-AB.vbf	Jaguar F-Type (X152)	IPC - Instrument Panel Cluster (IPC) Control Module	SBL
KX53-14C026-AA.vbf	Jaguar F-Type (X152)	IPC - Instrument Panel Cluster (IPC) Control Module	EXE
KX53-14C026-AC.vbf	Jaguar F-Type (X152)	IPC - Instrument Panel Cluster (IPC) Control Module	EXE
KX53-14C088-BB.vbf	Jaguar F-Type (X152)	IPC - Instrument Panel Cluster (IPC) Control Module	DATA
KX53-14C088-CA.vbf	Jaguar F-Type (X152)	IPC - Instrument Panel Cluster (IPC) Control Module	EXE

File name	Vehicle line (indicative)	Module (ECU)	Type
KX53-14C088-CB.vbf	Jaguar F-Type (X152)	IPC - Instrument Panel Cluster (IPC) Control Module	EXE
KX53-14C526-BA.vbf	Jaguar F-Type (X152)	AAM - Audio Amplifier Module	EXE
KX53-14C526-CA.vbf	Jaguar F-Type (X152)	AAM - Audio Amplifier Module	EXE
KX53-14C526-CB.vbf	Jaguar F-Type (X152)	AAM - Audio Amplifier Module	EXE
KX53-14C527-BA.vbf	Jaguar F-Type (X152)	AAM - Audio Amplifier Module	DATA
KX53-14C527-BAA.vbf	Jaguar F-Type (X152)	AAM - Audio Amplifier Module	DATA
KX53-14C527-BAB.vbf	Jaguar F-Type (X152)	AAM - Audio Amplifier Module	DATA
KX53-14C527-BAC.vbf	Jaguar F-Type (X152)	AAM - Audio Amplifier Module	DATA
KX53-14C527-BB.vbf	Jaguar F-Type (X152)	AAM - Audio Amplifier Module	DATA
KX53-14C527-BBA.vbf	Jaguar F-Type (X152)	AAM - Audio Amplifier Module	DATA
KX53-14C527-BBB.vbf	Jaguar F-Type (X152)	AAM - Audio Amplifier Module	DATA
KX53-14C527-BC.vbf	Jaguar F-Type (X152)	AAM - Audio Amplifier Module	DATA
KX53-14C527-BCA.vbf	Jaguar F-Type (X152)	AAM - Audio Amplifier Module	DATA
KX53-14C527-BCB.vbf	Jaguar F-Type (X152)	AAM - Audio Amplifier Module	DATA
KX53-14C527-BD.vbf	Jaguar F-Type (X152)	AAM - Audio Amplifier Module	DATA
KX53-14C527-BDA.vbf	Jaguar F-Type (X152)	AAM - Audio Amplifier Module	DATA
KX53-14C527-BDB.vbf	Jaguar F-Type (X152)	AAM - Audio Amplifier Module	DATA
KX53-14C527-BEA.vbf	Jaguar F-Type (X152)	AAM - Audio Amplifier Module	DATA
KX53-14C527-BEB.vbf	Jaguar F-Type (X152)	AAM - Audio Amplifier Module	DATA
KX53-14C527-BEC.vbf	Jaguar F-Type (X152)	AAM - Audio Amplifier Module	DATA
KX53-14C527-CA.vbf	Jaguar F-Type (X152)	AAM - Audio Amplifier Module	DATA
KX53-14C527-CAA.vbf	Jaguar F-Type (X152)	AAM - Audio Amplifier Module	DATA
KX53-14C527-CAB.vbf	Jaguar F-Type (X152)	AAM - Audio Amplifier Module	DATA
KX53-14C527-CAC.vbf	Jaguar F-Type (X152)	AAM - Audio Amplifier Module	DATA
KX53-14C527-CB.vbf	Jaguar F-Type (X152)	AAM - Audio Amplifier Module	DATA
KX53-14C527-CBA.vbf	Jaguar F-Type (X152)	AAM - Audio Amplifier Module	DATA
KX53-14C527-CBB.vbf	Jaguar F-Type (X152)	AAM - Audio Amplifier Module	DATA
KX53-14C527-CBC.vbf	Jaguar F-Type (X152)	AAM - Audio Amplifier Module	DATA
KX53-14C527-CBD.vbf	Jaguar F-Type (X152)	AAM - Audio Amplifier Module	DATA
KX53-14C527-CC.vbf	Jaguar F-Type (X152)	AAM - Audio Amplifier Module	DATA
KX53-14C527-CCA.vbf	Jaguar F-Type (X152)	AAM - Audio Amplifier Module	DATA
KX53-14C527-CCB.vbf	Jaguar F-Type (X152)	AAM - Audio Amplifier Module	DATA
KX53-14C527-CD.vbf	Jaguar F-Type (X152)	AAM - Audio Amplifier Module	DATA
KX53-14C527-CDA.vbf	Jaguar F-Type (X152)	AAM - Audio Amplifier Module	DATA
KX53-14C527-CDB.vbf	Jaguar F-Type (X152)	AAM - Audio Amplifier Module	DATA
KX53-14C527-CEA.vbf	Jaguar F-Type (X152)	AAM - Audio Amplifier Module	DATA
KX53-14C527-CEB.vbf	Jaguar F-Type (X152)	AAM - Audio Amplifier Module	DATA
KX53-14C527-CEC.vbf	Jaguar F-Type (X152)	AAM - Audio Amplifier Module	DATA
KX53-14C527-FA.vbf	Jaguar F-Type (X152)	AAM - Audio Amplifier Module	DATA
KX53-14C527-FAA.vbf	Jaguar F-Type (X152)	AAM - Audio Amplifier Module	DATA
KX53-14C527-FAB.vbf	Jaguar F-Type (X152)	AAM - Audio Amplifier Module	DATA
KX53-14C527-FB.vbf	Jaguar F-Type (X152)	AAM - Audio Amplifier Module	DATA
KX53-14C527-FBA.vbf	Jaguar F-Type (X152)	AAM - Audio Amplifier Module	DATA
KX53-14C527-FBB.vbf	Jaguar F-Type (X152)	AAM - Audio Amplifier Module	DATA
KX53-14C527-FC.vbf	Jaguar F-Type (X152)	AAM - Audio Amplifier Module	DATA
KX53-14C527-FCA.vbf	Jaguar F-Type (X152)	AAM - Audio Amplifier Module	DATA
KX53-14C527-FCB.vbf	Jaguar F-Type (X152)	AAM - Audio Amplifier Module	DATA
KX53-14C527-FD.vbf	Jaguar F-Type (X152)	AAM - Audio Amplifier Module	DATA
KX53-14C527-FDA.vbf	Jaguar F-Type (X152)	AAM - Audio Amplifier Module	DATA
KX53-14C527-FDB.vbf	Jaguar F-Type (X152)	AAM - Audio Amplifier Module	DATA
KX53-14C527-FEA.vbf	Jaguar F-Type (X152)	AAM - Audio Amplifier Module	DATA
KX53-14C527-FEB.vbf	Jaguar F-Type (X152)	AAM - Audio Amplifier Module	DATA
KX53-14C527-FEC.vbf	Jaguar F-Type (X152)	AAM - Audio Amplifier Module	DATA
KX53-14C527-GA.vbf	Jaguar F-Type (X152)	AAM - Audio Amplifier Module	DATA
KX53-14C527-GAA.vbf	Jaguar F-Type (X152)	AAM - Audio Amplifier Module	DATA
KX53-14C527-GAB.vbf	Jaguar F-Type (X152)	AAM - Audio Amplifier Module	DATA
KX53-14C527-GB.vbf	Jaguar F-Type (X152)	AAM - Audio Amplifier Module	DATA
KX53-14C527-GBA.vbf	Jaguar F-Type (X152)	AAM - Audio Amplifier Module	DATA
KX53-14C527-GBB.vbf	Jaguar F-Type (X152)	AAM - Audio Amplifier Module	DATA
KX53-14C527-GC.vbf	Jaguar F-Type (X152)	AAM - Audio Amplifier Module	DATA
KX53-14C527-GCA.vbf	Jaguar F-Type (X152)	AAM - Audio Amplifier Module	DATA
KX53-14C527-GCB.vbf	Jaguar F-Type (X152)	AAM - Audio Amplifier Module	DATA
KX53-14C527-GDA.vbf	Jaguar F-Type (X152)	AAM - Audio Amplifier Module	DATA
KX53-14C527-GDB.vbf	Jaguar F-Type (X152)	AAM - Audio Amplifier Module	DATA
KX53-14C527-GEA.vbf	Jaguar F-Type (X152)	AAM - Audio Amplifier Module	DATA
KX53-14C527-GEB.vbf	Jaguar F-Type (X152)	AAM - Audio Amplifier Module	DATA
KX53-14C527-GEC.vbf	Jaguar F-Type (X152)	AAM - Audio Amplifier Module	DATA
KX53-14C527-JA.vbf	Jaguar F-Type (X152)	AAM - Audio Amplifier Module	DATA
KX53-14C527-JB.vbf	Jaguar F-Type (X152)	AAM - Audio Amplifier Module	DATA
KX53-14C527-JC.vbf	Jaguar F-Type (X152)	AAM - Audio Amplifier Module	DATA
KX53-14C527-JD.vbf	Jaguar F-Type (X152)	AAM - Audio Amplifier Module	DATA
KX53-14C527-KA.vbf	Jaguar F-Type (X152)	AAM - Audio Amplifier Module	DATA
KX53-14C527-KB.vbf	Jaguar F-Type (X152)	AAM - Audio Amplifier Module	DATA
KX53-14C535-AA.vbf	Jaguar F-Type (X152)	FCIM - Front Controls Interface Module	EXE
KX53-14C536-AA.vbf	Jaguar F-Type (X152)	FCIM - Front Controls Interface Module	DATA
KX53-14C570-AAB.vbf	Jaguar F-Type (X152)	PCM - Powertrain Control Module	EXE

File name	Vehicle line (indicative)	Module (ECU)	Type
KX53-14C570-AAC.vbf	Jaguar F-Type (X152)	PCM - Powertrain Control Module	EXE
KX53-14C570-ACB.vbf	Jaguar F-Type (X152)	PCM - Powertrain Control Module	EXE
KX53-14C570-ACC.vbf	Jaguar F-Type (X152)	PCM - Powertrain Control Module	EXE
KX53-14C570-ADC.vbf	Jaguar F-Type (X152)	PCM - Powertrain Control Module	EXE
KX53-14C570-ADD.vbf	Jaguar F-Type (X152)	PCM - Powertrain Control Module	EXE
KX53-14C570-AHA.vbf	Jaguar F-Type (X152)	PCM - Powertrain Control Module	EXE
KX53-14C570-AHC.vbf	Jaguar F-Type (X152)	PCM - Powertrain Control Module	EXE
KX53-14C570-ATB.vbf	Jaguar F-Type (X152)	PCM - Powertrain Control Module	EXE
KX53-14C570-ATC.vbf	Jaguar F-Type (X152)	PCM - Powertrain Control Module	EXE
KX53-14C570-BGC.vbf	Jaguar F-Type (X152)	PCM - Powertrain Control Module	EXE
KX53-14C570-BGE.vbf	Jaguar F-Type (X152)	PCM - Powertrain Control Module	EXE
KX53-14C570-BGF.vbf	Jaguar F-Type (X152)	PCM - Powertrain Control Module	EXE
KX53-14C570-BLK.vbf	Jaguar F-Type (X152)	PCM - Powertrain Control Module	EXE
KX53-14C570-BNE.vbf	Jaguar F-Type (X152)	PCM - Powertrain Control Module	EXE
KX53-14C570-BPC.vbf	Jaguar F-Type (X152)	PCM - Powertrain Control Module	EXE
KX53-14C570-BPD.vbf	Jaguar F-Type (X152)	PCM - Powertrain Control Module	EXE
KX53-14C570-BPE.vbf	Jaguar F-Type (X152)	PCM - Powertrain Control Module	EXE
KX53-14C570-BPG.vbf	Jaguar F-Type (X152)	PCM - Powertrain Control Module	EXE
KX53-14C570-BPH.vbf	Jaguar F-Type (X152)	PCM - Powertrain Control Module	EXE
KX53-14C570-BRA.vbf	Jaguar F-Type (X152)	PCM - Powertrain Control Module	EXE
KX53-14C570-BRB.vbf	Jaguar F-Type (X152)	PCM - Powertrain Control Module	EXE
KX53-14C570-BRC.vbf	Jaguar F-Type (X152)	PCM - Powertrain Control Module	EXE
KX53-14C570-BRD.vbf	Jaguar F-Type (X152)	PCM - Powertrain Control Module	EXE
KX53-14C570-BRE.vbf	Jaguar F-Type (X152)	PCM - Powertrain Control Module	EXE
KX53-14C570-BRG.vbf	Jaguar F-Type (X152)	PCM - Powertrain Control Module	EXE
KX53-14C570-BUE.vbf	Jaguar F-Type (X152)	PCM - Powertrain Control Module	EXE
KX53-14C570-CAB.vbf	Jaguar F-Type (X152)	PCM - Powertrain Control Module	EXE
KX53-14C570-CAC.vbf	Jaguar F-Type (X152)	PCM - Powertrain Control Module	EXE
KX53-14C570-CCB.vbf	Jaguar F-Type (X152)	PCM - Powertrain Control Module	EXE
KX53-14C570-CCC.vbf	Jaguar F-Type (X152)	PCM - Powertrain Control Module	EXE
KX53-14C570-CHB.vbf	Jaguar F-Type (X152)	PCM - Powertrain Control Module	EXE
KX53-14C570-CHC.vbf	Jaguar F-Type (X152)	PCM - Powertrain Control Module	EXE
KX53-14C570-CTB.vbf	Jaguar F-Type (X152)	PCM - Powertrain Control Module	EXE
KX53-14C570-CTC.vbf	Jaguar F-Type (X152)	PCM - Powertrain Control Module	EXE
KX53-14C570-CTD.vbf	Jaguar F-Type (X152)	PCM - Powertrain Control Module	EXE
KX53-14C570-PAA.vbf	Jaguar F-Type (X152)	PCM - Powertrain Control Module	EXE
KX53-14C570-PAB.vbf	Jaguar F-Type (X152)	PCM - Powertrain Control Module	EXE
KX53-14C570-PCA.vbf	Jaguar F-Type (X152)	PCM - Powertrain Control Module	EXE
KX53-14C570-PEA.vbf	Jaguar F-Type (X152)	PCM - Powertrain Control Module	EXE
KX53-14C570-PHA.vbf	Jaguar F-Type (X152)	PCM - Powertrain Control Module	EXE
KX53-14C570-PTA.vbf	Jaguar F-Type (X152)	PCM - Powertrain Control Module	EXE
KX53-14C570-SAA.vbf	Jaguar F-Type (X152)	PCM - Powertrain Control Module	EXE
KX53-14C570-SAB.vbf	Jaguar F-Type (X152)	PCM - Powertrain Control Module	EXE
KX53-14C570-SAC.vbf	Jaguar F-Type (X152)	PCM - Powertrain Control Module	EXE
KX53-14C570-SAD.vbf	Jaguar F-Type (X152)	PCM - Powertrain Control Module	EXE
KX53-14C570-SCA.vbf	Jaguar F-Type (X152)	PCM - Powertrain Control Module	EXE
KX53-14C570-SCC.vbf	Jaguar F-Type (X152)	PCM - Powertrain Control Module	EXE
KX53-14C570-SEC.vbf	Jaguar F-Type (X152)	PCM - Powertrain Control Module	EXE
KX53-14C570-SHA.vbf	Jaguar F-Type (X152)	PCM - Powertrain Control Module	EXE
KX53-14C570-SHB.vbf	Jaguar F-Type (X152)	PCM - Powertrain Control Module	EXE
KX53-14C570-SHC.vbf	Jaguar F-Type (X152)	PCM - Powertrain Control Module	EXE
KX53-14C570-STB.vbf	Jaguar F-Type (X152)	PCM - Powertrain Control Module	EXE
KX53-14C570-STC.vbf	Jaguar F-Type (X152)	PCM - Powertrain Control Module	EXE
KX53-14C570-TAB.vbf	Jaguar F-Type (X152)	PCM - Powertrain Control Module	EXE
KX53-14C570-TAC.vbf	Jaguar F-Type (X152)	PCM - Powertrain Control Module	EXE
KX53-14C570-TAD.vbf	Jaguar F-Type (X152)	PCM - Powertrain Control Module	EXE
KX53-14C570-TCB.vbf	Jaguar F-Type (X152)	PCM - Powertrain Control Module	EXE
KX53-14C570-TCC.vbf	Jaguar F-Type (X152)	PCM - Powertrain Control Module	EXE
KX53-14C570-TCD.vbf	Jaguar F-Type (X152)	PCM - Powertrain Control Module	EXE
KX53-14C570-TEB.vbf	Jaguar F-Type (X152)	PCM - Powertrain Control Module	EXE
KX53-14C570-TEC.vbf	Jaguar F-Type (X152)	PCM - Powertrain Control Module	EXE
KX53-14C570-TED.vbf	Jaguar F-Type (X152)	PCM - Powertrain Control Module	EXE
KX53-14C570-TFB.vbf	Jaguar F-Type (X152)	PCM - Powertrain Control Module	EXE
KX53-14C570-TFC.vbf	Jaguar F-Type (X152)	PCM - Powertrain Control Module	EXE
KX53-14C570-TFD.vbf	Jaguar F-Type (X152)	PCM - Powertrain Control Module	EXE
KX53-14C570-THB.vbf	Jaguar F-Type (X152)	PCM - Powertrain Control Module	EXE
KX53-14C570-THC.vbf	Jaguar F-Type (X152)	PCM - Powertrain Control Module	EXE
KX53-14C570-THD.vbf	Jaguar F-Type (X152)	PCM - Powertrain Control Module	EXE
KX53-14C570-TTB.vbf	Jaguar F-Type (X152)	PCM - Powertrain Control Module	EXE
KX53-14C570-TTC.vbf	Jaguar F-Type (X152)	PCM - Powertrain Control Module	EXE
KX53-14C570-TTD.vbf	Jaguar F-Type (X152)	PCM - Powertrain Control Module	EXE
KX53-14C570-TTE.vbf	Jaguar F-Type (X152)	PCM - Powertrain Control Module	EXE
KX53-14C570-UAA.vbf	Jaguar F-Type (X152)	PCM - Powertrain Control Module	EXE
KX53-14C570-UAB.vbf	Jaguar F-Type (X152)	PCM - Powertrain Control Module	EXE
KX53-14C570-UAC.vbf	Jaguar F-Type (X152)	PCM - Powertrain Control Module	EXE
KX53-14C570-UCB.vbf	Jaguar F-Type (X152)	PCM - Powertrain Control Module	EXE

File name	Vehicle line (indicative)	Module (ECU)	Type
KX53-14C570-UCC.vbf	Jaguar F-Type (X152)	PCM - Powertrain Control Module	EXE
KX53-14C570-UEB.vbf	Jaguar F-Type (X152)	PCM - Powertrain Control Module	EXE
KX53-14C570-UEC.vbf	Jaguar F-Type (X152)	PCM - Powertrain Control Module	EXE
KX53-14C570-UHA.vbf	Jaguar F-Type (X152)	PCM - Powertrain Control Module	EXE
KX53-14C570-UHB.vbf	Jaguar F-Type (X152)	PCM - Powertrain Control Module	EXE
KX53-14C570-UHC.vbf	Jaguar F-Type (X152)	PCM - Powertrain Control Module	EXE
KX53-14C570-UTB.vbf	Jaguar F-Type (X152)	PCM - Powertrain Control Module	EXE
KX53-14C570-UTC.vbf	Jaguar F-Type (X152)	PCM - Powertrain Control Module	EXE
KX53-14C570-UTD.vbf	Jaguar F-Type (X152)	PCM - Powertrain Control Module	EXE
KX53-14C570-XAB.vbf	Jaguar F-Type (X152)	PCM - Powertrain Control Module	EXE
KX53-14C570-XAC.vbf	Jaguar F-Type (X152)	PCM - Powertrain Control Module	EXE
KX53-14C570-XAD.vbf	Jaguar F-Type (X152)	PCM - Powertrain Control Module	EXE
KX53-14C570-XCB.vbf	Jaguar F-Type (X152)	PCM - Powertrain Control Module	EXE
KX53-14C570-XCC.vbf	Jaguar F-Type (X152)	PCM - Powertrain Control Module	EXE
KX53-14C570-XCD.vbf	Jaguar F-Type (X152)	PCM - Powertrain Control Module	EXE
KX53-14C570-XHB.vbf	Jaguar F-Type (X152)	PCM - Powertrain Control Module	EXE
KX53-14C570-XHC.vbf	Jaguar F-Type (X152)	PCM - Powertrain Control Module	EXE
KX53-14C570-XHD.vbf	Jaguar F-Type (X152)	PCM - Powertrain Control Module	EXE
KX53-14C570-XTB.vbf	Jaguar F-Type (X152)	PCM - Powertrain Control Module	EXE
KX53-14C570-XTC.vbf	Jaguar F-Type (X152)	PCM - Powertrain Control Module	EXE
KX53-14C570-XTD.vbf	Jaguar F-Type (X152)	PCM - Powertrain Control Module	EXE
KX53-14D485-AA.vbf	Jaguar F-Type (X152)	IPMB - Image Processing Module B	EXE
KX53-14D485-AB.vbf	Jaguar F-Type (X152)	IPMB - Image Processing Module B	EXE
KX53-14D485-AC.vbf	Jaguar F-Type (X152)	IPMB - Image Processing Module B	EXE
KX53-14F530-BA.vbf	Jaguar F-Type (X152)	GWM - Gateway Module A	EXE
KX53-14F530-BB.vbf	Jaguar F-Type (X152)	GWM - Gateway Module A	EXE
KX53-14F531-BA.vbf	Jaguar F-Type (X152)	GWM - Gateway Module A	DATA
KX53-14F531-BB.vbf	Jaguar F-Type (X152)	GWM - Gateway Module A	DATA
KX53-14F531-BC.vbf	Jaguar F-Type (X152)	GWM - Gateway Module A	DATA
KX53-19C204-AA.vbf	Jaguar F-Type (X152)	IMC - Infotainment Master Controller	EXE
KX53-7J104-BKA.vbf	Jaguar F-Type (X152)	TCM - Transmission Control Module	EXE
KX53-7J104-BKB.vbf	Jaguar F-Type (X152)	TCM - Transmission Control Module	EXE
KX53-7J104-BKD.vbf	Jaguar F-Type (X152)	TCM - Transmission Control Module	EXE
KX53-7J104-BKE.vbf	Jaguar F-Type (X152)	TCM - Transmission Control Module	EXE
KX53-7J104-BVA.vbf	Jaguar F-Type (X152)	TCM - Transmission Control Module	EXE
KX53-7J104-BXA.vbf	Jaguar F-Type (X152)	TCM - Transmission Control Module	EXE
KX53-7J104-MDB.vbf	Jaguar F-Type (X152)	TCM - Transmission Control Module	EXE
KX53-7J104-MDC.vbf	Jaguar F-Type (X152)	TCM - Transmission Control Module	EXE
KX53-7J104-MDD.vbf	Jaguar F-Type (X152)	TCM - Transmission Control Module	EXE
KX53-7J104-MMB.vbf	Jaguar F-Type (X152)	TCM - Transmission Control Module	EXE
KX53-7J104-MMC.vbf	Jaguar F-Type (X152)	TCM - Transmission Control Module	EXE
KX53-7J104-MVA.vbf	Jaguar F-Type (X152)	TCM - Transmission Control Module	EXE
KX53-7J104-MXA.vbf	Jaguar F-Type (X152)	TCM - Transmission Control Module	EXE
KX5M-7J104-BNA.vbf	Not specified	TCM - Transmission Control Module	EXE
KX5M-7J104-BNB.vbf	Not specified	TCM - Transmission Control Module	EXE
KX5M-7J104-BND.vbf	Not specified	TCM - Transmission Control Module	EXE
KX5M-7J104-BNE.vbf	Not specified	TCM - Transmission Control Module	EXE
KX63-12K532-FBA.vbf	Jaguar XF (X260)	PCM - Powertrain Control Module	DATA
KX63-12K532-FBB.vbf	Jaguar XF (X260)	PCM - Powertrain Control Module	EXE
KX63-12K532-FBC.vbf	Jaguar XF (X260)	PCM - Powertrain Control Module	EXE
KX63-12K532-FBD.vbf	Jaguar XF (X260)	PCM - Powertrain Control Module	EXE
KX63-12K532-FBE.vbf	Jaguar XF (X260)	PCM - Powertrain Control Module	EXE
KX63-12K532-FBF.vbf	Jaguar XF (X260)	PCM - Powertrain Control Module	EXE
KX63-12K532-FBG.vbf	Jaguar XF (X260)	PCM - Powertrain Control Module	EXE
KX63-12K532-FBH.vbf	Jaguar XF (X260)	PCM - Powertrain Control Module	EXE
KX63-12K532-FCA.vbf	Jaguar XF (X260)	PCM - Powertrain Control Module	DATA
KX63-12K532-FCB.vbf	Jaguar XF (X260)	PCM - Powertrain Control Module	EXE
KX63-12K532-FCC.vbf	Jaguar XF (X260)	PCM - Powertrain Control Module	EXE
KX63-12K532-FCD.vbf	Jaguar XF (X260)	PCM - Powertrain Control Module	EXE
KX63-12K532-FCE.vbf	Jaguar XF (X260)	PCM - Powertrain Control Module	EXE
KX63-12K532-FCF.vbf	Jaguar XF (X260)	PCM - Powertrain Control Module	EXE
KX63-12K532-FCG.vbf	Jaguar XF (X260)	PCM - Powertrain Control Module	EXE
KX63-12K532-FCH.vbf	Jaguar XF (X260)	PCM - Powertrain Control Module	EXE
KX63-12K532-FDA.vbf	Jaguar XF (X260)	PCM - Powertrain Control Module	DATA
KX63-12K532-FDB.vbf	Jaguar XF (X260)	PCM - Powertrain Control Module	EXE
KX63-12K532-FDC.vbf	Jaguar XF (X260)	PCM - Powertrain Control Module	EXE
KX63-12K532-FDD.vbf	Jaguar XF (X260)	PCM - Powertrain Control Module	EXE
KX63-12K532-FDE.vbf	Jaguar XF (X260)	PCM - Powertrain Control Module	EXE
KX63-12K532-FDF.vbf	Jaguar XF (X260)	PCM - Powertrain Control Module	EXE
KX63-12K532-FDG.vbf	Jaguar XF (X260)	PCM - Powertrain Control Module	EXE
KX63-12K532-FDH.vbf	Jaguar XF (X260)	PCM - Powertrain Control Module	EXE
KX63-12K532-FEA.vbf	Jaguar XF (X260)	PCM - Powertrain Control Module	DATA
KX63-12K532-FEB.vbf	Jaguar XF (X260)	PCM - Powertrain Control Module	EXE
KX63-12K532-FEC.vbf	Jaguar XF (X260)	PCM - Powertrain Control Module	EXE
KX63-12K532-FED.vbf	Jaguar XF (X260)	PCM - Powertrain Control Module	EXE
KX63-12K532-FEE.vbf	Jaguar XF (X260)	PCM - Powertrain Control Module	EXE

File name	Vehicle line (indicative)	Module (ECU)	Type
KX63-12K532-FEF.vbf	Jaguar XF (X260)	PCM - Powertrain Control Module	EXE
KX63-12K532-FEG.vbf	Jaguar XF (X260)	PCM - Powertrain Control Module	EXE
KX63-12K532-FEH.vbf	Jaguar XF (X260)	PCM - Powertrain Control Module	EXE
KX63-12K532-FFA.vbf	Jaguar XF (X260)	PCM - Powertrain Control Module	EXE
KX63-12K532-FGA.vbf	Jaguar XF (X260)	PCM - Powertrain Control Module	EXE
KX63-12K532-FHA.vbf	Jaguar XF (X260)	PCM - Powertrain Control Module	EXE
KX63-12K532-FHB.vbf	Jaguar XF (X260)	PCM - Powertrain Control Module	EXE
KX63-12K532-FJA.vbf	Jaguar XF (X260)	PCM - Powertrain Control Module	EXE
KX63-12K532-FJB.vbf	Jaguar XF (X260)	PCM - Powertrain Control Module	EXE
KX63-12K532-FKA.vbf	Jaguar XF (X260)	PCM - Powertrain Control Module	EXE
KX63-12K532-FLA.vbf	Jaguar XF (X260)	PCM - Powertrain Control Module	EXE
KX63-12K532-FLB.vbf	Jaguar XF (X260)	PCM - Powertrain Control Module	EXE
KX63-12K532-FLC.vbf	Jaguar XF (X260)	PCM - Powertrain Control Module	EXE
KX63-12K532-FLD.vbf	Jaguar XF (X260)	PCM - Powertrain Control Module	EXE
KX63-12K532-FMA.vbf	Jaguar XF (X260)	PCM - Powertrain Control Module	EXE
KX63-12K532-FMB.vbf	Jaguar XF (X260)	PCM - Powertrain Control Module	EXE
KX63-12K532-FMC.vbf	Jaguar XF (X260)	PCM - Powertrain Control Module	EXE
KX63-12K532-FMD.vbf	Jaguar XF (X260)	PCM - Powertrain Control Module	EXE
KX63-12K532-FNA.vbf	Jaguar XF (X260)	PCM - Powertrain Control Module	EXE
KX63-12K532-FNB.vbf	Jaguar XF (X260)	PCM - Powertrain Control Module	EXE
KX63-12K532-FNC.vbf	Jaguar XF (X260)	PCM - Powertrain Control Module	EXE
KX63-12K532-FPA.vbf	Jaguar XF (X260)	PCM - Powertrain Control Module	EXE
KX63-12K532-FPB.vbf	Jaguar XF (X260)	PCM - Powertrain Control Module	EXE
KX63-12K532-FRA.vbf	Jaguar XF (X260)	PCM - Powertrain Control Module	EXE
KX63-12K532-FSA.vbf	Jaguar XF (X260)	PCM - Powertrain Control Module	EXE
KX63-12K532-FTA.vbf	Jaguar XF (X260)	PCM - Powertrain Control Module	EXE
KX63-12K532-FTB.vbf	Jaguar XF (X260)	PCM - Powertrain Control Module	EXE
KX63-12K532-FTC.vbf	Jaguar XF (X260)	PCM - Powertrain Control Module	EXE
KX63-12K532-GAA.vbf	Jaguar XF (X260)	PCM - Powertrain Control Module	DATA
KX63-12K532-GAB.vbf	Jaguar XF (X260)	PCM - Powertrain Control Module	EXE
KX63-12K532-GAC.vbf	Jaguar XF (X260)	PCM - Powertrain Control Module	EXE
KX63-12K532-GAD.vbf	Jaguar XF (X260)	PCM - Powertrain Control Module	EXE
KX63-12K532-GAE.vbf	Jaguar XF (X260)	PCM - Powertrain Control Module	EXE
KX63-12K532-GAF.vbf	Jaguar XF (X260)	PCM - Powertrain Control Module	EXE
KX63-12K532-GAG.vbf	Jaguar XF (X260)	PCM - Powertrain Control Module	EXE
KX63-12K532-GAH.vbf	Jaguar XF (X260)	PCM - Powertrain Control Module	EXE
KX63-12K532-GBA.vbf	Jaguar XF (X260)	PCM - Powertrain Control Module	DATA
KX63-12K532-GBB.vbf	Jaguar XF (X260)	PCM - Powertrain Control Module	EXE
KX63-12K532-GBC.vbf	Jaguar XF (X260)	PCM - Powertrain Control Module	EXE
KX63-12K532-GBD.vbf	Jaguar XF (X260)	PCM - Powertrain Control Module	EXE
KX63-12K532-GBE.vbf	Jaguar XF (X260)	PCM - Powertrain Control Module	EXE
KX63-12K532-GBF.vbf	Jaguar XF (X260)	PCM - Powertrain Control Module	EXE
KX63-12K532-GBG.vbf	Jaguar XF (X260)	PCM - Powertrain Control Module	EXE
KX63-12K532-GBH.vbf	Jaguar XF (X260)	PCM - Powertrain Control Module	EXE
KX63-12K532-GBJ.vbf	Jaguar XF (X260)	PCM - Powertrain Control Module	EXE
KX63-12K532-GDA.vbf	Jaguar XF (X260)	PCM - Powertrain Control Module	EXE
KX63-12K532-GEB.vbf	Jaguar XF (X260)	PCM - Powertrain Control Module	EXE
KX63-12K532-GEC.vbf	Jaguar XF (X260)	PCM - Powertrain Control Module	EXE
KX63-12K532-GED.vbf	Jaguar XF (X260)	PCM - Powertrain Control Module	EXE
KX63-12K532-GEE.vbf	Jaguar XF (X260)	PCM - Powertrain Control Module	EXE
KX63-12K532-GEF.vbf	Jaguar XF (X260)	PCM - Powertrain Control Module	EXE
KX63-12K532-GEG.vbf	Jaguar XF (X260)	PCM - Powertrain Control Module	EXE
KX63-12K532-GEH.vbf	Jaguar XF (X260)	PCM - Powertrain Control Module	EXE
KX63-12K532-PMC.vbf	Jaguar XF (X260)	PCM - Powertrain Control Module	EXE
KX63-12K532-PMD.vbf	Jaguar XF (X260)	PCM - Powertrain Control Module	EXE
KX63-12K532-PYA.vbf	Jaguar XF (X260)	PCM - Powertrain Control Module	DATA
KX63-12K532-PYB.vbf	Jaguar XF (X260)	PCM - Powertrain Control Module	DATA
KX63-12K532-PYC.vbf	Jaguar XF (X260)	PCM - Powertrain Control Module	EXE
KX63-12K532-PYD.vbf	Jaguar XF (X260)	PCM - Powertrain Control Module	EXE
KX63-12K532-PYE.vbf	Jaguar XF (X260)	PCM - Powertrain Control Module	EXE
KX63-12K532-PYF.vbf	Jaguar XF (X260)	PCM - Powertrain Control Module	EXE
KX63-12K532-PYH.vbf	Jaguar XF (X260)	PCM - Powertrain Control Module	EXE
KX63-12K532-PYJ.vbf	Jaguar XF (X260)	PCM - Powertrain Control Module	EXE
KX63-14C185-AA.vbf	Jaguar XF (X260)	BCM - Body Control Module	DATA
KX63-14C185-AB.vbf	Jaguar XF (X260)	BCM - Body Control Module	DATA
KX63-14C527-AA.vbf	Jaguar XF (X260)	AAM - Audio Amplifier Module	DATA
KX63-14C527-AAA.vbf	Jaguar XF (X260)	AAM - Audio Amplifier Module	DATA
KX63-14C527-AB.vbf	Jaguar XF (X260)	AAM - Audio Amplifier Module	DATA
KX63-14C527-ABA.vbf	Jaguar XF (X260)	AAM - Audio Amplifier Module	DATA
KX63-14C527-ACA.vbf	Jaguar XF (X260)	AAM - Audio Amplifier Module	DATA
KX63-14C527-AEA.vbf	Jaguar XF (X260)	AAM - Audio Amplifier Module	DATA
KX63-14C527-AFA.vbf	Jaguar XF (X260)	AAM - Audio Amplifier Module	DATA
KX63-14C527-AGA.vbf	Jaguar XF (X260)	AAM - Audio Amplifier Module	DATA
KX63-14C527-BEA.vbf	Jaguar XF (X260)	AAM - Audio Amplifier Module	DATA
KX63-14C527-BFA.vbf	Jaguar XF (X260)	AAM - Audio Amplifier Module	DATA
KX63-14C527-BGA.vbf	Jaguar XF (X260)	AAM - Audio Amplifier Module	DATA

File name	Vehicle line (indicative)	Module (ECU)	Type
KX63-14C527-CEA.vbf	Jaguar XF (X260)	AAM - Audio Amplifier Module	DATA
KX63-14C527-CFA.vbf	Jaguar XF (X260)	AAM - Audio Amplifier Module	DATA
KX63-14C527-CGA.vbf	Jaguar XF (X260)	AAM - Audio Amplifier Module	DATA
KX63-14C527-EA.vbf	Jaguar XF (X260)	AAM - Audio Amplifier Module	DATA
KX63-14C527-EAA.vbf	Jaguar XF (X260)	AAM - Audio Amplifier Module	DATA
KX63-14C527-EB.vbf	Jaguar XF (X260)	AAM - Audio Amplifier Module	DATA
KX63-14C527-EBA.vbf	Jaguar XF (X260)	AAM - Audio Amplifier Module	DATA
KX63-14C527-EBB.vbf	Jaguar XF (X260)	AAM - Audio Amplifier Module	DATA
KX63-14C527-EBC.vbf	Jaguar XF (X260)	AAM - Audio Amplifier Module	DATA
KX63-14C527-ECA.vbf	Jaguar XF (X260)	AAM - Audio Amplifier Module	DATA
KX63-14C527-EEA.vbf	Jaguar XF (X260)	AAM - Audio Amplifier Module	DATA
KX63-14C527-EFA.vbf	Jaguar XF (X260)	AAM - Audio Amplifier Module	DATA
KX63-14C527-EGA.vbf	Jaguar XF (X260)	AAM - Audio Amplifier Module	DATA
KX63-14C527-FEA.vbf	Jaguar XF (X260)	AAM - Audio Amplifier Module	DATA
KX63-14C527-FFA.vbf	Jaguar XF (X260)	AAM - Audio Amplifier Module	DATA
KX63-14C527-FGA.vbf	Jaguar XF (X260)	AAM - Audio Amplifier Module	DATA
KX63-14C527-GEA.vbf	Jaguar XF (X260)	AAM - Audio Amplifier Module	DATA
KX63-14C527-GFA.vbf	Jaguar XF (X260)	AAM - Audio Amplifier Module	DATA
KX63-14C527-GGA.vbf	Jaguar XF (X260)	AAM - Audio Amplifier Module	DATA
KX63-14C535-AA.vbf	Jaguar XF (X260)	FCIM - Front Controls Interface Module	EXE
KX63-14C535-AB.vbf	Jaguar XF (X260)	FCIM - Front Controls Interface Module	EXE
KX63-14C570-BAC.vbf	Jaguar XF (X260)	PCM - Powertrain Control Module	EXE
KX63-14C570-BAE.vbf	Jaguar XF (X260)	PCM - Powertrain Control Module	EXE
KX63-14C570-BAF.vbf	Jaguar XF (X260)	PCM - Powertrain Control Module	EXE
KX63-14C570-BCE.vbf	Jaguar XF (X260)	PCM - Powertrain Control Module	EXE
KX63-14C570-BEE.vbf	Jaguar XF (X260)	PCM - Powertrain Control Module	EXE
KX63-14C570-BFA.vbf	Jaguar XF (X260)	PCM - Powertrain Control Module	EXE
KX63-14C570-BFB.vbf	Jaguar XF (X260)	PCM - Powertrain Control Module	EXE
KX63-14C570-BFC.vbf	Jaguar XF (X260)	PCM - Powertrain Control Module	EXE
KX63-14C570-BFD.vbf	Jaguar XF (X260)	PCM - Powertrain Control Module	EXE
KX63-14C570-BFE.vbf	Jaguar XF (X260)	PCM - Powertrain Control Module	EXE
KX63-14C570-BFG.vbf	Jaguar XF (X260)	PCM - Powertrain Control Module	EXE
KX63-14C570-BFH.vbf	Jaguar XF (X260)	PCM - Powertrain Control Module	EXE
KX63-14C570-BFJ.vbf	Jaguar XF (X260)	PCM - Powertrain Control Module	EXE
KX63-14C570-BGC.vbf	Jaguar XF (X260)	PCM - Powertrain Control Module	EXE
KX63-14C570-BGD.vbf	Jaguar XF (X260)	PCM - Powertrain Control Module	EXE
KX63-14C570-BGE.vbf	Jaguar XF (X260)	PCM - Powertrain Control Module	EXE
KX63-14C570-BHA.vbf	Jaguar XF (X260)	PCM - Powertrain Control Module	EXE
KX63-14C570-BHB.vbf	Jaguar XF (X260)	PCM - Powertrain Control Module	EXE
KX63-14C570-BHC.vbf	Jaguar XF (X260)	PCM - Powertrain Control Module	EXE
KX63-14C570-BHD.vbf	Jaguar XF (X260)	PCM - Powertrain Control Module	EXE
KX63-14C570-BHE.vbf	Jaguar XF (X260)	PCM - Powertrain Control Module	EXE
KX63-14C570-BHG.vbf	Jaguar XF (X260)	PCM - Powertrain Control Module	EXE
KX63-14C570-BLD.vbf	Jaguar XF (X260)	PCM - Powertrain Control Module	EXE
KX63-14C570-BND.vbf	Jaguar XF (X260)	PCM - Powertrain Control Module	EXE
KX63-14C570-BPA.vbf	Jaguar XF (X260)	PCM - Powertrain Control Module	EXE
KX63-14C570-BPB.vbf	Jaguar XF (X260)	PCM - Powertrain Control Module	EXE
KX63-14C570-BPC.vbf	Jaguar XF (X260)	PCM - Powertrain Control Module	EXE
KX63-14C570-BPD.vbf	Jaguar XF (X260)	PCM - Powertrain Control Module	EXE
KX63-14C570-BPE.vbf	Jaguar XF (X260)	PCM - Powertrain Control Module	EXE
KX63-14C570-BPF.vbf	Jaguar XF (X260)	PCM - Powertrain Control Module	EXE
KX63-14C570-BPG.vbf	Jaguar XF (X260)	PCM - Powertrain Control Module	EXE
KX63-14C570-BPH.vbf	Jaguar XF (X260)	PCM - Powertrain Control Module	EXE
KX63-14C570-BRA.vbf	Jaguar XF (X260)	PCM - Powertrain Control Module	EXE
KX63-14C570-BRB.vbf	Jaguar XF (X260)	PCM - Powertrain Control Module	EXE
KX63-14C570-BRC.vbf	Jaguar XF (X260)	PCM - Powertrain Control Module	EXE
KX63-14C570-BRD.vbf	Jaguar XF (X260)	PCM - Powertrain Control Module	EXE
KX63-14C570-BRE.vbf	Jaguar XF (X260)	PCM - Powertrain Control Module	EXE
KX63-14C570-BRF.vbf	Jaguar XF (X260)	PCM - Powertrain Control Module	EXE
KX63-14C570-BTC.vbf	Jaguar XF (X260)	PCM - Powertrain Control Module	EXE
KX63-14C570-BTD.vbf	Jaguar XF (X260)	PCM - Powertrain Control Module	EXE
KX63-14C570-BTF.vbf	Jaguar XF (X260)	PCM - Powertrain Control Module	EXE
KX63-14C570-BUD.vbf	Jaguar XF (X260)	PCM - Powertrain Control Module	EXE
KX63-14F529-BB.vbf	Jaguar XF (X260)	GWM - Gateway Module A	EXE
KX63-14F529-BC.vbf	Jaguar XF (X260)	GWM - Gateway Module A	EXE
KX63-14F529-BD.vbf	Jaguar XF (X260)	GWM - Gateway Module A	EXE
KX63-14F529-BE.vbf	Jaguar XF (X260)	GWM - Gateway Module A	EXE
KX63-14F529-BF.vbf	Jaguar XF (X260)	GWM - Gateway Module A	EXE
KX63-14F529-BG.vbf	Jaguar XF (X260)	GWM - Gateway Module A	EXE
KX63-14F529-BH.vbf	Jaguar XF (X260)	GWM - Gateway Module A	EXE
KX63-14F530-BB.vbf	Jaguar XF (X260)	GWM - Gateway Module A	EXE
KX63-14F530-BC.vbf	Jaguar XF (X260)	GWM - Gateway Module A	EXE
KX63-14F530-BD.vbf	Jaguar XF (X260)	GWM - Gateway Module A	EXE
KX63-14F530-BE.vbf	Jaguar XF (X260)	GWM - Gateway Module A	EXE
KX63-14F530-BF.vbf	Jaguar XF (X260)	GWM - Gateway Module A	EXE
KX63-14F530-BG.vbf	Jaguar XF (X260)	GWM - Gateway Module A	EXE

File name	Vehicle line (indicative)	Module (ECU)	Type
KX63-14F530-BH.vbf	Jaguar XF (X260)	GWM - Gateway Module A	EXE
KX63-14F531-BB.vbf	Jaguar XF (X260)	GWM - Gateway Module A	DATA
KX63-14F531-BC.vbf	Jaguar XF (X260)	GWM - Gateway Module A	DATA
KX63-14F531-BD.vbf	Jaguar XF (X260)	GWM - Gateway Module A	DATA
KX63-14F531-BE.vbf	Jaguar XF (X260)	GWM - Gateway Module A	DATA
KX63-14F531-BF.vbf	Jaguar XF (X260)	GWM - Gateway Module A	DATA
KX63-14F531-BG.vbf	Jaguar XF (X260)	GWM - Gateway Module A	DATA
KX63-7J104-DFA.vbf	Jaguar XF (X260)	TCM - Transmission Control Module	EXE
KX63-7J104-DFB.vbf	Jaguar XF (X260)	TCM - Transmission Control Module	EXE
KX63-7J104-DFC.vbf	Jaguar XF (X260)	TCM - Transmission Control Module	EXE
KX63-7J104-DFD.vbf	Jaguar XF (X260)	TCM - Transmission Control Module	EXE
KX63-7J104-DGA.vbf	Jaguar XF (X260)	TCM - Transmission Control Module	EXE
KX63-7J104-DGB.vbf	Jaguar XF (X260)	TCM - Transmission Control Module	EXE
KX63-7J104-DGC.vbf	Jaguar XF (X260)	TCM - Transmission Control Module	EXE
KX63-7J104-DNA.vbf	Jaguar XF (X260)	TCM - Transmission Control Module	EXE
KX63-7J104-DNB.vbf	Jaguar XF (X260)	TCM - Transmission Control Module	EXE
KX63-7J104-DNC.vbf	Jaguar XF (X260)	TCM - Transmission Control Module	EXE
KX63-7J104-DTA.vbf	Jaguar XF (X260)	TCM - Transmission Control Module	EXE
KX63-7J104-DTB.vbf	Jaguar XF (X260)	TCM - Transmission Control Module	EXE
KX63-7J104-DTC.vbf	Jaguar XF (X260)	TCM - Transmission Control Module	EXE
KX63-7J104-DUB.vbf	Jaguar XF (X260)	TCM - Transmission Control Module	EXE
KX63-7J104-DUC.vbf	Jaguar XF (X260)	TCM - Transmission Control Module	EXE
KX63-7J104-DUD.vbf	Jaguar XF (X260)	TCM - Transmission Control Module	EXE
KX63-7J104-DVA.vbf	Jaguar XF (X260)	TCM - Transmission Control Module	EXE
KX63-7J104-DVB.vbf	Jaguar XF (X260)	TCM - Transmission Control Module	EXE
KX63-7J104-DVC.vbf	Jaguar XF (X260)	TCM - Transmission Control Module	EXE
KX63-7J104-FBA.vbf	Jaguar XF (X260)	TCM - Transmission Control Module	EXE
KX63-7J104-FBB.vbf	Jaguar XF (X260)	TCM - Transmission Control Module	EXE
KX63-7J104-FBD.vbf	Jaguar XF (X260)	TCM - Transmission Control Module	EXE
KX63-7J104-FBE.vbf	Jaguar XF (X260)	TCM - Transmission Control Module	EXE
KX63-7J104-FBF.vbf	Jaguar XF (X260)	TCM - Transmission Control Module	EXE
KX63-7J104-FCA.vbf	Jaguar XF (X260)	TCM - Transmission Control Module	EXE
KX63-7J104-FCC.vbf	Jaguar XF (X260)	TCM - Transmission Control Module	EXE
KX63-7J104-FCD.vbf	Jaguar XF (X260)	TCM - Transmission Control Module	EXE
KX63-7J104-FCE.vbf	Jaguar XF (X260)	TCM - Transmission Control Module	EXE
KX63-7J104-FJA.vbf	Jaguar XF (X260)	TCM - Transmission Control Module	EXE
KX63-7J104-FJB.vbf	Jaguar XF (X260)	TCM - Transmission Control Module	EXE
KX63-7J104-FJC.vbf	Jaguar XF (X260)	TCM - Transmission Control Module	EXE
KX63-7J104-FJD.vbf	Jaguar XF (X260)	TCM - Transmission Control Module	EXE
KX63-7J104-FJE.vbf	Jaguar XF (X260)	TCM - Transmission Control Module	EXE
KX63-7J104-FKA.vbf	Jaguar XF (X260)	TCM - Transmission Control Module	EXE
KX63-7J104-FKB.vbf	Jaguar XF (X260)	TCM - Transmission Control Module	EXE
KX63-7J104-FKC.vbf	Jaguar XF (X260)	TCM - Transmission Control Module	EXE
KX63-7J104-FKD.vbf	Jaguar XF (X260)	TCM - Transmission Control Module	EXE
KX63-7J104-FKE.vbf	Jaguar XF (X260)	TCM - Transmission Control Module	EXE
KX73-12K532-FAA.vbf	Jaguar XE (X760)	PCM - Powertrain Control Module	DATA
KX73-12K532-FAB.vbf	Jaguar XE (X760)	PCM - Powertrain Control Module	EXE
KX73-12K532-FAC.vbf	Jaguar XE (X760)	PCM - Powertrain Control Module	EXE
KX73-12K532-FAD.vbf	Jaguar XE (X760)	PCM - Powertrain Control Module	EXE
KX73-12K532-FAE.vbf	Jaguar XE (X760)	PCM - Powertrain Control Module	EXE
KX73-12K532-FAF.vbf	Jaguar XE (X760)	PCM - Powertrain Control Module	EXE
KX73-12K532-FAG.vbf	Jaguar XE (X760)	PCM - Powertrain Control Module	EXE
KX73-12K532-FCA.vbf	Jaguar XE (X760)	PCM - Powertrain Control Module	DATA
KX73-12K532-FCB.vbf	Jaguar XE (X760)	PCM - Powertrain Control Module	EXE
KX73-12K532-FCC.vbf	Jaguar XE (X760)	PCM - Powertrain Control Module	EXE
KX73-12K532-FCD.vbf	Jaguar XE (X760)	PCM - Powertrain Control Module	EXE
KX73-12K532-FCE.vbf	Jaguar XE (X760)	PCM - Powertrain Control Module	EXE
KX73-12K532-FCF.vbf	Jaguar XE (X760)	PCM - Powertrain Control Module	EXE
KX73-12K532-FCG.vbf	Jaguar XE (X760)	PCM - Powertrain Control Module	EXE
KX73-12K532-FDB.vbf	Jaguar XE (X760)	PCM - Powertrain Control Module	EXE
KX73-12K532-FDC.vbf	Jaguar XE (X760)	PCM - Powertrain Control Module	EXE
KX73-12K532-FDD.vbf	Jaguar XE (X760)	PCM - Powertrain Control Module	EXE
KX73-12K532-FDE.vbf	Jaguar XE (X760)	PCM - Powertrain Control Module	EXE
KX73-12K532-FDF.vbf	Jaguar XE (X760)	PCM - Powertrain Control Module	EXE
KX73-12K532-FDG.vbf	Jaguar XE (X760)	PCM - Powertrain Control Module	EXE
KX73-12K532-FEA.vbf	Jaguar XE (X760)	PCM - Powertrain Control Module	DATA
KX73-12K532-FEB.vbf	Jaguar XE (X760)	PCM - Powertrain Control Module	EXE
KX73-12K532-FEC.vbf	Jaguar XE (X760)	PCM - Powertrain Control Module	EXE
KX73-12K532-FED.vbf	Jaguar XE (X760)	PCM - Powertrain Control Module	EXE
KX73-12K532-FEE.vbf	Jaguar XE (X760)	PCM - Powertrain Control Module	EXE
KX73-12K532-FEF.vbf	Jaguar XE (X760)	PCM - Powertrain Control Module	EXE
KX73-12K532-FEG.vbf	Jaguar XE (X760)	PCM - Powertrain Control Module	EXE
KX73-12K532-FFA.vbf	Jaguar XE (X760)	PCM - Powertrain Control Module	EXE
KX73-12K532-FHA.vbf	Jaguar XE (X760)	PCM - Powertrain Control Module	EXE
KX73-12K532-FJA.vbf	Jaguar XE (X760)	PCM - Powertrain Control Module	EXE
KX73-12K532-FJB.vbf	Jaguar XE (X760)	PCM - Powertrain Control Module	EXE

File name	Vehicle line (indicative)	Module (ECU)	Type
KX73-12K532-FKA.vbf	Jaguar XE (X760)	PCM - Powertrain Control Module	EXE
KX73-12K532-FLA.vbf	Jaguar XE (X760)	PCM - Powertrain Control Module	EXE
KX73-12K532-FLB.vbf	Jaguar XE (X760)	PCM - Powertrain Control Module	EXE
KX73-12K532-FLC.vbf	Jaguar XE (X760)	PCM - Powertrain Control Module	EXE
KX73-12K532-FLD.vbf	Jaguar XE (X760)	PCM - Powertrain Control Module	EXE
KX73-12K532-FMA.vbf	Jaguar XE (X760)	PCM - Powertrain Control Module	EXE
KX73-12K532-FMB.vbf	Jaguar XE (X760)	PCM - Powertrain Control Module	EXE
KX73-12K532-FMC.vbf	Jaguar XE (X760)	PCM - Powertrain Control Module	EXE
KX73-12K532-FMD.vbf	Jaguar XE (X760)	PCM - Powertrain Control Module	EXE
KX73-12K532-FNA.vbf	Jaguar XE (X760)	PCM - Powertrain Control Module	EXE
KX73-12K532-FNB.vbf	Jaguar XE (X760)	PCM - Powertrain Control Module	EXE
KX73-12K532-FNC.vbf	Jaguar XE (X760)	PCM - Powertrain Control Module	EXE
KX73-12K532-FPA.vbf	Jaguar XE (X760)	PCM - Powertrain Control Module	EXE
KX73-12K532-FTA.vbf	Jaguar XE (X760)	PCM - Powertrain Control Module	EXE
KX73-12K532-FTC.vbf	Jaguar XE (X760)	PCM - Powertrain Control Module	EXE
KX73-12K532-GAA.vbf	Jaguar XE (X760)	PCM - Powertrain Control Module	DATA
KX73-12K532-GAB.vbf	Jaguar XE (X760)	PCM - Powertrain Control Module	EXE
KX73-12K532-GAC.vbf	Jaguar XE (X760)	PCM - Powertrain Control Module	EXE
KX73-12K532-GAD.vbf	Jaguar XE (X760)	PCM - Powertrain Control Module	EXE
KX73-12K532-GAE.vbf	Jaguar XE (X760)	PCM - Powertrain Control Module	EXE
KX73-12K532-GAF.vbf	Jaguar XE (X760)	PCM - Powertrain Control Module	EXE
KX73-12K532-GAG.vbf	Jaguar XE (X760)	PCM - Powertrain Control Module	EXE
KX73-12K532-GBA.vbf	Jaguar XE (X760)	PCM - Powertrain Control Module	DATA
KX73-12K532-GBB.vbf	Jaguar XE (X760)	PCM - Powertrain Control Module	EXE
KX73-12K532-GBC.vbf	Jaguar XE (X760)	PCM - Powertrain Control Module	EXE
KX73-12K532-GBD.vbf	Jaguar XE (X760)	PCM - Powertrain Control Module	EXE
KX73-12K532-GBE.vbf	Jaguar XE (X760)	PCM - Powertrain Control Module	EXE
KX73-12K532-GBF.vbf	Jaguar XE (X760)	PCM - Powertrain Control Module	EXE
KX73-12K532-GBG.vbf	Jaguar XE (X760)	PCM - Powertrain Control Module	EXE
KX73-12K532-GBH.vbf	Jaguar XE (X760)	PCM - Powertrain Control Module	EXE
KX73-12K532-GCA.vbf	Jaguar XE (X760)	PCM - Powertrain Control Module	EXE
KX73-14C185-AA.vbf	Jaguar XE (X760)	BCM - Body Control Module	DATA
KX73-14C185-AB.vbf	Jaguar XE (X760)	BCM - Body Control Module	DATA
KX73-14C204-FAA.vbf	Jaguar XE (X760)	PCM - Powertrain Control Module	EXE
KX73-14C204-FAB.vbf	Jaguar XE (X760)	PCM - Powertrain Control Module	EXE
KX73-14C204-FBA.vbf	Jaguar XE (X760)	PCM - Powertrain Control Module	EXE
KX73-14C204-FBB.vbf	Jaguar XE (X760)	PCM - Powertrain Control Module	EXE
KX73-14C273-FA.vbf	Jaguar XE (X760)	PCM - Powertrain Control Module	SBL
KX73-14C527-AA.vbf	Jaguar XE (X760)	AAM - Audio Amplifier Module	DATA
KX73-14C527-AAA.vbf	Jaguar XE (X760)	AAM - Audio Amplifier Module	DATA
KX73-14C527-AB.vbf	Jaguar XE (X760)	AAM - Audio Amplifier Module	DATA
KX73-14C527-ABA.vbf	Jaguar XE (X760)	AAM - Audio Amplifier Module	DATA
KX73-14C527-ABB.vbf	Jaguar XE (X760)	AAM - Audio Amplifier Module	DATA
KX73-14C527-ACA.vbf	Jaguar XE (X760)	AAM - Audio Amplifier Module	DATA
KX73-14C527-AEA.vbf	Jaguar XE (X760)	AAM - Audio Amplifier Module	DATA
KX73-14C527-AGA.vbf	Jaguar XE (X760)	AAM - Audio Amplifier Module	DATA
KX73-14C527-BEA.vbf	Jaguar XE (X760)	AAM - Audio Amplifier Module	DATA
KX73-14C527-BGA.vbf	Jaguar XE (X760)	AAM - Audio Amplifier Module	DATA
KX73-14C527-CEA.vbf	Jaguar XE (X760)	AAM - Audio Amplifier Module	DATA
KX73-14C527-CGA.vbf	Jaguar XE (X760)	AAM - Audio Amplifier Module	DATA
KX73-14C570-BAC.vbf	Jaguar XE (X760)	PCM - Powertrain Control Module	EXE
KX73-14C570-BAD.vbf	Jaguar XE (X760)	PCM - Powertrain Control Module	EXE
KX73-14C570-BAE.vbf	Jaguar XE (X760)	PCM - Powertrain Control Module	EXE
KX73-14C570-BCD.vbf	Jaguar XE (X760)	PCM - Powertrain Control Module	EXE
KX73-14C570-BED.vbf	Jaguar XE (X760)	PCM - Powertrain Control Module	EXE
KX73-14C570-BFB.vbf	Jaguar XE (X760)	PCM - Powertrain Control Module	EXE
KX73-14C570-BFC.vbf	Jaguar XE (X760)	PCM - Powertrain Control Module	EXE
KX73-14C570-BFD.vbf	Jaguar XE (X760)	PCM - Powertrain Control Module	EXE
KX73-14C570-BFE.vbf	Jaguar XE (X760)	PCM - Powertrain Control Module	EXE
KX73-14C570-BFF.vbf	Jaguar XE (X760)	PCM - Powertrain Control Module	EXE
KX73-14C570-BFG.vbf	Jaguar XE (X760)	PCM - Powertrain Control Module	EXE
KX73-14C570-BFH.vbf	Jaguar XE (X760)	PCM - Powertrain Control Module	EXE
KX73-14C570-BGC.vbf	Jaguar XE (X760)	PCM - Powertrain Control Module	EXE
KX73-14C570-BGD.vbf	Jaguar XE (X760)	PCM - Powertrain Control Module	EXE
KX73-14C570-BGE.vbf	Jaguar XE (X760)	PCM - Powertrain Control Module	EXE
KX73-14C570-BHA.vbf	Jaguar XE (X760)	PCM - Powertrain Control Module	EXE
KX73-14C570-BHB.vbf	Jaguar XE (X760)	PCM - Powertrain Control Module	EXE
KX73-14C570-BHC.vbf	Jaguar XE (X760)	PCM - Powertrain Control Module	EXE
KX73-14C570-BHD.vbf	Jaguar XE (X760)	PCM - Powertrain Control Module	EXE
KX73-14C570-BHE.vbf	Jaguar XE (X760)	PCM - Powertrain Control Module	EXE
KX73-14C570-BHF.vbf	Jaguar XE (X760)	PCM - Powertrain Control Module	EXE
KX73-14C570-BLD.vbf	Jaguar XE (X760)	PCM - Powertrain Control Module	EXE
KX73-14C570-BPC.vbf	Jaguar XE (X760)	PCM - Powertrain Control Module	EXE
KX73-14C570-BPD.vbf	Jaguar XE (X760)	PCM - Powertrain Control Module	EXE
KX73-14C570-BPE.vbf	Jaguar XE (X760)	PCM - Powertrain Control Module	EXE
KX73-14C570-BPF.vbf	Jaguar XE (X760)	PCM - Powertrain Control Module	EXE

File name	Vehicle line (indicative)	Module (ECU)	Type
KX73-14C570-BPG.vbf	Jaguar XE (X760)	PCM - Powertrain Control Module	EXE
KX73-14C570-BRA.vbf	Jaguar XE (X760)	PCM - Powertrain Control Module	EXE
KX73-14C570-BRB.vbf	Jaguar XE (X760)	PCM - Powertrain Control Module	EXE
KX73-14C570-BRC.vbf	Jaguar XE (X760)	PCM - Powertrain Control Module	EXE
KX73-14C570-BRD.vbf	Jaguar XE (X760)	PCM - Powertrain Control Module	EXE
KX73-14C570-BRE.vbf	Jaguar XE (X760)	PCM - Powertrain Control Module	EXE
KX73-14C570-BRF.vbf	Jaguar XE (X760)	PCM - Powertrain Control Module	EXE
KX73-14C570-BTC.vbf	Jaguar XE (X760)	PCM - Powertrain Control Module	EXE
KX73-14C570-BTD.vbf	Jaguar XE (X760)	PCM - Powertrain Control Module	EXE
KX73-14C570-BTE.vbf	Jaguar XE (X760)	PCM - Powertrain Control Module	EXE
KX73-14C570-BUD.vbf	Jaguar XE (X760)	PCM - Powertrain Control Module	EXE
KX73-14F529-AA.vbf	Jaguar XE (X760)	GWM - Gateway Module A	EXE
KX73-14F530-AA.vbf	Jaguar XE (X760)	GWM - Gateway Module A	EXE
KX73-14F531-AA.vbf	Jaguar XE (X760)	GWM - Gateway Module A	DATA
KX73-14F531-AB.vbf	Jaguar XE (X760)	GWM - Gateway Module A	DATA
KX73-14F531-AC.vbf	Jaguar XE (X760)	GWM - Gateway Module A	DATA
KX73-7J104-DFA.vbf	Jaguar XE (X760)	TCM - Transmission Control Module	EXE
KX73-7J104-DFB.vbf	Jaguar XE (X760)	TCM - Transmission Control Module	EXE
KX73-7J104-DFC.vbf	Jaguar XE (X760)	TCM - Transmission Control Module	EXE
KX73-7J104-DFD.vbf	Jaguar XE (X760)	TCM - Transmission Control Module	EXE
KX73-7J104-DGA.vbf	Jaguar XE (X760)	TCM - Transmission Control Module	EXE
KX73-7J104-DGB.vbf	Jaguar XE (X760)	TCM - Transmission Control Module	EXE
KX73-7J104-DGC.vbf	Jaguar XE (X760)	TCM - Transmission Control Module	EXE
KX73-7J104-DNB.vbf	Jaguar XE (X760)	TCM - Transmission Control Module	EXE
KX73-7J104-DVA.vbf	Jaguar XE (X760)	TCM - Transmission Control Module	EXE
KX73-7J104-DVB.vbf	Jaguar XE (X760)	TCM - Transmission Control Module	EXE
KX73-7J104-DVC.vbf	Jaguar XE (X760)	TCM - Transmission Control Module	EXE
KX73-7J104-FBA.vbf	Jaguar XE (X760)	TCM - Transmission Control Module	EXE
KX73-7J104-FBB.vbf	Jaguar XE (X760)	TCM - Transmission Control Module	EXE
KX73-7J104-FBC.vbf	Jaguar XE (X760)	TCM - Transmission Control Module	EXE
KX73-7J104-FBD.vbf	Jaguar XE (X760)	TCM - Transmission Control Module	EXE
KX73-7J104-FBE.vbf	Jaguar XE (X760)	TCM - Transmission Control Module	EXE
KX73-7J104-FCA.vbf	Jaguar XE (X760)	TCM - Transmission Control Module	EXE
KX73-7J104-FCB.vbf	Jaguar XE (X760)	TCM - Transmission Control Module	EXE
KX73-7J104-FCC.vbf	Jaguar XE (X760)	TCM - Transmission Control Module	EXE
KX73-7J104-FCD.vbf	Jaguar XE (X760)	TCM - Transmission Control Module	EXE
KX73-7J104-FCE.vbf	Jaguar XE (X760)	TCM - Transmission Control Module	EXE
KX73-7J104-FKA.vbf	Jaguar XE (X760)	TCM - Transmission Control Module	EXE
KX73-7J104-FKC.vbf	Jaguar XE (X760)	TCM - Transmission Control Module	EXE
KX73-7J104-FKD.vbf	Jaguar XE (X760)	TCM - Transmission Control Module	EXE
KX73-7J104-FKE.vbf	Jaguar XE (X760)	TCM - Transmission Control Module	EXE
KX7M-14C037-AC.vbf	Not specified	ABS - Anti-Lock Brake System Control Module	DATA
KX7M-14C037-AD.vbf	Not specified	ABS - Anti-Lock Brake System Control Module	DATA
KX7M-14C037-AE.vbf	Not specified	ABS - Anti-Lock Brake System Control Module	DATA
KX7M-14C037-AF.vbf	Not specified	ABS - Anti-Lock Brake System Control Module	DATA
KX7M-14C037-AG.vbf	Not specified	ABS - Anti-Lock Brake System Control Module	DATA
KX7M-14C098-AA.VBF	Not specified	RCM - Restraints Control Module	DATA
KX7M-14C098-BA.VBF	Not specified	RCM - Restraints Control Module	DATA
KX7M-14C152-AA.vbf	Not specified	TPM - Tire Pressure Monitor Module	DATA
KX7M-14C152-AB.vbf	Not specified	TPM - Tire Pressure Monitor Module	DATA
KX7M-14C218-AA.vbf	Not specified	PSCM - Power Steering Control Module	DATA
KX7M-14C570-SAA.vbf	Not specified	PCM - Powertrain Control Module	EXE
KX7M-14C570-SAC.vbf	Not specified	PCM - Powertrain Control Module	EXE
KX7M-14C570-STC.vbf	Not specified	PCM - Powertrain Control Module	EXE
KX7M-14C609-AA.vbf	Not specified	PSCM - Power Steering Control Module	DATA
KX7M-14E093-DA.vbf	Not specified	CHCM - Chassis Control Module	EXE
KX7M-14E093-DB.vbf	Not specified	CHCM - Chassis Control Module	EXE
KX7M-14E094-DAA.vbf	Not specified	CHCM - Chassis Control Module	EXE
KX7M-14E094-DAB.vbf	Not specified	CHCM - Chassis Control Module	EXE
KX7M-7J104-FPB.vbf	Not specified	TCM - Transmission Control Module	EXE
KX7M-7J104-FPC.vbf	Not specified	TCM - Transmission Control Module	EXE
KX7M-7J104-FPD.vbf	Not specified	TCM - Transmission Control Module	EXE
KX7M-7J104-FZA.vbf	Not specified	TCM - Transmission Control Module	EXE
KX7M-7J104-FZB.vbf	Not specified	TCM - Transmission Control Module	EXE
KX7M-7J104-FZD.vbf	Not specified	TCM - Transmission Control Module	EXE
KX7M-7J104-FZE.vbf	Not specified	TCM - Transmission Control Module	EXE
KX7M-7J104-FZF.vbf	Not specified	TCM - Transmission Control Module	EXE
KY32-14C025-JA.vbf	Not specified	IPC - Instrument Panel Cluster (IPC) Control Module	SBL
KY32-14C026-JB.vbf	Not specified	IPC - Instrument Panel Cluster (IPC) Control Module	EXE
KY32-14C026-JC.vbf	Not specified	IPC - Instrument Panel Cluster (IPC) Control Module	EXE
KY32-14C026-JD.vbf	Not specified	IPC - Instrument Panel Cluster (IPC) Control Module	EXE
KY32-14C026-KC.vbf	Not specified	IPC - Instrument Panel Cluster (IPC) Control Module	EXE
KY32-14C026-KD.vbf	Not specified	IPC - Instrument Panel Cluster (IPC) Control Module	EXE
KY32-14C273-FA.vbf	Not specified	PCM - Powertrain Control Module	SBL
KY32-14C570-UAB.vbf	Not specified	PCM - Powertrain Control Module	EXE
KY32-14C570-UAC.vbf	Not specified	PCM - Powertrain Control Module	EXE

File name	Vehicle line (indicative)	Module (ECU)	Type
KY32-14C570-UAE.vbf	Not specified	PCM - Powertrain Control Module	EXE
KY32-14C570-UFC.vbf	Not specified	PCM - Powertrain Control Module	EXE
KY32-14C570-UFD.vbf	Not specified	PCM - Powertrain Control Module	EXE
KY32-14D049-AB.vbf	Discovery 5 (L462)	CCM - Cruise Control Module	EXE
KY32-14D049-AC.vbf	Discovery 5 (L462)	CCM - Cruise Control Module	EXE
KY32-14D049-AD.vbf	Discovery 5 (L462)	CCM - Cruise Control Module	EXE
KY32-14D049-AE.vbf	Discovery 5 (L462)	CCM - Cruise Control Module	EXE
KY32-14D049-AF.vbf	Discovery 5 (L462)	CCM - Cruise Control Module	EXE
KY32-14D049-AG.vbf	Check in SDD (unconfirmed)	CCM - Cruise Control Module	EXE
KY32-14D049-AH.vbf	Discovery 5 (L462)	CCM - Cruise Control Module	EXE
KY32-14D051-AA.vbf	Not specified	CCM - Cruise Control Module	SBL
KY32-14D051-AB.vbf	Not specified	CCM - Cruise Control Module	SBL
L316_IPC_CCF.vbf	Defender (L316)	IPC - Instrument Panel Cluster (Low Line Spec.)	CARCFG
L316_PCM_DIESEL_CCF.vbf	Defender (L316)	PCM - Powertrain Control Module (Petrol)	CARCFG
L319_201000_BCM_CCF.vbf	Discovery 3/4 (L319)	BCM - Body control module	CARCFG
L319_201000_PCM_DIESE...	Discovery 3/4 (L319)	PCM - Powertrain Control Module (Diesel)	CARCFG
L319_201000_PCM_DIESE...	Discovery 3/4 (L319)	PCM - Powertrain Control Module (Diesel)	CARCFG
L319_201000_PCM_PETR...	Discovery 3/4 (L319)	PCM - Powertrain Control Module (Petrol)	CARCFG
L319_201400_BCM_CCF.vbf	Discovery 3/4 (L319)	BCM - Body control module	CARCFG
L319_201400_GWM_CCF....	Discovery 3/4 (L319)	GWM - Gateway module	CARCFG
L319_BCM_CCF.vbf	Discovery 3/4 (L319)	BCM - Body Cluster Module (Smart Junction Box)	CARCFG
L319_IPC_HI_CCF.vbf	Discovery 3/4 (L319)	IPC - Instrument Panel Cluster (High Line Spec.)	CARCFG
L319_IPC_LO_CCF.vbf	Discovery 3/4 (L319)	IPC - Instrument Panel Cluster (Low Line Spec.)	CARCFG
L319_PCM_DIESEL_CCF.vbf	Discovery 3/4 (L319)	PCM - Powertrain Control Module (Diesel)	CARCFG
L319_PCM_PETROL_V6_...	Discovery 3/4 (L319)	PCM - Powertrain Control Module (Petrol)	CARCFG
L319_PCM_PETROL_V8_...	Discovery 3/4 (L319)	PCM - Powertrain Control Module (Petrol)	CARCFG
L320_201000_BCM_CCF.vbf	Range Rover Sport I (L320)	BCM - Body control module	CARCFG
L320_201000_PCM_DIESE...	Range Rover Sport I (L320)	PCM - Powertrain Control Module (Diesel)	CARCFG
L320_201000_PCM_DIESE...	Range Rover Sport I (L320)	PCM - Powertrain Control Module (Diesel)	CARCFG
L320_201000_PCM_PETR...	Range Rover Sport I (L320)	PCM - Powertrain Control Module (Petrol)	CARCFG
L320_BCM_CCF.vbf	Range Rover Sport I (L320)	BCM - Body Cluster Module (Smart Junction Box)	CARCFG
L320_IPC_HI_CCF.vbf	Range Rover Sport I (L320)	IPC - Instrument Panel Cluster (High Line Spec.)	CARCFG
L320_IPC_LO_CCF.vbf	Range Rover Sport I (L320)	IPC - Instrument Panel Cluster (Low Line Spec.)	CARCFG
L320_PCM_DIESEL_CCF.vbf	Range Rover Sport I (L320)	PCM - Powertrain Control Module (V6 and V8 Diesels)	CARCFG
L320_PCM_PETROL_V8_...	Range Rover Sport I (L320)	PCM - Powertrain Control Module (Petrol)	CARCFG
L322_200600_IPC_HI_CC...	Range Rover III (L322)	IPC - Instrument Panel Cluster (High Line Spec.)	CARCFG
L322_200600_IPC_LO_CC...	Range Rover III (L322)	IPC - Instrument Panel Cluster (Low Line Spec.)	CARCFG
L322_200600_PCM_PETR...	Range Rover III (L322)	PCM - Powertrain Control Module (Petrol)	CARCFG
L322_200700_IPC_HI_CC...	Range Rover III (L322)	IPC - Instrument Panel Cluster (High Line Spec.)	CARCFG
L322_200700_IPC_LO_CC...	Range Rover III (L322)	IPC - Instrument Panel Cluster (Low Line Spec.)	CARCFG
L322_200700_PCM_DIESE...	Range Rover III (L322)	PCM - Powertrain Control Module (Diesel)	CARCFG
L322_200700_PCM_PETR...	Range Rover III (L322)	PCM - Powertrain Control Module (Petrol)	CARCFG
L322_201000_BCM_CCF.vbf	Range Rover III (L322)	BCM - Body control module	CARCFG
L322_201000_PCM_DIESE...	Range Rover III (L322)	PCM - Powertrain Control Module (Diesel)	CARCFG
L322_201000_PCM_DIESE...	Range Rover III (L322)	PCM - Powertrain Control Module (Diesel)	CARCFG
L322_201000_PCM_PETR...	Range Rover III (L322)	PCM - Powertrain Control Module (Petrol)	CARCFG
L322_GWM_CCF.vbf	Range Rover III (L322)	IGW - Gateway Module	CARCFG
L322_IGWM_APPL_16_A2....	Range Rover III (L322)	IGWM - Infotainment Gateway	EXE
L322_IGWM_SBL_03.vbf	Range Rover III (L322)	IGWM - Infotainment Gateway	SBL
L359_201300_BCM_CCF.vbf	Freelander 2 (L359)	BCM - Body control module	CARCFG
L359_201300_IPC_CCF.vbf	Freelander 2 (L359)	IPC - Instrument cluster module	CARCFG
L359_BCM_CCF.vbf	Freelander 2 (L359)	BCM (CEM) - Central Electrical Module	CARCFG
L359_IPC_CCF.vbf	Freelander 2 (L359)	IPC - Instrument Panel Cluster	CARCFG
L359_IPC_CCF_F114.vbf	Freelander 2 (L359)	IPC - Instrument Panel Cluster	CARCFG
L405_201300_BCM_CCF.vbf	Range Rover (L405)	BCM - Body control module	CARCFG
L405_201300_GWM_CCF....	Range Rover (L405)	GWM - Gateway module	CARCFG
L405_201400_BCM_CCF.vbf	Range Rover (L405)	BCM - Body control module	CARCFG
L405_201400_GWM_CCF....	Range Rover (L405)	GWM - Gateway module	CARCFG
L405_201600_BCM_CCF.vbf	Range Rover (L405)	BCM - Body control module	CARCFG
L405_201600_GWM_CCF....	Range Rover (L405)	GWM - Gateway module	CARCFG
L494_201400_BCM_CCF.vbf	Range Rover Sport (L494)	BCM - Body control module	CARCFG
L494_201400_GWM_CCF....	Range Rover Sport (L494)	GWM - Gateway module	CARCFG
L494_201600_BCM_CCF.vbf	Range Rover Sport (L494)	BCM - Body control module	CARCFG
L494_201600_GWM_CCF....	Range Rover Sport (L494)	GWM - Gateway module	CARCFG
L538JV_201600_BCM_CC...	Not specified	BCM - Body control module	CARCFG
L538JV_201600_GWM_CC...	Not specified	GWM - Gateway module	CARCFG
L538_201200_BCM_CCF.vbf	Range Rover Evoque (L538)	BCM - Body control module	CARCFG
L538_201200_IPC_CCF.vbf	Range Rover Evoque (L538)	IPC - Instrument cluster module	CARCFG
L538_201400_BCM_CCF.vbf	Range Rover Evoque (L538)	BCM - Body control module	CARCFG
L538_201400_GWM_CCF....	Range Rover Evoque (L538)	GWM - Gateway module	CARCFG
L538_201600_BCM_CCF.vbf	Range Rover Evoque (L538)	BCM - Body control module	CARCFG
L538_201600_GWM_CCF....	Range Rover Evoque (L538)	GWM - Gateway module	CARCFG
L538_201700_BCM_CCF.vbf	Range Rover Evoque (L538)	BCM - Body control module	CARCFG
L538_201700_GWM_CCF....	Range Rover Evoque (L538)	GWM - Gateway module	CARCFG
L550_201500_BCM_CCF.vbf	Discovery Sport (L550)	BCM - Body control module	CARCFG
L550_201500_GWM_CCF....	Discovery Sport (L550)	GWM - Gateway module	CARCFG

File name	Vehicle line (indicative)	Module (ECU)	Type
L550_201700_BCM_CCF.vbf	Discovery Sport (L550)	BCM - Body control module	CARCFG
L550_201700_GWM_CCF....	Discovery Sport (L550)	GWM - Gateway module	CARCFG
L8A2-14C028-BA.vbf	Not specified	RCM - Restraints Control Module	EXE
L8A2-14C028-BC.vbf	Not specified	RCM - Restraints Control Module	DATA
L8A2-14C098-CA.vbf	Not specified	RCM - Restraints Control Module	DATA
L8A2-14C098-CB.vbf	Not specified	RCM - Restraints Control Module	DATA
L8A2-14C197-AB.vbf	Not specified	BECM - Battery Energy Control Module	EXE
L8A2-14C366-AA.vbf	Not specified	TCCM - Transfer Case Control Module	EXE
L8A2-14C368-AA.vbf	Not specified	TCCM - Transfer Case Control Module	SBL
L8A2-14C570-BAB.vbf	Not specified	PCM - Powertrain Control Module	EXE
L8A2-14C570-BAC.vbf	Not specified	PCM - Powertrain Control Module	EXE
L8A2-14C570-BAD.vbf	Not specified	PCM - Powertrain Control Module	EXE
L8A2-14C570-BAE.vbf	Not specified	PCM - Powertrain Control Module	EXE
L8A2-14C570-BAF.vbf	Not specified	PCM - Powertrain Control Module	EXE
L8A2-14C570-BCB.vbf	Not specified	PCM - Powertrain Control Module	EXE
L8A2-14C570-BCC.vbf	Not specified	PCM - Powertrain Control Module	EXE
L8A2-14C570-BCD.vbf	Not specified	PCM - Powertrain Control Module	EXE
L8A2-14C570-BCE.vbf	Not specified	PCM - Powertrain Control Module	EXE
L8A2-14C570-BCF.vbf	Not specified	PCM - Powertrain Control Module	EXE
L8A2-14C570-BEB.vbf	Not specified	PCM - Powertrain Control Module	EXE
L8A2-14C570-BEC.vbf	Not specified	PCM - Powertrain Control Module	EXE
L8A2-14C570-BED.vbf	Not specified	PCM - Powertrain Control Module	EXE
L8A2-14C570-BEE.vbf	Not specified	PCM - Powertrain Control Module	EXE
L8A2-14C570-BEF.vbf	Not specified	PCM - Powertrain Control Module	EXE
L8A2-14C570-BFB.vbf	Not specified	PCM - Powertrain Control Module	EXE
L8A2-14C570-BFC.vbf	Not specified	PCM - Powertrain Control Module	EXE
L8A2-14C570-BFD.vbf	Not specified	PCM - Powertrain Control Module	EXE
L8A2-14C570-BFE.vbf	Not specified	PCM - Powertrain Control Module	EXE
L8A2-14C570-BFF.vbf	Not specified	PCM - Powertrain Control Module	EXE
L8A2-14C570-BGA.vbf	Not specified	PCM - Powertrain Control Module	EXE
L8A2-14C570-BGB.vbf	Not specified	PCM - Powertrain Control Module	EXE
L8A2-14C570-BGC.vbf	Not specified	PCM - Powertrain Control Module	EXE
L8A2-14C570-BGD.vbf	Not specified	PCM - Powertrain Control Module	EXE
L8A2-14C570-BGE.vbf	Not specified	PCM - Powertrain Control Module	EXE
L8A2-14C570-BGF.vbf	Not specified	PCM - Powertrain Control Module	EXE
L8A2-14C570-BGG.vbf	Not specified	PCM - Powertrain Control Module	EXE
L8A2-14C570-BHA.vbf	Not specified	PCM - Powertrain Control Module	EXE
L8A2-14C570-BHB.vbf	Not specified	PCM - Powertrain Control Module	EXE
L8A2-14C570-BHC.vbf	Not specified	PCM - Powertrain Control Module	EXE
L8A2-14C570-BHD.vbf	Not specified	PCM - Powertrain Control Module	EXE
L8A2-14C570-BHE.vbf	Not specified	PCM - Powertrain Control Module	EXE
L8A2-14C570-BHF.vbf	Not specified	PCM - Powertrain Control Module	EXE
L8A2-14C570-BHG.vbf	Not specified	PCM - Powertrain Control Module	EXE
L8A2-14C570-BLB.vbf	Not specified	PCM - Powertrain Control Module	EXE
L8A2-14C570-BLC.vbf	Not specified	PCM - Powertrain Control Module	EXE
L8A2-14C570-BLD.vbf	Not specified	PCM - Powertrain Control Module	EXE
L8A2-14C570-BLE.vbf	Not specified	PCM - Powertrain Control Module	EXE
L8A2-14C570-BLF.vbf	Not specified	PCM - Powertrain Control Module	EXE
L8A2-14C570-BNB.vbf	Not specified	PCM - Powertrain Control Module	EXE
L8A2-14C570-BNC.vbf	Not specified	PCM - Powertrain Control Module	EXE
L8A2-14C570-BND.vbf	Not specified	PCM - Powertrain Control Module	EXE
L8A2-14C570-BNE.vbf	Not specified	PCM - Powertrain Control Module	EXE
L8A2-14C570-BNF.vbf	Not specified	PCM - Powertrain Control Module	EXE
L8A2-14C570-BPA.vbf	Not specified	PCM - Powertrain Control Module	EXE
L8A2-14C570-BPB.vbf	Not specified	PCM - Powertrain Control Module	EXE
L8A2-14C570-BPC.vbf	Not specified	PCM - Powertrain Control Module	EXE
L8A2-14C570-BPD.vbf	Not specified	PCM - Powertrain Control Module	EXE
L8A2-14C570-BPE.vbf	Not specified	PCM - Powertrain Control Module	EXE
L8A2-14C570-BRB.vbf	Not specified	PCM - Powertrain Control Module	EXE
L8A2-14C570-BRC.vbf	Not specified	PCM - Powertrain Control Module	EXE
L8A2-14C570-BRD.vbf	Not specified	PCM - Powertrain Control Module	EXE
L8A2-14C570-BRE.vbf	Not specified	PCM - Powertrain Control Module	EXE
L8A2-14C570-BRF.vbf	Not specified	PCM - Powertrain Control Module	EXE
L8A2-14C570-BRG.vbf	Not specified	PCM - Powertrain Control Module	EXE
L8A2-14C570-BTB.vbf	Not specified	PCM - Powertrain Control Module	EXE
L8A2-14C570-BTC.vbf	Not specified	PCM - Powertrain Control Module	EXE
L8A2-14C570-BTD.vbf	Not specified	PCM - Powertrain Control Module	EXE
L8A2-14C570-BTE.vbf	Not specified	PCM - Powertrain Control Module	EXE
L8A2-14C570-BTF.vbf	Not specified	PCM - Powertrain Control Module	EXE
L8A2-14C570-BUB.vbf	Not specified	PCM - Powertrain Control Module	EXE
L8A2-14C570-BUC.vbf	Not specified	PCM - Powertrain Control Module	EXE
L8A2-14C570-BUD.vbf	Not specified	PCM - Powertrain Control Module	EXE
L8A2-14C570-BUE.vbf	Not specified	PCM - Powertrain Control Module	EXE
L8A2-14C570-BUF.vbf	Not specified	PCM - Powertrain Control Module	EXE
L8B2-14A752-AG.vbf	Not specified	Not specified	EXE
L8B2-14A752-AH.vbf	Not specified	Not specified	EXE

File name	Vehicle line (indicative)	Module (ECU)	Type
L8B2-14A752-AJ.vbf	Not specified	Not specified	EXE
L8B2-14A752-BA.vbf	Not specified	Not specified	EXE
L8B2-14A752-CA.vbf	Not specified	Not specified	EXE
L8B2-14A752-DA.vbf	Not specified	Not specified	EXE
L8B2-14A752-EA.vbf	Not specified	Not specified	EXE
L8B2-14A754-AA.vbf	Not specified	Not specified	SBL
L8B2-14C025-KA.vbf	Not specified	IPC - Instrument Panel Cluster (IPC) Control Module	SBL
L8B2-14C026-LA.vbf	Not specified	IPC - Instrument Panel Cluster (IPC) Control Module	EXE
L8B2-14C064-AF.vbf	Not specified	DDM - Driver Front Door Module	EXE
L8B2-14C064-AG.vbf	Not specified	DDM - Driver Front Door Module	EXE
L8B2-14C064-AH.vbf	Not specified	DDM - Driver Front Door Module	EXE
L8B2-14C067-AA.vbf	Not specified	DDM - Driver Front Door Module	SBL
L8B2-14C068-AF.vbf	Not specified	DRDM - Driver Rear Door Module	EXE
L8B2-14C068-AG.vbf	Not specified	DRDM - Driver Rear Door Module	EXE
L8B2-14C068-AH.vbf	Not specified	DRDM - Driver Rear Door Module	EXE
L8B2-14C071-AA.vbf	Not specified	DRDM - Driver Rear Door Module	SBL
L8B2-14C084-AB.vbf	Not specified	HCM - Headlamp Control Module #1	EXE
L8B2-14C084-AC.vbf	Not specified	HCM - Headlamp Control Module #1	EXE
L8B2-14C084-AD.vbf	Not specified	HCM - Headlamp Control Module #1	EXE
L8B2-14C084-AE.vbf	Not specified	HCM - Headlamp Control Module #1	EXE
L8B2-14C084-BB.vbf	Not specified	Not specified	EXE
L8B2-14C084-BC.vbf	Not specified	Not specified	EXE
L8B2-14C084-BD.vbf	Not specified	Not specified	EXE
L8B2-14C084-BE.vbf	Not specified	Not specified	EXE
L8B2-14C104-AD.vbf	Not specified	RFA - Remote Function Actuator	EXE
L8B2-14C104-AE.vbf	Not specified	RFA - Remote Function Actuator	EXE
L8B2-14C104-AF.vbf	Not specified	RFA - Remote Function Actuator	EXE
L8B2-14C108-AF.vbf	Not specified	PDM - Passenger Front Door Module	EXE
L8B2-14C108-AG.vbf	Not specified	PDM - Passenger Front Door Module	EXE
L8B2-14C108-AH.vbf	Not specified	PDM - Passenger Front Door Module	EXE
L8B2-14C111-AA.vbf	Not specified	PDM - Passenger Front Door Module	SBL
L8B2-14C112-AF.vbf	Not specified	PRDM - Passenger Rear Door Module	EXE
L8B2-14C112-AG.vbf	Not specified	PRDM - Passenger Rear Door Module	EXE
L8B2-14C112-AH.vbf	Not specified	PRDM - Passenger Rear Door Module	EXE
L8B2-14C115-AA.vbf	Not specified	PRDM - Passenger Rear Door Module	SBL
L8B2-14C119-AA.vbf	Not specified	ecu_address = 0x795;	DATA
L8B2-14C119-AC.vbf	Not specified	ecu_address = 0x795;	DATA
L8B2-14C151-AA.vbf	Not specified	TPM - Tire Pressure Monitor Module	EXE
L8B2-14C184-AC.vbf	Not specified	BCM - Body Control Module	CUSTOM
L8B2-14C184-AD.vbf	Not specified	BCM - Body Control Module	CUSTOM
L8B2-14C184-AH.vbf	Not specified	BCM - Body Control Module	CUSTOM
L8B2-14C187-AD.vbf	Not specified	BCM - Body Control Module	SBL
L8B2-14C187-AE.vbf	Not specified	BCM - Body Control Module	SBL
L8B2-14C197-BC.vbf	Not specified	BECM - Battery Energy Control Module	EXE
L8B2-14C198-BC.vbf	Not specified	BECM - Battery Energy Control Module	EXE
L8B2-14C200-BA.vbf	Not specified	BECM - Battery Energy Control Module	SBL
L8B2-14C309-AD.vbf	Not specified	Not specified	EXE
L8B2-14C311-AA.vbf	Not specified	Not specified	SBL
L8B2-14C386-AC.vbf	Not specified	PSCM - Power Steering Control Module	SIGCFG
L8B2-14C386-BC.vbf	Not specified	PSCM - Power Steering Control Module	SIGCFG
L8B2-14C388-AA.vbf	Not specified	ecu_address = 0x795;	SIGCFG
L8B2-14C388-AB.vbf	Not specified	ecu_address = 0x795;	SIGCFG
L8B2-14C399-AE.vbf	Not specified	HCM - Headlamp Control Module #1	SIGCFG
L8B2-14C399-BE.vbf	Not specified	Not specified	SIGCFG
L8B2-14C408-AG.vbf	Not specified	BCM - Body Control Module	SIGCFG
L8B2-14C408-AH.vbf	Not specified	BCM - Body Control Module	SIGCFG
L8B2-14C408-AK.vbf	Not specified	BCM - Body Control Module	SIGCFG
L8B2-14C430-AB.vbf	Not specified	TMC Traffic Message Channel Module	EXE
L8B2-14C434-AC.vbf	Not specified	TPM - Tire Pressure Monitor Module	SIGCFG
L8B2-14C561-AD.vbf	Defender (L663)	GSM - Gear Shift Module	EXE
L8B2-14C561-AE.vbf	Defender (L663)	GSM - Gear Shift Module	EXE
L8B2-14C563-AB.vbf	Not specified	GSM - Gear Shift Module	SBL
L8B2-14C572-BA.vbf	Not specified	PCM - Powertrain Control Module	SBL
L8B2-14D370-BB.vbf	Not specified	SODR - Side Obstacle Detection Control Module - Right	SBL
L8B2-14D458-AC.vbf	Not specified	EPICD - Electric Power Inverter Converter Control Module	SIGCFG
L8B2-14D459-AC.vbf	Not specified	EPICD - Electric Power Inverter Converter Control Module	EXE
L8B2-14E093-KH.vbf	Not specified	CHCM - Chassis Control Module	EXE
L8B2-14E093-KJ.vbf	Not specified	CHCM - Chassis Control Module	EXE
L8B2-14E093-SB.vbf	Not specified	CHCM - Chassis Control Module	EXE
L8B2-14E095-AC.vbf	Not specified	CHCM - Chassis Control Module	SBL
L8B2-14E282-AB.vbf	Not specified	WDCM - WirelessCharger	EXE
L8B2-14E282-AC.vbf	Not specified	WDCM - WirelessCharger	EXE
L8B2-14E284-AB.vbf	Not specified	WDCM - WirelessCharger	SBL
L8B2-14E284-AC.vbf	Not specified	WDCM - WirelessCharger	SBL
L8B2-14F216-AA.vbf	Not specified	RHVAC - Rear HVAC Control Module	SIGCFG
L8B2-14F217-AB.vbf	Not specified	RHVAC - Rear HVAC Control Module	EXE

File name	Vehicle line (indicative)	Module (ECU)	Type
L8B2-14F229-AD.vbf	Not specified	HUD - Head Up Display	SIGCFG
L8B2-14F230-BA.vbf	Not specified	HUD - Head Up Display	DATA
L8B2-14F530-CE.vbf	Not specified	GWM - Gateway Module A	EXE
L8B2-14F530-CF.vbf	Not specified	GWM - Gateway Module A	EXE
L8B2-14F530-CG.vbf	Not specified	GWM - Gateway Module A	EXE
L8B2-14F532-AE.vbf	Not specified	GWM - Gateway Module A	SBL
L8B2-14G131-AA.vbf	X950	EPIC - Electric Power Inverter Converter Control Module	EXE
L8B2-14G131-BD.vbf	Not specified	SGM - Starter / Generator Control Module	EXE
L8B2-14G132-AA.vbf	X950	EPIC - Electric Power Inverter Converter Control Module	DATA
L8B2-19C273-AB.vbf	Not specified	LPDM - Left Power Sliding Door Module	EXE
L8B2-19C273-AD.vbf	Not specified	LPDM - Left Power Sliding Door Module	EXE
L8B2-19L322-BF.vbf	Not specified	Not specified	EXE
L8B2-19L322-BG.vbf	Not specified	Not specified	EXE
L8B2-19L322-BH.vbf	Not specified	Not specified	EXE
L8B2-19L322-BJ.vbf	Not specified	Not specified	EXE
L8B2-19L322-BK.vbf	Not specified	Not specified	EXE
L8B2-19L322-BM.vbf	Not specified	Not specified	EXE
L8B2-19L324-AE.vbf	Not specified	IMC - Infotainment Master Controller	SBL
L8B2-19L324-AF.vbf	Not specified	IMC - Infotainment Master Controller	SBL
L8B2-19L324-AG.vbf	Not specified	IMC - Infotainment Master Controller	SBL
L8B2-4C045-AA.vbf	Jaguar X400	ecu_address = 0x795;	EXE
L8B2-4C045-AC.vbf	Jaguar X400	ecu_address = 0x795;	EXE
L8BM-19H535-AA.vbf	Not specified	TBM - Trailer Brake Control Module	SIGCFG
L8BM-19H536-AC.vbf	Not specified	TBM - Trailer Brake Control Module	EXE
L8D2-12K532-FVA.vbf	Check in SDD (unconfirmed)	PCM - Powertrain Control Module	EXE
L8D2-12K532-FVB.vbf	Check in SDD (unconfirmed)	PCM - Powertrain Control Module	EXE
L8D2-12K532-FVC.vbf	Check in SDD (unconfirmed)	PCM - Powertrain Control Module	EXE
L8D2-14A752-AE.vbf	Check in SDD (unconfirmed)	Not specified	EXE
L8D2-14A752-AF.vbf	Check in SDD (unconfirmed)	Not specified	EXE
L8D2-14A752-AJ.vbf	Check in SDD (unconfirmed)	Not specified	EXE
L8D2-14A752-BA.vbf	Check in SDD (unconfirmed)	Not specified	EXE
L8D2-14A752-BB.vbf	Check in SDD (unconfirmed)	Not specified	EXE
L8D2-14A753-AA.vbf	Check in SDD (unconfirmed)	Not specified	EXE
L8D2-14A753-AC.vbf	Check in SDD (unconfirmed)	Not specified	EXE
L8D2-14A753-BA.vbf	Check in SDD (unconfirmed)	Not specified	EXE
L8D2-14A753-BB.vbf	Check in SDD (unconfirmed)	Not specified	EXE
L8D2-14A753-BC.vbf	Check in SDD (unconfirmed)	Not specified	EXE
L8D2-14A754-AA.vbf	Check in SDD (unconfirmed)	Not specified	SBL
L8D2-14A754-AB.vbf	Check in SDD (unconfirmed)	Not specified	SBL
L8D2-14C036-AC.vbf	Check in SDD (unconfirmed)	ABS - Anti-Lock Brake System Control Module	EXE
L8D2-14C036-AD.vbf	Check in SDD (unconfirmed)	ABS - Anti-Lock Brake System Control Module	EXE
L8D2-14C036-AE.vbf	Check in SDD (unconfirmed)	ABS - Anti-Lock Brake System Control Module	EXE
L8D2-14C036-AG.vbf	Check in SDD (unconfirmed)	ABS - Anti-Lock Brake System Control Module	EXE
L8D2-14C036-AH.vbf	Check in SDD (unconfirmed)	ABS - Anti-Lock Brake System Control Module	EXE
L8D2-14C039-AB.vbf	Check in SDD (unconfirmed)	ABS - Anti-Lock Brake System Control Module	SBL
L8D2-14C039-AC.vbf	Check in SDD (unconfirmed)	ABS - Anti-Lock Brake System Control Module	SBL
L8D2-14C039-AD.vbf	Check in SDD (unconfirmed)	ABS - Anti-Lock Brake System Control Module	SBL
L8D2-14C197-AB.vbf	Check in SDD (unconfirmed)	BECM - Battery Energy Control Module	EXE
L8D2-14C197-AC.vbf	Check in SDD (unconfirmed)	BECM - Battery Energy Control Module	EXE
L8D2-14C197-AD.vbf	Check in SDD (unconfirmed)	BECM - Battery Energy Control Module	EXE
L8D2-14C197-BD.vbf	Check in SDD (unconfirmed)	BECM - Battery Energy Control Module	EXE
L8D2-14C200-BA.vbf	Check in SDD (unconfirmed)	BECM - Battery Energy Control Module	SBL
L8D2-14C337-DEA.vbf	Check in SDD (unconfirmed)	TCM - Transmission Control Module	EXE
L8D2-14C337-DEB.vbf	Check in SDD (unconfirmed)	TCM - Transmission Control Module	EXE
L8D2-14C337-RAA.vbf	Check in SDD (unconfirmed)	TCM - Transmission Control Module	EXE
L8D2-14C337-RAB.vbf	Check in SDD (unconfirmed)	TCM - Transmission Control Module	EXE
L8D2-14C337-RAC.vbf	Check in SDD (unconfirmed)	TCM - Transmission Control Module	EXE
L8D2-14C337-RAD.vbf	Check in SDD (unconfirmed)	TCM - Transmission Control Module	EXE
L8D2-14C337-RAE.vbf	Check in SDD (unconfirmed)	TCM - Transmission Control Module	EXE
L8D2-14C339-AA.vbf	Check in SDD (unconfirmed)	TCM - Transmission Control Module	SBL
L8D2-14C526-BA.vbf	Check in SDD (unconfirmed)	AAM - Audio Amplifier Module	EXE
L8D2-14C570-MPB.vbf	Check in SDD (unconfirmed)	PCM - Powertrain Control Module	EXE
L8D2-14C570-MPC.vbf	Check in SDD (unconfirmed)	PCM - Powertrain Control Module	EXE
L8D2-14C570-MPD.vbf	Check in SDD (unconfirmed)	PCM - Powertrain Control Module	EXE
L8D2-14C570-PPB.vbf	Check in SDD (unconfirmed)	PCM - Powertrain Control Module	EXE
L8D2-14C570-PPD.vbf	Check in SDD (unconfirmed)	PCM - Powertrain Control Module	EXE
L8D2-14C570-PPE.vbf	Check in SDD (unconfirmed)	PCM - Powertrain Control Module	EXE
L8D2-14C570-PPF.vbf	Check in SDD (unconfirmed)	PCM - Powertrain Control Module	EXE
L8D2-14C570-PPG.vbf	Check in SDD (unconfirmed)	PCM - Powertrain Control Module	EXE
L8D2-14C570-PPH.vbf	Check in SDD (unconfirmed)	PCM - Powertrain Control Module	EXE
L8D2-14C570-PPJ.vbf	Check in SDD (unconfirmed)	PCM - Powertrain Control Module	EXE
L8D2-14C570-PRB.vbf	Check in SDD (unconfirmed)	PCM - Powertrain Control Module	EXE
L8D2-14C570-PRD.vbf	Check in SDD (unconfirmed)	PCM - Powertrain Control Module	EXE
L8D2-14C570-PRE.vbf	Check in SDD (unconfirmed)	PCM - Powertrain Control Module	EXE
L8D2-14C570-PRF.vbf	Check in SDD (unconfirmed)	PCM - Powertrain Control Module	EXE
L8D2-14C570-PRG.vbf	Check in SDD (unconfirmed)	PCM - Powertrain Control Module	EXE

File name	Vehicle line (indicative)	Module (ECU)	Type
L8D2-14C570-PRH.vbf	Check in SDD (unconfirmed)	PCM - Powertrain Control Module	EXE
L8D2-14C570-PRJ.vbf	Check in SDD (unconfirmed)	PCM - Powertrain Control Module	EXE
L8D2-14C570-PUD.vbf	Check in SDD (unconfirmed)	PCM - Powertrain Control Module	EXE
L8D2-14C572-BC.vbf	Check in SDD (unconfirmed)	PCM - Powertrain Control Module	SBL
L8D2-14C572-BD.VBF	Check in SDD (unconfirmed)	PCM - Powertrain Control Module	SBL
L8D2-14F530-FB.vbf	Check in SDD (unconfirmed)	GWM - Gateway Module A	EXE
L8D2-14F530-FC.vbf	Check in SDD (unconfirmed)	GWM - Gateway Module A	EXE
L8D2-14F530-FD.vbf	Check in SDD (unconfirmed)	GWM - Gateway Module A	EXE
L8D2-14F530-FE.vbf	Check in SDD (unconfirmed)	GWM - Gateway Module A	EXE
L8D2-14F530-FG.vbf	Check in SDD (unconfirmed)	GWM - Gateway Module A	EXE
L8D2-14F530-GA.vbf	Check in SDD (unconfirmed)	GWM - Gateway Module A	EXE
L8D2-14F530-GB.vbf	Check in SDD (unconfirmed)	GWM - Gateway Module A	EXE
L8D2-14F530-GC.vbf	Check in SDD (unconfirmed)	GWM - Gateway Module A	EXE
L8D2-14F530-GD.vbf	Check in SDD (unconfirmed)	GWM - Gateway Module A	EXE
L8D2-14F530-GF.vbf	Check in SDD (unconfirmed)	GWM - Gateway Module A	EXE
L8D2-14F530-HB.vbf	Check in SDD (unconfirmed)	GWM - Gateway Module A	EXE
L8D2-14F530-HC.vbf	Check in SDD (unconfirmed)	GWM - Gateway Module A	EXE
L8D2-14F530-HD.vbf	Check in SDD (unconfirmed)	GWM - Gateway Module A	EXE
L8D2-14F530-JB.vbf	Check in SDD (unconfirmed)	GWM - Gateway Module A	EXE
L8D2-14F530-JC.vbf	Check in SDD (unconfirmed)	GWM - Gateway Module A	EXE
L8D2-14F530-JD.vbf	Check in SDD (unconfirmed)	GWM - Gateway Module A	EXE
L8D2-14F531-FB.vbf	Check in SDD (unconfirmed)	GWM - Gateway Module A	DATA
L8D2-14F531-FC.vbf	Check in SDD (unconfirmed)	GWM - Gateway Module A	DATA
L8D2-14F531-FD.vbf	Check in SDD (unconfirmed)	GWM - Gateway Module A	DATA
L8D2-14F531-FF.vbf	Check in SDD (unconfirmed)	GWM - Gateway Module A	DATA
L8D2-14F531-GA.vbf	Check in SDD (unconfirmed)	GWM - Gateway Module A	DATA
L8D2-14F531-GB.vbf	Check in SDD (unconfirmed)	GWM - Gateway Module A	DATA
L8D2-14F531-GC.vbf	Check in SDD (unconfirmed)	GWM - Gateway Module A	DATA
L8D2-14F531-GE.vbf	Check in SDD (unconfirmed)	GWM - Gateway Module A	DATA
L8D2-14F531-HB.vbf	Check in SDD (unconfirmed)	GWM - Gateway Module A	DATA
L8D2-14F531-HC.vbf	Check in SDD (unconfirmed)	GWM - Gateway Module A	DATA
L8D2-14F531-JB.vbf	Check in SDD (unconfirmed)	GWM - Gateway Module A	DATA
L8D2-14F531-JC.vbf	Check in SDD (unconfirmed)	GWM - Gateway Module A	DATA
L8D2-14G121-AE.vbf	Check in SDD (unconfirmed)	EPICB - Electric Power Inverter Converter Control Module B	EXE
L8D2-14G121-AF.vbf	Check in SDD (unconfirmed)	EPICB - Electric Power Inverter Converter Control Module B	EXE
L8D2-14G121-AG.vbf	Check in SDD (unconfirmed)	EPICB - Electric Power Inverter Converter Control Module B	EXE
L8D2-14G123-AD.vbf	Check in SDD (unconfirmed)	EPICB - Electric Power Inverter Converter Control Module B	SBL
L8D2-14G123-AE.vbf	Check in SDD (unconfirmed)	EPICB - Electric Power Inverter Converter Control Module B	SBL
L8D2-14G123-AF.vbf	Check in SDD (unconfirmed)	EPICB - Electric Power Inverter Converter Control Module B	SBL
L8D2-14G131-AA.vbf	Check in SDD (unconfirmed)	EPIC - Electric Power Inverter Converter Control Module	EXE
L8D2-14G131-BB.vbf	Check in SDD (unconfirmed)	SOBDMB - Secondary OBD Control Module B	EXE
L8D2-14G132-AB.vbf	Check in SDD (unconfirmed)	SOBDMB - Secondary OBD Control Module B	EXE
L8D2-14G132-AE.vbf	Check in SDD (unconfirmed)	EPIC - Electric Power Inverter Converter Control Module	EXE
L8D2-14G132-BB.vbf	Check in SDD (unconfirmed)	SOBDMB - Secondary OBD Control Module B	EXE
L8D2-14G133-AA.vbf	Check in SDD (unconfirmed)	EPIC - Electric Power Inverter Converter Control Module	SBL
L9A3-14C527-BA.vbf	Not specified	AAM - Audio Amplifier Module	DATA
L9A3-14C527-BAA.vbf	Not specified	AAM - Audio Amplifier Module	DATA
L9A3-14C527-BBA.vbf	Not specified	AAM - Audio Amplifier Module	DATA
L9A3-14C527-CA.vbf	Not specified	AAM - Audio Amplifier Module	DATA
L9A3-14C527-CAA.vbf	Not specified	AAM - Audio Amplifier Module	DATA
L9A3-14C527-CBA.vbf	Not specified	AAM - Audio Amplifier Module	DATA
L9C3-14C570-BAA.vbf	Check in SDD (unconfirmed)	PCM - Powertrain Control Module	EXE
L9C3-14C570-BAB.vbf	Check in SDD (unconfirmed)	PCM - Powertrain Control Module	EXE
L9C3-14C570-BAC.vbf	Check in SDD (unconfirmed)	PCM - Powertrain Control Module	EXE
L9C3-14C570-BAD.vbf	Check in SDD (unconfirmed)	PCM - Powertrain Control Module	EXE
L9C3-14C570-BGA.vbf	Check in SDD (unconfirmed)	PCM - Powertrain Control Module	EXE
L9C3-14C570-BGB.vbf	Check in SDD (unconfirmed)	PCM - Powertrain Control Module	EXE
L9C3-14C570-BGC.vbf	Check in SDD (unconfirmed)	PCM - Powertrain Control Module	EXE
L9C3-14C570-BGD.vbf	Check in SDD (unconfirmed)	PCM - Powertrain Control Module	EXE
L9C3-14C570-BHA.vbf	Check in SDD (unconfirmed)	PCM - Powertrain Control Module	EXE
L9C3-14C570-BHB.vbf	Check in SDD (unconfirmed)	PCM - Powertrain Control Module	EXE
L9C3-14C570-BHC.vbf	Check in SDD (unconfirmed)	PCM - Powertrain Control Module	EXE
L9C3-14C570-BRA.vbf	Check in SDD (unconfirmed)	PCM - Powertrain Control Module	EXE
L9C3-14C570-BRB.vbf	Check in SDD (unconfirmed)	PCM - Powertrain Control Module	EXE
L9C3-14C570-BRC.vbf	Check in SDD (unconfirmed)	PCM - Powertrain Control Module	EXE
L9D3-14C526-CA.vbf	Not specified	AAM - Audio Amplifier Module	EXE
L9W3-14C034-AA.vbf	Jaguar XE (X760)	PSM - Passenger Front Seat Module	EXE
L9W3-14C034-BA.vbf	Jaguar XE (X760)	PSM - Passenger Front Seat Module	EXE
L9W3-14C037-AAD.vbf	Jaguar XE (X760)	ABS - Anti-Lock Brake System Control Module	DATA
L9W3-14C037-AAE.vbf	Jaguar XE (X760)	ABS - Anti-Lock Brake System Control Module	DATA
L9W3-14C037-ABD.vbf	Jaguar XE (X760)	ABS - Anti-Lock Brake System Control Module	DATA
L9W3-14C037-ABE.vbf	Jaguar XE (X760)	ABS - Anti-Lock Brake System Control Module	DATA
L9W3-14C037-ACD.vbf	Jaguar XE (X760)	ABS - Anti-Lock Brake System Control Module	DATA
L9W3-14C037-ACE.vbf	Jaguar XE (X760)	ABS - Anti-Lock Brake System Control Module	DATA
L9W3-14C037-ADD.vbf	Jaguar XE (X760)	ABS - Anti-Lock Brake System Control Module	DATA
L9W3-14C037-ADE.vbf	Jaguar XE (X760)	ABS - Anti-Lock Brake System Control Module	DATA

File name	Vehicle line (indicative)	Module (ECU)	Type
L9W3-14C037-MAD.vbf	Jaguar XE (X760)	ABS - Anti-Lock Brake System Control Module	DATA
L9W3-14C037-MAE.vbf	Jaguar XE (X760)	ABS - Anti-Lock Brake System Control Module	DATA
L9W3-14C037-MBD.vbf	Jaguar XE (X760)	ABS - Anti-Lock Brake System Control Module	DATA
L9W3-14C037-MBE.vbf	Jaguar XE (X760)	ABS - Anti-Lock Brake System Control Module	DATA
L9W3-14C037-MCD.vbf	Jaguar XE (X760)	ABS - Anti-Lock Brake System Control Module	DATA
L9W3-14C037-MCE.vbf	Jaguar XE (X760)	ABS - Anti-Lock Brake System Control Module	DATA
L9W3-14C037-MDD.vbf	Jaguar XE (X760)	ABS - Anti-Lock Brake System Control Module	DATA
L9W3-14C037-MDE.vbf	Jaguar XE (X760)	ABS - Anti-Lock Brake System Control Module	DATA
L9W3-14C065-AD.vbf	Jaguar XE (X760)	DDM - Driver Front Door Module	DATA
L9W3-14C065-AF.vbf	Jaguar XE (X760)	DDM - Driver Front Door Module	DATA
L9W3-14C069-AD.vbf	Jaguar XE (X760)	DRDM - Driver Rear Door Module	DATA
L9W3-14C069-AF.vbf	Jaguar XE (X760)	DRDM - Driver Rear Door Module	DATA
L9W3-14C091-AA.vbf	Jaguar XE (X760)	PAM - Parking Assist Control Module	DATA
L9W3-14C091-AB.vbf	Jaguar XE (X760)	PAM - Parking Assist Control Module	DATA
L9W3-14C091-AD.vbf	Jaguar XE (X760)	PAM - Parking Assist Control Module	DATA
L9W3-14C105-AA.VBF	Jaguar XE (X760)	TMC Traffic Message Channel Module	EXE
L9W3-14C105-AB.vbf	Jaguar XE (X760)	TMC Traffic Message Channel Module	EXE
L9W3-14C105-BA.VBF	Jaguar XE (X760)	TMC Traffic Message Channel Module	EXE
L9W3-14C109-AD.vbf	Jaguar XE (X760)	PDM - Passenger Front Door Module	DATA
L9W3-14C109-AF.vbf	Jaguar XE (X760)	PDM - Passenger Front Door Module	DATA
L9W3-14C113-AD.vbf	Jaguar XE (X760)	PRDM - Passenger Rear Door Module	DATA
L9W3-14C113-AF.vbf	Jaguar XE (X760)	PRDM - Passenger Rear Door Module	DATA
L9W3-14C527-AA.vbf	Jaguar XE (X760)	AAM - Audio Amplifier Module	DATA
L9W3-14C527-AAA.vbf	Jaguar XE (X760)	AAM - Audio Amplifier Module	DATA
L9W3-14C527-AB.vbf	Jaguar XE (X760)	AAM - Audio Amplifier Module	DATA
L9W3-14C527-BA.vbf	Jaguar XE (X760)	AAM - Audio Amplifier Module	DATA
L9W3-14C527-BAA.vbf	Jaguar XE (X760)	AAM - Audio Amplifier Module	DATA
L9W3-14C527-BB.vbf	Jaguar XE (X760)	AAM - Audio Amplifier Module	DATA
L9W3-14C527-CA.vbf	Jaguar XE (X760)	AAM - Audio Amplifier Module	DATA
L9W3-14C527-CAA.vbf	Jaguar XE (X760)	AAM - Audio Amplifier Module	DATA
L9W3-14C527-CB.vbf	Jaguar XE (X760)	AAM - Audio Amplifier Module	DATA
L9W3-14C548-AA.vbf	Jaguar XE (X760)	PSM - Passenger Front Seat Module	EXE
L9W3-14C549-AA.vbf	Jaguar XE (X760)	PSM - Passenger Front Seat Module	EXE
L9W3-14C549-BA.vbf	Jaguar XE (X760)	PSM - Passenger Front Seat Module	EXE
L9W3-14C570-MPB.vbf	Jaguar XE (X760)	PCM - Powertrain Control Module	EXE
L9W3-14C570-MPC.vbf	Jaguar XE (X760)	PCM - Powertrain Control Module	EXE
L9W3-14C570-MPD.vbf	Jaguar XE (X760)	PCM - Powertrain Control Module	EXE
L9W3-14D485-AA.vbf	Jaguar XE (X760)	IPMB - Image Processing Module B	EXE
L9W3-14E094-DAA.vbf	Jaguar XE (X760)	CHCM - Chassis Control Module	EXE
L9W3-14F022-AA.vbf	Jaguar XE (X760)	IPMB - Image Processing Module B	DATA
L9W3-14F022-AB.vbf	Jaguar XE (X760)	IPMB - Image Processing Module B	DATA
L9W3-7J104-GBA.vbf	Jaguar XE (X760)	TCM - Transmission Control Module	EXE
L9W3-7J104-GBB.vbf	Jaguar XE (X760)	TCM - Transmission Control Module	EXE
L9W3-7J104-GBC.vbf	Jaguar XE (X760)	TCM - Transmission Control Module	EXE
LK52-12K532-PKA.vbf	Range Rover (L405)	PCM - Powertrain Control Module	EXE
LK52-12K532-PKB.vbf	Range Rover (L405)	PCM - Powertrain Control Module	EXE
LK52-14C037-ABB.vbf	Range Rover (L405)	ABS - Anti-Lock Brake System Control Module	DATA
LK52-14C037-ABC.vbf	Range Rover (L405)	ABS - Anti-Lock Brake System Control Module	DATA
LK52-14C037-ABD.vbf	Range Rover (L405)	ABS - Anti-Lock Brake System Control Module	DATA
LK52-14C037-ABE.vbf	Range Rover (L405)	ABS - Anti-Lock Brake System Control Module	DATA
LK52-14C037-ABG.vbf	Range Rover (L405)	ABS - Anti-Lock Brake System Control Module	DATA
LK52-14C037-ACB.vbf	Range Rover (L405)	ABS - Anti-Lock Brake System Control Module	DATA
LK52-14C037-ACC.vbf	Range Rover (L405)	ABS - Anti-Lock Brake System Control Module	DATA
LK52-14C037-ACD.vbf	Range Rover (L405)	ABS - Anti-Lock Brake System Control Module	DATA
LK52-14C037-ACE.vbf	Range Rover (L405)	ABS - Anti-Lock Brake System Control Module	DATA
LK52-14C037-ACF.vbf	Range Rover (L405)	ABS - Anti-Lock Brake System Control Module	DATA
LK52-14C037-ACG.vbf	Range Rover (L405)	ABS - Anti-Lock Brake System Control Module	DATA
LK52-14C037-ACH.vbf	Range Rover (L405)	ABS - Anti-Lock Brake System Control Module	DATA
LK52-14C037-ADB.vbf	Range Rover (L405)	ABS - Anti-Lock Brake System Control Module	DATA
LK52-14C037-ADC.vbf	Range Rover (L405)	ABS - Anti-Lock Brake System Control Module	DATA
LK52-14C037-ADD.vbf	Range Rover (L405)	ABS - Anti-Lock Brake System Control Module	DATA
LK52-14C037-ADE.vbf	Range Rover (L405)	ABS - Anti-Lock Brake System Control Module	DATA
LK52-14C037-ADG.vbf	Range Rover (L405)	ABS - Anti-Lock Brake System Control Module	DATA
LK52-14C037-AMB.vbf	Range Rover (L405)	ABS - Anti-Lock Brake System Control Module	DATA
LK52-14C037-AMC.vbf	Range Rover (L405)	ABS - Anti-Lock Brake System Control Module	DATA
LK52-14C037-AMD.vbf	Range Rover (L405)	ABS - Anti-Lock Brake System Control Module	DATA
LK52-14C037-AME.vbf	Range Rover (L405)	ABS - Anti-Lock Brake System Control Module	DATA
LK52-14C037-AMG.vbf	Range Rover (L405)	ABS - Anti-Lock Brake System Control Module	DATA
LK52-14C037-ANB.vbf	Range Rover (L405)	ABS - Anti-Lock Brake System Control Module	DATA
LK52-14C037-ANC.vbf	Range Rover (L405)	ABS - Anti-Lock Brake System Control Module	DATA
LK52-14C037-AND.vbf	Range Rover (L405)	ABS - Anti-Lock Brake System Control Module	DATA
LK52-14C037-ANE.vbf	Range Rover (L405)	ABS - Anti-Lock Brake System Control Module	DATA
LK52-14C037-ANF.vbf	Range Rover (L405)	ABS - Anti-Lock Brake System Control Module	DATA
LK52-14C037-ANG.vbf	Range Rover (L405)	ABS - Anti-Lock Brake System Control Module	DATA
LK52-14C037-ANH.vbf	Range Rover (L405)	ABS - Anti-Lock Brake System Control Module	DATA
LK52-14C037-ATB.vbf	Range Rover (L405)	ABS - Anti-Lock Brake System Control Module	DATA

File name	Vehicle line (indicative)	Module (ECU)	Type
LK52-14C037-ATC.vbf	Range Rover (L405)	ABS - Anti-Lock Brake System Control Module	DATA
LK52-14C037-ATD.vbf	Range Rover (L405)	ABS - Anti-Lock Brake System Control Module	DATA
LK52-14C037-ATE.vbf	Range Rover (L405)	ABS - Anti-Lock Brake System Control Module	DATA
LK52-14C037-ATG.vbf	Range Rover (L405)	ABS - Anti-Lock Brake System Control Module	DATA
LK52-14C037-DLB.vbf	Range Rover (L405)	ABS - Anti-Lock Brake System Control Module	DATA
LK52-14C037-DLC.vbf	Range Rover (L405)	ABS - Anti-Lock Brake System Control Module	DATA
LK52-14C037-DLD.vbf	Range Rover (L405)	ABS - Anti-Lock Brake System Control Module	DATA
LK52-14C037-DLE.vbf	Range Rover (L405)	ABS - Anti-Lock Brake System Control Module	DATA
LK52-14C037-DLG.vbf	Range Rover (L405)	ABS - Anti-Lock Brake System Control Module	DATA
LK52-14C037-DMB.vbf	Range Rover (L405)	ABS - Anti-Lock Brake System Control Module	DATA
LK52-14C037-DMC.vbf	Range Rover (L405)	ABS - Anti-Lock Brake System Control Module	DATA
LK52-14C037-DMD.vbf	Range Rover (L405)	ABS - Anti-Lock Brake System Control Module	DATA
LK52-14C037-DME.vbf	Range Rover (L405)	ABS - Anti-Lock Brake System Control Module	DATA
LK52-14C037-DMG.vbf	Range Rover (L405)	ABS - Anti-Lock Brake System Control Module	DATA
LK52-14C037-DUC.vbf	Range Rover (L405)	ABS - Anti-Lock Brake System Control Module	DATA
LK52-14C037-DUD.vbf	Range Rover (L405)	ABS - Anti-Lock Brake System Control Module	DATA
LK52-14C037-DUE.vbf	Range Rover (L405)	ABS - Anti-Lock Brake System Control Module	DATA
LK52-14C037-DUG.vbf	Range Rover (L405)	ABS - Anti-Lock Brake System Control Module	DATA
LK52-14C037-DZC.vbf	Range Rover (L405)	ABS - Anti-Lock Brake System Control Module	DATA
LK52-14C037-DZD.vbf	Range Rover (L405)	ABS - Anti-Lock Brake System Control Module	DATA
LK52-14C037-DZE.vbf	Range Rover (L405)	ABS - Anti-Lock Brake System Control Module	DATA
LK52-14C037-DZG.vbf	Range Rover (L405)	ABS - Anti-Lock Brake System Control Module	DATA
LK52-14C037-EAB.vbf	Range Rover (L405)	ABS - Anti-Lock Brake System Control Module	DATA
LK52-14C037-EAC.vbf	Range Rover (L405)	ABS - Anti-Lock Brake System Control Module	DATA
LK52-14C037-EAD.vbf	Range Rover (L405)	ABS - Anti-Lock Brake System Control Module	DATA
LK52-14C037-EAE.vbf	Range Rover (L405)	ABS - Anti-Lock Brake System Control Module	DATA
LK52-14C037-EAG.vbf	Range Rover (L405)	ABS - Anti-Lock Brake System Control Module	DATA
LK52-14C037-EBB.vbf	Range Rover (L405)	ABS - Anti-Lock Brake System Control Module	DATA
LK52-14C037-EBC.vbf	Range Rover (L405)	ABS - Anti-Lock Brake System Control Module	DATA
LK52-14C037-EBD.vbf	Range Rover (L405)	ABS - Anti-Lock Brake System Control Module	DATA
LK52-14C037-EBE.vbf	Range Rover (L405)	ABS - Anti-Lock Brake System Control Module	DATA
LK52-14C037-EBG.vbf	Range Rover (L405)	ABS - Anti-Lock Brake System Control Module	DATA
LK52-14C037-ECB.vbf	Range Rover (L405)	ABS - Anti-Lock Brake System Control Module	DATA
LK52-14C037-ECC.vbf	Range Rover (L405)	ABS - Anti-Lock Brake System Control Module	DATA
LK52-14C037-ECD.vbf	Range Rover (L405)	ABS - Anti-Lock Brake System Control Module	DATA
LK52-14C037-ECE.vbf	Range Rover (L405)	ABS - Anti-Lock Brake System Control Module	DATA
LK52-14C037-ECG.vbf	Range Rover (L405)	ABS - Anti-Lock Brake System Control Module	DATA
LK52-14C037-EDB.vbf	Range Rover (L405)	ABS - Anti-Lock Brake System Control Module	DATA
LK52-14C037-EDC.vbf	Range Rover (L405)	ABS - Anti-Lock Brake System Control Module	DATA
LK52-14C037-EDD.vbf	Range Rover (L405)	ABS - Anti-Lock Brake System Control Module	DATA
LK52-14C037-EDE.vbf	Range Rover (L405)	ABS - Anti-Lock Brake System Control Module	DATA
LK52-14C037-EDG.vbf	Range Rover (L405)	ABS - Anti-Lock Brake System Control Module	DATA
LK52-14C037-EFC.vbf	Range Rover (L405)	ABS - Anti-Lock Brake System Control Module	DATA
LK52-14C037-EFD.vbf	Range Rover (L405)	ABS - Anti-Lock Brake System Control Module	DATA
LK52-14C037-EFE.vbf	Range Rover (L405)	ABS - Anti-Lock Brake System Control Module	DATA
LK52-14C037-EFG.vbf	Range Rover (L405)	ABS - Anti-Lock Brake System Control Module	DATA
LK52-14C037-EFH.vbf	Range Rover (L405)	ABS - Anti-Lock Brake System Control Module	DATA
LK52-14C037-EGC.vbf	Range Rover (L405)	ABS - Anti-Lock Brake System Control Module	DATA
LK52-14C037-EGD.vbf	Range Rover (L405)	ABS - Anti-Lock Brake System Control Module	DATA
LK52-14C037-EGE.vbf	Range Rover (L405)	ABS - Anti-Lock Brake System Control Module	DATA
LK52-14C037-EGG.vbf	Range Rover (L405)	ABS - Anti-Lock Brake System Control Module	DATA
LK52-14C037-EGH.vbf	Range Rover (L405)	ABS - Anti-Lock Brake System Control Module	DATA
LK52-14C037-EHC.vbf	Range Rover (L405)	ABS - Anti-Lock Brake System Control Module	DATA
LK52-14C037-EHD.vbf	Range Rover (L405)	ABS - Anti-Lock Brake System Control Module	DATA
LK52-14C037-EHE.vbf	Range Rover (L405)	ABS - Anti-Lock Brake System Control Module	DATA
LK52-14C037-EHG.vbf	Range Rover (L405)	ABS - Anti-Lock Brake System Control Module	DATA
LK52-14C037-EHH.vbf	Range Rover (L405)	ABS - Anti-Lock Brake System Control Module	DATA
LK52-14C037-EJC.vbf	Range Rover (L405)	ABS - Anti-Lock Brake System Control Module	DATA
LK52-14C037-EJD.vbf	Range Rover (L405)	ABS - Anti-Lock Brake System Control Module	DATA
LK52-14C037-EJE.vbf	Range Rover (L405)	ABS - Anti-Lock Brake System Control Module	DATA
LK52-14C037-EJG.vbf	Range Rover (L405)	ABS - Anti-Lock Brake System Control Module	DATA
LK52-14C037-EJH.vbf	Range Rover (L405)	ABS - Anti-Lock Brake System Control Module	DATA
LK52-14C037-FAB.vbf	Range Rover (L405)	ABS - Anti-Lock Brake System Control Module	DATA
LK52-14C037-FAC.vbf	Range Rover (L405)	ABS - Anti-Lock Brake System Control Module	DATA
LK52-14C037-FAD.vbf	Range Rover (L405)	ABS - Anti-Lock Brake System Control Module	DATA
LK52-14C037-FAE.vbf	Range Rover (L405)	ABS - Anti-Lock Brake System Control Module	DATA
LK52-14C037-FAG.vbf	Range Rover (L405)	ABS - Anti-Lock Brake System Control Module	DATA
LK52-14C037-FBB.vbf	Range Rover (L405)	ABS - Anti-Lock Brake System Control Module	DATA
LK52-14C037-FBC.vbf	Range Rover (L405)	ABS - Anti-Lock Brake System Control Module	DATA
LK52-14C037-FBD.vbf	Range Rover (L405)	ABS - Anti-Lock Brake System Control Module	DATA
LK52-14C037-FBE.vbf	Range Rover (L405)	ABS - Anti-Lock Brake System Control Module	DATA
LK52-14C037-FBG.vbf	Range Rover (L405)	ABS - Anti-Lock Brake System Control Module	DATA
LK52-14C037-FFB.vbf	Range Rover (L405)	ABS - Anti-Lock Brake System Control Module	DATA
LK52-14C037-FFC.vbf	Range Rover (L405)	ABS - Anti-Lock Brake System Control Module	DATA
LK52-14C037-FFD.vbf	Range Rover (L405)	ABS - Anti-Lock Brake System Control Module	DATA
LK52-14C037-FGB.vbf	Range Rover (L405)	ABS - Anti-Lock Brake System Control Module	DATA

File name	Vehicle line (indicative)	Module (ECU)	Type
LK52-14C037-FGC.vbf	Range Rover (L405)	ABS - Anti-Lock Brake System Control Module	DATA
LK52-14C037-FGD.vbf	Range Rover (L405)	ABS - Anti-Lock Brake System Control Module	DATA
LK52-14C037-FGE.vbf	Range Rover (L405)	ABS - Anti-Lock Brake System Control Module	DATA
LK52-14C037-FGG.vbf	Range Rover (L405)	ABS - Anti-Lock Brake System Control Module	DATA
LK52-14C037-FHB.vbf	Range Rover (L405)	ABS - Anti-Lock Brake System Control Module	DATA
LK52-14C037-FHC.vbf	Range Rover (L405)	ABS - Anti-Lock Brake System Control Module	DATA
LK52-14C037-FHD.vbf	Range Rover (L405)	ABS - Anti-Lock Brake System Control Module	DATA
LK52-14C037-FHE.vbf	Range Rover (L405)	ABS - Anti-Lock Brake System Control Module	DATA
LK52-14C037-FHG.vbf	Range Rover (L405)	ABS - Anti-Lock Brake System Control Module	DATA
LK52-14C037-FPC.vbf	Range Rover (L405)	ABS - Anti-Lock Brake System Control Module	DATA
LK52-14C037-FPD.vbf	Range Rover (L405)	ABS - Anti-Lock Brake System Control Module	DATA
LK52-14C037-FPE.vbf	Range Rover (L405)	ABS - Anti-Lock Brake System Control Module	DATA
LK52-14C037-FPG.vbf	Range Rover (L405)	ABS - Anti-Lock Brake System Control Module	DATA
LK52-14C037-FRC.vbf	Range Rover (L405)	ABS - Anti-Lock Brake System Control Module	DATA
LK52-14C037-FRD.vbf	Range Rover (L405)	ABS - Anti-Lock Brake System Control Module	DATA
LK52-14C037-FRE.vbf	Range Rover (L405)	ABS - Anti-Lock Brake System Control Module	DATA
LK52-14C037-FRG.vbf	Range Rover (L405)	ABS - Anti-Lock Brake System Control Module	DATA
LK52-14C037-FSC.vbf	Range Rover (L405)	ABS - Anti-Lock Brake System Control Module	DATA
LK52-14C037-FSD.vbf	Range Rover (L405)	ABS - Anti-Lock Brake System Control Module	DATA
LK52-14C037-FSE.vbf	Range Rover (L405)	ABS - Anti-Lock Brake System Control Module	DATA
LK52-14C037-FSG.vbf	Range Rover (L405)	ABS - Anti-Lock Brake System Control Module	DATA
LK52-14C037-FTC.vbf	Range Rover (L405)	ABS - Anti-Lock Brake System Control Module	DATA
LK52-14C037-FTD.vbf	Range Rover (L405)	ABS - Anti-Lock Brake System Control Module	DATA
LK52-14C037-FTE.vbf	Range Rover (L405)	ABS - Anti-Lock Brake System Control Module	DATA
LK52-14C037-FTG.vbf	Range Rover (L405)	ABS - Anti-Lock Brake System Control Module	DATA
LK52-14C037-GAA.vbf	Range Rover (L405)	ABS - Anti-Lock Brake System Control Module	DATA
LK52-14C037-GAB.vbf	Range Rover (L405)	ABS - Anti-Lock Brake System Control Module	DATA
LK52-14C037-GAC.vbf	Range Rover (L405)	ABS - Anti-Lock Brake System Control Module	DATA
LK52-14C037-GAD.vbf	Range Rover (L405)	ABS - Anti-Lock Brake System Control Module	DATA
LK52-14C037-GAE.vbf	Range Rover (L405)	ABS - Anti-Lock Brake System Control Module	DATA
LK52-14C037-GBA.vbf	Range Rover (L405)	ABS - Anti-Lock Brake System Control Module	DATA
LK52-14C037-GBB.vbf	Range Rover (L405)	ABS - Anti-Lock Brake System Control Module	DATA
LK52-14C037-GBC.vbf	Range Rover (L405)	ABS - Anti-Lock Brake System Control Module	DATA
LK52-14C037-GBD.vbf	Range Rover (L405)	ABS - Anti-Lock Brake System Control Module	DATA
LK52-14C037-GBE.vbf	Range Rover (L405)	ABS - Anti-Lock Brake System Control Module	DATA
LK52-14C037-GCA.vbf	Range Rover (L405)	ABS - Anti-Lock Brake System Control Module	DATA
LK52-14C037-GCB.vbf	Range Rover (L405)	ABS - Anti-Lock Brake System Control Module	DATA
LK52-14C037-GCC.vbf	Range Rover (L405)	ABS - Anti-Lock Brake System Control Module	DATA
LK52-14C037-GCD.vbf	Range Rover (L405)	ABS - Anti-Lock Brake System Control Module	DATA
LK52-14C037-GCE.vbf	Range Rover (L405)	ABS - Anti-Lock Brake System Control Module	DATA
LK52-14C037-GDA.vbf	Range Rover (L405)	ABS - Anti-Lock Brake System Control Module	DATA
LK52-14C037-GDB.vbf	Range Rover (L405)	ABS - Anti-Lock Brake System Control Module	DATA
LK52-14C037-GDC.vbf	Range Rover (L405)	ABS - Anti-Lock Brake System Control Module	DATA
LK52-14C037-GDD.vbf	Range Rover (L405)	ABS - Anti-Lock Brake System Control Module	DATA
LK52-14C037-GDE.vbf	Range Rover (L405)	ABS - Anti-Lock Brake System Control Module	DATA
LK52-14C037-GEA.vbf	Range Rover (L405)	ABS - Anti-Lock Brake System Control Module	DATA
LK52-14C037-GEB.vbf	Range Rover (L405)	ABS - Anti-Lock Brake System Control Module	DATA
LK52-14C037-GEC.vbf	Range Rover (L405)	ABS - Anti-Lock Brake System Control Module	DATA
LK52-14C037-GED.vbf	Range Rover (L405)	ABS - Anti-Lock Brake System Control Module	DATA
LK52-14C037-GFA.vbf	Range Rover (L405)	ABS - Anti-Lock Brake System Control Module	DATA
LK52-14C037-GFB.vbf	Range Rover (L405)	ABS - Anti-Lock Brake System Control Module	DATA
LK52-14C037-GFC.vbf	Range Rover (L405)	ABS - Anti-Lock Brake System Control Module	DATA
LK52-14C037-GFD.vbf	Range Rover (L405)	ABS - Anti-Lock Brake System Control Module	DATA
LK52-14C037-GGA.vbf	Range Rover (L405)	ABS - Anti-Lock Brake System Control Module	DATA
LK52-14C037-GGB.vbf	Range Rover (L405)	ABS - Anti-Lock Brake System Control Module	DATA
LK52-14C037-GGC.vbf	Range Rover (L405)	ABS - Anti-Lock Brake System Control Module	DATA
LK52-14C037-GGD.vbf	Range Rover (L405)	ABS - Anti-Lock Brake System Control Module	DATA
LK52-14C037-GHA.vbf	Range Rover (L405)	ABS - Anti-Lock Brake System Control Module	DATA
LK52-14C037-GHB.vbf	Range Rover (L405)	ABS - Anti-Lock Brake System Control Module	DATA
LK52-14C037-GHC.vbf	Range Rover (L405)	ABS - Anti-Lock Brake System Control Module	DATA
LK52-14C037-GHD.vbf	Range Rover (L405)	ABS - Anti-Lock Brake System Control Module	DATA
LK52-14C037-GJA.vbf	Range Rover (L405)	ABS - Anti-Lock Brake System Control Module	DATA
LK52-14C037-GJB.vbf	Range Rover (L405)	ABS - Anti-Lock Brake System Control Module	DATA
LK52-14C037-GJC.vbf	Range Rover (L405)	ABS - Anti-Lock Brake System Control Module	DATA
LK52-14C037-GJD.vbf	Range Rover (L405)	ABS - Anti-Lock Brake System Control Module	DATA
LK52-14C037-GKA.vbf	Range Rover (L405)	ABS - Anti-Lock Brake System Control Module	DATA
LK52-14C037-GKB.vbf	Range Rover (L405)	ABS - Anti-Lock Brake System Control Module	DATA
LK52-14C037-GKC.vbf	Range Rover (L405)	ABS - Anti-Lock Brake System Control Module	DATA
LK52-14C037-GKD.vbf	Range Rover (L405)	ABS - Anti-Lock Brake System Control Module	DATA
LK52-14C185-AA.vbf	Range Rover (L405)	BCM - Body Control Module	DATA
LK52-14C218-EA.vbf	Range Rover (L405)	PSCM - Power Steering Control Module	EXE
LK52-14C218-FA.vbf	Range Rover (L405)	PSCM - Power Steering Control Module	EXE
LK52-14C218-GA.vbf	Range Rover (L405)	PSCM - Power Steering Control Module	EXE
LK52-14C526-DA.vbf	Range Rover (L405)	AAM - Audio Amplifier Module	EXE
LK52-14C527-BA.vbf	Range Rover (L405)	AAM - Audio Amplifier Module	DATA
LK52-14C527-BHA.vbf	Range Rover (L405)	AAM - Audio Amplifier Module	DATA

File name	Vehicle line (indicative)	Module (ECU)	Type
LK52-14C527-BHB.vbf	Range Rover (L405)	AAM - Audio Amplifier Module	DATA
LK52-14C527-BJA.vbf	Range Rover (L405)	AAM - Audio Amplifier Module	DATA
LK52-14C527-BJB.vbf	Range Rover (L405)	AAM - Audio Amplifier Module	DATA
LK52-14C527-CA.vbf	Range Rover (L405)	AAM - Audio Amplifier Module	DATA
LK52-14C527-CHA.vbf	Range Rover (L405)	AAM - Audio Amplifier Module	DATA
LK52-14C527-CHB.vbf	Range Rover (L405)	AAM - Audio Amplifier Module	DATA
LK52-14C527-CJA.vbf	Range Rover (L405)	AAM - Audio Amplifier Module	DATA
LK52-14C527-CJB.vbf	Range Rover (L405)	AAM - Audio Amplifier Module	DATA
LK52-14C527-DA.vbf	Range Rover (L405)	AAM - Audio Amplifier Module	DATA
LK52-14C527-DHA.vbf	Range Rover (L405)	AAM - Audio Amplifier Module	DATA
LK52-14C527-DHB.vbf	Range Rover (L405)	AAM - Audio Amplifier Module	DATA
LK52-14C527-DJA.vbf	Range Rover (L405)	AAM - Audio Amplifier Module	DATA
LK52-14C527-DJB.vbf	Range Rover (L405)	AAM - Audio Amplifier Module	DATA
LK52-14C527-FA.vbf	Range Rover (L405)	AAM - Audio Amplifier Module	DATA
LK52-14C527-FHA.vbf	Range Rover (L405)	AAM - Audio Amplifier Module	DATA
LK52-14C527-FHB.vbf	Range Rover (L405)	AAM - Audio Amplifier Module	DATA
LK52-14C527-FJA.vbf	Range Rover (L405)	AAM - Audio Amplifier Module	DATA
LK52-14C527-FJB.vbf	Range Rover (L405)	AAM - Audio Amplifier Module	DATA
LK52-14C527-GA.vbf	Range Rover (L405)	AAM - Audio Amplifier Module	DATA
LK52-14C527-GHA.vbf	Range Rover (L405)	AAM - Audio Amplifier Module	DATA
LK52-14C527-GHB.vbf	Range Rover (L405)	AAM - Audio Amplifier Module	DATA
LK52-14C527-GJA.vbf	Range Rover (L405)	AAM - Audio Amplifier Module	DATA
LK52-14C527-GJB.vbf	Range Rover (L405)	AAM - Audio Amplifier Module	DATA
LK52-14C527-HA.vbf	Range Rover (L405)	AAM - Audio Amplifier Module	DATA
LK52-14C527-HHA.vbf	Range Rover (L405)	AAM - Audio Amplifier Module	DATA
LK52-14C527-HHB.vbf	Range Rover (L405)	AAM - Audio Amplifier Module	DATA
LK52-14C527-HJA.vbf	Range Rover (L405)	AAM - Audio Amplifier Module	DATA
LK52-14C527-HJB.vbf	Range Rover (L405)	AAM - Audio Amplifier Module	DATA
LK52-14C570-JGA.vbf	Range Rover (L405)	PCM - Powertrain Control Module	EXE
LK52-14C570-JGC.vbf	Range Rover (L405)	PCM - Powertrain Control Module	EXE
LK52-14C570-JGE.vbf	Range Rover (L405)	PCM - Powertrain Control Module	EXE
LK52-14C570-JGF.vbf	Range Rover (L405)	PCM - Powertrain Control Module	EXE
LK52-14C570-JGG.vbf	Range Rover (L405)	PCM - Powertrain Control Module	EXE
LK52-14C570-JGH.vbf	Range Rover (L405)	PCM - Powertrain Control Module	EXE
LK52-14C570-JGK.vbf	Range Rover (L405)	PCM - Powertrain Control Module	EXE
LK52-14C570-JPA.vbf	Range Rover (L405)	PCM - Powertrain Control Module	EXE
LK52-14C570-JPC.vbf	Range Rover (L405)	PCM - Powertrain Control Module	EXE
LK52-14C570-JPE.vbf	Range Rover (L405)	PCM - Powertrain Control Module	EXE
LK52-14C570-JPF.vbf	Range Rover (L405)	PCM - Powertrain Control Module	EXE
LK52-14C570-JPG.vbf	Range Rover (L405)	PCM - Powertrain Control Module	EXE
LK52-14C570-JPH.vbf	Range Rover (L405)	PCM - Powertrain Control Module	EXE
LK52-14C570-JPL.vbf	Range Rover (L405)	PCM - Powertrain Control Module	EXE
LK52-14C570-JRA.vbf	Range Rover (L405)	PCM - Powertrain Control Module	EXE
LK52-14C570-JRD.vbf	Range Rover (L405)	PCM - Powertrain Control Module	EXE
LK52-14C570-JRE.vbf	Range Rover (L405)	PCM - Powertrain Control Module	EXE
LK52-14C570-JRF.vbf	Range Rover (L405)	PCM - Powertrain Control Module	EXE
LK52-14C570-JRG.vbf	Range Rover (L405)	PCM - Powertrain Control Module	EXE
LK52-14C570-JRH.vbf	Range Rover (L405)	PCM - Powertrain Control Module	EXE
LK52-14C570-JRK.vbf	Range Rover (L405)	PCM - Powertrain Control Module	EXE
LK52-14C570-JUA.vbf	Range Rover (L405)	PCM - Powertrain Control Module	EXE
LK52-14C570-JUB.vbf	Range Rover (L405)	PCM - Powertrain Control Module	EXE
LK52-14C570-JUD.vbf	Range Rover (L405)	PCM - Powertrain Control Module	EXE
LK52-14C570-JUF.vbf	Range Rover (L405)	PCM - Powertrain Control Module	EXE
LK52-14C570-JUG.vbf	Range Rover (L405)	PCM - Powertrain Control Module	EXE
LK52-14C570-JUH.vbf	Range Rover (L405)	PCM - Powertrain Control Module	EXE
LK52-14C570-JUJ.vbf	Range Rover (L405)	PCM - Powertrain Control Module	EXE
LK52-14C570-JUL.vbf	Range Rover (L405)	PCM - Powertrain Control Module	EXE
LK52-14C570-SAA.vbf	Range Rover (L405)	PCM - Powertrain Control Module	EXE
LK52-14C570-SAB.vbf	Range Rover (L405)	PCM - Powertrain Control Module	EXE
LK52-14C570-SCA.vbf	Range Rover (L405)	PCM - Powertrain Control Module	EXE
LK52-14C570-SEA.vbf	Range Rover (L405)	PCM - Powertrain Control Module	EXE
LK52-14C570-SFA.vbf	Range Rover (L405)	PCM - Powertrain Control Module	EXE
LK52-14C570-SFB.vbf	Range Rover (L405)	PCM - Powertrain Control Module	EXE
LK52-14C570-SHA.vbf	Range Rover (L405)	PCM - Powertrain Control Module	EXE
LK52-14C570-STA.vbf	Range Rover (L405)	PCM - Powertrain Control Module	EXE
LK52-14C609-AA.vbf	Range Rover (L405)	PSCM - Power Steering Control Module	EXE
LK52-14E094-JAA.vbf	Range Rover (L405)	CHCM - Chassis Control Module	EXE
LK52-14E094-JAB.vbf	Range Rover (L405)	CHCM - Chassis Control Module	EXE
LK52-14E094-JAC.vbf	Range Rover (L405)	CHCM - Chassis Control Module	EXE
LK52-14E094-JAD.vbf	Range Rover (L405)	CHCM - Chassis Control Module	EXE
LK52-14E094-JAE.vbf	Range Rover (L405)	CHCM - Chassis Control Module	EXE
LK52-14E094-JBA.vbf	Range Rover (L405)	CHCM - Chassis Control Module	EXE
LK52-14E094-JBB.vbf	Range Rover (L405)	CHCM - Chassis Control Module	EXE
LK52-14E094-JBC.vbf	Range Rover (L405)	CHCM - Chassis Control Module	EXE
LK52-14E094-JBD.vbf	Range Rover (L405)	CHCM - Chassis Control Module	EXE
LK52-14E094-JBE.vbf	Range Rover (L405)	CHCM - Chassis Control Module	EXE

File name	Vehicle line (indicative)	Module (ECU)	Type
LK52-14E094-JCA.vbf	Range Rover (L405)	CHCM - Chassis Control Module	EXE
LK52-14E094-JCB.vbf	Range Rover (L405)	CHCM - Chassis Control Module	EXE
LK52-14E094-JCC.vbf	Range Rover (L405)	CHCM - Chassis Control Module	EXE
LK52-14E094-JCD.vbf	Range Rover (L405)	CHCM - Chassis Control Module	EXE
LK52-14E094-JCE.vbf	Range Rover (L405)	CHCM - Chassis Control Module	EXE
LK52-14E094-JDA.vbf	Range Rover (L405)	CHCM - Chassis Control Module	EXE
LK52-14E094-JDB.vbf	Range Rover (L405)	CHCM - Chassis Control Module	EXE
LK52-14E094-JDC.vbf	Range Rover (L405)	CHCM - Chassis Control Module	EXE
LK52-14E094-JDD.vbf	Range Rover (L405)	CHCM - Chassis Control Module	EXE
LK52-14E094-JDF.vbf	Range Rover (L405)	CHCM - Chassis Control Module	EXE
LK52-14E094-JEA.vbf	Range Rover (L405)	CHCM - Chassis Control Module	EXE
LK52-14E094-JEB.vbf	Range Rover (L405)	CHCM - Chassis Control Module	EXE
LK52-14E094-JEC.vbf	Range Rover (L405)	CHCM - Chassis Control Module	EXE
LK52-14E094-JED.vbf	Range Rover (L405)	CHCM - Chassis Control Module	EXE
LK52-14E094-JEE.vbf	Range Rover (L405)	CHCM - Chassis Control Module	EXE
LK52-14E094-JFA.vbf	Range Rover (L405)	CHCM - Chassis Control Module	EXE
LK52-14E094-JFB.vbf	Range Rover (L405)	CHCM - Chassis Control Module	EXE
LK52-14E094-JFC.vbf	Range Rover (L405)	CHCM - Chassis Control Module	EXE
LK52-14E094-JFD.vbf	Range Rover (L405)	CHCM - Chassis Control Module	EXE
LK52-14E094-JFE.vbf	Range Rover (L405)	CHCM - Chassis Control Module	EXE
LK52-14F435-NAA.vbf	Range Rover (L405)	CHCMB - Chassis Control Module B	EXE
LK52-14F435-NAB.vbf	Range Rover (L405)	CHCMB - Chassis Control Module B	EXE
LK52-14F435-NBA.vbf	Range Rover (L405)	CHCMB - Chassis Control Module B	EXE
LK52-14F435-NBB.vbf	Range Rover (L405)	CHCMB - Chassis Control Module B	EXE
LK52-14F435-NBC.vbf	Range Rover (L405)	CHCMB - Chassis Control Module B	EXE
LK52-14F530-EA.vbf	Range Rover (L405)	GWM - Gateway Module A	EXE
LK52-14F530-EB.vbf	Range Rover (L405)	GWM - Gateway Module A	EXE
LK52-14F530-EC.vbf	Range Rover (L405)	GWM - Gateway Module A	EXE
LK52-14F530-FA.vbf	Range Rover (L405)	GWM - Gateway Module A	EXE
LK52-14F530-FB.vbf	Range Rover (L405)	GWM - Gateway Module A	EXE
LK52-14F530-FC.vbf	Range Rover (L405)	GWM - Gateway Module A	EXE
LK52-14F531-EA.vbf	Range Rover (L405)	GWM - Gateway Module A	DATA
LK52-14F531-EB.vbf	Range Rover (L405)	GWM - Gateway Module A	DATA
LK52-14F531-EC.vbf	Range Rover (L405)	GWM - Gateway Module A	DATA
LK52-14F531-FA.vbf	Range Rover (L405)	GWM - Gateway Module A	DATA
LK52-14F531-FB.vbf	Range Rover (L405)	GWM - Gateway Module A	DATA
LK52-14F531-FC.vbf	Range Rover (L405)	GWM - Gateway Module A	DATA
LK52-19C263-AA.vbf	Range Rover (L405)	FDM - Front Display Interface Module	EXE
LK52-19C273-AA.vbf	Range Rover (L405)	LPDM - Left Power Sliding Door Module	EXE
LK52-19C273-AB.vbf	Range Rover (L405)	LPDM - Left Power Sliding Door Module	EXE
LK52-7J104-GKA.vbf	Range Rover (L405)	TCM - Transmission Control Module	EXE
LK52-7J104-GKC.vbf	Range Rover (L405)	TCM - Transmission Control Module	EXE
LK52-7J104-GKD.vbf	Range Rover (L405)	TCM - Transmission Control Module	EXE
LK52-7J104-GKE.vbf	Range Rover (L405)	TCM - Transmission Control Module	EXE
LK52-7J104-GKF.vbf	Range Rover (L405)	TCM - Transmission Control Module	EXE
LK52-7J104-GKG.vbf	Range Rover (L405)	TCM - Transmission Control Module	EXE
LK52-7J104-GKH.vbf	Range Rover (L405)	TCM - Transmission Control Module	EXE
LK52-7J104-GRA.vbf	Range Rover (L405)	TCM - Transmission Control Module	EXE
LK52-7J104-GRB.vbf	Range Rover (L405)	TCM - Transmission Control Module	EXE
LK52-7J104-GRD.vbf	Range Rover (L405)	TCM - Transmission Control Module	EXE
LK52-7J104-GRE.vbf	Range Rover (L405)	TCM - Transmission Control Module	EXE
LK52-7J104-GRF.vbf	Range Rover (L405)	TCM - Transmission Control Module	EXE
LK5M-14C570-SCA.vbf	Not specified	PCM - Powertrain Control Module	EXE
LK5M-14C570-SHA.vbf	Not specified	PCM - Powertrain Control Module	EXE
LK5M-14C570-STA.vbf	Not specified	PCM - Powertrain Control Module	EXE
LK62-12K532-KDA.vbf	Range Rover Sport (L494)	PCM - Powertrain Control Module	EXE
LK62-12K532-KDB.vbf	Range Rover Sport (L494)	PCM - Powertrain Control Module	EXE
LK62-12K532-KDC.vbf	Range Rover Sport (L494)	PCM - Powertrain Control Module	EXE
LK62-12K532-KDD.vbf	Range Rover Sport (L494)	PCM - Powertrain Control Module	EXE
LK62-12K532-KDE.vbf	Range Rover Sport (L494)	PCM - Powertrain Control Module	EXE
LK62-12K532-KEA.vbf	Range Rover Sport (L494)	PCM - Powertrain Control Module	EXE
LK62-12K532-KEB.vbf	Range Rover Sport (L494)	PCM - Powertrain Control Module	EXE
LK62-12K532-KEC.vbf	Range Rover Sport (L494)	PCM - Powertrain Control Module	EXE
LK62-12K532-KED.vbf	Range Rover Sport (L494)	PCM - Powertrain Control Module	EXE
LK62-12K532-KEE.vbf	Range Rover Sport (L494)	PCM - Powertrain Control Module	EXE
LK62-12K532-KFA.vbf	Range Rover Sport (L494)	PCM - Powertrain Control Module	EXE
LK62-12K532-KFB.vbf	Range Rover Sport (L494)	PCM - Powertrain Control Module	EXE
LK62-12K532-KFC.vbf	Range Rover Sport (L494)	PCM - Powertrain Control Module	EXE
LK62-12K532-KFD.vbf	Range Rover Sport (L494)	PCM - Powertrain Control Module	EXE
LK62-12K532-KFE.vbf	Range Rover Sport (L494)	PCM - Powertrain Control Module	EXE
LK62-12K532-PKA.vbf	Range Rover Sport (L494)	PCM - Powertrain Control Module	EXE
LK62-12K532-PKB.vbf	Range Rover Sport (L494)	PCM - Powertrain Control Module	EXE
LK62-14C037-AAB.vbf	Range Rover Sport (L494)	ABS - Anti-Lock Brake System Control Module	DATA
LK62-14C037-AAC.vbf	Range Rover Sport (L494)	ABS - Anti-Lock Brake System Control Module	DATA
LK62-14C037-AAD.vbf	Range Rover Sport (L494)	ABS - Anti-Lock Brake System Control Module	DATA
LK62-14C037-AAE.vbf	Range Rover Sport (L494)	ABS - Anti-Lock Brake System Control Module	DATA

File name	Vehicle line (indicative)	Module (ECU)	Type
LK62-14C037-AAG.vbf	Range Rover Sport (L494)	ABS - Anti-Lock Brake System Control Module	DATA
LK62-14C037-AAH.vbf	Range Rover Sport (L494)	ABS - Anti-Lock Brake System Control Module	DATA
LK62-14C037-ABB.vbf	Range Rover Sport (L494)	ABS - Anti-Lock Brake System Control Module	DATA
LK62-14C037-ABE.vbf	Range Rover Sport (L494)	ABS - Anti-Lock Brake System Control Module	DATA
LK62-14C037-ABG.vbf	Range Rover Sport (L494)	ABS - Anti-Lock Brake System Control Module	DATA
LK62-14C037-ACB.vbf	Range Rover Sport (L494)	ABS - Anti-Lock Brake System Control Module	DATA
LK62-14C037-ACE.vbf	Range Rover Sport (L494)	ABS - Anti-Lock Brake System Control Module	DATA
LK62-14C037-ACF.vbf	Range Rover Sport (L494)	ABS - Anti-Lock Brake System Control Module	DATA
LK62-14C037-ACG.vbf	Range Rover Sport (L494)	ABS - Anti-Lock Brake System Control Module	DATA
LK62-14C037-ADB.vbf	Range Rover Sport (L494)	ABS - Anti-Lock Brake System Control Module	DATA
LK62-14C037-ADE.vbf	Range Rover Sport (L494)	ABS - Anti-Lock Brake System Control Module	DATA
LK62-14C037-ADF.vbf	Range Rover Sport (L494)	ABS - Anti-Lock Brake System Control Module	DATA
LK62-14C037-ADG.vbf	Range Rover Sport (L494)	ABS - Anti-Lock Brake System Control Module	DATA
LK62-14C037-AEB.vbf	Range Rover Sport (L494)	ABS - Anti-Lock Brake System Control Module	DATA
LK62-14C037-AFB.vbf	Range Rover Sport (L494)	ABS - Anti-Lock Brake System Control Module	DATA
LK62-14C037-AGB.vbf	Range Rover Sport (L494)	ABS - Anti-Lock Brake System Control Module	DATA
LK62-14C037-AGC.vbf	Range Rover Sport (L494)	ABS - Anti-Lock Brake System Control Module	DATA
LK62-14C037-AGD.vbf	Range Rover Sport (L494)	ABS - Anti-Lock Brake System Control Module	DATA
LK62-14C037-AGE.vbf	Range Rover Sport (L494)	ABS - Anti-Lock Brake System Control Module	DATA
LK62-14C037-AGG.vbf	Range Rover Sport (L494)	ABS - Anti-Lock Brake System Control Module	DATA
LK62-14C037-AHB.vbf	Range Rover Sport (L494)	ABS - Anti-Lock Brake System Control Module	DATA
LK62-14C037-AKB.vbf	Range Rover Sport (L494)	ABS - Anti-Lock Brake System Control Module	DATA
LK62-14C037-AKC.vbf	Range Rover Sport (L494)	ABS - Anti-Lock Brake System Control Module	DATA
LK62-14C037-AKD.vbf	Range Rover Sport (L494)	ABS - Anti-Lock Brake System Control Module	DATA
LK62-14C037-AKE.vbf	Range Rover Sport (L494)	ABS - Anti-Lock Brake System Control Module	DATA
LK62-14C037-AKG.vbf	Range Rover Sport (L494)	ABS - Anti-Lock Brake System Control Module	DATA
LK62-14C037-AVB.vbf	Range Rover Sport (L494)	ABS - Anti-Lock Brake System Control Module	DATA
LK62-14C037-AVC.vbf	Range Rover Sport (L494)	ABS - Anti-Lock Brake System Control Module	DATA
LK62-14C037-AVD.vbf	Range Rover Sport (L494)	ABS - Anti-Lock Brake System Control Module	DATA
LK62-14C037-AVE.vbf	Range Rover Sport (L494)	ABS - Anti-Lock Brake System Control Module	DATA
LK62-14C037-AVG.vbf	Range Rover Sport (L494)	ABS - Anti-Lock Brake System Control Module	DATA
LK62-14C037-AYB.vbf	Range Rover Sport (L494)	ABS - Anti-Lock Brake System Control Module	DATA
LK62-14C037-AYC.vbf	Range Rover Sport (L494)	ABS - Anti-Lock Brake System Control Module	DATA
LK62-14C037-AYD.vbf	Range Rover Sport (L494)	ABS - Anti-Lock Brake System Control Module	DATA
LK62-14C037-AYE.vbf	Range Rover Sport (L494)	ABS - Anti-Lock Brake System Control Module	DATA
LK62-14C037-AYG.vbf	Range Rover Sport (L494)	ABS - Anti-Lock Brake System Control Module	DATA
LK62-14C037-DKB.vbf	Range Rover Sport (L494)	ABS - Anti-Lock Brake System Control Module	DATA
LK62-14C037-DKC.vbf	Range Rover Sport (L494)	ABS - Anti-Lock Brake System Control Module	DATA
LK62-14C037-DKD.vbf	Range Rover Sport (L494)	ABS - Anti-Lock Brake System Control Module	DATA
LK62-14C037-DKE.vbf	Range Rover Sport (L494)	ABS - Anti-Lock Brake System Control Module	DATA
LK62-14C037-DKG.vbf	Range Rover Sport (L494)	ABS - Anti-Lock Brake System Control Module	DATA
LK62-14C037-DKH.vbf	Range Rover Sport (L494)	ABS - Anti-Lock Brake System Control Module	DATA
LK62-14C037-DLB.vbf	Range Rover Sport (L494)	ABS - Anti-Lock Brake System Control Module	DATA
LK62-14C037-DMB.vbf	Range Rover Sport (L494)	ABS - Anti-Lock Brake System Control Module	DATA
LK62-14C037-DMC.vbf	Range Rover Sport (L494)	ABS - Anti-Lock Brake System Control Module	DATA
LK62-14C037-DMD.vbf	Range Rover Sport (L494)	ABS - Anti-Lock Brake System Control Module	DATA
LK62-14C037-DME.vbf	Range Rover Sport (L494)	ABS - Anti-Lock Brake System Control Module	DATA
LK62-14C037-DMG.vbf	Range Rover Sport (L494)	ABS - Anti-Lock Brake System Control Module	DATA
LK62-14C037-DMH.vbf	Range Rover Sport (L494)	ABS - Anti-Lock Brake System Control Module	DATA
LK62-14C037-DNB.vbf	Range Rover Sport (L494)	ABS - Anti-Lock Brake System Control Module	DATA
LK62-14C037-DPB.vbf	Range Rover Sport (L494)	ABS - Anti-Lock Brake System Control Module	DATA
LK62-14C037-ECB.vbf	Range Rover Sport (L494)	ABS - Anti-Lock Brake System Control Module	DATA
LK62-14C037-ECC.vbf	Range Rover Sport (L494)	ABS - Anti-Lock Brake System Control Module	DATA
LK62-14C037-ECD.vbf	Range Rover Sport (L494)	ABS - Anti-Lock Brake System Control Module	DATA
LK62-14C037-ECE.vbf	Range Rover Sport (L494)	ABS - Anti-Lock Brake System Control Module	DATA
LK62-14C037-ECG.vbf	Range Rover Sport (L494)	ABS - Anti-Lock Brake System Control Module	DATA
LK62-14C037-EEB.vbf	Range Rover Sport (L494)	ABS - Anti-Lock Brake System Control Module	DATA
LK62-14C037-EEC.vbf	Range Rover Sport (L494)	ABS - Anti-Lock Brake System Control Module	DATA
LK62-14C037-EED.vbf	Range Rover Sport (L494)	ABS - Anti-Lock Brake System Control Module	DATA
LK62-14C037-EEE.vbf	Range Rover Sport (L494)	ABS - Anti-Lock Brake System Control Module	DATA
LK62-14C037-EEG.vbf	Range Rover Sport (L494)	ABS - Anti-Lock Brake System Control Module	DATA
LK62-14C037-EFB.vbf	Range Rover Sport (L494)	ABS - Anti-Lock Brake System Control Module	DATA
LK62-14C037-EFC.vbf	Range Rover Sport (L494)	ABS - Anti-Lock Brake System Control Module	DATA
LK62-14C037-EFD.vbf	Range Rover Sport (L494)	ABS - Anti-Lock Brake System Control Module	DATA
LK62-14C037-EFE.vbf	Range Rover Sport (L494)	ABS - Anti-Lock Brake System Control Module	DATA
LK62-14C037-EFG.vbf	Range Rover Sport (L494)	ABS - Anti-Lock Brake System Control Module	DATA
LK62-14C037-EGB.vbf	Range Rover Sport (L494)	ABS - Anti-Lock Brake System Control Module	DATA
LK62-14C037-EGC.vbf	Range Rover Sport (L494)	ABS - Anti-Lock Brake System Control Module	DATA
LK62-14C037-EGD.vbf	Range Rover Sport (L494)	ABS - Anti-Lock Brake System Control Module	DATA
LK62-14C037-EGE.vbf	Range Rover Sport (L494)	ABS - Anti-Lock Brake System Control Module	DATA
LK62-14C037-EGG.vbf	Range Rover Sport (L494)	ABS - Anti-Lock Brake System Control Module	DATA
LK62-14C037-EHB.vbf	Range Rover Sport (L494)	ABS - Anti-Lock Brake System Control Module	DATA
LK62-14C037-EHC.vbf	Range Rover Sport (L494)	ABS - Anti-Lock Brake System Control Module	DATA
LK62-14C037-EHD.vbf	Range Rover Sport (L494)	ABS - Anti-Lock Brake System Control Module	DATA
LK62-14C037-EHE.vbf	Range Rover Sport (L494)	ABS - Anti-Lock Brake System Control Module	DATA
LK62-14C037-EHF.vbf	Range Rover Sport (L494)	ABS - Anti-Lock Brake System Control Module	DATA

File name	Vehicle line (indicative)	Module (ECU)	Type
LK62-14C037-EHG.vbf	Range Rover Sport (L494)	ABS - Anti-Lock Brake System Control Module	DATA
LK62-14C037-EJB.vbf	Range Rover Sport (L494)	ABS - Anti-Lock Brake System Control Module	DATA
LK62-14C037-EJC.vbf	Range Rover Sport (L494)	ABS - Anti-Lock Brake System Control Module	DATA
LK62-14C037-EJD.vbf	Range Rover Sport (L494)	ABS - Anti-Lock Brake System Control Module	DATA
LK62-14C037-EJE.vbf	Range Rover Sport (L494)	ABS - Anti-Lock Brake System Control Module	DATA
LK62-14C037-EJF.vbf	Range Rover Sport (L494)	ABS - Anti-Lock Brake System Control Module	DATA
LK62-14C037-EJG.vbf	Range Rover Sport (L494)	ABS - Anti-Lock Brake System Control Module	DATA
LK62-14C037-EKB.vbf	Range Rover Sport (L494)	ABS - Anti-Lock Brake System Control Module	DATA
LK62-14C037-EKC.vbf	Range Rover Sport (L494)	ABS - Anti-Lock Brake System Control Module	DATA
LK62-14C037-EKD.vbf	Range Rover Sport (L494)	ABS - Anti-Lock Brake System Control Module	DATA
LK62-14C037-EKE.vbf	Range Rover Sport (L494)	ABS - Anti-Lock Brake System Control Module	DATA
LK62-14C037-EKF.vbf	Range Rover Sport (L494)	ABS - Anti-Lock Brake System Control Module	DATA
LK62-14C037-EKG.vbf	Range Rover Sport (L494)	ABS - Anti-Lock Brake System Control Module	DATA
LK62-14C037-ELB.vbf	Range Rover Sport (L494)	ABS - Anti-Lock Brake System Control Module	DATA
LK62-14C037-ELC.vbf	Range Rover Sport (L494)	ABS - Anti-Lock Brake System Control Module	DATA
LK62-14C037-ELD.vbf	Range Rover Sport (L494)	ABS - Anti-Lock Brake System Control Module	DATA
LK62-14C037-ELE.vbf	Range Rover Sport (L494)	ABS - Anti-Lock Brake System Control Module	DATA
LK62-14C037-ELF.vbf	Range Rover Sport (L494)	ABS - Anti-Lock Brake System Control Module	DATA
LK62-14C037-ELG.vbf	Range Rover Sport (L494)	ABS - Anti-Lock Brake System Control Module	DATA
LK62-14C037-EMB.vbf	Range Rover Sport (L494)	ABS - Anti-Lock Brake System Control Module	DATA
LK62-14C037-EMC.vbf	Range Rover Sport (L494)	ABS - Anti-Lock Brake System Control Module	DATA
LK62-14C037-EMD.vbf	Range Rover Sport (L494)	ABS - Anti-Lock Brake System Control Module	DATA
LK62-14C037-EME.vbf	Range Rover Sport (L494)	ABS - Anti-Lock Brake System Control Module	DATA
LK62-14C037-EMF.vbf	Range Rover Sport (L494)	ABS - Anti-Lock Brake System Control Module	DATA
LK62-14C037-EMG.vbf	Range Rover Sport (L494)	ABS - Anti-Lock Brake System Control Module	DATA
LK62-14C037-ENB.vbf	Range Rover Sport (L494)	ABS - Anti-Lock Brake System Control Module	DATA
LK62-14C037-ENC.vbf	Range Rover Sport (L494)	ABS - Anti-Lock Brake System Control Module	DATA
LK62-14C037-END.vbf	Range Rover Sport (L494)	ABS - Anti-Lock Brake System Control Module	DATA
LK62-14C037-ENE.vbf	Range Rover Sport (L494)	ABS - Anti-Lock Brake System Control Module	DATA
LK62-14C037-ENF.vbf	Range Rover Sport (L494)	ABS - Anti-Lock Brake System Control Module	DATA
LK62-14C037-ENG.vbf	Range Rover Sport (L494)	ABS - Anti-Lock Brake System Control Module	DATA
LK62-14C037-EPB.vbf	Range Rover Sport (L494)	ABS - Anti-Lock Brake System Control Module	DATA
LK62-14C037-EPC.vbf	Range Rover Sport (L494)	ABS - Anti-Lock Brake System Control Module	DATA
LK62-14C037-EPD.vbf	Range Rover Sport (L494)	ABS - Anti-Lock Brake System Control Module	DATA
LK62-14C037-EPE.vbf	Range Rover Sport (L494)	ABS - Anti-Lock Brake System Control Module	DATA
LK62-14C037-EPF.vbf	Range Rover Sport (L494)	ABS - Anti-Lock Brake System Control Module	DATA
LK62-14C037-EPG.vbf	Range Rover Sport (L494)	ABS - Anti-Lock Brake System Control Module	DATA
LK62-14C037-ERB.vbf	Range Rover Sport (L494)	ABS - Anti-Lock Brake System Control Module	DATA
LK62-14C037-ERC.vbf	Range Rover Sport (L494)	ABS - Anti-Lock Brake System Control Module	DATA
LK62-14C037-ERD.vbf	Range Rover Sport (L494)	ABS - Anti-Lock Brake System Control Module	DATA
LK62-14C037-ERE.vbf	Range Rover Sport (L494)	ABS - Anti-Lock Brake System Control Module	DATA
LK62-14C037-ETC.vbf	Range Rover Sport (L494)	ABS - Anti-Lock Brake System Control Module	DATA
LK62-14C037-ETD.vbf	Range Rover Sport (L494)	ABS - Anti-Lock Brake System Control Module	DATA
LK62-14C037-ETE.vbf	Range Rover Sport (L494)	ABS - Anti-Lock Brake System Control Module	DATA
LK62-14C037-ETF.vbf	Range Rover Sport (L494)	ABS - Anti-Lock Brake System Control Module	DATA
LK62-14C037-ETG.vbf	Range Rover Sport (L494)	ABS - Anti-Lock Brake System Control Module	DATA
LK62-14C037-FAB.vbf	Range Rover Sport (L494)	ABS - Anti-Lock Brake System Control Module	DATA
LK62-14C037-FAE.vbf	Range Rover Sport (L494)	ABS - Anti-Lock Brake System Control Module	DATA
LK62-14C037-FAF.vbf	Range Rover Sport (L494)	ABS - Anti-Lock Brake System Control Module	DATA
LK62-14C037-FBB.vbf	Range Rover Sport (L494)	ABS - Anti-Lock Brake System Control Module	DATA
LK62-14C037-FBE.vbf	Range Rover Sport (L494)	ABS - Anti-Lock Brake System Control Module	DATA
LK62-14C037-FBF.vbf	Range Rover Sport (L494)	ABS - Anti-Lock Brake System Control Module	DATA
LK62-14C037-FCB.vbf	Range Rover Sport (L494)	ABS - Anti-Lock Brake System Control Module	DATA
LK62-14C037-FCE.vbf	Range Rover Sport (L494)	ABS - Anti-Lock Brake System Control Module	DATA
LK62-14C037-FCF.vbf	Range Rover Sport (L494)	ABS - Anti-Lock Brake System Control Module	DATA
LK62-14C037-FDB.vbf	Range Rover Sport (L494)	ABS - Anti-Lock Brake System Control Module	DATA
LK62-14C037-FDE.vbf	Range Rover Sport (L494)	ABS - Anti-Lock Brake System Control Module	DATA
LK62-14C037-FDF.vbf	Range Rover Sport (L494)	ABS - Anti-Lock Brake System Control Module	DATA
LK62-14C037-FEB.vbf	Range Rover Sport (L494)	ABS - Anti-Lock Brake System Control Module	DATA
LK62-14C037-FEE.vbf	Range Rover Sport (L494)	ABS - Anti-Lock Brake System Control Module	DATA
LK62-14C037-FEF.vbf	Range Rover Sport (L494)	ABS - Anti-Lock Brake System Control Module	DATA
LK62-14C037-FFB.vbf	Range Rover Sport (L494)	ABS - Anti-Lock Brake System Control Module	DATA
LK62-14C037-FGB.vbf	Range Rover Sport (L494)	ABS - Anti-Lock Brake System Control Module	DATA
LK62-14C037-FHB.vbf	Range Rover Sport (L494)	ABS - Anti-Lock Brake System Control Module	DATA
LK62-14C037-FJB.vbf	Range Rover Sport (L494)	ABS - Anti-Lock Brake System Control Module	DATA
LK62-14C037-FJE.vbf	Range Rover Sport (L494)	ABS - Anti-Lock Brake System Control Module	DATA
LK62-14C037-FJF.vbf	Range Rover Sport (L494)	ABS - Anti-Lock Brake System Control Module	DATA
LK62-14C037-FKB.vbf	Range Rover Sport (L494)	ABS - Anti-Lock Brake System Control Module	DATA
LK62-14C037-FKC.vbf	Range Rover Sport (L494)	ABS - Anti-Lock Brake System Control Module	DATA
LK62-14C037-FKD.vbf	Range Rover Sport (L494)	ABS - Anti-Lock Brake System Control Module	DATA
LK62-14C037-FKF.vbf	Range Rover Sport (L494)	ABS - Anti-Lock Brake System Control Module	DATA
LK62-14C037-FKG.vbf	Range Rover Sport (L494)	ABS - Anti-Lock Brake System Control Module	DATA
LK62-14C037-FLB.vbf	Range Rover Sport (L494)	ABS - Anti-Lock Brake System Control Module	DATA
LK62-14C037-FME.vbf	Range Rover Sport (L494)	ABS - Anti-Lock Brake System Control Module	DATA
LK62-14C037-FMF.vbf	Range Rover Sport (L494)	ABS - Anti-Lock Brake System Control Module	DATA
LK62-14C037-FNC.vbf	Range Rover Sport (L494)	ABS - Anti-Lock Brake System Control Module	DATA

File name	Vehicle line (indicative)	Module (ECU)	Type
LK62-14C037-FND.vbf	Range Rover Sport (L494)	ABS - Anti-Lock Brake System Control Module	DATA
LK62-14C037-FNE.vbf	Range Rover Sport (L494)	ABS - Anti-Lock Brake System Control Module	DATA
LK62-14C037-FNG.vbf	Range Rover Sport (L494)	ABS - Anti-Lock Brake System Control Module	DATA
LK62-14C037-FPC.vbf	Range Rover Sport (L494)	ABS - Anti-Lock Brake System Control Module	DATA
LK62-14C037-FPD.vbf	Range Rover Sport (L494)	ABS - Anti-Lock Brake System Control Module	DATA
LK62-14C037-FPE.vbf	Range Rover Sport (L494)	ABS - Anti-Lock Brake System Control Module	DATA
LK62-14C037-FPF.vbf	Range Rover Sport (L494)	ABS - Anti-Lock Brake System Control Module	DATA
LK62-14C037-FPG.vbf	Range Rover Sport (L494)	ABS - Anti-Lock Brake System Control Module	DATA
LK62-14C037-FRC.vbf	Range Rover Sport (L494)	ABS - Anti-Lock Brake System Control Module	DATA
LK62-14C037-FRD.vbf	Range Rover Sport (L494)	ABS - Anti-Lock Brake System Control Module	DATA
LK62-14C037-FRE.vbf	Range Rover Sport (L494)	ABS - Anti-Lock Brake System Control Module	DATA
LK62-14C037-FRF.vbf	Range Rover Sport (L494)	ABS - Anti-Lock Brake System Control Module	DATA
LK62-14C037-FRG.vbf	Range Rover Sport (L494)	ABS - Anti-Lock Brake System Control Module	DATA
LK62-14C037-FSC.vbf	Range Rover Sport (L494)	ABS - Anti-Lock Brake System Control Module	DATA
LK62-14C037-FSD.vbf	Range Rover Sport (L494)	ABS - Anti-Lock Brake System Control Module	DATA
LK62-14C037-FSE.vbf	Range Rover Sport (L494)	ABS - Anti-Lock Brake System Control Module	DATA
LK62-14C037-FSF.vbf	Range Rover Sport (L494)	ABS - Anti-Lock Brake System Control Module	DATA
LK62-14C037-FSG.vbf	Range Rover Sport (L494)	ABS - Anti-Lock Brake System Control Module	DATA
LK62-14C037-FTC.vbf	Range Rover Sport (L494)	ABS - Anti-Lock Brake System Control Module	DATA
LK62-14C037-FTD.vbf	Range Rover Sport (L494)	ABS - Anti-Lock Brake System Control Module	DATA
LK62-14C037-FTE.vbf	Range Rover Sport (L494)	ABS - Anti-Lock Brake System Control Module	DATA
LK62-14C037-FTF.vbf	Range Rover Sport (L494)	ABS - Anti-Lock Brake System Control Module	DATA
LK62-14C037-FTG.vbf	Range Rover Sport (L494)	ABS - Anti-Lock Brake System Control Module	DATA
LK62-14C037-FUC.vbf	Range Rover Sport (L494)	ABS - Anti-Lock Brake System Control Module	DATA
LK62-14C037-FUD.vbf	Range Rover Sport (L494)	ABS - Anti-Lock Brake System Control Module	DATA
LK62-14C037-FUE.vbf	Range Rover Sport (L494)	ABS - Anti-Lock Brake System Control Module	DATA
LK62-14C037-FUF.vbf	Range Rover Sport (L494)	ABS - Anti-Lock Brake System Control Module	DATA
LK62-14C037-FUG.vbf	Range Rover Sport (L494)	ABS - Anti-Lock Brake System Control Module	DATA
LK62-14C037-FVC.vbf	Range Rover Sport (L494)	ABS - Anti-Lock Brake System Control Module	DATA
LK62-14C037-FVD.vbf	Range Rover Sport (L494)	ABS - Anti-Lock Brake System Control Module	DATA
LK62-14C037-FVE.vbf	Range Rover Sport (L494)	ABS - Anti-Lock Brake System Control Module	DATA
LK62-14C037-FVF.vbf	Range Rover Sport (L494)	ABS - Anti-Lock Brake System Control Module	DATA
LK62-14C037-FVG.vbf	Range Rover Sport (L494)	ABS - Anti-Lock Brake System Control Module	DATA
LK62-14C037-GAC.vbf	Range Rover Sport (L494)	ABS - Anti-Lock Brake System Control Module	DATA
LK62-14C037-GAD.vbf	Range Rover Sport (L494)	ABS - Anti-Lock Brake System Control Module	DATA
LK62-14C037-GBD.vbf	Range Rover Sport (L494)	ABS - Anti-Lock Brake System Control Module	DATA
LK62-14C037-GCC.vbf	Range Rover Sport (L494)	ABS - Anti-Lock Brake System Control Module	DATA
LK62-14C037-GCD.vbf	Range Rover Sport (L494)	ABS - Anti-Lock Brake System Control Module	DATA
LK62-14C037-HAA.vbf	Range Rover Sport (L494)	ABS - Anti-Lock Brake System Control Module	DATA
LK62-14C037-HAB.vbf	Range Rover Sport (L494)	ABS - Anti-Lock Brake System Control Module	DATA
LK62-14C037-HBA.vbf	Range Rover Sport (L494)	ABS - Anti-Lock Brake System Control Module	DATA
LK62-14C037-HBB.vbf	Range Rover Sport (L494)	ABS - Anti-Lock Brake System Control Module	DATA
LK62-14C037-HCA.vbf	Range Rover Sport (L494)	ABS - Anti-Lock Brake System Control Module	DATA
LK62-14C037-HCB.vbf	Range Rover Sport (L494)	ABS - Anti-Lock Brake System Control Module	DATA
LK62-14C185-AA.vbf	Range Rover Sport (L494)	BCM - Body Control Module	DATA
LK62-14C218-FA.vbf	Range Rover Sport (L494)	PSCM - Power Steering Control Module	EXE
LK62-14C218-GA.vbf	Range Rover Sport (L494)	PSCM - Power Steering Control Module	EXE
LK62-14C273-KAA.vbf	Range Rover Sport (L494)	PCM - Powertrain Control Module	SBL
LK62-14C527-ALA.vbf	Range Rover Sport (L494)	AAM - Audio Amplifier Module	DATA
LK62-14C527-ALB.vbf	Range Rover Sport (L494)	AAM - Audio Amplifier Module	DATA
LK62-14C527-ALC.vbf	Range Rover Sport (L494)	AAM - Audio Amplifier Module	DATA
LK62-14C527-BLA.vbf	Range Rover Sport (L494)	AAM - Audio Amplifier Module	DATA
LK62-14C527-BLB.vbf	Range Rover Sport (L494)	AAM - Audio Amplifier Module	DATA
LK62-14C527-BLC.vbf	Range Rover Sport (L494)	AAM - Audio Amplifier Module	DATA
LK62-14C527-CLA.vbf	Range Rover Sport (L494)	AAM - Audio Amplifier Module	DATA
LK62-14C527-CLB.vbf	Range Rover Sport (L494)	AAM - Audio Amplifier Module	DATA
LK62-14C527-CLC.vbf	Range Rover Sport (L494)	AAM - Audio Amplifier Module	DATA
LK62-14C527-DLA.vbf	Range Rover Sport (L494)	AAM - Audio Amplifier Module	DATA
LK62-14C527-DLB.vbf	Range Rover Sport (L494)	AAM - Audio Amplifier Module	DATA
LK62-14C527-DLC.vbf	Range Rover Sport (L494)	AAM - Audio Amplifier Module	DATA
LK62-14C570-BNA.vbf	Range Rover Sport (L494)	PCM - Powertrain Control Module	EXE
LK62-14C570-BNB.vbf	Range Rover Sport (L494)	PCM - Powertrain Control Module	EXE
LK62-14C570-BPA.vbf	Range Rover Sport (L494)	PCM - Powertrain Control Module	EXE
LK62-14C570-BPB.vbf	Range Rover Sport (L494)	PCM - Powertrain Control Module	EXE
LK62-14C570-BRA.vbf	Range Rover Sport (L494)	PCM - Powertrain Control Module	EXE
LK62-14C570-BRB.vbf	Range Rover Sport (L494)	PCM - Powertrain Control Module	EXE
LK62-14C570-BUA.vbf	Range Rover Sport (L494)	PCM - Powertrain Control Module	EXE
LK62-14C570-BUB.vbf	Range Rover Sport (L494)	PCM - Powertrain Control Module	EXE
LK62-14C570-SAA.vbf	Range Rover Sport (L494)	PCM - Powertrain Control Module	EXE
LK62-14C570-SAB.vbf	Range Rover Sport (L494)	PCM - Powertrain Control Module	EXE
LK62-14C570-SCA.vbf	Range Rover Sport (L494)	PCM - Powertrain Control Module	EXE
LK62-14C570-SEA.vbf	Range Rover Sport (L494)	PCM - Powertrain Control Module	EXE
LK62-14C570-SFA.vbf	Range Rover Sport (L494)	PCM - Powertrain Control Module	EXE
LK62-14C570-SFB.vbf	Range Rover Sport (L494)	PCM - Powertrain Control Module	EXE
LK62-14C570-SHA.vbf	Range Rover Sport (L494)	PCM - Powertrain Control Module	EXE
LK62-14C570-STA.vbf	Range Rover Sport (L494)	PCM - Powertrain Control Module	EXE

File name	Vehicle line (indicative)	Module (ECU)	Type
LK62-14C609-AA.vbf	Range Rover Sport (L494)	PSCM - Power Steering Control Module	EXE
LK62-14E094-HAA.vbf	Range Rover Sport (L494)	CHCM - Chassis Control Module	EXE
LK62-14E094-HAB.vbf	Range Rover Sport (L494)	CHCM - Chassis Control Module	EXE
LK62-14E094-HAC.vbf	Range Rover Sport (L494)	CHCM - Chassis Control Module	EXE
LK62-14E094-HAD.vbf	Range Rover Sport (L494)	CHCM - Chassis Control Module	EXE
LK62-14E094-HAE.vbf	Range Rover Sport (L494)	CHCM - Chassis Control Module	EXE
LK62-14E094-JAA.vbf	Range Rover Sport (L494)	CHCM - Chassis Control Module	EXE
LK62-14E094-JAB.vbf	Range Rover Sport (L494)	CHCM - Chassis Control Module	EXE
LK62-14E094-JAC.vbf	Range Rover Sport (L494)	CHCM - Chassis Control Module	EXE
LK62-14E094-JAD.vbf	Range Rover Sport (L494)	CHCM - Chassis Control Module	EXE
LK62-14E094-JAE.vbf	Range Rover Sport (L494)	CHCM - Chassis Control Module	EXE
LK62-14E094-JCA.vbf	Range Rover Sport (L494)	CHCM - Chassis Control Module	EXE
LK62-14E094-JCB.vbf	Range Rover Sport (L494)	CHCM - Chassis Control Module	EXE
LK62-14E094-JCC.vbf	Range Rover Sport (L494)	CHCM - Chassis Control Module	EXE
LK62-14E094-JCD.vbf	Range Rover Sport (L494)	CHCM - Chassis Control Module	EXE
LK62-14E094-JCE.vbf	Range Rover Sport (L494)	CHCM - Chassis Control Module	EXE
LK62-14E094-JDA.vbf	Range Rover Sport (L494)	CHCM - Chassis Control Module	EXE
LK62-14E094-JDB.vbf	Range Rover Sport (L494)	CHCM - Chassis Control Module	EXE
LK62-14E094-JDC.vbf	Range Rover Sport (L494)	CHCM - Chassis Control Module	EXE
LK62-14E094-JDD.vbf	Range Rover Sport (L494)	CHCM - Chassis Control Module	EXE
LK62-14E094-JDE.vbf	Range Rover Sport (L494)	CHCM - Chassis Control Module	EXE
LK62-14F435-NAA.vbf	Range Rover Sport (L494)	CHCMB - Chassis Control Module B	EXE
LK62-14F435-NAB.vbf	Range Rover Sport (L494)	CHCMB - Chassis Control Module B	EXE
LK62-14F435-NAC.vbf	Range Rover Sport (L494)	CHCMB - Chassis Control Module B	EXE
LK62-14F435-NAD.vbf	Range Rover Sport (L494)	CHCMB - Chassis Control Module B	EXE
LK62-14F435-NAE.vbf	Range Rover Sport (L494)	CHCMB - Chassis Control Module B	EXE
LK62-14F530-EA.vbf	Range Rover Sport (L494)	GWM - Gateway Module A	EXE
LK62-14F530-EB.vbf	Range Rover Sport (L494)	GWM - Gateway Module A	EXE
LK62-14F530-EC.vbf	Range Rover Sport (L494)	GWM - Gateway Module A	EXE
LK62-14F530-FA.vbf	Range Rover Sport (L494)	GWM - Gateway Module A	EXE
LK62-14F530-FB.vbf	Range Rover Sport (L494)	GWM - Gateway Module A	EXE
LK62-14F530-FC.vbf	Range Rover Sport (L494)	GWM - Gateway Module A	EXE
LK62-14F531-EA.vbf	Range Rover Sport (L494)	GWM - Gateway Module A	DATA
LK62-14F531-EB.vbf	Range Rover Sport (L494)	GWM - Gateway Module A	DATA
LK62-14F531-FA.vbf	Range Rover Sport (L494)	GWM - Gateway Module A	DATA
LK62-14F531-FB.vbf	Range Rover Sport (L494)	GWM - Gateway Module A	DATA
LK62-7J104-GKA.vbf	Range Rover Sport (L494)	TCM - Transmission Control Module	EXE
LK62-7J104-GKC.vbf	Range Rover Sport (L494)	TCM - Transmission Control Module	EXE
LK62-7J104-GKD.vbf	Range Rover Sport (L494)	TCM - Transmission Control Module	EXE
LK62-7J104-GKE.vbf	Range Rover Sport (L494)	TCM - Transmission Control Module	EXE
LK62-7J104-GKF.vbf	Range Rover Sport (L494)	TCM - Transmission Control Module	EXE
LK62-7J104-GKG.vbf	Range Rover Sport (L494)	TCM - Transmission Control Module	EXE
LK62-7J104-GKH.vbf	Range Rover Sport (L494)	TCM - Transmission Control Module	EXE
LK72-12K532-FAA.vbf	Discovery Sport (L550)	PCM - Powertrain Control Module	EXE
LK72-12K532-FAB.vbf	Discovery Sport (L550)	PCM - Powertrain Control Module	EXE
LK72-12K532-FAC.vbf	Discovery Sport (L550)	PCM - Powertrain Control Module	EXE
LK72-12K532-FAD.vbf	Discovery Sport (L550)	PCM - Powertrain Control Module	EXE
LK72-12K532-FAE.vbf	Discovery Sport (L550)	PCM - Powertrain Control Module	EXE
LK72-12K532-FAF.vbf	Discovery Sport (L550)	PCM - Powertrain Control Module	EXE
LK72-12K532-FAJ.vbf	Discovery Sport (L550)	PCM - Powertrain Control Module	EXE
LK72-12K532-FBA.vbf	Discovery Sport (L550)	PCM - Powertrain Control Module	EXE
LK72-12K532-FBB.vbf	Discovery Sport (L550)	PCM - Powertrain Control Module	EXE
LK72-12K532-FBC.vbf	Discovery Sport (L550)	PCM - Powertrain Control Module	EXE
LK72-12K532-FBD.vbf	Discovery Sport (L550)	PCM - Powertrain Control Module	EXE
LK72-12K532-FBE.vbf	Discovery Sport (L550)	PCM - Powertrain Control Module	EXE
LK72-12K532-FBF.vbf	Discovery Sport (L550)	PCM - Powertrain Control Module	EXE
LK72-12K532-FBJ.vbf	Discovery Sport (L550)	PCM - Powertrain Control Module	EXE
LK72-12K532-FCA.vbf	Discovery Sport (L550)	PCM - Powertrain Control Module	EXE
LK72-12K532-FCB.vbf	Discovery Sport (L550)	PCM - Powertrain Control Module	EXE
LK72-12K532-FCC.vbf	Discovery Sport (L550)	PCM - Powertrain Control Module	EXE
LK72-12K532-FCD.vbf	Discovery Sport (L550)	PCM - Powertrain Control Module	EXE
LK72-12K532-FCE.vbf	Discovery Sport (L550)	PCM - Powertrain Control Module	EXE
LK72-12K532-FCF.vbf	Discovery Sport (L550)	PCM - Powertrain Control Module	EXE
LK72-12K532-FCJ.vbf	Discovery Sport (L550)	PCM - Powertrain Control Module	EXE
LK72-12K532-FDA.vbf	Discovery Sport (L550)	PCM - Powertrain Control Module	EXE
LK72-12K532-FEA.vbf	Discovery Sport (L550)	PCM - Powertrain Control Module	EXE
LK72-12K532-FFA.vbf	Discovery Sport (L550)	PCM - Powertrain Control Module	EXE
LK72-12K532-FFB.vbf	Discovery Sport (L550)	PCM - Powertrain Control Module	EXE
LK72-12K532-FFC.vbf	Discovery Sport (L550)	PCM - Powertrain Control Module	EXE
LK72-12K532-FJA.vbf	Discovery Sport (L550)	PCM - Powertrain Control Module	EXE
LK72-12K532-FJB.vbf	Discovery Sport (L550)	PCM - Powertrain Control Module	EXE
LK72-12K532-FJC.vbf	Discovery Sport (L550)	PCM - Powertrain Control Module	EXE
LK72-12K532-FKA.vbf	Discovery Sport (L550)	PCM - Powertrain Control Module	EXE
LK72-12K532-FKB.vbf	Discovery Sport (L550)	PCM - Powertrain Control Module	EXE
LK72-12K532-FKC.vbf	Discovery Sport (L550)	PCM - Powertrain Control Module	EXE
LK72-12K532-FMA.vbf	Discovery Sport (L550)	PCM - Powertrain Control Module	EXE

File name	Vehicle line (indicative)	Module (ECU)	Type
LK72-12K532-FMB.vbf	Discovery Sport (L550)	PCM - Powertrain Control Module	EXE
LK72-12K532-FMC.vbf	Discovery Sport (L550)	PCM - Powertrain Control Module	EXE
LK72-12K532-FNA.vbf	Discovery Sport (L550)	PCM - Powertrain Control Module	EXE
LK72-12K532-FNB.vbf	Discovery Sport (L550)	PCM - Powertrain Control Module	EXE
LK72-12K532-FNC.vbf	Discovery Sport (L550)	PCM - Powertrain Control Module	EXE
LK72-12K532-FND.vbf	Discovery Sport (L550)	PCM - Powertrain Control Module	EXE
LK72-12K532-FNE.vbf	Discovery Sport (L550)	PCM - Powertrain Control Module	EXE
LK72-12K532-FVA.vbf	Discovery Sport (L550)	PCM - Powertrain Control Module	EXE
LK72-12K532-FVB.vbf	Discovery Sport (L550)	PCM - Powertrain Control Module	EXE
LK72-12K532-FVC.vbf	Discovery Sport (L550)	PCM - Powertrain Control Module	EXE
LK72-12K532-GCA.vbf	Discovery Sport (L550)	PCM - Powertrain Control Module	EXE
LK72-12K532-GCB.vbf	Discovery Sport (L550)	PCM - Powertrain Control Module	EXE
LK72-12K532-GCC.vbf	Discovery Sport (L550)	PCM - Powertrain Control Module	EXE
LK72-12K532-GCD.vbf	Discovery Sport (L550)	PCM - Powertrain Control Module	EXE
LK72-12K532-GCE.vbf	Discovery Sport (L550)	PCM - Powertrain Control Module	EXE
LK72-12K532-GCF.vbf	Discovery Sport (L550)	PCM - Powertrain Control Module	EXE
LK72-14C025-AA.vbf	Discovery Sport (L550)	IPC - Instrument Panel Cluster (IPC) Control Module	SBL
LK72-14C026-AA.vbf	Discovery Sport (L550)	IPC - Instrument Panel Cluster (IPC) Control Module	EXE
LK72-14C026-AB.vbf	Discovery Sport (L550)	IPC - Instrument Panel Cluster (IPC) Control Module	EXE
LK72-14C026-AC.vbf	Discovery Sport (L550)	IPC - Instrument Panel Cluster (IPC) Control Module	EXE
LK72-14C026-AD.vbf	Discovery Sport (L550)	IPC - Instrument Panel Cluster (IPC) Control Module	EXE
LK72-14C026-AE.vbf	Discovery Sport (L550)	IPC - Instrument Panel Cluster (IPC) Control Module	EXE
LK72-14C026-AF.vbf	Discovery Sport (L550)	IPC - Instrument Panel Cluster (IPC) Control Module	EXE
LK72-14C026-JA.vbf	Discovery Sport (L550)	IPC - Instrument Panel Cluster (IPC) Control Module	EXE
LK72-14C026-JB.vbf	Discovery Sport (L550)	IPC - Instrument Panel Cluster (IPC) Control Module	EXE
LK72-14C026-KA.vbf	Discovery Sport (L550)	IPC - Instrument Panel Cluster (IPC) Control Module	EXE
LK72-14C026-KB.vbf	Discovery Sport (L550)	IPC - Instrument Panel Cluster (IPC) Control Module	EXE
LK72-14C027-AA.vbf	Discovery Sport (L550)	RCM - Restraints Control Module	SBL
LK72-14C028-AA.vbf	Discovery Sport (L550)	RCM - Restraints Control Module	EXE
LK72-14C028-AB.vbf	Discovery Sport (L550)	RCM - Restraints Control Module	EXE
LK72-14C028-AD.vbf	Discovery Sport (L550)	RCM - Restraints Control Module	EXE
LK72-14C028-AE.vbf	Discovery Sport (L550)	RCM - Restraints Control Module	EXE
LK72-14C037-AAC.vbf	Discovery Sport (L550)	ABS - Anti-Lock Brake System Control Module	DATA
LK72-14C037-AAD.vbf	Discovery Sport (L550)	ABS - Anti-Lock Brake System Control Module	DATA
LK72-14C037-AAE.vbf	Discovery Sport (L550)	ABS - Anti-Lock Brake System Control Module	DATA
LK72-14C037-AAG.vbf	Discovery Sport (L550)	ABS - Anti-Lock Brake System Control Module	DATA
LK72-14C037-AAH.vbf	Discovery Sport (L550)	ABS - Anti-Lock Brake System Control Module	DATA
LK72-14C037-AL.vbf	Discovery Sport (L550)	ABS - Anit-Lock Brake System (ABS) Control Module	DATA
LK72-14C037-AN.vbf	Discovery Sport (L550)	ABS - Anit-Lock Brake System (ABS) Control Module	DATA
LK72-14C037-AP.vbf	Discovery Sport (L550)	ABS - Anit-Lock Brake System (ABS) Control Module	DATA
LK72-14C037-AR.vbf	Discovery Sport (L550)	ABS - Anit-Lock Brake System (ABS) Control Module	DATA
LK72-14C037-AS.vbf	Discovery Sport (L550)	ABS - Anit-Lock Brake System (ABS) Control Module	DATA
LK72-14C065-AC.vbf	Discovery Sport (L550)	DDM - Driver Front Door Module	DATA
LK72-14C069-AC.vbf	Discovery Sport (L550)	DRDM - Driver Rear Door Module	DATA
LK72-14C085-AA.vbf	Discovery Sport (L550)	HCM - Headlamp Control Module #1	DATA
LK72-14C085-AB.vbf	Discovery Sport (L550)	HCM - Headlamp Control Module #1	DATA
LK72-14C085-AC.vbf	Discovery Sport (L550)	HCM - Headlamp Control Module #1	DATA
LK72-14C085-AD.vbf	Discovery Sport (L550)	HCM - Headlamp Control Module #1	DATA
LK72-14C085-BA.vbf	Discovery Sport (L550)	Not specified	DATA
LK72-14C085-BB.vbf	Discovery Sport (L550)	Not specified	DATA
LK72-14C085-BC.vbf	Discovery Sport (L550)	Not specified	DATA
LK72-14C085-BD.vbf	Discovery Sport (L550)	Not specified	DATA
LK72-14C088-BB.vbf	Discovery Sport (L550)	IPC - Instrument Panel Cluster (IPC) Control Module	EXE
LK72-14C088-BD.vbf	Discovery Sport (L550)	IPC - Instrument Panel Cluster (IPC) Control Module	EXE
LK72-14C088-BE.vbf	Discovery Sport (L550)	IPC - Instrument Panel Cluster (IPC) Control Module	EXE
LK72-14C088-CA.vbf	Discovery Sport (L550)	IPC - Instrument Panel Cluster (IPC) Control Module	EXE
LK72-14C088-CB.vbf	Discovery Sport (L550)	IPC - Instrument Panel Cluster (IPC) Control Module	EXE
LK72-14C088-CC.vbf	Discovery Sport (L550)	IPC - Instrument Panel Cluster (IPC) Control Module	DATA
LK72-14C088-CD.vbf	Discovery Sport (L550)	IPC - Instrument Panel Cluster (IPC) Control Module	EXE
LK72-14C088-CE.vbf	Discovery Sport (L550)	IPC - Instrument Panel Cluster (IPC) Control Module	EXE
LK72-14C088-CF.vbf	Discovery Sport (L550)	IPC - Instrument Panel Cluster (IPC) Control Module	EXE
LK72-14C088-CG.vbf	Discovery Sport (L550)	IPC - Instrument Panel Cluster (IPC) Control Module	EXE
LK72-14C088-DA.vbf	Discovery Sport (L550)	IPC - Instrument Panel Cluster (IPC) Control Module	EXE
LK72-14C088-EB.vbf	Discovery Sport (L550)	IPC - Instrument Panel Cluster (IPC) Control Module	EXE
LK72-14C088-EC.vbf	Discovery Sport (L550)	IPC - Instrument Panel Cluster (IPC) Control Module	EXE
LK72-14C088-FA.vbf	Discovery Sport (L550)	IPC - Instrument Panel Cluster (IPC) Control Module	EXE
LK72-14C088-FB.vbf	Discovery Sport (L550)	IPC - Instrument Panel Cluster (IPC) Control Module	EXE
LK72-14C088-GA.vbf	Discovery Sport (L550)	IPC - Instrument Panel Cluster (IPC) Control Module	EXE
LK72-14C088-GC.vbf	Discovery Sport (L550)	IPC - Instrument Panel Cluster (IPC) Control Module	EXE
LK72-14C088-GD.vbf	Discovery Sport (L550)	IPC - Instrument Panel Cluster (IPC) Control Module	EXE
LK72-14C088-JA.vbf	Discovery Sport (L550)	IPC - Instrument Panel Cluster (IPC) Control Module	DATA
LK72-14C088-JB.vbf	Discovery Sport (L550)	IPC - Instrument Panel Cluster (IPC) Control Module	DATA
LK72-14C088-JC.vbf	Discovery Sport (L550)	IPC - Instrument Panel Cluster (IPC) Control Module	DATA
LK72-14C088-JD.vbf	Discovery Sport (L550)	IPC - Instrument Panel Cluster (IPC) Control Module	DATA
LK72-14C088-JE.vbf	Discovery Sport (L550)	IPC - Instrument Panel Cluster (IPC) Control Module	DATA
LK72-14C088-JF.vbf	Discovery Sport (L550)	IPC - Instrument Panel Cluster (IPC) Control Module	DATA

File name	Vehicle line (indicative)	Module (ECU)	Type
LK72-14C088-JH.vbf	Discovery Sport (L550)	IPC - Instrument Panel Cluster (IPC) Control Module	DATA
LK72-14C088-TA.vbf	Discovery Sport (L550)	IPC - Instrument Panel Cluster (IPC) Control Module	EXE
LK72-14C088-XA.vbf	Discovery Sport (L550)	IPC - Instrument Panel Cluster (IPC) Control Module	DATA
LK72-14C091-AF.vbf	Discovery Sport (L550)	PAM - Parking Assist Control Module	DATA
LK72-14C091-AG.vbf	Discovery Sport (L550)	PAM - Parking Assist Control Module	DATA
LK72-14C091-AH.vbf	Discovery Sport (L550)	PAM - Parking Assist Control Module	DATA
LK72-14C098-AA.vbf	Discovery Sport (L550)	RCM - Restraints Control Module	DATA
LK72-14C098-AB.vbf	Discovery Sport (L550)	RCM - Restraints Control Module	DATA
LK72-14C098-AC.vbf	Discovery Sport (L550)	RCM - Restraints Control Module	DATA
LK72-14C098-AD.vbf	Discovery Sport (L550)	RCM - Restraints Control Module	DATA
LK72-14C098-AE.vbf	Discovery Sport (L550)	RCM - Restraints Control Module	DATA
LK72-14C098-AF.vbf	Discovery Sport (L550)	RCM - Restraints Control Module	DATA
LK72-14C098-BA.vbf	Discovery Sport (L550)	RCM - Restraints Control Module	DATA
LK72-14C098-BB.vbf	Discovery Sport (L550)	RCM - Restraints Control Module	DATA
LK72-14C098-BC.vbf	Discovery Sport (L550)	RCM - Restraints Control Module	DATA
LK72-14C098-BE.vbf	Discovery Sport (L550)	RCM - Restraints Control Module	DATA
LK72-14C098-BF.vbf	Discovery Sport (L550)	RCM - Restraints Control Module	DATA
LK72-14C105-AA.vbf	Discovery Sport (L550)	TMC Traffic Message Channel Module	EXE
LK72-14C105-BA.vbf	Discovery Sport (L550)	TMC Traffic Message Channel Module	EXE
LK72-14C105-CA.vbf	Discovery Sport (L550)	TMC Traffic Message Channel Module	EXE
LK72-14C109-AC.vbf	Discovery Sport (L550)	PDM - Passenger Front Door Module	DATA
LK72-14C113-AC.vbf	Discovery Sport (L550)	PRDM - Passenger Rear Door Module	DATA
LK72-14C121-AB.vbf	Discovery Sport (L550)	RGTM - Rear Gate / Trunk Module	EXE
LK72-14C121-AC.vbf	Discovery Sport (L550)	RGTM - Rear Gate / Trunk Module	EXE
LK72-14C122-AA.vbf	Discovery Sport (L550)	RGTM - Rear Gate / Trunk Module	DATA
LK72-14C122-AB.vbf	Discovery Sport (L550)	RGTM - Rear Gate / Trunk Module	DATA
LK72-14C124-AA.vbf	Discovery Sport (L550)	RGTM - Rear Gate / Trunk Module	SBL
LK72-14C152-AC.vbf	Discovery Sport (L550)	TPM - Tire Pressure Monitor Module	DATA
LK72-14C152-AD.vbf	Discovery Sport (L550)	TPM - Tire Pressure Monitor Module	DATA
LK72-14C152-AE.vbf	Discovery Sport (L550)	TPM - Tire Pressure Monitor Module	DATA
LK72-14C185-AA.VBF	Discovery Sport (L550)	BCM - Body Control Module	DATA
LK72-14C218-AA.vbf	Discovery Sport (L550)	PSCM - Power Steering Control Module	DATA
LK72-14C218-CA.vbf	Discovery Sport (L550)	PSCM - Power Steering Control Module	DATA
LK72-14C218-GA.vbf	Discovery Sport (L550)	PSCM - Power Steering Control Module	DATA
LK72-14C337-CAA.vbf	Discovery Sport (L550)	TCM - Transmission Control Module	EXE
LK72-14C337-CAB.vbf	Discovery Sport (L550)	TCM - Transmission Control Module	EXE
LK72-14C337-CAC.vbf	Discovery Sport (L550)	TCM - Transmission Control Module	EXE
LK72-14C337-CAD.vbf	Discovery Sport (L550)	TCM - Transmission Control Module	EXE
LK72-14C337-CAE.vbf	Discovery Sport (L550)	TCM - Transmission Control Module	EXE
LK72-14C337-CAF.vbf	Discovery Sport (L550)	TCM - Transmission Control Module	EXE
LK72-14C337-CAG.vbf	Discovery Sport (L550)	TCM - Transmission Control Module	EXE
LK72-14C337-CBA.vbf	Discovery Sport (L550)	TCM - Transmission Control Module	EXE
LK72-14C337-CBB.vbf	Discovery Sport (L550)	TCM - Transmission Control Module	EXE
LK72-14C337-CBC.vbf	Discovery Sport (L550)	TCM - Transmission Control Module	EXE
LK72-14C337-CBD.vbf	Discovery Sport (L550)	TCM - Transmission Control Module	EXE
LK72-14C337-CBE.vbf	Discovery Sport (L550)	TCM - Transmission Control Module	EXE
LK72-14C337-CBF.vbf	Discovery Sport (L550)	TCM - Transmission Control Module	EXE
LK72-14C337-CBH.vbf	Discovery Sport (L550)	TCM - Transmission Control Module	EXE
LK72-14C337-CBJ.vbf	Discovery Sport (L550)	TCM - Transmission Control Module	EXE
LK72-14C337-CCA.vbf	Discovery Sport (L550)	TCM - Transmission Control Module	EXE
LK72-14C337-CCB.vbf	Discovery Sport (L550)	TCM - Transmission Control Module	EXE
LK72-14C337-CCC.vbf	Discovery Sport (L550)	TCM - Transmission Control Module	EXE
LK72-14C337-CCD.vbf	Discovery Sport (L550)	TCM - Transmission Control Module	EXE
LK72-14C337-CCE.vbf	Discovery Sport (L550)	TCM - Transmission Control Module	EXE
LK72-14C337-CCF.vbf	Discovery Sport (L550)	TCM - Transmission Control Module	EXE
LK72-14C337-CCG.vbf	Discovery Sport (L550)	TCM - Transmission Control Module	EXE
LK72-14C337-CDA.vbf	Discovery Sport (L550)	TCM - Transmission Control Module	EXE
LK72-14C337-CDB.vbf	Discovery Sport (L550)	TCM - Transmission Control Module	EXE
LK72-14C337-CDC.vbf	Discovery Sport (L550)	TCM - Transmission Control Module	EXE
LK72-14C337-CDD.vbf	Discovery Sport (L550)	TCM - Transmission Control Module	EXE
LK72-14C337-CDE.vbf	Discovery Sport (L550)	TCM - Transmission Control Module	EXE
LK72-14C337-CDF.vbf	Discovery Sport (L550)	TCM - Transmission Control Module	EXE
LK72-14C337-CDG.vbf	Discovery Sport (L550)	TCM - Transmission Control Module	EXE
LK72-14C337-CEA.vbf	Discovery Sport (L550)	TCM - Transmission Control Module	EXE
LK72-14C337-CEB.vbf	Discovery Sport (L550)	TCM - Transmission Control Module	EXE
LK72-14C337-CEC.vbf	Discovery Sport (L550)	TCM - Transmission Control Module	EXE
LK72-14C337-CED.vbf	Discovery Sport (L550)	TCM - Transmission Control Module	EXE
LK72-14C337-CEE.vbf	Discovery Sport (L550)	TCM - Transmission Control Module	EXE
LK72-14C337-CEF.vbf	Discovery Sport (L550)	TCM - Transmission Control Module	EXE
LK72-14C337-CEG.vbf	Discovery Sport (L550)	TCM - Transmission Control Module	EXE
LK72-14C337-CEH.vbf	Discovery Sport (L550)	TCM - Transmission Control Module	EXE
LK72-14C337-CFA.vbf	Discovery Sport (L550)	TCM - Transmission Control Module	EXE
LK72-14C337-CFB.vbf	Discovery Sport (L550)	TCM - Transmission Control Module	EXE
LK72-14C337-CFC.vbf	Discovery Sport (L550)	TCM - Transmission Control Module	EXE
LK72-14C337-CFD.vbf	Discovery Sport (L550)	TCM - Transmission Control Module	EXE
LK72-14C337-CFE.vbf	Discovery Sport (L550)	TCM - Transmission Control Module	EXE

File name	Vehicle line (indicative)	Module (ECU)	Type
LK72-14C337-CFF.vbf	Discovery Sport (L550)	TCM - Transmission Control Module	EXE
LK72-14C337-CFG.vbf	Discovery Sport (L550)	TCM - Transmission Control Module	EXE
LK72-14C337-CGA.vbf	Discovery Sport (L550)	TCM - Transmission Control Module	EXE
LK72-14C337-CGB.vbf	Discovery Sport (L550)	TCM - Transmission Control Module	EXE
LK72-14C337-CGC.vbf	Discovery Sport (L550)	TCM - Transmission Control Module	EXE
LK72-14C337-CGD.vbf	Discovery Sport (L550)	TCM - Transmission Control Module	EXE
LK72-14C527-AA.vbf	Discovery Sport (L550)	AAM - Audio Amplifier Module	DATA
LK72-14C527-AAA.vbf	Discovery Sport (L550)	AAM - Audio Amplifier Module	DATA
LK72-14C527-AAB.vbf	Discovery Sport (L550)	AAM - Audio Amplifier Module	DATA
LK72-14C527-AB.vbf	Discovery Sport (L550)	AAM - Audio Amplifier Module	DATA
LK72-14C527-ABA.vbf	Discovery Sport (L550)	AAM - Audio Amplifier Module	DATA
LK72-14C527-ABB.vbf	Discovery Sport (L550)	AAM - Audio Amplifier Module	DATA
LK72-14C527-AGA.vbf	Discovery Sport (L550)	AAM - Audio Amplifier Module	DATA
LK72-14C527-AGB.vbf	Discovery Sport (L550)	AAM - Audio Amplifier Module	DATA
LK72-14C527-BA.vbf	Discovery Sport (L550)	AAM - Audio Amplifier Module	DATA
LK72-14C527-BAA.vbf	Discovery Sport (L550)	AAM - Audio Amplifier Module	DATA
LK72-14C527-BAB.vbf	Discovery Sport (L550)	AAM - Audio Amplifier Module	DATA
LK72-14C527-BBA.vbf	Discovery Sport (L550)	AAM - Audio Amplifier Module	DATA
LK72-14C527-BBB.vbf	Discovery Sport (L550)	AAM - Audio Amplifier Module	DATA
LK72-14C527-BFA.vbf	Discovery Sport (L550)	AAM - Audio Amplifier Module	DATA
LK72-14C527-BGA.vbf	Discovery Sport (L550)	AAM - Audio Amplifier Module	DATA
LK72-14C527-BGB.vbf	Discovery Sport (L550)	AAM - Audio Amplifier Module	DATA
LK72-14C527-CA.vbf	Discovery Sport (L550)	AAM - Audio Amplifier Module	DATA
LK72-14C527-CAA.vbf	Discovery Sport (L550)	AAM - Audio Amplifier Module	DATA
LK72-14C527-CAB.vbf	Discovery Sport (L550)	AAM - Audio Amplifier Module	DATA
LK72-14C527-CBA.vbf	Discovery Sport (L550)	AAM - Audio Amplifier Module	DATA
LK72-14C527-CBB.vbf	Discovery Sport (L550)	AAM - Audio Amplifier Module	DATA
LK72-14C527-CCA.vbf	Discovery Sport (L550)	AAM - Audio Amplifier Module	DATA
LK72-14C527-CGA.vbf	Discovery Sport (L550)	AAM - Audio Amplifier Module	DATA
LK72-14C527-CGB.vbf	Discovery Sport (L550)	AAM - Audio Amplifier Module	DATA
LK72-14C527-EA.vbf	Discovery Sport (L550)	AAM - Audio Amplifier Module	DATA
LK72-14C527-FA.vbf	Discovery Sport (L550)	AAM - Audio Amplifier Module	DATA
LK72-14C527-GA.vbf	Discovery Sport (L550)	AAM - Audio Amplifier Module	DATA
LK72-14C570-BAB.vbf	Discovery Sport (L550)	PCM - Powertrain Control Module	EXE
LK72-14C570-BAC.vbf	Discovery Sport (L550)	PCM - Powertrain Control Module	EXE
LK72-14C570-BAD.vbf	Discovery Sport (L550)	PCM - Powertrain Control Module	EXE
LK72-14C570-BAE.vbf	Discovery Sport (L550)	PCM - Powertrain Control Module	EXE
LK72-14C570-BAG.vbf	Discovery Sport (L550)	PCM - Powertrain Control Module	EXE
LK72-14C570-BCB.vbf	Discovery Sport (L550)	PCM - Powertrain Control Module	EXE
LK72-14C570-BCC.vbf	Discovery Sport (L550)	PCM - Powertrain Control Module	EXE
LK72-14C570-BCD.vbf	Discovery Sport (L550)	PCM - Powertrain Control Module	EXE
LK72-14C570-BCE.vbf	Discovery Sport (L550)	PCM - Powertrain Control Module	EXE
LK72-14C570-BCG.vbf	Discovery Sport (L550)	PCM - Powertrain Control Module	EXE
LK72-14C570-BJD.vbf	Discovery Sport (L550)	PCM - Powertrain Control Module	EXE
LK72-14C570-BJE.vbf	Discovery Sport (L550)	PCM - Powertrain Control Module	EXE
LK72-14C570-BJF.vbf	Discovery Sport (L550)	PCM - Powertrain Control Module	EXE
LK72-14C570-BTB.vbf	Discovery Sport (L550)	PCM - Powertrain Control Module	EXE
LK72-14C570-BTC.vbf	Discovery Sport (L550)	PCM - Powertrain Control Module	EXE
LK72-14C570-BTD.vbf	Discovery Sport (L550)	PCM - Powertrain Control Module	EXE
LK72-14C570-BTE.vbf	Discovery Sport (L550)	PCM - Powertrain Control Module	EXE
LK72-14C570-BTG.vbf	Discovery Sport (L550)	PCM - Powertrain Control Module	EXE
LK72-14C570-CFB.vbf	Discovery Sport (L550)	PCM - Powertrain Control Module	EXE
LK72-14C570-CFC.vbf	Discovery Sport (L550)	PCM - Powertrain Control Module	EXE
LK72-14C570-CFD.vbf	Discovery Sport (L550)	PCM - Powertrain Control Module	EXE
LK72-14C570-CFG.vbf	Discovery Sport (L550)	PCM - Powertrain Control Module	EXE
LK72-14C570-CFJ.vbf	Discovery Sport (L550)	PCM - Powertrain Control Module	EXE
LK72-14C570-CGB.vbf	Discovery Sport (L550)	PCM - Powertrain Control Module	EXE
LK72-14C570-CGC.vbf	Discovery Sport (L550)	PCM - Powertrain Control Module	EXE
LK72-14C570-CGD.vbf	Discovery Sport (L550)	PCM - Powertrain Control Module	EXE
LK72-14C570-CGE.vbf	Discovery Sport (L550)	PCM - Powertrain Control Module	EXE
LK72-14C570-CGF.vbf	Discovery Sport (L550)	PCM - Powertrain Control Module	EXE
LK72-14C570-CGG.vbf	Discovery Sport (L550)	PCM - Powertrain Control Module	EXE
LK72-14C570-CGH.vbf	Discovery Sport (L550)	PCM - Powertrain Control Module	EXE
LK72-14C570-CHB.vbf	Discovery Sport (L550)	PCM - Powertrain Control Module	EXE
LK72-14C570-CHC.vbf	Discovery Sport (L550)	PCM - Powertrain Control Module	EXE
LK72-14C570-CHD.vbf	Discovery Sport (L550)	PCM - Powertrain Control Module	EXE
LK72-14C570-CHE.vbf	Discovery Sport (L550)	PCM - Powertrain Control Module	EXE
LK72-14C570-CHH.vbf	Discovery Sport (L550)	PCM - Powertrain Control Module	EXE
LK72-14C570-CHJ.vbf	Discovery Sport (L550)	PCM - Powertrain Control Module	EXE
LK72-14C570-CYA.vbf	Discovery Sport (L550)	PCM - Powertrain Control Module	EXE
LK72-14C570-CYB.vbf	Discovery Sport (L550)	PCM - Powertrain Control Module	EXE
LK72-14C570-CYC.vbf	Discovery Sport (L550)	PCM - Powertrain Control Module	EXE
LK72-14C609-AA.vbf	Discovery Sport (L550)	PSCM - Power Steering Control Module	DATA
LK72-14D049-AB.vbf	Discovery Sport (L550)	CCM - Cruise Control Module	EXE
LK72-14D049-AC.vbf	Discovery Sport (L550)	CCM - Cruise Control Module	EXE
LK72-14D049-AD.vbf	Discovery Sport (L550)	CCM - Cruise Control Module	EXE

File name	Vehicle line (indicative)	Module (ECU)	Type
LK72-14D049-AE.vbf	Discovery Sport (L550)	CCM - Cruise Control Module	EXE
LK72-14D049-AF.vbf	Discovery Sport (L550)	CCM - Cruise Control Module	EXE
LK72-14D051-AA.vbf	Discovery Sport (L550)	CCM - Cruise Control Module	SBL
LK72-14D183-AA.vbf	Discovery Sport (L550)	OCS - Restraints Occupant Classification System Module	DATA
LK72-14D183-AB.VBF	Discovery Sport (L550)	OCS - Restraints Occupant Classification System Module	DATA
LK72-14D485-AA.vbf	Discovery Sport (L550)	IPMB - Image Processing Module B	EXE
LK72-14D485-AB.vbf	Discovery Sport (L550)	IPMB - Image Processing Module B	EXE
LK72-14D485-AD.vbf	Discovery Sport (L550)	IPMB - Image Processing Module B	EXE
LK72-14D564-AC.vbf	Discovery Sport (L550)	SODR - Side Obstacle Detection Control Module - Right	DATA
LK72-14D564-AE.vbf	Discovery Sport (L550)	SODR - Side Obstacle Detection Control Module - Right	DATA
LK72-14E094-UAB.vbf	Discovery Sport (L550)	CHCM - Chassis Control Module	EXE
LK72-14E094-UAD.vbf	Discovery Sport (L550)	CHCM - Chassis Control Module	EXE
LK72-14E094-UAE.vbf	Discovery Sport (L550)	CHCM - Chassis Control Module	EXE
LK72-14E094-UAF.vbf	Discovery Sport (L550)	CHCM - Chassis Control Module	EXE
LK72-14E094-UBB.vbf	Discovery Sport (L550)	CHCM - Chassis Control Module	EXE
LK72-14E094-UBD.vbf	Discovery Sport (L550)	CHCM - Chassis Control Module	EXE
LK72-14E282-AB.vbf	Discovery Sport (L550)	WDCM - WirelessCharger	EXE
LK72-14E284-AB.vbf	Discovery Sport (L550)	WDCM - WirelessCharger	SBL
LK72-14F022-AA.vbf	Discovery Sport (L550)	Not specified	DATA
LK72-14F022-AD.vbf	Discovery Sport (L550)	Not specified	DATA
LK72-14F022-AE.vbf	Discovery Sport (L550)	Not specified	DATA
LK72-14F022-AF.vbf	Discovery Sport (L550)	Not specified	DATA
LK72-14F022-AG.vbf	Discovery Sport (L550)	Not specified	DATA
LK72-14F217-AC.vbf	Discovery Sport (L550)	RHVAC - Rear HVAC Control Module	EXE
LK72-14F217-AD.vbf	Discovery Sport (L550)	RHVAC - Rear HVAC Control Module	EXE
LK72-14F217-AE.vbf	Discovery Sport (L550)	RHVAC - Rear HVAC Control Module	EXE
LK72-14F219-AC.vbf	Discovery Sport (L550)	RHVAC - Rear HVAC Control Module	SBL
LK72-14F230-AB.vbf	Discovery Sport (L550)	HUD - Head Up Display	EXE
LK72-14F230-AC.vbf	Discovery Sport (L550)	HUD - Head Up Display	EXE
LK72-14F231-AB.vbf	Discovery Sport (L550)	HUD - Head Up Display	DATA
LK72-14F397-CA.vbf	Discovery Sport (L550)	IPMA - Image Processing Module A	EXE
LK72-14F397-CB.vbf	Discovery Sport (L550)	IPMA - Image Processing Module A	EXE
LK72-14F397-CC.vbf	Discovery Sport (L550)	IPMA - Image Processing Module A	EXE
LK72-14F397-CD.vbf	Discovery Sport (L550)	IPMA - Image Processing Module A	EXE
LK72-14F397-CE.vbf	Discovery Sport (L550)	IPMA - Image Processing Module A	EXE
LK72-14F397-CG.vbf	Discovery Sport (L550)	IPMA - Image Processing Module A	EXE
LK72-14F397-DA.vbf	Discovery Sport (L550)	IPMA - Image Processing Module A	EXE
LK72-14F397-DB.vbf	Discovery Sport (L550)	IPMA - Image Processing Module A	EXE
LK72-14F397-DC.vbf	Discovery Sport (L550)	IPMA - Image Processing Module A	EXE
LK72-14F397-DD.vbf	Discovery Sport (L550)	IPMA - Image Processing Module A	EXE
LK72-14F397-DE.vbf	Discovery Sport (L550)	IPMA - Image Processing Module A	EXE
LK72-14F397-DG.vbf	Discovery Sport (L550)	IPMA - Image Processing Module A	EXE
LK72-14F397-EA.vbf	Discovery Sport (L550)	IPMA - Image Processing Module A	EXE
LK72-14F397-EB.vbf	Discovery Sport (L550)	IPMA - Image Processing Module A	EXE
LK72-14F397-EC.vbf	Discovery Sport (L550)	IPMA - Image Processing Module A	EXE
LK72-14F397-ED.vbf	Discovery Sport (L550)	IPMA - Image Processing Module A	EXE
LK72-14F397-EE.vbf	Discovery Sport (L550)	IPMA - Image Processing Module A	EXE
LK72-14F397-EG.vbf	Discovery Sport (L550)	IPMA - Image Processing Module A	EXE
LK72-14F397-FA.vbf	Discovery Sport (L550)	IPMA - Image Processing Module A	EXE
LK72-14F397-FB.vbf	Discovery Sport (L550)	IPMA - Image Processing Module A	EXE
LK72-14F397-FC.vbf	Discovery Sport (L550)	IPMA - Image Processing Module A	EXE
LK72-14F397-FD.vbf	Discovery Sport (L550)	IPMA - Image Processing Module A	EXE
LK72-14F397-FE.vbf	Discovery Sport (L550)	IPMA - Image Processing Module A	EXE
LK72-14F397-FG.vbf	Discovery Sport (L550)	IPMA - Image Processing Module A	EXE
LK72-14F398-BA.vbf	Discovery Sport (L550)	IPMA - Image Processing Module A	EXE
LK72-14F398-BB.vbf	Discovery Sport (L550)	IPMA - Image Processing Module A	EXE
LK72-14F398-BC.vbf	Discovery Sport (L550)	IPMA - Image Processing Module A	EXE
LK72-14F398-BD.vbf	Discovery Sport (L550)	IPMA - Image Processing Module A	EXE
LK72-14F398-BE.vbf	Discovery Sport (L550)	IPMA - Image Processing Module A	EXE
LK72-14F398-BG.vbf	Discovery Sport (L550)	IPMA - Image Processing Module A	EXE
LK72-14F398-CA.vbf	Discovery Sport (L550)	IPMA - Image Processing Module A	EXE
LK72-14F398-CB.vbf	Discovery Sport (L550)	IPMA - Image Processing Module A	EXE
LK72-14F398-CC.vbf	Discovery Sport (L550)	IPMA - Image Processing Module A	EXE
LK72-14F398-CD.vbf	Discovery Sport (L550)	IPMA - Image Processing Module A	EXE
LK72-14F398-CE.vbf	Discovery Sport (L550)	IPMA - Image Processing Module A	EXE
LK72-14F398-CG.vbf	Discovery Sport (L550)	IPMA - Image Processing Module A	EXE
LK72-18D619-AA.vbf	Discovery Sport (L550)	HVAC - HVAC Control Module	EXE
LK72-18D619-AC.vbf	Discovery Sport (L550)	HVAC - HVAC Control Module	EXE
LK72-18D619-AD.vbf	Discovery Sport (L550)	HVAC - HVAC Control Module	EXE
LK72-18D620-AB.vbf	Discovery Sport (L550)	HVAC - HVAC Control Module	DATA
LK72-18D620-AE.vbf	Discovery Sport (L550)	HVAC - HVAC Control Module	DATA
LK72-18D620-AF.vbf	Discovery Sport (L550)	HVAC - HVAC Control Module	DATA
LK72-18D620-AG.vbf	Discovery Sport (L550)	HVAC - HVAC Control Module	DATA
LK72-18D620-AH.vbf	Discovery Sport (L550)	HVAC - HVAC Control Module	DATA
LK72-18D620-AJ.vbf	Discovery Sport (L550)	HVAC - HVAC Control Module	DATA
LK72-18D620-AL.vbf	Discovery Sport (L550)	HVAC - HVAC Control Module	DATA

File name	Vehicle line (indicative)	Module (ECU)	Type
LK72-18D620-AM.vbf	Discovery Sport (L550)	HVAC - HVAC Control Module	DATA
LK72-18D620-AN.vbf	Discovery Sport (L550)	HVAC - HVAC Control Module	DATA
LK72-18D620-AP.vbf	Discovery Sport (L550)	HVAC - HVAC Control Module	DATA
LK72-18D620-BB.vbf	Discovery Sport (L550)	HVAC - HVAC Control Module	DATA
LK72-18D620-BE.vbf	Discovery Sport (L550)	HVAC - HVAC Control Module	DATA
LK72-18D620-BF.vbf	Discovery Sport (L550)	HVAC - HVAC Control Module	DATA
LK72-18D620-BG.vbf	Discovery Sport (L550)	HVAC - HVAC Control Module	DATA
LK72-18D620-BH.vbf	Discovery Sport (L550)	HVAC - HVAC Control Module	DATA
LK72-18D620-BJ.vbf	Discovery Sport (L550)	HVAC - HVAC Control Module	DATA
LK72-18D620-BL.vbf	Discovery Sport (L550)	HVAC - HVAC Control Module	DATA
LK72-18D620-BM.vbf	Discovery Sport (L550)	HVAC - HVAC Control Module	DATA
LK72-18D620-BN.vbf	Discovery Sport (L550)	HVAC - HVAC Control Module	DATA
LK72-18D620-BP.vbf	Discovery Sport (L550)	HVAC - HVAC Control Module	DATA
LK72-18D620-CB.vbf	Discovery Sport (L550)	HVAC - HVAC Control Module	DATA
LK72-18D620-CE.vbf	Discovery Sport (L550)	HVAC - HVAC Control Module	DATA
LK72-18D620-CF.vbf	Discovery Sport (L550)	HVAC - HVAC Control Module	DATA
LK72-18D620-CG.vbf	Discovery Sport (L550)	HVAC - HVAC Control Module	DATA
LK72-18D620-CH.vbf	Discovery Sport (L550)	HVAC - HVAC Control Module	DATA
LK72-18D620-CK.vbf	Discovery Sport (L550)	HVAC - HVAC Control Module	DATA
LK72-18D620-CL.vbf	Discovery Sport (L550)	HVAC - HVAC Control Module	DATA
LK72-18D620-CM.vbf	Discovery Sport (L550)	HVAC - HVAC Control Module	DATA
LK72-18D620-CN.vbf	Discovery Sport (L550)	HVAC - HVAC Control Module	DATA
LK72-18D620-DB.vbf	Discovery Sport (L550)	HVAC - HVAC Control Module	DATA
LK72-18D620-DE.vbf	Discovery Sport (L550)	HVAC - HVAC Control Module	DATA
LK72-18D620-DG.vbf	Discovery Sport (L550)	HVAC - HVAC Control Module	DATA
LK72-18D620-DH.vbf	Discovery Sport (L550)	HVAC - HVAC Control Module	DATA
LK72-18D620-DK.vbf	Discovery Sport (L550)	HVAC - HVAC Control Module	DATA
LK72-18D620-DL.vbf	Discovery Sport (L550)	HVAC - HVAC Control Module	DATA
LK72-18D620-DM.vbf	Discovery Sport (L550)	HVAC - HVAC Control Module	DATA
LK72-18D620-DN.vbf	Discovery Sport (L550)	HVAC - HVAC Control Module	DATA
LK72-19C204-AA.vbf	Discovery Sport (L550)	IMC - Infotainment Master Controller	EXE
LK83-14C037-BHB.vbf	Jaguar F-Pace (X761)	ABS - Anti-Lock Brake System Control Module	DATA
LK83-14C037-BHC.vbf	Jaguar F-Pace (X761)	ABS - Anti-Lock Brake System Control Module	DATA
LK83-14C037-BKB.vbf	Jaguar F-Pace (X761)	ABS - Anti-Lock Brake System Control Module	DATA
LK83-14C037-BKC.vbf	Jaguar F-Pace (X761)	ABS - Anti-Lock Brake System Control Module	DATA
LK83-14C037-BLB.vbf	Jaguar F-Pace (X761)	ABS - Anti-Lock Brake System Control Module	DATA
LK83-14C037-BLC.vbf	Jaguar F-Pace (X761)	ABS - Anti-Lock Brake System Control Module	DATA
LK83-14C037-BMB.vbf	Jaguar F-Pace (X761)	ABS - Anti-Lock Brake System Control Module	DATA
LK83-14C037-BMC.vbf	Jaguar F-Pace (X761)	ABS - Anti-Lock Brake System Control Module	DATA
LK83-14C037-BXB.vbf	Jaguar F-Pace (X761)	ABS - Anti-Lock Brake System Control Module	DATA
LK83-14C037-BXC.vbf	Jaguar F-Pace (X761)	ABS - Anti-Lock Brake System Control Module	DATA
LK83-14C037-BYB.vbf	Jaguar F-Pace (X761)	ABS - Anti-Lock Brake System Control Module	DATA
LK83-14C037-BYC.vbf	Jaguar F-Pace (X761)	ABS - Anti-Lock Brake System Control Module	DATA
LK83-14C037-CAB.vbf	Jaguar F-Pace (X761)	ABS - Anti-Lock Brake System Control Module	DATA
LK83-14C037-CAC.vbf	Jaguar F-Pace (X761)	ABS - Anti-Lock Brake System Control Module	DATA
LK83-14C037-CBB.vbf	Jaguar F-Pace (X761)	ABS - Anti-Lock Brake System Control Module	DATA
LK83-14C037-CBC.vbf	Jaguar F-Pace (X761)	ABS - Anti-Lock Brake System Control Module	DATA
LK83-14C037-CCB.vbf	Jaguar F-Pace (X761)	ABS - Anti-Lock Brake System Control Module	DATA
LK83-14C037-CCC.vbf	Jaguar F-Pace (X761)	ABS - Anti-Lock Brake System Control Module	DATA
LK83-14C037-CDB.vbf	Jaguar F-Pace (X761)	ABS - Anti-Lock Brake System Control Module	DATA
LK83-14C037-CDC.vbf	Jaguar F-Pace (X761)	ABS - Anti-Lock Brake System Control Module	DATA
LK83-14C037-CEB.vbf	Jaguar F-Pace (X761)	ABS - Anti-Lock Brake System Control Module	DATA
LK83-14C037-CEC.vbf	Jaguar F-Pace (X761)	ABS - Anti-Lock Brake System Control Module	DATA
LK83-14C037-CHB.vbf	Jaguar F-Pace (X761)	ABS - Anti-Lock Brake System Control Module	DATA
LK83-14C037-CHC.vbf	Jaguar F-Pace (X761)	ABS - Anti-Lock Brake System Control Module	DATA
LK83-14C037-CKB.vbf	Jaguar F-Pace (X761)	ABS - Anti-Lock Brake System Control Module	DATA
LK83-14C037-CKC.vbf	Jaguar F-Pace (X761)	ABS - Anti-Lock Brake System Control Module	DATA
LK83-14C037-CMB.vbf	Jaguar F-Pace (X761)	ABS - Anti-Lock Brake System Control Module	DATA
LK83-14C037-CMC.vbf	Jaguar F-Pace (X761)	ABS - Anti-Lock Brake System Control Module	DATA
LK83-14C037-CTB.vbf	Jaguar F-Pace (X761)	ABS - Anti-Lock Brake System Control Module	DATA
LK83-14C037-CTC.vbf	Jaguar F-Pace (X761)	ABS - Anti-Lock Brake System Control Module	DATA
LK83-14C037-CUB.vbf	Jaguar F-Pace (X761)	ABS - Anti-Lock Brake System Control Module	DATA
LK83-14C037-CUC.vbf	Jaguar F-Pace (X761)	ABS - Anti-Lock Brake System Control Module	DATA
LK83-14C037-CXB.vbf	Jaguar F-Pace (X761)	ABS - Anti-Lock Brake System Control Module	DATA
LK83-14C037-CXC.vbf	Jaguar F-Pace (X761)	ABS - Anti-Lock Brake System Control Module	DATA
LK83-14C037-CZB.vbf	Jaguar F-Pace (X761)	ABS - Anti-Lock Brake System Control Module	DATA
LK83-14C037-CZC.vbf	Jaguar F-Pace (X761)	ABS - Anti-Lock Brake System Control Module	DATA
LK83-14C037-DAB.vbf	Jaguar F-Pace (X761)	ABS - Anti-Lock Brake System Control Module	DATA
LK83-14C037-DAC.vbf	Jaguar F-Pace (X761)	ABS - Anti-Lock Brake System Control Module	DATA
LK83-14C037-DBB.vbf	Jaguar F-Pace (X761)	ABS - Anti-Lock Brake System Control Module	DATA
LK83-14C037-DBC.vbf	Jaguar F-Pace (X761)	ABS - Anti-Lock Brake System Control Module	DATA
LK83-14C037-DCB.vbf	Jaguar F-Pace (X761)	ABS - Anti-Lock Brake System Control Module	DATA
LK83-14C037-DCC.vbf	Jaguar F-Pace (X761)	ABS - Anti-Lock Brake System Control Module	DATA
LK83-14C037-NHB.vbf	Jaguar F-Pace (X761)	ABS - Anti-Lock Brake System Control Module	DATA
LK83-14C037-NHC.vbf	Jaguar F-Pace (X761)	ABS - Anti-Lock Brake System Control Module	DATA
LK83-14C037-NKB.vbf	Jaguar F-Pace (X761)	ABS - Anti-Lock Brake System Control Module	DATA

File name	Vehicle line (indicative)	Module (ECU)	Type
LK83-14C037-NKC.vbf	Jaguar F-Pace (X761)	ABS - Anti-Lock Brake System Control Module	DATA
LK83-14C037-NLB.vbf	Jaguar F-Pace (X761)	ABS - Anti-Lock Brake System Control Module	DATA
LK83-14C037-NLC.vbf	Jaguar F-Pace (X761)	ABS - Anti-Lock Brake System Control Module	DATA
LK83-14C037-NMB.vbf	Jaguar F-Pace (X761)	ABS - Anti-Lock Brake System Control Module	DATA
LK83-14C037-NMC.vbf	Jaguar F-Pace (X761)	ABS - Anti-Lock Brake System Control Module	DATA
LK83-14C037-NXB.vbf	Jaguar F-Pace (X761)	ABS - Anti-Lock Brake System Control Module	DATA
LK83-14C037-NXC.vbf	Jaguar F-Pace (X761)	ABS - Anti-Lock Brake System Control Module	DATA
LK83-14C037-NYB.vbf	Jaguar F-Pace (X761)	ABS - Anti-Lock Brake System Control Module	DATA
LK83-14C037-NYC.vbf	Jaguar F-Pace (X761)	ABS - Anti-Lock Brake System Control Module	DATA
LK83-14C037-PEB.vbf	Jaguar F-Pace (X761)	ABS - Anti-Lock Brake System Control Module	DATA
LK83-14C037-PEC.vbf	Jaguar F-Pace (X761)	ABS - Anti-Lock Brake System Control Module	DATA
LK83-14C037-PHB.vbf	Jaguar F-Pace (X761)	ABS - Anti-Lock Brake System Control Module	DATA
LK83-14C037-PHC.vbf	Jaguar F-Pace (X761)	ABS - Anti-Lock Brake System Control Module	DATA
LK83-14C037-PKB.vbf	Jaguar F-Pace (X761)	ABS - Anti-Lock Brake System Control Module	DATA
LK83-14C037-PKC.vbf	Jaguar F-Pace (X761)	ABS - Anti-Lock Brake System Control Module	DATA
LK83-14C037-PMB.vbf	Jaguar F-Pace (X761)	ABS - Anti-Lock Brake System Control Module	DATA
LK83-14C037-PMC.vbf	Jaguar F-Pace (X761)	ABS - Anti-Lock Brake System Control Module	DATA
LK83-14C037-PTB.vbf	Jaguar F-Pace (X761)	ABS - Anti-Lock Brake System Control Module	DATA
LK83-14C037-PTC.vbf	Jaguar F-Pace (X761)	ABS - Anti-Lock Brake System Control Module	DATA
LK83-14C037-PUB.vbf	Jaguar F-Pace (X761)	ABS - Anti-Lock Brake System Control Module	DATA
LK83-14C037-PUC.vbf	Jaguar F-Pace (X761)	ABS - Anti-Lock Brake System Control Module	DATA
LK83-14C037-PXB.vbf	Jaguar F-Pace (X761)	ABS - Anti-Lock Brake System Control Module	DATA
LK83-14C037-PXC.vbf	Jaguar F-Pace (X761)	ABS - Anti-Lock Brake System Control Module	DATA
LK83-14C037-PZB.vbf	Jaguar F-Pace (X761)	ABS - Anti-Lock Brake System Control Module	DATA
LK83-14C037-PZC.vbf	Jaguar F-Pace (X761)	ABS - Anti-Lock Brake System Control Module	DATA
LK83-14C037-RBB.vbf	Jaguar F-Pace (X761)	ABS - Anti-Lock Brake System Control Module	DATA
LK83-14C037-RBC.vbf	Jaguar F-Pace (X761)	ABS - Anti-Lock Brake System Control Module	DATA
LK83-14C037-RCB.vbf	Jaguar F-Pace (X761)	ABS - Anti-Lock Brake System Control Module	DATA
LK83-14C037-RCC.vbf	Jaguar F-Pace (X761)	ABS - Anti-Lock Brake System Control Module	DATA
LK83-14C152-AA.vbf	Jaguar F-Pace (X761)	TPM - Tire Pressure Monitor Module	DATA
LK83-14C527-ADA.vbf	Jaguar F-Pace (X761)	AAM - Audio Amplifier Module	DATA
LK83-14C527-BDA.vbf	Jaguar F-Pace (X761)	AAM - Audio Amplifier Module	DATA
LK83-14C527-CDA.vbf	Jaguar F-Pace (X761)	AAM - Audio Amplifier Module	DATA
LK83-14C570-UAA.vbf	Jaguar F-Pace (X761)	PCM - Powertrain Control Module	EXE
LK83-14C570-UAB.vbf	Jaguar F-Pace (X761)	PCM - Powertrain Control Module	EXE
LK83-14C570-UFA.vbf	Jaguar F-Pace (X761)	PCM - Powertrain Control Module	EXE
LK83-14C570-UFB.vbf	Jaguar F-Pace (X761)	PCM - Powertrain Control Module	EXE
LPLA-14C036-AB.vbf	Multiple models (shared module)	ABS - Anti-Lock Brake System Control Module	EXE
LPLA-14C036-AC.vbf	Multiple models (shared module)	ABS - Anti-Lock Brake System Control Module	EXE
LPLA-14C036-AD.vbf	Multiple models (shared module)	ABS - Anti-Lock Brake System Control Module	EXE
LPLA-14C036-AE.vbf	Multiple models (shared module)	ABS - Anti-Lock Brake System Control Module	EXE
LPLA-14C036-AF.vbf	Multiple models (shared module)	ABS - Anti-Lock Brake System Control Module	EXE
LPLA-14C039-AA.vbf	Multiple models (shared module)	ABS - Anti-Lock Brake System Control Module	SBL
LPLA-14C184-AA.vbf	Multiple models (shared module)	BCM - Body Control Module	CUSTOM
LPLA-14C184-AB.vbf	Multiple models (shared module)	BCM - Body Control Module	CUSTOM
LPLA-14C184-AC.vbf	Multiple models (shared module)	BCM - Body Control Module	CUSTOM
LPLA-14C184-AD.vbf	Multiple models (shared module)	BCM - Body Control Module	CUSTOM
LPLA-14C217-AA.vbf	Multiple models (shared module)	PSCM - Power Steering Control Module	EXE
LPLA-14C408-AA.vbf	Multiple models (shared module)	BCM - Body Control Module	SIGCFG
LPLA-14C528-AD.vbf	Multiple models (shared module)	AAM - Audio Amplifier Module	SBL
LPLA-14C570-DGA.vbf	Multiple models (shared module)	PCM - Powertrain Control Module	EXE
LPLA-14C570-DGB.vbf	Multiple models (shared module)	PCM - Powertrain Control Module	EXE
LPLA-14C570-DGC.vbf	Multiple models (shared module)	PCM - Powertrain Control Module	EXE
LPLA-14C570-DMA.vbf	Multiple models (shared module)	PCM - Powertrain Control Module	EXE
LPLA-14C570-DMB.vbf	Multiple models (shared module)	PCM - Powertrain Control Module	EXE
LPLA-14C570-DNA.vbf	Multiple models (shared module)	PCM - Powertrain Control Module	EXE
LPLA-14C570-DNB.vbf	Multiple models (shared module)	PCM - Powertrain Control Module	EXE
LPLA-14C570-DPA.vbf	Multiple models (shared module)	PCM - Powertrain Control Module	EXE
LPLA-14C570-DPC.vbf	Multiple models (shared module)	PCM - Powertrain Control Module	EXE
LPLA-14C570-DRA.vbf	Multiple models (shared module)	PCM - Powertrain Control Module	EXE
LPLA-14C570-DRC.vbf	Multiple models (shared module)	PCM - Powertrain Control Module	EXE
LPLA-14C570-DUA.vbf	Multiple models (shared module)	PCM - Powertrain Control Module	EXE
LPLA-14C570-DUB.vbf	Multiple models (shared module)	PCM - Powertrain Control Module	EXE
LPLA-14C570-SAA.vbf	Multiple models (shared module)	PCM - Powertrain Control Module	EXE
LPLA-14C570-SAB.vbf	Multiple models (shared module)	PCM - Powertrain Control Module	EXE
LPLA-14C570-SCA.vbf	Multiple models (shared module)	PCM - Powertrain Control Module	EXE
LPLA-14C570-SEA.vbf	Multiple models (shared module)	PCM - Powertrain Control Module	EXE
LPLA-14C570-SHA.vbf	Multiple models (shared module)	PCM - Powertrain Control Module	EXE
LPLA-14C570-STA.vbf	Multiple models (shared module)	PCM - Powertrain Control Module	EXE
LPLA-14C572-CA.vbf	Multiple models (shared module)	PCM - Powertrain Control Module	SBL
LPLA-18D619-AA.vbf	Multiple models (shared module)	HVAC - HVAC Control Module	EXE
LPLA-18D619-BA.vbf	Multiple models (shared module)	HVAC - HVAC Control Module	EXE
LPLA-18D619-CA.vbf	Multiple models (shared module)	HVAC - HVAC Control Module	EXE
LPLA-19L322-BC.vbf	Multiple models (shared module)	Not specified	EXE
LPLA-19L324-AB.vbf	Multiple models (shared module)	IMC - Infotainment Master Controller	SBL
LX53-14C570-AAA.vbf	Jaguar F-Type (X152)	PCM - Powertrain Control Module	EXE

File name	Vehicle line (indicative)	Module (ECU)	Type
LX53-14C570-ACA.vbf	Jaguar F-Type (X152)	PCM - Powertrain Control Module	EXE
LX53-14C570-ADA.vbf	Jaguar F-Type (X152)	PCM - Powertrain Control Module	EXE
LX53-14C570-AHA.vbf	Jaguar F-Type (X152)	PCM - Powertrain Control Module	EXE
LX53-14C570-AHB.vbf	Jaguar F-Type (X152)	PCM - Powertrain Control Module	EXE
LX53-14C570-ATA.vbf	Jaguar F-Type (X152)	PCM - Powertrain Control Module	EXE
LX53-14C570-CAA.vbf	Jaguar F-Type (X152)	PCM - Powertrain Control Module	EXE
LX53-14C570-CCA.vbf	Jaguar F-Type (X152)	PCM - Powertrain Control Module	EXE
LX53-14C570-CHA.vbf	Jaguar F-Type (X152)	PCM - Powertrain Control Module	EXE
LX53-14C570-CHB.vbf	Jaguar F-Type (X152)	PCM - Powertrain Control Module	EXE
LX53-14C570-CTA.vbf	Jaguar F-Type (X152)	PCM - Powertrain Control Module	EXE
LX53-14C570-CTB.vbf	Jaguar F-Type (X152)	PCM - Powertrain Control Module	EXE
LX53-14C570-PAB.vbf	Jaguar F-Type (X152)	PCM - Powertrain Control Module	EXE
LX53-14C570-PAC.vbf	Jaguar F-Type (X152)	PCM - Powertrain Control Module	EXE
LX53-14C570-PCB.vbf	Jaguar F-Type (X152)	PCM - Powertrain Control Module	EXE
LX53-14C570-PEB.vbf	Jaguar F-Type (X152)	PCM - Powertrain Control Module	EXE
LX53-14C570-PHB.vbf	Jaguar F-Type (X152)	PCM - Powertrain Control Module	EXE
LX53-14C570-PTB.vbf	Jaguar F-Type (X152)	PCM - Powertrain Control Module	EXE
LX53-14C570-SAB.vbf	Jaguar F-Type (X152)	PCM - Powertrain Control Module	EXE
LX53-14C570-SAC.vbf	Jaguar F-Type (X152)	PCM - Powertrain Control Module	EXE
LX53-14C570-SCB.vbf	Jaguar F-Type (X152)	PCM - Powertrain Control Module	EXE
LX53-14C570-SEB.vbf	Jaguar F-Type (X152)	PCM - Powertrain Control Module	EXE
LX53-14C570-SHB.vbf	Jaguar F-Type (X152)	PCM - Powertrain Control Module	EXE
LX53-14C570-STB.vbf	Jaguar F-Type (X152)	PCM - Powertrain Control Module	EXE
LX53-14C570-TAA.vbf	Jaguar F-Type (X152)	PCM - Powertrain Control Module	EXE
LX53-14C570-TCA.vbf	Jaguar F-Type (X152)	PCM - Powertrain Control Module	EXE
LX53-14C570-TEA.vbf	Jaguar F-Type (X152)	PCM - Powertrain Control Module	EXE
LX53-14C570-TFA.vbf	Jaguar F-Type (X152)	PCM - Powertrain Control Module	EXE
LX53-14C570-THA.vbf	Jaguar F-Type (X152)	PCM - Powertrain Control Module	EXE
LX53-14C570-THB.vbf	Jaguar F-Type (X152)	PCM - Powertrain Control Module	EXE
LX53-14C570-TTA.vbf	Jaguar F-Type (X152)	PCM - Powertrain Control Module	EXE
LX53-14C570-TTB.vbf	Jaguar F-Type (X152)	PCM - Powertrain Control Module	EXE
LX53-14C570-UAA.vbf	Jaguar F-Type (X152)	PCM - Powertrain Control Module	EXE
LX53-14C570-UCA.vbf	Jaguar F-Type (X152)	PCM - Powertrain Control Module	EXE
LX53-14C570-UEA.vbf	Jaguar F-Type (X152)	PCM - Powertrain Control Module	EXE
LX53-14C570-UHA.vbf	Jaguar F-Type (X152)	PCM - Powertrain Control Module	EXE
LX53-14C570-UHB.vbf	Jaguar F-Type (X152)	PCM - Powertrain Control Module	EXE
LX53-14C570-UTA.vbf	Jaguar F-Type (X152)	PCM - Powertrain Control Module	EXE
LX53-14C570-UTB.vbf	Jaguar F-Type (X152)	PCM - Powertrain Control Module	EXE
LX53-14C570-XAA.vbf	Jaguar F-Type (X152)	PCM - Powertrain Control Module	EXE
LX53-14C570-XCA.vbf	Jaguar F-Type (X152)	PCM - Powertrain Control Module	EXE
LX53-14C570-XHA.vbf	Jaguar F-Type (X152)	PCM - Powertrain Control Module	EXE
LX53-14C570-XHB.vbf	Jaguar F-Type (X152)	PCM - Powertrain Control Module	EXE
LX53-14C570-XTA.vbf	Jaguar F-Type (X152)	PCM - Powertrain Control Module	EXE
LX53-14E094-DAA.vbf	Jaguar F-Type (X152)	CHCM - Chassis Control Module	EXE
LX53-14E094-DBA.vbf	Jaguar F-Type (X152)	CHCM - Chassis Control Module	EXE
LX53-14E094-DCA.vbf	Jaguar F-Type (X152)	CHCM - Chassis Control Module	EXE
LX53-14E094-DDA.vbf	Jaguar F-Type (X152)	CHCM - Chassis Control Module	EXE
LX53-14E094-DEA.vbf	Jaguar F-Type (X152)	CHCM - Chassis Control Module	EXE
LX53-14E094-DFA.vbf	Jaguar F-Type (X152)	CHCM - Chassis Control Module	EXE
LX53-14E094-DGA.vbf	Jaguar F-Type (X152)	CHCM - Chassis Control Module	EXE
LX53-14E094-DHA.vbf	Jaguar F-Type (X152)	CHCM - Chassis Control Module	EXE
LX53-14E094-DJA.vbf	Jaguar F-Type (X152)	CHCM - Chassis Control Module	EXE
LX53-14E094-DKA.vbf	Jaguar F-Type (X152)	CHCM - Chassis Control Module	EXE
LX53-14F397-AA.vbf	Jaguar F-Type (X152)	IPMA - Image Processing Module A	EXE
LX53-14F397-BA.vbf	Jaguar F-Type (X152)	IPMA - Image Processing Module A	EXE
LX53-14F398-AA.vbf	Jaguar F-Type (X152)	IPMA - Image Processing Module A	EXE
LX53-19C204-AA.vbf	Jaguar F-Type (X152)	IMC - Infotainment Master Controller	EXE
LX63-14C037-AAB.vbf	Jaguar XF (X260)	ABS - Anti-Lock Brake System Control Module	DATA
LX63-14C037-AAC.vbf	Jaguar XF (X260)	ABS - Anti-Lock Brake System Control Module	DATA
LX63-14C037-ABB.vbf	Jaguar XF (X260)	ABS - Anti-Lock Brake System Control Module	DATA
LX63-14C037-ABC.vbf	Jaguar XF (X260)	ABS - Anti-Lock Brake System Control Module	DATA
LX63-14C037-ACB.vbf	Jaguar XF (X260)	ABS - Anti-Lock Brake System Control Module	DATA
LX63-14C037-ACC.vbf	Jaguar XF (X260)	ABS - Anti-Lock Brake System Control Module	DATA
LX63-14C037-ADB.vbf	Jaguar XF (X260)	ABS - Anti-Lock Brake System Control Module	DATA
LX63-14C037-ADC.vbf	Jaguar XF (X260)	ABS - Anti-Lock Brake System Control Module	DATA
LX63-14C037-AGB.vbf	Jaguar XF (X260)	ABS - Anti-Lock Brake System Control Module	DATA
LX63-14C037-AGC.vbf	Jaguar XF (X260)	ABS - Anti-Lock Brake System Control Module	DATA
LX63-14C037-AHB.vbf	Jaguar XF (X260)	ABS - Anti-Lock Brake System Control Module	DATA
LX63-14C037-AHC.vbf	Jaguar XF (X260)	ABS - Anti-Lock Brake System Control Module	DATA
LX63-14C037-AJB.vbf	Jaguar XF (X260)	ABS - Anti-Lock Brake System Control Module	DATA
LX63-14C037-AJC.vbf	Jaguar XF (X260)	ABS - Anti-Lock Brake System Control Module	DATA
LX63-14C037-AKB.vbf	Jaguar XF (X260)	ABS - Anti-Lock Brake System Control Module	DATA
LX63-14C037-AKC.vbf	Jaguar XF (X260)	ABS - Anti-Lock Brake System Control Module	DATA
LX63-14C037-AMB.vbf	Jaguar XF (X260)	ABS - Anti-Lock Brake System Control Module	DATA
LX63-14C037-AMC.vbf	Jaguar XF (X260)	ABS - Anti-Lock Brake System Control Module	DATA
LX63-14C037-ANB.vbf	Jaguar XF (X260)	ABS - Anti-Lock Brake System Control Module	DATA

File name	Vehicle line (indicative)	Module (ECU)	Type
LX63-14C037-ANC.vbf	Jaguar XF (X260)	ABS - Anti-Lock Brake System Control Module	DATA
LX63-14C037-APB.vbf	Jaguar XF (X260)	ABS - Anti-Lock Brake System Control Module	DATA
LX63-14C037-APC.vbf	Jaguar XF (X260)	ABS - Anti-Lock Brake System Control Module	DATA
LX63-14C037-ARB.vbf	Jaguar XF (X260)	ABS - Anti-Lock Brake System Control Module	DATA
LX63-14C037-ARC.vbf	Jaguar XF (X260)	ABS - Anti-Lock Brake System Control Module	DATA
LX63-14C037-ASB.vbf	Jaguar XF (X260)	ABS - Anti-Lock Brake System Control Module	DATA
LX63-14C037-ASC.vbf	Jaguar XF (X260)	ABS - Anti-Lock Brake System Control Module	DATA
LX63-14C037-ATB.vbf	Jaguar XF (X260)	ABS - Anti-Lock Brake System Control Module	DATA
LX63-14C037-ATC.vbf	Jaguar XF (X260)	ABS - Anti-Lock Brake System Control Module	DATA
LX63-14C037-AUB.vbf	Jaguar XF (X260)	ABS - Anti-Lock Brake System Control Module	DATA
LX63-14C037-AUC.vbf	Jaguar XF (X260)	ABS - Anti-Lock Brake System Control Module	DATA
LX63-14C037-AVB.vbf	Jaguar XF (X260)	ABS - Anti-Lock Brake System Control Module	DATA
LX63-14C037-AVC.vbf	Jaguar XF (X260)	ABS - Anti-Lock Brake System Control Module	DATA
LX63-14C037-AXB.vbf	Jaguar XF (X260)	ABS - Anti-Lock Brake System Control Module	DATA
LX63-14C037-AXC.vbf	Jaguar XF (X260)	ABS - Anti-Lock Brake System Control Module	DATA
LX63-14C037-AYB.vbf	Jaguar XF (X260)	ABS - Anti-Lock Brake System Control Module	DATA
LX63-14C037-AYC.vbf	Jaguar XF (X260)	ABS - Anti-Lock Brake System Control Module	DATA
LX63-14C037-AZB.vbf	Jaguar XF (X260)	ABS - Anti-Lock Brake System Control Module	DATA
LX63-14C037-AZC.vbf	Jaguar XF (X260)	ABS - Anti-Lock Brake System Control Module	DATA
LX63-14C037-BAB.vbf	Jaguar XF (X260)	ABS - Anti-Lock Brake System Control Module	DATA
LX63-14C037-BAC.vbf	Jaguar XF (X260)	ABS - Anti-Lock Brake System Control Module	DATA
LX63-14C037-EBB.vbf	Jaguar XF (X260)	ABS - Anti-Lock Brake System Control Module	DATA
LX63-14C037-EBC.vbf	Jaguar XF (X260)	ABS - Anti-Lock Brake System Control Module	DATA
LX63-14C037-ECB.vbf	Jaguar XF (X260)	ABS - Anti-Lock Brake System Control Module	DATA
LX63-14C037-ECC.vbf	Jaguar XF (X260)	ABS - Anti-Lock Brake System Control Module	DATA
LX63-14C037-EFB.vbf	Jaguar XF (X260)	ABS - Anti-Lock Brake System Control Module	DATA
LX63-14C037-EFC.vbf	Jaguar XF (X260)	ABS - Anti-Lock Brake System Control Module	DATA
LX63-14C037-EGB.vbf	Jaguar XF (X260)	ABS - Anti-Lock Brake System Control Module	DATA
LX63-14C037-EGC.vbf	Jaguar XF (X260)	ABS - Anti-Lock Brake System Control Module	DATA
LX63-14C037-EHB.vbf	Jaguar XF (X260)	ABS - Anti-Lock Brake System Control Module	DATA
LX63-14C037-EHC.vbf	Jaguar XF (X260)	ABS - Anti-Lock Brake System Control Module	DATA
LX63-14C037-EJB.vbf	Jaguar XF (X260)	ABS - Anti-Lock Brake System Control Module	DATA
LX63-14C037-EJC.vbf	Jaguar XF (X260)	ABS - Anti-Lock Brake System Control Module	DATA
LX63-14C037-EKB.vbf	Jaguar XF (X260)	ABS - Anti-Lock Brake System Control Module	DATA
LX63-14C037-EKC.vbf	Jaguar XF (X260)	ABS - Anti-Lock Brake System Control Module	DATA
LX63-14C037-ELB.vbf	Jaguar XF (X260)	ABS - Anti-Lock Brake System Control Module	DATA
LX63-14C037-ELC.vbf	Jaguar XF (X260)	ABS - Anti-Lock Brake System Control Module	DATA
LX63-14C037-EMB.vbf	Jaguar XF (X260)	ABS - Anti-Lock Brake System Control Module	DATA
LX63-14C037-EMC.vbf	Jaguar XF (X260)	ABS - Anti-Lock Brake System Control Module	DATA
LX63-14C037-FAB.vbf	Jaguar XF (X260)	ABS - Anti-Lock Brake System Control Module	DATA
LX63-14C037-FAC.vbf	Jaguar XF (X260)	ABS - Anti-Lock Brake System Control Module	DATA
LX63-14C037-FBB.vbf	Jaguar XF (X260)	ABS - Anti-Lock Brake System Control Module	DATA
LX63-14C037-FBC.vbf	Jaguar XF (X260)	ABS - Anti-Lock Brake System Control Module	DATA
LX63-14C037-FCB.vbf	Jaguar XF (X260)	ABS - Anti-Lock Brake System Control Module	DATA
LX63-14C037-FCC.vbf	Jaguar XF (X260)	ABS - Anti-Lock Brake System Control Module	DATA
LX63-14C037-FDB.vbf	Jaguar XF (X260)	ABS - Anti-Lock Brake System Control Module	DATA
LX63-14C037-FDC.vbf	Jaguar XF (X260)	ABS - Anti-Lock Brake System Control Module	DATA
LX63-14C037-FGB.vbf	Jaguar XF (X260)	ABS - Anti-Lock Brake System Control Module	DATA
LX63-14C037-FGC.vbf	Jaguar XF (X260)	ABS - Anti-Lock Brake System Control Module	DATA
LX63-14C037-FHB.vbf	Jaguar XF (X260)	ABS - Anti-Lock Brake System Control Module	DATA
LX63-14C037-FHC.vbf	Jaguar XF (X260)	ABS - Anti-Lock Brake System Control Module	DATA
LX63-14C037-FJB.vbf	Jaguar XF (X260)	ABS - Anti-Lock Brake System Control Module	DATA
LX63-14C037-FJC.vbf	Jaguar XF (X260)	ABS - Anti-Lock Brake System Control Module	DATA
LX63-14C037-FMB.vbf	Jaguar XF (X260)	ABS - Anti-Lock Brake System Control Module	DATA
LX63-14C037-FMC.vbf	Jaguar XF (X260)	ABS - Anti-Lock Brake System Control Module	DATA
LX63-14C037-FNB.vbf	Jaguar XF (X260)	ABS - Anti-Lock Brake System Control Module	DATA
LX63-14C037-FNC.vbf	Jaguar XF (X260)	ABS - Anti-Lock Brake System Control Module	DATA
LX63-14C037-FRB.vbf	Jaguar XF (X260)	ABS - Anti-Lock Brake System Control Module	DATA
LX63-14C037-FRC.vbf	Jaguar XF (X260)	ABS - Anti-Lock Brake System Control Module	DATA
LX63-14C037-FSB.vbf	Jaguar XF (X260)	ABS - Anti-Lock Brake System Control Module	DATA
LX63-14C037-FSC.vbf	Jaguar XF (X260)	ABS - Anti-Lock Brake System Control Module	DATA
LX63-14C037-FTB.vbf	Jaguar XF (X260)	ABS - Anti-Lock Brake System Control Module	DATA
LX63-14C037-FTC.vbf	Jaguar XF (X260)	ABS - Anti-Lock Brake System Control Module	DATA
LX63-14C037-FUB.vbf	Jaguar XF (X260)	ABS - Anti-Lock Brake System Control Module	DATA
LX63-14C037-FUC.vbf	Jaguar XF (X260)	ABS - Anti-Lock Brake System Control Module	DATA
LX63-14C037-FVB.vbf	Jaguar XF (X260)	ABS - Anti-Lock Brake System Control Module	DATA
LX63-14C037-FVC.vbf	Jaguar XF (X260)	ABS - Anti-Lock Brake System Control Module	DATA
LX63-14C037-FXB.vbf	Jaguar XF (X260)	ABS - Anti-Lock Brake System Control Module	DATA
LX63-14C037-FXC.vbf	Jaguar XF (X260)	ABS - Anti-Lock Brake System Control Module	DATA
LX63-14C037-FYB.vbf	Jaguar XF (X260)	ABS - Anti-Lock Brake System Control Module	DATA
LX63-14C037-FYC.vbf	Jaguar XF (X260)	ABS - Anti-Lock Brake System Control Module	DATA
LX63-14C037-FZB.vbf	Jaguar XF (X260)	ABS - Anti-Lock Brake System Control Module	DATA
LX63-14C037-FZC.vbf	Jaguar XF (X260)	ABS - Anti-Lock Brake System Control Module	DATA
LX63-14C037-GAB.vbf	Jaguar XF (X260)	ABS - Anti-Lock Brake System Control Module	DATA
LX63-14C037-GAC.vbf	Jaguar XF (X260)	ABS - Anti-Lock Brake System Control Module	DATA
LX63-14C037-GBB.vbf	Jaguar XF (X260)	ABS - Anti-Lock Brake System Control Module	DATA

File name	Vehicle line (indicative)	Module (ECU)	Type
LX63-14C037-GBC.vbf	Jaguar XF (X260)	ABS - Anti-Lock Brake System Control Module	DATA
LX63-14C037-GDB.vbf	Jaguar XF (X260)	ABS - Anti-Lock Brake System Control Module	DATA
LX63-14C037-GDC.vbf	Jaguar XF (X260)	ABS - Anti-Lock Brake System Control Module	DATA
LX63-14C037-GEB.vbf	Jaguar XF (X260)	ABS - Anti-Lock Brake System Control Module	DATA
LX63-14C037-GEC.vbf	Jaguar XF (X260)	ABS - Anti-Lock Brake System Control Module	DATA
LX63-14C037-GFB.vbf	Jaguar XF (X260)	ABS - Anti-Lock Brake System Control Module	DATA
LX63-14C037-GFC.vbf	Jaguar XF (X260)	ABS - Anti-Lock Brake System Control Module	DATA
LX63-14C037-GGB.vbf	Jaguar XF (X260)	ABS - Anti-Lock Brake System Control Module	DATA
LX63-14C037-GGC.vbf	Jaguar XF (X260)	ABS - Anti-Lock Brake System Control Module	DATA
LX63-14C037-MAB.vbf	Jaguar XF (X260)	ABS - Anti-Lock Brake System Control Module	DATA
LX63-14C037-MAC.vbf	Jaguar XF (X260)	ABS - Anti-Lock Brake System Control Module	DATA
LX63-14C037-MBB.vbf	Jaguar XF (X260)	ABS - Anti-Lock Brake System Control Module	DATA
LX63-14C037-MBC.vbf	Jaguar XF (X260)	ABS - Anti-Lock Brake System Control Module	DATA
LX63-14C037-MCB.vbf	Jaguar XF (X260)	ABS - Anti-Lock Brake System Control Module	DATA
LX63-14C037-MCC.vbf	Jaguar XF (X260)	ABS - Anti-Lock Brake System Control Module	DATA
LX63-14C037-MDB.vbf	Jaguar XF (X260)	ABS - Anti-Lock Brake System Control Module	DATA
LX63-14C037-MDC.vbf	Jaguar XF (X260)	ABS - Anti-Lock Brake System Control Module	DATA
LX63-14C037-MGB.vbf	Jaguar XF (X260)	ABS - Anti-Lock Brake System Control Module	DATA
LX63-14C037-MGC.vbf	Jaguar XF (X260)	ABS - Anti-Lock Brake System Control Module	DATA
LX63-14C037-MHB.vbf	Jaguar XF (X260)	ABS - Anti-Lock Brake System Control Module	DATA
LX63-14C037-MHC.vbf	Jaguar XF (X260)	ABS - Anti-Lock Brake System Control Module	DATA
LX63-14C037-MJB.vbf	Jaguar XF (X260)	ABS - Anti-Lock Brake System Control Module	DATA
LX63-14C037-MJC.vbf	Jaguar XF (X260)	ABS - Anti-Lock Brake System Control Module	DATA
LX63-14C037-MKB.vbf	Jaguar XF (X260)	ABS - Anti-Lock Brake System Control Module	DATA
LX63-14C037-MKC.vbf	Jaguar XF (X260)	ABS - Anti-Lock Brake System Control Module	DATA
LX63-14C037-MNB.vbf	Jaguar XF (X260)	ABS - Anti-Lock Brake System Control Module	DATA
LX63-14C037-MNC.vbf	Jaguar XF (X260)	ABS - Anti-Lock Brake System Control Module	DATA
LX63-14C037-MPB.vbf	Jaguar XF (X260)	ABS - Anti-Lock Brake System Control Module	DATA
LX63-14C037-MPC.vbf	Jaguar XF (X260)	ABS - Anti-Lock Brake System Control Module	DATA
LX63-14C037-MRB.vbf	Jaguar XF (X260)	ABS - Anti-Lock Brake System Control Module	DATA
LX63-14C037-MRC.vbf	Jaguar XF (X260)	ABS - Anti-Lock Brake System Control Module	DATA
LX63-14C037-MSB.vbf	Jaguar XF (X260)	ABS - Anti-Lock Brake System Control Module	DATA
LX63-14C037-MSC.vbf	Jaguar XF (X260)	ABS - Anti-Lock Brake System Control Module	DATA
LX63-14C037-MTB.vbf	Jaguar XF (X260)	ABS - Anti-Lock Brake System Control Module	DATA
LX63-14C037-MTC.vbf	Jaguar XF (X260)	ABS - Anti-Lock Brake System Control Module	DATA
LX63-14C037-MUB.vbf	Jaguar XF (X260)	ABS - Anti-Lock Brake System Control Module	DATA
LX63-14C037-MUC.vbf	Jaguar XF (X260)	ABS - Anti-Lock Brake System Control Module	DATA
LX63-14C037-MVB.vbf	Jaguar XF (X260)	ABS - Anti-Lock Brake System Control Module	DATA
LX63-14C037-MVC.vbf	Jaguar XF (X260)	ABS - Anti-Lock Brake System Control Module	DATA
LX63-14C037-MXB.vbf	Jaguar XF (X260)	ABS - Anti-Lock Brake System Control Module	DATA
LX63-14C037-MXC.vbf	Jaguar XF (X260)	ABS - Anti-Lock Brake System Control Module	DATA
LX63-14C037-MYB.vbf	Jaguar XF (X260)	ABS - Anti-Lock Brake System Control Module	DATA
LX63-14C037-MYC.vbf	Jaguar XF (X260)	ABS - Anti-Lock Brake System Control Module	DATA
LX63-14C037-MZB.vbf	Jaguar XF (X260)	ABS - Anti-Lock Brake System Control Module	DATA
LX63-14C037-MZC.vbf	Jaguar XF (X260)	ABS - Anti-Lock Brake System Control Module	DATA
LX63-14C037-NAB.vbf	Jaguar XF (X260)	ABS - Anti-Lock Brake System Control Module	DATA
LX63-14C037-NAC.vbf	Jaguar XF (X260)	ABS - Anti-Lock Brake System Control Module	DATA
LX63-14C037-SBB.vbf	Jaguar XF (X260)	ABS - Anti-Lock Brake System Control Module	DATA
LX63-14C037-SBC.vbf	Jaguar XF (X260)	ABS - Anti-Lock Brake System Control Module	DATA
LX63-14C037-SCB.vbf	Jaguar XF (X260)	ABS - Anti-Lock Brake System Control Module	DATA
LX63-14C037-SCC.vbf	Jaguar XF (X260)	ABS - Anti-Lock Brake System Control Module	DATA
LX63-14C037-SFC.vbf	Jaguar XF (X260)	ABS - Anti-Lock Brake System Control Module	DATA
LX63-14C037-SGB.vbf	Jaguar XF (X260)	ABS - Anti-Lock Brake System Control Module	DATA
LX63-14C037-SGC.vbf	Jaguar XF (X260)	ABS - Anti-Lock Brake System Control Module	DATA
LX63-14C037-SHB.vbf	Jaguar XF (X260)	ABS - Anti-Lock Brake System Control Module	DATA
LX63-14C037-SHC.vbf	Jaguar XF (X260)	ABS - Anti-Lock Brake System Control Module	DATA
LX63-14C037-SJB.vbf	Jaguar XF (X260)	ABS - Anti-Lock Brake System Control Module	DATA
LX63-14C037-SJC.vbf	Jaguar XF (X260)	ABS - Anti-Lock Brake System Control Module	DATA
LX63-14C037-SKB.vbf	Jaguar XF (X260)	ABS - Anti-Lock Brake System Control Module	DATA
LX63-14C037-SKC.vbf	Jaguar XF (X260)	ABS - Anti-Lock Brake System Control Module	DATA
LX63-14C037-SLB.vbf	Jaguar XF (X260)	ABS - Anti-Lock Brake System Control Module	DATA
LX63-14C037-SLC.vbf	Jaguar XF (X260)	ABS - Anti-Lock Brake System Control Module	DATA
LX63-14C037-SMB.vbf	Jaguar XF (X260)	ABS - Anti-Lock Brake System Control Module	DATA
LX63-14C037-SMC.vbf	Jaguar XF (X260)	ABS - Anti-Lock Brake System Control Module	DATA
LX63-14C037-TAB.vbf	Jaguar XF (X260)	ABS - Anti-Lock Brake System Control Module	DATA
LX63-14C037-TAC.vbf	Jaguar XF (X260)	ABS - Anti-Lock Brake System Control Module	DATA
LX63-14C037-TBB.vbf	Jaguar XF (X260)	ABS - Anti-Lock Brake System Control Module	DATA
LX63-14C037-TBC.vbf	Jaguar XF (X260)	ABS - Anti-Lock Brake System Control Module	DATA
LX63-14C037-TCB.vbf	Jaguar XF (X260)	ABS - Anti-Lock Brake System Control Module	DATA
LX63-14C037-TCC.vbf	Jaguar XF (X260)	ABS - Anti-Lock Brake System Control Module	DATA
LX63-14C037-TDB.vbf	Jaguar XF (X260)	ABS - Anti-Lock Brake System Control Module	DATA
LX63-14C037-TDC.vbf	Jaguar XF (X260)	ABS - Anti-Lock Brake System Control Module	DATA
LX63-14C037-TGB.vbf	Jaguar XF (X260)	ABS - Anti-Lock Brake System Control Module	DATA
LX63-14C037-TGC.vbf	Jaguar XF (X260)	ABS - Anti-Lock Brake System Control Module	DATA
LX63-14C037-THB.vbf	Jaguar XF (X260)	ABS - Anti-Lock Brake System Control Module	DATA
LX63-14C037-THC.vbf	Jaguar XF (X260)	ABS - Anti-Lock Brake System Control Module	DATA

File name	Vehicle line (indicative)	Module (ECU)	Type
LX63-14C037-TJB.vbf	Jaguar XF (X260)	ABS - Anti-Lock Brake System Control Module	DATA
LX63-14C037-TJC.vbf	Jaguar XF (X260)	ABS - Anti-Lock Brake System Control Module	DATA
LX63-14C037-TRB.vbf	Jaguar XF (X260)	ABS - Anti-Lock Brake System Control Module	DATA
LX63-14C037-TRC.vbf	Jaguar XF (X260)	ABS - Anti-Lock Brake System Control Module	DATA
LX63-14C037-TSB.vbf	Jaguar XF (X260)	ABS - Anti-Lock Brake System Control Module	DATA
LX63-14C037-TSC.vbf	Jaguar XF (X260)	ABS - Anti-Lock Brake System Control Module	DATA
LX63-14C037-TUB.vbf	Jaguar XF (X260)	ABS - Anti-Lock Brake System Control Module	DATA
LX63-14C037-TUC.vbf	Jaguar XF (X260)	ABS - Anti-Lock Brake System Control Module	DATA
LX63-14C037-TVB.vbf	Jaguar XF (X260)	ABS - Anti-Lock Brake System Control Module	DATA
LX63-14C037-TVC.vbf	Jaguar XF (X260)	ABS - Anti-Lock Brake System Control Module	DATA
LX63-14C037-TXB.vbf	Jaguar XF (X260)	ABS - Anti-Lock Brake System Control Module	DATA
LX63-14C037-TXC.vbf	Jaguar XF (X260)	ABS - Anti-Lock Brake System Control Module	DATA
LX63-14C037-TYB.vbf	Jaguar XF (X260)	ABS - Anti-Lock Brake System Control Module	DATA
LX63-14C037-TYC.vbf	Jaguar XF (X260)	ABS - Anti-Lock Brake System Control Module	DATA
LX63-14C037-TZB.vbf	Jaguar XF (X260)	ABS - Anti-Lock Brake System Control Module	DATA
LX63-14C037-TZC.vbf	Jaguar XF (X260)	ABS - Anti-Lock Brake System Control Module	DATA
LX63-14C037-UAB.vbf	Jaguar XF (X260)	ABS - Anti-Lock Brake System Control Module	DATA
LX63-14C037-UAC.vbf	Jaguar XF (X260)	ABS - Anti-Lock Brake System Control Module	DATA
LX63-14C037-UBB.vbf	Jaguar XF (X260)	ABS - Anti-Lock Brake System Control Module	DATA
LX63-14C037-UBC.vbf	Jaguar XF (X260)	ABS - Anti-Lock Brake System Control Module	DATA
LX63-14C037-UDB.vbf	Jaguar XF (X260)	ABS - Anti-Lock Brake System Control Module	DATA
LX63-14C037-UDC.vbf	Jaguar XF (X260)	ABS - Anti-Lock Brake System Control Module	DATA
LX63-14C037-UEB.vbf	Jaguar XF (X260)	ABS - Anti-Lock Brake System Control Module	DATA
LX63-14C037-UEC.vbf	Jaguar XF (X260)	ABS - Anti-Lock Brake System Control Module	DATA
LX63-14C037-UFB.vbf	Jaguar XF (X260)	ABS - Anti-Lock Brake System Control Module	DATA
LX63-14C037-UFC.vbf	Jaguar XF (X260)	ABS - Anti-Lock Brake System Control Module	DATA
LX63-14C037-UGB.vbf	Jaguar XF (X260)	ABS - Anti-Lock Brake System Control Module	DATA
LX63-14C037-UGC.vbf	Jaguar XF (X260)	ABS - Anti-Lock Brake System Control Module	DATA
LX63-14C527-AA.vbf	Jaguar XF (X260)	AAM - Audio Amplifier Module	DATA
LX63-14C527-ABA.vbf	Jaguar XF (X260)	AAM - Audio Amplifier Module	DATA
LX63-14C527-ACA.vbf	Jaguar XF (X260)	AAM - Audio Amplifier Module	DATA
LX63-14C527-ADA.vbf	Jaguar XF (X260)	AAM - Audio Amplifier Module	DATA
LX63-14C527-AEA.vbf	Jaguar XF (X260)	AAM - Audio Amplifier Module	DATA
LX63-14C527-AFA.vbf	Jaguar XF (X260)	AAM - Audio Amplifier Module	DATA
LX63-14C527-AGA.vbf	Jaguar XF (X260)	AAM - Audio Amplifier Module	DATA
LX63-14C527-BA.vbf	Jaguar XF (X260)	AAM - Audio Amplifier Module	DATA
LX63-14C527-BBA.vbf	Jaguar XF (X260)	AAM - Audio Amplifier Module	DATA
LX63-14C527-BCA.vbf	Jaguar XF (X260)	AAM - Audio Amplifier Module	DATA
LX63-14C527-BDA.vbf	Jaguar XF (X260)	AAM - Audio Amplifier Module	DATA
LX63-14C527-BEA.vbf	Jaguar XF (X260)	AAM - Audio Amplifier Module	DATA
LX63-14C527-BFA.vbf	Jaguar XF (X260)	AAM - Audio Amplifier Module	DATA
LX63-14C527-BGA.vbf	Jaguar XF (X260)	AAM - Audio Amplifier Module	DATA
LX63-14C527-CA.vbf	Jaguar XF (X260)	AAM - Audio Amplifier Module	DATA
LX63-14C527-CBA.vbf	Jaguar XF (X260)	AAM - Audio Amplifier Module	DATA
LX63-14C527-CCA.vbf	Jaguar XF (X260)	AAM - Audio Amplifier Module	DATA
LX63-14C527-CDA.vbf	Jaguar XF (X260)	AAM - Audio Amplifier Module	DATA
LX63-14C527-CEA.vbf	Jaguar XF (X260)	AAM - Audio Amplifier Module	DATA
LX63-14C527-CFA.vbf	Jaguar XF (X260)	AAM - Audio Amplifier Module	DATA
LX63-14C527-CGA.vbf	Jaguar XF (X260)	AAM - Audio Amplifier Module	DATA
LX63-14C527-EA.vbf	Jaguar XF (X260)	AAM - Audio Amplifier Module	DATA
LX63-14C527-EBA.vbf	Jaguar XF (X260)	AAM - Audio Amplifier Module	DATA
LX63-14C527-ECA.vbf	Jaguar XF (X260)	AAM - Audio Amplifier Module	DATA
LX63-14C527-EDA.vbf	Jaguar XF (X260)	AAM - Audio Amplifier Module	DATA
LX63-14C527-EEA.vbf	Jaguar XF (X260)	AAM - Audio Amplifier Module	DATA
LX63-14C527-EFA.vbf	Jaguar XF (X260)	AAM - Audio Amplifier Module	DATA
LX63-14C527-EGA.vbf	Jaguar XF (X260)	AAM - Audio Amplifier Module	DATA
LX63-14C527-FA.vbf	Jaguar XF (X260)	AAM - Audio Amplifier Module	DATA
LX63-14C527-FBA.vbf	Jaguar XF (X260)	AAM - Audio Amplifier Module	DATA
LX63-14C527-FCA.vbf	Jaguar XF (X260)	AAM - Audio Amplifier Module	DATA
LX63-14C527-FDA.vbf	Jaguar XF (X260)	AAM - Audio Amplifier Module	DATA
LX63-14C527-FEA.vbf	Jaguar XF (X260)	AAM - Audio Amplifier Module	DATA
LX63-14C527-FFA.vbf	Jaguar XF (X260)	AAM - Audio Amplifier Module	DATA
LX63-14C527-FGA.vbf	Jaguar XF (X260)	AAM - Audio Amplifier Module	DATA
LX63-14C527-GA.vbf	Jaguar XF (X260)	AAM - Audio Amplifier Module	DATA
LX63-14C527-GBA.vbf	Jaguar XF (X260)	AAM - Audio Amplifier Module	DATA
LX63-14C527-GCA.vbf	Jaguar XF (X260)	AAM - Audio Amplifier Module	DATA
LX63-14C527-GDA.vbf	Jaguar XF (X260)	AAM - Audio Amplifier Module	DATA
LX63-14C527-GEA.vbf	Jaguar XF (X260)	AAM - Audio Amplifier Module	DATA
LX63-14C527-GFA.vbf	Jaguar XF (X260)	AAM - Audio Amplifier Module	DATA
LX63-14C527-GGA.vbf	Jaguar XF (X260)	AAM - Audio Amplifier Module	DATA
LX63-14C570-BGA.vbf	Jaguar XF (X260)	PCM - Powertrain Control Module	EXE
LX63-14C570-BGD.vbf	Jaguar XF (X260)	PCM - Powertrain Control Module	EXE
LX63-14C570-BLA.vbf	Jaguar XF (X260)	PCM - Powertrain Control Module	EXE
LX63-14C570-BLD.vbf	Jaguar XF (X260)	PCM - Powertrain Control Module	EXE
LX63-14C570-BNA.vbf	Jaguar XF (X260)	PCM - Powertrain Control Module	EXE
LX63-14C570-BND.vbf	Jaguar XF (X260)	PCM - Powertrain Control Module	EXE

File name	Vehicle line (indicative)	Module (ECU)	Type
LX63-14C570-BPA.vbf	Jaguar XF (X260)	PCM - Powertrain Control Module	EXE
LX63-14C570-BPB.vbf	Jaguar XF (X260)	PCM - Powertrain Control Module	EXE
LX63-14C570-BPE.vbf	Jaguar XF (X260)	PCM - Powertrain Control Module	EXE
LX63-14C570-BRA.vbf	Jaguar XF (X260)	PCM - Powertrain Control Module	EXE
LX63-14C570-BRB.vbf	Jaguar XF (X260)	PCM - Powertrain Control Module	EXE
LX63-14C570-BRE.vbf	Jaguar XF (X260)	PCM - Powertrain Control Module	EXE
LX63-14C570-BUA.vbf	Jaguar XF (X260)	PCM - Powertrain Control Module	EXE
LX63-14C570-BUD.vbf	Jaguar XF (X260)	PCM - Powertrain Control Module	EXE
LX63-14F397-AA.vbf	Jaguar XF (X260)	IPMA - Image Processing Module A	EXE
LX63-14F397-BA.vbf	Jaguar XF (X260)	IPMA - Image Processing Module A	EXE
LX63-14F397-CA.vbf	Jaguar XF (X260)	IPMA - Image Processing Module A	EXE
LX63-14F397-DA.vbf	Jaguar XF (X260)	IPMA - Image Processing Module A	EXE
LX63-14F398-AA.vbf	Jaguar XF (X260)	IPMA - Image Processing Module A	EXE
LX63-14F398-BA.vbf	Jaguar XF (X260)	IPMA - Image Processing Module A	EXE
LX73-12K532-FCA.vbf	Jaguar XE (X760)	PCM - Powertrain Control Module	EXE
LX73-12K532-FCB.vbf	Jaguar XE (X760)	PCM - Powertrain Control Module	EXE
LX73-12K532-FCC.vbf	Jaguar XE (X760)	PCM - Powertrain Control Module	EXE
LX73-12K532-FDA.vbf	Jaguar XE (X760)	PCM - Powertrain Control Module	EXE
LX73-12K532-FDB.vbf	Jaguar XE (X760)	PCM - Powertrain Control Module	EXE
LX73-12K532-FDC.vbf	Jaguar XE (X760)	PCM - Powertrain Control Module	EXE
LX73-12K532-FHB.vbf	Jaguar XE (X760)	PCM - Powertrain Control Module	EXE
LX73-12K532-FJB.vbf	Jaguar XE (X760)	PCM - Powertrain Control Module	EXE
LX73-12K532-FKB.vbf	Jaguar XE (X760)	PCM - Powertrain Control Module	EXE
LX73-12K532-FNB.vbf	Jaguar XE (X760)	PCM - Powertrain Control Module	EXE
LX73-12K532-FPB.vbf	Jaguar XE (X760)	PCM - Powertrain Control Module	EXE
LX73-12K532-FTB.vbf	Jaguar XE (X760)	PCM - Powertrain Control Module	EXE
LX73-14C025-AA.vbf	Jaguar XE (X760)	IPC - Instrument Panel Cluster (IPC) Control Module	SBL
LX73-14C025-XA.vbf	Jaguar XE (X760)	IPC - Instrument Panel Cluster (IPC) Control Module	SBL
LX73-14C026-AA.vbf	Jaguar XE (X760)	IPC - Instrument Panel Cluster (IPC) Control Module	EXE
LX73-14C026-AB.vbf	Jaguar XE (X760)	IPC - Instrument Panel Cluster (IPC) Control Module	EXE
LX73-14C026-AC.vbf	Jaguar XE (X760)	IPC - Instrument Panel Cluster (IPC) Control Module	EXE
LX73-14C026-AE.vbf	Jaguar XE (X760)	IPC - Instrument Panel Cluster (IPC) Control Module	EXE
LX73-14C026-AF.vbf	Jaguar XE (X760)	IPC - Instrument Panel Cluster (IPC) Control Module	EXE
LX73-14C026-AG.vbf	Jaguar XE (X760)	IPC - Instrument Panel Cluster (IPC) Control Module	EXE
LX73-14C026-JA.vbf	Jaguar XE (X760)	IPC - Instrument Panel Cluster (IPC) Control Module	EXE
LX73-14C026-JB.vbf	Jaguar XE (X760)	IPC - Instrument Panel Cluster (IPC) Control Module	EXE
LX73-14C026-JC.vbf	Jaguar XE (X760)	IPC - Instrument Panel Cluster (IPC) Control Module	EXE
LX73-14C026-JD.vbf	Jaguar XE (X760)	IPC - Instrument Panel Cluster (IPC) Control Module	EXE
LX73-14C026-KA.vbf	Jaguar XE (X760)	IPC - Instrument Panel Cluster (IPC) Control Module	EXE
LX73-14C026-KB.vbf	Jaguar XE (X760)	IPC - Instrument Panel Cluster (IPC) Control Module	EXE
LX73-14C026-KC.vbf	Jaguar XE (X760)	IPC - Instrument Panel Cluster (IPC) Control Module	EXE
LX73-14C026-XA.vbf	Jaguar XE (X760)	IPC - Instrument Panel Cluster (IPC) Control Module	EXE
LX73-14C028-AA.vbf	Jaguar XE (X760)	RCM - Restraints Control Module	EXE
LX73-14C034-AA.vbf	Jaguar XE (X760)	DSM - Driver Front Seat Module	EXE
LX73-14C034-BA.vbf	Jaguar XE (X760)	DSM - Driver Front Seat Module	EXE
LX73-14C036-AD.vbf	Jaguar XE (X760)	ABS - Anti-Lock Brake System Control Module	EXE
LX73-14C036-AE.vbf	Jaguar XE (X760)	ABS - Anti-Lock Brake System Control Module	EXE
LX73-14C036-BD.vbf	Jaguar XE (X760)	ABS - Anti-Lock Brake System Control Module	EXE
LX73-14C036-BE.vbf	Jaguar XE (X760)	ABS - Anti-Lock Brake System Control Module	EXE
LX73-14C037-ABD.vbf	Jaguar XE (X760)	ABS - Anti-Lock Brake System Control Module	DATA
LX73-14C037-ABE.vbf	Jaguar XE (X760)	ABS - Anti-Lock Brake System Control Module	DATA
LX73-14C037-ACD.vbf	Jaguar XE (X760)	ABS - Anti-Lock Brake System Control Module	DATA
LX73-14C037-ACE.vbf	Jaguar XE (X760)	ABS - Anti-Lock Brake System Control Module	DATA
LX73-14C037-ADD.vbf	Jaguar XE (X760)	ABS - Anti-Lock Brake System Control Module	DATA
LX73-14C037-ADE.vbf	Jaguar XE (X760)	ABS - Anti-Lock Brake System Control Module	DATA
LX73-14C037-AFD.vbf	Jaguar XE (X760)	ABS - Anti-Lock Brake System Control Module	DATA
LX73-14C037-AFE.vbf	Jaguar XE (X760)	ABS - Anti-Lock Brake System Control Module	DATA
LX73-14C037-AGD.vbf	Jaguar XE (X760)	ABS - Anti-Lock Brake System Control Module	DATA
LX73-14C037-AGE.vbf	Jaguar XE (X760)	ABS - Anti-Lock Brake System Control Module	DATA
LX73-14C037-AHD.vbf	Jaguar XE (X760)	ABS - Anti-Lock Brake System Control Module	DATA
LX73-14C037-AHE.vbf	Jaguar XE (X760)	ABS - Anti-Lock Brake System Control Module	DATA
LX73-14C037-AJD.vbf	Jaguar XE (X760)	ABS - Anti-Lock Brake System Control Module	DATA
LX73-14C037-AJE.vbf	Jaguar XE (X760)	ABS - Anti-Lock Brake System Control Module	DATA
LX73-14C037-AKD.vbf	Jaguar XE (X760)	ABS - Anti-Lock Brake System Control Module	DATA
LX73-14C037-AKE.vbf	Jaguar XE (X760)	ABS - Anti-Lock Brake System Control Module	DATA
LX73-14C037-ALD.vbf	Jaguar XE (X760)	ABS - Anti-Lock Brake System Control Module	DATA
LX73-14C037-ALE.vbf	Jaguar XE (X760)	ABS - Anti-Lock Brake System Control Module	DATA
LX73-14C037-AMD.vbf	Jaguar XE (X760)	ABS - Anti-Lock Brake System Control Module	DATA
LX73-14C037-AME.vbf	Jaguar XE (X760)	ABS - Anti-Lock Brake System Control Module	DATA
LX73-14C037-AND.vbf	Jaguar XE (X760)	ABS - Anti-Lock Brake System Control Module	DATA
LX73-14C037-ANE.vbf	Jaguar XE (X760)	ABS - Anti-Lock Brake System Control Module	DATA
LX73-14C037-ASD.vbf	Jaguar XE (X760)	ABS - Anti-Lock Brake System Control Module	DATA
LX73-14C037-ASE.vbf	Jaguar XE (X760)	ABS - Anti-Lock Brake System Control Module	DATA
LX73-14C037-ATD.vbf	Jaguar XE (X760)	ABS - Anti-Lock Brake System Control Module	DATA
LX73-14C037-ATE.vbf	Jaguar XE (X760)	ABS - Anti-Lock Brake System Control Module	DATA
LX73-14C037-AUD.vbf	Jaguar XE (X760)	ABS - Anti-Lock Brake System Control Module	DATA

File name	Vehicle line (indicative)	Module (ECU)	Type
LX73-14C037-AUE.vbf	Jaguar XE (X760)	ABS - Anti-Lock Brake System Control Module	DATA
LX73-14C037-AVD.vbf	Jaguar XE (X760)	ABS - Anti-Lock Brake System Control Module	DATA
LX73-14C037-AVE.vbf	Jaguar XE (X760)	ABS - Anti-Lock Brake System Control Module	DATA
LX73-14C037-AXD.vbf	Jaguar XE (X760)	ABS - Anti-Lock Brake System Control Module	DATA
LX73-14C037-AXE.vbf	Jaguar XE (X760)	ABS - Anti-Lock Brake System Control Module	DATA
LX73-14C037-AYD.vbf	Jaguar XE (X760)	ABS - Anti-Lock Brake System Control Module	DATA
LX73-14C037-AYE.vbf	Jaguar XE (X760)	ABS - Anti-Lock Brake System Control Module	DATA
LX73-14C037-AZD.vbf	Jaguar XE (X760)	ABS - Anti-Lock Brake System Control Module	DATA
LX73-14C037-AZE.vbf	Jaguar XE (X760)	ABS - Anti-Lock Brake System Control Module	DATA
LX73-14C037-BAD.vbf	Jaguar XE (X760)	ABS - Anti-Lock Brake System Control Module	DATA
LX73-14C037-BAE.vbf	Jaguar XE (X760)	ABS - Anti-Lock Brake System Control Module	DATA
LX73-14C037-BBD.vbf	Jaguar XE (X760)	ABS - Anti-Lock Brake System Control Module	DATA
LX73-14C037-BBE.vbf	Jaguar XE (X760)	ABS - Anti-Lock Brake System Control Module	DATA
LX73-14C037-BDD.vbf	Jaguar XE (X760)	ABS - Anti-Lock Brake System Control Module	DATA
LX73-14C037-BDE.vbf	Jaguar XE (X760)	ABS - Anti-Lock Brake System Control Module	DATA
LX73-14C037-BFD.vbf	Jaguar XE (X760)	ABS - Anti-Lock Brake System Control Module	DATA
LX73-14C037-BFE.vbf	Jaguar XE (X760)	ABS - Anti-Lock Brake System Control Module	DATA
LX73-14C037-BFF.vbf	Jaguar XE (X760)	ABS - Anti-Lock Brake System Control Module	DATA
LX73-14C037-BGD.vbf	Jaguar XE (X760)	ABS - Anti-Lock Brake System Control Module	DATA
LX73-14C037-BGE.vbf	Jaguar XE (X760)	ABS - Anti-Lock Brake System Control Module	DATA
LX73-14C037-BGF.vbf	Jaguar XE (X760)	ABS - Anti-Lock Brake System Control Module	DATA
LX73-14C037-BHD.vbf	Jaguar XE (X760)	ABS - Anti-Lock Brake System Control Module	DATA
LX73-14C037-BHE.vbf	Jaguar XE (X760)	ABS - Anti-Lock Brake System Control Module	DATA
LX73-14C037-BJD.vbf	Jaguar XE (X760)	ABS - Anti-Lock Brake System Control Module	DATA
LX73-14C037-BJE.vbf	Jaguar XE (X760)	ABS - Anti-Lock Brake System Control Module	DATA
LX73-14C037-BKD.vbf	Jaguar XE (X760)	ABS - Anti-Lock Brake System Control Module	DATA
LX73-14C037-BKE.vbf	Jaguar XE (X760)	ABS - Anti-Lock Brake System Control Module	DATA
LX73-14C037-BKF.vbf	Jaguar XE (X760)	ABS - Anti-Lock Brake System Control Module	DATA
LX73-14C037-BLD.vbf	Jaguar XE (X760)	ABS - Anti-Lock Brake System Control Module	DATA
LX73-14C037-BLE.vbf	Jaguar XE (X760)	ABS - Anti-Lock Brake System Control Module	DATA
LX73-14C037-BLF.vbf	Jaguar XE (X760)	ABS - Anti-Lock Brake System Control Module	DATA
LX73-14C037-BMD.vbf	Jaguar XE (X760)	ABS - Anti-Lock Brake System Control Module	DATA
LX73-14C037-BME.vbf	Jaguar XE (X760)	ABS - Anti-Lock Brake System Control Module	DATA
LX73-14C037-BMF.vbf	Jaguar XE (X760)	ABS - Anti-Lock Brake System Control Module	DATA
LX73-14C037-MBD.vbf	Jaguar XE (X760)	ABS - Anti-Lock Brake System Control Module	DATA
LX73-14C037-MBE.vbf	Jaguar XE (X760)	ABS - Anti-Lock Brake System Control Module	DATA
LX73-14C037-MCD.vbf	Jaguar XE (X760)	ABS - Anti-Lock Brake System Control Module	DATA
LX73-14C037-MCE.vbf	Jaguar XE (X760)	ABS - Anti-Lock Brake System Control Module	DATA
LX73-14C037-MDD.vbf	Jaguar XE (X760)	ABS - Anti-Lock Brake System Control Module	DATA
LX73-14C037-MDE.vbf	Jaguar XE (X760)	ABS - Anti-Lock Brake System Control Module	DATA
LX73-14C037-MJD.vbf	Jaguar XE (X760)	ABS - Anti-Lock Brake System Control Module	DATA
LX73-14C037-MJE.vbf	Jaguar XE (X760)	ABS - Anti-Lock Brake System Control Module	DATA
LX73-14C037-MMD.vbf	Jaguar XE (X760)	ABS - Anti-Lock Brake System Control Module	DATA
LX73-14C037-MME.vbf	Jaguar XE (X760)	ABS - Anti-Lock Brake System Control Module	DATA
LX73-14C037-MND.vbf	Jaguar XE (X760)	ABS - Anti-Lock Brake System Control Module	DATA
LX73-14C037-MNE.vbf	Jaguar XE (X760)	ABS - Anti-Lock Brake System Control Module	DATA
LX73-14C037-MSD.vbf	Jaguar XE (X760)	ABS - Anti-Lock Brake System Control Module	DATA
LX73-14C037-MSE.vbf	Jaguar XE (X760)	ABS - Anti-Lock Brake System Control Module	DATA
LX73-14C037-MTD.vbf	Jaguar XE (X760)	ABS - Anti-Lock Brake System Control Module	DATA
LX73-14C037-MTE.vbf	Jaguar XE (X760)	ABS - Anti-Lock Brake System Control Module	DATA
LX73-14C037-MUD.vbf	Jaguar XE (X760)	ABS - Anti-Lock Brake System Control Module	DATA
LX73-14C037-MUE.vbf	Jaguar XE (X760)	ABS - Anti-Lock Brake System Control Module	DATA
LX73-14C037-MVD.vbf	Jaguar XE (X760)	ABS - Anti-Lock Brake System Control Module	DATA
LX73-14C037-MVE.vbf	Jaguar XE (X760)	ABS - Anti-Lock Brake System Control Module	DATA
LX73-14C037-MXD.vbf	Jaguar XE (X760)	ABS - Anti-Lock Brake System Control Module	DATA
LX73-14C037-MXE.vbf	Jaguar XE (X760)	ABS - Anti-Lock Brake System Control Module	DATA
LX73-14C037-MYD.vbf	Jaguar XE (X760)	ABS - Anti-Lock Brake System Control Module	DATA
LX73-14C037-MYE.vbf	Jaguar XE (X760)	ABS - Anti-Lock Brake System Control Module	DATA
LX73-14C037-MZD.vbf	Jaguar XE (X760)	ABS - Anti-Lock Brake System Control Module	DATA
LX73-14C037-MZE.vbf	Jaguar XE (X760)	ABS - Anti-Lock Brake System Control Module	DATA
LX73-14C037-NAD.vbf	Jaguar XE (X760)	ABS - Anti-Lock Brake System Control Module	DATA
LX73-14C037-NAE.vbf	Jaguar XE (X760)	ABS - Anti-Lock Brake System Control Module	DATA
LX73-14C037-NBD.vbf	Jaguar XE (X760)	ABS - Anti-Lock Brake System Control Module	DATA
LX73-14C037-NBE.vbf	Jaguar XE (X760)	ABS - Anti-Lock Brake System Control Module	DATA
LX73-14C037-NDD.vbf	Jaguar XE (X760)	ABS - Anti-Lock Brake System Control Module	DATA
LX73-14C037-NDE.vbf	Jaguar XE (X760)	ABS - Anti-Lock Brake System Control Module	DATA
LX73-14C037-NFD.vbf	Jaguar XE (X760)	ABS - Anti-Lock Brake System Control Module	DATA
LX73-14C037-NFE.vbf	Jaguar XE (X760)	ABS - Anti-Lock Brake System Control Module	DATA
LX73-14C037-NFF.vbf	Jaguar XE (X760)	ABS - Anti-Lock Brake System Control Module	DATA
LX73-14C037-NGD.vbf	Jaguar XE (X760)	ABS - Anti-Lock Brake System Control Module	DATA
LX73-14C037-NGE.vbf	Jaguar XE (X760)	ABS - Anti-Lock Brake System Control Module	DATA
LX73-14C037-NGF.vbf	Jaguar XE (X760)	ABS - Anti-Lock Brake System Control Module	DATA
LX73-14C037-NHD.vbf	Jaguar XE (X760)	ABS - Anti-Lock Brake System Control Module	DATA
LX73-14C037-NHE.vbf	Jaguar XE (X760)	ABS - Anti-Lock Brake System Control Module	DATA
LX73-14C037-NJD.vbf	Jaguar XE (X760)	ABS - Anti-Lock Brake System Control Module	DATA
LX73-14C037-NJE.vbf	Jaguar XE (X760)	ABS - Anti-Lock Brake System Control Module	DATA

File name	Vehicle line (indicative)	Module (ECU)	Type
LX73-14C037-NKD.vbf	Jaguar XE (X760)	ABS - Anti-Lock Brake System Control Module	DATA
LX73-14C037-NKE.vbf	Jaguar XE (X760)	ABS - Anti-Lock Brake System Control Module	DATA
LX73-14C037-NKF.vbf	Jaguar XE (X760)	ABS - Anti-Lock Brake System Control Module	DATA
LX73-14C037-NLD.vbf	Jaguar XE (X760)	ABS - Anti-Lock Brake System Control Module	DATA
LX73-14C037-NLE.vbf	Jaguar XE (X760)	ABS - Anti-Lock Brake System Control Module	DATA
LX73-14C037-NLF.vbf	Jaguar XE (X760)	ABS - Anti-Lock Brake System Control Module	DATA
LX73-14C037-NMD.vbf	Jaguar XE (X760)	ABS - Anti-Lock Brake System Control Module	DATA
LX73-14C037-NME.vbf	Jaguar XE (X760)	ABS - Anti-Lock Brake System Control Module	DATA
LX73-14C037-NMF.vbf	Jaguar XE (X760)	ABS - Anti-Lock Brake System Control Module	DATA
LX73-14C039-AA.vbf	Jaguar XE (X760)	ABS - Anti-Lock Brake System Control Module	SBL
LX73-14C064-AA.vbf	Jaguar XE (X760)	DDM - Driver Front Door Module	EXE
LX73-14C064-AB.vbf	Jaguar XE (X760)	DDM - Driver Front Door Module	EXE
LX73-14C064-AC.vbf	Jaguar XE (X760)	DDM - Driver Front Door Module	EXE
LX73-14C064-AD.vbf	Jaguar XE (X760)	DDM - Driver Front Door Module	EXE
LX73-14C065-AC.vbf	Jaguar XE (X760)	DDM - Driver Front Door Module	DATA
LX73-14C065-AD.vbf	Jaguar XE (X760)	DDM - Driver Front Door Module	DATA
LX73-14C065-AE.vbf	Jaguar XE (X760)	DDM - Driver Front Door Module	DATA
LX73-14C065-AF.vbf	Jaguar XE (X760)	DDM - Driver Front Door Module	DATA
LX73-14C068-AA.vbf	Jaguar XE (X760)	DRDM - Driver Rear Door Module	EXE
LX73-14C068-AB.vbf	Jaguar XE (X760)	DRDM - Driver Rear Door Module	EXE
LX73-14C068-AC.vbf	Jaguar XE (X760)	DRDM - Driver Rear Door Module	EXE
LX73-14C068-AD.vbf	Jaguar XE (X760)	DRDM - Driver Rear Door Module	EXE
LX73-14C069-AC.vbf	Jaguar XE (X760)	DRDM - Driver Rear Door Module	DATA
LX73-14C069-AD.vbf	Jaguar XE (X760)	DRDM - Driver Rear Door Module	DATA
LX73-14C069-AE.vbf	Jaguar XE (X760)	DRDM - Driver Rear Door Module	DATA
LX73-14C069-AF.vbf	Jaguar XE (X760)	DRDM - Driver Rear Door Module	DATA
LX73-14C085-AA.vbf	Jaguar XE (X760)	HCM - Headlamp Control Module #1	DATA
LX73-14C085-AB.vbf	Jaguar XE (X760)	HCM - Headlamp Control Module #1	DATA
LX73-14C085-AC.vbf	Jaguar XE (X760)	HCM - Headlamp Control Module #1	DATA
LX73-14C085-AD.vbf	Jaguar XE (X760)	HCM - Headlamp Control Module #1	DATA
LX73-14C085-BA.vbf	Jaguar XE (X760)	Not specified	DATA
LX73-14C085-BB.vbf	Jaguar XE (X760)	Not specified	DATA
LX73-14C085-BC.vbf	Jaguar XE (X760)	Not specified	DATA
LX73-14C085-BD.vbf	Jaguar XE (X760)	Not specified	DATA
LX73-14C088-BC.vbf	Jaguar XE (X760)	IPC - Instrument Panel Cluster (IPC) Control Module	EXE
LX73-14C088-BE.vbf	Jaguar XE (X760)	IPC - Instrument Panel Cluster (IPC) Control Module	EXE
LX73-14C088-CA.vbf	Jaguar XE (X760)	IPC - Instrument Panel Cluster (IPC) Control Module	EXE
LX73-14C088-CB.vbf	Jaguar XE (X760)	IPC - Instrument Panel Cluster (IPC) Control Module	EXE
LX73-14C088-CC.vbf	Jaguar XE (X760)	IPC - Instrument Panel Cluster (IPC) Control Module	EXE
LX73-14C088-CD.vbf	Jaguar XE (X760)	IPC - Instrument Panel Cluster (IPC) Control Module	EXE
LX73-14C088-CE.vbf	Jaguar XE (X760)	IPC - Instrument Panel Cluster (IPC) Control Module	EXE
LX73-14C088-DB.vbf	Jaguar XE (X760)	IPC - Instrument Panel Cluster (IPC) Control Module	EXE
LX73-14C088-EB.vbf	Jaguar XE (X760)	IPC - Instrument Panel Cluster (IPC) Control Module	EXE
LX73-14C088-EC.vbf	Jaguar XE (X760)	IPC - Instrument Panel Cluster (IPC) Control Module	EXE
LX73-14C088-FB.vbf	Jaguar XE (X760)	IPC - Instrument Panel Cluster (IPC) Control Module	EXE
LX73-14C088-FC.vbf	Jaguar XE (X760)	IPC - Instrument Panel Cluster (IPC) Control Module	EXE
LX73-14C088-GA.vbf	Jaguar XE (X760)	IPC - Instrument Panel Cluster (IPC) Control Module	EXE
LX73-14C088-GB.vbf	Jaguar XE (X760)	IPC - Instrument Panel Cluster (IPC) Control Module	EXE
LX73-14C088-JA.vbf	Jaguar XE (X760)	IPC - Instrument Panel Cluster (IPC) Control Module	DATA
LX73-14C088-JB.vbf	Jaguar XE (X760)	IPC - Instrument Panel Cluster (IPC) Control Module	DATA
LX73-14C088-JC.vbf	Jaguar XE (X760)	IPC - Instrument Panel Cluster (IPC) Control Module	DATA
LX73-14C088-JE.vbf	Jaguar XE (X760)	IPC - Instrument Panel Cluster (IPC) Control Module	DATA
LX73-14C088-JF.vbf	Jaguar XE (X760)	IPC - Instrument Panel Cluster (IPC) Control Module	DATA
LX73-14C091-AA.vbf	Jaguar XE (X760)	PAM - Parking Assist Control Module	DATA
LX73-14C091-AB.vbf	Jaguar XE (X760)	PAM - Parking Assist Control Module	DATA
LX73-14C091-AC.vbf	Jaguar XE (X760)	PAM - Parking Assist Control Module	DATA
LX73-14C098-AB.vbf	Jaguar XE (X760)	RCM - Restraints Control Module	DATA
LX73-14C098-AC.vbf	Jaguar XE (X760)	RCM - Restraints Control Module	DATA
LX73-14C098-AD.vbf	Jaguar XE (X760)	RCM - Restraints Control Module	DATA
LX73-14C098-AE.vbf	Jaguar XE (X760)	RCM - Restraints Control Module	DATA
LX73-14C098-BA.vbf	Jaguar XE (X760)	RCM - Restraints Control Module	DATA
LX73-14C098-BB.vbf	Jaguar XE (X760)	RCM - Restraints Control Module	DATA
LX73-14C098-BC.vbf	Jaguar XE (X760)	RCM - Restraints Control Module	DATA
LX73-14C098-CA.vbf	Jaguar XE (X760)	RCM - Restraints Control Module	DATA
LX73-14C098-CB.vbf	Jaguar XE (X760)	RCM - Restraints Control Module	DATA
LX73-14C105-AA.vbf	Jaguar XE (X760)	TMC Traffic Message Channel Module	EXE
LX73-14C105-BA.vbf	Jaguar XE (X760)	TMC Traffic Message Channel Module	EXE
LX73-14C108-AA.vbf	Jaguar XE (X760)	PDM - Passenger Front Door Module	EXE
LX73-14C108-AB.vbf	Jaguar XE (X760)	PDM - Passenger Front Door Module	EXE
LX73-14C108-AC.vbf	Jaguar XE (X760)	PDM - Passenger Front Door Module	EXE
LX73-14C108-AD.vbf	Jaguar XE (X760)	PDM - Passenger Front Door Module	EXE
LX73-14C109-AC.vbf	Jaguar XE (X760)	PDM - Passenger Front Door Module	DATA
LX73-14C109-AD.vbf	Jaguar XE (X760)	PDM - Passenger Front Door Module	DATA
LX73-14C109-AE.vbf	Jaguar XE (X760)	PDM - Passenger Front Door Module	DATA
LX73-14C109-AF.vbf	Jaguar XE (X760)	PDM - Passenger Front Door Module	DATA
LX73-14C112-AA.vbf	Jaguar XE (X760)	PRDM - Passenger Rear Door Module	EXE

File name	Vehicle line (indicative)	Module (ECU)	Type
LX73-14C112-AB.vbf	Jaguar XE (X760)	PRDM - Passenger Rear Door Module	EXE
LX73-14C112-AC.vbf	Jaguar XE (X760)	PRDM - Passenger Rear Door Module	EXE
LX73-14C112-AD.vbf	Jaguar XE (X760)	PRDM - Passenger Rear Door Module	EXE
LX73-14C113-AC.vbf	Jaguar XE (X760)	PRDM - Passenger Rear Door Module	DATA
LX73-14C113-AD.vbf	Jaguar XE (X760)	PRDM - Passenger Rear Door Module	DATA
LX73-14C113-AE.vbf	Jaguar XE (X760)	PRDM - Passenger Rear Door Module	DATA
LX73-14C113-AF.vbf	Jaguar XE (X760)	PRDM - Passenger Rear Door Module	DATA
LX73-14C185-AA.vbf	Jaguar XE (X760)	BCM - Body Control Module	DATA
LX73-14C185-AB.VBF	Jaguar XE (X760)	BCM - Body Control Module	DATA
LX73-14C185-AC.vbf	Jaguar XE (X760)	BCM - Body Control Module	DATA
LX73-14C217-AA.vbf	Jaguar XE (X760)	PSCM - Power Steering Control Module	EXE
LX73-14C218-AA.vbf	Jaguar XE (X760)	PSCM - Power Steering Control Module	DATA
LX73-14C218-BA.vbf	Jaguar XE (X760)	PSCM - Power Steering Control Module	DATA
LX73-14C218-CA.vbf	Jaguar XE (X760)	PSCM - Power Steering Control Module	DATA
LX73-14C218-DA.vbf	Jaguar XE (X760)	PSCM - Power Steering Control Module	DATA
LX73-14C218-EA.vbf	Jaguar XE (X760)	PSCM - Power Steering Control Module	DATA
LX73-14C218-FA.vbf	Jaguar XE (X760)	PSCM - Power Steering Control Module	DATA
LX73-14C218-GA.vbf	Jaguar XE (X760)	PSCM - Power Steering Control Module	DATA
LX73-14C386-AA.vbf	Jaguar XE (X760)	PSCM - Power Steering Control Module	SIGCFG
LX73-14C527-AA.vbf	Jaguar XE (X760)	AAM - Audio Amplifier Module	DATA
LX73-14C527-AAA.vbf	Jaguar XE (X760)	AAM - Audio Amplifier Module	DATA
LX73-14C527-AB.vbf	Jaguar XE (X760)	AAM - Audio Amplifier Module	DATA
LX73-14C527-ABB.vbf	Jaguar XE (X760)	AAM - Audio Amplifier Module	DATA
LX73-14C527-ABC.vbf	Jaguar XE (X760)	AAM - Audio Amplifier Module	DATA
LX73-14C527-ACA.vbf	Jaguar XE (X760)	AAM - Audio Amplifier Module	DATA
LX73-14C527-ADA.vbf	Jaguar XE (X760)	AAM - Audio Amplifier Module	DATA
LX73-14C527-AEA.vbf	Jaguar XE (X760)	AAM - Audio Amplifier Module	DATA
LX73-14C527-AEB.vbf	Jaguar XE (X760)	AAM - Audio Amplifier Module	DATA
LX73-14C527-AFA.vbf	Jaguar XE (X760)	AAM - Audio Amplifier Module	DATA
LX73-14C527-AFB.vbf	Jaguar XE (X760)	AAM - Audio Amplifier Module	DATA
LX73-14C527-BA.vbf	Jaguar XE (X760)	AAM - Audio Amplifier Module	DATA
LX73-14C527-BAA.vbf	Jaguar XE (X760)	AAM - Audio Amplifier Module	DATA
LX73-14C527-BB.vbf	Jaguar XE (X760)	AAM - Audio Amplifier Module	DATA
LX73-14C527-BBB.vbf	Jaguar XE (X760)	AAM - Audio Amplifier Module	DATA
LX73-14C527-BBC.vbf	Jaguar XE (X760)	AAM - Audio Amplifier Module	DATA
LX73-14C527-BCA.vbf	Jaguar XE (X760)	AAM - Audio Amplifier Module	DATA
LX73-14C527-BDA.vbf	Jaguar XE (X760)	AAM - Audio Amplifier Module	DATA
LX73-14C527-BEA.vbf	Jaguar XE (X760)	AAM - Audio Amplifier Module	DATA
LX73-14C527-BEB.vbf	Jaguar XE (X760)	AAM - Audio Amplifier Module	DATA
LX73-14C527-BFA.vbf	Jaguar XE (X760)	AAM - Audio Amplifier Module	DATA
LX73-14C527-BFB.vbf	Jaguar XE (X760)	AAM - Audio Amplifier Module	DATA
LX73-14C527-CA.vbf	Jaguar XE (X760)	AAM - Audio Amplifier Module	DATA
LX73-14C527-CAA.vbf	Jaguar XE (X760)	AAM - Audio Amplifier Module	DATA
LX73-14C527-CB.vbf	Jaguar XE (X760)	AAM - Audio Amplifier Module	DATA
LX73-14C527-CBB.vbf	Jaguar XE (X760)	AAM - Audio Amplifier Module	DATA
LX73-14C527-CBC.vbf	Jaguar XE (X760)	AAM - Audio Amplifier Module	DATA
LX73-14C527-CCA.vbf	Jaguar XE (X760)	AAM - Audio Amplifier Module	DATA
LX73-14C527-CDA.vbf	Jaguar XE (X760)	AAM - Audio Amplifier Module	DATA
LX73-14C527-CEA.vbf	Jaguar XE (X760)	AAM - Audio Amplifier Module	DATA
LX73-14C527-CEB.vbf	Jaguar XE (X760)	AAM - Audio Amplifier Module	DATA
LX73-14C527-CFA.vbf	Jaguar XE (X760)	AAM - Audio Amplifier Module	DATA
LX73-14C527-CFB.vbf	Jaguar XE (X760)	AAM - Audio Amplifier Module	DATA
LX73-14C570-BAA.vbf	Jaguar XE (X760)	PCM - Powertrain Control Module	EXE
LX73-14C570-BAB.vbf	Jaguar XE (X760)	PCM - Powertrain Control Module	EXE
LX73-14C570-BAC.vbf	Jaguar XE (X760)	PCM - Powertrain Control Module	EXE
LX73-14C570-BAD.vbf	Jaguar XE (X760)	PCM - Powertrain Control Module	EXE
LX73-14C570-BAE.vbf	Jaguar XE (X760)	PCM - Powertrain Control Module	EXE
LX73-14C570-BCB.vbf	Jaguar XE (X760)	PCM - Powertrain Control Module	EXE
LX73-14C570-BCC.vbf	Jaguar XE (X760)	PCM - Powertrain Control Module	EXE
LX73-14C570-BCD.vbf	Jaguar XE (X760)	PCM - Powertrain Control Module	EXE
LX73-14C570-BCE.vbf	Jaguar XE (X760)	PCM - Powertrain Control Module	EXE
LX73-14C570-BEA.vbf	Jaguar XE (X760)	PCM - Powertrain Control Module	EXE
LX73-14C570-BEB.vbf	Jaguar XE (X760)	PCM - Powertrain Control Module	EXE
LX73-14C570-BEC.vbf	Jaguar XE (X760)	PCM - Powertrain Control Module	EXE
LX73-14C570-BFA.vbf	Jaguar XE (X760)	PCM - Powertrain Control Module	EXE
LX73-14C570-BFB.vbf	Jaguar XE (X760)	PCM - Powertrain Control Module	EXE
LX73-14C570-BFD.vbf	Jaguar XE (X760)	PCM - Powertrain Control Module	EXE
LX73-14C570-BFE.vbf	Jaguar XE (X760)	PCM - Powertrain Control Module	EXE
LX73-14C570-BFF.vbf	Jaguar XE (X760)	PCM - Powertrain Control Module	EXE
LX73-14C570-BGA.vbf	Jaguar XE (X760)	PCM - Powertrain Control Module	EXE
LX73-14C570-BGB.vbf	Jaguar XE (X760)	PCM - Powertrain Control Module	EXE
LX73-14C570-BGD.vbf	Jaguar XE (X760)	PCM - Powertrain Control Module	EXE
LX73-14C570-BHA.vbf	Jaguar XE (X760)	PCM - Powertrain Control Module	EXE
LX73-14C570-BHB.vbf	Jaguar XE (X760)	PCM - Powertrain Control Module	EXE
LX73-14C570-BHC.vbf	Jaguar XE (X760)	PCM - Powertrain Control Module	EXE
LX73-14C570-BHD.vbf	Jaguar XE (X760)	PCM - Powertrain Control Module	EXE

File name	Vehicle line (indicative)	Module (ECU)	Type
LX73-14C570-BHE.vbf	Jaguar XE (X760)	PCM - Powertrain Control Module	EXE
LX73-14C570-BLB.vbf	Jaguar XE (X760)	PCM - Powertrain Control Module	EXE
LX73-14C570-BLD.vbf	Jaguar XE (X760)	PCM - Powertrain Control Module	EXE
LX73-14C570-BPA.vbf	Jaguar XE (X760)	PCM - Powertrain Control Module	EXE
LX73-14C570-BPB.vbf	Jaguar XE (X760)	PCM - Powertrain Control Module	EXE
LX73-14C570-BPD.vbf	Jaguar XE (X760)	PCM - Powertrain Control Module	EXE
LX73-14C570-BPE.vbf	Jaguar XE (X760)	PCM - Powertrain Control Module	EXE
LX73-14C570-BPF.vbf	Jaguar XE (X760)	PCM - Powertrain Control Module	EXE
LX73-14C570-BRA.vbf	Jaguar XE (X760)	PCM - Powertrain Control Module	EXE
LX73-14C570-BRB.vbf	Jaguar XE (X760)	PCM - Powertrain Control Module	EXE
LX73-14C570-BRC.vbf	Jaguar XE (X760)	PCM - Powertrain Control Module	EXE
LX73-14C570-BRD.vbf	Jaguar XE (X760)	PCM - Powertrain Control Module	EXE
LX73-14C570-BRE.vbf	Jaguar XE (X760)	PCM - Powertrain Control Module	EXE
LX73-14C570-BTB.vbf	Jaguar XE (X760)	PCM - Powertrain Control Module	EXE
LX73-14C570-BTC.vbf	Jaguar XE (X760)	PCM - Powertrain Control Module	EXE
LX73-14C570-BTD.vbf	Jaguar XE (X760)	PCM - Powertrain Control Module	EXE
LX73-14C570-BTE.vbf	Jaguar XE (X760)	PCM - Powertrain Control Module	EXE
LX73-14C570-BUA.vbf	Jaguar XE (X760)	PCM - Powertrain Control Module	EXE
LX73-14C570-BUB.vbf	Jaguar XE (X760)	PCM - Powertrain Control Module	EXE
LX73-14C570-BUD.vbf	Jaguar XE (X760)	PCM - Powertrain Control Module	EXE
LX73-14C609-AA.vbf	Jaguar XE (X760)	PSCM - Power Steering Control Module	DATA
LX73-14C609-BA.vbf	Jaguar XE (X760)	PSCM - Power Steering Control Module	DATA
LX73-14D024-AB.vbf	Jaguar XE (X760)	ATCM - All Terrain Control Module	EXE
LX73-14D026-AA.vbf	Jaguar XE (X760)	ATCM - All Terrain Control Module	SBL
LX73-14D049-AB.vbf	Jaguar XE (X760)	CCM - Cruise Control Module	EXE
LX73-14D049-AC.vbf	Jaguar XE (X760)	CCM - Cruise Control Module	EXE
LX73-14D049-AD.vbf	Jaguar XE (X760)	CCM - Cruise Control Module	EXE
LX73-14D051-AA.vbf	Jaguar XE (X760)	CCM - Cruise Control Module	SBL
LX73-14D183-AA.vbf	Jaguar XE (X760)	OCS - Restraints Occupant Classification System Module	DATA
LX73-14D368-AA.vbf	Jaguar XE (X760)	SODR - Side Obstacle Detection Control Module - Right	EXE
LX73-14D368-AB.vbf	Jaguar XE (X760)	SODR - Side Obstacle Detection Control Module - Right	EXE
LX73-14D368-AC.vbf	Jaguar XE (X760)	SODR - Side Obstacle Detection Control Module - Right	EXE
LX73-14D368-AD.vbf	Jaguar XE (X760)	SODR - Side Obstacle Detection Control Module - Right	EXE
LX73-14D368-AE.vbf	Jaguar XE (X760)	SODR - Side Obstacle Detection Control Module - Right	EXE
LX73-14D368-BA.vbf	Jaguar XE (X760)	SODR - Side Obstacle Detection Control Module - Right	EXE
LX73-14D485-AA.vbf	Jaguar XE (X760)	IPMB - Image Processing Module B	EXE
LX73-14D564-AA.vbf	Jaguar XE (X760)	SODR - Side Obstacle Detection Control Module - Right	DATA
LX73-14D564-AB.vbf	Jaguar XE (X760)	SODR - Side Obstacle Detection Control Module - Right	DATA
LX73-14D564-AC.vbf	Jaguar XE (X760)	SODR - Side Obstacle Detection Control Module - Right	DATA
LX73-14D564-AD.vbf	Jaguar XE (X760)	SODR - Side Obstacle Detection Control Module - Right	DATA
LX73-14D564-AE.vbf	Jaguar XE (X760)	SODR - Side Obstacle Detection Control Module - Right	DATA
LX73-14D564-BA.vbf	Jaguar XE (X760)	SODR - Side Obstacle Detection Control Module - Right	DATA
LX73-14E282-AA.vbf	Jaguar XE (X760)	WDCM - WirelessCharger	EXE
LX73-14E282-AB.vbf	Jaguar XE (X760)	WDCM - WirelessCharger	EXE
LX73-14E284-AB.vbf	Jaguar XE (X760)	WDCM - WirelessCharger	SBL
LX73-14F022-AA.vbf	Jaguar XE (X760)	IPMB - Image Processing Module B	DATA
LX73-14F230-AB.vbf	Jaguar XE (X760)	HUD - Head Up Display	EXE
LX73-14F230-AC.vbf	Jaguar XE (X760)	HUD - Head Up Display	EXE
LX73-14F231-AB.vbf	Jaguar XE (X760)	HUD - Head Up Display	DATA
LX73-14F397-CA.vbf	Jaguar XE (X760)	IPMA - Image Processing Module A	EXE
LX73-14F397-CB.vbf	Jaguar XE (X760)	IPMA - Image Processing Module A	EXE
LX73-14F397-CC.vbf	Jaguar XE (X760)	IPMA - Image Processing Module A	EXE
LX73-14F397-DA.vbf	Jaguar XE (X760)	IPMA - Image Processing Module A	EXE
LX73-14F397-DB.vbf	Jaguar XE (X760)	IPMA - Image Processing Module A	EXE
LX73-14F397-DC.vbf	Jaguar XE (X760)	IPMA - Image Processing Module A	EXE
LX73-14F398-BA.vbf	Jaguar XE (X760)	IPMA - Image Processing Module A	EXE
LX73-14F398-BB.vbf	Jaguar XE (X760)	IPMA - Image Processing Module A	EXE
LX73-14F398-BC.vbf	Jaguar XE (X760)	IPMA - Image Processing Module A	EXE
LX73-14F530-CA.vbf	Jaguar XE (X760)	GWM - Gateway Module A	EXE
LX73-14F530-CB.vbf	Jaguar XE (X760)	GWM - Gateway Module A	EXE
LX73-14F530-CC.vbf	Jaguar XE (X760)	GWM - Gateway Module A	EXE
LX73-14F530-DA.vbf	Jaguar XE (X760)	GWM - Gateway Module A	EXE
LX73-14F530-DB.vbf	Jaguar XE (X760)	GWM - Gateway Module A	EXE
LX73-14F530-DC.vbf	Jaguar XE (X760)	GWM - Gateway Module A	EXE
LX73-14F530-DD.vbf	Jaguar XE (X760)	GWM - Gateway Module A	EXE
LX73-14F530-DE.vbf	Jaguar XE (X760)	GWM - Gateway Module A	EXE
LX73-14F531-CA.vbf	Jaguar XE (X760)	GWM - Gateway Module A	DATA
LX73-14F531-CB.vbf	Jaguar XE (X760)	GWM - Gateway Module A	DATA
LX73-14F531-CC.vbf	Jaguar XE (X760)	GWM - Gateway Module A	DATA
LX73-14F531-DA.vbf	Jaguar XE (X760)	GWM - Gateway Module A	DATA
LX73-14F531-DB.vbf	Jaguar XE (X760)	GWM - Gateway Module A	DATA
LX73-14F531-DC.vbf	Jaguar XE (X760)	GWM - Gateway Module A	DATA
LX73-14F531-DD.vbf	Jaguar XE (X760)	GWM - Gateway Module A	DATA
LX73-14F531-DE.vbf	Jaguar XE (X760)	GWM - Gateway Module A	DATA
LX73-18D619-AA.vbf	Jaguar XE (X760)	HVAC - HVAC Control Module	EXE
LX73-18D620-AA.vbf	Jaguar XE (X760)	HVAC - HVAC Control Module	DATA

File name	Vehicle line (indicative)	Module (ECU)	Type
LX73-18D620-AB.vbf	Jaguar XE (X760)	HVAC - HVAC Control Module	DATA
LX73-18D620-AC.vbf	Jaguar XE (X760)	HVAC - HVAC Control Module	DATA
LX73-18D620-AD.vbf	Jaguar XE (X760)	HVAC - HVAC Control Module	DATA
LX73-18D620-AE.vbf	Jaguar XE (X760)	HVAC - HVAC Control Module	DATA
LX73-18D620-AF.vbf	Jaguar XE (X760)	HVAC - HVAC Control Module	DATA
LX73-18D620-BA.vbf	Jaguar XE (X760)	HVAC - HVAC Control Module	DATA
LX73-18D620-BB.vbf	Jaguar XE (X760)	HVAC - HVAC Control Module	DATA
LX73-18D620-BC.vbf	Jaguar XE (X760)	HVAC - HVAC Control Module	DATA
LX73-18D620-BD.vbf	Jaguar XE (X760)	HVAC - HVAC Control Module	DATA
LX73-18D620-BE.vbf	Jaguar XE (X760)	HVAC - HVAC Control Module	DATA
LX73-18D620-BF.vbf	Jaguar XE (X760)	HVAC - HVAC Control Module	DATA
LX73-19C204-AA.vbf	Jaguar XE (X760)	IMC - Infotainment Master Controller	EXE
LX73-19C273-AA.vbf	Jaguar XE (X760)	LPDM - Left Power Sliding Door Module	EXE
LX73-19C273-AB.vbf	Jaguar XE (X760)	LPDM - Left Power Sliding Door Module	EXE
LX73-19C274-BA.vbf	Jaguar XE (X760)	LPDM - Left Power Sliding Door Module	DATA
LX73-7J104-GNA.vbf	Jaguar XE (X760)	TCM - Transmission Control Module	EXE
LX73-7J104-GNB.vbf	Jaguar XE (X760)	TCM - Transmission Control Module	EXE
LX73-7J104-GNC.vbf	Jaguar XE (X760)	TCM - Transmission Control Module	EXE
LX73-7J104-GND.vbf	Jaguar XE (X760)	TCM - Transmission Control Module	EXE
M2H2-19C273-AA.vbf	Not specified	LPDM - Left Power Sliding Door Module	EXE
M2H2-19C274-AA.vbf	Not specified	LPDM - Left Power Sliding Door Module	DATA
M7A3-7J104-CZA.vbf	Jaguar XE (X760)	TCM - Transmission Control Module	EXE
M7A3-7J104-CZB.vbf	Jaguar XE (X760)	TCM - Transmission Control Module	EXE
M7A3-7J104-CZC.vbf	Jaguar XE (X760)	TCM - Transmission Control Module	EXE
M7A3-7J104-CZD.vbf	Jaguar XE (X760)	TCM - Transmission Control Module	EXE
M8A2-12K532-KBA.vbf	Not specified	PCM - Powertrain Control Module	EXE
M8A2-12K532-KBD.vbf	Not specified	PCM - Powertrain Control Module	EXE
M8A2-12K532-KEA.vbf	Not specified	PCM - Powertrain Control Module	EXE
M8A2-12K532-KED.vbf	Not specified	PCM - Powertrain Control Module	EXE
M8A2-12K532-VAA.vbf	Not specified	PCM - Powertrain Control Module	EXE
M8A2-12K532-VAE.vbf	Not specified	PCM - Powertrain Control Module	EXE
M8A2-12K532-VBA.vbf	Not specified	PCM - Powertrain Control Module	EXE
M8A2-12K532-VEE.vbf	Not specified	PCM - Powertrain Control Module	EXE
M8A2-14C026-JA.vbf	Not specified	IPC - Instrument Panel Cluster (IPC) Control Module	EXE
M8A2-14C026-JB.vbf	Not specified	IPC - Instrument Panel Cluster (IPC) Control Module	EXE
M8A2-14C026-KA.vbf	Not specified	IPC - Instrument Panel Cluster (IPC) Control Module	EXE
M8A2-14C026-KB.vbf	Not specified	IPC - Instrument Panel Cluster (IPC) Control Module	EXE
M8A2-14C029-AB.vbf	Not specified	DSM - Driver Front Seat Module	SBL
M8A2-14C088-BA.vbf	Not specified	IPC - Instrument Panel Cluster (IPC) Control Module	EXE
M8A2-14C088-BB.vbf	Not specified	IPC - Instrument Panel Cluster (IPC) Control Module	EXE
M8A2-14C088-DA.vbf	Not specified	IPC - Instrument Panel Cluster (IPC) Control Module	EXE
M8A2-14C088-EA.vbf	Not specified	IPC - Instrument Panel Cluster (IPC) Control Module	EXE
M8A2-14C088-EB.vbf	Not specified	IPC - Instrument Panel Cluster (IPC) Control Module	EXE
M8A2-14C088-FA.vbf	Not specified	IPC - Instrument Panel Cluster (IPC) Control Module	EXE
M8A2-14C088-FB.vbf	Not specified	IPC - Instrument Panel Cluster (IPC) Control Module	EXE
M8A2-14C088-GA.vbf	Not specified	IPC - Instrument Panel Cluster (IPC) Control Module	EXE
M8A2-14C088-GB.vbf	Not specified	IPC - Instrument Panel Cluster (IPC) Control Module	EXE
M8A2-14C217-AB.vbf	Defender (L663)	PSCM - Power Steering Control Module	EXE
M8A2-14C217-BB.vbf	Not specified	PSCM - Power Steering Control Module	EXE
M8A2-14C218-AAB.vbf	Not specified	PSCM - Power Steering Control Module	DATA
M8A2-14C218-AB.vbf	Not specified	PSCM - Power Steering Control Module	DATA
M8A2-14C218-BAB.vbf	Not specified	PSCM - Power Steering Control Module	DATA
M8A2-14C218-BB.vbf	Not specified	PSCM - Power Steering Control Module	DATA
M8A2-14C273-KAA.vbf	Not specified	PCM - Powertrain Control Module	SBL
M8A2-14C273-KAB.vbf	Not specified	PCM - Powertrain Control Module	SBL
M8A2-14C273-VAA.vbf	Not specified	PCM - Powertrain Control Module	SBL
M8A2-14C273-VAB.vbf	Not specified	PCM - Powertrain Control Module	SBL
M8A2-14C561-CA.vbf	Not specified	GSM - Gear Shift Module	EXE
M8A2-14C561-DA.vbf	Not specified	GSM - Gear Shift Module	EXE
M8A2-14C563-DA.vbf	Not specified	GSM - Gear Shift Module	SBL
M8A2-14C570-BAB.vbf	Not specified	PCM - Powertrain Control Module	EXE
M8A2-14C570-BAC.vbf	Not specified	PCM - Powertrain Control Module	EXE
M8A2-14C570-BCA.vbf	Not specified	PCM - Powertrain Control Module	EXE
M8A2-14C570-BFA.vbf	Not specified	PCM - Powertrain Control Module	EXE
M8A2-14C570-BFB.vbf	Not specified	PCM - Powertrain Control Module	EXE
M8A2-14C570-BHA.vbf	Not specified	PCM - Powertrain Control Module	EXE
M8A2-14C570-BHB.vbf	Not specified	PCM - Powertrain Control Module	EXE
M8A2-14C570-BTB.vbf	Not specified	PCM - Powertrain Control Module	EXE
M8A2-14C570-BTC.vbf	Not specified	PCM - Powertrain Control Module	EXE
M8A2-14C570-DNA.vbf	Not specified	PCM - Powertrain Control Module	EXE
M8A2-14C570-DNB.vbf	Not specified	PCM - Powertrain Control Module	EXE
M8A2-14C570-DPB.vbf	Not specified	PCM - Powertrain Control Module	EXE
M8A2-14C570-DPC.vbf	Not specified	PCM - Powertrain Control Module	EXE
M8A2-14C570-DRB.vbf	Not specified	PCM - Powertrain Control Module	EXE
M8A2-14C570-DRC.vbf	Not specified	PCM - Powertrain Control Module	EXE
M8A2-14C570-DUB.vbf	Not specified	PCM - Powertrain Control Module	EXE

File name	Vehicle line (indicative)	Module (ECU)	Type
M8A2-14C570-DUC.vbf	Not specified	PCM - Powertrain Control Module	EXE
M8A2-14C609-AB.vbf	Not specified	PSCM - Power Steering Control Module	DATA
M8A2-14C609-BB.vbf	Not specified	PSCM - Power Steering Control Module	DATA
M8A2-14F397-AC.vbf	Not specified	IPMA - Image Processing Module A	EXE
M8A2-14F397-AD.vbf	Not specified	IPMA - Image Processing Module A	EXE
M8A2-14F397-AF.vbf	Not specified	IPMA - Image Processing Module A	EXE
M8A2-14F397-AG.vbf	Not specified	IPMA - Image Processing Module A	EXE
M8A2-14F397-BC.vbf	Not specified	IPMA - Image Processing Module A	EXE
M8A2-14F397-BD.vbf	Not specified	IPMA - Image Processing Module A	EXE
M8A2-14F397-BF.vbf	Not specified	IPMA - Image Processing Module A	EXE
M8A2-14F397-BG.vbf	Not specified	IPMA - Image Processing Module A	EXE
M8A2-14F531-AB.vbf	Not specified	GWM - Gateway Module A	DATA
M8A2-19J243-AA.vbf	Not specified	NFSM	EXE
M8A2-19J243-AB.vbf	Not specified	NFSM	EXE
M8A2-19J243-AC.vbf	Not specified	NFSM	EXE
M8A2-19J243-BA.vbf	Not specified	NFSM	EXE
M8A2-19J243-BB.vbf	Not specified	NFSM	EXE
M8A2-19J243-BC.vbf	Not specified	NFSM	EXE
M8A2-19J243-CA.vbf	Not specified	NFSM	EXE
M8A2-19J243-CB.vbf	Not specified	NFSM	EXE
M8A2-19J243-CC.vbf	Not specified	NFSM	EXE
M8A2-19J243-DA.vbf	Not specified	NFSM	EXE
M8A2-19J243-DB.vbf	Not specified	NFSM	EXE
M8A2-19J243-DC.vbf	Not specified	NFSM	EXE
M8A2-19J503-AA.vbf	Not specified	NFSM	EXE
M8A2-19J503-AB.vbf	Not specified	NFSM	EXE
M8A2-19J503-BA.vbf	Not specified	NFSM	EXE
M8A2-19J503-BB.vbf	Not specified	NFSM	EXE
M8A2-19J503-CA.vbf	Not specified	NFSM	EXE
M8A2-19J503-CB.vbf	Not specified	NFSM	EXE
M8A2-19J503-DA.vbf	Not specified	NFSM	EXE
M8A2-19J503-DB.vbf	Not specified	NFSM	EXE
M8B2-14C561-AA.vbf	Defender (L663)	GSM - Gear Shift Module	EXE
M8B2-14F531-CA.vbf	Not specified	GWM - Gateway Module A	DATA
M8D2-14C026-AA.vbf	Check in SDD (unconfirmed)	IPC - Instrument Panel Cluster (IPC) Control Module	EXE
M8D2-14C026-AB.vbf	Check in SDD (unconfirmed)	IPC - Instrument Panel Cluster (IPC) Control Module	EXE
M8D2-14C036-AB.vbf	Check in SDD (unconfirmed)	ABS - Anti-Lock Brake System Control Module	EXE
M8D2-14C036-AE.vbf	Check in SDD (unconfirmed)	ABS - Anti-Lock Brake System Control Module	EXE
M8D2-14C088-CA.vbf	Check in SDD (unconfirmed)	IPC - Instrument Panel Cluster (IPC) Control Module	EXE
M8D2-14C088-CB.vbf	Check in SDD (unconfirmed)	IPC - Instrument Panel Cluster (IPC) Control Module	EXE
M8D2-14C088-JA.vbf	Check in SDD (unconfirmed)	IPC - Instrument Panel Cluster (IPC) Control Module	DATA
M8D2-14C088-JB.vbf	Check in SDD (unconfirmed)	IPC - Instrument Panel Cluster (IPC) Control Module	DATA
M8D2-14C197-AA.vbf	Check in SDD (unconfirmed)	BECM - Battery Energy Control Module	EXE
M8D2-14C217-AB.vbf	Range Rover Evoque (L551)	PSCM - Power Steering Control Module	EXE
M8D2-14C218-AAB.vbf	Check in SDD (unconfirmed)	PSCM - Power Steering Control Module	DATA
M8D2-14C218-AB.vbf	Check in SDD (unconfirmed)	PSCM - Power Steering Control Module	DATA
M8D2-14C320-AD.vbf	Check in SDD (unconfirmed)	PDM - Passenger Front Door Module	SIGCFG
M8D2-14C321-AC.vbf	Check in SDD (unconfirmed)	DDM - Driver Front Door Module	SIGCFG
M8D2-14C321-AD.vbf	Check in SDD (unconfirmed)	DDM - Driver Front Door Module	SIGCFG
M8D2-14C339-AB.vbf	Check in SDD (unconfirmed)	TCM - Transmission Control Module	SBL
M8D2-14C386-AA.vbf	Check in SDD (unconfirmed)	PSCM - Power Steering Control Module	DATA
M8D2-14C410-AD.vbf	Check in SDD (unconfirmed)	PRDM - Passenger Rear Door Module	SIGCFG
M8D2-14C435-AD.vbf	Check in SDD (unconfirmed)	DRDM - Driver Rear Door Module	SIGCFG
M8D2-14C570-MPB.vbf	Check in SDD (unconfirmed)	PCM - Powertrain Control Module	EXE
M8D2-14C570-MPC.vbf	Check in SDD (unconfirmed)	PCM - Powertrain Control Module	EXE
M8D2-14C570-MRB.vbf	Check in SDD (unconfirmed)	PCM - Powertrain Control Module	EXE
M8D2-14C570-MRC.vbf	Check in SDD (unconfirmed)	PCM - Powertrain Control Module	EXE
M8D2-14C570-PGC.vbf	Check in SDD (unconfirmed)	PCM - Powertrain Control Module	EXE
M8D2-14C570-PMB.vbf	Check in SDD (unconfirmed)	PCM - Powertrain Control Module	EXE
M8D2-14C570-PPC.vbf	Check in SDD (unconfirmed)	PCM - Powertrain Control Module	EXE
M8D2-14C570-PRC.vbf	Check in SDD (unconfirmed)	PCM - Powertrain Control Module	EXE
M8D2-14C572-BA.vbf	Check in SDD (unconfirmed)	PCM - Powertrain Control Module	SBL
M8D2-14C572-BB.vbf	Check in SDD (unconfirmed)	PCM - Powertrain Control Module	SBL
M8D2-14C609-AB.vbf	Check in SDD (unconfirmed)	PSCM - Power Steering Control Module	DATA
M8D2-14D368-AC.vbf	Check in SDD (unconfirmed)	SODR - Side Obstacle Detection Control Module - Right	EXE
M8D2-14D368-AD.vbf	Check in SDD (unconfirmed)	SODR - Side Obstacle Detection Control Module - Right	EXE
M8D2-14D368-AF.vbf	Check in SDD (unconfirmed)	SODR - Side Obstacle Detection Control Module - Right	EXE
M8D2-14D370-AA.vbf	Check in SDD (unconfirmed)	SODR - Side Obstacle Detection Control Module - Right	SBL
M8D2-14E093-GB.vbf	Check in SDD (unconfirmed)	CHCM - Chassis Control Module	EXE
M8D2-14E153-AB.vbf	Check in SDD (unconfirmed)	DADC - Driver Assistance Domain Controller	EXE
M8D2-14E153-AC.vbf	Check in SDD (unconfirmed)	DADC - Driver Assistance Domain Controller	EXE
M8D2-14F397-AB.vbf	Check in SDD (unconfirmed)	IPMA - Image Processing Module A	EXE
M8D2-14F397-AE.vbf	Check in SDD (unconfirmed)	IPMA - Image Processing Module A	EXE
M8D2-14F397-BB.vbf	Check in SDD (unconfirmed)	IPMA - Image Processing Module A	EXE
M8D2-14F397-BE.vbf	Check in SDD (unconfirmed)	IPMA - Image Processing Module A	EXE
M8D2-19C274-BA.vbf	Check in SDD (unconfirmed)	LPDM - Left Power Sliding Door Module	DATA

File name	Vehicle line (indicative)	Module (ECU)	Type
M8D2-7B762-AB.vbf	Check in SDD (unconfirmed)	AWD - All Wheel Drive Module	EXE
M8D2-7B762-BB.vbf	Check in SDD (unconfirmed)	AWD - All Wheel Drive Module	EXE
M8D2-7B763-AB.vbf	Check in SDD (unconfirmed)	AWD - All Wheel Drive Module	DATA
M8D2-7B763-BB.vbf	Check in SDD (unconfirmed)	AWD - All Wheel Drive Module	DATA
M8D2-7B772-BA.vbf	Check in SDD (unconfirmed)	AWD - All Wheel Drive Module	EXE
M8D2-7B773-BA.vbf	Check in SDD (unconfirmed)	AWD - All Wheel Drive Module	DATA
M8DM-19H537-AB.vbf	Not specified	Not specified	DATA
M8E2-10F962-AA.vbf	Not specified	ILCM - Interior Lighting Control Module	EXE
M8E2-10F964-AA.vbf	Not specified	ILCM - Interior Lighting Control Module	SBL
M8E2-14C030-AA.vbf	Not specified	DSM - Driver Front Seat Module	EXE
M8EM-19H536-AB.vbf	Not specified	Not specified	DATA
M8EM-19H538-AB.vbf	Not specified	TBM - Trailer Brake Control Module	SBL
M9A3-14C065-AE.vbf	Jaguar XF (X260)	DDM - Driver Front Door Module	DATA
M9A3-14C069-AE.vbf	Jaguar XF (X260)	DRDM - Driver Rear Door Module	DATA
M9A3-14C105-AA.vbf	Not specified	TMC Traffic Message Channel Module	EXE
M9A3-14C105-AB.vbf	Not specified	TMC Traffic Message Channel Module	EXE
M9A3-14C105-AC.vbf	Not specified	TMC Traffic Message Channel Module	EXE
M9A3-14C105-BA.vbf	Not specified	TMC Traffic Message Channel Module	EXE
M9A3-14C105-BC.vbf	Not specified	TMC Traffic Message Channel Module	EXE
M9A3-14C109-AE.vbf	Jaguar XF (X260)	PDM - Passenger Front Door Module	DATA
M9A3-14C113-AE.vbf	Jaguar XF (X260)	PRDM - Passenger Rear Door Module	DATA
M9A3-14C527-BAD.vbf	Not specified	AAM - Audio Amplifier Module	DATA
M9A3-14C527-BD.vbf	Not specified	AAM - Audio Amplifier Module	DATA
M9A3-14C527-CAD.vbf	Not specified	AAM - Audio Amplifier Module	DATA
M9A3-14C527-CD.vbf	Not specified	AAM - Audio Amplifier Module	DATA
M9A3-14C527-DAD.vbf	Not specified	AAM - Audio Amplifier Module	DATA
M9A3-14C527-DD.vbf	Not specified	AAM - Audio Amplifier Module	DATA
M9A3-14C527-ZD.vbf	Not specified	AAM - Audio Amplifier Module	DATA
M9A3-14E094-GAA.vbf	Not specified	CHCM - Chassis Control Module	EXE
M9A3-14E094-GAB.vbf	Not specified	CHCM - Chassis Control Module	EXE
M9A3-14E094-GAC.vbf	Not specified	CHCM - Chassis Control Module	EXE
M9A3-14E157-AC.vbf	Not specified	DADC - Driver Assistance Domain Controller	EXE
M9A3-14E157-AD.vbf	Not specified	DADC - Driver Assistance Domain Controller	EXE
M9A3-14E157-AG.vbf	Not specified	DADC - Driver Assistance Domain Controller	EXE
M9A3-14E157-AH.vbf	Not specified	DADC - Driver Assistance Domain Controller	EXE
M9A3-19J244-EC.vbf	Not specified	NFSM	DATA
M9A3-19J244-FC.vbf	Not specified	NFSM	DATA
M9D3-14C027-AA.vbf	Not specified	RCM - Restraints Control Module	SBL
M9D3-14C028-AA.vbf	Not specified	RCM - Restraints Control Module	EXE
M9D3-14C030-AA.vbf	Not specified	DSM - Driver Front Seat Module	EXE
M9D3-14C217-AB.vbf	Defender (L663)	PSCM - Power Steering Control Module	EXE
M9D3-14C217-AC.vbf	Defender (L663)	PSCM - Power Steering Control Module	EXE
M9D3-14C217-BB.vbf	Not specified	PSCM - Power Steering Control Module	EXE
M9D3-14C217-BC.vbf	Not specified	PSCM - Power Steering Control Module	EXE
M9D3-14C217-KB.vbf	Defender (L663)	PSCM - Power Steering Control Module	EXE
M9D3-14C217-LB.vbf	Not specified	PSCM - Power Steering Control Module	EXE
M9D3-14C218-AAA.vbf	Not specified	PSCM - Power Steering Control Module	DATA
M9D3-14C218-AB.vbf	Not specified	PSCM - Power Steering Control Module	DATA
M9D3-14C218-AD.vbf	Not specified	PSCM - Power Steering Control Module	DATA
M9D3-14C218-BAA.vbf	Not specified	PSCM - Power Steering Control Module	DATA
M9D3-14C218-BB.vbf	Not specified	PSCM - Power Steering Control Module	DATA
M9D3-14C218-BD.vbf	Not specified	PSCM - Power Steering Control Module	DATA
M9D3-14C218-GB.vbf	Not specified	PSCM - Power Steering Control Module	DATA
M9D3-14C218-HB.vbf	Not specified	PSCM - Power Steering Control Module	DATA
M9D3-14C386-AA.vbf	Not specified	PSCM - Power Steering Control Module	DATA
M9D3-14C386-BA.vbf	Not specified	PSCM - Power Steering Control Module	DATA
M9D3-14C609-AB.vbf	Not specified	PSCM - Power Steering Control Module	DATA
M9D3-14C609-AD.vbf	Not specified	PSCM - Power Steering Control Module	DATA
M9D3-14C609-BB.vbf	Not specified	PSCM - Power Steering Control Module	DATA
M9D3-14C609-BD.vbf	Not specified	PSCM - Power Steering Control Module	DATA
M9D3-14C609-GB.vbf	Not specified	PSCM - Power Steering Control Module	DATA
M9D3-14C609-HB.vbf	Not specified	PSCM - Power Steering Control Module	DATA
M9D3-18D619-AA.vbf	Not specified	HVAC - HVAC Control Module	EXE
M9D3-18D619-AB.vbf	Not specified	HVAC - HVAC Control Module	EXE
M9D3-18D619-BA.vbf	Not specified	HVAC - HVAC Control Module	EXE
M9R3-14C030-AB.vbf	Not specified	DSM - Driver Front Seat Module	EXE
M9W3-14C065-AC.vbf	Jaguar XE (X760)	DDM - Driver Front Door Module	DATA
M9W3-14C069-AC.vbf	Jaguar XE (X760)	DRDM - Driver Rear Door Module	DATA
M9W3-14C109-AC.vbf	Jaguar XE (X760)	PDM - Passenger Front Door Module	DATA
M9W3-14C113-AC.vbf	Jaguar XE (X760)	PRDM - Passenger Rear Door Module	DATA
M9W3-14C527-AAD.vbf	Jaguar XE (X760)	AAM - Audio Amplifier Module	DATA
M9W3-14C527-AD.vbf	Jaguar XE (X760)	AAM - Audio Amplifier Module	DATA
M9W3-14C527-CAD.vbf	Jaguar XE (X760)	AAM - Audio Amplifier Module	DATA
M9W3-14C527-CD.vbf	Jaguar XE (X760)	AAM - Audio Amplifier Module	DATA
M9W3-14C527-DAD.vbf	Jaguar XE (X760)	AAM - Audio Amplifier Module	DATA
M9W3-14C527-DD.vbf	Jaguar XE (X760)	AAM - Audio Amplifier Module	DATA

File name	Vehicle line (indicative)	Module (ECU)	Type
M9W3-14C527-ZD.vbf	Jaguar XE (X760)	AAM - Audio Amplifier Module	DATA
M9W3-14E094-GAA.vbf	Jaguar XE (X760)	CHCM - Chassis Control Module	EXE
M9W3-14E094-GAB.vbf	Jaguar XE (X760)	CHCM - Chassis Control Module	EXE
M9W3-14E094-GAC.vbf	Jaguar XE (X760)	CHCM - Chassis Control Module	EXE
M9W3-14E157-AF.vbf	Jaguar XE (X760)	DADC - Driver Assistance Domain Controller	EXE
M9W3-14E157-AG.vbf	Jaguar XE (X760)	DADC - Driver Assistance Domain Controller	EXE
M9W3-19J244-DC.vbf	Jaguar XE (X760)	NFSM	DATA
M9W3-19J244-EC.vbf	Jaguar XE (X760)	NFSM	DATA
MK52-14C570-JGB.vbf	Range Rover (L405)	PCM - Powertrain Control Module	EXE
MK52-14C570-JLB.vbf	Range Rover (L405)	PCM - Powertrain Control Module	EXE
MK52-14C570-JPB.vbf	Range Rover (L405)	PCM - Powertrain Control Module	EXE
MK52-14C570-JRB.vbf	Range Rover (L405)	PCM - Powertrain Control Module	EXE
MK52-14C570-JUB.vbf	Range Rover (L405)	PCM - Powertrain Control Module	EXE
MK52-14C570-SFC.vbf	Range Rover (L405)	PCM - Powertrain Control Module	EXE
MK52-14C570-SHC.vbf	Range Rover (L405)	PCM - Powertrain Control Module	EXE
MK52-7J104-FAA.vbf	Range Rover (L405)	TCM - Transmission Control Module	EXE
MK52-7J104-FBA.vbf	Range Rover (L405)	TCM - Transmission Control Module	EXE
MK52-7J104-FFA.vbf	Range Rover (L405)	TCM - Transmission Control Module	EXE
MK52-7J104-FGA.vbf	Range Rover (L405)	TCM - Transmission Control Module	EXE
MK52-7J104-FKA.vbf	Range Rover (L405)	TCM - Transmission Control Module	EXE
MK52-7J104-FTA.vbf	Range Rover (L405)	TCM - Transmission Control Module	EXE
MK52-7J104-FUA.vbf	Range Rover (L405)	TCM - Transmission Control Module	EXE
MK52-7J104-FXA.vbf	Range Rover (L405)	TCM - Transmission Control Module	EXE
MK52-7J104-FZA.vbf	Range Rover (L405)	TCM - Transmission Control Module	EXE
MK62-12K532-KAA.vbf	Range Rover Sport (L494)	PCM - Powertrain Control Module	EXE
MK62-12K532-KBA.vbf	Range Rover Sport (L494)	PCM - Powertrain Control Module	EXE
MK62-12K532-KCA.vbf	Range Rover Sport (L494)	PCM - Powertrain Control Module	EXE
MK62-12K532-KDB.vbf	Range Rover Sport (L494)	PCM - Powertrain Control Module	EXE
MK62-12K532-KEB.vbf	Range Rover Sport (L494)	PCM - Powertrain Control Module	EXE
MK62-12K532-KFB.vbf	Range Rover Sport (L494)	PCM - Powertrain Control Module	EXE
MK62-14C570-BNB.vbf	Range Rover Sport (L494)	PCM - Powertrain Control Module	EXE
MK62-14C570-BPA.vbf	Range Rover Sport (L494)	PCM - Powertrain Control Module	EXE
MK62-14C570-BRB.vbf	Range Rover Sport (L494)	PCM - Powertrain Control Module	EXE
MK62-14C570-BUB.vbf	Range Rover Sport (L494)	PCM - Powertrain Control Module	EXE
MK62-14C570-SFC.vbf	Range Rover Sport (L494)	PCM - Powertrain Control Module	EXE
MK62-14C570-SHC.vbf	Range Rover Sport (L494)	PCM - Powertrain Control Module	EXE
MK62-14C570-STC.vbf	Range Rover Sport (L494)	PCM - Powertrain Control Module	EXE
MK62-14F530-AA.vbf	Range Rover Sport (L494)	GWM - Gateway Module A	EXE
MK62-14F530-DA.vbf	Range Rover Sport (L494)	GWM - Gateway Module A	EXE
MK62-14F531-AA.vbf	Range Rover Sport (L494)	GWM - Gateway Module A	DATA
MK62-14F531-DA.vbf	Range Rover Sport (L494)	GWM - Gateway Module A	DATA
MK62-7J104-FBA.vbf	Range Rover Sport (L494)	TCM - Transmission Control Module	EXE
MK62-7J104-FFA.vbf	Range Rover Sport (L494)	TCM - Transmission Control Module	EXE
MK62-7J104-FGA.vbf	Range Rover Sport (L494)	TCM - Transmission Control Module	EXE
MK62-7J104-FKA.vbf	Range Rover Sport (L494)	TCM - Transmission Control Module	EXE
MK62-7J104-FTA.vbf	Range Rover Sport (L494)	TCM - Transmission Control Module	EXE
MK62-7J104-FUA.vbf	Range Rover Sport (L494)	TCM - Transmission Control Module	EXE
MK62-7J104-FXA.vbf	Range Rover Sport (L494)	TCM - Transmission Control Module	EXE
MK62-7J104-FZA.vbf	Range Rover Sport (L494)	TCM - Transmission Control Module	EXE
MK62-7J104-GJA.vbf	Range Rover Sport (L494)	TCM - Transmission Control Module	EXE
MK72-12K532-VAA.vbf	Discovery Sport (L550)	PCM - Powertrain Control Module	EXE
MK72-12K532-VCA.vbf	Discovery Sport (L550)	PCM - Powertrain Control Module	EXE
MK72-12K532-VDA.vbf	Discovery Sport (L550)	PCM - Powertrain Control Module	EXE
MK72-12K532-VKA.vbf	Discovery Sport (L550)	PCM - Powertrain Control Module	EXE
MK72-12K532-VLA.vbf	Discovery Sport (L550)	PCM - Powertrain Control Module	EXE
MK72-14C034-AB.vbf	Discovery Sport (L550)	DSM - Driver Front Seat Module	DATA
MK72-14C034-AD.vbf	Discovery Sport (L550)	DSM - Driver Front Seat Module	DATA
MK72-14C037-AAB.vbf	Discovery Sport (L550)	ABS - Anti-Lock Brake System Control Module	DATA
MK72-14C037-AAE.vbf	Discovery Sport (L550)	ABS - Anti-Lock Brake System Control Module	DATA
MK72-14C037-ABB.vbf	Discovery Sport (L550)	ABS - Anti-Lock Brake System Control Module	DATA
MK72-14C037-ABE.vbf	Discovery Sport (L550)	ABS - Anti-Lock Brake System Control Module	DATA
MK72-14C037-ACB.vbf	Discovery Sport (L550)	ABS - Anti-Lock Brake System Control Module	DATA
MK72-14C037-ACE.vbf	Discovery Sport (L550)	ABS - Anti-Lock Brake System Control Module	DATA
MK72-14C037-ADB.vbf	Discovery Sport (L550)	ABS - Anti-Lock Brake System Control Module	DATA
MK72-14C037-ADE.vbf	Discovery Sport (L550)	ABS - Anti-Lock Brake System Control Module	DATA
MK72-14C037-AEB.vbf	Discovery Sport (L550)	ABS - Anti-Lock Brake System Control Module	DATA
MK72-14C037-AEE.vbf	Discovery Sport (L550)	ABS - Anti-Lock Brake System Control Module	DATA
MK72-14C037-AFB.vbf	Discovery Sport (L550)	ABS - Anti-Lock Brake System Control Module	DATA
MK72-14C037-AFE.vbf	Discovery Sport (L550)	ABS - Anti-Lock Brake System Control Module	DATA
MK72-14C037-AGB.vbf	Discovery Sport (L550)	ABS - Anti-Lock Brake System Control Module	DATA
MK72-14C037-AGE.vbf	Discovery Sport (L550)	ABS - Anti-Lock Brake System Control Module	DATA
MK72-14C037-AHB.vbf	Discovery Sport (L550)	ABS - Anti-Lock Brake System Control Module	DATA
MK72-14C037-AHE.vbf	Discovery Sport (L550)	ABS - Anti-Lock Brake System Control Module	DATA
MK72-14C037-AJB.vbf	Discovery Sport (L550)	ABS - Anti-Lock Brake System Control Module	DATA
MK72-14C037-AJE.vbf	Discovery Sport (L550)	ABS - Anti-Lock Brake System Control Module	DATA
MK72-14C037-AKB.vbf	Discovery Sport (L550)	ABS - Anti-Lock Brake System Control Module	DATA

File name	Vehicle line (indicative)	Module (ECU)	Type
MK72-14C037-AKE.vbf	Discovery Sport (L550)	ABS - Anti-Lock Brake System Control Module	DATA
MK72-14C037-ALB.vbf	Discovery Sport (L550)	ABS - Anti-Lock Brake System Control Module	DATA
MK72-14C037-ALE.vbf	Discovery Sport (L550)	ABS - Anti-Lock Brake System Control Module	DATA
MK72-14C037-AMB.vbf	Discovery Sport (L550)	ABS - Anti-Lock Brake System Control Module	DATA
MK72-14C037-AME.vbf	Discovery Sport (L550)	ABS - Anti-Lock Brake System Control Module	DATA
MK72-14C037-ANB.vbf	Discovery Sport (L550)	ABS - Anti-Lock Brake System Control Module	DATA
MK72-14C037-ANE.vbf	Discovery Sport (L550)	ABS - Anti-Lock Brake System Control Module	DATA
MK72-14C037-ARB.vbf	Discovery Sport (L550)	ABS - Anti-Lock Brake System Control Module	DATA
MK72-14C037-ARE.vbf	Discovery Sport (L550)	ABS - Anti-Lock Brake System Control Module	DATA
MK72-14C037-ASE.vbf	Discovery Sport (L550)	ABS - Anti-Lock Brake System Control Module	DATA
MK72-14C037-ATE.vbf	Discovery Sport (L550)	ABS - Anti-Lock Brake System Control Module	DATA
MK72-14C037-AUE.vbf	Discovery Sport (L550)	ABS - Anti-Lock Brake System Control Module	DATA
MK72-14C037-AVE.vbf	Discovery Sport (L550)	ABS - Anti-Lock Brake System Control Module	DATA
MK72-14C037-AXE.vbf	Discovery Sport (L550)	ABS - Anti-Lock Brake System Control Module	DATA
MK72-14C037-AYE.vbf	Discovery Sport (L550)	ABS - Anti-Lock Brake System Control Module	DATA
MK72-14C037-AZE.vbf	Discovery Sport (L550)	ABS - Anti-Lock Brake System Control Module	DATA
MK72-14C037-BAE.vbf	Discovery Sport (L550)	ABS - Anti-Lock Brake System Control Module	DATA
MK72-14C037-BBE.vbf	Discovery Sport (L550)	ABS - Anti-Lock Brake System Control Module	DATA
MK72-14C037-BDE.vbf	Discovery Sport (L550)	ABS - Anti-Lock Brake System Control Module	DATA
MK72-14C037-BEE.vbf	Discovery Sport (L550)	ABS - Anti-Lock Brake System Control Module	DATA
MK72-14C037-BFE.vbf	Discovery Sport (L550)	ABS - Anti-Lock Brake System Control Module	DATA
MK72-14C037-BGE.vbf	Discovery Sport (L550)	ABS - Anti-Lock Brake System Control Module	DATA
MK72-14C037-BHE.vbf	Discovery Sport (L550)	ABS - Anti-Lock Brake System Control Module	DATA
MK72-14C037-BJE.vbf	Discovery Sport (L550)	ABS - Anti-Lock Brake System Control Module	DATA
MK72-14C064-BB.vbf	Discovery Sport (L550)	DDM - Driver Front Door Module	EXE
MK72-14C065-AB.vbf	Discovery Sport (L550)	DDM - Driver Front Door Module	DATA
MK72-14C068-BB.vbf	Discovery Sport (L550)	DRDM - Driver Rear Door Module	EXE
MK72-14C069-AB.vbf	Discovery Sport (L550)	DRDM - Driver Rear Door Module	DATA
MK72-14C085-AA.vbf	Discovery Sport (L550)	HCM - Headlamp Control Module #1	DATA
MK72-14C085-BA.vbf	Discovery Sport (L550)	Not specified	DATA
MK72-14C098-AA.vbf	Discovery Sport (L550)	RCM - Restraints Control Module	DATA
MK72-14C098-AB.vbf	Discovery Sport (L550)	RCM - Restraints Control Module	DATA
MK72-14C098-BA.vbf	Discovery Sport (L550)	RCM - Restraints Control Module	DATA
MK72-14C098-BB.vbf	Discovery Sport (L550)	RCM - Restraints Control Module	DATA
MK72-14C108-BB.vbf	Discovery Sport (L550)	PDM - Passenger Front Door Module	EXE
MK72-14C109-AB.vbf	Discovery Sport (L550)	PDM - Passenger Front Door Module	DATA
MK72-14C112-BB.vbf	Discovery Sport (L550)	PRDM - Passenger Rear Door Module	EXE
MK72-14C113-AB.vbf	Discovery Sport (L550)	PRDM - Passenger Rear Door Module	DATA
MK72-14C121-AA.vbf	Discovery Sport (L550)	RGTM - Rear Gate / Trunk Module	EXE
MK72-14C121-AB.vbf	Discovery Sport (L550)	RGTM - Rear Gate / Trunk Module	EXE
MK72-14C122-AA.vbf	Discovery Sport (L550)	RGTM - Rear Gate / Trunk Module	DATA
MK72-14C122-AB.vbf	Discovery Sport (L550)	RGTM - Rear Gate / Trunk Module	DATA
MK72-14C124-AA.vbf	Discovery Sport (L550)	RGTM - Rear Gate / Trunk Module	SBL
MK72-14C152-AB.vbf	Discovery Sport (L550)	TPM - Tire Pressure Monitor Module	DATA
MK72-14C185-AA.vbf	Discovery Sport (L550)	BCM - Body Control Module	DATA
MK72-14C185-AB.vbf	Discovery Sport (L550)	BCM - Body Control Module	DATA
MK72-14C185-AD.vbf	Discovery Sport (L550)	BCM - Body Control Module	DATA
MK72-14C337-CHA.vbf	Discovery Sport (L550)	TCM - Transmission Control Module	EXE
MK72-14C337-CHB.vbf	Discovery Sport (L550)	TCM - Transmission Control Module	EXE
MK72-14C337-CKA.vbf	Discovery Sport (L550)	TCM - Transmission Control Module	EXE
MK72-14C337-CKC.vbf	Discovery Sport (L550)	TCM - Transmission Control Module	EXE
MK72-14C337-CMA.vbf	Discovery Sport (L550)	TCM - Transmission Control Module	EXE
MK72-14C337-CMC.vbf	Discovery Sport (L550)	TCM - Transmission Control Module	EXE
MK72-14C337-CPA.vbf	Discovery Sport (L550)	TCM - Transmission Control Module	EXE
MK72-14C337-CPC.vbf	Discovery Sport (L550)	TCM - Transmission Control Module	EXE
MK72-14C337-CSA.vbf	Discovery Sport (L550)	TCM - Transmission Control Module	EXE
MK72-14C337-CSB.vbf	Discovery Sport (L550)	TCM - Transmission Control Module	EXE
MK72-14C337-DBA.vbf	Discovery Sport (L550)	TCM - Transmission Control Module	EXE
MK72-14C337-RAA.vbf	Discovery Sport (L550)	TCM - Transmission Control Module	EXE
MK72-14C433-AA.vbf	Discovery Sport (L550)	RGTM - Rear Gate / Trunk Module	SIGCFG
MK72-14C526-BA.vbf	Discovery Sport (L550)	AAM - Audio Amplifier Module	EXE
MK72-14C527-BAD.vbf	Discovery Sport (L550)	AAM - Audio Amplifier Module	DATA
MK72-14C527-BAE.vbf	Discovery Sport (L550)	AAM - Audio Amplifier Module	DATA
MK72-14C527-BD.vbf	Discovery Sport (L550)	AAM - Audio Amplifier Module	DATA
MK72-14C527-BE.vbf	Discovery Sport (L550)	AAM - Audio Amplifier Module	DATA
MK72-14C527-CAD.vbf	Discovery Sport (L550)	AAM - Audio Amplifier Module	DATA
MK72-14C527-CAE.vbf	Discovery Sport (L550)	AAM - Audio Amplifier Module	DATA
MK72-14C527-CD.vbf	Discovery Sport (L550)	AAM - Audio Amplifier Module	DATA
MK72-14C527-CE.vbf	Discovery Sport (L550)	AAM - Audio Amplifier Module	DATA
MK72-14C527-DAD.vbf	Discovery Sport (L550)	AAM - Audio Amplifier Module	DATA
MK72-14C527-DAE.vbf	Discovery Sport (L550)	AAM - Audio Amplifier Module	DATA
MK72-14C527-DD.vbf	Discovery Sport (L550)	AAM - Audio Amplifier Module	DATA
MK72-14C527-DE.vbf	Discovery Sport (L550)	AAM - Audio Amplifier Module	DATA
MK72-14C527-ZD.vbf	Discovery Sport (L550)	AAM - Audio Amplifier Module	DATA
MK72-14C527-ZE.vbf	Discovery Sport (L550)	AAM - Audio Amplifier Module	DATA
MK72-14C570-BAA.vbf	Discovery Sport (L550)	PCM - Powertrain Control Module	EXE

File name	Vehicle line (indicative)	Module (ECU)	Type
MK72-14C570-CGA.vbf	Discovery Sport (L550)	PCM - Powertrain Control Module	EXE
MK72-14C570-CHA.vbf	Discovery Sport (L550)	PCM - Powertrain Control Module	EXE
MK72-14C570-CRA.vbf	Discovery Sport (L550)	PCM - Powertrain Control Module	EXE
MK72-14D049-AC.vbf	Discovery Sport (L550)	TCM - Transmission Control Module	EXE
MK72-14D049-AE.vbf	Discovery Sport (L550)	CCM - Cruise Control Module	EXE
MK72-14D564-AC.vbf	Discovery Sport (L550)	SODR - Side Obstacle Detection Control Module - Right	DATA
MK72-14D564-AD.vbf	Discovery Sport (L550)	SODR - Side Obstacle Detection Control Module - Right	DATA
MK72-14E094-GAA.vbf	Discovery Sport (L550)	CHCM - Chassis Control Module	EXE
MK72-14E157-AB.vbf	Discovery Sport (L550)	DADC - Driver Assistance Domain Controller	EXE
MK72-14E157-AC.vbf	Discovery Sport (L550)	DADC - Driver Assistance Domain Controller	EXE
MK72-14E282-AB.vbf	Discovery Sport (L550)	WDCM - WirelessCharger	EXE
MK72-14E282-AC.vbf	Discovery Sport (L550)	WDCM - WirelessCharger	EXE
MK72-14E284-AB.vbf	Discovery Sport (L550)	WDCM - WirelessCharger	SBL
MK72-14E284-AC.vbf	Discovery Sport (L550)	WDCM - WirelessCharger	SBL
MK72-14F230-AA.vbf	Discovery Sport (L550)	HUD - Head Up Display	EXE
MK72-14F231-AA.vbf	Discovery Sport (L550)	HUD - Head Up Display	DATA
MK72-14F398-AB.vbf	Discovery Sport (L550)	IPMA - Image Processing Module A	EXE
MK72-14F398-AE.vbf	Discovery Sport (L550)	IPMA - Image Processing Module A	EXE
MK72-18D620-AB.vbf	Discovery Sport (L550)	HVAC - HVAC Control Module	DATA
MK72-18D620-BB.vbf	Discovery Sport (L550)	HVAC - HVAC Control Module	DATA
MK72-18D620-CB.vbf	Discovery Sport (L550)	HVAC - HVAC Control Module	DATA
MK72-18D620-DB.vbf	Discovery Sport (L550)	HVAC - HVAC Control Module	DATA
MK72-19J244-BB.vbf	Discovery Sport (L550)	NFSM	DATA
MK72-19J244-DB.vbf	Discovery Sport (L550)	NFSM	DATA
MK72-19J244-EB.vbf	Discovery Sport (L550)	NFSM	DATA
MK72-19J244-FB.vbf	Discovery Sport (L550)	NFSM	DATA
MK72-19J504-AB.vbf	Discovery Sport (L550)	NFSM	DATA
MK72-19J504-BB.vbf	Discovery Sport (L550)	NFSM	DATA
MK72-19J504-CB.vbf	Discovery Sport (L550)	NFSM	DATA
MK72-19J504-DB.vbf	Discovery Sport (L550)	NFSM	DATA
MK83-12K532-VLA.vbf	Jaguar F-Pace (X761)	PCM - Powertrain Control Module	EXE
MK83-12K532-VLE.vbf	Jaguar F-Pace (X761)	PCM - Powertrain Control Module	EXE
MK83-14C026-AA.vbf	Jaguar F-Pace (X761)	IPC - Instrument Panel Cluster (IPC) Control Module	EXE
MK83-14C026-AB.vbf	Jaguar F-Pace (X761)	IPC - Instrument Panel Cluster (IPC) Control Module	EXE
MK83-14C034-AC.vbf	Jaguar F-Pace (X761)	DSM - Driver Front Seat Module	DATA
MK83-14C034-AE.vbf	Jaguar F-Pace (X761)	DSM - Driver Front Seat Module	DATA
MK83-14C036-AD.vbf	Jaguar F-Pace (X761)	ABS - Anti-Lock Brake System Control Module	EXE
MK83-14C037-ACD.vbf	Jaguar F-Pace (X761)	ABS - Anti-Lock Brake System Control Module	DATA
MK83-14C037-ADD.vbf	Jaguar F-Pace (X761)	ABS - Anti-Lock Brake System Control Module	DATA
MK83-14C037-AED.vbf	Jaguar F-Pace (X761)	ABS - Anti-Lock Brake System Control Module	DATA
MK83-14C037-AFD.vbf	Jaguar F-Pace (X761)	ABS - Anti-Lock Brake System Control Module	DATA
MK83-14C037-ALD.vbf	Jaguar F-Pace (X761)	ABS - Anti-Lock Brake System Control Module	DATA
MK83-14C037-AMD.vbf	Jaguar F-Pace (X761)	ABS - Anti-Lock Brake System Control Module	DATA
MK83-14C037-ARD.vbf	Jaguar F-Pace (X761)	ABS - Anti-Lock Brake System Control Module	DATA
MK83-14C037-ASD.vbf	Jaguar F-Pace (X761)	ABS - Anti-Lock Brake System Control Module	DATA
MK83-14C037-ATD.vbf	Jaguar F-Pace (X761)	ABS - Anti-Lock Brake System Control Module	DATA
MK83-14C037-AUD.vbf	Jaguar F-Pace (X761)	ABS - Anti-Lock Brake System Control Module	DATA
MK83-14C037-AVD.vbf	Jaguar F-Pace (X761)	ABS - Anti-Lock Brake System Control Module	DATA
MK83-14C037-AXD.vbf	Jaguar F-Pace (X761)	ABS - Anti-Lock Brake System Control Module	DATA
MK83-14C064-AA.vbf	Jaguar F-Pace (X761)	DDM - Driver Front Door Module	EXE
MK83-14C065-AD.vbf	Jaguar F-Pace (X761)	DDM - Driver Front Door Module	DATA
MK83-14C065-AE.vbf	Jaguar F-Pace (X761)	DDM - Driver Front Door Module	DATA
MK83-14C065-AF.vbf	Jaguar F-Pace (X761)	DDM - Driver Front Door Module	DATA
MK83-14C069-AD.vbf	Jaguar F-Pace (X761)	DRDM - Driver Rear Door Module	DATA
MK83-14C069-AE.vbf	Jaguar F-Pace (X761)	DRDM - Driver Rear Door Module	DATA
MK83-14C069-AF.vbf	Jaguar F-Pace (X761)	DRDM - Driver Rear Door Module	DATA
MK83-14C085-AA.vbf	Jaguar F-Pace (X761)	HCM - Headlamp Control Module #1	DATA
MK83-14C085-AB.vbf	Jaguar F-Pace (X761)	HCM - Headlamp Control Module #1	DATA
MK83-14C085-AC.vbf	Jaguar F-Pace (X761)	HCM - Headlamp Control Module #1	DATA
MK83-14C085-BA.vbf	Jaguar F-Pace (X761)	Not specified	DATA
MK83-14C085-BB.vbf	Jaguar F-Pace (X761)	Not specified	DATA
MK83-14C085-BC.vbf	Jaguar F-Pace (X761)	Not specified	DATA
MK83-14C088-CB.vbf	Jaguar F-Pace (X761)	IPC - Instrument Panel Cluster (IPC) Control Module	EXE
MK83-14C088-CC.vbf	Jaguar F-Pace (X761)	IPC - Instrument Panel Cluster (IPC) Control Module	EXE
MK83-14C088-JA.vbf	Jaguar F-Pace (X761)	IPC - Instrument Panel Cluster (IPC) Control Module	DATA
MK83-14C088-JB.vbf	Jaguar F-Pace (X761)	IPC - Instrument Panel Cluster (IPC) Control Module	DATA
MK83-14C088-JC.vbf	Jaguar F-Pace (X761)	IPC - Instrument Panel Cluster (IPC) Control Module	DATA
MK83-14C098-CA.vbf	Jaguar F-Pace (X761)	RCM - Restraints Control Module	DATA
MK83-14C098-DA.vbf	Jaguar F-Pace (X761)	RCM - Restraints Control Module	DATA
MK83-14C098-DB.vbf	Jaguar F-Pace (X761)	RCM - Restraints Control Module	DATA
MK83-14C098-DD.vbf	Jaguar F-Pace (X761)	RCM - Restraints Control Module	DATA
MK83-14C098-EA.vbf	Jaguar F-Pace (X761)	RCM - Restraints Control Module	DATA
MK83-14C105-AA.vbf	Jaguar F-Pace (X761)	TMC Traffic Message Channel Module	EXE
MK83-14C105-AC.vbf	Jaguar F-Pace (X761)	TMC Traffic Message Channel Module	EXE
MK83-14C105-BA.vbf	Jaguar F-Pace (X761)	TMC Traffic Message Channel Module	EXE
MK83-14C105-BC.vbf	Jaguar F-Pace (X761)	TMC Traffic Message Channel Module	EXE

File name	Vehicle line (indicative)	Module (ECU)	Type
MK83-14C109-AD.vbf	Jaguar F-Pace (X761)	PDM - Passenger Front Door Module	DATA
MK83-14C109-AE.vbf	Jaguar F-Pace (X761)	PDM - Passenger Front Door Module	DATA
MK83-14C109-AF.vbf	Jaguar F-Pace (X761)	PDM - Passenger Front Door Module	DATA
MK83-14C113-AD.vbf	Jaguar F-Pace (X761)	PRDM - Passenger Rear Door Module	DATA
MK83-14C113-AE.vbf	Jaguar F-Pace (X761)	PRDM - Passenger Rear Door Module	DATA
MK83-14C113-AF.vbf	Jaguar F-Pace (X761)	PRDM - Passenger Rear Door Module	DATA
MK83-14C121-AA.vbf	Jaguar F-Pace (X761)	RGTM - Rear Gate / Trunk Module	EXE
MK83-14C122-AA.vbf	Jaguar F-Pace (X761)	RGTM - Rear Gate / Trunk Module	DATA
MK83-14C124-AA.vbf	Jaguar F-Pace (X761)	RGTM - Rear Gate / Trunk Module	SBL
MK83-14C152-AC.vbf	Jaguar F-Pace (X761)	TPM - Tire Pressure Monitor Module	DATA
MK83-14C185-AA.vbf	Jaguar F-Pace (X761)	BCM - Body Control Module	DATA
MK83-14C185-AB.vbf	Jaguar F-Pace (X761)	BCM - Body Control Module	DATA
MK83-14C185-AD.vbf	Jaguar F-Pace (X761)	BCM - Body Control Module	DATA
MK83-14C433-AA.vbf	Jaguar F-Pace (X761)	RGTM - Rear Gate / Trunk Module	SIGCFG
MK83-14C527-BAD.vbf	Jaguar F-Pace (X761)	AAM - Audio Amplifier Module	DATA
MK83-14C527-BAE.vbf	Jaguar F-Pace (X761)	AAM - Audio Amplifier Module	DATA
MK83-14C527-BD.vbf	Jaguar F-Pace (X761)	AAM - Audio Amplifier Module	DATA
MK83-14C527-BE.vbf	Jaguar F-Pace (X761)	AAM - Audio Amplifier Module	DATA
MK83-14C527-BED.vbf	Jaguar F-Pace (X761)	AAM - Audio Amplifier Module	DATA
MK83-14C527-BEE.vbf	Jaguar F-Pace (X761)	AAM - Audio Amplifier Module	DATA
MK83-14C527-CAD.vbf	Jaguar F-Pace (X761)	AAM - Audio Amplifier Module	DATA
MK83-14C527-CAE.vbf	Jaguar F-Pace (X761)	AAM - Audio Amplifier Module	DATA
MK83-14C527-CD.vbf	Jaguar F-Pace (X761)	AAM - Audio Amplifier Module	DATA
MK83-14C527-CE.vbf	Jaguar F-Pace (X761)	AAM - Audio Amplifier Module	DATA
MK83-14C527-DAD.vbf	Jaguar F-Pace (X761)	AAM - Audio Amplifier Module	DATA
MK83-14C527-DAE.vbf	Jaguar F-Pace (X761)	AAM - Audio Amplifier Module	DATA
MK83-14C527-DD.vbf	Jaguar F-Pace (X761)	AAM - Audio Amplifier Module	DATA
MK83-14C527-DE.vbf	Jaguar F-Pace (X761)	AAM - Audio Amplifier Module	DATA
MK83-14C527-ZD.vbf	Jaguar F-Pace (X761)	AAM - Audio Amplifier Module	DATA
MK83-14C527-ZE.vbf	Jaguar F-Pace (X761)	AAM - Audio Amplifier Module	DATA
MK83-14C570-JGA.vbf	Jaguar F-Pace (X761)	PCM - Powertrain Control Module	EXE
MK83-14C570-JGB.vbf	Jaguar F-Pace (X761)	PCM - Powertrain Control Module	EXE
MK83-14C570-JGC.vbf	Jaguar F-Pace (X761)	PCM - Powertrain Control Module	EXE
MK83-14C570-JGD.vbf	Jaguar F-Pace (X761)	PCM - Powertrain Control Module	EXE
MK83-14C570-JGF.vbf	Jaguar F-Pace (X761)	PCM - Powertrain Control Module	EXE
MK83-14C570-JLF.vbf	Jaguar F-Pace (X761)	PCM - Powertrain Control Module	EXE
MK83-14C570-JNB.vbf	Jaguar F-Pace (X761)	PCM - Powertrain Control Module	EXE
MK83-14C570-JNC.vbf	Jaguar F-Pace (X761)	PCM - Powertrain Control Module	EXE
MK83-14C570-JND.vbf	Jaguar F-Pace (X761)	PCM - Powertrain Control Module	EXE
MK83-14C570-JNF.vbf	Jaguar F-Pace (X761)	PCM - Powertrain Control Module	EXE
MK83-14C570-JPB.vbf	Jaguar F-Pace (X761)	PCM - Powertrain Control Module	EXE
MK83-14C570-JPC.vbf	Jaguar F-Pace (X761)	PCM - Powertrain Control Module	EXE
MK83-14C570-JPD.vbf	Jaguar F-Pace (X761)	PCM - Powertrain Control Module	EXE
MK83-14C570-JPF.vbf	Jaguar F-Pace (X761)	PCM - Powertrain Control Module	EXE
MK83-14C570-JRB.vbf	Jaguar F-Pace (X761)	PCM - Powertrain Control Module	EXE
MK83-14C570-JRC.vbf	Jaguar F-Pace (X761)	PCM - Powertrain Control Module	EXE
MK83-14C570-JRD.vbf	Jaguar F-Pace (X761)	PCM - Powertrain Control Module	EXE
MK83-14C570-JRF.vbf	Jaguar F-Pace (X761)	PCM - Powertrain Control Module	EXE
MK83-14C570-JUA.vbf	Jaguar F-Pace (X761)	PCM - Powertrain Control Module	EXE
MK83-14C570-JUB.vbf	Jaguar F-Pace (X761)	PCM - Powertrain Control Module	EXE
MK83-14C570-JUC.vbf	Jaguar F-Pace (X761)	PCM - Powertrain Control Module	EXE
MK83-14C570-JUD.vbf	Jaguar F-Pace (X761)	PCM - Powertrain Control Module	EXE
MK83-14C570-JUF.vbf	Jaguar F-Pace (X761)	PCM - Powertrain Control Module	EXE
MK83-14D024-BA.vbf	Jaguar F-Pace (X761)	ATCM - All Terrain Control Module	EXE
MK83-14D024-DA.vbf	Jaguar F-Pace (X761)	ATCM - All Terrain Control Module	EXE
MK83-14D026-BA.vbf	Jaguar F-Pace (X761)	ATCM - All Terrain Control Module	SBL
MK83-14D183-AA.vbf	Jaguar F-Pace (X761)	OCS - Restraints Occupant Classification System Module	DATA
MK83-14D183-AB.vbf	Jaguar F-Pace (X761)	OCS - Restraints Occupant Classification System Module	DATA
MK83-14D564-AB.vbf	Jaguar F-Pace (X761)	SODR - Side Obstacle Detection Control Module - Right	DATA
MK83-14D564-AD.vbf	Jaguar F-Pace (X761)	SODR - Side Obstacle Detection Control Module - Right	DATA
MK83-14D564-AE.vbf	Jaguar F-Pace (X761)	SODR - Side Obstacle Detection Control Module - Right	DATA
MK83-14E094-GAA.vbf	Jaguar F-Pace (X761)	CHCM - Chassis Control Module	EXE
MK83-14E094-GAB.vbf	Jaguar F-Pace (X761)	CHCM - Chassis Control Module	EXE
MK83-14E094-GAC.vbf	Jaguar F-Pace (X761)	CHCM - Chassis Control Module	EXE
MK83-14E094-GBA.vbf	Jaguar F-Pace (X761)	CHCM - Chassis Control Module	EXE
MK83-14E094-GBB.vbf	Jaguar F-Pace (X761)	CHCM - Chassis Control Module	EXE
MK83-14E094-GBC.vbf	Jaguar F-Pace (X761)	CHCM - Chassis Control Module	EXE
MK83-14E094-GCA.vbf	Jaguar F-Pace (X761)	CHCM - Chassis Control Module	EXE
MK83-14E094-GCB.vbf	Jaguar F-Pace (X761)	CHCM - Chassis Control Module	EXE
MK83-14E094-GCC.vbf	Jaguar F-Pace (X761)	CHCM - Chassis Control Module	EXE
MK83-14E094-GDA.vbf	Jaguar F-Pace (X761)	CHCM - Chassis Control Module	EXE
MK83-14E094-GDB.vbf	Jaguar F-Pace (X761)	CHCM - Chassis Control Module	EXE
MK83-14E094-GDC.vbf	Jaguar F-Pace (X761)	CHCM - Chassis Control Module	EXE
MK83-14E094-GEA.vbf	Jaguar F-Pace (X761)	CHCM - Chassis Control Module	EXE
MK83-14E094-GEB.vbf	Jaguar F-Pace (X761)	CHCM - Chassis Control Module	EXE
MK83-14E094-GEC.vbf	Jaguar F-Pace (X761)	CHCM - Chassis Control Module	EXE

File name	Vehicle line (indicative)	Module (ECU)	Type
MK83-14E153-AC.vbf	Jaguar F-Pace (X761)	DADC - Driver Assistance Domain Controller	EXE
MK83-14E153-AD.vbf	Jaguar I-Pace (X590)	DADC - Driver Assistance Domain Controller	EXE
MK83-14E153-AG.vbf	Jaguar F-Pace (X761)	DADC - Driver Assistance Domain Controller	EXE
MK83-14E153-AH.vbf	Jaguar F-Pace (X761)	DADC - Driver Assistance Domain Controller	EXE
MK83-14E157-AC.vbf	Jaguar F-Pace (X761)	DADC - Driver Assistance Domain Controller	EXE
MK83-14E157-AD.vbf	Jaguar F-Pace (X761)	DADC - Driver Assistance Domain Controller	EXE
MK83-14E157-AG.vbf	Jaguar F-Pace (X761)	DADC - Driver Assistance Domain Controller	EXE
MK83-14E157-AH.vbf	Jaguar F-Pace (X761)	DADC - Driver Assistance Domain Controller	EXE
MK83-14F230-AA.vbf	Jaguar F-Pace (X761)	HUD - Head Up Display	EXE
MK83-14F231-AA.vbf	Jaguar F-Pace (X761)	HUD - Head Up Display	DATA
MK83-14F398-AB.vbf	Jaguar F-Pace (X761)	IPMA - Image Processing Module A	EXE
MK83-14F398-AC.vbf	Jaguar F-Pace (X761)	IPMA - Image Processing Module A	EXE
MK83-14F398-AE.vbf	Jaguar F-Pace (X761)	IPMA - Image Processing Module A	EXE
MK83-14F398-AF.vbf	Jaguar F-Pace (X761)	IPMA - Image Processing Module A	EXE
MK83-14F530-CA.vbf	Jaguar F-Pace (X761)	GWM - Gateway Module A	EXE
MK83-14F530-CB.vbf	Jaguar F-Pace (X761)	GWM - Gateway Module A	EXE
MK83-14F531-AA.vbf	Jaguar F-Pace (X761)	GWM - Gateway Module A	DATA
MK83-14F531-AB.vbf	Jaguar F-Pace (X761)	GWM - Gateway Module A	DATA
MK83-14F531-BB.vbf	Jaguar F-Pace (X761)	GWM - Gateway Module A	DATA
MK83-14F531-CA.vbf	Jaguar F-Pace (X761)	GWM - Gateway Module A	DATA
MK83-18D619-AA.vbf	Jaguar F-Pace (X761)	HVAC - HVAC Control Module	EXE
MK83-18D620-AB.vbf	Jaguar F-Pace (X761)	HVAC - HVAC Control Module	DATA
MK83-18D620-BB.vbf	Jaguar F-Pace (X761)	HVAC - HVAC Control Module	DATA
MK83-18D620-CB.vbf	Jaguar F-Pace (X761)	HVAC - HVAC Control Module	DATA
MK83-18D620-DB.vbf	Jaguar F-Pace (X761)	HVAC - HVAC Control Module	DATA
MK83-19J244-DB.vbf	Jaguar F-Pace (X761)	NFSM	DATA
MK83-19J244-DC.vbf	Jaguar F-Pace (X761)	NFSM	DATA
MK83-19J244-EB.vbf	Jaguar F-Pace (X761)	NFSM	DATA
MK83-19J244-EC.vbf	Jaguar F-Pace (X761)	NFSM	DATA
MK83-19J504-AA.vbf	Jaguar F-Pace (X761)	NFSM	DATA
MK83-19J504-AB.vbf	Jaguar F-Pace (X761)	NFSM	DATA
MK83-19J504-BB.vbf	Jaguar F-Pace (X761)	NFSM	DATA
MK83-7J104-DUA.vbf	Jaguar F-Pace (X761)	TCM - Transmission Control Module	EXE
MK83-7J104-DUB.vbf	Jaguar F-Pace (X761)	TCM - Transmission Control Module	EXE
MK83-7J104-DUC.vbf	Jaguar F-Pace (X761)	TCM - Transmission Control Module	EXE
MK83-7J104-GJA.vbf	Jaguar F-Pace (X761)	TCM - Transmission Control Module	EXE
MK83-7J104-GJB.vbf	Jaguar F-Pace (X761)	TCM - Transmission Control Module	EXE
MK83-7J104-GJC.vbf	Jaguar F-Pace (X761)	TCM - Transmission Control Module	EXE
MK83-7J104-GKA.vbf	Jaguar F-Pace (X761)	TCM - Transmission Control Module	EXE
MK83-7J104-GKB.vbf	Jaguar F-Pace (X761)	TCM - Transmission Control Module	EXE
MK83-7J104-GKC.vbf	Jaguar F-Pace (X761)	TCM - Transmission Control Module	EXE
MK83-7J104-GLA.vbf	Jaguar F-Pace (X761)	TCM - Transmission Control Module	EXE
MK83-7J104-GLB.vbf	Jaguar F-Pace (X761)	TCM - Transmission Control Module	EXE
MK83-7J104-GLC.vbf	Jaguar F-Pace (X761)	TCM - Transmission Control Module	EXE
MK83-7J104-GMA.vbf	Jaguar F-Pace (X761)	TCM - Transmission Control Module	EXE
MK83-7J104-GMB.vbf	Jaguar F-Pace (X761)	TCM - Transmission Control Module	EXE
MK83-7J104-GMC.vbf	Jaguar F-Pace (X761)	TCM - Transmission Control Module	EXE
MK83-7J104-GRA.vbf	Jaguar F-Pace (X761)	TCM - Transmission Control Module	EXE
MK83-7J104-GRB.vbf	Jaguar F-Pace (X761)	TCM - Transmission Control Module	EXE
MK83-7J104-GRC.vbf	Jaguar F-Pace (X761)	TCM - Transmission Control Module	EXE
MK8M-14C152-AA.vbf	Not specified	TPM - Tire Pressure Monitor Module	DATA
MK8M-14C280-AA.vbf	Not specified	TBM - Trailer Brake Control Module	EXE
MK8M-14C280-AB.vbf	Not specified	TBM - Trailer Brake Control Module	EXE
MK8M-14C282-AA.vbf	Not specified	TBM - Trailer Brake Control Module	SBL
MK8M-14C527-CA.vbf	Not specified	AAM - Audio Amplifier Module	DATA
MK8M-14C527-CAA.vbf	Not specified	AAM - Audio Amplifier Module	DATA
MK8M-14C527-CAE.vbf	Not specified	AAM - Audio Amplifier Module	DATA
MK8M-14C527-DA.vbf	Not specified	AAM - Audio Amplifier Module	DATA
MK8M-14C527-DAA.vbf	Not specified	AAM - Audio Amplifier Module	DATA
MK8M-14C527-DAE.vbf	Not specified	AAM - Audio Amplifier Module	DATA
MK8M-14C527-ZA.vbf	Not specified	AAM - Audio Amplifier Module	DATA
MK8M-14C570-SAA.vbf	Not specified	PCM - Powertrain Control Module	EXE
MK8M-14C570-SCA.vbf	Not specified	PCM - Powertrain Control Module	EXE
MK8M-14C570-SEA.vbf	Not specified	PCM - Powertrain Control Module	EXE
MK8M-14C570-SHA.vbf	Not specified	PCM - Powertrain Control Module	EXE
MK8M-14C570-STA.vbf	Not specified	PCM - Powertrain Control Module	EXE
MK8M-14C572-TA.vbf	Not specified	PCM - Powertrain Control Module	SBL
MK8M-14E094-GAA.vbf	Not specified	CHCM - Chassis Control Module	EXE
MK8M-14E094-GAB.vbf	Not specified	CHCM - Chassis Control Module	EXE
MK8M-19J244-EA.vbf	Not specified	NFSM	DATA
MK8M-7J104-FZA.vbf	Not specified	TCM - Transmission Control Module	EXE
MK8M-7J104-MZA.vbf	Not specified	TCM - Transmission Control Module	EXE
MNDU-19C204-AA.vbf	Not specified	IMC - Infotainment Master Controller	EXE
MPLA-14C570-DGB.vbf	Multiple models (shared module)	PCM - Powertrain Control Module	EXE
MPLA-14C570-DMB.vbf	Multiple models (shared module)	PCM - Powertrain Control Module	EXE
MPLA-14C570-DNB.vbf	Multiple models (shared module)	PCM - Powertrain Control Module	EXE

File name	Vehicle line (indicative)	Module (ECU)	Type
MPLA-14C570-DPB.vbf	Multiple models (shared module)	PCM - Powertrain Control Module	EXE
MPLA-14C570-DRB.vbf	Multiple models (shared module)	PCM - Powertrain Control Module	EXE
MPLA-14C570-DUB.vbf	Multiple models (shared module)	PCM - Powertrain Control Module	EXE
MPLA-14C570-SAC.vbf	Multiple models (shared module)	PCM - Powertrain Control Module	EXE
MPLA-14C570-SHC.vbf	Multiple models (shared module)	PCM - Powertrain Control Module	EXE
MPLA-14C570-STC.vbf	Multiple models (shared module)	PCM - Powertrain Control Module	EXE
MX53-14C026-JA.vbf	Jaguar F-Type (X152)	IPC - Instrument Panel Cluster (IPC) Control Module	EXE
MX53-14C026-JB.vbf	Jaguar F-Type (X152)	IPC - Instrument Panel Cluster (IPC) Control Module	EXE
MX53-14C026-JD.vbf	Jaguar F-Type (X152)	IPC - Instrument Panel Cluster (IPC) Control Module	EXE
MX53-14C026-KA.vbf	Jaguar F-Type (X152)	IPC - Instrument Panel Cluster (IPC) Control Module	EXE
MX53-14C026-KB.vbf	Jaguar F-Type (X152)	IPC - Instrument Panel Cluster (IPC) Control Module	EXE
MX53-14C026-KC.vbf	Jaguar F-Type (X152)	IPC - Instrument Panel Cluster (IPC) Control Module	EXE
MX53-14C036-AB.vbf	Jaguar F-Type (X152)	SPCM - Secondary Powertrain Control Module	EXE
MX53-14C037-AAB.vbf	Jaguar F-Type (X152)	SPCM - Secondary Powertrain Control Module	DATA
MX53-14C037-AAC.vbf	Jaguar F-Type (X152)	SPCM - Secondary Powertrain Control Module	DATA
MX53-14C037-ABB.vbf	Jaguar F-Type (X152)	SPCM - Secondary Powertrain Control Module	DATA
MX53-14C037-ABC.vbf	Jaguar F-Type (X152)	SPCM - Secondary Powertrain Control Module	DATA
MX53-14C037-ACB.vbf	Jaguar F-Type (X152)	SPCM - Secondary Powertrain Control Module	DATA
MX53-14C037-ACC.vbf	Jaguar F-Type (X152)	SPCM - Secondary Powertrain Control Module	DATA
MX53-14C037-ADB.vbf	Jaguar F-Type (X152)	SPCM - Secondary Powertrain Control Module	DATA
MX53-14C037-ADC.vbf	Jaguar F-Type (X152)	SPCM - Secondary Powertrain Control Module	DATA
MX53-14C037-AEB.vbf	Jaguar F-Type (X152)	SPCM - Secondary Powertrain Control Module	DATA
MX53-14C037-AEC.vbf	Jaguar F-Type (X152)	SPCM - Secondary Powertrain Control Module	DATA
MX53-14C037-AFB.vbf	Jaguar F-Type (X152)	SPCM - Secondary Powertrain Control Module	DATA
MX53-14C037-AFC.vbf	Jaguar F-Type (X152)	SPCM - Secondary Powertrain Control Module	DATA
MX53-14C037-AGB.vbf	Jaguar F-Type (X152)	SPCM - Secondary Powertrain Control Module	DATA
MX53-14C037-AGC.vbf	Jaguar F-Type (X152)	SPCM - Secondary Powertrain Control Module	DATA
MX53-14C037-AHB.vbf	Jaguar F-Type (X152)	SPCM - Secondary Powertrain Control Module	DATA
MX53-14C037-AHC.vbf	Jaguar F-Type (X152)	SPCM - Secondary Powertrain Control Module	DATA
MX53-14C037-AJB.vbf	Jaguar F-Type (X152)	SPCM - Secondary Powertrain Control Module	DATA
MX53-14C037-AJC.vbf	Jaguar F-Type (X152)	SPCM - Secondary Powertrain Control Module	DATA
MX53-14C037-AKB.vbf	Jaguar F-Type (X152)	SPCM - Secondary Powertrain Control Module	DATA
MX53-14C037-AKC.vbf	Jaguar F-Type (X152)	SPCM - Secondary Powertrain Control Module	DATA
MX53-14C037-ALB.vbf	Jaguar F-Type (X152)	SPCM - Secondary Powertrain Control Module	DATA
MX53-14C037-ALC.vbf	Jaguar F-Type (X152)	SPCM - Secondary Powertrain Control Module	DATA
MX53-14C037-AMB.vbf	Jaguar F-Type (X152)	SPCM - Secondary Powertrain Control Module	DATA
MX53-14C037-AMC.vbf	Jaguar F-Type (X152)	SPCM - Secondary Powertrain Control Module	DATA
MX53-14C037-ANB.vbf	Jaguar F-Type (X152)	SPCM - Secondary Powertrain Control Module	DATA
MX53-14C037-ANC.vbf	Jaguar F-Type (X152)	SPCM - Secondary Powertrain Control Module	DATA
MX53-14C037-APB.vbf	Jaguar F-Type (X152)	SPCM - Secondary Powertrain Control Module	DATA
MX53-14C037-APC.vbf	Jaguar F-Type (X152)	SPCM - Secondary Powertrain Control Module	DATA
MX53-14C037-ARB.vbf	Jaguar F-Type (X152)	SPCM - Secondary Powertrain Control Module	DATA
MX53-14C037-ARC.vbf	Jaguar F-Type (X152)	SPCM - Secondary Powertrain Control Module	DATA
MX53-14C037-ASB.vbf	Jaguar F-Type (X152)	SPCM - Secondary Powertrain Control Module	DATA
MX53-14C037-ASC.vbf	Jaguar F-Type (X152)	SPCM - Secondary Powertrain Control Module	DATA
MX53-14C037-ATB.vbf	Jaguar F-Type (X152)	SPCM - Secondary Powertrain Control Module	DATA
MX53-14C037-ATC.vbf	Jaguar F-Type (X152)	SPCM - Secondary Powertrain Control Module	DATA
MX53-14C037-AUB.vbf	Jaguar F-Type (X152)	SPCM - Secondary Powertrain Control Module	DATA
MX53-14C037-AUC.vbf	Jaguar F-Type (X152)	SPCM - Secondary Powertrain Control Module	DATA
MX53-14C037-AVB.vbf	Jaguar F-Type (X152)	SPCM - Secondary Powertrain Control Module	DATA
MX53-14C037-AVC.vbf	Jaguar F-Type (X152)	SPCM - Secondary Powertrain Control Module	DATA
MX53-14C037-AYB.vbf	Jaguar F-Type (X152)	SPCM - Secondary Powertrain Control Module	DATA
MX53-14C037-AYC.vbf	Jaguar F-Type (X152)	SPCM - Secondary Powertrain Control Module	DATA
MX53-14C037-AZB.vbf	Jaguar F-Type (X152)	SPCM - Secondary Powertrain Control Module	DATA
MX53-14C037-AZC.vbf	Jaguar F-Type (X152)	SPCM - Secondary Powertrain Control Module	DATA
MX53-14C037-BAB.vbf	Jaguar F-Type (X152)	SPCM - Secondary Powertrain Control Module	DATA
MX53-14C037-BAC.vbf	Jaguar F-Type (X152)	SPCM - Secondary Powertrain Control Module	DATA
MX53-14C037-BBB.vbf	Jaguar F-Type (X152)	SPCM - Secondary Powertrain Control Module	DATA
MX53-14C037-BBC.vbf	Jaguar F-Type (X152)	SPCM - Secondary Powertrain Control Module	DATA
MX53-14C037-BCB.vbf	Jaguar F-Type (X152)	SPCM - Secondary Powertrain Control Module	DATA
MX53-14C037-BCC.vbf	Jaguar F-Type (X152)	SPCM - Secondary Powertrain Control Module	DATA
MX53-14C084-AA.vbf	Jaguar F-Type (X152)	HCM - Headlamp Control Module #1	EXE
MX53-14C084-AB.vbf	Jaguar F-Type (X152)	HCM - Headlamp Control Module #1	EXE
MX53-14C084-BA.vbf	Jaguar F-Type (X152)	Not specified	EXE
MX53-14C084-BB.vbf	Jaguar F-Type (X152)	Not specified	EXE
MX53-14C085-AA.vbf	Jaguar F-Type (X152)	HCM - Headlamp Control Module #1	DATA
MX53-14C085-AB.vbf	Jaguar F-Type (X152)	HCM - Headlamp Control Module #1	DATA
MX53-14C085-BA.vbf	Jaguar F-Type (X152)	Not specified	DATA
MX53-14C085-BB.vbf	Jaguar F-Type (X152)	Not specified	DATA
MX53-14C088-JA.vbf	Jaguar F-Type (X152)	IPC - Instrument Panel Cluster (IPC) Control Module	DATA
MX53-14C088-JB.vbf	Jaguar F-Type (X152)	IPC - Instrument Panel Cluster (IPC) Control Module	DATA
MX53-14C088-JC.vbf	Jaguar F-Type (X152)	IPC - Instrument Panel Cluster (IPC) Control Module	DATA
MX53-14C088-JE.vbf	Jaguar F-Type (X152)	IPC - Instrument Panel Cluster (IPC) Control Module	DATA
MX53-14C091-AA.vbf	Jaguar F-Type (X152)	PAM - Parking Assist Control Module	DATA
MX53-14C091-AC.vbf	Jaguar F-Type (X152)	PAM - Parking Assist Control Module	DATA
MX53-14C098-AA.vbf	Jaguar F-Type (X152)	RCM - Restraints Control Module	DATA

File name	Vehicle line (indicative)	Module (ECU)	Type
MX53-14C098-BA.vbf	Jaguar F-Type (X152)	RCM - Restraints Control Module	DATA
MX53-14C185-AA.vbf	Jaguar F-Type (X152)	BCM - Body Control Module	DATA
MX53-14C218-AA.vbf	Jaguar F-Type (X152)	PSCM - Power Steering Control Module	DATA
MX53-14C218-BA.vbf	Jaguar F-Type (X152)	PSCM - Power Steering Control Module	DATA
MX53-14C399-AB.vbf	Jaguar F-Type (X152)	HCM - Headlamp Control Module #1	SIGCFG
MX53-14C399-BB.vbf	Jaguar F-Type (X152)	Not specified	SIGCFG
MX53-14C527-BA.vbf	Jaguar F-Type (X152)	AAM - Audio Amplifier Module	DATA
MX53-14C527-BB.vbf	Jaguar F-Type (X152)	AAM - Audio Amplifier Module	DATA
MX53-14C527-BC.vbf	Jaguar F-Type (X152)	AAM - Audio Amplifier Module	DATA
MX53-14C527-BD.vbf	Jaguar F-Type (X152)	AAM - Audio Amplifier Module	DATA
MX53-14C527-BFA.vbf	Jaguar F-Type (X152)	AAM - Audio Amplifier Module	DATA
MX53-14C527-BFB.vbf	Jaguar F-Type (X152)	AAM - Audio Amplifier Module	DATA
MX53-14C527-BFC.vbf	Jaguar F-Type (X152)	AAM - Audio Amplifier Module	DATA
MX53-14C527-BFD.vbf	Jaguar F-Type (X152)	AAM - Audio Amplifier Module	DATA
MX53-14C527-BGA.vbf	Jaguar F-Type (X152)	AAM - Audio Amplifier Module	DATA
MX53-14C527-BGB.vbf	Jaguar F-Type (X152)	AAM - Audio Amplifier Module	DATA
MX53-14C527-BGC.vbf	Jaguar F-Type (X152)	AAM - Audio Amplifier Module	DATA
MX53-14C527-BGD.vbf	Jaguar F-Type (X152)	AAM - Audio Amplifier Module	DATA
MX53-14C527-BHA.vbf	Jaguar F-Type (X152)	AAM - Audio Amplifier Module	DATA
MX53-14C527-BHB.vbf	Jaguar F-Type (X152)	AAM - Audio Amplifier Module	DATA
MX53-14C527-CA.vbf	Jaguar F-Type (X152)	AAM - Audio Amplifier Module	DATA
MX53-14C527-CB.vbf	Jaguar F-Type (X152)	AAM - Audio Amplifier Module	DATA
MX53-14C527-CC.vbf	Jaguar F-Type (X152)	AAM - Audio Amplifier Module	DATA
MX53-14C527-CFA.vbf	Jaguar F-Type (X152)	AAM - Audio Amplifier Module	DATA
MX53-14C527-CFB.vbf	Jaguar F-Type (X152)	AAM - Audio Amplifier Module	DATA
MX53-14C527-CFC.vbf	Jaguar F-Type (X152)	AAM - Audio Amplifier Module	DATA
MX53-14C527-CFD.vbf	Jaguar F-Type (X152)	AAM - Audio Amplifier Module	DATA
MX53-14C527-CGA.vbf	Jaguar F-Type (X152)	AAM - Audio Amplifier Module	DATA
MX53-14C527-CGB.vbf	Jaguar F-Type (X152)	AAM - Audio Amplifier Module	DATA
MX53-14C527-CGC.vbf	Jaguar F-Type (X152)	AAM - Audio Amplifier Module	DATA
MX53-14C527-CGD.vbf	Jaguar F-Type (X152)	AAM - Audio Amplifier Module	DATA
MX53-14C527-CHA.vbf	Jaguar F-Type (X152)	AAM - Audio Amplifier Module	DATA
MX53-14C527-CHB.vbf	Jaguar F-Type (X152)	AAM - Audio Amplifier Module	DATA
MX53-14C527-FA.vbf	Jaguar F-Type (X152)	AAM - Audio Amplifier Module	DATA
MX53-14C527-FB.vbf	Jaguar F-Type (X152)	AAM - Audio Amplifier Module	DATA
MX53-14C527-FC.vbf	Jaguar F-Type (X152)	AAM - Audio Amplifier Module	DATA
MX53-14C527-FFA.vbf	Jaguar F-Type (X152)	AAM - Audio Amplifier Module	DATA
MX53-14C527-FFB.vbf	Jaguar F-Type (X152)	AAM - Audio Amplifier Module	DATA
MX53-14C527-FFC.vbf	Jaguar F-Type (X152)	AAM - Audio Amplifier Module	DATA
MX53-14C527-FFD.vbf	Jaguar F-Type (X152)	AAM - Audio Amplifier Module	DATA
MX53-14C527-FGA.vbf	Jaguar F-Type (X152)	AAM - Audio Amplifier Module	DATA
MX53-14C527-FGB.vbf	Jaguar F-Type (X152)	AAM - Audio Amplifier Module	DATA
MX53-14C527-FGC.vbf	Jaguar F-Type (X152)	AAM - Audio Amplifier Module	DATA
MX53-14C527-FGD.vbf	Jaguar F-Type (X152)	AAM - Audio Amplifier Module	DATA
MX53-14C527-FHA.vbf	Jaguar F-Type (X152)	AAM - Audio Amplifier Module	DATA
MX53-14C527-FHB.vbf	Jaguar F-Type (X152)	AAM - Audio Amplifier Module	DATA
MX53-14C527-GA.vbf	Jaguar F-Type (X152)	AAM - Audio Amplifier Module	DATA
MX53-14C527-GB.vbf	Jaguar F-Type (X152)	AAM - Audio Amplifier Module	DATA
MX53-14C527-GC.vbf	Jaguar F-Type (X152)	AAM - Audio Amplifier Module	DATA
MX53-14C527-GFA.vbf	Jaguar F-Type (X152)	AAM - Audio Amplifier Module	DATA
MX53-14C527-GFB.vbf	Jaguar F-Type (X152)	AAM - Audio Amplifier Module	DATA
MX53-14C527-GFC.vbf	Jaguar F-Type (X152)	AAM - Audio Amplifier Module	DATA
MX53-14C527-GFD.vbf	Jaguar F-Type (X152)	AAM - Audio Amplifier Module	DATA
MX53-14C527-GGA.vbf	Jaguar F-Type (X152)	AAM - Audio Amplifier Module	DATA
MX53-14C527-GGB.vbf	Jaguar F-Type (X152)	AAM - Audio Amplifier Module	DATA
MX53-14C527-GGC.vbf	Jaguar F-Type (X152)	AAM - Audio Amplifier Module	DATA
MX53-14C527-GGD.vbf	Jaguar F-Type (X152)	AAM - Audio Amplifier Module	DATA
MX53-14C527-GHA.vbf	Jaguar F-Type (X152)	AAM - Audio Amplifier Module	DATA
MX53-14C527-GHB.vbf	Jaguar F-Type (X152)	AAM - Audio Amplifier Module	DATA
MX53-14C570-BHA.vbf	Jaguar F-Type (X152)	PCM - Powertrain Control Module	EXE
MX53-14C570-BHB.vbf	Jaguar F-Type (X152)	PCM - Powertrain Control Module	EXE
MX53-14C570-BHC.vbf	Jaguar F-Type (X152)	PCM - Powertrain Control Module	EXE
MX53-14C570-CAB.vbf	Jaguar F-Type (X152)	PCM - Powertrain Control Module	EXE
MX53-14C570-CFA.vbf	Jaguar F-Type (X152)	PCM - Powertrain Control Module	EXE
MX53-14C570-CFB.vbf	Jaguar F-Type (X152)	PCM - Powertrain Control Module	EXE
MX53-14C570-CTA.vbf	Jaguar F-Type (X152)	PCM - Powertrain Control Module	EXE
MX53-14C570-RHA.vbf	Jaguar F-Type (X152)	PCM - Powertrain Control Module	EXE
MX53-14C570-RHB.vbf	Jaguar F-Type (X152)	PCM - Powertrain Control Module	EXE
MX53-14C570-RHC.vbf	Jaguar F-Type (X152)	PCM - Powertrain Control Module	EXE
MX53-14C570-UAB.vbf	Jaguar F-Type (X152)	PCM - Powertrain Control Module	EXE
MX53-14C570-UTA.vbf	Jaguar F-Type (X152)	PCM - Powertrain Control Module	EXE
MX53-14C570-ZAB.vbf	Jaguar F-Type (X152)	PCM - Powertrain Control Module	EXE
MX53-14C570-ZAC.vbf	Jaguar F-Type (X152)	PCM - Powertrain Control Module	EXE
MX53-14C570-ZCB.vbf	Jaguar F-Type (X152)	PCM - Powertrain Control Module	EXE
MX53-14C570-ZCC.vbf	Jaguar F-Type (X152)	PCM - Powertrain Control Module	EXE
MX53-14C570-ZEB.vbf	Jaguar F-Type (X152)	PCM - Powertrain Control Module	EXE

File name	Vehicle line (indicative)	Module (ECU)	Type
MX53-14C570-ZEC.vbf	Jaguar F-Type (X152)	PCM - Powertrain Control Module	EXE
MX53-14C570-ZHB.vbf	Jaguar F-Type (X152)	PCM - Powertrain Control Module	EXE
MX53-14C570-ZHC.vbf	Jaguar F-Type (X152)	PCM - Powertrain Control Module	EXE
MX53-14C570-ZTA.vbf	Jaguar F-Type (X152)	PCM - Powertrain Control Module	EXE
MX53-14C570-ZTB.vbf	Jaguar F-Type (X152)	PCM - Powertrain Control Module	EXE
MX53-14C570-ZTC.vbf	Jaguar F-Type (X152)	PCM - Powertrain Control Module	EXE
MX53-14E094-DAA.vbf	Jaguar F-Type (X152)	CHCM - Chassis Control Module	EXE
MX53-14E094-DAB.vbf	Jaguar F-Type (X152)	CHCM - Chassis Control Module	EXE
MX53-14E094-DBA.vbf	Jaguar F-Type (X152)	CHCM - Chassis Control Module	EXE
MX53-14E094-DBB.vbf	Jaguar F-Type (X152)	CHCM - Chassis Control Module	EXE
MX53-14E094-DCA.vbf	Jaguar F-Type (X152)	CHCM - Chassis Control Module	EXE
MX53-14E094-DCB.vbf	Jaguar F-Type (X152)	CHCM - Chassis Control Module	EXE
MX53-14E094-DDA.vbf	Jaguar F-Type (X152)	CHCM - Chassis Control Module	EXE
MX53-14E094-DDB.vbf	Jaguar F-Type (X152)	CHCM - Chassis Control Module	EXE
MX53-14E094-DEA.vbf	Jaguar F-Type (X152)	CHCM - Chassis Control Module	EXE
MX53-14E094-DEB.vbf	Jaguar F-Type (X152)	CHCM - Chassis Control Module	EXE
MX53-14E094-DFA.vbf	Jaguar F-Type (X152)	CHCM - Chassis Control Module	EXE
MX53-14E094-DFB.vbf	Jaguar F-Type (X152)	CHCM - Chassis Control Module	EXE
MX53-14F396-AA.vbf	Jaguar F-Type (X152)	IPMA - Image Processing Module A	EXE
MX53-14F397-AA.vbf	Jaguar F-Type (X152)	IPMA - Image Processing Module A	EXE
MX53-14F397-BA.vbf	Jaguar F-Type (X152)	IPMA - Image Processing Module A	EXE
MX53-14F398-AA.vbf	Jaguar F-Type (X152)	IPMA - Image Processing Module A	EXE
MX53-14F530-AA.vbf	Jaguar F-Type (X152)	GWM - Gateway Module A	EXE
MX53-14F530-AB.vbf	Jaguar F-Type (X152)	GWM - Gateway Module A	EXE
MX53-14F531-AA.vbf	Jaguar F-Type (X152)	GWM - Gateway Module A	DATA
MX53-19C204-AA.vbf	Jaguar F-Type (X152)	IMC - Infotainment Master Controller	EXE
MX53-7J104-BGA.vbf	Jaguar F-Type (X152)	TCM - Transmission Control Module	EXE
MX53-7J104-BGB.vbf	Jaguar F-Type (X152)	TCM - Transmission Control Module	EXE
MX53-7J104-BKA.vbf	Jaguar F-Type (X152)	TCM - Transmission Control Module	EXE
MX53-7J104-BKB.vbf	Jaguar F-Type (X152)	TCM - Transmission Control Module	EXE
MX53-7J104-BNB.vbf	Jaguar F-Type (X152)	TCM - Transmission Control Module	EXE
MX53-7J104-BNC.vbf	Jaguar F-Type (X152)	TCM - Transmission Control Module	EXE
MX53-7J104-BND.vbf	Jaguar F-Type (X152)	TCM - Transmission Control Module	EXE
MX53-7J104-BNE.vbf	Jaguar F-Type (X152)	TCM - Transmission Control Module	EXE
MX53-7J104-BNF.vbf	Jaguar F-Type (X152)	TCM - Transmission Control Module	EXE
MX63-14C026-JA.vbf	Jaguar XF (X260)	IPC - Instrument Panel Cluster (IPC) Control Module	EXE
MX63-14C026-JB.vbf	Jaguar XF (X260)	IPC - Instrument Panel Cluster (IPC) Control Module	EXE
MX63-14C026-JC.vbf	Jaguar XF (X260)	IPC - Instrument Panel Cluster (IPC) Control Module	EXE
MX63-14C026-KA.vbf	Jaguar XF (X260)	IPC - Instrument Panel Cluster (IPC) Control Module	EXE
MX63-14C026-KB.vbf	Jaguar XF (X260)	IPC - Instrument Panel Cluster (IPC) Control Module	EXE
MX63-14C026-KC.vbf	Jaguar XF (X260)	IPC - Instrument Panel Cluster (IPC) Control Module	EXE
MX63-14C034-AC.vbf	Jaguar XF (X260)	DSM - Driver Front Seat Module	DATA
MX63-14C034-AE.vbf	Jaguar XF (X260)	DSM - Driver Front Seat Module	DATA
MX63-14C037-AAD.vbf	Jaguar XF (X260)	ABS - Anti-Lock Brake System Control Module	DATA
MX63-14C037-ABD.vbf	Jaguar XF (X260)	ABS - Anti-Lock Brake System Control Module	DATA
MX63-14C037-ACD.vbf	Jaguar XF (X260)	ABS - Anti-Lock Brake System Control Module	DATA
MX63-14C037-ADD.vbf	Jaguar XF (X260)	ABS - Anti-Lock Brake System Control Module	DATA
MX63-14C037-AED.vbf	Jaguar XF (X260)	ABS - Anti-Lock Brake System Control Module	DATA
MX63-14C037-AFD.vbf	Jaguar XF (X260)	ABS - Anti-Lock Brake System Control Module	DATA
MX63-14C037-AGD.vbf	Jaguar XF (X260)	ABS - Anti-Lock Brake System Control Module	DATA
MX63-14C037-AHD.vbf	Jaguar XF (X260)	ABS - Anti-Lock Brake System Control Module	DATA
MX63-14C037-ALD.vbf	Jaguar XF (X260)	ABS - Anti-Lock Brake System Control Module	DATA
MX63-14C037-AMD.vbf	Jaguar XF (X260)	ABS - Anti-Lock Brake System Control Module	DATA
MX63-14C037-AND.vbf	Jaguar XF (X260)	ABS - Anti-Lock Brake System Control Module	DATA
MX63-14C037-APD.vbf	Jaguar XF (X260)	ABS - Anti-Lock Brake System Control Module	DATA
MX63-14C037-ARD.vbf	Jaguar XF (X260)	ABS - Anti-Lock Brake System Control Module	DATA
MX63-14C037-ASD.vbf	Jaguar XF (X260)	ABS - Anti-Lock Brake System Control Module	DATA
MX63-14C037-BAD.vbf	Jaguar XF (X260)	ABS - Anti-Lock Brake System Control Module	DATA
MX63-14C037-BBD.vbf	Jaguar XF (X260)	ABS - Anti-Lock Brake System Control Module	DATA
MX63-14C037-BCD.vbf	Jaguar XF (X260)	ABS - Anti-Lock Brake System Control Module	DATA
MX63-14C037-BDD.vbf	Jaguar XF (X260)	ABS - Anti-Lock Brake System Control Module	DATA
MX63-14C037-BED.vbf	Jaguar XF (X260)	ABS - Anti-Lock Brake System Control Module	DATA
MX63-14C037-BFD.vbf	Jaguar XF (X260)	ABS - Anti-Lock Brake System Control Module	DATA
MX63-14C037-BGD.vbf	Jaguar XF (X260)	ABS - Anti-Lock Brake System Control Module	DATA
MX63-14C037-BHD.vbf	Jaguar XF (X260)	ABS - Anti-Lock Brake System Control Module	DATA
MX63-14C037-BJD.vbf	Jaguar XF (X260)	ABS - Anti-Lock Brake System Control Module	DATA
MX63-14C037-BKD.vbf	Jaguar XF (X260)	ABS - Anti-Lock Brake System Control Module	DATA
MX63-14C037-BLD.vbf	Jaguar XF (X260)	ABS - Anti-Lock Brake System Control Module	DATA
MX63-14C037-BMD.vbf	Jaguar XF (X260)	ABS - Anti-Lock Brake System Control Module	DATA
MX63-14C065-AD.vbf	Jaguar XF (X260)	DDM - Driver Front Door Module	DATA
MX63-14C065-AF.vbf	Jaguar XF (X260)	DDM - Driver Front Door Module	DATA
MX63-14C065-BD.vbf	Jaguar XF (X260)	DDM - Driver Front Door Module	DATA
MX63-14C065-BF.vbf	Jaguar XF (X260)	DDM - Driver Front Door Module	DATA
MX63-14C069-AD.vbf	Jaguar XF (X260)	DRDM - Driver Rear Door Module	DATA
MX63-14C069-AF.vbf	Jaguar XF (X260)	DRDM - Driver Rear Door Module	DATA
MX63-14C069-BD.vbf	Jaguar XF (X260)	DRDM - Driver Rear Door Module	DATA

File name	Vehicle line (indicative)	Module (ECU)	Type
MX63-14C069-BF.vbf	Jaguar XF (X260)	DRDM - Driver Rear Door Module	DATA
MX63-14C085-AA.vbf	Jaguar XF (X260)	HCM - Headlamp Control Module #1	DATA
MX63-14C085-AB.vbf	Jaguar XF (X260)	HCM - Headlamp Control Module #1	DATA
MX63-14C085-AC.vbf	Jaguar XF (X260)	HCM - Headlamp Control Module #1	DATA
MX63-14C085-BA.vbf	Jaguar XF (X260)	Not specified	DATA
MX63-14C085-BB.vbf	Jaguar XF (X260)	Not specified	DATA
MX63-14C085-BC.vbf	Jaguar XF (X260)	Not specified	DATA
MX63-14C088-JA.vbf	Jaguar XF (X260)	IPC - Instrument Panel Cluster (IPC) Control Module	DATA
MX63-14C088-JB.vbf	Jaguar XF (X260)	IPC - Instrument Panel Cluster (IPC) Control Module	DATA
MX63-14C088-JC.vbf	Jaguar XF (X260)	IPC - Instrument Panel Cluster (IPC) Control Module	DATA
MX63-14C098-CB.vbf	Jaguar XF (X260)	RCM - Restraints Control Module	DATA
MX63-14C098-DA.vbf	Jaguar XF (X260)	RCM - Restraints Control Module	DATA
MX63-14C098-DB.vbf	Jaguar XF (X260)	RCM - Restraints Control Module	DATA
MX63-14C098-DD.vbf	Jaguar XF (X260)	RCM - Restraints Control Module	DATA
MX63-14C098-EA.vbf	Jaguar XF (X260)	RCM - Restraints Control Module	DATA
MX63-14C105-AA.vbf	Jaguar XF (X260)	TMC Traffic Message Channel Module	EXE
MX63-14C105-AC.vbf	Jaguar XF (X260)	TMC Traffic Message Channel Module	EXE
MX63-14C105-BA.vbf	Jaguar XF (X260)	TMC Traffic Message Channel Module	EXE
MX63-14C105-BC.vbf	Jaguar XF (X260)	TMC Traffic Message Channel Module	EXE
MX63-14C105-CA.vbf	Jaguar XF (X260)	TMC Traffic Message Channel Module	EXE
MX63-14C105-CC.vbf	Jaguar XF (X260)	TMC Traffic Message Channel Module	EXE
MX63-14C105-DA.vbf	Jaguar XF (X260)	TMC Traffic Message Channel Module	EXE
MX63-14C105-DC.vbf	Jaguar XF (X260)	TMC Traffic Message Channel Module	EXE
MX63-14C109-AD.vbf	Jaguar XF (X260)	PDM - Passenger Front Door Module	DATA
MX63-14C109-AF.vbf	Jaguar XF (X260)	PDM - Passenger Front Door Module	DATA
MX63-14C109-BD.vbf	Jaguar XF (X260)	PDM - Passenger Front Door Module	DATA
MX63-14C109-BF.vbf	Jaguar XF (X260)	PDM - Passenger Front Door Module	DATA
MX63-14C113-AD.vbf	Jaguar XF (X260)	PRDM - Passenger Rear Door Module	DATA
MX63-14C113-AF.vbf	Jaguar XF (X260)	PRDM - Passenger Rear Door Module	DATA
MX63-14C113-BD.vbf	Jaguar XF (X260)	PRDM - Passenger Rear Door Module	DATA
MX63-14C113-BF.vbf	Jaguar XF (X260)	PRDM - Passenger Rear Door Module	DATA
MX63-14C121-AA.vbf	Jaguar XF (X260)	RGTM - Rear Gate / Trunk Module	EXE
MX63-14C121-BA.vbf	Jaguar XF (X260)	RGTM - Rear Gate / Trunk Module	EXE
MX63-14C122-AA.vbf	Jaguar XF (X260)	RGTM - Rear Gate / Trunk Module	DATA
MX63-14C122-BA.vbf	Jaguar XF (X260)	RGTM - Rear Gate / Trunk Module	DATA
MX63-14C124-AA.vbf	Jaguar XF (X260)	RGTM - Rear Gate / Trunk Module	SBL
MX63-14C124-BA.vbf	Jaguar XF (X260)	RGTM - Rear Gate / Trunk Module	SBL
MX63-14C152-AC.vbf	Jaguar XF (X260)	TPM - Tire Pressure Monitor Module	DATA
MX63-14C185-AA.vbf	Jaguar XF (X260)	BCM - Body Control Module	DATA
MX63-14C185-AB.vbf	Jaguar XF (X260)	BCM - Body Control Module	DATA
MX63-14C185-AD.vbf	Jaguar XF (X260)	BCM - Body Control Module	DATA
MX63-14C433-AA.vbf	Jaguar XF (X260)	RGTM - Rear Gate / Trunk Module	SIGCFG
MX63-14C433-BA.vbf	Jaguar XF (X260)	RGTM - Rear Gate / Trunk Module	SIGCFG
MX63-14C526-BA.vbf	Jaguar XF (X260)	AAM - Audio Amplifier Module	EXE
MX63-14C526-CA.vbf	Jaguar XF (X260)	AAM - Audio Amplifier Module	EXE
MX63-14C526-DA.vbf	Jaguar XF (X260)	AAM - Audio Amplifier Module	EXE
MX63-14C527-BAD.vbf	Jaguar XF (X260)	AAM - Audio Amplifier Module	DATA
MX63-14C527-BAE.vbf	Jaguar XF (X260)	AAM - Audio Amplifier Module	DATA
MX63-14C527-BD.vbf	Jaguar XF (X260)	AAM - Audio Amplifier Module	DATA
MX63-14C527-BE.vbf	Jaguar XF (X260)	AAM - Audio Amplifier Module	DATA
MX63-14C527-CAD.vbf	Jaguar XF (X260)	AAM - Audio Amplifier Module	DATA
MX63-14C527-CAE.vbf	Jaguar XF (X260)	AAM - Audio Amplifier Module	DATA
MX63-14C527-CD.vbf	Jaguar XF (X260)	AAM - Audio Amplifier Module	DATA
MX63-14C527-CE.vbf	Jaguar XF (X260)	AAM - Audio Amplifier Module	DATA
MX63-14C527-DAD.vbf	Jaguar XF (X260)	AAM - Audio Amplifier Module	DATA
MX63-14C527-DAE.vbf	Jaguar XF (X260)	AAM - Audio Amplifier Module	DATA
MX63-14C527-DD.vbf	Jaguar XF (X260)	AAM - Audio Amplifier Module	DATA
MX63-14C527-DE.vbf	Jaguar XF (X260)	AAM - Audio Amplifier Module	DATA
MX63-14C527-FA.vbf	Jaguar XF (X260)	AAM - Audio Amplifier Module	DATA
MX63-14C527-GA.vbf	Jaguar XF (X260)	AAM - Audio Amplifier Module	DATA
MX63-14C527-HA.vbf	Jaguar XF (X260)	AAM - Audio Amplifier Module	DATA
MX63-14C527-ZD.vbf	Jaguar XF (X260)	AAM - Audio Amplifier Module	DATA
MX63-14C527-ZE.vbf	Jaguar XF (X260)	AAM - Audio Amplifier Module	DATA
MX63-14C570-BAA.vbf	Jaguar XF (X260)	PCM - Powertrain Control Module	EXE
MX63-14C570-BAB.vbf	Jaguar XF (X260)	PCM - Powertrain Control Module	EXE
MX63-14C570-BCA.vbf	Jaguar XF (X260)	PCM - Powertrain Control Module	EXE
MX63-14C570-BEA.vbf	Jaguar XF (X260)	PCM - Powertrain Control Module	EXE
MX63-14C570-BEB.vbf	Jaguar XF (X260)	PCM - Powertrain Control Module	EXE
MX63-14C570-BFA.vbf	Jaguar XF (X260)	PCM - Powertrain Control Module	EXE
MX63-14C570-BFC.vbf	Jaguar XF (X260)	PCM - Powertrain Control Module	EXE
MX63-14C570-BGA.vbf	Jaguar XF (X260)	PCM - Powertrain Control Module	EXE
MX63-14C570-BGB.vbf	Jaguar XF (X260)	PCM - Powertrain Control Module	EXE
MX63-14C570-BHA.vbf	Jaguar XF (X260)	PCM - Powertrain Control Module	EXE
MX63-14C570-BHB.vbf	Jaguar XF (X260)	PCM - Powertrain Control Module	EXE
MX63-14C570-BPA.vbf	Jaguar XF (X260)	PCM - Powertrain Control Module	EXE
MX63-14C570-BRA.vbf	Jaguar XF (X260)	PCM - Powertrain Control Module	EXE

File name	Vehicle line (indicative)	Module (ECU)	Type
MX63-14C570-BRB.vbf	Jaguar XF (X260)	PCM - Powertrain Control Module	EXE
MX63-14C570-BTA.vbf	Jaguar XF (X260)	PCM - Powertrain Control Module	EXE
MX63-14C570-BUA.vbf	Jaguar XF (X260)	PCM - Powertrain Control Module	EXE
MX63-14D049-AB.vbf	Check in SDD (unconfirmed)	CCM - Cruise Control Module	EXE
MX63-14D049-AC.vbf	Jaguar XF (X260)	CCM - Cruise Control Module	EXE
MX63-14D049-AD.vbf	Jaguar XF (X260)	CCM - Cruise Control Module	EXE
MX63-14D051-AA.vbf	Jaguar XF (X260)	CCM - Cruise Control Module	SBL
MX63-14D183-AA.vbf	Jaguar XF (X260)	OCS - Restraints Occupant Classification System Module	DATA
MX63-14D368-AC.vbf	Jaguar XF (X260)	SODR - Side Obstacle Detection Control Module - Right	EXE
MX63-14D368-AE.vbf	Jaguar XF (X260)	SODR - Side Obstacle Detection Control Module - Right	EXE
MX63-14D368-AF.vbf	Jaguar XF (X260)	SODR - Side Obstacle Detection Control Module - Right	EXE
MX63-14D368-AJ.vbf	Jaguar XF (X260)	SODR - Side Obstacle Detection Control Module - Right	EXE
MX63-14D370-AA.vbf	Jaguar XF (X260)	SODR - Side Obstacle Detection Control Module - Right	SBL
MX63-14D564-AB.vbf	Jaguar XF (X260)	SODR - Side Obstacle Detection Control Module - Right	DATA
MX63-14D564-AD.vbf	Jaguar XF (X260)	SODR - Side Obstacle Detection Control Module - Right	DATA
MX63-14D564-AE.vbf	Jaguar XF (X260)	SODR - Side Obstacle Detection Control Module - Right	DATA
MX63-14D564-BB.vbf	Jaguar XF (X260)	SODR - Side Obstacle Detection Control Module - Right	DATA
MX63-14D564-BD.vbf	Jaguar XF (X260)	SODR - Side Obstacle Detection Control Module - Right	DATA
MX63-14D564-BE.vbf	Jaguar XF (X260)	SODR - Side Obstacle Detection Control Module - Right	DATA
MX63-14E093-KA.vbf	Jaguar XF (X260)	CHCM - Chassis Control Module	EXE
MX63-14E094-GAA.vbf	Jaguar XF (X260)	CHCM - Chassis Control Module	EXE
MX63-14E094-GAB.vbf	Jaguar XF (X260)	CHCM - Chassis Control Module	EXE
MX63-14E094-GAC.vbf	Jaguar XF (X260)	CHCM - Chassis Control Module	EXE
MX63-14E094-GBA.vbf	Jaguar XF (X260)	CHCM - Chassis Control Module	EXE
MX63-14E094-GBB.vbf	Jaguar XF (X260)	CHCM - Chassis Control Module	EXE
MX63-14E094-GBC.vbf	Jaguar XF (X260)	CHCM - Chassis Control Module	EXE
MX63-14E094-GCA.vbf	Jaguar XF (X260)	CHCM - Chassis Control Module	EXE
MX63-14E094-GCB.vbf	Jaguar XF (X260)	CHCM - Chassis Control Module	EXE
MX63-14E094-GCC.vbf	Jaguar XF (X260)	CHCM - Chassis Control Module	EXE
MX63-14E094-KAB.vbf	Jaguar XF (X260)	CHCM - Chassis Control Module	EXE
MX63-14E094-KAC.vbf	Jaguar XF (X260)	CHCM - Chassis Control Module	EXE
MX63-14E094-KAD.vbf	Jaguar XF (X260)	CHCM - Chassis Control Module	EXE
MX63-14E094-KBA.vbf	Jaguar XF (X260)	CHCM - Chassis Control Module	EXE
MX63-14E094-KBB.vbf	Jaguar XF (X260)	CHCM - Chassis Control Module	EXE
MX63-14E094-KBC.vbf	Jaguar XF (X260)	CHCM - Chassis Control Module	EXE
MX63-14E094-KCA.vbf	Jaguar XF (X260)	CHCM - Chassis Control Module	EXE
MX63-14E094-KCB.vbf	Jaguar XF (X260)	CHCM - Chassis Control Module	EXE
MX63-14E094-KCC.vbf	Jaguar XF (X260)	CHCM - Chassis Control Module	EXE
MX63-14E094-KDA.vbf	Jaguar XF (X260)	CHCM - Chassis Control Module	EXE
MX63-14E094-KDB.vbf	Jaguar XF (X260)	CHCM - Chassis Control Module	EXE
MX63-14E094-KDC.vbf	Jaguar XF (X260)	CHCM - Chassis Control Module	EXE
MX63-14E094-KEA.vbf	Jaguar XF (X260)	CHCM - Chassis Control Module	EXE
MX63-14E094-KEB.vbf	Jaguar XF (X260)	CHCM - Chassis Control Module	EXE
MX63-14E094-KEC.vbf	Jaguar XF (X260)	CHCM - Chassis Control Module	EXE
MX63-14E157-AC.vbf	Jaguar XF (X260)	DADC - Driver Assistance Domain Controller	EXE
MX63-14E157-AD.vbf	Jaguar XF (X260)	DADC - Driver Assistance Domain Controller	EXE
MX63-14E157-AG.vbf	Jaguar XF (X260)	DADC - Driver Assistance Domain Controller	EXE
MX63-14E157-AH.vbf	Jaguar XF (X260)	DADC - Driver Assistance Domain Controller	EXE
MX63-14E157-CC.vbf	Jaguar XF (X260)	DADC - Driver Assistance Domain Controller	EXE
MX63-14E157-CF.vbf	Jaguar XF (X260)	DADC - Driver Assistance Domain Controller	EXE
MX63-14E157-CG.vbf	Jaguar XF (X260)	DADC - Driver Assistance Domain Controller	EXE
MX63-14F217-BB.vbf	Jaguar XF (X260)	RHVAC - Rear HVAC Control Module	EXE
MX63-14F217-BC.VBF	Jaguar XF (X260)	RHVAC - Rear HVAC Control Module	EXE
MX63-14F217-BD.vbf	Jaguar XF (X260)	RHVAC - Rear HVAC Control Module	EXE
MX63-14F219-BA.vbf	Jaguar XF (X260)	RHVAC - Rear HVAC Control Module	SBL
MX63-14F230-AA.vbf	Jaguar XF (X260)	HUD - Head Up Display	EXE
MX63-14F231-AA.vbf	Jaguar XF (X260)	HUD - Head Up Display	DATA
MX63-14F398-AB.vbf	Jaguar XF (X260)	IPMA - Image Processing Module A	EXE
MX63-14F398-AC.vbf	Jaguar XF (X260)	IPMA - Image Processing Module A	EXE
MX63-14F398-AE.vbf	Jaguar XF (X260)	IPMA - Image Processing Module A	EXE
MX63-14F398-AF.vbf	Jaguar XF (X260)	IPMA - Image Processing Module A	EXE
MX63-18D620-AB.vbf	Jaguar XF (X260)	HVAC - HVAC Control Module	DATA
MX63-18D620-BB.vbf	Jaguar XF (X260)	HVAC - HVAC Control Module	DATA
MX63-19C273-AC.vbf	Jaguar XF (X260)	IDMA - Interactive Display Module 'A'	EXE
MX63-19C273-AE.vbf	Jaguar XF (X260)	IDMA - Interactive Display Module 'A'	EXE
MX63-19C274-AC.vbf	Jaguar XF (X260)	IDMA - Interactive Display Module 'A'	EXE
MX63-19C274-AD.vbf	Jaguar XF (X260)	IDMA - Interactive Display Module 'A'	DATA
MX63-19C275-AC.vbf	Jaguar XF (X260)	LPDM - Left Power Sliding Door Module	SBL
MX63-19C275-AD.vbf	Jaguar XF (X260)	LPDM - Left Power Sliding Door Module	SBL
MX63-19J244-GA.vbf	Jaguar XF (X260)	NFSM	DATA
MX63-19J244-GB.vbf	Jaguar XF (X260)	NFSM	DATA
MX63-19J244-GC.vbf	Jaguar XF (X260)	NFSM	DATA
MX63-19J244-HA.vbf	Jaguar XF (X260)	NFSM	DATA
MX63-19J244-HB.vbf	Jaguar XF (X260)	NFSM	DATA
MX63-19J244-HC.vbf	Jaguar XF (X260)	NFSM	DATA
MX63-19J244-JA.vbf	Jaguar XF (X260)	NFSM	DATA

File name	Vehicle line (indicative)	Module (ECU)	Type
MX63-19J244-JB.vbf	Jaguar XF (X260)	NFSM	DATA
MX63-19J244-JC.vbf	Jaguar XF (X260)	NFSM	DATA
MX63-19J244-KA.vbf	Jaguar XF (X260)	NFSM	DATA
MX63-19J244-KB.vbf	Jaguar XF (X260)	NFSM	DATA
MX63-19J244-KC.vbf	Jaguar XF (X260)	NFSM	DATA
MX63-19J504-AA.vbf	Jaguar XF (X260)	NFSM	DATA
MX63-19J504-AB.vbf	Jaguar XF (X260)	NFSM	DATA
MX63-19J504-BA.vbf	Jaguar XF (X260)	NFSM	DATA
MX63-19J504-BB.vbf	Jaguar XF (X260)	NFSM	DATA
MX63-19J504-CB.vbf	Jaguar XF (X260)	NFSM	DATA
MX63-19J504-DB.vbf	Jaguar XF (X260)	NFSM	DATA
MX63-7J104-DFA.vbf	Jaguar XF (X260)	TCM - Transmission Control Module	EXE
MX63-7J104-DFB.vbf	Jaguar XF (X260)	TCM - Transmission Control Module	EXE
MX63-7J104-DFC.vbf	Jaguar XF (X260)	TCM - Transmission Control Module	EXE
MX63-7J104-DUA.vbf	Jaguar XF (X260)	TCM - Transmission Control Module	EXE
MX63-7J104-DUB.vbf	Jaguar XF (X260)	TCM - Transmission Control Module	EXE
MX63-7J104-DUC.vbf	Jaguar XF (X260)	TCM - Transmission Control Module	EXE
MX63-7J104-DVA.vbf	Jaguar XF (X260)	TCM - Transmission Control Module	EXE
MX63-7J104-DVB.vbf	Jaguar XF (X260)	TCM - Transmission Control Module	EXE
MX63-7J104-DVC.vbf	Jaguar XF (X260)	TCM - Transmission Control Module	EXE
MX63-7J104-GLA.vbf	Jaguar XF (X260)	TCM - Transmission Control Module	EXE
MX63-7J104-GLC.vbf	Jaguar XF (X260)	TCM - Transmission Control Module	EXE
MX63-7J104-GMB.vbf	Jaguar XF (X260)	TCM - Transmission Control Module	EXE
MX63-7J104-GUB.vbf	Jaguar XF (X260)	TCM - Transmission Control Module	EXE
MX63-7J104-GVA.vbf	Jaguar XF (X260)	TCM - Transmission Control Module	EXE
MX63-7J104-GVB.vbf	Jaguar XF (X260)	TCM - Transmission Control Module	EXE
MX63-7J104-GVC.vbf	Jaguar XF (X260)	TCM - Transmission Control Module	EXE
MX73-12K532-VAA.vbf	Jaguar XE (X760)	PCM - Powertrain Control Module	EXE
MX73-12K532-VAB.vbf	Jaguar XE (X760)	PCM - Powertrain Control Module	EXE
MX73-12K532-VAE.vbf	Jaguar XE (X760)	PCM - Powertrain Control Module	EXE
MX73-12K532-VEE.vbf	Jaguar XE (X760)	PCM - Powertrain Control Module	EXE
MX73-12K532-VGA.vbf	Jaguar XE (X760)	PCM - Powertrain Control Module	EXE
MX73-12K532-VGB.vbf	Jaguar XE (X760)	PCM - Powertrain Control Module	EXE
MX73-12K532-VGE.vbf	Jaguar XE (X760)	PCM - Powertrain Control Module	EXE
MX73-12K532-VHA.vbf	Jaguar XE (X760)	PCM - Powertrain Control Module	EXE
MX73-12K532-VHB.vbf	Jaguar XE (X760)	PCM - Powertrain Control Module	EXE
MX73-14C025-AB.vbf	Jaguar XE (X760)	IPC - Instrument Panel Cluster (IPC) Control Module	SBL
MX73-14C026-AB.vbf	Jaguar XE (X760)	IPC - Instrument Panel Cluster (IPC) Control Module	EXE
MX73-14C026-AC.vbf	Jaguar XE (X760)	IPC - Instrument Panel Cluster (IPC) Control Module	EXE
MX73-14C034-AC.vbf	Jaguar XE (X760)	DSM - Driver Front Seat Module	DATA
MX73-14C034-AE.vbf	Jaguar XE (X760)	DSM - Driver Front Seat Module	DATA
MX73-14C037-AAD.vbf	Jaguar XE (X760)	ABS - Anti-Lock Brake System Control Module	DATA
MX73-14C037-ACD.vbf	Jaguar XE (X760)	ABS - Anti-Lock Brake System Control Module	DATA
MX73-14C037-ADD.vbf	Jaguar XE (X760)	ABS - Anti-Lock Brake System Control Module	DATA
MX73-14C037-AED.vbf	Jaguar XE (X760)	ABS - Anti-Lock Brake System Control Module	DATA
MX73-14C037-AFD.vbf	Jaguar XE (X760)	ABS - Anti-Lock Brake System Control Module	DATA
MX73-14C037-AGD.vbf	Jaguar XE (X760)	ABS - Anti-Lock Brake System Control Module	DATA
MX73-14C037-AHD.vbf	Jaguar XE (X760)	ABS - Anti-Lock Brake System Control Module	DATA
MX73-14C037-AJD.vbf	Jaguar XE (X760)	ABS - Anti-Lock Brake System Control Module	DATA
MX73-14C037-AND.vbf	Jaguar XE (X760)	ABS - Anti-Lock Brake System Control Module	DATA
MX73-14C037-APD.vbf	Jaguar XE (X760)	ABS - Anti-Lock Brake System Control Module	DATA
MX73-14C037-ARD.vbf	Jaguar XE (X760)	ABS - Anti-Lock Brake System Control Module	DATA
MX73-14C037-ASD.vbf	Jaguar XE (X760)	ABS - Anti-Lock Brake System Control Module	DATA
MX73-14C037-ATD.vbf	Jaguar XE (X760)	ABS - Anti-Lock Brake System Control Module	DATA
MX73-14C037-AUD.vbf	Jaguar XE (X760)	ABS - Anti-Lock Brake System Control Module	DATA
MX73-14C037-AVD.vbf	Jaguar XE (X760)	ABS - Anti-Lock Brake System Control Module	DATA
MX73-14C037-AXD.vbf	Jaguar XE (X760)	ABS - Anti-Lock Brake System Control Module	DATA
MX73-14C037-AYD.vbf	Jaguar XE (X760)	ABS - Anti-Lock Brake System Control Module	DATA
MX73-14C037-AZD.vbf	Jaguar XE (X760)	ABS - Anti-Lock Brake System Control Module	DATA
MX73-14C065-AB.vbf	Jaguar XE (X760)	DDM - Driver Front Door Module	DATA
MX73-14C065-AD.vbf	Jaguar XE (X760)	DDM - Driver Front Door Module	DATA
MX73-14C069-AB.vbf	Jaguar XE (X760)	DRDM - Driver Rear Door Module	DATA
MX73-14C069-AD.vbf	Jaguar XE (X760)	DRDM - Driver Rear Door Module	DATA
MX73-14C085-AA.vbf	Jaguar XE (X760)	HCM - Headlamp Control Module #1	DATA
MX73-14C085-AB.vbf	Jaguar XE (X760)	HCM - Headlamp Control Module #1	DATA
MX73-14C085-AC.vbf	Jaguar XE (X760)	HCM - Headlamp Control Module #1	DATA
MX73-14C085-BA.vbf	Jaguar XE (X760)	Not specified	DATA
MX73-14C085-BB.vbf	Jaguar XE (X760)	Not specified	DATA
MX73-14C085-BC.vbf	Jaguar XE (X760)	Not specified	DATA
MX73-14C088-BB.vbf	Jaguar XE (X760)	IPC - Instrument Panel Cluster (IPC) Control Module	EXE
MX73-14C088-BC.vbf	Jaguar XE (X760)	IPC - Instrument Panel Cluster (IPC) Control Module	EXE
MX73-14C088-CB.vbf	Jaguar XE (X760)	IPC - Instrument Panel Cluster (IPC) Control Module	EXE
MX73-14C088-CC.vbf	Jaguar XE (X760)	IPC - Instrument Panel Cluster (IPC) Control Module	EXE
MX73-14C088-DB.vbf	Jaguar XE (X760)	IPC - Instrument Panel Cluster (IPC) Control Module	EXE
MX73-14C088-EC.vbf	Jaguar XE (X760)	IPC - Instrument Panel Cluster (IPC) Control Module	EXE
MX73-14C088-ED.vbf	Jaguar XE (X760)	IPC - Instrument Panel Cluster (IPC) Control Module	EXE

File name	Vehicle line (indicative)	Module (ECU)	Type
MX73-14C088-FB.vbf	Jaguar XE (X760)	IPC - Instrument Panel Cluster (IPC) Control Module	EXE
MX73-14C088-FC.vbf	Jaguar XE (X760)	IPC - Instrument Panel Cluster (IPC) Control Module	EXE
MX73-14C088-GB.vbf	Jaguar XE (X760)	IPC - Instrument Panel Cluster (IPC) Control Module	EXE
MX73-14C088-GC.vbf	Jaguar XE (X760)	IPC - Instrument Panel Cluster (IPC) Control Module	EXE
MX73-14C098-AC.vbf	Jaguar XE (X760)	RCM - Restraints Control Module	DATA
MX73-14C098-AD.vbf	Jaguar XE (X760)	RCM - Restraints Control Module	DATA
MX73-14C098-AE.vbf	Jaguar XE (X760)	RCM - Restraints Control Module	DATA
MX73-14C098-AF.vbf	Jaguar XE (X760)	RCM - Restraints Control Module	DATA
MX73-14C098-CA.vbf	Jaguar XE (X760)	RCM - Restraints Control Module	DATA
MX73-14C098-CB.vbf	Jaguar XE (X760)	RCM - Restraints Control Module	DATA
MX73-14C098-CC.vbf	Jaguar XE (X760)	RCM - Restraints Control Module	DATA
MX73-14C098-DA.vbf	Jaguar XE (X760)	RCM - Restraints Control Module	DATA
MX73-14C098-DB.vbf	Jaguar XE (X760)	RCM - Restraints Control Module	DATA
MX73-14C098-DD.vbf	Jaguar XE (X760)	RCM - Restraints Control Module	DATA
MX73-14C109-AB.vbf	Jaguar XE (X760)	PDM - Passenger Front Door Module	DATA
MX73-14C109-AD.vbf	Jaguar XE (X760)	PDM - Passenger Front Door Module	DATA
MX73-14C113-AB.vbf	Jaguar XE (X760)	PRDM - Passenger Rear Door Module	DATA
MX73-14C113-AD.vbf	Jaguar XE (X760)	PRDM - Passenger Rear Door Module	DATA
MX73-14C121-AA.vbf	Jaguar XE (X760)	RGTM - Rear Gate / Trunk Module	EXE
MX73-14C122-AA.vbf	Jaguar XE (X760)	RGTM - Rear Gate / Trunk Module	DATA
MX73-14C124-AA.vbf	Jaguar XE (X760)	RGTM - Rear Gate / Trunk Module	SBL
MX73-14C152-AB.vbf	Jaguar XE (X760)	TPM - Tire Pressure Monitor Module	DATA
MX73-14C185-AA.vbf	Jaguar XE (X760)	BCM - Body Control Module	DATA
MX73-14C185-AB.vbf	Jaguar XE (X760)	BCM - Body Control Module	DATA
MX73-14C185-AD.vbf	Jaguar XE (X760)	BCM - Body Control Module	DATA
MX73-14C433-AA.vbf	Jaguar XE (X760)	RGTM - Rear Gate / Trunk Module	SIGCFG
MX73-14C526-AG.vbf	Jaguar XE (X760)	AAM - Audio Amplifier Module	EXE
MX73-14C526-AH.vbf	Jaguar XE (X760)	AAM - Audio Amplifier Module	EXE
MX73-14C526-BA.vbf	Jaguar XE (X760)	AAM - Audio Amplifier Module	EXE
MX73-14C526-CA.vbf	Jaguar XE (X760)	AAM - Audio Amplifier Module	EXE
MX73-14C526-DA.vbf	Jaguar XE (X760)	AAM - Audio Amplifier Module	EXE
MX73-14C527-AAD.vbf	Jaguar XE (X760)	AAM - Audio Amplifier Module	DATA
MX73-14C527-AAE.vbf	Jaguar XE (X760)	AAM - Audio Amplifier Module	DATA
MX73-14C527-AD.vbf	Jaguar XE (X760)	AAM - Audio Amplifier Module	DATA
MX73-14C527-AE.vbf	Jaguar XE (X760)	AAM - Audio Amplifier Module	DATA
MX73-14C527-CAD.vbf	Jaguar XE (X760)	AAM - Audio Amplifier Module	DATA
MX73-14C527-CAE.vbf	Jaguar XE (X760)	AAM - Audio Amplifier Module	DATA
MX73-14C527-CD.vbf	Jaguar XE (X760)	AAM - Audio Amplifier Module	DATA
MX73-14C527-CE.vbf	Jaguar XE (X760)	AAM - Audio Amplifier Module	DATA
MX73-14C527-DAD.vbf	Jaguar XE (X760)	AAM - Audio Amplifier Module	DATA
MX73-14C527-DAE.vbf	Jaguar XE (X760)	AAM - Audio Amplifier Module	DATA
MX73-14C527-DD.vbf	Jaguar XE (X760)	AAM - Audio Amplifier Module	DATA
MX73-14C527-DE.vbf	Jaguar XE (X760)	AAM - Audio Amplifier Module	DATA
MX73-14C527-ZD.vbf	Jaguar XE (X760)	AAM - Audio Amplifier Module	DATA
MX73-14C527-ZE.vbf	Jaguar XE (X760)	AAM - Audio Amplifier Module	DATA
MX73-14C570-BAA.vbf	Jaguar XE (X760)	PCM - Powertrain Control Module	EXE
MX73-14C570-BEA.vbf	Jaguar XE (X760)	PCM - Powertrain Control Module	EXE
MX73-14C570-BFA.vbf	Jaguar XE (X760)	PCM - Powertrain Control Module	EXE
MX73-14C570-BGA.vbf	Jaguar XE (X760)	PCM - Powertrain Control Module	EXE
MX73-14C570-BGB.vbf	Jaguar XE (X760)	PCM - Powertrain Control Module	EXE
MX73-14C570-BHA.vbf	Jaguar XE (X760)	PCM - Powertrain Control Module	EXE
MX73-14C570-BHB.vbf	Jaguar XE (X760)	PCM - Powertrain Control Module	EXE
MX73-14C570-BRA.vbf	Jaguar XE (X760)	PCM - Powertrain Control Module	EXE
MX73-14C570-BRB.vbf	Jaguar XE (X760)	PCM - Powertrain Control Module	EXE
MX73-14C570-BUA.vbf	Jaguar XE (X760)	PCM - Powertrain Control Module	EXE
MX73-14C570-MPB.vbf	Jaguar XE (X760)	PCM - Powertrain Control Module	EXE
MX73-14D023-AA.vbf	Jaguar XE (X760)	ATCM - All Terrain Control Module	SIGCFG
MX73-14D024-AA.vbf	Jaguar XE (X760)	ATCM - All Terrain Control Module	EXE
MX73-14D026-AA.vbf	Jaguar XE (X760)	ATCM - All Terrain Control Module	SBL
MX73-14D183-BA.vbf	Jaguar XE (X760)	OCS - Restraints Occupant Classification System Module	DATA
MX73-14D564-AA.vbf	Jaguar XE (X760)	SODR - Side Obstacle Detection Control Module - Right	DATA
MX73-14D564-AB.vbf	Jaguar XE (X760)	SODR - Side Obstacle Detection Control Module - Right	DATA
MX73-14E094-GAA.vbf	Jaguar XE (X760)	CHCM - Chassis Control Module	EXE
MX73-14E094-GAB.vbf	Jaguar XE (X760)	CHCM - Chassis Control Module	EXE
MX73-14E094-GAC.vbf	Jaguar XE (X760)	CHCM - Chassis Control Module	EXE
MX73-14E094-GBA.vbf	Jaguar XE (X760)	CHCM - Chassis Control Module	EXE
MX73-14E094-GBB.vbf	Jaguar XE (X760)	CHCM - Chassis Control Module	EXE
MX73-14E094-GBC.vbf	Jaguar XE (X760)	CHCM - Chassis Control Module	EXE
MX73-14E094-GCA.vbf	Jaguar XE (X760)	CHCM - Chassis Control Module	EXE
MX73-14E094-GCB.vbf	Jaguar XE (X760)	CHCM - Chassis Control Module	EXE
MX73-14E094-GCC.vbf	Jaguar XE (X760)	CHCM - Chassis Control Module	EXE
MX73-14E157-AC.vbf	Jaguar XE (X760)	DADC - Driver Assistance Domain Controller	EXE
MX73-14E157-AD.vbf	Jaguar XE (X760)	DADC - Driver Assistance Domain Controller	EXE
MX73-14E157-AG.vbf	Jaguar XE (X760)	DADC - Driver Assistance Domain Controller	EXE
MX73-14E157-AH.vbf	Jaguar XE (X760)	DADC - Driver Assistance Domain Controller	EXE
MX73-14F230-AA.vbf	Jaguar XE (X760)	HUD - Head Up Display	EXE

File name	Vehicle line (indicative)	Module (ECU)	Type
MX73-14F231-AA.vbf	Jaguar XE (X760)	HUD - Head Up Display	DATA
MX73-14F398-AB.vbf	Jaguar XE (X760)	IPMA - Image Processing Module A	EXE
MX73-14F398-AC.vbf	Jaguar XE (X760)	IPMA - Image Processing Module A	EXE
MX73-14F398-AE.vbf	Jaguar XE (X760)	IPMA - Image Processing Module A	EXE
MX73-14F398-AF.vbf	Jaguar XE (X760)	IPMA - Image Processing Module A	EXE
MX73-14F531-AA.vbf	Jaguar XE (X760)	GWM - Gateway Module A	DATA
MX73-14F531-AB.vbf	Jaguar XE (X760)	GWM - Gateway Module A	DATA
MX73-18D620-AA.vbf	Jaguar XE (X760)	HVAC - HVAC Control Module	DATA
MX73-18D620-AB.vbf	Jaguar XE (X760)	HVAC - HVAC Control Module	DATA
MX73-18D620-AD.vbf	Jaguar XE (X760)	HVAC - HVAC Control Module	DATA
MX73-18D620-BA.vbf	Jaguar XE (X760)	HVAC - HVAC Control Module	DATA
MX73-18D620-BB.vbf	Jaguar XE (X760)	HVAC - HVAC Control Module	DATA
MX73-18D620-BD.vbf	Jaguar XE (X760)	HVAC - HVAC Control Module	DATA
MX73-19C274-AA.vbf	Jaguar XE (X760)	LPDM - Left Power Sliding Door Module	DATA
MX73-19J244-DA.vbf	Jaguar XE (X760)	NFSM	DATA
MX73-19J244-DB.vbf	Jaguar XE (X760)	NFSM	DATA
MX73-19J244-DC.vbf	Jaguar XE (X760)	NFSM	DATA
MX73-19J244-EA.vbf	Jaguar XE (X760)	NFSM	DATA
MX73-19J244-EB.vbf	Jaguar XE (X760)	NFSM	DATA
MX73-19J244-EC.vbf	Jaguar XE (X760)	NFSM	DATA
MX73-19J504-AA.vbf	Jaguar XE (X760)	NFSM	DATA
MX73-19J504-AB.vbf	Jaguar XE (X760)	NFSM	DATA
MX73-19J504-BB.vbf	Jaguar XE (X760)	NFSM	DATA
MX73-7J104-DFA.vbf	Jaguar XE (X760)	TCM - Transmission Control Module	EXE
MX73-7J104-DFB.vbf	Jaguar XE (X760)	TCM - Transmission Control Module	EXE
MX73-7J104-DUA.vbf	Jaguar XE (X760)	TCM - Transmission Control Module	EXE
MX73-7J104-DUB.vbf	Jaguar XE (X760)	TCM - Transmission Control Module	EXE
MX73-7J104-DUC.vbf	Jaguar XE (X760)	TCM - Transmission Control Module	EXE
MX73-7J104-DVA.vbf	Jaguar XE (X760)	TCM - Transmission Control Module	EXE
MX73-7J104-DVB.vbf	Jaguar XE (X760)	TCM - Transmission Control Module	EXE
MX73-7J104-DVC.vbf	Jaguar XE (X760)	TCM - Transmission Control Module	EXE
MX73-7J104-GBB.vbf	Jaguar XE (X760)	TCM - Transmission Control Module	EXE
MX73-7J104-GLA.vbf	Jaguar XE (X760)	TCM - Transmission Control Module	EXE
MX73-7J104-GLB.vbf	Jaguar XE (X760)	TCM - Transmission Control Module	EXE
MX73-7J104-GLC.vbf	Jaguar XE (X760)	TCM - Transmission Control Module	EXE
MX73-7J104-GMA.vbf	Jaguar XE (X760)	TCM - Transmission Control Module	EXE
MX73-7J104-GMB.vbf	Jaguar XE (X760)	TCM - Transmission Control Module	EXE
MX73-7J104-GUA.vbf	Jaguar XE (X760)	TCM - Transmission Control Module	EXE
MX73-7J104-GVA.vbf	Jaguar XE (X760)	TCM - Transmission Control Module	EXE
MX73-7J104-GVB.vbf	Jaguar XE (X760)	TCM - Transmission Control Module	EXE
NNB500420.vbf	Not specified	ACM - Low line head Unit / Integrated MOST head unit	GBL
NNS00394.2DF	Not specified	-	-
NNS50189.0DF	Not specified	-	-
NNS50190.0DF	Not specified	-	-
NNS50191.0DF	Not specified	-	-
NNS50192.0DF	Not specified	-	-
NNS50193.0DF	Not specified	-	-
NNS50194.0DF	Not specified	-	-
NNS50195.0DF	Not specified	-	-
NNS50209.0DF	Not specified	-	-
NNS50243.0DF	Not specified	-	-
NNV50040.0PF	Not specified	-	-
NNV50097.0PF	Not specified	-	-
NNV50294.0PF	Not specified	-	-
UH42-14D419-AC.vbf	Range Rover III (L322)	TVM - TV Module	EXE
VBFParser11.xsl	Not specified	-	-
VBFParser20.xsl	Not specified	-	-
X150_FSJB_CCF.vbf	Not specified	FSJB - Front Smart Junction Box	CARCFG
X150_ICM_GBL.vbf	Not specified	ICM - Infotainment Control Module	GBL
X150_PCM_PETROL_CCF...	Not specified	PCM - Powertrain Control Module (Petrol)	CARCFG
X150_RSJB_CCF.vbf	Not specified	RSJB - Rear Smart Junction Box	CARCFG
X152_201400_BCM_CCF.vbf	Not specified	BCM - Body control module	CARCFG
X152_201400_GWM_CCF....	Not specified	GWM - Gateway module	CARCFG
X152_201600_BCM_CCF.vbf	Not specified	BCM - Body control module	CARCFG
X152_201600_GWM_CCF....	Not specified	GWM - Gateway module	CARCFG
X250-ICM-GBL.VBF	Not specified	ICM - Infotainment Control Module	GBL
X25010_PCM_DIESEL_CC...	Not specified	PCM - Powertrain Control Module (Diesel)	CARCFG
X25012_PCM_I4DIESEL_C...	Not specified	PCM - Powertrain Control Module (Diesel)	CARCFG
X250_FSJB_CCF.vbf	Not specified	FSJB - Front Smart Junction Box	CARCFG
X250_ICM_GBL.vbf	Not specified	ICM - Infotainment Control Module	GBL
X250_PCM_DIESEL_CCF....	Not specified	PCM - Powertrain Control Module (Petrol)	CARCFG
X250_PCM_PETROL_CCF...	Not specified	PCM - Powertrain Control Module (Petrol)	CARCFG
X250_RSJB_CCF.vbf	Not specified	RSJB - Rear Smart Junction Box	CARCFG
X260_201600_BCM_CCF.vbf	Not specified	BCM - Body control module	CARCFG
X260_201600_GWM_CCF....	Not specified	GWM - Gateway module	CARCFG
X351_201000_BCM_CCF.vbf	Not specified	BCM - Body control module	CARCFG

File name	Vehicle line (indicative)	Module (ECU)	Type
X351_201000_PCM_DIES...	Not specified	PCM - Powertrain Control Module (Diesel)	CARCFG
X351_201000_PCM_PETR...	Not specified	PCM - Powertrain Control Module (Petrol)	CARCFG
X351_201300_GWM_CCF....	Not specified	GWM - Gateway module	CARCFG
X351_201600_BCM_CCF.vbf	Not specified	BCM - Body control module	CARCFG
X351_201600_GWM_CCF....	Not specified	GWM - Gateway module	CARCFG
X760_201600_BCM_CCF.vbf	Not specified	BCM - Body control module	CARCFG
X760_201600_GWM_CCF....	Not specified	GWM - Gateway module	CARCFG
X760_201700_BCM_CCF.vbf	Not specified	BCM - Body control module	CARCFG
X760_201700_GWM_CCF....	Not specified	GWM - Gateway module	CARCFG
X761_201700_BCM_CCF.vbf	Not specified	BCM - Body control module	CARCFG
X761_201700_GWM_CCF....	Not specified	GWM - Gateway module	CARCFG